

FOCUSED ION BEAM (FIB)

Measure: products scattered from C/SiC or SiC or similar samples; vary: impact temperatures and species, target material, microstructure, etc.; use: finite-rate oxidation model closure and validation; models: corresponding MD simulations, 0D closure of GSI reaction kinetics; status: shared-use FIBs at Illinois, experience using FIB with MD simulations and continuum modeling.





FURNACE: FLOW

Measure: interface mass spectroscopy of products, PLIF; vary: materials (graphite, PAN carbon fibers, C/SiC, SiC, ...), temperature, pressure, gas (O₂, H₂, H₂O, air, CO₂, C₂H₄, etc.); use: quantify passive structural degradation (SEM, EDX, XRD microscopy); models: 1D surface evolution transport and kinetics; status: furnaces and mass spectrometers on campus (MRL), experience in team with measurements and model closure.



FURNACE: STRESS



Measure: oxidation rate, O distribution with atom-probe tomography (APT), geometric evolution, strength, stress-coupling; vary: materials (graphite, PAN carbon fibers, C/SiC, SiC, ...), temperature, pressure, gas (O₂, H₂, H₂O, air, CO₂, C₂H₄, etc.); use: quantify passive strength degradation; models: 1D surface oxidation and strength coupling; status: furnaces with stress-strain capabilities on campus (MRL), experience in team with measurements and



PLASMATRON ABLATION



model closure.

measure: in-situ PLIF of near-surface reactants and products; vary: materials, temperature, pressure, gases; use: quantify structural degradation under extreme aerothermal conditions simulating combustor flow conditions; models: 1D/2D-axi surface evolution with flow; status: PI with experience from NASA Ames, extensive PLIF systems available at Illinois, anticipated plasmatron ready on-site early 2020.



Laser Ablation



Measure: ultrafast diagnostics of transient products; vary: target material, temperature, pressure, gases; use: transient response validation; models: 1D/2D-axi surface transport/kinetics models; status: experience with fs diagnostics and laser methods, especially laser-induced breakdown (LIB).




JET MIXING, IGNITION AND PROPAGATION



Measure: mixing & evolution of ignition kernel with emission spectroscopy, PLIF; vary: fuels, flow conditions; use: validation for mixing, combustion kinetics, ignition; models: 2D-axi or 3D jet combustion simulations (short time for TIK); status: based on current LIB and transient ignition kernel (TIK) configurations and corresponding models; variant: add axisymmetric flame holder for predicting flame-holding limits.



FLEXIBLE/ROUGH SURFACE SUPERSONIC WIND TUNNEL



Measure: wall deflection and T, PIV, FLEET, high-speed schlieren; vary: flow conditions, materials, material roughness; use: mechanical models, flow-structure interaction models; models: 2D analog; 3D for simple geometry turbulence studies; status: on-campus wind tunnels with flow and surface measurement diagnostics operated by the PIs.

