

# Aviation Event Statistics Manual

**IO-Aero Team** 

1	Gene	eral Documentation	1
	1.1	Introduction	
	1.2	Requirements	. 1
	1.3	Installation	
	1.4	Configuration IO-AVSTATS	. 4
	1.5	Configuration Logging	
	1.6	First Steps	. 7
	1.7	Advanced Usage	
	1.8	Data Sources	
	1.9	PostgreSQL Administration	26
2	Mast	er Data Logs	29
3	Trans	saction Data Logs	31
4	API 1	Documentation	33
	4.1	ioavstats	33
5	Abou	ıt .	39
	5.1	Release Notes	
	5.2	End-User License Agreement	58
6	Indic	es and tables	61
	6.1	Repository	61
	6.2	Version	61
	Pyth	on Module Index	63
	Indo	v	65

# **General Documentation**

This section contains the core documentation for setting up and starting with IO-AVSTATS. It covers everything from installation to basic and advanced configurations.

# 1.1 Introduction

The Aviation Event Statistics (IO-AVSTATS) includes the following applications:

- ae1982 Aviation Event Analysis
- pd1982 IO-AVSTATS-DB Database Profiling
- slara Association Rule Analysis

# 1.2 Requirements

The required software is listed below. Regarding the corresponding software versions, you will find the detailed information in the Release Notes.

# 1.2.1 Operating System

Continuous delivery / integration (CD/CI) runs on macOS and Ubuntu and development is also done with Windows 10/11.

For the Windows operating systems, only additional the functionality of the make tool must be made available, e.g. via Make for Windows

The command-line shells supported are:

Operating system	Command-line shell(s)
macOS	zsh
Ubuntu	bash
Windows 10/11	cmd and PowerShell

For macOS and Ubuntu, the end-of-line character and the execution authorization may need to be adjusted for the shell scripts. If the dos2Unix program is installed, the necessary adjustments can be made using the scripts ./scripts/run\_prep\_zsh\_scripts.zsh (macOS) and ./scripts/run\_prep\_bash\_scripts.sh (Ubuntu).

# 1.2.2 Python

This project utilizes Python 3.10, which introduces significant enhancements in type hinting and type annotations. These improvements provide a more robust and clear definition of function parameters,

return types, and variable types, contributing to improved code readability and maintainability. The use of Python 3.10 ensures compatibility with these advanced typing features, offering a more structured and error-resistant development environment.

# 1.2.3 Docker Desktop

The project employs PostgreSQL for data storage and leverages Docker images provided by PostgreSQL to simplify the installation process. Docker Desktop is used for its ease of managing and running containerized applications, allowing for a consistent and isolated environment for PostgreSQL. This approach streamlines the setup, ensuring that the database environment is quickly replicable and maintainable across different development setups.

# 1.2.4 MS Access Database Engine- only for Windows

This Software consists of a set of components that facilitate the transfer of data between existing Microsoft Office files such as Microsoft Office Access (\*.mdb and \*.accdb) files and Microsoft Office Excel (\*.xls, \*.xlsx, and \*.xlsb) files to other data sources. Connectivity to existing text files is also supported.

# 1.2.5 DBeaver Community - optional

DBeaver is recommended as the user interface for interacting with the PostgreSQL database due to its comprehensive and user-friendly features. It provides a flexible and intuitive platform for database management, supporting a wide range of database functionalities including SQL scripting, data visualization, and import/export capabilities. Additionally, the project includes predefined connection configurations for DBeaver, facilitating a hassle-free and streamlined setup process for users.

#### 1.3 Installation

# 1.3.1 Python

The project repository contains a scripts directory that includes operating system-specific installation scripts for Python, ensuring a smooth setup across various environments.

- macOS: The run\_install\_python.zsh script is available for macOS users. This script is adapted for the Zsh shell, which is the standard shell on recent versions of macOS, and it streamlines the Python installation.
- **Ubuntu**: For users on Ubuntu, the run\_install\_python.sh script is provided. This Bash script is created to operate within the default shell environment of Ubuntu, facilitating the Python installation process.
- Windows: The run\_install\_python.bat script is tailored for users on Windows systems. It is designed to be run in the Command Prompt and automates the Python installation process on Windows.

These scripts are named according to the convention run\_install\_python.<ext>, where <ext> corresponds to the script extension appropriate for the target operating system and shell environment (e.g., .bat for Windows, .sh for Ubuntu Bash, .zsh for macOS). Users are recommended to execute the script matching their OS to ensure an efficient Python setup.

#### 1.3.2 Miniconda

The scripts directory includes a collection of operating system-specific scripts named run\_install\_miniconda to streamline the installation of Miniconda. These scripts are designed to cater to the needs of different environments, making the setup process efficient and user-friendly.

• Windows CMD Shell: The run\_install\_miniconda.bat script is tailored for the Windows CMD shell. It automates the Miniconda installation process on Windows, providing a hassle-free

setup with a simple double-click or command line execution.

- **Ubuntu Bash Shell**: Ubuntu users can take advantage of the run\_install\_miniconda.sh script. This Bash script is intended for use within the Ubuntu terminal, encapsulating the necessary commands to install Miniconda seamlessly on Ubuntu systems.
- macOS Zsh Shell: For macOS, the run\_install\_miniconda.zsh script is available. It is optimized for the Zsh shell, which is the default on recent versions of macOS. This script simplifies the installation and configuration of Miniconda, ensuring a smooth integration with macOS.

Each script in the scripts directory is named to reflect its compatibility with the corresponding operating system and shell environment. Users are encouraged to execute the script that matches their OS for a smooth and error-free Miniconda installation experience.

## 1.3.3 Docker Desktop

The scripts directory contains scripts that assist with installing Docker Desktop on macOS and Ubuntu, facilitating an automated and streamlined setup.

- macOS: The run\_install\_docker.zsh script is designed for macOS users. By utilizing this Zsh script, the installation of Docker Desktop on macOS is executed through a series of automated steps, which are managed by the script to ensure a smooth installation process.
- **Ubuntu**: The run\_install\_docker.sh script is available for Ubuntu users. This Bash script sets up Docker Desktop on Ubuntu systems by configuring the necessary repositories and managing the installation steps through the system's package manager.
- Windows: For Windows users, it is recommended to download and install Docker Desktop using the traditional installer available at Docker Desktop for Windows. This approach guarantees the most stable version and is tailored to integrate seamlessly with Windows-specific features and configurations.

Please select and execute the appropriate script for your operating system from the scripts directory. Windows users should follow the provided link to obtain the official installer for a guided installation experience.

#### 1.3.4 MS Access Database Engine

- **Windows**: The software can be downloaded from here and then installed according to the instructions provided.
- **Ubuntu Bash Shell**: The necessary software can be downloaded with the package manager apt as follows:

```
sudo apt-get update -y
sudo apt-get install -y unixodbc-dev
```

• macOS Zsh Shell: The necessary software can be downloaded with the package manager Homebrew as follows:

```
brew update
brew install unixodbc
```

#### 1.3.5 DBeaver - optional

DBeaver is an optional but highly recommended tool for this software as it offers a user-friendly interface to gain insights into the database internals. The project provides convenient scripts for installing DBeaver on macOS and Ubuntu.

• macOS: The run\_install\_dbeaver.zsh script is crafted for macOS systems. By running this Zsh script, users can easily install DBeaver and quickly connect to the database for management

1.3. Installation 3

and querying tasks.

- **Ubuntu**: For Ubuntu users, the run\_install\_dbeaver.sh script facilitates the installation of DBeaver. This Bash script automates the setup process, adding necessary repositories and handling the installation seamlessly.
- Windows: Windows users are advised to download and install DBeaver using the official installer from the DBeaver website at DBeaver Download. The installer ensures that DBeaver is properly configured and optimized for Windows environments.

To install DBeaver, locate the appropriate script in the scripts directory for macOS or Ubuntu. If you're a Windows user, please use the provided link to access the official installer for an intuitive installation experience.

# 1.3.6 Python Libraries

The project's Python dependencies are managed partly through Conda and partly through pip. To facilitate a straightforward installation process, a Makefile is provided at the root of the project.

- Development Environment: Run the command make conda-dev from the terminal to set up a development environment. This will install the necessary Python libraries using Conda and pip as specified for development purposes.
- **Production Environment**: Execute the command make conda-prod for preparing a production environment. It ensures that all the required dependencies are installed following the configurations optimized for production deployment.

The Makefile targets abstract away the complexity of managing multiple package managers and streamline the environment setup. It is crucial to have both Conda and the appropriate pip tool available in your system's PATH to utilize the Makefile commands successfully.

# 1.4 Configuration IO-AVSTATS

For the administration of the configuration parameters of **IO-AVSTATS** the tool dynaconf is used. The file settings.io\_aero.toml is available as the configuration file. The names of **IO-AVSTATS** related environment variables must include the prefix IO\_AERO. Layered environments are supported. The test layer is used for the automated tests.

#### 1.4.1 Available Parameters

Parameter	Description
correction_work_dir	file directory containing the files with the manual corrections
database_commit_size	number of rows processed before a progress message is created
download_chunk_size	chunk size for download from the <b>NTSB</b> website
download_file_aviation_occurrence_categories	name of the file containing data of aviation occurrence categories
download_file_countries_states_json	name of the file containing data of countries and states
download_file_faa_airports_xlsx	name of the file containing data of airports
download_file_faa_npias	name of the file containing National Plan of Integrated Airport Systems
download_file_faa_runways_xlsx	name of the file containing data of runways

download_file_sequence_of_events  aname of the file containing data of sequence of events  simplemaps: name of the zipped US city file  download_file_simplemaps_us_zips_xlsx  download_file_simplemaps_us_zips_xlsx  code file  ZIP Code Database: name of the unzipped US zip code file  download_timeout  download_timeout  download_url_ntsb_prefix  download_work_dir  Prefix of the download link for the NTSB data sets  download_work_dir  NTSB data sets  is_runtime_environment_local  is_verbose  display progress messages for processing of NTSB data sets  max_deviation_longitude  max_deviation_longitude  dobc_connection_string  postgres_container_name  container name  postgres_container_name  postgres_container_name  postgres_dbhame  postgres_dbhame  postgres_adbhame  postgres_adbhame  postgres_password  database server hostname  database password  postgres_password  guest database username  postgres_password  postgres_password  guest database username  postgres_user_admin  postgres_user_admin  postgres_user_admin  postgres_version  razorsql_jar_file_windows  name of the zipped US city  file  simplemaps: name of the zipped US zip  code file  zimplemaps: name of the zipped US zip  code file  simplemaps: name of the zipped US zip  code file  ZIP Code Database: name of the unzipped  US zip code file  prefix of the download link for the NTSB  data sets  local execution environment of the Intile  processing of NTSB data sets  local execution environment of the Intile  processing of NTSB data sets  maximum decimal deviation of the latitude in the database table even  maximum decimal deviation of the longitude in the database table even  maximum decimal deviation of the longitude in the database table even  maximum decimal deviation of the longitude in the database connection string for the MS Access ODBC driver  driver  postgres_container_name  database schema name  database password  guest database password  guest database username  gostgres_user_admin  administration database username  postgres_user_domin  administration da	download_file_main_phases_of_flight	name of the file containing data of main
download_file_simplemaps_us_cities_xlsx  download_file_simplemaps_us_zips_xlsx  download_file_simplemaps_us_zips_xlsx  download_file_zip_codes_org_xls  download_file_zip_codes_org_xls  download_file_zip_codes_org_xls  download_timeout  download_timeout  download_url_ntsb_prefix  download_work_dir  prefix of the download link for the NTSB data sets  download_work_dir  procker  is_runtime_environment_local  local execution environment - unlike Docker  is_verbose  display progress messages for processing of NTSB data sets  local execution environment - unlike Docker  is_verbose  max_deviation_latitude  max_deviation_longitude  max_deviation_longitude  max_deviation_longitude  dobc_connection_string  postgres_connection_port  database port number  connection string for the MS Access ODBC database schema name  postgres_dbname  postgres_dbname  postgres_dbname  database schema name  database server hostname  database server hostname  database password  database password  gostgres_password_admin  postgres_password_admin  postgres_password_guest  postgres_password_guest  postgres_user  database username  postgres_password_guest  postgres_password  postgres_password_guest  postgres_user  database username  postgres_password_suest  postgres_user  database username  postgres_password  postgres_password  postgres_password  postgres_password  postgres_password  postgres_password  postgres_password_suest  postgres_user  database username  postgres_password  postgres		phases of a flight
download_file_simplemaps_us_cities_xisx file  download_file_simplemaps_us_zips_xlsx	download_file_sequence_of_events	
download_file_zin_codes_org_xls    ZIP Code Database: name of the unzipped US zip code file	download_file_simplemaps_us_cities_xlsx	
download_ine_zip_codes_org_xis  download_timeout  seconds to wait for the server to send data prefix of the download link for the NTSB data sets  download_work_dir  is_runtime_environment_local is_verbose  max_deviation_latitude  max_deviation_longitude  max_deviation_longitude  odbc_connection_string  postgres_container_name     postgres_dhame postgres_dhame postgres_dhame postgres_dhame postgres_dhame postgres_password postgres_password database server hostname database server hostname postgres_password_admin postgres_password_guest postgres_user_guest postgres_user_guest postgres_version  razorsql_jar_file_windows razorsql_prefite  tive file adabase schema postgres_User_andmin postgres_user_guest postgres_user_gate postgres_user_gate file postgres_version razorsql_prefite file directory of the database schema postgres_user_guest po	download_file_simplemaps_us_zips_xlsx	
download_url_ntsb_prefix  download_url_ntsb_prefix  download_work_dir  NTSB data sets    local execution environment - unlike Docker     is_runtime_environment_local     is_verbose   display progress messages for processing max_deviation_latitude   maximum decimal deviation of the latitude in the database table even     max_deviation_longitude   maximum decimal deviation of the longitude in the database table even     max_deviation_string   connection string for the MS Access ODBC driver     postgres_connection_port   database port number     postgres_container_name   container name     postgres_database_schema   database schema name     postgres_dbname   database server hostname     postgres_lobate   database password     postgres_password   database password     postgres_password_admin   administration database password     postgres_password_guest   guest database password     postgres_password_guest   guest database username     postgres_user_guest   guest database username	download_file_zip_codes_org_xls	
data sets  download_work_dir  working directory for the processing of NTSB data sets  local execution environment - unlike Docker  is_verbose  display progress messages for processing max_deviation_latitude  max_deviation_longitude  max_deviation_longitude  dobc_connection_string  postgres_connection_port  postgres_container_name  postgres_database_schema  postgres_database_schema  postgres_dbname  postgres_dbname  postgres_host  postgres_password  postgres_password  postgres_password_admin  postgres_password_guest  postgres_password  postgres_password  postgres_user_admin  postgres_user_guest  postgres_user_guest  postgres_version  razorsql_jar_file_windows  razorsql_profile  file directory of the database schema reference  file directory of the database schema reference  file directory of the database schema reference  file ame of the database schema reference	download_timeout	seconds to wait for the server to send data
is_runtime_environment_local is_verbose  max_deviation_latitude  max_deviation_longitude  max_deviation_string  postgres_connection_port postgres_dbname postgres_dbname postgres_dbname postgres_password postgres_password postgres_password_admin postgres_password_admin postgres_password_admin postgres_pgdata  postgres_pgdata  postgres_user_postgres_user_guest postgres_user_guest postgres_uer_glar_file_windows razorsql_jar_file_windows razorsql_jar_file_windows razorsql_prefirence_dir  postgres_dbrawe raximum decimal deviation of the longitude in the database table even connection string for the MS Access ODBC driver database table even connection string for the MS Access ODBC driver database port number container name container name database schema name database schema name database schema name database schema name database server hostname database password database password guest database password file directory on the host for the database files razorsql_far_file_windows name of the jar file (Windows version) name of the Java file (Windows version) name of the RazorSQL connection profile file directory of the database schema reference file file name of the database schema reference	download_url_ntsb_prefix	1 -
is_runtime_environment_local  is_verbose  display progress messages for processing  max_deviation_latitude  max_deviation_longitude  max_deviation_longitude  database table even  maximum decimal deviation of the latitude in the database table even  maximum decimal deviation of the longitude in the database table even  connection_string connection_string for the MS Access ODBC driver  postgres_connection_port database port number  container name  postgres_database_schema  postgres_database_schema database schema name  database name  postgres_dbname_admin administration database name  postgres_password  postgres_password  postgres_password_admin administration database password  postgres_password_guest guest database password  postgres_password_guest guest database username  postgres_user  postgres_user  database username  gostgres_user_admin administration database username  postgres_user_guest guest database username  postgres_totatabase password  file directory of the database schema reference file  file directory of the database schema reference	download_work_dir	
max_deviation_latitude  max_deviation_longitude  max_deviation_longitude  max_deviation_longitude  max_deviation_longitude  max_imum decimal deviation of the longitude in the database table even  connection string for the MS Access ODBC driver  postgres_connection_port  postgres_container_name  postgres_database_schema  postgres_database_schema  postgres_dbname  postgres_dbname  postgres_dbname  postgres_password  database ever hostname  postgres_password  postgres_password  postgres_password  postgres_password_admin  postgres_password_guest  postgres_password_guest  postgres_password  postgres_user  postgres_user  postgres_user  postgres_user  guest database password  file directory on the host for the database files  postgres_user_admin  postgres_user_admin  postgres_user_guest  guest database username  postgres_user_guest  guest database username  requested PostgreSQL version from DockerHub  razorsql_jar_file_windows  razorsql_java_path_windows  razorsql_java_path_windows  razorsql_freference_dir  file directory of the database schema reference  file directory of the database schema reference	is_runtime_environment_local	
max_deviation_longitude  max_deviation_longitude  max_deviation_longitude  maximum decimal deviation of the longitude in the database table even  connection string for the MS Access ODBC driver  postgres_connection_port  postgres_container_name  postgres_database_schema  postgres_dbname  postgres_dbname  postgres_dbname_admin  postgres_password  postgres_password  postgres_password_admin  postgres_password_admin  postgres_password_guest  postgres_password_guest  postgres_user  database username  requested PostgreSQL version from DockerHub  razorsql_jar_file_windows  name of the jar file (Windows version)  name of the Java file (Windows version)  name of the RazorSQL connection profile  file directory of the database schema reference  file directory of the database schema reference	is_verbose	display progress messages for processing
tude in the database table even  odbc_connection_string connection string for the MS Access ODBC driver  postgres_connection_port database port number  container name  postgres_database_schema database schema name  postgres_dbname database name  postgres_dbname_admin administration database name  postgres_password database server hostname  postgres_password guest guest database password  postgres_password_admin administration database password  postgres_password_guest guest database password  postgres_password_guest guest database password  postgres_user database username  postgres_user_admin administration database username  postgres_user_guest guest database username  postgres_version from DockerHub  razorsql_jar_file_windows  name of the jar file (Windows version)  name of the jar file (Windows version)  name of the RazorSQL connection profile  file directory of the database schema reference file  file directory of the database schema reference	max_deviation_latitude	
postgres_connection_port database port number  postgres_container_name container name  postgres_database_schema database schema name  postgres_dbname database name  postgres_dbname_admin administration database name  postgres_password database password  postgres_password_admin administration database password  postgres_password_guest guest database password  postgres_password_guest guest database password  postgres_password_guest guest database password  postgres_password_guest guest database username  postgres_user  postgres_user_admin administration database username  postgres_user_guest guest database username  postgres_user_guest guest database username  postgres_user_guest guest database username  postgres_version requested PostgreSQL version from DockerHub  razorsql_jar_file_windows name of the jar file (Windows version)  razorsql_profile name of the database schema reference file file directory of the database schema reference file	max_deviation_longitude	g .
postgres_container_name container name  postgres_database_schema database schema name  postgres_dbname database name  postgres_dbname_admin administration database name  postgres_host database password  postgres_password admin administration database password  postgres_password_admin administration database password  postgres_password_guest guest database password  postgres_password_guest file directory on the host for the database files  postgres_user database username  postgres_user_guest guest database username  postgres_user_guest guest database username  postgres_user_guest guest database username  requested PostgreSQL version from DockerHub  razorsql_jar_file_windows name of the jar file (Windows version)  razorsql_profile name of the RazorSQL connection profile  file directory of the database schema reference file  file name of the database schema reference	odbc_connection_string	_
postgres_container_name container name  postgres_database_schema database schema name  postgres_dbname database name  postgres_dbname_admin administration database name  postgres_host database password  postgres_password admin administration database password  postgres_password_admin administration database password  postgres_password_guest guest database password  postgres_password_guest file directory on the host for the database files  postgres_user database username  postgres_user_guest guest database username  postgres_user_guest guest database username  postgres_user_guest guest database username  requested PostgreSQL version from DockerHub  razorsql_jar_file_windows name of the jar file (Windows version)  razorsql_profile name of the RazorSQL connection profile  file directory of the database schema reference file  file name of the database schema reference	postgres_connection_port	database port number
postgres_dbname postgres_dbname_admin postgres_host database server hostname postgres_password postgres_password_admin postgres_password_admin postgres_password_admin postgres_password_guest guest database password file directory on the host for the database files postgres_user postgres_user_admin postgres_user_admin postgres_user_guest guest database username guest database username postgres_user_guest guest database username requested PostgreSQL version from DockerHub razorsql_jar_file_windows name of the jar file (Windows version) razorsql_profile name of the RazorSQL connection profile file directory of the database schema reference file file name of the database schema reference		container name
postgres_dbname_admin  postgres_host  database server hostname  database password  postgres_password_admin  postgres_password_admin  postgres_password_guest  postgres_password_guest  postgres_password_guest  postgres_password  postgres_password  postgres_password  postgres_password  file directory on the host for the database files  postgres_user  database username  postgres_user_admin  postgres_user_guest  guest database username  postgres_user_guest  guest database username  requested PostgreSQL version from DockerHub  razorsql_jar_file_windows  name of the jar file (Windows version)  razorsql_profile  name of the RazorSQL connection profile  file directory of the database schema reference file  file name of the database schema reference	postgres_database_schema	database schema name
postgres_host database server hostname postgres_password postgres_password_admin administration database password postgres_password_guest guest database password  postgres_pgdata file directory on the host for the database files  postgres_user database username postgres_user_admin administration database username postgres_user_guest guest database username  postgres_version requested PostgreSQL version from DockerHub  razorsql_jar_file_windows name of the jar file (Windows version) razorsql_java_path_windows name of the Java file (Windows version) razorsql_reference_dir file directory of the database schema reference file file name of the database schema reference	postgres_dbname	database name
postgres_password postgres_password_admin postgres_password_guest  postgres_password_guest  postgres_pgdata  postgres_pgdata  postgres_user  postgres_user_admin postgres_user_guest  postgres_user_guest  postgres_user_guest  postgres_version  razorsql_jar_file_windows razorsql_java_path_windows  razorsql_profile  razorsql_reference_dir  razorsql_reference_dir  razorsql_reference_file  diadabase password guest database password file directory on the host for the database files guest database username administration database username guest database username requested PostgreSQL version from DockerHub razorsql_jar_file_windows razorsql_java_path_windows razorsql_profile file directory of the Java file (Windows version) razorsql_reference_dir  file directory of the database schema reference file file name of the database schema reference	postgres_dbname_admin	administration database name
postgres_password_admin postgres_password_guest  postgres_password_guest  postgres_pgdata  postgres_pgdata  postgres_user  postgres_user_admin  postgres_user_guest  postgres_user_guest  postgres_version  postgres_version  razorsql_jar_file_windows  razorsql_java_path_windows  razorsql_profile  razorsql_reference_dir  postgres_user_side  guest database username  requested PostgreSQL version from DockerHub  name of the jar file (Windows version)  name of the Java file (Windows version)  file directory of the database schema reference file  file name of the database schema reference	postgres_host	database server hostname
postgres_password_guest  postgres_pgdata  file directory on the host for the database files  postgres_user  database username  postgres_user_admin  postgres_user_guest  guest database username  administration database username  postgres_user_guest  guest database username  requested PostgreSQL version from DockerHub  razorsql_jar_file_windows  name of the jar file (Windows version)  razorsql_java_path_windows  name of the Java file (Windows version)  razorsql_profile  razorsql_reference_dir  file directory of the database schema reference file  file name of the database schema reference	postgres_password	database password
postgres_pgdata  file directory on the host for the database files  postgres_user  database username  postgres_user_admin  postgres_user_guest  postgres_version  postgres_version  razorsql_jar_file_windows  razorsql_java_path_windows  razorsql_profile  razorsql_reference_dir  razorsql_reference_dir  file directory on the host for the database files  file directory on the host for the database files  file directory on the host for the database files  file directory on the host for the database schema reference files  file directory on the host for the database username  administration database username  requested PostgreSQL version from DockerHub  name of the jar file (Windows version)  name of the Java file (Windows version)  file directory of the database schema reference file  file name of the database schema reference	postgres_password_admin	administration database password
postgres_user database username postgres_user_admin administration database username postgres_user_guest guest database username  postgres_version requested PostgreSQL version from DockerHub  razorsql_jar_file_windows name of the jar file (Windows version) razorsql_java_path_windows name of the Java file (Windows version) razorsql_profile name of the RazorSQL connection profile file directory of the database schema reference file  razorsql_reference_dir file name of the database schema reference	postgres_password_guest	guest database password
postgres_user_admin  postgres_user_guest  postgres_version  razorsql_jar_file_windows  razorsql_java_path_windows  razorsql_profile  razorsql_reference_dir  razorsql_reference_file  guest database username  requested PostgreSQL version from DockerHub  name of the jar file (Windows version)  name of the Java file (Windows version)  file directory of the database schema reference file  file name of the database schema reference	postgres_pgdata	
postgres_user_guest guest database username  requested PostgreSQL version from DockerHub  razorsql_jar_file_windows name of the jar file (Windows version)  razorsql_java_path_windows name of the Java file (Windows version)  razorsql_profile name of the RazorSQL connection profile  razorsql_reference_dir file directory of the database schema reference file  razorsql_reference_file file name of the database schema reference	postgres_user	database username
requested PostgreSQL version from DockerHub razorsql_jar_file_windows name of the jar file (Windows version) razorsql_java_path_windows name of the Java file (Windows version) razorsql_profile name of the RazorSQL connection profile file directory of the database schema reference file  razorsql_reference_file  file name of the database schema reference	postgres_user_admin	administration database username
razorsql_jar_file_windows razorsql_java_path_windows razorsql_profile razorsql_profile razorsql_reference_dir  razorsql_reference_file  razorsql_reference_file  razorsql_reference_file  razorsql_reference_file  razorsql_reference_file  razorsql_reference_file  erHub name of the jar file (Windows version) name of the Java file (Windows version) name of the RazorSQL connection profile file directory of the database schema reference		guest database username
razorsql_java_path_windows razorsql_profile razorsql_reference_dir  razorsql_reference_dir  razorsql_reference_file  razorsql_reference_file  file directory of the database schema reference file  file name of the Java file (Windows version)  name of the Java file (Windows version)  name of the RazorSQL connection profile  file directory of the database schema reference	postgres_version	
razorsql_java_path_windows razorsql_profile razorsql_reference_dir  razorsql_reference_dir  razorsql_reference_file  razorsql_reference_file  file directory of the database schema reference file  file name of the Java file (Windows version)  name of the Java file (Windows version)  name of the RazorSQL connection profile  file directory of the database schema reference	razorsql_jar_file_windows	name of the jar file (Windows version)
razorsql_reference_dir  file directory of the database schema reference file  file name of the database schema reference	razorsql_java_path_windows	
razorsal reference file file name of the database schema reference	razorsql_profile	name of the RazorSQL connection profile
razoreal reference file	razorsql_reference_dir	file directory of the database schema reference file
	razorsql_reference_file	

# 1.4.2 Example

[default]

```
check_value = "default"
correction_work_dir = "data/correction"
database_commit_size = 10000
download_chunk_size = 524288
...

[test]
check_value = "test"
correction_work_dir = "data/correction_test"
download_work_dir = "data/download_test"
postgres_connection_port = 5433
postgres_container_name = "io_avstats_db_test"
postgres_password = "postgres_password"
postgres_password_admin = "postgres_password_admin"
postgres_pgdata = "data/postgres_test"
```

#### 1.4.3 Notes

The configuration parameters in the configuration files can be overridden with corresponding environment variables, e.g. the environment variable <code>IO\_AERO\_IS\_VERBOSE</code> overrides the configuration parameter <code>is\_verbose</code>.

# 1.5 Configuration Logging

In **IO-AVSTATS** the Python standard module for logging is used - details can be found here.

The file logging\_cfg.yaml controls the logging behaviour of the application.

#### Default content:

```
version: 1
disable_existing_loggers: False
formatters:
  simple:
    format: "%(asctime)s [%(name)s] [%(module)s.py] %(levelname)-5s
%(funcName)s:%(lineno)d %(message)s'
    format: "%(asctime)s [%(name)s] [%(module)s.py ] %(levelname)-5s
%(funcName)s:%(lineno)d \n%(message)s"
handlers:
 console:
   class: logging.StreamHandler
   level: INFO
   formatter: simple
  file_handler:
   class: logging.FileHandler
    level: INFO
    filename: logging_io_aero.log
    formatter: extended
root:
  level: DEBUG
  handlers: [ console, file_handler ]
```

# 1.6 First Steps

To get started, you'll first need to clone the repository, which contains essential scripts for various operating systems. After cloning, you will use these scripts to install the necessary foundational software. Finally, you will complete the repository-specific installation to set up your environment correctly. Detailed instructions for each of these steps are provided below.

# 1.6.1 Cloning the Repository

Start by cloning the *io-avstats* repository. This repository contains essential scripts and configurations needed for the project.

git clone https://github.com/io-aero/io-avstats

#### 1.6.2 Install Foundational Software

Once you have successfully cloned the repository, navigate to the cloned directory. Within the *scripts* folder, you will find scripts tailored for various operating systems. Proceed with the subsection that corresponds to your operating system for further instructions.

#### macOS

To set up the project on a macOS system, the following steps should be performed in a terminal window within the repository directory:

a. Grant Execute Permission to Installation Scripts

Provide execute permissions to the installation scripts:

```
chmod +x scripts/*.zsh
```

b. Install Python and pip

Run the script to install Python and pip:

```
./scripts/run_install_python.zsh
```

c. Install Miniconda and the Correct Python Version

Use the following script to install Miniconda and set the right Python version:

```
./scripts/run_install_miniconda.zsh
```

d. Install Docker Desktop

To install Docker Desktop, run:

```
./scripts/run_install_docker.zsh
```

e. Optionally Install DBeaver

If needed, install DBeaver using the following script:

```
./scripts/run_install_dbeaver.zsh
```

f. Close the Terminal Window

Once all installations are complete, close the terminal window.

#### Ubuntu

To set up the project on an Ubuntu system, the following steps should be performed in a terminal window within the repository directory:

1.6. First Steps 7

a. Grant Execute Permission to Installation Scripts

Provide execute permissions to the installation scripts:

```
chmod +x scripts/*.sh
```

b. Install Python and pip

Run the script to install Python and pip:

```
./scripts/run_install_python.sh
```

c. Install Miniconda and the Correct Python Version

Use the following script to install Miniconda and set the right Python version:

```
./scripts/run_install_miniconda.sh
```

d. Install Docker Desktop

This step is not required for WSL (Windows Subsystem for Linux) if Decker Desktop is installed in Windows and this is configured for WSL 2 based engine.

To install Docker Desktop, run:

```
./scripts/run_install_docker.sh
```

e. Optionally Install DBeaver

If needed, install DBeaver using the following script:

```
./scripts/run_install_dbeaver.sh
```

f. Close the Terminal Window

Once all installations are complete, close the terminal window.

Windows 10/11

To set up the project on a Windows 10/11 system, the following steps should be performed in a command prompt (cmd) within the repository directory:

a. Install Python and pip

Run the script to install Python and pip:

```
scripts/run_install_python.bat
```

b. Install Miniconda and the Correct Python Version

Use the following script to install Miniconda and set the right Python version:

```
scripts/run_install_miniconda.bat
```

c. Close the Command Prompt

Once all installations are complete, close the command prompt.

d. Install Docker Desktop

To install Docker Desktop, download the software from here:

https://www.docker.com/products/docker-desktop/

and follow the installation instructions.

e. Optionally Install DBeaver

If needed, install DBeaver, download the software from here:

https://dbeaver.io/

and follow the installation instructions.

# 1.6.3 Repository-Specific Installation

After installing the basic software, you need to perform installation steps specific to the *io-avstats* repository. This involves setting up project-specific dependencies and environment configurations. To perform the repository-specific installation, the following steps should be performed in a command prompt or a terminal window (depending on the operating system) the repository directory.

#### **Setting Up the Python Environment**

To begin, you'll need to set up the Python environment using Miniconda, which is already pre-installed. You can use the provided Makefile for managing the environment.

a. For production use, run the following command:

make conda-prod

b. For **software development**, use the following command:

make conda-dev

These commands will create and configure a virtual environment for your Python project, ensuring a clean and reproducible development or production environment. The virtual environment is automatically activated by the Makefile, so you don't need to activate it manually.

#### **System Testing with Unit Tests**

If you have previously executed *make conda-dev*, you can now perform a system test to verify the installation using *make test*. Follow these steps:

a. Run the System Test:

Execute the system test using the following command:

make tests

This command will initiate the system tests using the previously installed components to verify the correctness of your installation.

b. Review the Test Results:

After the tests are completed, review the test results in the terminal. Ensure that all tests pass without errors.

If any tests fail, review the error messages to identify and resolve any issues with your installation.

Running system tests using *make tests* is a valuable step to ensure that your installation is working correctly, and your environment is properly configured for your project. It helps identify and address any potential problems early in the development process.

#### **Downloading Database Files (Optional)**

Database files can be downloaded from the IO-Aero Google Drive directory <code>io\_aero\_data/io-avstats/database/io\_avstats\_db</code> to your local repository directory <code>data</code>. Before extracting, if a <code>postgres</code> directory exists within the <code>data</code> directory, it should be deleted.

Follow these steps to manage the database files:

a. Access the IO-Aero Google Drive Directory:

Navigate to the IO-Aero Google Drive and locate the directory *io\_aero\_data/TO DO/database/TO DO. b. Download Database Files:* 

Download the necessary database files from the specified directory to your local repository directory data.

c. Delete Existing postgres Directory (if present):

If a directory named *postgres* already exists within the *data* directory, you should delete it to avoid conflicts.

1.6. First Steps 9

#### d. Extract Database Files:

The downloaded database files are in an archive format (ZIP) and should be extracted in the *data* directory. After completing these steps, the database files should reside in the *data* directory of your local repository and will be ready for use.

#### Creating the Docker Container with PostgreSQL DB

To create the Docker container with PostgreSQL database software, you can use the provided <code>run\_io\_avstats</code> script. Depending on your operating system, follow the relevant instructions below: <code>a. macOS (zsh)</code>:

```
./scripts/run_io_avstats.zsh s_d_c
```

#### b. Ubuntu (sh):

```
./scripts/run_io_avstats.sh s_d_c
```

#### c. Windows 10/11 (cmd):

```
scripts\run_io_avstats.cmd s_d_c
```

These commands will initiate the process of creating the Docker container with PostgreSQL database software.

# 1.7 Advanced Usage

The main tool for operating **IO-AVSTATS** is the "run\_io\_avstats" script. The script is fully available in the Windows version and in a greatly reduced version for macOS and Ubuntu.

#### 1.7.1 Overview

The following tasks can be executed with this script:

Code	Task	Additional parameter(s)
a_o_c	Load aviation occurrence categories into PostgreSQL	
c_d_c	Run Docker Compose tasks - Cloud	clean, down, logs or up
c_d_i	Create or update an application Docker image	all or single Streamlit app
c_d_s	Create the IO-AVSTATS-DB PostgreSQL database schema	
c_f_z	Zip the files for the cloud	
c_l_l	Correct decimal US latitudes and longitudes	
c_p_d	Cleansing PostgreSQL data	
f_n_a	Find the nearest airports	
l_a_p	Load airport data into PostgreSQL	
l_c_d	Load data from a correction file into PostgreSQL	-e / -excel
l_c_s	Load country and state data into PostgreSQL	
l_n_a	Load NTSB MS Access database data into PostgreSQL	-m / -msaccess
l_s_d	Load simplemaps data into PostgreSQL	
l_s_e	Load sequence of events data into PostgreSQL	
l_z_d	Load ZIP Code Database data into PostgreSQL	
r_d_s	Refresh the PostgreSQL database schema	
r_s_a	Run a Streamlit application	
s_d_c	Set up the IO-AVSTATS-DB PostgreSQL database container	
u_d_s	Update the IO-AVSTATS-DB PostgreSQL database schema	
u_p_d	Complete processing of a modifying MS Access file	-m / -msaccess
v_n_d	Verify selected NTSB data	

version Show the IO-AVSTATS version	
-------------------------------------	--

#### 1.7.2 Detailed task list

#### a\_o\_c - Load aviation occurrence categories into PostgreSQL

#### Purpose

Load the definition of the valid CICTT codes.

#### **Data Source**

The data source can be found on the NTSB website here:

AVIATION OCCURRENCE CATEGORIES - DEFINITIONS AND USAGE NOTES

The NTSB provides the data in a pdf file which must then be converted to MS Excel format xlsx before processing.

#### Implementation

```
CREATE TABLE public.io_aviation_occurrence_categories (
    cictt_code varchar(10) NOT NULL,
    identifier varchar(100) NOT NULL,
    definition text NOT NULL,
    first_processed timestamp NOT NULL,
    last_processed timestamp NULL,
    last_seen timestamp NULL,
    CONSTRAINT io_aviation_occurrence_categories_pkey PRIMARY KEY (cictt_code)
);
```

. . .

#### c\_d\_c - Run Docker Compose tasks - Cloud

#### **Purpose**

Manage the Docker containers needed in the cloud:

- portainer: container management
- IO-AVSTATS-DB: PostgreSQL database
- Application ae1982: Aircraft Events since 1982
- Application **pd1982**: Profiling Data since 1982
- Application slara: Association Rule Analysis
- load\_balancer: load balancer NGINX

#### **Processing Options**

```
- clean - Remove all containers and images
- down - Stop Docker Compose
- logs - Fetch the logs of a container
- up - Start Docker Compose
```

#### c\_d\_i - Create or update an application Docker image

#### Purpose

Create the application-specific Docker images and store them on DockerHub.

#### **Processing Options**

```
- all - All Streamlit applications
- ae1982 - Aircraft Accidents in the US since 1982
```

```
- pd1982 - Profiling Data for the US since 1982
- slara - Association Rule Analysis
```

#### c\_d\_s - Create the IO-AVSTATS-DB PostgreSQL database schema

#### **Purpose**

Create the database schema including the following steps, among others:

- 1. creation of a new database user, and
- 2. creation of a new database, and
- 3. creation of database objects such as database tables and so on.

The following parameters are used when creating the database schema:

- postgres\_dbname\_admin administration database name
- postgres\_password\_admin administration database password
- postgres\_user\_admin administration database username

Subsequently, the task u\_d\_s (Update the PostgreSQL database schema) is also executed.

#### c\_f\_z - Zip the files for the cloud

#### Purpose

Collect and zip the elements needed for the cloud to run the **IO-AVSTATS** application there. The result is contained in the file **cloud.zip**.

#### c\_1\_1 - Correct decimal US latitudes and longitude

#### Purpose

An attempt is made to calculate missing decimal longitudes and latitudes using the database tables `io\_lat\_lng` and `io\_states`.

#### **Implementation**

- 1. In the database table **`events`** the values in the columns **`io\_dec\_lat\_lng\_actions`**, **`io\_dec\_latitude`**, **`io\_dec\_longitude`** and **`io\_latlong\_acq`** are deleted.
- 2.

All rows in the database table `events` are processed where at least one of the columns `dec\_latitude` or `dec\_longitude` is empty or 0 and the column `ev\_country` has the content `USA`.

- 2.1 An erroneous swapping of latitude and longitude is corrected.
- 2.2 An attempt is made to calculate a missing column `dec\_latitude` from the column `latitude` and a missing column `dec\_longitude` from the column `longitude`.
- 2.3 An attempt is made to calculate a missing column `dec\_latitude` or `dec\_longitude` from the column `ev\_site\_zipcode`.
- 2.4 It tries to calculate a missing column `dec\_latitude` or `dec\_longitude` from the column `ev\_city`.
- 2.5 An attempt is made to calculate a missing column `dec\_latitude` or `dec\_longitude` from the column `ev\_state`.
- 2.6 For a missing column `dec\_latitude` resp. `dec\_longitude` the center of the USA is assumed.

#### c\_p\_d - Cleansing PostgreSQL data

#### Purpose

Clean up data the abnormalities in the database. This includes the following activities:

- remove trailing whitespace in string data types (trimming),
- converting string data types that contain only whitespace to NULL (nullifying).

As a result, a much simplified processing of the data is possible, e.g. for comparisons.

On the one hand, the task can be executed explicitly with the " $run_io_avstats_db$ " script (task " $c_p_d$ ") and, on the other hand, it always runs after loading NTSB MS Access data into the PostgreSQL database (task " $l_n_a$ " and " $u_p_d$ ").

f\_n\_a - Find the nearest airports

• TODO

#### Purpose

1\_a\_p - Load airport data into PostgreSQL

• TODO

#### **Purpose**

**Data Source** 

#### **Implementation**

1\_c\_d - Load data from a correction file into PostgreSQL

• TODO

#### **Purpose**

#### **Data Source**

#### Implementation

This task allows files containing aviation accident data to be downloaded from the NTSB download site. These files are there as MS Access databases in a compressed format. The following subtasks are executed:

- 1. A connection to the NTSB download page is established.
- 2. The selected file is downloaded to the local system in chunks.
- 3. The downloaded file is then unpacked.
- 4. A script with the database schema definition is created with RazorSQL from the downloaded database.
- 5. The newly created script is then compared with a reference script for matching.

1\_c\_s - Load country and state data into PostgreSQL

• TODO

#### Purpose

#### **Data Source**

#### Implementation

1\_n\_a - Load NTSB MS Access database data into PostgreSQL

#### Purpose

This task allows files containing aviation event data to be downloaded from the **NTSB** download site. These files are there as MS Access databases in a compressed format. The following subtasks are

#### executed:

- 1. A connection to the **NTSB** download page is established.
- 2. The selected file is downloaded to the local system in chunks.
- 3. The downloaded file is then unpacked.
- 4. A script with the database schema definition is created with RazorSQL from the downloaded database.
- 5. The newly created script is then compared with a reference script for matching.

Subsequently, the downloaded data can be loaded into the PostgreSQL database with the task  $l_n_a$  (Load NTSB MS Access database data into PostgreSQL).

#### **Data Sources**

- Pre2008.zip: data set for 1982 through 2007
- avall.zip: data set from 2008 to the present
- upDDMON.zip: monthly supplements on the 1st, 8th, 15th and 22nd

#### **Implementation**

The PostgreSQL database IO-AVSTATS-DB completely maps the database schema of the NTSB MS Access database.

1\_s\_d - Load simplemaps data into PostgreSQL

TODO

#### **Purpose**

#### **Data Source**

#### **Implementation**

This task transfers the data from an NTSB MS Access database previously downloaded from the NTSB website to the PostgreSQL database. The same MS Access database can be processed several times with this task without any problems, since only the changes are newly transferred to the PostgreSQL database. The initial loading is done with both MS Access databases Pre2008 ubd avall. After that only the monthly updates are then transferred.

1\_s\_e - Load sequence of events data into PostgreSQL

• TODO

#### Purpose

#### Data Source

#### **Implementation**

 ${\tt 1\_z\_d} \text{ -} \textbf{Load ZIP Code Database data into PostgreSQL}$ 

• TODO

#### **Purpose**

#### **Data Source**

#### **Implementation**

This task transfers the data from an NTSB MS Access database previously downloaded from the NTSB website to the PostgreSQL database. The same MS Access database can be processed several times with this task without any problems, since only the changes are newly transferred to the PostgreSQL database. The initial loading is done with both MS Access databases Pre2008 ubd avall. After that only the monthly updates are then transferred.

#### r\_d\_s - Refresh the PostgreSQL database schema

• TODO

Hereby changes can be made to the database schema. The task can be executed several times without problems, since before a change is always first checked whether this has already been done.

- 1. Materialized database view
- ``io\_app\_ae1982`` provides the data for processing the task ``c\_l\_l`` (Correct decimal US latitudes and longitudes).

#### Example protocol:

#### r\_s\_a - Run the IO-AVSTATS application

• TODO

#### s\_d\_c - Set up the PostgreSQL database container

• TODO

#### u\_d\_s - Update the PostgreSQL database schema

• TODO

Hereby changes can be made to the database schema. The task can be executed several times without problems, since before a change is always first checked whether this has already been done.

- 1. New database tables:
- ``io\_countries``: contains latitude and longitude of selected countries.
- "io\_lat\_lng": used to store the simplemaps and United States Zip Codes.org data.
- "io\_states": contains the identification, name, latitude and longitude of all US states.
- 2. Extensions for database tables:
- 2.1 Database table "events".
  - The columns ``io\_city``, ``io\_country``, ``io\_latitude``, ``io\_longitude``, ``io\_site\_zipcode`` and ``io\_state`` to store manual corrections.
  - The columns ``io\_deviating\_dec\_latitude``, ``io\_deviating\_dec\_longitude``, ``io\_invalid\_latitude``, ``io\_invalid\_longitude``, ``io\_invalid\_us\_city``, ``io\_invalid\_us\_state`` and , ``io\_invalid\_us\_zipcode`` for documenting data plausibility (task ``v\_n\_d``).
  - the columns "io\_dec\_lat\_lng\_actions", "io\_dec\_latitude" and "io\_dec\_longitude" to store

corrected decimal latitude and longitude values.

- 3. New database views:
- ``io\_lat\_lng\_issues`` provides the data for processing the task ``c\_l\_l`` (Correct decimal US latitudes and longitudes).
- "io\_accidents\_us\_1982" provides event data for aviation accidents in the U.S. since 1982.

#### u\_p\_d - Complete processing of a modifying MS Access file

• TODO

#### v\_n\_d - Verify selected NTSB data

#### Purpose

This task can be used to perform a plausibility check for the following columns in the database table `events`:

- `dec\_latitude`,
- `dec\_longitude`,
- `ev\_state`,
- `ev\_site\_zipcode`,
- `latitude`,
- `longitude`,

and the combination of:

- `ev\_state` and `ev\_city`,
- `ev\_state`, `ev\_city` and `ev\_site\_zipcode`.

The results of the check are stored in the following columns:

- `io\_deviating\_dec\_latitude` (absolute difference),
- `io\_deviating\_dec\_longitude` (absolute difference),
- `io\_invalid\_latitude` (true),
- `io\_invalid\_longitude` (true),
- `io\_invalid\_us\_city` (true),
- `io\_invalid\_us\_city\_zipcode` (true),
- `io\_invalid\_us\_state` (true),
- `io\_invalid\_us\_zipcode` (true).

The tests are performed according to the following logic:

- `io\_deviating\_dec\_latitude`: Absolute difference between `dec\_latitude` and `latitude` exceeding a given limit in `max\_deviation\_latitude`.
- `io\_deviating\_dec\_longitude`: Absolute difference between `dec\_longitude` and `longitude` exceeding a given limit `max\_deviation\_longitude`.
- `io\_invalid\_latitude`: Can the latitude in the `latitude` column be converted to its decimal equivalent?
- `io\_invalid\_longitude`: Can the longitude in the `longitude` column be converted to its decimal equivalent?

- `io\_invalid\_us\_city`: For country *USA* and the given state, is the specified value in the `ev\_city` column an existing city?
- `io\_invalid\_us\_city\_zipcode`: For country *USA* and the given state, are the specified values in the `ev\_city` column and in the `ev\_site\_zipcode` column an existing city?
- `io\_invalid\_us\_state`: For country *USA*, is the specified value in the `ev\_state` column a valid state identifier?
- `io\_invalid\_us\_zipcode`: For country *USA*, is the specified value in the `ev\_site\_zipcode` column an existing zip code?

#### version - Show the "IO-AVSTATS" version

• TODO

#### 1.7.3 First installation

The initial load in a fresh Windows environment requires the execution of the following tasks in the given order:

- ``c\_d\_s`` Create the IO-AVSTATS-DB PostgreSQL database schema
- ``l\_c\_s`` Load country and state data into PostgreSQL
- ``l\_a\_p`` Load airport data into PostgreSQL
- ``a\_o\_c`` Load aviation occurrence categories into PostgreSQL
- ``l\_s\_e`` Load sequence of events data into PostgreSQL
- ``l\_s\_d`` Load simplemaps data into PostgreSQL
- ``l\_z\_d`` Load ZIP Code Database data into PostgreSQL
- "u\_p\_d" Complete processing of a modifying MS Access file: "Pre2008"

#### 1.7.4 Regular updates

### Every 1st of the month

- 1. Stop the Docker container "IO-AVSTATS-DB"
- 2. Restore the current state of Pre2008
- 3. Start the Docker container "IO-AVSTATS-DB"
- 4. Process the current "avall" file with code "l\_n\_a"

### Every 1st, 8th, 15th and 22nd

• Process the current ``upDDMON`` file with code ``u\_p\_d``

#### 1.8 Data Sources

#### 1.8.1 AVIATION OCCURRENCE CATEGORIES

The CICTT codes used in the `Aviation\_Occurrence\_Categories/aviation\_occurrence\_categories.xlsx` file is taken from this document.

1.8. Data Sources

# **AVIATION OCCURRENCE CATEGORIES**

# **DEFINITIONS AND USAGE NOTES**

October 2013 (4.6)

· - Aviation e - -

# 1.8.2 CICTT\_SOE\_MAP.csv

The content of the database table *io\_sequence\_of\_events* is created based on this csv file.

eventsoe_no	meaning	CCTT_Code	CICTT_Description
0	Unknown or undetermined	UNK	Unknown
10	Aircraft loading event	RAMP	Ground Handling
20	Aircraft servicing event	RAMP	Ground Handling
30	Preflight or dispatch event		
40	Aircraft maintenance event		
50	Aircraft inspection event		
60	Attempted remediation/recovery		
70	Airport occurrence	ADRM	Aerodrome
80	Ground handling event	RAMP	Ground Handling
81	AC/prop/rotor contact w person	RAMP	Ground Handling
82	Prop/jet/rotor blast/suction	RAMP	Ground Handling
90	Abnormal runway contact	ARC	Abnormal Runway Contact
91	Tailstrike	ARC	Abnormal Runway Contact
92	Hard landing	ARC	Abnormal Runway Contact
93	Dragged wing/rotor/float/other	ARC	Abnormal Runway Contact
94	Landing gear collapse	ARC	Abnormal Runway Contact

# 1.8.3 FAA Airports

The FAA provides data on airports in the United States in the form of a csv file. This data is updated by the FAA at irregular intervals.



# 1.8.4 FAA Runways

The FAA provides data on runways in the United States in the form of a csv file. This data is updated by the FAA at irregular intervals.

1.8. Data Sources



# 1.8.5 geodatos

The decimal latitude and longitude for the USA used in the `Countries\_States/countries\_states.json` file is taken from the geodatos website.



# 1.8.6 National Plan of Integrated Airport Systems (NPIAS)

The FAA provides data on preferred airports in the United States in the form of an MS Excel file. This data is updated by the FAA at irregular intervals.



#### 1.8.7 NTSB

The main data used in **IO-AVSTATS** is provided by the National Transportation Safety Board. On the accident data page is the link Downloadable data sets, which contains the aviation accident data in MS Access format for free download.

File	Created (mm/dd/yyyy)	Description
avall.zip	current	Data from January 1, 2008 to today
PRE1982.zip	10/27/2020	unknown
Pre2008.zip	09/30/2020	Data from January 1, 1982 to December 31, 2007
upDDMON.zip	current	New additions and updates until DD day in the month MON

The schemas of the two databases *avall* and *Pre2008* are identical except for the two new optional columns *dec\_latitude* and *dec\_longitude* in the database table *events* of the database *avall*.

1.8. Data Sources 21

#### **Database Schema Comparison**

Before any new **NTSB** data set can be processed, the database schema of the new data set must first be compared with the database schema of the previous version of the **NTSB** data set *avall.mdb*.

#### Procedure:

- The RazorSQL program is started.
- Under 'Connections' select 'Add Connection Profile'.
- Select MS Access under Add Connection Profile.
- *Connection Type* is ODBC (Direct).
- In addition, an entry must be made at *Connection Profile Name* and *Database File*: Connection Profile Name: IO-AVSTATS Database File: IO-AVSTATS.mdb
- After pressing the CONNECT button you will be connected to the selected MS Access database.



• After opening the database, a SQL script with the DDL statements can be generated in the menu under *DB Tools* and *Generate DDL*.



• This SQL script can be saved as a file for further processing in the menu under *File* and *Save As*.

In case of any discrepancy, these must be implemented into the existing PostgreSQL database.

# **Table Processing Order**

Based on the foreign keys (FK) present in the database schema, the following processing sequence results when creating the database schema and loading or updating the database tables:

Level 1 - without FK - events

Level 2 - FK: ev\_id - aircraft - dt\_events - NTSB\_Admin

Level 3 - FK: *ev\_id* & *Aircraft\_Key* - dt\_aircraft - engines - Events\_Sequence - Findings - Flight\_Crew - injury - narratives - Occurrences

Level 4 - FK: ev\_id & Aircraft\_Key & crew\_no - dt\_Flight\_Crew - flight\_time

Level 4 - FK: ev\_id & Aircraft\_Key & Occurrence\_No - seq\_of\_events

1.8. Data Sources 23

#### Issues

The problem database tables listed below are not included in the PostgreSQL database schema. *Empty database tables* 

The following database tables are included in the Entity Relationship Diagram (ERD), but they do not contain any data in the database: - Occurrences - seq\_of\_events

Legacy database tables

The following database tables are included in the database but are missing from the ERD: - Country - ct\_iaids - ct\_seqevt - eADMSPUB\_DataDictionary - states

\*Inconsistent database data - foreign key\*

• database table *ntsb\_admin*: database table *event* has no row with *ev\_id* = 20210527103155 (data source: *avall.zip*) - as a consequence, the foreign key to the events table had to be removed

Inconsistent database data - country USA and state

ev_state	count
AO	17
СВ	1
GM	45
GU	8
OF	14
PO	15
PR	112
UN	3
VI	6

Inconsistent database data - invalid USA latitude

```
SELECT count(*)
  FROM io_lat_lng_issues
WHERE io_dec_lat_lng_actions LIKE '%ERROR.00.920%'
```

count 430

Inconsistent database data - invalid USA longitude

```
SELECT count(*)
  FROM io_lat_lng_issues
WHERE io_dec_lat_lng_actions LIKE '%ERROR.00.921%'
```

count 462

## 1.8.8 opendatasoft

The decimal latitudes and longitudes for the US states used in

> C == public.opendatasoft.com/explore/dataset/us-state-boundaries/export/ 🚺 Diátaxis 🔃 The GITHUB\_TOKE... 🎧 c-bik/dql 👄 JSON to XML 👫 FlightGear Flight Si... 🧗 New to FlightGear -... 🞧 streamlit\_nlp\_apps/... 🖺 PLY (Pyt opendatasoft MAP BUILDER CHART BUILDER 56 records **US State Boundaries** No active filters Мар 🚣 Export **⇔** API Information III Analyze **Filters** This dataset is licensed under: Public domain Q Search records... Flat file formats name CSV Alabama CSV uses semicolon (;) as a separator. Alaska American Samoa JSON Arizona **≛** Whole dataset Excel Arkansas California Geographic file formats > More GeoJSON Whole dataset Shapefile ♣ Whole dataset **KML** 

the `Countries\_States/countries\_states.json` file are taken from the opendatasoft website.

# 1.8.9 simplemaps

In order to fill in the missing decimal latitudes and longitudes, free available data from **simplemaps** is used. simplemaps offers postal codes and cities with their latitude and longitude.

The US Zip Codes Database link provides latitude and longitude for selected US zip codes:

-in	lat	lng
zip	iat	Ing
00601	18.18027	-66.75266
00602	18.36075	-67.17541
00603	18.45744	-67.12225
00606	18.16585	-66.93716
00610	18.2911	-67.12243
00611	18.27698	-66.80688
00612	18.41283	-66.7051
00616	18.41878	-66.6679
00617	18.44598	-66.56006
00622	17.98892	-67.1566
00623	18.08429	-67.15336
00624	18.05905	-66.71932

The United States Cities Database link provides latitude and longitude for selected US cities:

1.8. Data Sources 25

-		_	_	-	_	
city_ascii	state_id	state_name	county_fips	county_name	lat	Ing
New York	NY	New York	36081	Queens	40.6943	-73.9249
Los Angeles	CA	California	06037	Los Angeles	34.1141	-118.4068
Chicago	IL	Illinois	17031	Cook	41.8375	-87.6866
Miami	FL	Florida	12086	Miami-Dade	25.784	-80.2101
Dallas	TX	Texas	48113	Dallas	32.7935	-96.7667
Houston	TX	Texas	48201	Harris	29.786	-95.3885
Philadelphia	PA	Pennsylvania	42101	Philadelphia	40.0077	-75.1339
Atlanta	GA	Georgia	13121	Fulton	33.7628	-84.422
Washington	DC	District of Columbia	11001	District of Columbia	38.9047	-77.0163
Boston	MA	Massachusetts	25025	Suffolk	42.3188	-71.0852
Phoenix	AZ	Arizona	04013	Maricopa	33.5722	-112.0892
Detroit	MI	Michigan	26163	Wayne	42.3834	-83.1024
San Francisco	CA	California	06075	San Francisco	37.7558	-122.4449
Seattle	WA	Washington	53033	King	47.6211	-122.3244
San Diego	CA	California	06073	San Diego	32.8313	-117.1222
Minneapolis	MN	Minnesota	27053	Hennepin	44.9635	-93.2678

# 1.8.10 United States Zip Codes.org

In order to fill in the missing decimal latitudes and longitudes, free available data from **United States Zip Codes.org** is used. **United States Zip Codes.org** offers more complete postal codes but only with estimated latitudes and longitudes.

type	decommissioned	primary_city	acceptable_cities	state	country	latitude	longitude	
UNIQUE	0	Holtsville		NY	US	40.81	-73.04	
UNIQUE	0	Holtsville		NY	US	40.81	-73.04	
STANDARD	0	Adjuntas		PR	US	18.16	-66.72	
STANDARD	0	Aguada		PR	US	18.38	-67.18	
STANDARD	0	Aguadilla	Ramey	PR	US	18.43	-67.15	
PO BOX	0	Aguadilla	Ramey	PR	US	18.43	-67.15	
PO BOX	0	Aguadilla		PR	US	18.43	-67.15	
STANDARD	0	Maricao		PR	US	18.18	-66.98	
STANDARD	0	Anasco		PR	US	18.28	-67.14	
PO BOX	0	Angeles		PR	US	18.28	-66.79	
STANDARD	0	Arecibo		PR	US	18.45	-66.73	
PO BOX	0	Arecibo		PR	US	18.45	-66.73	
PO BOX	0	Arecibo		PR	US	18.45	-66.73	
STANDARD	0	Bajadero		PR	US	18.42	-66.67	
STANDARD	0	Barceloneta		PR	US	18.45	-66.56	
STANDARD	0	Boqueron		PR	US	17.99	-67.15	
STANDARD	0	Cabo Rojo		PR	US	18.08	-67.14	
	UNIQUE UNIQUE STANDARD STANDARD STANDARD PO BOX STANDARD STANDARD PO BOX STANDARD PO BOX STANDARD PO BOX STANDARD STANDARD STANDARD STANDARD STANDARD STANDARD	UNIQUE 0 UNIQUE 0 STANDARD 0 STANDARD 0 STANDARD 0 STANDARD 0 PO BOX 0 STANDARD 0 STANDARD 0 STANDARD 0 STANDARD 0 PO BOX 0 STANDARD 0 PO BOX 0 STANDARD 0	UNIQUE 0 Holtsville UNIQUE 0 Holtsville STANDARD 0 Adjuntas STANDARD 0 Aguadilla STANDARD 0 Aguadilla PO BOX 0 Aguadilla PO BOX 0 Maricao STANDARD 0 Maricao STANDARD 0 Anasco PO BOX 0 Angeles STANDARD 0 Arecibo PO BOX 0 Arecibo STANDARD 0 Bajadero STANDARD 0 Bajadero STANDARD 0 Barceloneta STANDARD 0 Boqueron	UNIQUE 0 Holtsville UNIQUE 0 Holtsville STANDARD 0 Adjuntas STANDARD 0 Aguada STANDARD 0 Aguadilla Ramey PO BOX 0 Aguadilla Ramey PO BOX 0 Aguadilla STANDARD 0 Maricao STANDARD 0 Anasco PO BOX 0 Angeles STANDARD 0 Arecibo PO BOX 0 Arecibo PO BOX 0 Arecibo STANDARD 0 Bajadero STANDARD 0 Bajadero STANDARD 0 Barceloneta STANDARD 0 Boqueron	UNIQUE         0 Holtsville         NY           UNIQUE         0 Holtsville         NY           STANDARD         0 Adjuntas         PR           STANDARD         0 Aguada         PR           STANDARD         0 Aguadilla         Ramey         PR           PO BOX         0 Aguadilla         PR           PO BOX         0 Aguadilla         PR           STANDARD         0 Maricao         PR           STANDARD         0 Anasco         PR           PO BOX         0 Angeles         PR           STANDARD         0 Arecibo         PR           PO BOX         0 Arecibo         PR           STANDARD         0 Bajadero         PR           STANDARD         0 Barceloneta         PR           STANDARD         0 Boqueron         PR	UNIQUE 0 Holtsville NY US UNIQUE 0 Holtsville NY US STANDARD 0 Adjuntas PR US STANDARD 0 Aguada PR US STANDARD 0 Aguadilla Ramey PR US PO BOX 0 Aguadilla Ramey PR US STANDARD 0 Maricao PR US STANDARD 0 Maricao PR US STANDARD 0 Anasco PR US STANDARD 0 Anasco PR US PO BOX 0 Angeles PR US STANDARD 0 Arecibo PR US STANDARD 0 Bajadero PR US STANDARD 0 Bajadero PR US STANDARD 0 Barceloneta PR US	UNIQUE         0 Holtsville         NY         US         40.81           UNIQUE         0 Holtsville         NY         US         40.81           STANDARD         0 Adjuntas         PR         US         18.16           STANDARD         0 Aguada         PR         US         18.38           STANDARD         0 Aguadilla         Ramey         PR         US         18.43           PO BOX         0 Aguadilla         PR         US         18.43           STANDARD         0 Maricao         PR         US         18.18           STANDARD         0 Anasco         PR         US         18.28           PO BOX         0 Angeles         PR         US         18.28           STANDARD         0 Arecibo         PR         US         18.45           PO BOX         0 Arecibo         PR         US         18.45           PO BOX         0 Arecibo         PR         US         18.45           STANDARD         0 Bajadero         PR         US         18.45           STANDARD         0 Barceloneta         PR         US         17.99	UNIQUE         0 Holtsville         NY         US         40.81         -73.04           UNIQUE         0 Holtsville         NY         US         40.81         -73.04           STANDARD         0 Adjuntas         PR         US         18.16         -66.72           STANDARD         0 Aguada         PR         US         18.38         -67.18           STANDARD         0 Aguadilla         Ramey         PR         US         18.43         -67.15           PO BOX         0 Aguadilla         Ramey         PR         US         18.43         -67.15           PO BOX         0 Aguadilla         PR         US         18.43         -67.15           STANDARD         0 Maricao         PR         US         18.18         -66.98           STANDARD         0 Anasco         PR         US         18.28         -67.14           PO BOX         0 Angeles         PR         US         18.28         -66.79           STANDARD         0 Arecibo         PR         US         18.45         -66.73           PO BOX         0 Arecibo         PR         US         18.45         -66.73           STANDARD         0 Bajadero         PR

# 1.9 PostgreSQL Administration

**IO-AVSTATS** uses the PostgreSQL DBMS for data management. PostgreSQL is a very powerful relational database system where the SQL language can be extended by procedural add-ons like PL/pgSQL or PL/Python.

**IO-AVSTATS** provides all the tools to import the data from the MS Access databases available on the \*\*NTSB\*\* website and the data from the basic flat files available on **simplemaps** United States Cities Database and US Zip Codes Database websites.

#### 1.9.1 Docker

The PostgreSQL Docker community provides PostgreSQL images suitable for **IO-AVSTATS** on DockerHub. The official image can be found here. The  $c\_d\_l$  task available in the  $run\_io\_avstats\_db$  script downloads a selected PostgreSQL DBMS image from DockerHub and creates, configures and starts a Docker container.

#### 1.9.2 Parameterization

The parameters can be defined either via environment variables or in the *settings.io\_aero.toml* file. Details can be found under *Configuration* and *IO-AVSTATS*.

The following parameters are used when downloading the Docker image and creating the Docker container:

- postgres\_connection\_port the database IP address
- postgres\_container\_name the container name
- postgres\_dbname\_admin the administration database name
- postgres\_password\_admin the administration database password
- postgres\_pgdata the file directory on the host for the database files
- postgres\_user\_admin the administration database username
- postgres\_version the requested PostgreSQL version from DockerHub

When using environment variables, they must contain the prefix IO\_AERO\_, e.g., IO\_AERO\_POSTGRES\_USER.

# 1.9.3 Backup & Restore

Since the **IO-AVSTATS** database contains only statistical data, it is subject to a relatively low frequency of change. The following three events can lead to a change in the **IO-AVSTATS** database:

- 1. a new change file on the NTSB download site, or
- 2. an evolution of the database software or schema, or
- 3. a new PostgreSQL version that requires database migration.

This does not require sophisticated methods for backing up and restoring the **IO-AVSTATS** database, especially since the database contents reside in a dedicated local file directory. For data backup it is therefore sufficient to create a copy of the file directory with the **IO-AVSTATS** database before a change event. This copy can then replace the corrupted **IO-AVSTATS** database in the event of an error.

Very important: before any backup or restore, the PostgreSQL Docker container must be stopped first!

Chapter 2	
Master Data Logs	
Chapter 2	

# **Transaction Data Logs**

Chapter 3

## **API Documentation**

Here, you will find detailed API documentation, which includes information about all modules within the IO-AVSTATS, allowing developers to understand the functionalities available.

### 4.1 ioavstats

## 4.1.1 ioavstats package

#### **Subpackages**

ioavstats.pages package Submodules ioavstats.pages.Association\_Rule\_Analysis module ioavstats.pages.Aviation\_Event\_Analysis module ioavstats.pages.Database\_Profiling module Module contents

IO-AVSTATS Applications.

#### Submodules

#### ioavstats.Menu module

IO-Aero Menu.

#### ioavstats.avstats module

IO-AVSTATS interface.

```
ioavstats.avstats.check_arg_msaccess (args: Namespace) → None
    Check the command line argument: -m / -msaccess.
    Args:
        args (argparse.Namespace): Command line arguments.

ioavstats.avstats.check_arg_msexcel (args: Namespace) → None
    Check the command line argument: -e / -msexcel.
    Args:
        args (argparse.Namespace): Command line arguments.

ioavstats.avstats.check_arg_task (args: Namespace) → None
    Check the command line argument: -t / -task.
    Args:
```

args (argparse.Namespace): Command line arguments.

```
ioavstats.avstats.cleansing_postgres_data() \rightarrow None
    c_p_d: Cleansing PostgreSQL data.
ioavstats.avstats.correct_dec_lat_lng() → None
    c_l_l: Correct US decimal latitudes and longitudes.
ioavstats.avstats.create_db_schema() \rightarrow None
    c_d_s: Create the PostgreSQL database schema.
ioavstats.avstats.download_ntsb_msaccess_file (msaccess: str) \rightarrow None
    d_n_a: Download a NTSB MS Access database file.
    Args:
          msaccess (str):
              The NTSB MS Access database file without file extension.
ioavstats.avstats.find_nearest_airports() → None
    f_n_a: Find the nearest airports.
ioavstats.avstats.generate_sql() \rightarrow None
    Generate SQL statements: INSERT & UPDATE.
ioavstats.avstats.get_args() \rightarrow None
    Load the command line arguments into the memory.
ioavstats.avstats.load_aviation_occurrence_categories ( ) \rightarrow None
    a_o_c: Load aviation occurrence categories into PostgreSQL.
ioavstats.avstats.load_airport_data() → None
    l_a_p: Load airport data into PostgreSQL.
ioavstats.avstats.load_correction_data (filename: str) \rightarrow None
    1 c d: Load data from a correction file into PostgreSQL.
    Args:
          filename (str):
              The filename of the correction file.
ioavstats.avstats.load_country_state_data() \rightarrow None
    l_c_s: Load country and state data into PostgreSQL.
ioavstats.avstats.load_ntsb_msaccess_data (msaccess: str) \rightarrow None
    l_n_a: Load NTSB MS Access database data into PostgreSQL.
    Args:
          msaccess (str):
              The NTSB MS Access database file without file extension.
ioavstats.avstats.load_sequence_of_events() → None
    l_s_e: Load sequence of events data into PostgreSQL.
ioavstats.avstats.load_simplemaps_data() \rightarrow None
    l_s_d: Load simplemaps data into PostgreSQL.
ioavstats.avstats.load_zip_code_db_data() \rightarrow None
    l_z_d: Load ZIP Code Database data into PostgreSQL.
ioavstats.avstats.progress_msg (msg: str) \rightarrow None
    Create a progress message.
```

```
Args:
          msg (str): Progress message
ioavstats.avstats.progress_msg_time_elapsed (duration: int, event: str) \rightarrow None
    Create a time elapsed message.
    Args:
          duration (int): Time elapsed in ns. event (str): Event description.
ioavstats.avstats.refresh_db_schema() → None
    r_d_s: Refresh the PostgreSQL database schema.
ioavstats.avstats.terminate_fatal (error\_msg: str) \rightarrow None
    Terminate the application immediately.
    Args:
          error_msg (str): Error message
ioavstats.avstats.update_db_schema ( ) \rightarrow None
    u_d_s: Update the PostgreSQL database schema.
ioavstats.avstats.verify_ntsb_data() → None
    v_n_d: Verify selected NTSB data.
ioavstats.avstats.version() \rightarrow str
    Return the version number of the IO-AVSTATS application.
                The version number of the IO-AVSTATS application
    Returns
    Return type str
ioavstats.code_generator module
IO-AVSTATS interface.
ioavstats.code_generator.generate_sql() \rightarrow None
    Generate SQL statements: INSERT & UPDATE.
    The underlying database structures originate from a DDL export of RazorSQL.
ioavstats.db_ddl_base module
Managing the database schema of the PostgreSQL database.
ioavstats.db_ddl_base.create_db_schema ( ) \rightarrow None
    Create the database schema.
ioavstats.db_ddl_base.refresh_db_schema ( ) \rightarrow None
    Refresh the database schema.
ioavstats.db_ddl_base.update_db_schema() \rightarrow None
    Update the database schema.
ioavstats.db_dml_base module
Managing the database schema of the PostgreSQL database.
ioavstats.db_dml_base.download_us_cities_file() → None
    Download a US zip code file.
ioavstats.db_dml_base.download_zip_code_db_file() \rightarrow None
    Download the ZIP Code Database file.
```

4.1. ioaystats 35

```
ioavstats.db dml base.load airport data() \rightarrow None
    Load airports.
ioavstats.db_dml_base.load_aviation_occurrence_categories() \rightarrow None
    Load aviation occurrence categories.
ioavstats.db_dml_base.load_country_state_data() \rightarrow None
    Load country and state data.
ioavstats.db_dml_base.load_sequence_of_events() → None
    Load sequence of events sequence data.
ioavstats.db_dml_base.load_simplemaps_data() \rightarrow None
    Load simplemaps data.
ioavstats.db_dml_base.load_zip_codes_org_data() → None
    Load ZIP Code Database data.
ioavstats.db dml corr module
Managing the database schema of the PostgreSQL database.
ioavstats.db_dml_corr.ROW: list[OrderedDict]
ioavstats.db_dml_corr.cleansing_postgres_data() \rightarrow None
    Cleansing PostgreSQL data.
ioavstats.db_dml_corr.correct_dec_lat_lng() \rightarrow None
    Correct decimal latitude and longitude.
ioavstats.db_dml_corr.find_nearest_airports() → None
    Find the nearest airports.
ioavstats.db_dml_corr.load_correction_data (filename: str) \rightarrow None
    Load data from a correction file into the PostgreSQL database.
    Args:
         filename (str):
              The MS Excel file.
ioavstats.db_dml_corr.verify_ntsb_data() \rightarrow None
    Verify selected NTSB data.
ioavstats.db dml msaccess module
Managing the database schema of the PostgreSQL database.
ioavstats.db_dml_msaccess.load_ntsb_msaccess_data ( msaccess: str ) \rightarrow None
    Load data from MS Access to the PostgreSQL database.
    Args:
         msaccess (str):
              The MS Access database file without file extension.
ioavstats.db_dml_msaccess.download_ntsb_msaccess_file (msaccess: str) \rightarrow None
    Download an MS Access database file.
    Args:
         msaccess (str):
```

The MS Access database file without file extension.

# ioavstats.glob local module Global constants and variables. ioavstats.user\_guide module Creation of the user guide. ioavstats.user\_guide.get\_ae1982\_app ( ) $\rightarrow$ None ae1982 - Creates the user guide for the whole application. ioavstats.user\_guide.get\_ae1982\_bar\_chart ( chart\_id: str, chart\_title: str ) $\rightarrow$ None ae1982 - Creates the user guide for bar charts. ioavstats.user\_guide.get\_pd1982\_app ( ) $\rightarrow$ None pd1982 - Creates the user guide for the whole application. ioavstats.user\_guide.get\_pd1982\_data\_profile() $\rightarrow$ None pd1982 - Creates the user guide for the 'Show data profile' task. ioavstats.user\_guide.get\_pd1982\_details() $\rightarrow$ None pd1982 - Creates the user guide for the 'Show details' task. ioavstats.utils module Application Utilities. ioavstats.utils.get\_args() $\rightarrow$ str Load the command line arguments into the memory. ioavstats.utils.get\_engine (settings: LazySettings) → Engine Create a simple user PostgreSQL database engine. ioavstats.utils.get\_postgres\_connection ( ) → <module 'psycopg.connection' from 'C:\\ProgramData\\miniconda3\\envs\\ioavstats\\Lib\\site-packages\\psycopg\\connection.py'> Create a PostgreSQL connection. ioavstats.utils.**prepare\_latitude** ( *latitude\_string: str* ) → str Prepare a latitude structure. Args: latitude\_string (str): Latitude string. Returns: str: Latitude structure. ioavstats.utils.prepare\_longitude(longitude\_string: str) → str Prepare a longitude structure. Args: longitude\_string (str): longitude string. Returns: str: longitude structure.

pg\_conn (connection): Database connection. app\_id (str): Application name.

(

'C:\\ProgramData\\miniconda3\\envs\\ioavstats\\Lib\\site-packages\\psycopg\\connection.py'>,

ioavstats.utils.present\_about

Present the 'about' information.

app id: str)  $\rightarrow$  None

Args:

4.1. ioaystats 37

pg\_conn:

<module

'psycopg.connection'

from

ioavstats.utils.upd\_io\_processed\_files ( file\_name: str, cur\_pg: <module 'psycopg.cursor' from 'C:\\ProgramData\\miniconda3\\envs\\ioavstats\\Lib\\site-packages\\psycopg\\cursor.py'> )  $\rightarrow$  None

Update the database table io\_processed\_files.

#### ioavstats.utils\_msaccess module

Miscellaneous helper functions.

```
ioavstats.utils_msaccess.get_msaccess_cursor ( filename: str ) \rightarrow tuple[Connection, Cursor]
```

Create an MS Access cursor.

Args:

filename (str): MS Access filename.

Returns:

tuple[pyodbc.Connection,pyodbc.Cursor]: ODBC database connection and cursor.

#### **Module contents**

IO-AVSTATS.

### **About**

This section provides additional context and legal information about IO-AVSTATS, including release notes and licensing details.

## **5.1 Release Notes**

### 5.1.1 Version 24.04.22

Release Date: 22.04.2024

### **Modified Features**

- Migration to Python 3.11.
- pipenv replaced by conda.

#### **Applied Software**

Software	Version	Remark	Status
Docker Desktop	4.29.0		upgrade
Python	3.11.wwe		upgrade
RazorSQL	10.5.4		upgrade

#### Windows-specific Software

Important: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

#### **Processed files**

NTSB - National Transport Safety Board Data source up22APR.zip

• Download link: 04/22/2024 3:00:19 AM

### 5.1.2 Version 24.04.15

Release Date: 15.04.2024

#### **Modified Features**

• Removing CodeArtifact.

#### **Applied Software**

Software	Version	Remark	Status
Docker Desktop	4.28.0		
Python	3.10.11		
RazorSQL	10.5.3		

Windows-specific Software

Important: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

#### **Processed files**

NTSB - National Transport Safety Board

Data source up15APR.zip

• Download link: 04/15/2024 3:00:27 AM

#### 5.1.3 Version 24.04.08

Release Date: 08.04.2024

### **Modified Features**

• Removing CodeArtifact.

### **Applied Software**

Software	Version	Remark	Status
Docker Desktop	4.28.0		
Python	3.10.11		
RazorSQL	10.5.3		

Windows-specific Software

**Important**: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

#### **Processed files**

NTSB - National Transport Safety Board

Data source up08APR.zip

• Download link: 04/08/2024 3:00:20 AM

#### 5.1.4 Version 24.04.01

Release Date: 01.04.2024

**Applied Software** 

Software	Version	Remark	Status
AWS CLI	2.15.34		upgrade
Docker Desktop	4.28.0		
Python	3.10.11		
RazorSQL	10.5.3		

Windows-specific Software

Important: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

#### **Processed files**

FAA - Aeronautical data Delivery Service

Data source Airports

• Download link: Version: 03/21/2024

Data source Runways

• Download link: Version: 03/21/2024

NTSB - National Transport Safety Board

Data source avall.zip

• Download link: 04/01/2024 06:09:05 AM

Data source up01APR.zip

• Download link: 04/01/2024 3:00:22 AM

#### 5.1.5 Version 24.03.22

Release Date: 22.03.2024

**Modified Features** 

• Applying ruff to the code.

#### **Applied Software**

Software	Version	Remark	Status
AWS CLI	2.15.31		upgrade
Docker Desktop	4.28.0		
Python	3.10.11		
RazorSQL	10.5.3		

Windows-specific Software

**Important**: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

#### **Processed files**

NTSB - National Transport Safety Board

Data source up15MAR.zip

• Download link: 03/22/2024 3:00:23 AM

#### 5.1.6 Version 24.03.15

Release Date: 15.03.2024

**Modified Features** 

• Using Pandas to load csv, xls and xlsx data.

#### **Applied Software**

Software	Version	Remark	Status
AWS CLI	2.15.29		upgrade
Docker Desktop	4.28.0		
Python	3.10.11		
RazorSQL	10.5.3		

Windows-specific Software

Important: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

#### **Processed files**

NTSB - National Transport Safety Board

Data source up15MAR.zip

• Download link: 03/15/2024 8:28:07 AM

#### 5.1.7 Version 24.03.08

Release Date: 08.03.2024

### **Applied Software**

Software	Version	Remark	Status
AWS CLI	2.15.26		upgrade
Docker Desktop	4.28.0		upgrade

Python	3.10.11	
RazorSQL	10.5.3	

#### Windows-specific Software

Important: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

#### **Processed files**

FAA - Aeronautical data Delivery Service

Data source Airports

• Download link: Version: 02/21/2024

Data source Runways

• Download link: Version: 02/20/2024

NTSB - National Transport Safety Board

Data source up08MAR.zip

• Download link: 03/08/2024 3:00:14 AM

#### 5.1.8 Version 24.03.01

Release Date: 01.03.2024

**Applied Software** 

Software	Version	Remark	Status
AWS CLI	2.15.20		
Docker Desktop	4.27.2		upgrade
Python	3.10.11		
RazorSQL	10.5.3		

#### Windows-specific Software

Important: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

Installation details
<ul> <li>Visual Studio core editor</li> </ul>
<ul> <li>Desktop development with C++</li> </ul>
▼ Included
✓ C++ core desktop features
▼ Optional
✓ MSVC v143 - VS 2022 C++ x64/x86 build t
C++ ATL for latest v143 build tools (x86 &
Windows 11 SDK (10.0.22000.0)
Security Issue Analysis
Just-In-Time debugger
C++ profiling tools
C++ CMake tools for Windows
Test Adapter for Boost.Test
Test Adapter for Google Test
Live Share
IntelliCode
C++ AddressSanitizer
vcpkg package manager
C++ MFC for latest v143 build tools (x86
C++ Modules for v143 build tools (x64/x8
Windows 11 SDK (10.0.22621.0)
C++/CLI support for v143 build tools (Late
C++ Clang tools for Windows (15.0.1 - x64
JavaScript diagnostics
Incredibuild - Build Acceleration
Windows 10 SDK (10.0.20348.0)
✓ Windows 10 SDK (10.0.19041.0)
Windows 10 SDK (10.0.18362.0)
MSVC v142 - VS 2019 C++ x64/x86 build t
MSVC v141 - VS 2017 C++ x64/x86 build t
MSVC v140 - VS 2015 C++ build tools (v1
Windows App SDK C++ Templates

## **Processed files**

NTSB - National Transport Safety Board Data source avall.zip

• Download link: 03/01/2024 06:03:06 AM

Data source up01MAR.zip

• Download link: 03/01/2024 3:00:23 AM

#### 5.1.9 Version 24.02.22

Release Date: 22.02.2024

**Applied Software** 

Software	Version	Remark	Status
AWS CLI	2.15.20		
Docker Desktop	4.27.1		
Python	3.10.11		
RazorSQL	10.5.3		

Windows-specific Software

**Important**: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

#### **Processed files**

NTSB - National Transport Safety Board

Data source up22FEB.zip

• Download link: 02/22/2024 3:00:14 AM

### 5.1.10 Version 24.02.15

Release Date: 15.02.2024

**Applied Software** 

Software	Version	Remark	Status
AWS CLI	2.15.20		upgrade
Docker Desktop	4.27.1		upgrade
Python	3.10.11		
RazorSQL	10.5.3		

Windows-specific Software

**Important**: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		

#### **Processed files**

NTSB - National Transport Safety Board

Data source up15FEB.zip

• Download link: 02/15/2024 3:00:23 AM

## 5.1.11 Version 24.02.08

Release Date: 08.02.2024

## **Applied Software**

Software	Version	Remark	Status
AWS CLI	2.15.16		upgrade
Docker Desktop	4.26.1		
PostgreSQL	16.1		
Python	3.10.11		
RazorSQL	10.5.3		upgrade

Windows-specific Software

**Important**: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
The LLVM Compiler Infrastructure	17.0.6		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		
Visual Studio Community 2022	2022		

Installation details
<ul> <li>Visual Studio core editor</li> </ul>
<ul> <li>Desktop development with C++</li> </ul>
▼ Included
✓ C++ core desktop features
▼ Optional
✓ MSVC v143 - VS 2022 C++ x64/x86 build t
C++ ATL for latest v143 build tools (x86 &
Windows 11 SDK (10.0.22000.0)
Security Issue Analysis
Just-In-Time debugger
C++ profiling tools
C++ CMake tools for Windows
Test Adapter for Boost.Test
Test Adapter for Google Test
Live Share
IntelliCode
C++ AddressSanitizer
vcpkg package manager
C++ MFC for latest v143 build tools (x86
C++ Modules for v143 build tools (x64/x8
Windows 11 SDK (10.0.22621.0)
C++/CLI support for v143 build tools (Late
C++ Clang tools for Windows (15.0.1 - x64
JavaScript diagnostics
Incredibuild - Build Acceleration
Windows 10 SDK (10.0.20348.0)
✓ Windows 10 SDK (10.0.19041.0)
Windows 10 SDK (10.0.18362.0)
MSVC v142 - VS 2019 C++ x64/x86 build t
MSVC v141 - VS 2017 C++ x64/x86 build t
MSVC v140 - VS 2015 C++ build tools (v1
Windows App SDK C++ Templates

## **Processed files**

NTSB - National Transport Safety Board Data source up08FEB.zip

• Download link: 02/08/2024 3:00:18 AM

## 5.1.12 Version 24.02.01

Release Date: 01.02.2024

## **Applied Software**

Software	Version	Remark	Status
AWS CLI	2.15.16		upgrade
Docker Desktop	4.26.1		
PostgreSQL	16.1		
Python	3.10.11		
RazorSQL	10.5.3		upgrade

### Windows-specific Software

**Important**: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
The LLVM Compiler Infrastructure	17.0.6		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		
Visual Studio Community 2022	2022		

Installation details
Visual Studio core editor
<ul> <li>Desktop development with C++</li> </ul>
▼ Included
✓ C++ core desktop features
▼ Optional
✓ MSVC v143 - VS 2022 C++ x64/x86 build t
C++ ATL for latest v143 build tools (x86 &
Windows 11 SDK (10.0.22000.0)
Security Issue Analysis
Just-In-Time debugger
C++ profiling tools
C++ CMake tools for Windows
Test Adapter for Boost.Test
Test Adapter for Google Test
Live Share
IntelliCode
C++ AddressSanitizer
vcpkg package manager
C++ MFC for latest v143 build tools (x86
C++ Modules for v143 build tools (x64/x8
Windows 11 SDK (10.0.22621.0)
C++/CLI support for v143 build tools (Late
C++ Clang tools for Windows (15.0.1 - x64
JavaScript diagnostics
Incredibuild - Build Acceleration
Windows 10 SDK (10.0.20348.0)
✓ Windows 10 SDK (10.0.19041.0)
Windows 10 SDK (10.0.18362.0)
MSVC v142 - VS 2019 C++ x64/x86 build t
MSVC v141 - VS 2017 C++ x64/x86 build t
MSVC v140 - VS 2015 C++ build tools (v1
☐ Windows App SDK C++ Templates

## **Processed files**

FAA - Aeronautical data Delivery Service

Data source Airports

• Download link: Version: 01/25/2024

Data source Runways

• Download link: Version: 01/25/2024

simplemaps - Interactive Maps & Data Data source United States Cities Database

• Download link: Version: 1.78

Data source US Zip Codes Database

• Download link: Version: 1.84

NTSB - National Transport Safety Board

Data source avall.zip

• Download link: 02/01/2024 06:15:30 AM

Data source up01FEB.zip

• Download link: 02/01/2024 3:00:41 AM

#### 5.1.13 Version 24.01.22

Release Date: 22.01.2024

#### **Modified Features**

• new column 'cm\_inPc' in database table 'findings'

#### **Applied Software**

Software	Version	Remark	Status
AWS CLI	2.15.3		
Docker Desktop	4.26.1		
PostgreSQL	16.1		
Python	3.10.11		
RazorSQL	10.5.2		update

Windows-specific Software

Important: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
The LLVM Compiler Infrastructure	17.0.6		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		
Visual Studio Community 2022	2022		

Installation details
Visual Studio core editor
<ul> <li>Desktop development with C++</li> </ul>
▼ Included
✓ C++ core desktop features
▼ Optional
✓ MSVC v143 - VS 2022 C++ x64/x86 build t
C++ ATL for latest v143 build tools (x86 &
Windows 11 SDK (10.0.22000.0)
Security Issue Analysis
Just-In-Time debugger
C++ profiling tools
C++ CMake tools for Windows
Test Adapter for Boost.Test
Test Adapter for Google Test
Live Share
IntelliCode
C++ AddressSanitizer
vcpkg package manager
C++ MFC for latest v143 build tools (x86
C++ Modules for v143 build tools (x64/x8
Windows 11 SDK (10.0.22621.0)
C++/CLI support for v143 build tools (Late
C++ Clang tools for Windows (15.0.1 - x64
JavaScript diagnostics
Incredibuild - Build Acceleration
Windows 10 SDK (10.0.20348.0)
✓ Windows 10 SDK (10.0.19041.0)
Windows 10 SDK (10.0.18362.0)
MSVC v142 - VS 2019 C++ x64/x86 build t
MSVC v141 - VS 2017 C++ x64/x86 build t
MSVC v140 - VS 2015 C++ build tools (v1
Windows App SDK C++ Templates

## **Processed files**

NTSB - National Transport Safety Board Data source up22JAN.zip

• Download link: 01/22/2024 3:00:11 AM

## 5.1.14 Version 24.01.15

Release Date: 15.01.2024

#### **New Features**

• IO-AVSTATS includes IO-AVSTATS-DB

#### **Modified Features**

• new IO-TEMPLATE-APP version

#### **Applied Software**

Software	Version	Remark	Status
AWS CLI	2.15.3		
Docker Desktop	4.26.1		
PostgreSQL	16.1		
Python	3.10.11		
RazorSQL	10.5.1		

### Windows-specific Software

**Important**: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
The LLVM Compiler Infrastructure	17.0.6		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		
Visual Studio Community 2022	2022		

Installation details
Visual Studio core editor
<ul> <li>Desktop development with C++</li> </ul>
▼ Included
✓ C++ core desktop features
▼ Optional
✓ MSVC v143 - VS 2022 C++ x64/x86 build t
C++ ATL for latest v143 build tools (x86 &
Windows 11 SDK (10.0.22000.0)
Security Issue Analysis
Just-In-Time debugger
C++ profiling tools
C++ CMake tools for Windows
Test Adapter for Boost.Test
Test Adapter for Google Test
Live Share
IntelliCode
C++ AddressSanitizer
vcpkg package manager
C++ MFC for latest v143 build tools (x86
C++ Modules for v143 build tools (x64/x8
Windows 11 SDK (10.0.22621.0)
C++/CLI support for v143 build tools (Late
C++ Clang tools for Windows (15.0.1 - x64
JavaScript diagnostics
Incredibuild - Build Acceleration
Windows 10 SDK (10.0.20348.0)
✓ Windows 10 SDK (10.0.19041.0)
Windows 10 SDK (10.0.18362.0)
MSVC v142 - VS 2019 C++ x64/x86 build t
MSVC v141 - VS 2017 C++ x64/x86 build t
MSVC v140 - VS 2015 C++ build tools (v1
Windows App SDK C++ Templates

## **Processed files**

NTSB - National Transport Safety Board Data source up15JAN.zip

• Download link: 01/15/2024 3:00:19 AM

## 5.1.15 Version 24.01.08

Release Date: 08.01.2024

## **Applied Software**

Software	Version	Remark	Status
AWS CLI	2.15.3		update
Docker Desktop	4.26.1		
PostgreSQL	16.1		
Python	3.10.11		
RazorSQL	10.5.1		

### Windows-specific Software

**Important**: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
The LLVM Compiler Infrastructure	17.0.6		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		
Visual Studio Community 2022	2022		

Installation details		
Visual Studio core editor		
<ul> <li>Desktop development with C++</li> </ul>		
▼ Included		
✓ C++ core desktop features		
▼ Optional		
✓ MSVC v143 - VS 2022 C++ x64/x86 build t		
C++ ATL for latest v143 build tools (x86 &		
Windows 11 SDK (10.0.22000.0)		
Security Issue Analysis		
Just-In-Time debugger		
C++ profiling tools		
C++ CMake tools for Windows		
Test Adapter for Boost.Test		
Test Adapter for Google Test		
Live Share		
IntelliCode		
C++ AddressSanitizer		
vcpkg package manager		
C++ MFC for latest v143 build tools (x86		
C++ Modules for v143 build tools (x64/x8		
Windows 11 SDK (10.0.22621.0)		
C++/CLI support for v143 build tools (Late		
C++ Clang tools for Windows (15.0.1 - x64		
JavaScript diagnostics		
Incredibuild - Build Acceleration		
Windows 10 SDK (10.0.20348.0)		
✓ Windows 10 SDK (10.0.19041.0)		
Windows 10 SDK (10.0.18362.0)		
MSVC v142 - VS 2019 C++ x64/x86 build t		
MSVC v141 - VS 2017 C++ x64/x86 build t		
MSVC v140 - VS 2015 C++ build tools (v1		
Windows App SDK C++ Templates		

## **Processed files**

NTSB - National Transport Safety Board Data source up08JAN.zip

• Download link: 01/08/2024 3:00:17 AM

## 5.1.16 Version 24.01.01

Release Date: 01.01.2024

## **Applied Software**

Software	Version	Remark	Status
AWS CLI	2.15.3		
Docker Desktop	4.26.1		
PostgreSQL	16.1		
Python	3.10.11		
RazorSQL	10.5.1		

### Windows-specific Software

**Important**: All software components should be installed in the 64 bit version!

Software	Version	Remark	Status
7-Zip	23.01		
The LLVM Compiler Infrastructure	17.0.6		
Make for Windows	3.81		
MS Access Database Engine 2016 Redistributable	8/11/2020		
Visual Studio Community 2022	2022		

Installation details		
Visual Studio core editor		
<ul> <li>Desktop development with C++</li> </ul>		
▼ Included		
✓ C++ core desktop features		
▼ Optional		
✓ MSVC v143 - VS 2022 C++ x64/x86 build t		
C++ ATL for latest v143 build tools (x86 &		
Windows 11 SDK (10.0.22000.0)		
Security Issue Analysis		
Just-In-Time debugger		
C++ profiling tools		
C++ CMake tools for Windows		
Test Adapter for Boost.Test		
Test Adapter for Google Test		
Live Share		
IntelliCode		
C++ AddressSanitizer		
vcpkg package manager		
C++ MFC for latest v143 build tools (x86		
C++ Modules for v143 build tools (x64/x8		
Windows 11 SDK (10.0.22621.0)		
C++/CLI support for v143 build tools (Late		
C++ Clang tools for Windows (15.0.1 - x64		
JavaScript diagnostics		
Incredibuild - Build Acceleration		
Windows 10 SDK (10.0.20348.0)		
✓ Windows 10 SDK (10.0.19041.0)		
Windows 10 SDK (10.0.18362.0)		
MSVC v142 - VS 2019 C++ x64/x86 build t		
MSVC v141 - VS 2017 C++ x64/x86 build t		
MSVC v140 - VS 2015 C++ build tools (v1		
Windows App SDK C++ Templates		

#### **Processed files**

NTSB - National Transport Safety Board Data source avall.zip

• Download link: 01/01/2024 06:23:50 AM

Data source up01JAN.zip

• Download link: 01/01/2024 3:00:17 AM

## 5.2 End-User License Agreement

### 5.2.1 End-User License Agreement (EULA) of IO-Aero Software

This End=User License Agreement ("EULA") is a legal agreement between you and IO-Aero.

This **EULA** agreement governs your acquisition and use of our **IO-Aero Software** ("Software") directly from **IO-Aero** or indirectly through a **IO-Aero** authorized reseller or distributor (a "Reseller").

Please read this **EULA** agreement carefully before completing the installation process and using the **IO-Aero Software**. It provides a license to use the **IO-Aero Software** and contains warranty information and liability disclaimers.

If you register for a free trial of the **IO-Aero Software**, this **EULA** agreement will also govern that trial. By clicking "accept" or installing and/or using the **IO-Aero Software**, you are confirming your acceptance of the Software and agreeing to become bound by the terms of this **EULA** agreement.

If you are entering into this **EULA** agreement on behalf of a company or other legal entity, you represent that you have the authority to bind such entity and its affiliates to these terms and conditions. If you do not have such authority or if you do not agree with the terms and conditions of this **EULA** agreement, do not install or use the Software, and you must not accept this **EULA** agreement.

This **EULA** agreement shall apply only to the Software supplied by **IO-Aero** herewith regardless of whether other software is referred to or described herein. The terms also apply to any **IO-Aero** updates, supplements, Internet-based services, and support services for the Software, unless other terms accompany those items on delivery. If so, those terms apply.

#### **License Grant**

**IO-Aero** hereby grants you a personal, non-transferable, non-exclusive licence to use the **IO-Aero Software** on your devices in accordance with the terms of this **EULA** agreement.

You are permitted to load the **IO-Aero Software** (for example a PC, laptop, mobile or tablet) under your control. You are responsible for ensuring your device meets the minimum requirements of the **IO-Aero Software**.

#### You are not permitted to:

- Edit, alter, modify, adapt, translate or otherwise change the whole or any part of the Software nor permit the whole or any part of the Software to be combined with or become incorporated in any other software, nor decompile, disassemble or reverse engineer the Software or attempt to do any such things
- Reproduce, copy, distribute, resell or otherwise use the Software for any commercial purpose
- Allow any third party to use the Software on behalf of or for the benefit of any third party
- Use the Software in any way which breaches any applicable local, national or international law
- use the Software for any purpose that **IO-Aero** considers is a breach of this **EULA** agreement Intellectual Property and Ownership

**IO-Aero** shall at all times retain ownership of the Software as originally downloaded by you and all subsequent downloads of the Software by you. The Software (and the copyright, and other intellectual property rights of whatever nature in the Software, including any modifications made thereto) are and shall remain the property of **IO-Aero**.

**IO-Aero** reserves the right to grant licences to use the Software to third parties.

#### **Termination**

This EULA agreement is effective from the date you first use the Software and shall continue until

terminated. You may terminate it at any time upon written notice to IO-Aero.

It will also terminate immediately if you fail to comply with any term of this **EULA** agreement. Upon such termination, the licenses granted by this **EULA** agreement will immediately terminate, and you agree to stop all access and use of the Software. The provisions that by their nature continue and survive will survive any termination of this **EULA** agreement.

#### **Governing Law**

This **EULA** agreement, and any dispute arising out of or in connection with this **EULA** agreement, shall be governed by and construed in accordance with the laws of the United States.

## Indices and tables

- genindex
- modindex

# **6.1 Repository**

Link to the repository for accessing the source code and contributing to the project: IO-AVSTATS GitHub Repository

## 6.2 Version

This documentation is for IO-AVSTATS version 24.3.22.

```
ioavstats,38
ioavstats.avstats,33
ioavstats.code_generator,35
ioavstats.db_ddl_base,35
ioavstats.db_dml_base,35
ioavstats.db_dml_corr,36
ioavstats.db_dml_msaccess,36
ioavstats.glob_local,37
ioavstats.Menu,33
ioavstats.pages,33
ioavstats.user_guide,37
ioavstats.utils,37
ioavstats.utils_msaccess,38
```

С	get_ae1982_app() (in module ioavstat-
	s.user_guide), 37
check_arg_msaccess() (in module ioavstats.avs- tats), 33	get_ae1982_bar_chart() (in module ioavstat- s.user_guide), 37
check_arg_msexcel() (in module ioavstats.avs- tats), 33	get_args() (in module ioavstats.avstats), 34 get_args() (in module ioavstats.utils), 37
check_arg_task() (in module ioavstats.avstats),	get_engine() (in module ioavstats.utils), 37 get_msaccess_cursor() (in module ioavstats.util-
cleansing_postgres_data() (in module ioavstat- s.avstats), 34	s_msaccess), 38 get_pd1982_app() (in module ioavstat-
cleansing_postgres_data() (in module ioavstat- s.db_dml_corr), 36	s.user_guide), 37 get_pd1982_data_profile() (in module ioavstat-
correct_dec_lat_lng() (in module ioavstats.avs- tats), 34	s.user_guide), 37 get_pd1982_details() (in module ioavstat-
correct_dec_lat_lng() (in module ioavstats.d- b_dml_corr), 36	s.user_guide), 37 get_postgres_connection() (in module ioavstat-
create_db_schema() (in module ioavstats.avs- tats), 34	s.utils), 37
create_db_schema() (in module ioavstats.db_d-	1
dl_base), 35	ioavstats module, 38
D	ioavstats.avstats
download_ntsb_msaccess_file() (in module	module, 33
ioavstats.avstats), 34	ioavstats.code_generator
download_ntsb_msaccess_file() (in module	module, 35
ioavstats.db_dml_msaccess), 36	ioavstats.db_ddl_base
download_us_cities_file() (in module ioavstat-	module, 35
s.db_dml_base), 35	ioavstats.db_dml_base
download_zip_code_db_file() (in module	module, 35
ioavstats.db_dml_base), 35	ioavstats.db_dml_corr
	module, 36
F	ioavstats.db_dml_msaccess
find_nearest_airports() (in module ioavstat-	module, 36
s.avstats), 34	ioavstats.glob_local
find_nearest_airports() (in module ioavstats.d-	module, 37
b_dml_corr), 36	ioavstats.Menu module, 33
	ioavstats.pages
G	module, 33
generate_sql() (in module ioavstats.avstats), 34	ioavstats.user_guide
generate_sql() (in module ioavstats.code_gener-	module, 37
ator), 35	ioavstats.utils

module, 37	<pre>prepare_longitude() (in module ioavstats.utils),</pre>
ioavstats.utils_msaccess	37
module, 38	present_about() (in module ioavstats.utils), 37 progress_msg() (in module ioavstats.avstats),
L	34
load_airport_data() (in module ioavstats.avs- tats), 34	progress_msg_time_elapsed() (in module ioavstats.avstats), 35
load_airport_data() (in module ioavstats.d- b_dml_base), 36	R
load_aviation_occurrence_categories() (in module ioavstats.avstats), 34	refresh_db_schema() (in module ioavstats.avs- tats), 35
load_aviation_occurrence_categories() (in module ioavstats.db_dml_base), 36	refresh_db_schema() (in module ioavstats.d- b_ddl_base), 35
load_correction_data() (in module ioavstat- s.avstats), 34	ROW (in module ioavstats.db_dml_corr), 36
load_correction_data() (in module ioavstats.d-b_dml_corr), 36	T torminate fatal() (in module icovertate average)
load_country_state_data() (in module ioavstat- s.avstats), 34	terminate_fatal() (in module ioavstats.avstats), 35
load_country_state_data() (in module ioavstat- s.db_dml_base), 36	U
load_ntsb_msaccess_data() (in module ioavstat- s.avstats), 34	upd_io_processed_files() (in module ioavstat- s.utils), 38
load_ntsb_msaccess_data() (in module ioavstat-s.db_dml_msaccess), 36	update_db_schema() (in module ioavstats.avs- tats), 35
load_sequence_of_events() (in module ioavstat- s.avstats), 34	update_db_schema() (in module ioavstats.d- b_ddl_base), 35
load_sequence_of_events() (in module ioavstat- s.db_dml_base), 36	V
load_simplemaps_data() (in module ioavstat- s.avstats), 34	verify_ntsb_data() (in module ioavstats.avstats), 35
load_simplemaps_data() (in module ioavstat- s.db_dml_base), 36	verify_ntsb_data() (in module ioavstats.db_dm-l_corr), 36
load_zip_code_db_data() (in module ioavstat- s.avstats), 34	version() (in module ioavstats.avstats), 35
load_zip_codes_org_data() (in module ioavstat- s.db_dml_base), 36	
M	
module	
ioavstats, 38	
ioavstats.avstats, 33	
ioavstats.code_generator, 35	
ioavstats.db_ddl_base, 35	
ioavstats.db_dml_base, 35	
ioavstats.db_dml_corr, 36	
ioavstats.db_dml_msaccess, 36	
ioavstats.glob_local, 37	
ioavstats.Menu, 33	
ioavstats.pages, 33 ioavstats.user_guide, 37	
ioavstats.utils, 37	
ioavstats.utils_msaccess, 38	
P	
•	
prepare_latitude() (in module ioavstats.utils), 37	

66 Index