

### **Networks and Protocols 1**

**Basic Concepts** 

### Agenda

- Basic networking concepts
- Fundamentals of data transmission, a review of basic concepts
- MAC layer
- Network layer
- Networks for IoT


### Computer network

- A set of computers interconnected some way with the purpose of communicate with each other
  - Has SW and HW components
- Issues to solve
  - Scalability
  - Addressing
  - Interconnection
  - Routing
  - Reliability
  - Security
  - Privacy



# connections

- Easiest and most intuitive way to interconnect computers
- The number of links increases exponentially with the number of devices
  - o n devices implies n(n-1)/2 links
    - **Problem:** large amount of cables and I/O ports on each device
    - Solution: diffusion/commuted LAN and WAN



#### Types of Networks: Local Area Networks

#### Local Area Networks (LAN)

- Private
- Limited coverage
  - Interconnects devices in a home, office or building
- Each device has a unique identifier in the network: its address
  - Messages are labeled with the source and destination addresses

#### Types of LAN


- Broadcast LAN
  - Computers interconnected by a shared transmission medium
  - When a computer wants to send information, it diffused it through the media to all the rest of connected devices
  - If two or more devices transmit simultaneously a collision happens and the resulting information is invalid
- Switched LAN
  - Computers interconnected through a switch
  - The information is sent only to the destination device
  - Free of collisions




#### Types of networks: Local Area Networks

#### LAN topologies

- Broadcast LAN
  - Common cable (bus)
    - Example: Ethernet 10Base2








- Example: Ethernet 10Base-T
- Wireless LAN (WLAN)
  - The Access Point (AP) acts as a wireless hub
  - Example: Wi-Fi




- Switch (start)
  - Example: Fast Ethernet 100BASE-TX












#### Types of networks: Wide Area Networks

#### Wide Area Network (WAN)

- Cover a larger geographical area (city, country or even global)
- Usually of public access, managed by telecoms


#### Types of WAN

- WAN point to point
  - Connect two devices by a transmission medium (air, cable, optic fiber)
  - Examples: conventional modem or ADSL between the home computer and the Internet Service Provider (ISP)



#### Types of networks: Wide Area Networks


- Types of WAN (continuation)
  - Circuit Switched WAN
    - A dedicated connection is established (circuit) between the two devices
    - The switches do not process the information
      - They only establish the required circuits for the connection
    - Example: Public Switched Telephone Network (PSTN)






#### Types of networks: Wide Area Networks

- Types of WAN (continuation)
  - Packet Switched WAN
    - The information is divided in blocks (packets or segments)
    - The switches process the packets performing two basic functions:
      - Packet routing: decide which is the best route from source to destination
      - Packet forwarding: select the next node to sent a packet based on the routing information





- A internet is formed by connecting several networks
- Nodes are connected locally forming LANs, these are interconnected by WANs
- Specific nodes are used to organize the traffic (routers/gateways)



#### UNIVERSIDAD COMPLUTENSE MADRID

#### The OSI Model

- OSI (Open Systems Interconnection), developed by the International Organization for Standardization (ISO)
  - Covers all the aspects involved in communications (late 70's)
  - Its goal is to enable the communication of two devices regardless of the subjacent technologies
- It is a model for the development of protocols
  - Each layer is meant to include specific purpose protocols

	ПО		
	llic		on
IJĸ	ш	CI U	UII

**Specific Application** 

**Presentation** 

Information representation, encriptation

Session

Authentication, reconnections after disconnection

**Transport** 

End-to-end connections and reliability

**Networking** 

Global addressing and routing

**Data Link** 

Link addressing

**Physical** 

Medium access and bit transmision











OSI Model

TCP/IP 5 layer Model (generic)

TCP/IP on Ethernet

TCP/IP on Public phone

**Application** 

Presentation

Session

Transport

Network

Data Link

Physical

**Application** 

TCP-UDP

IP

MAC

Physical

**Application** 

TCP-UDP

IP

Ethernet

10BASE-T, 100BASE-TX, ... Application

TCP-UDP

IP


PPP

dial-up modem or ADSL



#### TCP/IP architecture

- Layers 5, 4 and 3 are end-to-end (internet)
- Layers 2 and 1 are step-by-step, between host and router or between routers (link)





### Main network devices

- **Hubs:** Work at the physical layer (level 1)
  - Retransmit bit by bit what they receive through one port to the rest of its ports
  - They can connect devices or network segments of the same type and speed
- Switches: are devices that work at the data link layer (level 2)
  - Send a frame to the corresponding output according to the destination MAC address
  - Can store the complete frame and check for errors
  - Can interconnect devices and networks of the same type, even if they work at different speeds (e.g. 100Base-TX and 1000Base-T)
- Routers: are devices that work at the network layer (level 3)
  - Can interconnect networks of different types
  - They perform two basic operations:
    - Format conversions
    - Routing




### TCP/IP protocols architecture

#### **Encapsulation**

- At each level the protocol adds a header to the message (payload) that contains information specific for that protocol
- The transport header includes information of the source and destination processes, error control (e.g. checksums) or flow control
- The network layer adds information about the source and destination devices, error control and fragmentation
- The MAC layer includes the L2 addresses of the two devices communicating at that step


#### **Reception**

- Each layer processes its corresponding header and sends the payload to the next layer protocol
- Errors are checked at each level
- Routers can assemble a new packet for the next step, the datagram (3) is barely modified






### NP1: networking infrastructure



#### What is covered in NP1

#### New Protocols adapted to IoT



### Agenda

- Basic networking concepts
- Fundamentals of data transmission, a review of basic concepts
- MAC layer
- Network layer
- Networks for IoT



### Digital communication: data and signals

• **Data**: transmitted information, sequence of bits

o e.g.: 10110001


Signals: electromagnetic codification used to send information


through a medium

Digital: base band




Analog: digital signal modulates an analog carrier signal






### Signal and data elements


- Data elements: binary digit bit -
- Signal elements:
  - Symbol: waveform used to represent the bits
    - It has a certain time duration
  - With V = 2<sup>R</sup> different symbols we can represent R bits per symbol
    - R < 1: more than one symbol is used to represent one bit (redundancy)</li>
- Transmission rate
  - Bauds: transmission rate in symbols/s
  - bps: transmission rate in bits/s (bps = R x bauds)








### Digital transmission (base band)



### Analog transmission (wide band)

#### Sinusoid signal components:

- $s(t) = A \sin(2 \pi f t + \Phi)$ , where:
- ullet A o amplitude
- $\bullet$  f  $\rightarrow$  frequency
- $\bullet$   $\Phi$   $\rightarrow$  phase
- T=1/f  $\rightarrow$  period




#### Analog transmission: modulation


#### **Basic schemes**


- ASK (Amplitude Shift Key)
- FSK (Frequency Shift Key)
- PSK (Phase Shift Key)

#### Advanced schemes:

- QPSK
- 8-QAM
- ...










### Frequency Division Multiplexing (FDM)






### Time Division Multiplexing (TDM)


Temporal split of the channel

- Time is splitted in slots
- Each slot is assigned to a soul




#### Two alternatives

Synchronous: static slot



Statistical: dynamic slot as






### Channel properties

Attenuation:

$$\circ \quad A_{dB} = 10 \cdot \log(P_R/P_T)$$




Low pass: fi == 0

Band pass: fi != 0

Modulation required








Canal paso-baja

Amplitud










# Electromagnetic wave propagation

- Line of sight: direct transmission between sender and receiver, without obstacles
  - Signals are attenuated with the distance



- Obstacles: signals are attenuated by the obstacles
  - The absorption increases with material conductivity



# Electromagnetic wave propagation

Free Space Loss en dB:

$$L_{fs} = 32.45 + 20 \log D + 20 \log f$$

D: Distance between the sender and receiver in Km

f: frequency in MHz

E.g. 
$$f = 868MHz$$

D = 0.01 km, 
$$L_{fc}$$
 = 32.45 + 20 log(0.01) + 20 log(868) = 51 dB

D = 0.05 km, 
$$L_{fs}$$
 = 32.45 + 20 log(0.05) + 20 log(868) = 65 dB

D = 0.10 km, 
$$L_{fs}$$
 = 32.45 + 20 log(0.10) + 20 log(868) = 71 dB


D = 0.50 km, 
$$L_{fc}$$
 = 32.45 + 20 log(0.50) + 20 log(868) = 85 dB

D = 1.00 km, 
$$L_{fs}$$
 = 32.45 + 20 log(1.00) + 20 log(868) = 91 dB




# Electromagnetic wave propagation

Obstacles can also reflect waves



Or diffract the transmitted signal





### Fresnel Zones

Points of space in which a reflection produces a shift in phase proportional to  $\lambda/2$  with respect to the direct wave:

$$D = d1 + d2$$

$$\overline{AP} + \overline{PB} - D = n\frac{\lambda}{2}$$


$$\sqrt{r_n^2+d1^2}+\sqrt{r_n^2+d1^2}-D=nrac{\lambda}{2}$$

$$\sqrt{1+x^2} pprox 1 + rac{x^2}{2}$$

$$d1(1+rac{r_n^2}{2d1^2})+d2(1+rac{r_n^2}{2d2^2})-D=nrac{\lambda}{2}$$

$$r_n^2(rac{1}{d1}+rac{1}{d2})=n\lambda$$

$$r_n = \sqrt{n\lambdarac{d1d2}{d1+d2}}$$



In the mid point:

$$d1=d2=D/2 \ r_n=\sqrt{n\lambda D/4}=\sqrt{rac{nc}{4}rac{D}{f}}$$

$$r_n = 8.657 \sqrt{n rac{D}{f}}$$
 Direction


Obstacles should be avoided in the first Fresnel zone




### **Fresnel Zones**

The radius of the fresnel zones increase with the distance

 Antennas can be lifted up to avoid reflexions with the ground and other obstacles








### Earth curvature

The expression  $r = 8.657 \times \text{sqrt}(D / f)$  does not take the earth curvature into account



$$\theta = D/R$$
 $H = R - R \cos(\theta/2)$ 
 $\cos(\theta/2) \approx 1 - (\theta/2)^2/2 = 1 - \theta^2/8 = 1 - D^2/(8R^2)$ 
 $H = D^2/(8R)$ 

$$H = 1000 \cdot D^2/(8 \cdot R)$$

H height in km


R earth radius (6371 km)

D Distance between sender and receiver in km



## Earth Curvature

#### https://www.zytrax.com/tech/wireless/calc.htm#fresnel




D (km)	H (m)	
0.1	negligible	
0.5	negligible	
1	negligible	
2	negligible	
5	0.49	

D (km)	H (m)	
10	1.96	
15	4.41	
20	7.84	
25	12.26	
30	17.65	



# Fresnel zone: rule of thumb 60/40

A good compromise is to have at least 60% of the first fresnel zone free of obstacles




f = 868MHz

D (km)	r (m)	H (m)	0.6 r (m)	0.6r + H (m)
0.1	2.94	0.0002	1.76	1.76
0.5	6.57	0.0049	3.94	3.95
1	9.29	0.0196	5.57	5.59
2	13.14	0.0785	7.88	7.96
5	20.78	0.4905	12.47	12.96
10	29.38	1.9620	17.63	19.59



# COMPLUTENSE Received Signal Strength Indication (RSSI)

- Received power, expressed in dBm
- Is an indication of how well the emitted signal is received
  - Usually a negative value, the closer to zero the better





# Link Margin




**RSSI - Received Signal Strength Indication** 



# Effective Isotropic Radiated Power (EIPR)


- Effective radiated power with respect to a hypothetical isotropic antenna
  - The gain of the emitter antenna is expressed in dBi





### **Effective Radiated Power (ERP)**

- Effective radiated power with respect to an half wave dipole antenna ( $\lambda/2$ )
  - The gain of the emitter antenna is expressed in dBd



ERIP (dBm) = ERP (dBm) + 2.15



# Agenda

- Basic networking concepts
- Fundamentals of data transmission, a review of basic concepts
- MAC layer
- Network layer
- Networks for IoT



### **MAC** layer

### Responsibilities:


- Framing
- Identification (seq. numbers and MAC addressing)
- Error detection
- Medium access and collision detection

#### **Ethernet networks**

#### Ethernet MAC protocol

- Ethernet uses CSMA/CD as MAC protocol, which is based on CSMA
  - CSMA = Carrier Sense Multiple Access
  - CSMA/CD = Carrier Sense Multiple Access / Collision Detection
  - Both are distributed protocols and collisions are possible
  - CSMA/CD is more efficient as it can detect collisions and effectively react to them


- When a computer has a frame ready to be sent, it first listens the channel, and sends only if it is free
- Each frame must be acknowledged (ACK) by the receiver to confirm a correct reception without collisions
- In case of collisions:
  - If the computers involved retransmit immediately after the time-out for an ACK reception, a collision will happen again
  - To avoid it the computers must wait a random backoff time to start a new transmission





### CSMA/CD

- The emitter listen the channel while the frame is being send
- If the listened signal differs from the send signal, a collision is detected
- The transmission must last long enough for a transmission started at the farthest point be perceived before the end of the frame transmission





# Agenda

- Basic networking concepts
- Fundamentals of data transmission, a review of basic concepts
- MAC layer
- Network layer
- Networks for IoT

# Network layer: IP protocol

#### **Internet Network Protocol**

- Provides a basic datagram delivery service
  - TCP/IP networks are build on top of this service
- It is a connectionless oriented protocol (not reliable)
  - It does not detect nor recover lost or erroneous datagrams
  - Datagrams are not guaranteed to arrive in order
  - Duplicate datagrams are not detected/removed

#### **Basic responsibilities of the IP protocol**

- Global addressing
  - Unique address in the Internet
- Datagram Fragmentation and reassembly
  - Datagram is divided into fragments of the appropriate size for the underlying network
- Forwarding of datagrams
  - Forwarding is done based on the routing information stored in routing tables
  - The information in routing tables can be:
    - Static: manually filled by system administrator
    - Dynamic: filled by some routing protocol that uses the IP services, like RIP, OSPF, BGP, etc.


# IPv4: datagram format

HEADER

0	4	8 1	6 19	9	31
Version	IHL	Service type	Total Length		
Id			Flags	Fragment offset	
Time To Live		Protocol	Checksum		
Source IP address					
Destination IP address					
Options					
Data					



# IPv4: Fragmentation



- IPv4 addresses are 4 bytes (32 bits)
  - Dot Notation: each byte in decimal notation, with dot separator between bytes
  - Example: 128.2.7.9 = 10000000 . 00000010 . 00000111 . 00001001
- Types of addresses
  - Unicast: a single host
  - Multicast: a group of hosts
  - Broadcast: All hosts in my local network



# Routing: Introduction to

- Routing: in a packet switched network the routing algorithm must find a path from source to destination traversing the intermediate switches or routers
- In caso of more than one valid path, the "best" one must be selected
- A metric must be selected to choose which path is the "best"
  - Number of hops: takes into account the number of intermediate routers that must be traversed to reach the destination
  - **Geographical distance**: takes into account the distance (in km) of the path
  - Average latency: usually equivalent to geographical distance, as latency is usually proportional to the length of the lines
  - Band width: takes into account the band width of each of the networks that must be traversed
  - Amount of traffic: takes into account the average usage of the lines in the path, trying to avoid saturation/congestion



# Routing: Introduction to

#### **Local Routing:**

- No information of the network topology
- E.g. flooding


#### Static Routing:

- The network administrator manually decides the routing tables based on his knowledge of the network topology
- The network cannot adapt automatically to changes in the topology Dynamic Routing:
  - The routing tables are build automatically, based on periodic information interchange between the routers in the network
  - No need for manual configuration
  - They adapt automatically to changes in the network
- Two common approaches
  - Distance vector algorithms: e.g. RIP
  - Link state algorithms: e.g. OSPF

# IPv4 forwarding

#### **Routing tables in IPv4**

Example: assume the following network



Red 200.16.2.0/24

• The routing table for host A could be the following:

```
# route -n
       Kernel IP routing table
       Destination
                      Gateway
                                    Genmask
                                                      Flags
                                                                  Iface
       200.16.1.0
                      0.0.0.0
                                     255.255.255.0
                                                      U
                                                               eth0
       200.16.2.0
                      200.16.1.20
                                     255.255.255.0
                                                               eth0
                                                      UG
       200.16.3.1
                      200.16.1.20
                                     255.255.255.255
                                                      UGH
                                                               eth0
4--->
       0.0.0.0
                      200.16.1.10
                                     0.0.0.0
                                                               eth0
                                                      UG
```

#### IPv4 is obsolete



- IPv4 uses 32 bits addresses
  - Máximum of 4.294.967.296 different addresses
  - Class addressing does not allow to use them all (~250 million)
- Problem with class addressing
  - A lot of class B addresses are required, we have run out of them
  - Several consecutive class C addresses have been used as a superclass network address to solve this problem
  - Routing tables growth too large
- CIDR (Classless Interdomain Routing) alleviates the problem
  - The routing tables store also the network mask
    - Helps to reduce the number of entries required in the routing tables
    - · We can assign blocks of addresses better suited to the required size
- NAT (Network Address Translation) is used to save public IP addresses
  - A router hides a local network from the rest of the Internet.
  - The routers appears as a single machine with only one public IP address to the rest of the Internet
  - CG-NAT (Carrier Grade NAT) used by ISP as a double NAT
    - Your router has no more a public IP, you cannot serve from home!
      WE RUNNED OUT OF IPv4 ADDRESSES!!!


### Agenda

- Basic networking concepts
- Fundamentals of data transmission, a review of basic concepts
- MAC layer
- Network layer
- Networks for IoT



#### Wireless networks for IoT


- Simple protocols, with low bandwidth and low power consumption
  - Efficient bandwidth exploitation is key
  - Simple nodes, low computational capabilities, battery powered
- Disparity of ranges
  - Personal Area Networks (PAN)
  - Wide area Networks (WAN)
- Large number of nodes, with low bandwidth
  - Gateway, interface with the exterior
  - Limited Bandwidth
  - Several topologies possible





### Specific IoT stacks

- IETF (Internet Engineering Task Force) has developed alternative protocols (designed specifically) for IoT on top of IPv6
- The IPSO (Internet Protocol for Smart Objects) Alliance has published alternative standards and protocols for each layer of the TCP/IP stack





### Global perspective



Short Range Communicating Devices



Bluetooth 4.8



#### 35% SOM

- ✓ Well established standards
- ✓ Good for:
  - Mobile devices
  - In-home
  - Short range
- Not good:
  - Battery life
  - Long range



Long Range w/ Battery Internet of Objects



#### 55% **SOM**

- Emerging PHY solutions
- ✓ Good for:
  - Long range
  - Long battery
  - Low cost
  - Positioning
- Not good:
  - High data-rate



Long Range w/Power Traditional M2M



10% SOM

- ✓ Well established standards
- ✓ Good for:
  - Long range
  - High data-rate
  - Coverage
- Not good:
  - Battery life
  - Cost