Day 2

- Unsigned Binary Integers and 2s-Complement
- Signed Negation and Signed Extension
- Stored Program Computers
- Representing Instructions
- Logical Operations
- Conditional Operations
 - Compiling If Statements
 - Compiling Loop Statements



Unsigned Binary Integers

Given an n-bit number

$$x = x_{n-1}2^{n-1} + x_{n-2}2^{n-2} + \Box + x_12^1 + x_02^0$$

- Range: 0 to +2ⁿ 1
- Example
 - 0000 0000 0000 0000 0000 0000 0000 1011₂ = 0 + ... + $1 \times 2^3 + 0 \times 2^2 + 1 \times 2^1 + 1 \times 2^0$ = 0 + ... + 8 + 0 + 2 + 1 = 11_{10}
- Using 32 bits
 - 0 to +4,294,967,295



2s-Complement Signed Integers

Given an n-bit number

$$x = -x_{n-1} 2^{n-1} + x_{n-2} 2^{n-2} + \Box + x_1 2^1 + x_0 2^0$$

- Range: −2ⁿ⁻¹ to +2ⁿ⁻¹ − 1
- Example
- Using 32 bits
 - -2,147,483,648 to +2,147,483,647



2s-Complement Signed Integers

- Bit 31 is sign bit
 - 1 for negative numbers
 - 0 for non-negative numbers
- $-(-2^{n-1})$ can't be represented
- Non-negative numbers have the same unsigned and 2s-complement representation
- Some specific numbers
 - 0: 0000 0000 ... 0000
 - —1: 1111 1111 ... 1111
 - Most-negative: 1000 0000 ... 0000
 - Most-positive: 0111 1111 ... 1111



Signed Negation

- Complement and add 1
 - Complement means 1 → 0, 0 → 1

$$X + \overline{X} = 1111...111_2 = -1$$

$$\overline{x} + 1 = -x$$

- Example: negate +2
 - $+2 = 0000 \ 0000 \ \dots \ 0010_2$
 - $-2 = 1111 \ 1111 \dots \ 1101_2 + 1$ = 1111 \ 1111 \ \dots \ 1110_2



Sign Extension

- Representing a number using more bits
 - Preserve the numeric value
- Replicate the sign bit to the left
 - c.f. unsigned values: extend with 0s
- Examples: 8-bit to 16-bit
 - **+**2: 0000 0010 => 0000 0000 0000 0010
 - -2: 1111 1110 => 1111 1111 1111 1110



Sign Extension in ARM


In ARM instruction set


Instruction	Example	Meaning
load register halfword signed	LDRHS r1, [r2,#20]	r1= Memory[r2 + 20]
load register byte signed	LDRBS r1, [r2,#20]	r1= Memory[r2 + 20]



Stored Program Computers

The BIG Picture





- Instructions represented in binary, just like data
- Instructions and data stored in memory
- Programs can operate on programs
 - e.g., compilers, linkers, ...
- Binary compatibility allows compiled programs to work on different computers
 - Standardized ISAs



Representing Instructions

- Instructions are encoded in binary
 - Called machine code

- ARM instructions
 - Encoded as 32-bit instruction words
 - Small number of formats encoding operation code (opcode), register numbers, ...
 - Regularity!
- Register numbers r0 to r15



ARM Data Processing (DP) Instructions


Cond	F	I	Opcode	S	Rn	Rd	Operand2
4 bits	2 bits	1 bits	4 bits	1 bits	4 bits	4 bits	12 bits

Instruction fields

- Opcode : Basic operation of the instruction
- Rd: The destination register operand
- Rn: The first register source operand
- Operand2: The second source operand
- I:Immediate. If I is 0, the second source operand is a register, else the second source is a 12-bit immediate.
- S: Set Condition Code
- Cond: Condition
- F: Instruction Format.




DP Instruction Example



ADD
$$r5, r1, r2$$
 ; $r5 = r1 + r2$

$$; r5 = r1 + r2$$





Hexadecimal

- Base 16
 - Compact representation of bit strings
 - 4 bits per hex digit

0	0000	4	0100	8	1000	С	1100
1	0001	5	0101	9	1001	d	1101
2	0010	6	0110	а	1010	е	1110
3	0011	7	0111	b	1011	f	1111

- Example: eca8 6420
 - 1110 1100 1010 1000 0110 0100 0010 0000



ARM Data Transfer (DT) Instruction

Cond	F	Opcode	Rn	Rd	Offset12
4 bits	2 bits	6 bits	4 bits	4 bits	12 bits

LDR r5, [r3, #32] ; Temporary reg r5 gets A[8]

14	1	24	3	5	32
4 bits	2 bits	6 bits	4 bits	4 bits	12 bits



Design Principle 4

- Good design demands good compromises
 - Different formats complicate decoding, but allow 32-bit instructions uniformly
 - Keep formats as similar as possible



Logical Operations

Instructions for bitwise manipulation

Operation	С	Java	ARM
Bitwise AND	&	&	AND
Bitwise OR			ORR
Bitwise NOT	~	~	MVN
Shift left	<<	<<	LSL
Shift right	>>	>>	LSR

 Useful for extracting and inserting groups of bits in a word



AND Operations

- Useful to mask bits in a word
 - Select some bits, clear others to 0

AND r5, r1, r2; reg r5 = reg r1

& reg r2

r2	0000 0000 0000 0000 00	00 11	01 1100 0000
r1	0000 0000 0000 0000 00	11 11	00 0000 0000

0000 0000 0000 0000 0000 1100 0000 0000



r5

OR Operations

- Useful to include bits in a word
 - Set some bits to 1, leave others unchanged

```
ORR r5, r1, r2 ; reg r5 = reg r1 | reg r2
```

```
r2 0000 0000 0000 0000 00 11 01 1100 0000
```

r1 0000 0000 0000 0000 00 11 11 00 0000 0000

r5 0000 0000 0000 0000 00 11 11 01 1100 0000



NOT Operations

- Useful to invert bits in a word
 - Change 0 to 1, and 1 to 0
- ARM has Move Not (MVN)

```
MVN r5, r1; reg r5 = \sim reg r1
```

```
r1 0000 0000 0000 0001 1100 0000 0000
```

r5 | 1111 1111 1111 1100 0011 1111 1111



- Logical shift left (LSL)
 - Shift left and fill with 0 bits
 - LSLby i bits multiplies by 2i
- Logical shift right(LSR)
 - Shift right and fill with 0 bits
 - LSRby i bits divides by 2i (unsigned only)



- Although ARM has shift operations, they are not separate instructions
- ARM offers the ability to shift the second operand as part of any data processing instruction!
- Examples
 - $ADD \ r5, r1, r2, \ LSL \ \#2 \ ; \ r5 = r1 + (r2 << 2)$
 - MOV r6,r5, LSR #4 ; r6 = r5 >> 4
 - \blacksquare MOV r6,r5, LSR r3; r6 = r5 >> r3



- Still the assembler supports instructions such as
 - LSR r6,r5,#4 ; r6 = r5 >> 4
- They are synonyms for MOV instructions with shifted register second operands
 - MOV r6,r5, LSR #4 ; r6 = r5 >> 4



C	ond	000	Opcode	S	Rn	Rd	shift_imm	Rm
4 k	oits	3 bits	4 bits	1 bit	4 bits	4 bits	8 bits	4 bits

- shift_imm: how many positions to shift
- Logical shift left (LSL)
 - <OP> Rd, Rn, Rm, LSL #<shift_imm>
 - $Eg: ADD \ r5, \ r1, \ r2, \ LSL \#2; \ r5 = r1 + (r2 << 2)$
- Logical shift right(LSR)
 - <OP> Rd, Rn, Rm, LSR #<shift_imm>
 - Eg: ADD r5, r1, r2, LSR #2; r5 = r1 + (r2 << 2)



Conditional Operations

- What distinguishes a computer from a simple calculator is its ability to make decisions.
- Based on the input data and the values created during computation, different instructions execute.
 - Eg: if conditions, loops
- Branch to a labeled instruction if a condition is true
 - Otherwise, continue sequentially



Conditional Branches

CMP reg1,reg2 BEQ L1

- Mnemonic CMP stands for compare. It sets the Program Status Register
- BEQ stands for Branch if Equal
- if (reg1 == reg2) branch to instruction labeled L1;

CMP reg1,reg2 BNE L1

- BNE stands for Branch if Not Equal
- if (reg1 != reg2) branch to instruction labeled L1;



Unconditional Branch

- B exit ; go to exit
 - unconditional jump to instruction labeled exit;



Signed vs. Unsigned

- Signed comparison: BGE,BLT,BGT,BLE
- Unsigned comparison: BHS,BLO,BHI,BLS
- Example

 - - CMP r0,r1
 - BLO L1; unsigned branch
 - Branch not taken since 4,294,967,295_{ten} > 1_{ten}
 - BLT L2 ; signed branch
 - Branch taken to L2 since -1_{ten} < 1_{ten}.



Branch Instruction format

Condition	12	address
4 bits	4 bits	24 bits

Encoding of options for Condition field

Value	Meaning	Value	Meaning
0	EQ (EQual)	8	HI (unsigned HIgher)
1	NE (Not Equal)	9	LS (unsigned Lower or Same)
2	HS (unsigned Higher or Same)	10	GE (signed Greater than or Equal)
3	LO (unsigned LOwer)	11	LT (signed Less Than)
4	MI (MInus, <0)	12	GT (signed Greater Than)
5	PL - (PLus, >=0)	13	LE (signed Less Than or Equal)
6	VS (oVerflow Set, overflow)	14	AL (Always)
7	VC (oVerflow Clear, no overflow)	15	NV (reserved)



PC-relative addressing

- 24-bit address
- Problem :
 - 2²⁴ or 16 MB is not enough for large programs
- Solution :
 - Program counter (PC) = Register + Branch address
 - More than 2³² memory locations
 - But which Register?



PC-relative addressing

- Conditional branches in loops and if statements, branch to a nearby instruction.
 - Generally less than 16 instructions away
- Hence PC= PC ± Branch address
- All ARM instructions are 4 bytes
 - Refer to the number of words to the next instruction instead of the number of bytes
 - Relative distance increase by 4-times



Conditional Execution

Before

CMP r3, r4;

BNE Else

ADD r0, r1, r2

B Exit

Else:

SUB r0,rl,r2

Exit:

; go to Else if $(i \neq j)$

; f = g + h (skipped if $i \neq j$)

; go to Exit

; f = g - h (skipped if i = j)

Conditional Execution

After

```
CMP r3, r4;

ADDEQ r0, r1, r2 ; f = g + h (skipped if i \neq j)

SUBNE r0, r1, r2 ; f = g - h (skipped if i = j)
```

- No branches
- Increases performance



ARM instruction format summary

Name	Format		Example						Comments	
Field size		4 bits	2 bits	1 bit	4 bits	1 bit	4 bits	4 bits	12 bits	All ARM instructions are 32 bits long
DP format	DP	Cond	F	I	Opcode	S	Rn	Rd	Operand2	Arithmetic instruction format
DT format	DT	Cond	F	2	Opcode	Opcode Rn		Rd	Offset12	Data transfer format
Field size		4 bits	2 bits	2 bits	24 bits			3		
BR format	BR	Cond	F	Opcode	signed_immed_24			ed_24	B and BL instructions	



Compiling If Statements

C code:

if
$$(i==j)$$
 $f = g+h$;
else $f = g-h$;


- f,g,h,i,j in r0,r1,r2,r3,r4
- Compiled ARM code:

CMP r3,r4 BNE Else

ADD r1,r1,r2 B Exit

Else:

SUB r0,r1,r2



Assembler calculates addresses

;
$$f = g - h$$
 (skipped if $i = j$)

Exit:



Exercise

 Use the template provided as ex3.s to convert the following C code to assembly

```
if (i>=j) f = a+b; else f = a-b;
```

- Use signed comparison
- a,b,i,j in r0,r1,r2,r3 respectively
- Put f to r5



Exercise

 Use the template provided as ex4.s to convert the following C code to assembly

```
if (i>5) f = 70;
else if (i>3) f = 55;
else f = 30;
```

- i in r0
- Put f to r5
- Hint: Use MOV instruction
 - MOV r5,#70 makes r5=70



Compiling Loop Statements

C code:

```
while (save[i] == k) i += 1;
```

- i in r3, k in r5, base address of save in r6
- Compiled ARM code:

```
Loop: ADD r12,r6, r3, LSL # 2 ; r12 = address of save[i] ; Temp reg r0 = save[i] ; Temp reg r0 = save[i] \neq k ADD r3,r3,#1 ; i = i + 1 B Loop ; go to Loop Exit:
```



Exercise

 Use the template provided as ex5.s to convert the following C code to assembly


```
j=0;
for (i=0;i<10;i++){
j+=i;
}</pre>
```

Put final j to r5



Basic Blocks

- A basic block is a sequence of instructions with
 - No embedded branches (except at end)
 - No branch targets (except at beginning)



- A compiler identifies basic blocks for optimization
- An advanced processor can accelerate execution of basic blocks

