Ibrahim Rupawala ASU ID: 1210448106

Features Implemented:

All the 20 Instructions given in the assignment has been implemented successfully with Data Hazard Detection, Data Forwarding, Control Hazard Detection & Branch Delay Slot.

Dharak Patel

ASU ID: 1210436133

Data Hazard Detection:

For Implementing Hazard Detection the pipeline has been stalled when the following condition has been detected:

if (ID/EX.MemRead and ((ID/EX.RegisterRt = IF/ID.RegisterRs) or (ID/EX.RegisterRt = IF/ID.RegisterRt))) => stall the pipeline. This Hazard detection unit has been implemented in the Instruction DECODE stage of the pipeline and was found successful to prevent the situations where the result written in any instruction is used by the subsequent instruction as its operands. With the forwarding unit implemented in the design the stall cycle in the situation where the operand has been used immediately in the next instruction after the LOAD has been reduced from 2 to 1. Data Hazard Detection has been verified in the Implementation results below. Eg cases: LW \$2, 20(\$1) followed by ADD \$4, \$2, \$5 & SUB \$2, \$1, \$3 followed by AND \$12, \$2, \$5

Data Forwarding:

For implementation of Data forwarding two 3 input Mux's have been added before the ALU in the EX stage and the inputs to the ALU have been forwarded from the MEM & WB stage whenever the register required by the instruction in the EX stage matched with the register/s in the MEM and/or WB stage. Forwarding the values from the MEM stage, WB stage & both MEM and WB stage simultaneously has been successfully verified in the Implementation results below. Eg case: LW \$16, 8(\$0) followed by ADD \$10, \$1, \$16 followed by ADD \$17, \$10, \$16

Control Hazard Detection:

Control Hazards are caused by delay between the fetching of instructions and decisions about changes in control flow (branches and jumps). In the given design all the conditional branches has been considered as **not taken**. If the branches are detected to be taken the IF/ID FF is being flushed and the pipeline is loaded again with the new instructions from the target address. This Control Hazard Detection logic is being implemented in the EX stage of the pipeline as the ALU is being used for the branch outcome decision. All the Branch and Jump instructions have been verified in the Implementation results below.

Implementing the Branch Delay Slot requires that the instruction following the Branch and Jumps is executed regardless of the outcome of the Branch. For implementing the same the ID/EX FF is **not flushed** even if the branches are found to be taken.

IPC Calculation:

For IPC calculation loop consisting of 50 instructions containing all given 20 instructions has been coded and this loop is iterated 10 times, thus leading to 50 * 10 = 500 instruction execution. Number of cycles found to execute given 500 instructions is found to be 554. Hence IPC = 500/554 = 0.9025 is being recorded.

Design Parameters:	Design Size & Composition:	
'area_umsq': 11041.438061	Number of ports:	278
'delay_ns': data required time - slack = 0.7935 - (- 3.5629) = 4.3563	Number of nets:	3503
'dyn_power_mw': 0.0998423	Number of cells:	3206
'error_count': 0.00 out of all tests performed	Number of combinational cells:	2827
'lkg_power_mw': 0.0085090	Number of sequential cells:	379
'target_ns': 2.0	Number of macros/black boxes:	0
	Number of buf/inv:	391
	Number of references:	48

Implementation of Results:

RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1= 0 rfRdDat p1=00000000 rfWAdr p0= 0 rfWrDat p0=00000000

- Comments: Input PC = 4000, Instruction = LW, load \$r1 = 00f0f0f0, Output Received = None
- RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1= 1 rfRdDat p1=xxxxxxxx rfWAdr p0= 0 rfWrDat p0=ffffffff
 - Comments: Input PC = 4004, Instruction = LW, load \$r2 = 000f0f0f, Output Received = None
- RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1= 2 rfRdDat p1=xxxxxxxxx rfWAdr p0= 0 rfWrDat p0=ffffffff
- Comments: Input PC = 4008, Instruction = LW, load \$r3 = 0000000a, Output Received = None
- clk cnt= 14 ICache: iCRdAdr=4012 iCRdDat=8c1e0008 DCache:dCAdr= 1 dCRdDat=00f0f0f0 dCWDat=xxxxxxxx RegFile: rfRdAdr_p0= 0 rfRdDat_p0=00000000 rfRdAdr_p1= 3 rfRdDat_p1=xxxxxxxx rfWAdr_p0= 0 rfWrDat_p0=ffffffff
 - Comments: Input PC = 4012, Instruction = LW, load \$r30 = 00000fa0, Output Received = None

Starting Toggle Collection

clk cnt= 15 ICache: iCRdAdr= 4016 iCRdDat=00415020 DCache:dCAdr= 2 dCRdDat=000f0f0f dCWDat=xxxxxxxx RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1=30 rfRdDat p1=xxxxxxxxx rfWAdr p0= 1 rfWrDat p0=00f0f0f0

- Comments: Input PC = 4016, Instruction = ADD, \$r1+\$r2 => \$r10, Output Received = for 1st LW instruction
- clk cnt= 16 ICache: iCRdAdr= 4020 iCRdDat=14220008 DCache:dCAdr= 4 dCRdDat=0000000a dCWDat=xxxxxxxx RegFile: rfRdAdr p0= 2 rfRdDat p0=000f0f0f0 rfRdAdr p1= 1 rfRdDat p1=00f0f0f0 rfWAdr_p0= 2 rfWrDat_p0=000f0f0f0f
- Comments: Input PC = 4020, Instruction = BNE, \$r1 != \$r2 => Branch to target, Output Received = for 2nd LW instruction clk cnt= 17 ICache: iCRdAdr= 4024 iCRdDat=0022482a DCache:dCAdr= 8 dCRdDat=00000fa0 dCWDat=xxxxxxxx RegFile: rfRdAdr p0= 1 rfRdDat p0=00f0f0f0 rfRdAdr p1= 2 rfRdDat p1=000f0f0f rfWAdr p0= 3 rfWrDat p0=0000000a
 - Comments: Input PC = 4024 (1st Inst of Branch Delay Slot, will be executed), Instruction = SLT, \$r1 < \$r2 => \$r9 = 1, Output Received = for 3rd LW instruction

```
RegFile: rfRdAdr p0= 1 rfRdDat p0=00f0f0f0 rfRdAdr p1= 2 rfRdDat p1=000f0f0f rfWAdr p0=30 rfWrDat p0=00000fa0
      Comments: Input PC = 4028 (2nd Inst of Branch Delay Slot, won't get executed), Instruction = ADD, $r1+$r2 => $r10, Output
       Received = for 4<sup>th</sup> LW instruction
clk cnt= 19 ICache: iCRdAdr= 4056 iCRdDat=342c0f0f
                                                 DCache:dCAdr=
                                                                        0 dCRdDat=00000000 dCWDat=000f0f0f
RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1= 0 rfRdDat p1=00000000 rfWAdr p0=10 rfWrDat p0=00fffffff
      Comments: Input PC = 4056 (Branch Taken), Instruction = ORI, $r1+0f0f => $r12, Output Received = for add Inst on pc 4016
clk cnt= 20 ICache: iCRdAdr= 4060 iCRdDat=10220004 DCache:dCAdr=
                                                                        0 dCRdDat=00000000 dCWDat=000f0f0f
RegFile: rfRdAdr p0= 1 rfRdDat p0=00f0f0f0 rfRdAdr p1=12 rfRdDat p1=xxxxxxxxx rfWAdr p0= 0 rfWrDat p0=000000000
      Comments: Input PC = 4060, Instruction = BEO, if $1 == $2 => Branch to target, Output Received = ALU outputs 0 for BNE on pc
clk cnt= 21 ICache: iCRdAdr= 4064 iCRdDat=00225083
                                                  DCache:dCAdr=4294967295 dCRdDat=00000000 dCWDat=00000000
RegFile: rfRdAdr p0= 1 rfRdDat p0=00f0f0f0 rfRdAdr p1= 2 rfRdDat p1=000f0f0f rfWAdr_p0= 9 rfWrDat_p0=000000000
      Comments: Input PC = 4064(BEO is not taken hence normal execution), Instruction = SRA, $2 >> shamt(2) => $10, Output Received
       = SLT (Branch Delay Slot on pc 4024)
RegFile: rfRdAdr p0= 1 rfRdDat p0=00f0f0f0 rfRdAdr p1= 2 rfRdDat p1=000f0f0f rfWAdr p0= 0 rfWrDat p0=fffffffff
      Comments: Input PC = 4068, Instruction = LW, load $r16 = 00000fa0, Output Received = Single cycle stall for the BNE instruction
clk cnt= 23 ICache: iCRdAdr= 4072 iCRdDat=00305020
                                                 DCache:dCAdr=
                                                                        1 dCRdDat=00000000 dCWDat=000f0f0f
RegFile: rfRdAdr p0= 0 rfRdDat_p0=00000000 rfRdAdr_p1=16 rfRdDat_p1=xxxxxxxxx rfWAdr_p0=12 rfWrDat_p0=00f0ffff
     Comments: Input PC = 4072, Instruction = ADD, $r1+$r16 => $r10 (Forwarding the value of $r16 from MEM stage), Output Received
       = for ORI Instruction at pc 4056
clk cnt= 24 ICache: iCRdAdr= 4076 iCRdDat=01508820 DCache:dCAdr=
                                                                   246723 dCRdDat=00000000 dCWDat=000f0f0f
RegFile: rfRdAdr p0= 1 rfRdDat p0=00f0f0f0 rfRdAdr p1=16 rfRdDat p1=xxxxxxxxx rfWAdr p0= 0 rfWrDat p0=00000001
      Comments: Input PC = 4076, Instruction = ADD, $r10+$r16 => $r17 (Forwarding the value of $r16 from WB stage and $r10 from
       MEM stage), Output Received = for BEQ Instruction ALUResult is zero if both operands are equal, here branch not taken hence 1'b1
clk cnt= 25 ICache: iCRdAdr= 4076 iCRdDat=01508820
                                                 DCache:dCAdr=
                                                                        8 dCRdDat=00000fa0 dCWDat=xxxxxxxx
RegFile: rfRdAdr p0= 1 rfRdDat p0=00f0f0f0 rfRdAdr p1=16 rfRdDat p1=xxxxxxxxx rfWAdr p0=10 rfWrDat p0=0003c3c3
      Comments: Input PC= 4076 (stall for LW Inst on pc 4068), Instruction = ADD, $r10+$r16 => $r17, Output Received = for SRA Inst on
       pc 4064
RegFile: rfRdAdr p0=10 rfRdDat p0=0003c3c3 rfRdAdr p1=16 rfRdDat p1=00000fa0 rfWAdr p0=16 rfWrDat p0=00000fa0
      Comments: Input PC= 4080, Instruction = Jump, Jump to target, Output Received = for LW Inst on pc 4068
clk cnt= 27 ICache: iCRdAdr=4084 iCRdDat=acle0040 DCache:dCAdr= 15794320 dCRdDat=00000000 dCWDat=xxxxxxxx
RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1= 0 rfRdDat p1=00000000 rfWAdr p0=10 rfWrDat p0=ffffffff
     Comments: Input PC= 4084, (1st Inst of Branch Delay Slot, will be executed), Instruction = SW, Store Mem [64] to $r30, Output
       Received = stall for the LW instruction at pc 4068 due to the data dependency on $110 used immediately by ADD on pc 4072
clk cnt= 28 ICache: iCRdAdr= 4088 iCRdDat=00415020
                                                 DCache:dCAdr= 15798320 dCRdDat=00000000 dCWDat=00000fa0
RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1=30 rfRdDat p1=00000fa0 rfWAdr p0=10 rfWrDat p0=00f10090
      Comments: Input PC= 4088, (2nd Inst of Branch Delay Slot, won't get executed), Instruction = ADD, $r1+$r2 => $r10, Output
       Received = for ADD at pc 4072 (Forwarding the value of $r16 from MEM stage)
clk cnt= 29 ICache: iCRdAdr= 4200 iCRdDat=8c190040
                                                 DCache:dCAdr=4294967295 dCRdDat=00000000 dCWDat=00000000
RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1= 0 rfRdDat p1=00000000 rfWAdr p0=17 rfWrDat p0=00f11030
      Comments: Input PC= 4200 (Due to Jump Instruction), Instruction = LW, load $r25=00000fa0, Output Received = for ADD at pc 4076
       (Forwarding the value of $r16 from WB stage and $r10 from MEM stage)
clk cnt= 30 ICache: iCRdAdr= 4204 iCRdDat=03200008
                                                  DCache: dCAdr=
                                                                       64 dCRdDat=00000000 dCWDat=00000fa0
RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1=25 rfRdDat p1=xxxxxxxxx rfWAdr p0= 0 rfWrDat p0=ffffffff
      Comments: Input PC= 4204, Instruction = JR, jump to Mem [$25], Output Received = for SW on pc 4084
Comments: Input PC= 4208, Instruction = XORI, $r1 \,^0160f => r13, Output Received = for the Flush due to jump Inst on pc 4080
clk cnt= 32 ICache: iCRdAdr= 4208 iCRdDat=382d0f0f DCache:dCAdr=
                                                                       64 dCRdDat=00000fa0 dCWDat=xxxxxxxx
RegFile: rfRdAdr p0=25 rfRdDat p0=xxxxxxxxx rfRdAdr p1= 0 rfRdDat p1=00000000 rfWAdr p0= 0 rfWrDat p0=ffffffff
```

RegFile: rfRdAdr p0=25 rfRdDat p0=xxxxxxxxx rfRdAdr p1= 0 rfRdDat p1=00000000 rfWAdr p0= 0 rfWrDat p0=000000000

Comments: Input PC= 4208(stall for LW Inst on pc 4200, 1st Inst of Branch Delay Slot, will be executed), Instruction = XORI, \$r1^ 0f0f => r13, Output Received = Single cycle stall due to LW Inst at pc 4200

clk cnt= 33 ICache: iCRdAdr= 4212 iCRdDat=01508820 DCache:dCAdr=4294967295 dCRdDat=00000000 dCWDat=00000000 RegFile: rfRdAdr p0= 1 rfRdDat p0=00f0f0f0 rfRdAdr p1=13 rfRdDat p1=xxxxxxxxx rfWAdr p0=25 rfWrDat p0=00000fa0

Comments: Input PC= 4212 (2nd Inst of Branch Delay Slot, won't get executed), Instruction = ADD, \$r10+\$r16 => \$r17, Output Received = for LW Inst at pc 4200

clk cnt= 34 ICache: iCRdAdr= 4000 iCRdDat=8c010001 DCache:dCAdr=4294967295 dCRdDat=00000000 dCWDat=000000000 RegFile: rfRdAdr p0= 0 rfRdDat p0=00000000 rfRdAdr p1= 0 rfRdDat p1=00000000 rfWAdr p0= 0 rfWrDat p0=fffffffff

Comments: Input PC= 4000 (JR Instruction), Instruction = LW, load \$r1 = 00f0f0f0, Output Received = Default ALU for JR Inst as JR does not use ALU (ALUOut = 0xffff ffff hardcoded in ALU if the ALUControl Signal is not received)