
Welcome to the World of Assembly Language Programming

Base Slide Prepared by
Madhusudan Basak
Lecturer

Department of CSE, BUET



Abdus Salam Azad, Assistant Professor, CSE, BUET




References

- Assembly Language Programming and Organization of the IBM PC
 - --- Ytha Yu and Charles Marut

- Assembly Language for the IBM-PC
 - --- Kip R. Irvine

What Is Assembly Language?



Definition (Simplified) from wiki

a <u>low-level programming language</u> for a <u>computer</u>, in which there is a very strong (generally <u>one-to-one</u>) correspondence between the language and the <u>architecture's machine code instructions</u>.

 Each assembly language is specific to a particular computer architecture --- Platform Dependent

Why use it?

- Direct hardware manipulation
 - Gives you complete control over the system's resources
- Performance and efficiency
- Access to specialized processor instructions

Disadvantages 😊

- Hard and tedious
- Non-portable(machine dependent)
- Bug-prone
- Difficult to debug

A question?

 In what kind of situations, assembly language will be the only/best solution?

- Drivers and communication with custom hardware/electronics.
- An Compiler
- Optimizations

Chapter 1 Microcomputer Systems


The Components of a Microcomputer System

- Functionally three parts
 - CPU
 - Memory circuits
 - I/O circuits


Bus

- A set of wires or connections with which a processor communicates with memory and I/O circuits
- There are three kind of buses:
 - address bus
 - data bus,
 - control bus

Bus Connections




Memory - Bytes and Words



CPU

- Two main components
 - Execution Unit(EU)
 - Bus Interface Unit(BIU)

Intel 8086 Microprocessor Organization



Execution Unit

- The purpose of the execution unit (EU) is to execute Instructions.
 - It contains a circuit called the arithmetic and logic unit (ALU).
 - The ALU can perform arithmetic (+, , x ,I) and logic (AND, OR, NOT) operations.
- The data for the operations are stored in registers
- A register is like a memory location except that we normally refer to it by a name rather than a number.
- The EU has eight registers for storing data; their names arc AX, BX, CX, DX, SI, DI, BP, and SP.

Bus Interface Unit

- The Bus Interface unit (BIU) facilitates communication between the EU and the memory or I/O circuits.
- It is responsible for transmitting addresses, data, and control signals on the buses.
- Its registers are named CS, DS, ES, SS, and IP.
 - They hold addresses of memory locations.
 - The IP (instruction pointer) contains the address of the next instruction to be executed by the EU.

Instruction Execution

Fetch

- 1. Fetch an instruction from memory.
- 2. Decode the instruction to determine the operation.
- 3. Fetch data from memory if necessary.

Execute

- 4. Perform the operation on the data.
- 5. Store the result in memory if needed

Chapter 3

ORGANIZATION OF THE IBM PERSONAL COMPUTERS


Organization of the 8086/8088 Microprocessors

- Registers
 - There are fourteen 16 bit registers
 - 3 Types of registers
 - Data Registers holds data for operation
 - Address Registers holds addresses of instruction or data
 - Status Register holds current status of processor

Data Registers

- AX (Accumulator Register)
- BX (Base Register)
- CX (Count Register)
- DX (Data Register)
- Each one can be used by parts
 - e.g., AX has two equal parts
 - The higher part (8 bit) is referred as AH and
 - The lower part AL
 - both of them can be used independently

Data Registers



Memory Organization

- 8086 features 1 20 bit physical address for memory
 - 2^20 == 1MB Memory is supported

- However, all registers are of 16 bit
- The memory is divided (non-disjoint) into segments

Segment

- Each segment consists of a block of 2^16 consecutive bytes in the memory
 - 64KB in size
 - Each memory location in a memory segment is addressable by a 16 bit offset
- Each segment is identified with a 16 bit segment number
 - Hence there are 2^16 segments
 - Numbered from 0000h to FFFFh

Logical Address and Physical Address

- Each Location in memory can be addressed by specifying a segment number and and offset within the segment
 - Written as segment:offset
 - Called the logical address
- To find the physical address from a logical address
 - Shift left the segment number by four bit, then add offset
 - segment*10h + offset


• If you have a segment A4FBh and offset 4872h. Then what is the 20 bit physical address?

A4FB0h


+4872h

A9822h (20 bit physical address)

Segment Registers (Address Registers)



Pointer and Index Registers, Instruction pointers (Address Registers)



Overlapping Scenario

	10021	11016101	
	10020	01001001	
Segment 2 ends —	→ 1001F	11110011	
40 + AB	1001E	10011100 -	
		. 4.	
	10010	01111001	
Segment 1 ends —	→ 1000F	11101011	
	1000E	10011101	
	10000	01010001	
Segment 0 ends -	→ OFFFF	11111110	
Carling of the same	OFFFE	10011111	,
	Sec. Market	The string of	
	regulation (C		
	00021	01000000	
Segment 2 begins —	→ 00020	01101010	
	0001F	10110101	
	00011	01011001	
Segment 1 begins-	→ 00010	11111111	
	0000F	10001110	
S Sebo Parishera Sal		School 1	
antended the own to	00003	10101011	
	00002	00000010	
THE NEW ONL HE WAS	00001	10101010	
Segment 0 begins	→ 00000	00111000	1

Overlapping Scenario

Example 3.1 For the memory location whose physical address is specified by 1256Ah, give the address in segment:offset form for segments 1256h and 1240h.

Solution: Let X be the offset in segment 1256h and Y the offset in segment 1240h. We have

$$1256Ah = 12560h + X$$
 and $1256Ah = 12400h + Y$

and so

thus-

$$X = 1256Ah - 12560h = Ah$$
 and $Y = 1256Ah - 12400h = 16Ah$

$$1256Ah = 1256:000A = 1240:016A$$

Physical and Logical address calculation

Example 3.2 A memory location has physical address 80FD2h. In what segment does it have offset BFD2h?

Solution: We'know that

physical address = segment \times 10h + offset

Thus

segment × 10h = physical address - offset

· in this example

physical address = 80FD2h - offset = BFD2h segment × 10h = .75000h


So the segment must be 7500h.

Segment Registers

- Code, Data, and Stack are maintained in different segments
- Stack is used by the processor to implement procedure calls.


Task	Segment Registers	Pointer and Index Registers
Code	CS	IP
Data	DS	SI
	ES	EĪ
Stack	SS	SP
		ВР

FLAGS Register(Status Register)



Memory Organization of the PC

- 8086/8088 has only 1MB of memory
- Not all memory for application programs
- Interrupt Vector, Video Display Memory etc are needed
- IBM fixed all the positions and allowed all to live happily



	Address
BIOS	F0000h
Reserved	E0000h
Reserved	D0000h
Reserved	C0000h
Video	B0000h
Video	A0000h
Application program area	
DOS	
BIOS and DOS data	00400h
Interrupt vectors	00000h

I/O ports addresses

- The 8086/8088 supports · 64 KB of I/O ports
- Interrupt controller (20h-21h)
- Keyboard controller (60h-63h)
- etc...

