



INTRODUCTION TO BRANCH INSTRUCTIONS

CONDITIONAL BRANCH EXECUTION

IMPLEMENTING BRANCHING STRUCTURES/FUNCTIONS

COMBINED COMPARE AND CONDITIONAL BRANCH

IF-THEN CONDITIONAL INSTRUCTION BLOCK

INTRODUCTION TO BRANCH INSTRUCTIONS

ARM Cortex-M4 Assembly Language

Overview

INTRODUCTION TO BRANCH INSTRUCTIONS

- A user program for real-time application involve decision making, conditional execution, calling subtasks or functions
- To handle these complexities, the processor architecture supports branch and control instructions to allow the software developer to control the flow of program execution
- The Cortex-M processor supports different types of branch and control instructions with varying complexity
 - **1. Branch instructions** (conditional and unconditional) simple branch instructions
 - **2. Function calls** (conditional and unconditional) requires a return address before calling the function
 - **3. Combined compare and conditional branch** implements two operations in one instruction to improve the branch operation efficiency
 - **4. Conditional execution of instructions** (IF-THEN instruction) allow to map if-else and switch-case types of higher-level conditional constructs directly to these assembly instructions
 - Table branch –

B, BX, BL, & BLX

BRANCH INSTRUCTIONS

The most basic branch instructions, supported by Cortex-M processor, are:

| Mnemonic | Brief description | Encoding | Flags |
|----------|---------------------------|--------------|-------|
| В | Branch | 16 or 32 bit | - |
| BX | Branch indirect | 16 bit | - |
| BL | Branch with link | 32 bit | - |
| BLX | Branch indirect with link | 16 bit | - |

- The instruction **B** is also called branch immediate, and **BX** is also termed branch register
- For **BL** and **BLX** instructions, the address of the next instruction, following the branch instruction, is saved to register **LR** (link register or R14) at the time of execution of the branch instruction, which is used subsequently at the time of returning.

B, BX, BL, & BLX

BRANCH INSTRUCTIONS

The general syntax for branch instructions is given:

 $B\{cond\}$ label $BX\{cond\}$ Rm $BL\{cond\}$ label $BLX\{cond\}$ Rm

- {cond} is one of the condition codes.
 - When the optional condition code is omitted, these branch instructions become unconditional branches.
 - On the other hand, use of any of the conditional codes makes these branch instructions become conditional branches.
- label specifies the address of the instruction to which the branch must be performed.
 - The compilation tools (assembler or compiler) are responsible to evaluate the required value of the offset from this **label** to the current value of the program counter (R15 or **PC**) (i.e., the address of the current **B** instruction being executed).
- Rm is a register containing the address to which the branch must be performed
 - Bit 0 of the address contained in register Rm should be set to 1, which indicates that the code execution is in Thumb mode. However, the address to which the branch is performed to is obtained by resetting the bit 0 to 0.

Conditional Code Suffixes

BRANCH INSTRUCTIONS

| Code Suffix | Flags | Description |
|-------------|--------------------|---------------------------------------|
| EQ | Z = 1 | Equal (==) |
| NE | Z = 0 | Not equal $(! =)$ |
| CS or HS | C = 1 | Unsigned higher or same (≥) |
| CC or LO | C = 0 | Unsigned lower (<) |
| MI | N = 1 | Negative |
| PL | N = 0 | Positive or zero |
| VS | V = 1 | Overflow occurred |
| VC | V = 0 | Overflow did not occur |
| HI | C = 1 and $Z = 0$ | Unsigned higher (>) |
| LS | C = 0 or $Z = 1$ | Unsigned lower or same (\leq) |
| GE | N = V | Signed greater than or equal (\leq) |
| $_{ m LT}$ | N != V | Signed less than |
| GT | Z = 0 and $N = V$ | Signed greater than |
| LE | Z = 1 and $N != V$ | Signed less than or equal |
| AL | any value | Always. This is the default setting |

Branch Ranges

BRANCH INSTRUCTIONS

| Instruction | Branch instruction offset range | | |
|-------------|--|--|--|
| В | -256 to 254 bytes for 16-bit encoding (outside IT block) -2 KB to +2 KB bytes for 16-bit encoding (inside IT block) -1 MB to +1 MB bytes for 32-bit encoding (outside IT block) -16 MB to +16 MB bytes for 32-bit encoding (inside IT block) | | |
| BL | -16 MB to +16 MB bytes | | |
| BX | Any arbitrary value in the register | | |
| BLX | Any arbitrary value in the register | | |

CONDITIONAL BRANCH EXECUTION

ARM Cortex-M4 Assembly Language

Introduction

CONDITIONAL BRANCH EXECUTION

- Conditional branch instructions are used to determine whether a branch should be carried out and are implemented with the help of Cortex-M processor application program status register (APSR)
- There are four bits, namely, overflow (V), carry (C), negative (N), and the zero (Z) flags, which indicate the status of the current operation performed by the microprocessor.
- Irrespective of their category, branch instructions work depending on the current values of the flags but do not affect the flags.

Introduction

CONDITIONAL BRANCH EXECUTION

Conditional branch instructions can be broadly categorized in three groups:

1. Single-flag Branch instructions

- e.g., in making the decision whether 0x7FFF FFFF and 0x8000 0000 are equal, the microprocessor needs to take only one flag (the Z flag in this case) into account
- 2. Signed Branch instructions used when operands are treated as signed numbers
 - e.g., let's take the case of testing whether 0x7FFF FFFF is greater than 0x8000 0000 (both signed), then 0x7FFF FFFF is greater than 0x8000 0000
- **3. Unsigned Branch instructions** used when the operands are interpreted as unsigned numbers
 - e.g., let's take the case of testing whether 0x7FFF FFFF is greater than 0x8000 0000 (both unsigned), then 0x8000 0000 is greater than 0x7FFF FFFF
- For signed/unsigned branch, we may need to consider multiple flags

Single-Flag Branch Instructions

CONDITIONAL BRANCH EXECUTION

- BEQ, BNE, BCS, BCC, BMI,
 BPL, BVS, and BVC are examples of single-flag branch instructions
- These single-flag instructions can be used in different scenarios for making decisions

| Code Suffix | Flags | Description |
|-------------|--------------------|---------------------------------------|
| EQ | Z = 1 | Equal (==) |
| NE | Z = 0 | Not equal $(! =)$ |
| CS or HS | C = 1 | Unsigned higher or same (\geq) |
| CC or LO | C = 0 | Unsigned lower (<) |
| MI | N = 1 | Negative |
| PL | N = 0 | Positive or zero |
| VS | V = 1 | Overflow occurred |
| VC | V = 0 | Overflow did not occur |
| HI | C = 1 and $Z = 0$ | Unsigned higher (>) |
| LS | C = 0 or Z = 1 | Unsigned lower or same (≤) |
| GE | N = V | Signed greater than or equal (\leq) |
| LT | N != V | Signed less than |
| GT | Z = 0 and $N = V$ | Signed greater than |
| LE | Z = 1 and $N != V$ | Signed less than or equal |
| AL | any value | Always. This is the default setting |

Single-Flag Branch Instructions

CONDITIONAL BRANCH EXECUTION

The Z-Flag Usage

- The Thumb2 instruction set uses condition codes **EQ** (equal) and **NE** (not equal) with branch instructions to check equality (==) and inequality (!=) of data objects.
- The EQ code results in true condition when Z flag is 1 while NE code gives true condition for Z = 0

```
MOV R3, #10
loop
SUBS R3, R3, #2
BNE loop ; Branch to Loop if result of previous ; instruction is not equal to zero
```

If we used SUB here instead of SUBS then condition would have become meaningless

Single-Flag Branch Instructions

CONDITIONAL BRANCH EXECUTION

The C-Flag Usage

 Using the BCC or BCS singleflag branch instructions, we can count the number of 1s in each number.

```
LDR RO, = var ; variable
   LDR R1, [R0]
   MOV R5, #32
                   ; Initialize the counter to 32
loop
                    ; assuming a word size variable
   RORS R1, #1
   BCC skip
   ADD R4, #1 ; Increment if bit is 1
    SUBS R5, #1
    BNE loop
    B store
skip
    SUBS R5, #1
    BNE loop
store
   LDR R2, = parity ; variable to store 1 count
    STRB R4, [R2]
stop
    B stop
```

Unsigned Conditional Branch Instructions

CONDITIONAL BRANCH EXECUTION

- The carry and zero flags are used In order to implement unsigned conditional branch
- For some comparisons, either the zero or carry flag is used, while for others their combination is used

| $\{Instruction\}$ | Description |
|--|---|
| BLO label BHS label BLS label BHI label | Branch to label if unsigned less than (same as BCC) Branch to label if unsigned greater than or equal to (same as BCS) Branch to label if unsigned less than or equal to Branch to label if unsigned greater than |

• One example illustrating the use of unsigned conditional branch is when we need to differentiate characters from the standard and extended ASCII character sets

Signed Conditional Branch Instructions

CONDITIONAL BRANCH EXECUTION

 To implement the signed conditional branch, the negative, overflow, and zero flags are used

| {Instruction} | Description |
|---------------|--|
| BLT label | Branch to label if signed less than |
| BGE label | Branch to label if signed greater than or equal to |
| BGT label | Branch to label if signed greater than |
| BLE label | Branch to label if signed less than or equal to |

 An example illustrating the use of signed conditional branch instructions to count the negative numbers in an array of numbers

IMPLEMENTING BRANCHING STRUCTURES

ARM Cortex-M4 Assembly Language

Introduction

IMPLEMENTING BRANCHING STRUCTURES

- The execution flow of a program can be altered using branching structures.
- Let's discuss the following three basic branching structures.
 - 1. If-else branching
 - Loop based branching
 - 3. Switch-case based branching
- In the following we discuss these three basic branching structures along with their different variants and examples.

If-else Branching

IMPLEMENTING BRANCHING STRUCTURES

Implementing if

- The *if* branching structure tests a condition and based on the result of condition testing, a set of instructions is executed.
- If the condition is true, the instructions inside the if block are executed

```
// verify that the variable is in range
if(('a' <= x) && (x <= 'z'))
    {
        x = x - 32;
    }
}</pre>
CMP R0, #'a'; Less than 'a' condition is tested
BLT stop
CMP R0, #'z'; Greater than 'z' condition is tested
BGT stop
SUB R0, #0x20
stop
B stop
B stop
```

If-else Branching

IMPLEMENTING BRANCHING STRUCTURES

Implementing if-else

- In case of if-else structure, there is a condition to test, while there are two different instruction blocks.
- When the condition is true, the set of instructions corresponding to if block is executed, otherwise the instructions inside the else block are executed.
- Omitting the else block reduces the if-else structure to if block.

```
if((x%2) ==0) // if remainder is zero, then even
    y = 'E';
else
    y = 'O'; // otherwise it is odd

TST R0, #0x1; Test if LSB of R0 is 1
BEQ even
MOV R1, #'O'
B stop

WOV R1, #'E'
stop
B stop
```

Loop Based Branching

IMPLEMENTING BRANCHING STRUCTURES

Implementing for Loop

- Looping structures allow a program to execute a set of instructions for a number of times
- A for loop is used whenever we know in advance the number of times a set of instructions should be executed

```
MOV R0, #'*'
LDR R2, = Array
MOV R1, #0

for(i = 0; i <50; i ++)
Array [i] = '*';

CMP R1, #50
BGE stop
STRB R0, [R2], #1; Store '*' to the current address
ADD R1, #1
B loop
stop
B stop
```

Loop Based Branching

IMPLEMENTING BRANCHING STRUCTURES

Implementing while Loop

- When the number of loop iterations is not known in advance, we use while loop
- while loop is iterated until a certain condition is fulfilled

```
int count = 0;
int i = 0;
// Test the condition for loop
while( ARRAY [i] != '\n')
  count ++;
```

```
LDR R2, = ARRAY
MOV R1, #0 ; initialize the count to 0
LDRB R0, [R2], #1
loop

CMP R0, #0x0A ; check loop termination condition
BEQ stop
ADD R1, #1
LDRB R0, [R2], #1
B loop

stop
B stop
```

Switch-case Based Branching

IMPLEMENTING BRANCHING STRUCTURES

- The condition testing can be performed for multiple possible values, resulting in multiway branching.
- For instance, a variable can be tested for three different possible values and correspondingly one of the three different code segments is executed.
- This situation can be implemented using switchcase conditional structure
- When the switch-case construct has multiple cases, it requires multiple test or compare operations followed by conditional branch instructions but this type of implementation will execute slowly if the number of cases is large

```
switch(x){ // Switch construct with three cases
 case ' <0':
   v = -1;
 case '==0':
   y = 0;
 case ' >0': // Note there is no default case
   y = 1;
                 CMP R0, #0
                 BLT negative
                 BEQ zero
                 BGT positive
            negative
                 MOV R1, -1
                 B stop
            zero
                 MOV R1, 0
                 B stop
            positive
                 MOV R1, 1
            stop
                 B stop
```

IMPLEMENTING FUNCTIONS

ARM Cortex-M4 Assembly Language

Simple Function Call

- When BL and BLX instructions are used, the address of the next instruction following the branch instruction is saved to LR register (the link register or R14)
- This address is used at the time of returning from the called function.
- The return from the function can be implemented using instruction BX LR, which causes program control to return to the calling process.
- Note that BL or BLX instructions are not used when returning from a function or subroutine

```
AREA MYCODE, CODE, READONLY
   EXPORT main
    ENTRY
 main
    MOV RO, #0x18
   MOV R1, R0
    BL addition; Branch with link to 'addition'
   LDR R3, = addition
                    ; Branch indirect with link
   BLX R3
    SUB R2, R1, R2
                   ; Branch to 'stop'
   B stop
   ADD R2, R1, R0; R2 = R1 + R0
   BX LR
              ; Branch with link
stop
    B stop
    END
```

Nested Function Calls

IMPLEMENTING FUNCTIONS

```
AREA MYCODE , CODE , READONLY
   EXPORT main; the first instruction to call
   ENTRY
 main
   MOV R0, #0x18
   MOV R1, R0
   BL multiply_add ; Branch with link to 'multiply_add'
    SUB R2, R1, R2
   B stop
multiply add
   PUSH {LR} ; First preserve the return address
   BL addition ; Call another function
   MUL R2, R2, R0
   POP {LR} ; Retrieve return address from stack
   BX LR ; Branch indirect with link
addition
   PUSH {LR}
   ADD R2, R1, R0; R2 = R1 + R0
   POP {PC}
stop
   B stop
    END
```

Slide 26

Implementing Branch Operations Indirectly

- Other assembly programming instructions can be used to implement the branch operation indirectly
- Example below illustrate indirect branch operation using MOV, LDR instructions

```
MOV R15, R0 ; Branch to an address in R0

LDR R15, [R0] ; Branch to an address in memory
; specified by R0
; Do a stack pop operation to change
; the program counter .
```

- The **POP PC** instruction is used to implement the return operation from a function call, which conventionally would have been implemented using a BX LR instruction
- Some other assembly programming instructions, e.g., ADD and SUB, can also update the PC register. However, it is recommended that these instructions should not be used to create a branch operation

Recursive Function Call

```
unsigned long Fact(unsigned long n)
{
  if(n <=1)
  {
    return 1;
  }
  return n*Fact(n -1);
}</pre>
```

```
AREA Mydata, DATA, READWRITE
Result DCD 0
    ; Separate memory segment for function call
   AREA MyFunction, CODE , READONLY
Func1
                  ; Assume sufficient stack size
    PUSH {LR}
   CMP R0, #1 ; is available
    BEQ Done
    PUSH {RO}
    SUB R0, R0, #1
    BL Func1
   POP {R1}
   MUL R0, R0, R1
Done
   POP {LR}
    BX LR
    ; New memory segment for main function
   AREA MyMain, CODE, READONLY
    EXPORT main ; Entry point of user program
                   ; and is called from startup
 main
                    ; file
   MOV R0, #4
   BL Func1
   LDR R1, = Result
    STR R0, [R1]
Stop
    B Stop
    END
```

Passing Parameters to Functions

- In high level languages, there are two well-known mechanisms for parameter passing to functions:
 - 1. Call by Value: the actual data values are passed to the called function
 - 2. Call by Reference: the address of the data is passed to the function. Particularly useful when dealing with data arrays.
- Unlike high-level languages, assembly language functions do not have associated parameter lists due to which it is up to the programmer to devise strategies for passing parameters to functions

Passing Parameters to Functions

IMPLEMENTING FUNCTIONS

Call by Value

- For R4 = M + N R3, where M and N are 32-bit data.
- Addition function implemented and the operands are passed through the call by value method

```
AREA DATA1, READONLY
M DCD 5
N DCD 3
    AREA MYCODE, CODE, READONLY
    EXPORT main; the first instruction to call
    ENTRY
 main
    LDR R6, =M
    LDR R7, =N
    LDR R0, [R6]
    LDR R1, [R7]
    BL addition; Branch to function 'addition' and
                ; pass R0 and R1 as parameters
    MOV R3, #0x3
    SUB R4, R1, R3
    B stop
addition
    ADD R1, R1, R0; R1 = R1 + R0
    BX LR
stop
    B stop
    END
```

Passing Parameters to Functions

IMPLEMENTING FUNCTIONS

Call by Reference

- For R4 = M + N R3, where M and N are 32-bit data.
- Addition function implemented and the operands are passed through the call by reference method

```
AREA DATA1, READONLY
M DCD 5
N DCD 3
    AREA MYCODE, CODE, READONLY
    EXPORT main
    ENTRY
  main
    LDR R6, =M
    LDR R7, =N
    BL addition ; Branch to function 'addition'
    MOV R3, #0x3
    SUB R4, R1, R3
    B stop
addition
    LDR R0, [R6]
    LDR R1, [R7]
    ADD R1, R1 , R0 ; R1 = R1 + R0
    BX LR
stop
    B stop
    END
```

COMBINED COMPARE AND CONDITIONAL BRANCH

ARM Cortex-M4 Assembly Language

CBZ & CBNZ Instructions

COMBINED COMPARE AND CONDITIONAL BRANCH

CBZ Rn, label CBNZ Rn, label

CBZ and CBNZ performs comparison with zero and branch conditionally

| Mnemonic | Brief description | Encoding | Flags |
|----------|--------------------------------|----------|-------|
| CBZ | Compare and branch if zero | 16 bit | - |
| CBNZ | Compare and branch if not zero | 16 bit | _ |

- CBZ instruction is equivalent to two consecutive instructions, CMP (compare with zero) followed by conditional branch BEQ
- Similarly, CBNZ is equivalent to CMP with zero followed by BNE
- APSR condition flags values are not affected by the CBZ and CBNZ instructions
- The compare and branch instructions only support forward branches

CBZ & CBNZ Instructions

COMBINED COMPARE AND CONDITIONAL BRANCH

CBZ Example

```
// Iterative function calling
i=6;
while (i != 0 ) {
 funcA (); // Call a function
 i--;
   MOV RO, #6 ; Set loop counter
loop1
   CBZ RO, looplexit ; If loop counter = 0 then exit loop
   BL funcA ; Call a function
   SUB RO, #1 ; Loop counter decrement
   B loop1
                     ; Next loop iteration
looplexit
```

CBZ & CBNZ Instructions

COMBINED COMPARE AND CONDITIONAL BRANCH

CBNZ Example

```
status = strchr ( emailid , '0');
// if emailid does not contain 0, then status is 0.
if ( status == 0) {
   generate_error_message ();
}
...
   CBNZ R0 , email_id_ok ; R0 contains a character from ; the emailid string .
   BNE generate_error_message
email_id_ok
...
```

IF-THEN CONDITIONAL INSTRUCTION BLOCK

ARM Cortex-M4 Assembly Language

What is If-Then Block?

- Apart from the conditional branch instructions ARM Cortex-M architecture extends the use of condition codes to other instructions as well
 - e.g., ADD and SUB instructions can be executed conditionally by using the optional condition code
- Conditional execution of an instruction is implemented by Thumb2 ISA using If-Then (IT) block.
 - The IT instructions allow up to four succeeding instructions to be conditionally executed and they collectively form an IT block.
 - The IT block instruction is very useful for handling small conditional codes.
 - It avoids branch penalties because there is no change to program flow.
 - Conditional instructions, except for conditional branches, must be inside an IT instruction block.

Syntax

IF-THEN CONDITIONAL INSTRUCTION BLOCK

The syntax of IT instruction is

$$IT\{x\{y\{z\}\}\}\ cond$$

- x, y, and z are the optional conditional execution switches for second, third, and fourth instructions in the IT block
- cond is the base condition for the IT instruction block. The first instruction following
 IT instruction is executed if the cond is true
- Each of the optional condition switches x, y, and z can be either T (THEN) or E (ELSE)
 - When condition switch T is used, then cond is applied to the corresponding instruction
 - The use of condition switch **E** applies the inverse **cond** to the corresponding instruction

| Mnemonic Brief description | | Encoding Flags | |
|----------------------------|---------------------------------|-------------------------|---|
| IT | If-then conditional instruction | 16 bit | - |

Syntax

- In IT instruction blocks, the first instruction must be the IT instruction itself, detailing the choice of condition switches along with the condition it checks.
- The first conditional instruction after the IT instruction must be TRUE.
- The condition codes for second through fourth instructions following the IT instruction can be either TRUE or FALSE.
- The use of condition code with an instruction is specified with a two-letter suffix, such as EQ or CC, appended to the instruction mnemonic.
- The conditional instructions following the IT instruction in the IT block must specify either the condition code *cond* or its logical inverse as part of their instruction syntax

Conditional Code Suffixes

- The cond operand in IT instruction uses the same condition codes as conditional branch
- It is possible to use AL (the always condition) for *cond* in an IT instruction.
- If this is done, all of the instructions in the IT block must be unconditional, and each of x, y, and z must be T or omitted but not E.

| Code Suffix | Flags | Description |
|-------------|--------------------|---------------------------------------|
| EQ | Z = 1 | Equal (==) |
| NE | Z = 0 | Not equal (! =) |
| CS or HS | C = 1 | Unsigned higher or same (≥) |
| CC or LO | C = 0 | Unsigned lower (<) |
| MI | N = 1 | Negative |
| PL | N = 0 | Positive or zero |
| VS | V = 1 | Overflow occurred |
| VC | V = 0 | Overflow did not occur |
| HI | C = 1 and $Z = 0$ | Unsigned higher (>) |
| LS | C = 0 or Z = 1 | Unsigned lower or same (\leq) |
| GE | N = V | Signed greater than or equal (\leq) |
| $_{ m LT}$ | N != V | Signed less than |
| GT | Z = 0 and $N = V$ | Signed greater than |
| LE | Z = 1 and $N != V$ | Signed less than or equal |
| AL | any value | Always. This is the default setting |

How Condition Code works?

- The condition code suffix appended to an instruction inside an IT block requires the processor to test the condition code based on the status of the flags.
- If the condition test of a conditional instruction in IT block fails, the instruction
 - Does not execute
 - Does not write any value to its destination register
 - Does not affect any of the flags
 - Does not generate any exception
- This feature often eliminates the need to branch, avoiding pipeline stalls and results in an improved execution performance and can also increase code density

How Condition Code works?

- By default the data processing instructions do not affect the condition code flags but can be made to by suffixing S.
- On the other hand, the comparison instructions, e.g., CMP, TST, do affect the flags implicitly.
- The execution of an instruction in IT block is conditionally dependent on the status of the condition flags, which are updated by a priorly executed instruction.
- The prior instruction that has updated the flags can either be the immediately preceding instruction that updated the flags, or there may be an arbitrary number of intermediate instructions that did not update the flags

Examples

```
CMP R0, R1
                                 ; Compare parameters loaded to R0
IF Only Block
                                    ; with R1
                               ; If R0 < R1
• 3 Instructions
                ITTT LT
                ADDLT R2, R0, R1 ; add the two operands
                MULLT R3, R2, R0 ; multiply the sum with first
                                  ; operand in R0
                ASRLT R3, R3, #1 ; divide the result by 2
IF-ELSE Block
                 CMP RO, R1
                                    ; Compare parameters
                                     ; loaded to R0 with R1

    4 instructions

                                ; If R0 < R1
                 ITTEE LT
                 ADDLT R2, R0, R1 ; part of IF
                MULLT R3, R2, R0 ; part of IF
                 SUBGE R2, R0, R1 ; part of ELSE
                ASRGE R3, R3, #1 ; part of ELSE
```

Examples

IF-THEN CONDITIONAL INSTRUCTION BLOCK

Implementing if-else using IT block

Examples

IF-THEN CONDITIONAL INSTRUCTION BLOCK

Implementing nested if-else using IT block

```
if(R0 > R1) {
  if(R1 > R2) {
    if(R2 > R3) {
       R4 = 0x123;
    }
}
```

```
CMP R0, R1 ; Compare R0 with R1 ; Condition to check if R0 > R1 SUBSGT R5, R1, R2 ; check if R1 > R2 SUBSGT R5, R2, R3 ; check if R2 > R3 MOVGT R4, #0x123
```

Instruction Execution

IF-THEN CONDITIONAL INSTRUCTION BLOCK

Data Processing Instructions inside IT Block

- It is important to note that data processing instructions, encoded using 16-bit encoding, do not update APSR when they are used inside an IT instruction block.
- If the suffix S is added to the conditionally executed instructions inside the IT block, then 32-bit encoding of the instruction would be used by the assembler.

Interrupt Handling while inside IT Block

- In case an exception or interrupt has happened, while the processor was executing an IT instruction block, the execution status for that IT block is stored to the stacked **xPSR** register (specifically in the IT/Interrupt-Continuable Instruction [ICI] bit field).
- Once the execution of the interrupt service routine has been completed, the IT block execution is resumed and the remaining instructions of the block can continue the execution.
- In case of multi-cycle instructions (for example, multiple load and store) inside an IT block, if an exception occurs during its execution, the whole instruction is abandoned and restarted after the interrupt process is completed.

Rules for IT Block Construction

- A branch or any instruction that modifies the PC must either be outside an IT block or must be the last instruction inside the IT block.
- Do not branch to any instruction inside an IT block, except when returning from an exception handler
- All conditional instructions except conditional branches must be inside an IT block.
 Conditional branch instructions can be the last instructions of an IT block.
- The conditional branch instructions have a larger branch range when they are used inside an IT block.
- Each instruction inside the IT block must specify a condition code suffix that is either the same or logical inverse of the condition code used by the IT instruction.
- The first conditional instruction inside the IT block should always use the condition code the same as the one used by the IT instruction itself.

IT Instruction Advantages Illustration

- Conditional execution based on IT block can provide both the code density as well as execution speed improvement
- To validate these advantages, Greatest Common Divisor (GCD) Algorithm, proposed by Euclid, is implemented for both with and without IT Instructions

```
// GCD implementation based
// on Euclid algorithm
int gcd( int a, int b) {
  while (a != b) {
    if (a > b)
        a = a - b;
    else
        b = b - a;
  }
  return a;
}
```

```
; Euclid GCD algorithm
; without IT Instructions
gcd

CMP R0, R1

BEQ stop

BLT less

SUBS R0, R0, R1

B gcd

less

SUBS R1, R1, R0

B gcd

stop
```

```
; Euclid GCD algorithm
; with IT Instructions
gcd
CMP R0, R1
ITE GT
SUBGT R0, R0, R1
SUBLE R1, R1, R0
BNE gcd
```

IT Instruction Advantages Illustration

- It is important to note that branch instructions for Cortex-M3/M4 based processors can take from 2 to 4 cycles for their execution, depending on the alignment and width of the target instruction.
- For the micro-controller used in this class, it takes 3 cycles for branch execution.
- On the other hand, many of the data processing instructions require **one cycle** for their execution.
- The extra cycles required for the branch operation are attributed to the fact that branch instructions require refilling of the pipeline.
- In case of conditional branch, if the condition is false then branch does not occur and in this case the instruction only takes one cycle for its execution

IT Instruction Advantages Illustration

- The execution performance for the GCD algorithm is superior for the IT block-based implementation compared to the conditional branch-based implementation
- Euclid GCD Algorithm without IT Instructions
 - Seven 16-bits instructions (14 bytes of ROM used)
- Euclid GCD Algorithm with IT Instructions
 - Five 16-bits instructions (10 bytes of ROM used)

| | Conditional Branch | IT block |
|------------------|---------------------------|-----------|
| R0 = 1, R1 = 2 | 13 cycles | 12 cycles |
| R0 = 10, R1 = 24 | 45 cycles | 40 cycles |

```
; Euclid GCD algorithm
; without IT Instructions
gcd
    CMP R0, R1
    BEQ stop
    BLT less
    SUBS RO, RO, R1
    B gcd
less
    SUBS R1, R1, R0
    B gcd
stop
; Euclid GCD algorithm
; with IT Instructions
acd
   CMP RO, R1
    ITE GT
    SUBGT RO, RO, R1
    SUBLE R1, R1, R0
    BNE gcd
```

THANK YOU

Any Questions???