# Versioning Standard

Isomorph Research Laboratories:: Dept of the Unreal

# 2 October 2021

Testing Suffix Note that -alpha or -beta may be optionally included at the end of a version number to indicate initial testing of a product to be more explicit to those not understanding the semantic meanings of 0.5.0 or 0.9.0. In these cases, the correct version numbers should still be included, and the inclusion of the testing suffix is intended as an easier way of identifying the testing face for those not familier with the product. Note that this should almost always be done if versions are being distributed for external testing, in order to make the state of the product perfectly clear. In all other cases, this can be done at the discretion of the designer.

### Software

Isomorph Research Laboratories uses "Semantic Versioning," the form of which is major.minor.patch.

## Major

This number which should be no more than **two** digits, indicates that a backwards-incompatible change was made.

For example, a version update from 1.5.7 to 2.0.0 indicates that a change was made in the software, such that things that interacted with the previous API may no longer work.

**Prototypes** A special exception to this rule is in the case of *prototypes*, which are defined as early revisions of a project that are not yet ready for distribution, due to safety concerns, unstable code, not yet implementing all features required for testing, not yet having been tested, etc.

In these cases, where the revision is still a prototype, the Major part of the version number will be 0, without exception.

# Minor

This number, which should be no more than **two** digits, indicates that new functionality has been added.

For example, a version update from 1.4.7 to 1.5.0 indicates that the new version (1.5.0) includes some functionality and features not included in the previous version.

Note: This number resets to 0 upon iteration of the "major" number. e.g. 1.5.4 to 2.0.0

**Prototypes** In the case where the current revision is a prototype, there are two minor revisions that carry special semantic meaning: -0.5.x indicates that the product is currently undergoing *alpha* testing and revisions required therein -0.9.x indicates that the product is currently undergoing *beta* testing and revisions required therein

#### Patch

This number, which should be no more than **three** digits, indicates that bugs or issues in previous versions have been addressed.

For example, a version update from 2.1.0 to 2.1.1 indicates that bug-fixes and corrections of feature implementation have occured.

This number resets to 0 upon iteration of the "minor" number, e.g. 1.5.4 to 1.6.0 or 1.5.4 to 2.0.0.

#### Follow Letter

In some cases, when a project splits into various branches for any reason, a letter is added to the end of the version number to distinguish between branches.

Each branch begins iterating and update its version number independently from the others, but the letter remains, so that it is easier to identify the common parent of several branches.

For example, the project entitled "Nomad" has been split into three branches: explorer, ranger, and commander.

Assuming the common parent of version 0.5.0, the new branches would begin at 0.5.0e, 0.5.0r, and 0.5.0c respectively. Further iterations in each design are independent from the others, and only iterate the version number of their branch. For example, if the explorer class added new features, it would iterate to 0.6.0e while ranger and commander classes would remain at 0.5.0r and 0.5.0c, respectively.

## Hardware

#### Major

This number which should be no more than **two** digits, indicates that a backwards-incompatible change was made. This is usually done upon complete redesign of

hardware, or upon adding new features which massively change the behavior of the product in any way.

For example, a version update from 1.5.7 to 2.0.0 indicates that a change was made in the hardware that changes the behavior, such as changing voltage requirements, or changing the number of outputs included.

**Prototypes** A special exception to this rule is in the case of *prototypes*, which are defined as early revisions of a project that are not yet ready for distribution, due to safety concerns, unstable code, not yet implementing all features required for testing, not yet having been tested, etc.

In these cases, where the revision is still a prototype, the Major part of the version number will be 0, without exception.

## Minor

This number, which should be no more than **two** digits, indicates that new functionality has been added which does not change the overall behavior of the hardware. This is often a subject of debate amongst project managers, and should ultimately be left at their discretion.

For example, a version update from 1.4.7 to 1.5.0 indicates that the new version (1.5.0) includes some functionality and features not included in the previous version but that do not change overall behavior, such as increasing clock speed of an onboard processor, or adding extra power filtering not *expressly* needed for the product.

Note: This number resets to 0 upon iteration of the "major" number. e.g. 1.5.4 to 2.0.0

**Prototypes** In the case where the current revision is a prototype, there are two minor revisions that carry special semantic meaning: -0.5.x indicates that the product is currently undergoing alpha testing and revisions required therein -0.9.x indicates that the product is currently undergoing beta testing and revisions required therein

# Patch

This number, which should be no more than **three** digits, indicates that bugs or issues in previous versions have been addressed. This is often done upon the remedying of manufactory errors, such as PCB misprints or incorrect traces, where the product produced does not match the expected behavior for the minor revision. If any functionality or behavior is changed, the minor or major number should be updated instead.

A common case in which a patch number would be incremented: if a PCB (ver. 1.2.0) is found to have an incorrect trace, which must be broken, and a patch wire soldered in, that PCB would now be at version 1.2.1.

This number resets to 0 upon iteration of the "minor" number, e.g. 1.5.4 to 1.6.0 or 1.5.4 to 2.0.0.

## Follow Letter

Follow letters are not used as in software, since splitting hardware functionality constitutes a new project name for the new functionality, and the version number is reset.