GoPiGo3 Cloud Data with ThingSpeak

Contents

GoPiGo3 Cloud Data with ThingSpeak	1
ThingSpeak Sensor Data Example	
Create ThingSpeak Account	
Setup ThingSpeak Channel	1
Create ThingSpeak Python Program	1
Jpload the Sensor Data	4

ThingSpeak Sensor Data Example

http://www.billthecomputerguy.com/gopigo

Create ThingSpeak Account

ThingSpeak.com is a free cloud service that can be used to collect and display data from the GoPiGo3. You can create a maximum of 4 channels with 8 data fields per channel.

- 1. Go to www.thingspeak.com Create a free account.
- 2. Go to **My Profile**. Edit and change your time zone to your local time zone.

Setup ThingSpeak Channel

- 1. Logon to your ThinkSpeak account.
- 2. Click **New Channel** to create a new channel. Give it a name.
- 3. Field 1: Distance Sensor Click Save Channel.
- 4. Click the **API Keys** tab. Copy the **Write API Key**. We will use this key to upload data to this channel.

Create ThingSpeak Python Program

We are going to upload Distance Sensor Data to our ThingSpeak channel.

Create the following file to hold your **Write API Key** for the channel you are using. You can keep multiple API keys in this file, just be sure to give each one a different name.

```
1  # thingspeak_api_key.py
2  # ThingSpeak channel write api keys
3
4  THINGSPEAK_API_KEY = 'insert your api key here'
```

```
#!/usr/bin/env python3
2
3
               thingspeak distance sensor.py
      Name:
      Author: William A Loring
4
5
      Created: 10/17/21 Revised:
6
      Purpose: Example of uploading data to a ThingSpeak Channel
  ....
7
8
  # This uses the EasyGoPiGo3 library
9
  # https://gopigo3.readthedocs.io/en/master/api-basic/easygopigo3.html#easygopigo3
11 # Import the time library for the sleep function
12 import time
13 import requests
14 # Substitute your api key in this file for updating your ThingSpeak channel
15 import thingspeak api key
16 # Import GoPiGo3 library
17 from easygopigo3 import EasyGoPiGo3
18
19 # Create an instance of the GoPiGo3 class
20 gpg = EasyGoPiGo3()
21
22 # Initialize a Distance Sensor object
23 my distance sensor = gpg.init distance sensor()
24
25 # ThingSpeak update URL
26 THINGS_URL = 'https://api.thingspeak.com/update?api_key=%s' % thingspeak_api_key.THINGSPEAK_API_KEY
27
28
29
  def main():
30
       while True:
31
           # Read the sensor data into millimeters and inches variables
32
           mm = str(my distance sensor.read mm())
33
           inches = str(my_distance_sensor.read_inches())
34
35
           # Print the values of the sensor to the console for debugging
36
           print("Distance Sensor Reading: " + inches + " inches " + mm + " mm")
37
38
           # Send sensor data to ThingSpeak
39
           thingspeak send(mm, inches)
40
41
           # 15 seconds is the minimum amount of time between uploads
42
           # Sleep is set to 15 seconds for testing purposes
43
           time.sleep(15)
44
45
46
   def thingspeak send(mm, inches):
47
48
           Update the ThingSpeak channel using the requests library
49
      print("Update Thingspeak Channel")
50
51
       # Open url and upload ThingSpeak data
52
       # Each @field number corresponds to a field in ThingSpeak
53
       ts update = requests.post(
54
           THINGS URL + "&fieldl=" + str(mm) + "&field2=" + str(inches))
55
56
       # Print ThngSpeak response to console
       # ts update.text is the thingspeak data entry number in the channel
58
      print("ThingSpeak Channel Entry: " + ts update.text)
59
60
61
  # If a standalone program, call the main function
62 # Else, use as a module
63 if __name__ == '__main__':
64
      main()
```

Upload the Sensor Data

Run the program. Move the GoPiGo around by hand or by a remote control program. Go to your ThingSpeak channel. Your data should show up almost immediately.