



# CSR Phase Space Dilution in CBETA



# What is CBETA?


## Cornell BNL ERL Test Accelerator



# What is CSR?

- **Synchrotron Radiation** (SR) emitted by an electron “kicks” other electrons in the same bunch.
- The radiation at long wavelengths (on the order of the bunch length) can add **coherently**.
- The radiation intensity scales as  $N_p^2$

SR Power spectrum of a 70pC Bunch through a dipole magnet



Courtesy of I.V. Bazarov

## Effects on beam

- Increase energy spread and emittance
- Energy loss
- Potential micro-bunching Instability

See Helper slide #1  
for detailed description

# Bmad Simulation Overview

## Two particle interaction




Figure 1: CSR calculation geometry. A “source” particle (red dots) is a distance  $z$  behind the “kicked” particle (blue dots). The radiation from the “source” particle at point  $P'$  and time  $t'$  interacts at some later time  $t$  with the kicked particle at point  $P$ .

$$\left( \frac{d\mathcal{E}}{ds} \right)_{\text{CSR}} = \int_{-\infty}^{\infty} ds' \frac{d\lambda(s')}{ds'} I_{\text{CSR}}(s - s')$$

$$I_{\text{CSR}} = -r_e m c^2 \left( \frac{2 \epsilon_L}{z L} + \frac{2}{L} \frac{\gamma^2 \theta_s \theta_k}{1 + \gamma^2 \theta_s^2} \right)$$

## 1D Model in Bmad




FIG. 6. (Color) Bmad implementation of the CSR algorithm. The beam of particles is divided up into a number of bins. The contribution of a particle to a bin’s total charge is determined by the overlap of the particle’s triangular charge distribution and the bins.

$$d\mathcal{E}_j = ds_{\text{slice}} \sum_{i=1}^{N_b} (\lambda_i - \lambda_{i-1}) \frac{I_{\text{CSR}}(j - i) + I_{\text{CSR}}(j - i + 1)}{2}$$

## Important parameters:

- $\text{Np}$  ( # particles )
- $\text{Nb}$  ( # bins )
- $\text{Q}$  ( bunch charge )

## Extra features:

- Can include Space Charge at high energy
- Can include shielding effect
- Can handle the case when design orbit is not the reference orbit ( like FFA cells )


# Benchmarking with Elegant



(10 equivalent FA cells, Np = 1M, Nb = 3000, Q = 5nC)


*Bmad*

*z-pz*



*x-px*

*Elegant*




The two programs agree well


Note: Elegant CSR cannot handle FFA cells (design  $\neq$  reference orbit),  
so FA cells were converted into equivalent bends and drifts for comparison

# Which CBETA section(s)


## generate the most CSR ?



The bunch undergoes the most “bending” in FA and FB



### One periodic FA cell





The bending is different for the four design orbits

# Effect of varying Nb

**CBETA 1-pass** ( $N_p = 600k$ ,  $Q=25pC$ )

z-pz phase space at the end of LINAC pass 2 (6 MeV)




$N_p/N_b$  cannot  
be too small

Picked  $N_b = 2500$

# Effect of varying Q

## CBETA 1-pass ( $N_p = 1M$ , $N_b = 2500$ )

z-pz phase space at the end of LINAC pass 2 (6 MeV)




For  $Q=50\text{pC}$ , max energy spread exceeds  $\pm 5.0\%$

# Effect of varying Q

## CBETA 1-pass ( $N_p = 1M$ , $N_b=2500$ )

x-px phase space as the end of LINAC pass 2 (6 MeV)







For  $Q > 75\text{pC}$ , max x beam size exceeds 15mm

# CBETA 4-pass varying Q (Np = 1M, Nb=2500)

CBET 

## No CSR





$$Q = 1 \text{ pC}$$

**Particle loss = 215 / 1M, Final  $\sigma_\delta \approx 7.00E-3$ , Final  $\sigma_x \approx 0.67$  mm**

# CBETA 4-pass varying Q (Np = 1M, Nb=2500)

CBET 


## No CSR





$x$  (nm)

**Particle loss = 658 / 1M, Final  $\sigma_\delta \approx 8.71E-3$ , Final  $\sigma_x \approx 1.42$  mm**

# CBETA 4-pass varying Np (5pC, Nb=2500)



Np chart		
100k	500k	900k
200k	600k	1M
300k	700k	
400k	800k	



A large  $N_p$  is required to reduce numerical noise


characteristic CSR energy change per unit length as

$$W_0 \equiv N r_c m c^2 \frac{(\kappa\sigma)^{2/3}}{\sigma^2}.$$


## Increase Bunch Length

A Gaussian bunch with various bunch length is tracked down 16 FA cells (42 MeV) with CSR.

### Relative energy loss $\langle\delta\rangle$



### Relative energy spread $\sigma_\delta$



Increasing bunch length mitigates CSR effects of energy loss and increasing energy spread.

## Vacuum Chamber Shielding

- Acts like waveguide with cutoff frequency
- Potentially decreases energy loss and spread





Figure 5.8: Average energy loss and energy spread versus the shielding parameter  $b_s$ .

Further simulation for CBETA required

- CSR could deteriorate CBETA beam quality as bunch charge and number of FFA pass increase.
- For CBETA 1-pass,  $Q < 50\text{pC}$  is required for final max energy spread  $< \pm 5.0\%$   
( Beam stop can ideally take  $\pm 7.0\%$  )
- For CBETA 4-pass,  $Q < 5\text{pC}$  is required for final max energy spread  $< \pm 5.0\%$ , but for  $Q = 1\text{pC}$  **200/1M particles lost** with the current lattice

## Future Plan

- Investigate particle loss
- Test effect of **shielding**
- Test effect of **increasing bunch length**

# Acknowledgement

- David Sagan (for Bmad assistance)
- Christopher Mayes (for CSR conceptual clearance)
- Kirsten Deitrick (for Elegant assistance)
- Georg Hoffstaetter (for result interpretation and **everything**)
- Christian Stoll (for python plot with large Np)

# References

- Bmad Manual
- Elegant Manual
- CBETA Design Report
- <http://www.slac.stanford.edu/cgi-wrap/getdoc/slac-pub-14893.pdf>