





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

(i) Important!

This replacement procedure can be used for: BMW X1 (E84) xDrive 28 i, BMW X1 (E84) xDrive 23 d, BMW X1 (E84) xDrive 25 i, BMW X1 (E84) xDrive 28 i Flex

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Coupe (E92) 330i 3.0

CLUB.AUTODOC.CO.UK 1–14







REPLACEMENT: BRAKE DISCS – BMW X1 (E84). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- HEX bit No.H5.
- HEX bit No.H7.
- Drive socket # 17
- Wheel impact socket #17

- Brake caliper wind back tool
- Ratchet wrench
- Torque wrench
- Tap wrench
- Impact screwdriver
- Crow bar
- Fender cover
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-14







Replacement: brake discs – BMW X1 (E84). Tip from AUTODOC experts:

- Replace the brake disks on the car BMW X1 (E84) in complete set for each axis.
 Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE DISCS – BMW X1 (E84). RECOMMENDED SEQUENCE OF STEPS:

- Open the hood.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Remove the wiper arm cover.



Unscrew the brake fluid reservoir cap.



CLUB.AUTODOC.CO.UK 3-14







- 5 Secure the wheels with chocks.
- 6 Loosen the wheel mounting bolts. Use wheel impact socket #17.



- Raise the front of the car and secure on supports.
- Unscrew the wheel bolts.



Replacement: brake discs – BMW X1 (E84). Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.
- Remove the wheel.



CLUB.AUTODOC.CO.UK 4-14







Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



Spread the brake pads. Use a crowbar.



Detach the brake caliper retaining spring. Use a crowbar.



14 Remove the brake caliper.



CLUB.AUTODOC.CO.UK 5-14







Replacement: brake discs – BMW X1 (E84). Professionals recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them.
 Replace, if necessary.

15

Remove the brake pads.



16

Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 6-14







Unscrew the caliper bracket fastening. Use a drive socket #17. Use a tap wrench.



18 Remove the caliper bracket.

20



Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the brake disc fastening. Use HEX No.H5. Use an impact screwdriver.



CLUB.AUTODOC.CO.UK 7-14







Remove the brake disc.



Clean the hub. Use a wire brush. Treat the contacting surface. Use copper grease.



23 Install the brake disc.

24



Tighten the brake disc fastening. Use HEX No.H5. Use a torque wrench. Tighten it to 16 Nm torque.



CLUB.AUTODOC.CO.UK 8-14







Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



AUTODOC recommends:

 Replacement: brake discs – BMW X1 (E84). After applying the spray, wait a few minutes.

26 Install the brake caliper bracket.

25



Tighten the brake caliper bracket. Use a drive socket #17. Use a torque wrench. Tighten it to 110 Nm torque.



CLUB.AUTODOC.CO.UK 9-14







Treat the brake caliper piston. Use a brake cleaner.



Replacement: brake discs – BMW X1 (E84). AUTODOC experts recommend:

• After applying the spray, wait a few minutes.

Press in the brake caliper piston. Use brake caliper wind back tool.



- Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use antisqueal paste.
- 31 Install the brake pads.



CLUB.AUTODOC.CO.UK 10-14