





#### SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

### i Important!

This replacement procedure can be used for: BMW 3 Convertible (E93) 318i 2.0, BMW 3 Convertible (E93) 320i 2.0, BMW 3 Convertible (E93) 325i 3.0, BMW 3 Convertible (E93) 325i 2.5, BMW 3 Convertible (E93) 320d 2.0, BMW 3 Convertible (E93) 323i 2.5

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Saloon (E90) 318i 2.0

CLUB.AUTODOC.CO.UK 1–11







# REPLACEMENT: BRAKE PADS – BMW 3 CONVERTIBLE (E93). TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- Combination spanner #13
- Combination spanner #15

- Drive socket # 13
- Wheel impact socket #17
- Torque wrench
- Brake caliper wind back tool
- Flat Screwdriver
- Crow bar
- Wheel chock

**Buy tools** 

CLUB.AUTODOC.CO.UK 2-11







## Replacement: brake pads – BMW 3 Convertible (E93). AUTODOC recommends:

- Perform the replacement of brake pads in complete set for each axis. This provides effective braking.
- The replacement procedure is identical for all brake pads on the same axle.
- Please note: all work on the car BMW 3 Convertible (E93) should be done
  with the engine switched off.

#### CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

Open the bonnet. Unscrew the brake fluid reservoir cap.

Secure the wheels with chocks.

3



Loosen the wheel mounting bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 3-11







- Raise the rear of the car and secure on supports.
- 5 Unscrew the wheel bolts.



#### **AUTODOC** recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
   BMW 3 Convertible (E93)
- Remove the wheel.



- Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the brake caliper fastening. Use a combination spanner #13. Use a combination spanner #15.



CLUB.AUTODOC.CO.UK 4-11







Spread the brake pads. Use a crowbar.



10 Remove the brake caliper.

9



## Replacement: brake pads – BMW 3 Convertible (E93). AUTODOC experts recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

CLUB.AUTODOC.CO.UK 5-11







Remove the brake pads. Use a flat screwdriver.



Remove the brake pads retaining clips. Use a flat screwdriver.



Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



#### **AUTODOC** recommends:

- Replacement: brake pads BMW 3 Convertible (E93). After applying the spray, wait a few minutes.
- 14 Install the brake pads retaining clips.



CLUB.AUTODOC.CO.UK 6-11







Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use antisqueal paste.



#### **AUTODOC** recommends:

• Make sure the disc surface is clean before installing the pads.

16 Install new brake pads.

17



### Replacement: brake pads – BMW 3 Convertible (E93). Tip:

• Make sure the pads are installed with linings facing the disc.

Treat the brake caliper piston. Use a brake cleaner.



CLUB.AUTODOC.CO.UK 7-11








#### **AUTODOC** recommends:

 Replacement: brake pads – BMW 3 Convertible (E93). After applying the spray, wait a few minutes.





Install the brake caliper and fix it. Use a combination spanner #15. Use a drive socket #13. Use a torque wrench. Tighten it to 35 Nm torque.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



20

21

Clean the brake disk surface. Use a brake cleaner.



CLUB.AUTODOC.CO.UK 8-11







# Replacement: brake pads – BMW 3 Convertible (E93). Tip from AUTODOC experts:

• After applying the spray, wait a few minutes.

22

Install the wheel.



#### **AUTODOC** recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. BMW 3 Convertible (E93)
- Screw in the wheel bolts. Use wheel impact socket #17.



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque wrench. Tighten it to 120 Nm torque.



CLUB.AUTODOC.CO.UK 9-11







### Replacement: brake pads – BMW 3 Convertible (E93). Tip:

 Without starting the engine, press the brake pedal several times until you feel significant resistance.

25

Remove the jacks and chocks.



#### **AUTODOC** recommends:

- Check the brake fluid level in the expansion tank and refill if necessary.
- 26

Tighten the brake fluid reservoir cap. Close the hood.

## Replacement: brake pads – BMW 3 Convertible (E93). AUTODOC recommends:

Slow down smoothly for first 150-200 km after the brake pads replacement.
 Avoid unneccessary and sharp braking to a stop.



**VIEW MORE TUTORIALS** 

CLUB.AUTODOC.CO.UK 10-11