





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for: BMW 3 Convertible (E36) 320i 2.0, BMW 3 Convertible (E36) 325i 2.5, BMW 3 Convertible (E36) M3 3.0, BMW 3 Convertible (E36) 328i 2.8, BMW 3 Convertible (E36) 323i 2.5, BMW 3 Convertible (E36) M3 3.2

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 5 Saloon (E39) 520i 2.0

CLUB.AUTODOC.CO.UK 1-6







REPLACEMENT: AIR FILTER – BMW 3 CONVERTIBLE (E36). TOOLS YOU NEED:



Fender cover

Buy tools

CLUB.AUTODOC.CO.UK 2-6







AUTODOC recommends:

- Replacement: air filter BMW 3 Convertible (E36). Do not ignore the
 maintenance schedule, recommendations, and requirements specified by the
 manufacturer on the use of the car part.
- All work should be done with the engine stopped.

REPLACEMENT: AIR FILTER – BMW 3 CONVERTIBLE (E36). USE THE FOLLOWING PROCEDURE:

Open the bonnet.

4

- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Release the air filter cover clips.



Remove the air filter housing.



CLUB.AUTODOC.CO.UK 3-6







Clean the air filter cover and housing.



Replacement: air filter – BMW 3 Convertible (E36). Tip from AUTODOC experts:

• Before cleaning the air filter cover and housing, cover the air duct parts, mass airflow sensor (if available), throttle valve with a clean cloth.





Insert a new filter element into the filter housing. Make sure that the filter edge fits tight to the housing.



CLUB.AUTODOC.CO.UK 4-6







AUTODOC recommends:

- Replacement: air filter BMW 3 Convertible (E36). Be sure to position the filtering element correctly. Avoid misalignment.
- During installation, make sure to prevent dust and dirt from getting into the air filter housing.
- Take care to only use quality filters.

Reinstall the air filter housing.



Press the air filter cover clips into place.



- Remove the fender protection cover.
- Close the hood.



VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 5-6