





SIMILAR VIDEO TUTORIAL



This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for:

BMW 3 Coupe (F46) 323Ci 2.5. BMW 3 Coupe (F46) 328Ci

BMW 3 Coupe (E46) 323Ci 2.5, BMW 3 Coupe (E46) 328Ci 2.8, BMW 3 Coupe (E46) 320Ci 2.0, BMW 3 Coupe (E46) 330xi 3.0, BMW 3 Coupe (E46) 320Ci 2.2, BMW 3 Coupe (E46) 325Ci 2.5, BMW 3 Coupe (E46) 330Ci 3.0

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 5 Saloon (E39) 520i 2.0

CLUB.AUTODOC.CO.UK 1–9







REPLACEMENT: SERPENTINE BELT – BMW 3 COUPE (E46). TOOLS YOU'LL NEED:



- Combination spanner #13
- Combination spanner #32
- Drive socket # 16

- Ratchet wrench
- Torque wrench
- Fender cover

Buy tools

CLUB.AUTODOC.CO.UK 2-9







Replacement: serpentine belt – BMW 3 Coupe (E46). AUTODOC recommends:

• All work should be done with the engine stopped.

REPLACEMENT: SERPENTINE BELT – BMW 3 COUPE (E46). USE THE FOLLOWING PROCEDURE:

- Open the bonnet.
- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Unscrew the fastener of the viscous fan clutch. Use a combination spanner #32.



Remove the fan shroud seal.



Unscrew and remove the viscous fan clutch.



CLUB.AUTODOC.CO.UK 3–9







6 Remove the fan shroud.



Pull aside the AC compressor belt tensioner pulley. Use a combination spanner #13.



Remove the AC compressor belt.



9 Remove the tensioner pulley cap.

10



Pull aside the V-ribbed belt tensioner pulley. Use a drive socket #16. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 4–9







11 Remove the V-ribbed belt.



Return the tensioner pulley to its initial position. Use a drive socket #16. Use a ratchet wrench.



Replacement: serpentine belt – BMW 3 Coupe (E46). Professionals recommend:

- Check the condition of the tensioner pulley and idler pulley. Replace them if necessary.
- Pull aside the V-ribbed belt tensioner pulley. Use a drive socket #16. Use a ratchet wrench.



13

CLUB.AUTODOC.CO.UK 5–9







14 Install the V-ribbed belt.



Replacement: serpentine belt – BMW 3 Coupe (E46). Tip from AUTODOC:

• Make sure that the V-ribbed belt fits all pulleys snugly.

Return the tensioner pulley to its initial position. Use a drive socket #16. Use a ratchet wrench.



Reinstall the tensioner pulley cap.



17 Install the AC compressor belt.



CLUB.AUTODOC.CO.UK 6–9







Replacement: serpentine belt – BMW 3 Coupe (E46). Tip:

• Make sure that the V-ribbed belt fits all pulleys snugly.





19 Install the fan shroud.

21



20 Install and screw in the viscous fan clutch.



Tighten the fastener of the viscous fan clutch. Use a combination spanner #32. Use a torque wrench. Tighten it to 40 nm torque.



CLUB.AUTODOC.CO.UK 7–9







Reinstall the fan shroud seal.



- Remove the fender protection cover.
- Close the hood.



VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 8-9