





### **VIDEO TUTORIAL**



## i Important!

This replacement procedure can be used for:

BMW 1 Coupe (E82) 118d 2.0, BMW 1 Coupe (E82) 120d 2.0, BMW 1 Convertible (E88) 120i 2.0, BMW 1 Convertible (E88) 125i 3.0, BMW 1 Coupe (E82) 125i 3.0, BMW 1 Convertible (E88) 118i 2.0, BMW 1 Convertible (E88) 120d 2.0, BMW 1 Convertible (E88) 128i 3.0

The steps may slightly vary depending on the car design.

CLUB.AUTODOC.CO.UK 1-16







# REPLACEMENT: BRAKE DISCS – BMW E82. LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Anti-squeal paste
- Copper grease
- HEX bit no.H6.
- HEX bit no.H7.
- Drive socket # 18
- Wheel impact socket #17

- Ratchet wrench
- Torque wrench
- Tap wrench
- Brake caliper wind back tool
- Impact screwdriver
- Crow bar
- Fender cover
- Wheel chock

**BUY TOOLS** 

CLUB.AUTODOC.CO.UK 2-16







### Replacement: brake discs – BMW E82. AUTODOC recommends:

- Replace the brake disks on the car BMW E82 in complete set for each axis.
  Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- All work should be done with the engine stopped.

# REPLACEMENT: BRAKE DISCS – BMW E82. RECOMMENDED SEQUENCE OF STEPS:

1

Open the hood.



Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.

3

Remove the wiper arm cover.



CLUB.AUTODOC.CO.UK 3-16







4 Unscrew the brake fluid reservoir cap.



Secure the wheels with chocks.



6 Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.



8 Unscrew the wheel bolts.



CLUB.AUTODOC.CO.UK 4–16







### **AUTODOC** recommends:

• Important! Hold the wheel while unscrewing the fastening bolts. BMW E82



12



Spread the brake pads. Use a crowbar.



Remove the dust boot caps of the brake caliper guide pins. Use a crowbar.



Unscrew the brake caliper fastening. Use HEX No.H7. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 5-16







Detach the brake caliper retaining spring. Use a crowbar.



Remove the brake caliper.



### Replacement: brake discs – BMW E82. AUTODOC experts recommend:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.
- Check the brake caliper bracket, brake caliper guide pins and boots. Clean them. Replace, if necessary.

CLUB.AUTODOC.CO.UK 6-16







15 Remove the brake pads.



- Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the caliper bracket fastening. Use a drive socket #18. Use a tap wrench.



Remove the caliper bracket.



- Clean the brake disc fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the brake disc fastening. Use HEX No.H6. Use an impact screwdriver.



CLUB.AUTODOC.CO.UK 7–16







Remove the brake disc.



Clean the hub. Use a wire brush. Treat the contacting surface. Use copper grease.



23 Install the brake disc.

24



Tighten the brake disc fastening. Use HEX No.H6. Use a torque wrench. Tighten it to 9 Nm torque.



CLUB.AUTODOC.CO.UK 8-16







Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use a brake cleaner.



### Replacement: brake discs – BMW E82. Tip:

- After applying the spray, wait a few minutes.
- 26 Install the brake caliper bracket.

28



Tighten the brake caliper bracket. Use a drive socket #18. Use a torque wrench. Tighten it to 110 Nm torque.



Treat the brake caliper piston. Use a brake cleaner.



CLUB.AUTODOC.CO.UK 9-16








### **AUTODOC** recommends:

 Replacement: brake discs – BMW E82. After applying the spray, wait a few minutes.





Treat the brake pads in the area where their surface comes into contact with the brake caliper bracket. Use antisqueal paste.



31 Install the brake pads.

**32** 



Install the brake caliper and fix it. Use HEX No.H7. Use a torque wrench. Tighten it to 30 Nm torque.



CLUB.AUTODOC.CO.UK 10-16