





This video shows the replacement procedure of a similar car part on another vehicle

i Important!

This replacement procedure can be used for: BMW Z4 Coupe (E86) 3.0 si

The steps may slightly vary depending on the car design.

This tutorial was created based on the replacement procedure for a similar car part on: BMW 3 Convertible (E46) 318Ci 2.0

CLUB.AUTODOC.CO.UK 1–13



REPLACEMENT: STRUT MOUNT – BMW Z4 COUPE (E86). LIST OF THE TOOLS YOU'LL NEED:



- Wire brush
- WD-40 spray
- Copper grease
- Combination spanner #17
- Drive socket # 13
- Drive socket # 18
- Wheel impact socket #17
- Ratchet wrench

- Torque wrench
- Adjustable wrench
- Tap wrench
- Crow bar
- Vice
- Hydraulic transmission jack
- Wheel chock

Buy tools

CLUB.AUTODOC.CO.UK 2-13





Replacement: strut mount – BMW Z4 Coupe (E86). AUTODOC experts recommend:

- The replacement procedure is identical for the mounts of the right and left shock absorbers of the rear suspension.
- Both mounts of the rear shock struts should be replaced simultaneously.
- All work should be done with the engine stopped.

CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

- Press and hold the folding roof control switch. Hold the button pressed until you get access to the upper fasteners of the shock absorber.
- Remove the shock strut mount caps. Use a crowbar.



Clean the fasteners of the shock absorber upper mount. Use WD-40 spray.



CLUB.AUTODOC.CO.UK 3-13





Loosen the upper fastener of the shock absorber. Use a drive socket #13. Use a ratchet wrench.



5 Secure the wheels with chocks.



6 Loosen the wheel mounting bolts. Use wheel impact socket #17.



- Raise the rear of the car and secure on supports.
- 8 Unscrew the wheel bolts.



CLUB.AUTODOC.CO.UK 4–13





AUTODOC recommends:

Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts.
BMW Z4 Coupe (E86)



12



Support the arm. Use a hydraulic transmission jack.



Clean the shock absorber fasteners. Use a wire brush. Use WD-40 spray.



Unscrew the lower fastener of the shock absorber. Use a drive socket #18. Use a tap wrench.



CLUB.AUTODOC.CO.UK 5-13





Unscrew the upper fastener of the shock absorber. Use a drive socket #13. Use a ratchet wrench.



Replacement: strut mount – BMW Z4 Coupe (E86). AUTODOC recommends:

• To avoid injuries, hold the shock absorber when undoing the fastening bolts.

14 Remove the fastening bolt.



Remove the shock absorber.



Grip the shock absorber in a vice.



CLUB.AUTODOC.CO.UK 6-13



O

Clean the shock absorber rod fastener. Use a wire brush.



Remove the shock absorber piston rod fastening. Use a combination spanner #17.



Release the vice and take out the shock absorber.



20

Remove the shock absorber mount, boot and bump stop.



Replacement: strut mount – BMW Z4 Coupe (E86). Tip from AUTODOC:

• Examine the shock absorber dust cap and the bump stop. Replace them if necessary.

CLUB.AUTODOC.CO.UK 7-13







Install the new mount, boot, and bump stop on the shock absorber.



Grip the shock absorber in a vice.



Screw the shock strut piston rod upper fastening. Use a combination spanner #17. Use an adjustable wrench. Use a torque wrench. Tighten it to 20 Nm torque.



Release the vice and take out the shock absorber.



CLUB.AUTODOC.CO.UK 8-13







Clean the shock absorber mounting seats. Use a wire brush. Use WD-40 spray.



Place the shock absorber in the wheel arch and secure it.



AUTODOC recommends:

- Important! Hold the shock absorber while screwing in the fastening bolts. BMW Z4 Coupe (E86)
- Screw the upper fastener of the shock absorber. Use a drive socket #13.



Tighten the lower fastener of the shock absorber. Use a drive socket #18. Use a torque wrench. Tighten it to 100 Nm torque.



CLUB.AUTODOC.CO.UK 9-13





Remove the support from under the arm.



AUTODOC recommends:

• Replacement: strut mount – BMW Z4 Coupe (E86). Lower the transmission jack smoothly, without jerks, to avoid damaging components and mechanisms.

Clean the wheel rim mounting seat. Use a wire brush. Treat the contacting surface. Use copper grease.



Install the wheel.



Replacement: strut mount – BMW Z4 Coupe (E86). Professionals recommend:

• To avoid injury, hold up the wheel when screwing in the fastening bolts.

CLUB.AUTODOC.CO.UK 10-13