

## NOTES:

- 1) AVOID PORT 0 (BITS 0 AND 1 WILL BE USED FOR THE SERIAL PORT)
  AND AVOID PORTS 4, 6 AND 7 (THESE WILL BE USED FOR BUS EXPANSION LATER).
  MAKE THE LEDS TURN ON WHEN THE CORRESPONDING PORT LINES ARE LOW.
- 2) BOTH LED COM PORTS NEED TO BE CONNECTED TO VDD (A1)

TITLE: Lab02 Input/Output					REV: 1.1
		Compa	ny: ECE3710		Sheet: 1/1
		Date:	2023-01-23	Drawn By: Jacob W	atts

