
0


- Search Adafruit
- SHOP
- BLOG
- <u>LEARN</u>
- FORUMSVIDEOS
- MY ACCOUNT
- SIGN OUT
- CLOSE MENU


0 Items

Hello, Jacob D'Avy | Sign Out | My Account | Wishlists

- SHOP
- BLOG
- LEARN
- FORUMS
- <u>VIDEOS</u>







Normal SRAM Operation

Fragmented Heap

Stack Crash!

Memories of an Arduino

How to get the most from your Arduino Memory

- You know you have a memory problem when...
- Memory Architectures
 - Arduino Memories
 - Arduino Memory Comparision
- Measuring Memory Usage
- Large Memory Consumers

- Solving Memory Problems
 - Optimizing Program Memory
 - Optimizing SRAM
 - Using EEPROM
- Single Page
- Download PDF

Contributors

Bill Earl Feedback? Corrections? LEARN ARDUINO

Optimizing SRAM

by Bill Earl

SRAM is the most precious memory commodity on the Arduino. Although SRAM shortages are probably the most common memory problems on the Arduino. They are also the hardest to diagnose. If your program is failing in an otherwise inexplicable fashion, the chances are good you have crashed the stack due to a SRAM shortage.

There are a number of things that you can do to reduce SRAM usage. These are just a few guidelines to get you started:

Remove Unused Variables

If you are not sure whether a variable is being used or not, comment it out. If the sketch still compiles, get rid of it!

F() Those Strings!

(Park the char* in Harvard PROGMEM)

Literal strings are repeat memory offenders. First they take up space in the program image in Flash, then they are copied to SRAM at startup as static variables. This is a horrible waste of SRAM since we will never be writing to them.

Paul Stoffregen of PJRC and Teensyduino fame developed the F() macro as a super-simple solution to this problem. The F() macro tells the compiler to keep your strings in PROGMEM. All you have to do is to enclose the literal string in the F() macro.

For example, replacing this:

Copy Code

1. Serial.println("Sram sram sram sram. Lovely sram! Wonderful sram! Sram sra-a-a-a-a sram sra-a-a-a-am sram. Lovely sram! Lovely sram! Lovely sram! with this:

Copy Code

1. Serial.println(F("Sram sram sram sram. Lovely sram! Wonderful sram! Sram sra-a-a-a-a sram sra-a-a-a sram. Lovely sram! Lovely sram! Lovely Will save you 180 bytes of wonderful SRAM!

Reserve() your strings

The Arduino string library allows you to reserve buffer space for a string with the reserve() function. The idea is you can prevent String from fragmenting the heap by using reserve(num) to pre-allocate memory for a String that grows.

With the memory already allocated, String doesn't need to call realloc() if the string grows in length. In most usages, lots of other little String objects are used temporarily as you perform these operations, forcing the new string allocation to a new area of the heap and leaving a big hole where the previous one was (memory fragmentation). Usually all you need to do is use reserve() on any long-lived String objects that you know will be increasing in length as you process text.

You can do better with C strings, but if you just follow these guidelines for String objects, they work nearly as efficiently and using them is so much easier.

Move constant data to PROGMEM.

Data items declared as PROGMEM do not get copied to SRAM at startup. They are a little less convenient to work with, but they can save significant amounts of SRAM. The basic Arduino reference for PROGMEM is <a href="https://example.com/here-exa

Reduce Buffer Sizes

Buffer and Array Allocations:

If you allocate a buffer, make sure it is no bigger than it needs to be.

Buffers in Libraries:

Also be aware that some libraries allocate buffers behind the scenes that may be candidates for trimming as well.

System Buffers

Another buffer hidden deeply in the system is the 64 byte serial receive buffer. If your sketch is not receiving a lot of high-speed serial data, you can probably cut this buffer size in half - or maybe even less.

The Serial buffer size is defined in HardwareSerial.cpp. This file can be found in your Arduino install directory:

....\Arduino-1.x.x\hardware\arduino\cores\arduino\HardwareSerial.cpp

Look for the line:

#define SERIAL_BUFFER_SIZE 64

And change it to 32 or less.


Reduce Oversized Variables

Don't use a float when an int will do. Don't use an int when a byte will do. Try to use the smallest data type capable of holding the information.

Data Types	Size in Bytes	Can contain:
boolean	1	true (1) or false (0)
char	1	ASCII character or signed value between -128 and 127
unsigned char, byte, uint8_t	1	ASCII character or unsigned value between 0 and 255
int, short	2	signed value between -32,768 and 32,767
unsigned int, word, uint16_t	2	unsigned value between 0 and 65,535
long	4	signed value between -2,147,483,648 and 2,147,483,647
unsigned long, uint32_t	4	unsigned value between 0 and 4,294,967,295
float, double	4	floating point value between - 3.4028235E+38 and 3.4028235E+38 (Note that double is the same as a float on this platform.)

Think Globally. Allocate Locally.

Let's have another look at how SRAM is used (and abused):



Global & Static Variables

Global and Static variables are the first things loaded into SRAM. They push the start of the heap upward toward the stack and they will occupy this space for all eternity.

Dynamic Allocations

Dynamically allocated objects and data cause the heap to grow toward the stack. Unlike Global and Static variables, these variables can be de-allocated to free up space. **But this does not necessarily cause the heap to shrink!** If there is other dynamic data above it in the heap, the top of the heap will not move. When the heap is full of holes like swiss cheese we call it a "**fragmented heap**".

Local Variables

Every function call creates a stack frame that makes the stack grow toward the heap. Each stack frame will contain:

- All parameters passed to the function
- All local variables declared in the function.

This data is usable within the function, but the space is 100% reclaimed when the function exits!

The Takeaway?


- Avoid dynamic heap allocations These can quickly fragment the limited heap-space.
- Prefer local to global allocation Stack variables only exist while they are being used. If you have variables that only are used in a small section of your code, consider making that code into a function and declaring the variables local to the function.

OPTIMIZING PROGRAM MEMORY USING EEPROM

Last updated on 2016-04-17 at 06.36.31 PM Published on 2013-08-02 at 10.19.49 AM



Arduino Uno R3 (Atmega328 - assembled) \$24.95 <u>ADD TO CART</u>




DC Boarduino (Arduino compatible) Kit (w/ATmega328) \$17.50 ADD TO CART



Arduino Mega 2560 R3 (Atmega2560 - assembled) \$45.95 OUT OF STOCK (NOTIFY ME)



Arduino Mega R3 Android Accessory Development Kit (ADK) Board \$84.95 OUT OF STOCK (NOTIFY ME)



FLORA - Wearable electronic platform: Arduino-compatible \$14.95 <u>ADD TO CART</u>



Teensy (ATmega32u4 USB dev board) 2.0 \$15.95 <u>ADD TO CART</u>



Atmega32u4 Breakout Board \$19.90 <u>ADD TO CART</u>



Arduino Uno Ethernet \$65.00 <u>OUT OF STOCK (NOTIFY ME)</u> <u>ADD ALL TO CART</u>

RELATED GUIDES

Smart Cocktail Shaker

<u>Use an Arduino and Android device to help you mix drinks!</u> by <u>Tony DiCola</u>



Learn how to hack a kitchen scale to be readable by an Arduino so it can send data to an Android device over USB or bluetooth.

Sparkle Skirt

Stitch a circuit that lights up when you move



Add LED pixels to a layered skirt, and use a FLORA motion sensor to trigger it to twinkle when you dance. FEATURED

FLORA TV-B-Gone

A tiny television neutralizer



The most wearable TV-B-Gone yet! Use freehand wiring with solder to whip up this pin capable of shutting off most television sets. Craft your own fabric ornament to match any outfit.

POPULAR

Arduino Lesson 3. RGB LEDs

Learn Arduino, Lesson 3. RGB LEDs



 $\frac{\text{This is Lesson 3 in the Learn Arduino Adafruit series. In this lesson, you will learn how to use a RGB LED with an Arduino.}{\times}$

OUT OF STOCK NOTIFICATION

YOUR NAME	
YOUR EMAIL	

NOTIFY ME

- <u>CONTACT</u>
- <u>SUPPORT</u>
- <u>DISTRIBUTORS</u>
- EDUCATORS
- JOBS
- FAO
- SHIPPING & RETURNS
- TERMS OF SERVICE
- PRIVACY & LEGAL
- ABOUT US

ENGINEERED IN NYC Adafruit ®

"How wonderful it is that nobody need wait a single moment before starting to improve the world" - Anne Frank

