			atible with all commands. For best compatibility, see https://ptzoptics.com/firmware-finder/
Command	Function ACK	Command Package z0 4y FF	Note Return when the command is accepted
ACK/Comletion	Completion	z0 5y FF	Return when the command has been executed
z = Camera Address + 8	Syntax Error	z0 60 02 FF	Returned when the command format is different or when a command with illegal command parameters is accepted
Error Messages	Command Buffer Full	z0 60 03 FF	Indicates that two sockets are already being used(executing two commands) and the command could not be accepted when received
	Command Canceled	z0 6y 04 FF	Returned when a command which is being executed in a socket specified by the cancel command is canceled. The completion message for the command is not returned
	No Socket Command Not Executable	z0 6y 05 FF e z0 6y 41 FF	Returned when no command is executed in a socket specified by the cancel command, or when an invalid socket number is specified Returned when a command canot be executed due to current conditions. For example, when commands controlling the focus manually are received during auto focus
z = Camera Address + 8			
	Stop Tele (Standard)	8x 01 04 07 00 FF 8x 01 04 07 02 FF	
CAM_Zoom	Wide (Standard)	8x 01 04 07 03 FF	
	Tele (Variable) Wide (Variable)	8x 01 04 07 2p FF 8x 01 04 07 3p FF	p = 0(low) - 7(high)
	Direct	8x 01 04 47 0p 0q 0r 0s FF	pqrs: Zoom Position (04 00 00 00 is zoomed all the way in, 00 00 00 00 is zoomed all the way out)
	Stop	8x 01 04 08 00 FF	
	Far (Standard) Near (Standard)	8x 01 04 08 02 FF 8x 01 04 08 03 FF	
	Far (Variable)	8x 01 04 08 2p FF	p = 0(low) - 7(high)
CAM_Focus	Near (Variable) Direct	8x 01 04 08 3p FF 8x 01 04 48 0p 0q 0r 0s FF	pgrs: Focus Position
CAM_FOCUS	Auto Focus	8x 01 04 38 02 FF	pqrs: Focus Position
	Manual Focus	8x 01 04 38 03 FF	AF On/Off
	Auto/Manual Focus Lock	8x 01 04 38 10 FF 8x 0a 04 68 02 FF	
	Focus Unlock	8x 0a 04 68 03 FF	Prevents any other operation or command from adjusting the current focus state
	Auto Indoor Mode	8x 01 04 35 00 FF	Normal Auto
	Outdoor Mode	8x 01 04 35 01 FF 8x 01 04 35 02 FF	Indoor mode Outdoor mode
CAM_WB	OnePush Mode	8x 01 04 35 03 FF	One Push WB mode
	Manual OnePush Trigger	8x 01 04 35 05 FF 8x 01 04 10 05 FF	Manual Control mode One Push WB Trigger
	Reset	8x 01 04 03 00 FF	
CAM_RGain	Up	8x 01 04 03 02 FF	Manual Control of R Gain
	Down Direct	8x 01 04 03 03 FF 8x 01 04 43 00 00 0p 0q FF	pq: R Gain
	Reset	8x 01 04 04 00 FF	
CAM_BGain	Up Down	8x 01 04 04 02 FF 8x 01 04 04 03 FF	Manual Control of B Gain
	Direct	8x 01 04 44 00 00 0p 0q FF	pq: B Gain
CAM_AE	Full Auto	8x 01 04 39 00 FF	Automatic Exposure mode
	Manual Shutter Priority	8x 01 04 39 03 FF 8x 01 04 39 0A FF	Manual Control mode Shutter Priority Automatic Exposure mode
0/4M_/L	Iris Priority	8x 01 04 39 0B FF	Iris Priority Automatic Exposure mode
	Bright Reset	8x 01 04 39 0D FF 8x 01 04 0B 00 FF	Bright Mode(Manual control)
	Up	8x 01 04 0B 00 FF	lris Setting
CAM_Iris	Down	8x 01 04 0B 03 FF	
	Direct Reset	8x 01 04 4B 00 00 0p 0q FF 8x 01 04 0A 00 FF	pq: Iris Position Default Shutter setting
CAMA Ob. w	Up	8x 01 04 0A 02 FF	Default Orditter setting
CAM_Shutter	Down	8x 01 04 0A 03 FF	
	Direct On	8x 01 04 4A 00 00 0p 0q FF 8x 01 04 33 02 FF	pq: Shutter Position
CAM_Backlight	Off	8x 01 04 33 03 FF	Back Light Compensation On/Off
CAM_Flicker	- Off	8x 01 04 23 0p FF 8x 01 04 63 00 FF	p: Flicker Settings - (0: Off, 1: 50Hz, 2: 60Hz)
CAM_PictureEffect	B&W	8x 01 04 63 04 FF	Picture Effect Setting
	Reset	8x 01 04 3F 00 pp FF	
CAM_Memory	Set Recall	8x 01 04 3F 01 pp FF 8x 01 04 3F 02 pp FF	pp: Memory Number(=0 to 127)
Preset Recall Speed	Preset Speed	8x 01 06 01 p FF	p is speed grade,the values are (0x1~0x18)
CAM_LR_Reverse	On Off	8x 01 04 61 02 FF 8x 01 04 61 03 FF	Image Flip Horizontal On/Off
CAM Pintur File	On	8x 01 04 66 02 FF	In one File Visid at One Off
CAM_PictureFlip	Off	8x 01 04 66 03 FF	Image Flip Vertical On/Off
	Up Down	8x 01 06 01 VV WW 03 01 FF 8x 01 06 01 VV WW 03 02 FF	
	Left	8x 01 06 01 VV WW 01 03 FF	
	Right UpLeft	8x 01 06 01 VV WW 02 03 FF 8x 01 06 01 VV WW 01 01 FF	
	UpRight	8x 01 06 01 VV WW 02 01 FF	VV: Pan speed 0x01 (low speed) to 0x18 (high speed)
Dan TillDrive	DownLeft DownPight	8x 01 06 01 VV WW 01 02 FF 8x 01 06 01 VV WW 02 02 FF	WW: Tilt speed 0x01 (low speed) to 0x14 (high speed)
Pan_TiltDrive	DownRight Stop	8x 01 06 01 VV WW 02 02 FF 8x 01 06 01 VV WW 03 03 FF	
	AbsolutePosition	8x 01 06 02 VV WW 0Y 0Y 0Y 0Y 0Z 0Z 0Z 0Z FF	YYYY: Pan Position ZZZZ: Tilt Position
		0Y 0Z 0Z 0Z 0Z FF 8x 01 06 03 VV WW 0Y 0Y 0Y	YYYY: Pan Position ZZZZ: Tilt Position
	RelativePosition	8x 01 06 03 VV WW 0Y 0Y 0Y 0Y 0Z 0Z 0Z 0Z FF	III I OSIION EEEE. III I OSIION
	Home	8x 01 06 04 FF	
CAM_Brightness	Reset Direct	8x 01 06 05 FF 8x 01 04 A1 00 00 0p 0q FF	pq: Brightness Position
CAM_Contrast	Direct	8x 01 04 A2 00 00 0p 0q FF	pq: Contrast Position
	Off Elle H	8x 01 04 A4 00 FF	
CAM_Flip	Flip-H Flip-V	8x 01 04 A4 01 FF 8x 01 04 A4 02 FF	Single Command For Video Flip
	Flip-HV	8x 01 04 A4 03 FF	
	Save High	8x 01 04 A5 10 FF 8x 01 04 A9 00 FF	Save Current Setting High
CAM_SettingSave	Normal	8x 01 04 A9 01 FF	Normal
CAM_SettingSave CAM_AWBSensitivity		8x 01 04 A9 02 FF	Low
	Low		
CAM_AWBSensitivity	Low Top	8x 01 04 AA 00 FF	AF Zone weight select
CAM_AWBSensitivity CAM_AFZone	Low	8x 01 04 AA 00 FF 8x 01 04 AA 01 FF 8x 01 04 AA 02 FF	AF Zone weight select
CAM_AWBSensitivity	Low Top Center Bottom Direct	8x 01 04 AA 00 FF 8x 01 04 AA 01 FF 8x 01 04 AA 02 FF 8x 01 04 4F 00 00 00 0p FF	AF Zone weight select p: Color Hue setting 0h (– 14 dgrees) to Eh (+14 degrees)
CAM_AWBSensitivity CAM_AFZone	Low Top Center Bottom Direct Open / Close	8x 01 04 AA 00 FF 8x 01 04 AA 01 FF 8x 01 04 AA 02 FF	1
CAM_AWBSensitivity CAM_AFZone CAM_ColorHue	Low Top Center Bottom Direct Open / Close Navigate Up Navigate Down	8x 01 04 AA 00 FF 8x 01 04 AA 01 FF 8x 01 04 AA 02 FF 8x 01 04 4F 00 00 00 0p FF 8x 01 04 3F 02 5F FF 8x 01 06 01 0E 0E 03 01 FF 8x 01 06 01 0E 0E 03 02 FF	1
CAM_AWBSensitivity CAM_AFZone	Low Top Center Bottom Direct Open / Close Navigate Up Navigate Down Navigate Left	8x 01 04 AA 00 FF 8x 01 04 AA 01 FF 8x 01 04 AA 02 FF 8x 01 04 AA 02 FF 8x 01 04 4F 00 00 00 0p FF 8x 01 04 3F 02 5F FF 8x 01 06 01 0E 0E 03 01 FF 8x 01 06 10 E 0E 03 02 FF 8x 01 06 01 0E 0E 03 07 FF	1
CAM_AWBSensitivity CAM_AFZone CAM_ColorHue	Low Top Center Bottom Direct Open / Close Navigate Up Navigate Down	8x 01 04 AA 00 FF 8x 01 04 AA 01 FF 8x 01 04 AA 02 FF 8x 01 04 4F 00 00 00 0p FF 8x 01 04 3F 02 5F FF 8x 01 06 01 0E 0E 03 01 FF 8x 01 06 01 0E 0E 03 02 FF	1

Command	Command Package	Return Package	Note
CAM_ZoomPosInq	8x 09 04 47 FF	y0 50 0p 0q 0r 0s FF	pgrs: Zoom Position
		y0 50 02 FF	Auto Focus
CAM_FocusAFModeInq	8x 09 04 38 FF	y0 50 03 FF	Manual Focus
CAM_FocusPosInq	8x 09 04 48 FF	y0 50 0p 0q 0r 0s FF	pqrs: Focus Position
		y0 50 00 FF	Auto
		y0 50 01 FF	Indoor mode
		y0 50 02 FF	Outdoor mode
		y0 50 03 FF	OnePush mode
CAM_WBModeInq	8x 09 04 35 FF	y0 50 05 FF	Manual
CAM_RGainInq	8x 09 04 43 FF	y0 50 00 00 0p 0q FF	pq: R Gain
CAM_BGainInq	8x 09 04 44 FF	y0 50 00 00 0p 0q FF	pq: B Gain
		y0 50 00 FF	Full Auto
		y0 50 03 FF	Manual
		y0 50 0A FF	Shutter priority (SAE)
		y0 50 0B FF	Iris priority (AAE)
CAM_AEModeInq	8x 09 04 39 FF	y0 50 0D FF	Bright
CAM_ShutterPosInq	8x 09 04 4A FF	y0 50 00 00 0p 0q FF	pq: Shutter Position
CAM_IrisPosInq	8x 09 04 4B FF	y0 50 00 00 0p 0q FF	pq: Iris Position
CAM_BrightPosInq	8x 09 04 4D FF	y0 50 00 00 0p 0q FF	pq: Bright Position
		y0 50 02 FF	On
CAM_ExpCompModeInq	8x 09 04 3E FF	y0 50 03 FF	Off
CAM_ExpCompPosInq	8x 09 04 4E FF	y0 50 00 00 0p 0q FF	pq: ExpComp Position
		y0 50 02 FF	On
CAM_BacklightModeInq	8x 09 04 33 FF	y0 50 03 FF	Off
		y0 50 02 FF	Auto Noise 2D
CAM_Noise2DModeInq	8x 09 04 50 FF	y0 50 03 FF	Manual Noise 2D
CAM_Noise2DLevel	8x 09 04 53 FF	y0 50 0p FF	Noise Reduction (2D) p: 0 to 5
CAM_Noise3DLevel	8x 09 04 54 FF	y0 50 0p FF	Noise Reduction (3D) p: 0 to 8
CAM_FlickerModeInq	8x 09 04 55 FF	y0 50 0p FF	p: Flicker Settings(0: OFF, 1: 50Hz, 2: 60Hz)
		y0 50 02 FF	Auto Sharpness
CAM_ApertureModeInq (Sharpness)	8x 09 04 05 FF	y0 50 03 FF	Manual Sharpness
CAM_ApertureInq (Sharpness)	8x 09 04 42 FF	y0 50 00 00 0p 0q FF	pq: Aperture Gain
		y0 50 02 FF	Off
CAM_PictureEffectModeInq	8x 09 04 63 FF	y0 50 04 FF	B&W
		y0 50 02 FF	On
CAM_LR_ReverseInq	8x 09 04 61 FF	y0 50 03 FF	Off
		y0 50 02 FF	On
CAM_PictureFlipInq	8x 09 04 66 FF	y0 50 03 FF	Off
CAM_ColorGainInq	8x 09 04 49 FF	y0 50 00 00 00 0p FF	p: Color Gain setting 0h (60%) to Eh (200%)
		y0 50 0w 0w 0w 0w	www. Pan Position
CAM_PanTiltPosInq	8x 09 06 12 FF	0z 0z 0z 0z FF	zzzz: Tilt Position
CAM_GainLimitInq	8x 09 04 2C FF	y0 50 0q FF	p: Gain Limit
		y0 50 01 FF	High
		y0 50 02 FF	Normal
CAM_AFSensitivityInq	8x 09 04 58 FF	y0 50 03 FF	Low
CAM_BrightnessInq	8x 09 04 A1 FF	y0 50 00 00 0p 0q FF	pq: Brightness Position
CAM_ContrastInq	8x 09 04 A2 FF	y0 50 00 00 0p 0q FF	pq: Contrast Position
		y0 50 00 FF	Off
		y0 50 01 FF	Flip-H
		y0 50 02 FF	Flip-V
CAM_FlipInq	8x 09 04 A4 FF	y0 50 03 FF	Filp-HV
		y0 50 00 FF	Top
		y0 50 01 FF	Center
CAM_AFZone	8x 09 04 AA FF	y0 50 02 FF	Bottom
CAM_ColorHueInq	8x 09 04 4F FF	y0 50 00 00 00 0p FF	p: Color Hue setting 0h (- 14 dgrees) to Eh (+14 degrees
		y0 50 00 FF	High
İ		y0 50 01 FF	Normal
CAM_AWBSensitivityInq	8x 09 04 A9 FF	y0 50 02 FF	Low
y = (x + 8) - X = VISCA Address			

Direct Shutter Values	p,q values	CAM Memory	p,q values	CAM Memory	p,q values
1/30	0,1	Preset 0	0,0	Preset 32	2,0
1/60	0,2	Preset 1	0,1	Preset 33	2,1
1/90	0,3	Preset 2	0,2	Preset 34	2,2
1/100	0,4	Preset 3	0,3	Preset 35	2,3
1/125	0,5	Preset 4	0,4	Preset 36	2,4
1/180	0,6	Preset 5	0,5	Preset 37	2,5
1/250	0,7	Preset 6	0,6	Preset 38	2,6
1/350	0,8	Preset 7	0,7	Preset 39	2,7
1/500	0,9	Preset 8	0,8	Preset 40	2,8
1/725	0,A	Preset 9	0,9	Preset 41	2,9
1/1000	0,B	Preset 10	0,A	Preset 42	2,A
1/1500	0,C	Preset 11	0,B	Preset 43	2,B
1/2000	0,D	Preset 12	0,C	Preset 44	2,C
1/3000	0,E	Preset 13	0,D	Preset 45	2,D
1/4000	0,F	Preset 14	0,E	Preset 46	2,E
1/6000	1,0	Preset 15	0,F	Preset 47	2,F
1/10000	1,1	Preset 16	1,0	Preset 48	3,0
Direct Iris Values	p,q values	Preset 17	1,1	Preset 49	3,1
Close	0,0:0,3	Preset 18	1,2	Preset 50	3,2
F11	0,6	Preset 19	1,3	Preset 51	3,3
F9.6	0,7	Preset 20	1,4	Preset 52	3,4
F8.0	0,8	Preset 21	1,5	Preset 53	3,5
F6.8	0,9	Preset 22	1,6	Preset 54	3,6
F5.6	0,A	Preset 23	1,7	Preset 55	3,7
F4.8	0,B	Preset 24	1,8	Preset 56	3,8
F4.0	0,C	Preset 25	1,9	Preset 57	3,9
F3.4	0,D	Preset 26	1,A	Preset 58	3,A
F2.8	0,E	Preset 27	1,B	Preset 59	3,B
F2.4	F2.4 0,F		Preset 28 1,C		3,C
F2.0	F2.0 1,0		1,D	Preset 61	3,D
F1.8	1,1	Preset 30	1,E	Preset 62	3,E
Exp Comp Values	p,q values	Preset 31	1,F	Preset 63	3,F
-7	0,0	Gain Values	p,q values		
-6	0,1	0	0,0		
-5	0,2	1	0,1		
-4	0,3	2	0,2		
-3	0,4	3	0,3		
-2	0,5	4	0,4		
-1	0,6	5	0,5		
0	0,7	6	0,6		
1	0,8	7	0,7		
2	0,9				
3	0,A				
4	0,B				
5	0,C				
	0,D				

0,E

Values for Direct	p,q values	Values for Direct	p,q values	Values for Direct	p,q values	Values for Direct	p,q values
R and B values	p,q values	R and B values	p,q values	R and B values	p,q values	R and B values	p,q values
0	0,0	64	4,0	128	8,0	192	C,0
1	0,1	65	4,1	129	8,1	193	C,1
2	0,2	66	4,2	130	8,2	194	C,2
3	0,3	67	4,3	131	8,3	195	C,3
4	0,4	68	4,4	132	8,4	196	C,4
5	0,5	69	4,5	133	8,5	197	C,5
6	0,6	70	4,6	134	8,6	198	C,6
7 8	0,7	71	4,7	135 136	8,7	199 200	C,7
9	0,8	72 73	4,8	137	8,8	200	C,8
10	0,9 0,A	73	4,9 4,A	137	8,9 8,A	201	C,9 C,A
11	0,A 0,B	75	4,A 4,B	139	8,B	202	C,A C,B
12	0,B	76	4,B 4,C	140	8,C	204	C,C
13	0,C 0,D	77	4,C 4,D	141	8,D	205	C,D
14	0,E	78	4,E	142	8,E	206	C,E
15	0,E	79	4,F	143	8,F	207	C,F
16	1,0	80	5,0	144	9,0	208	D,0
17	1,1	81	5,1	145	9,1	209	D,1
18	1,2	82	5,2	146	9,2	210	D,2
19	1,3	83	5,3	147	9,3	211	D,3
20	1,4	84	5,4	148	9,4	212	D,4
21	1,5	85	5,5	149	9,5	213	D,5
22	1,6	86	5,6	150	9,6	214	D,6
23	1,7	87	5,7	151	9,7	215	D,7
24	1,8	88	5,8	152	9,8	216	D,8
25	1,9	89	5,9	153	9,9	217	D,9
26	1,A	90	5,A	154	9,A	218	D,A
27	1,B	91	5,B	155	9,B	219	D,B
28	1,C	92	5,C	156	9,C	220	D,C
29	1,D	93	5,D	157	9,D	221	D,D
30	1,E	94	5,E	158	9,E	222	D,E
31	1,F	95	5,F	159	9,F	223	D,F
32	2,0	96	6,0	160	A,0	224	E,0
33	2,1	97	6,1	161	A,1	225	E,1
34	2,2	98	6,2	162	A,2	226	E,2
35	2,3	99	6,3	163	A,3	227	E,3
36	2,4	100	6,4	164	A,4	228	E,4
37	2,5	101	6,5	165	A,5	229	E,5
38	2,6	102	6,6	166	A,6	230	E,6
39	2,7	103	6,7	167	A,7	231	E,7
40	2,8	104	6,8	168	A,8	232	E,8
41	2,9	105	6,9	169	A,9	233	E,9
42	2,A	106	6,A	170	A,A	234	E,A
43	2,B	107	6,B	171	A,B	235	E,B
44	2,C	108	6,C	172	A,C	236	E,C
45	2,D	109	6,D	173	A,D	237	E,D
46	2,E	110	6,E	174	A,E	238	E,E
47	2,F	111	6,F	175	A,F	239	A,F
48	3,0	112	7,0	176	B,0	240	F,0
49	3,1	113	7,1	177	B,1	241	F,1
50	3,2	114	7,2	178	B,2	242	F,2
51	3,3	115	7,3	179	В,3	243	F,3
52	3,4	116	7,4	180	B,4	244	F,4
53	3,5	117	7,5	181	B,5	245	F,5
54	3,6	118	7,6	182	B,6	246	F,6
55	3,7	119	7,7	183	B,7	247	F,7
56	3,8	120	7,8	184	B,8	248	F,8
57	3,9	121	7,9	185	B,9	249	F,9
58	3,A	122	7,A	186	B,A	250	F,A
59	3,B	123	7,B	187	B,B	251	F,B
60	3,C	124	7,C	188	B,C	252	F,C
61	3,D	125	7,D	189	B,D	253	F,D
62	3,E	126	7,E	190	B,E	254	F,E
63	3,F	127	7,F	191	B,F	255	F,F