WindCube software package

version 1.2

Jana Preißler, C-CAPS, NUIG, jana.preissler@nuigalway.ie

November 11, 2015

1 Introduction

This is a documentation for scripts written in Python 2.7 to convert the ASCII files exported from the internal MySQL data base on the WindCube instrument to netCDF file format. This software package can also be used to plot the radial wind, carrier-to-noise ratio and relative backscatter, and calculate horizontal wind speed and direction, and vertical wind speed from VAD scans. This all can be done on an operational basis (run as cron job).

The programme package has been tested on Windows 7 and Ubuntu 12.04 (server). Adjusting the data paths in the configuration file should be the only change necessary to run it on either of the platforms.

The three scripts are explained in the following sections. A list of required python modules is given at the end of the document.

2 The input

The ASCII input files are exported from the internal MySQL data base on the Wind-Cube using the scripts provided by the manufacturer. The file names should follow this convention:

YYYYmmdd-HH_ending.txt,

with YYYY, year in four digits; mm, month in two digits; dd day of the month in two digits; HH, hour of the day in two digits. The file endings (ending) can be adjusted in the configuration file config_lidar.py ('fend' in 'VarDict'). They are pre-set to the following:

- whole_radial: contains the whole radial wind and carrier-to-noise ratio (CNR),
- radial_beta: contains the attenuated relative backscatter,
- spectra: contains the Doppler spectra,
- dbs_wind: contains the wind components from the DBS scans.

These input files are looked for in the input path given in config_lidar.py ('DataPath'), appending the year to it:

DataPath\YYYY\.

Likewise, the folder YYYY\ is appended to the output path. If the year folder is missing, it will be added to the output path.

3 The configuration file

All variable parameters are specified in the configuration file config_lidar.py. The user needs to modify the input and output paths, the scan ID numbers, the global attributes and general variables for netCDF files (location, latitude, longitude, etc.; GloDict and GenDict['val']). Also, the date of the run needs to be set. The script can be run as cron job in near real time operation. Alternatively, as string can be provided as sDate.

The list proplist includes all runs, the software should go through: ['beta', 'wind', 'dbs', 'spectra']. The run 'spectra' reads in the spectra files and stores them as netCDF. No plots are done in this run. The run 'beta' reads in the beta files, stores them as netCDF and plots the different scans depending on SWITCH_MODE (see below). The run 'wind' reads in the radial wind files, stores them as netCDF and plots the different scans depending on SWITCH_MODE (see below). It also calculates the horizontal wind and direction as well as the vertical wind velocity and plots them, if 'VAD' is included in SWITCH_MODE. The run 'dbs' is for testing purposes only. It can be used to compare the wind components from a DBS to the VAD results.

The switches can be used to customise the output. The user has the choice to plot the background, or use the confidence index provided by the instrument to remove the background (SWITCH_REMOVE_BG); zoom in on the background noise by reducing the colour scale limits (SWITCH_ZOOM); print status messages on screen if run from command line (SWITCH_OUTPUT); timing of the main processes while running the script and printing time elapsed since start of script if output is activated (SWITCH_TIMER); of the scan types that will be processed and plotted (either all types (['all']) or specific types provided in a list: ['VAD', 'LOW', 'LOS', 'LOS90']) (SWITCH_MODE); create additional output in HDCP2-like netCDF format (requires, in run 'wind', existing beta netCDF file, or in run 'beta', existing wind and VAD netCDF file).

The SWITCH_NC should remain at False, as the other two options are faulty and/or not properly tested. At this setting all text files of the specified date in data path are used as input. If there are 24 input text files, they will be deleted after loading them.

For hard-target scans, a zoom in to specific LOS scans can be set up. The range limits are adjusted in dictionary LOSzoom, where the dictionary keys are scan IDs and the values are a list of plot limits in meter [min_range, max_range].

The large dictionary VarDict contains all variables for reading the text files, plotting and netcdf creation. There is one entry in the dictionary for each output parameter (level 0: spectra; level 1: wind, cnr, beta, dbs; level 2: VAD). The dictionary AttDict contains

variable information for the HDCP2-like output. This needs cleaning up / combining VarDict and AttDict.

4 The windcube tools

This script includes all tools for data reading, output, and the wind fit (VAD).

get_data

Reads in data from text files returned from the MySQL data base on the instrument. Returns a pandas data frame including all data.

$export_to_netcdf$

Exports pandas data frame to netCDF file, including global attributes, long names and units.

open_existing_nc

Opens existing netCDF file, created by export_to_netcdf. Returns a pandas data frame.

wind_fit

Runs a loop over all VAD scans and fits a sine curve to each range bin (least square fit). Calls the plotting function to plot the horizontal wind speed and direction and the vertical wind. Exports results to a separate netCDF file for each VAD scan type.

set_outliers_to_nan

Removes outliers before the wind fit.

printif

Prints message if output option is set in configuration file (SWITCH_OUTPUT).

timer

Calculates time since start of the script. Prints the difference, if output option is set to True.

5 The windcube plotting

This script contains all functions necessary for plotting the different scan patterns and results.

prepare_plotting

Brings the pandas data frame to a 2-dimensional grid. Returns also axes limits and color bar properties.

get_lims

Determines the plotting limits and returns them. Called by prepare_plotting.

plot_ts

Plots a time-height contour plot. Stores it in the output directory.

plot_low_scan

Plots low level scan data on a polar grid.

plot_los

Plots LOS (line-of-sight) scans. Calls plot_ts.

plot_correlation

Scatter plot of two cloumns in a pandas data frame.

6 The windcube extras

This script contains extra functions, mostly used for testing.

```
compare\_dbs
```

Compares DBS wind to VAD scan fit results.

```
create_hdcp2_output
```

Brings the data in correct format to be processed by export_to_netcdf and output in HDCP2-like netCDF format.

7 The run file

The file run.py should be used to start the programme. It is importing all information from the configuration file as well as all functions from the other files. It then calls the functions according to the specifications in the configuration file, especially the switches.

8 Python modules

```
datetime date and time conversions
glob handling files

matplotlib plotting (namely matplotlib.pyplot and matplotlib.dates)
numpy numerical operations
os file and path handling
pandas easier handling of large data sets
pdb de-bugging
scipy least square fit of wind data (namely scipy.optimize)
seaborn plotting
time process timing
xray conversion to netcdf
```