Lab 2: Transistor superthreshold saturation current and drain characteristics

Group number: 4.5

Team member 1: Jan Hohenheim

Team member 2: Maxim Gärtner

Date: 12.10.2021

The objective of this lab is to understand *super-threshold* (also called *above-threshold* or *strong inversion*) transistor operation and to understand transistor drain conductance characteristics, particularly *channel length modulation*.

The specific experimental **objectives of this lab** are as follows:

- 1. To characterize drain current of a transistor as a function of gate voltage in superthreshold operation in the ohmic (triode) and saturation regions.
- 2. To characterize the drain saturation properties in super-threshold.
- 3. To characterize drain conductance (the Early effect) and how it scales with transistor length (may not be possible this year) and saturation drain current.

An intuitive and quantitative understanding of all these effects, along with the subthreshold behavior (next week), is useful for the design of effective circuits, especially analog design of high performance amplifiers.

1 Terminology

- above-threshold = super-threshold = strong inversion
- sub-threshold = below-threshold = weak inversion
- triode region = ohmic region = linear drain conductance behavior with small drain-source voltage
- saturation = large $V_{\rm ds}$
- ullet overdrive = $V_{
 m g}-V_{
 m T}$
- ullet $U_{
 m T}=kT/q$ = thermal voltage = 25mV at room temperature
- $V_{\rm T}$ = threshold voltage = 0.4V to 0.8V depending on process

2 Useful Quantities

The following is a list of the physical parameters and constants we will be referring to in this lab, along with their values when appropriate. The units that are most natural for these quantities are also included; these units are not self--consistent, so make sure you convert the units when appropriate.

 ϵ_0 : Permittivity of vacuum = $8.86\times 10^{-12} F/m$

 ϵ_{Si} : Relative permittivity of Si = $11.7\epsilon_0$

 ϵ_{ox} : Relative permittivity of ${\rm SiO_2}$ = $3.9\epsilon_0$

 μ_n : electron surface mobility, ${
m cm}^2/{
m V/s}$

 μ_p : hole surface mobility, ${
m cm}^2/{
m V/s}$

 C_{ox} : gate capacitance across the oxide per unit area, ${
m fF}/{
m \mu m^2}$

 C_{dep} : capacitance of depletion region per unit area, ${
m fF}/{
m \mu m^2}$

 t_{ox} : gate oxide thickness pprox 3.8 nm for the class chip in 180 nm techology.

 V_T : threshold voltage, V (V_{T0} is V_T when V_s = 0).

W : electrical width of transistor channel, $=4~\mu m$ for both devices in this lab

L : electrical length of transistor channel, $=4~\mu m$ for both devices in this lab

$$\beta \equiv \mu C_{ox} W/L, \ \mu A/V^2$$

 V_E : Early voltage, characterizes drain conductance.

3 Prelab

Write the expressions/eqations in LaTeX, like $Vod = V_{\rm g} - V_{\rm T}$, or upload the pictures of handwritten expressions.

• For nFET, write the most general expression for I_{ds} above threshold in terms of $V_g,\ V_s,\ V_d$ (all voltages are referenced to the bulk), and the parameters and constants given above. Leave out the drain conductance Early effect in this equation. Assume $\kappa=1$ and that $V_{Tn}>0$.

```
For triode: I_{ds}=eta(V_g-V_s-V_{Tn})(V_d-V_s)
For saturation: I_{ds}=rac{1}{2}eta(V_g-V_s-V_{Tn})^2
```


• For pFET, write the most general expression for I_{ds} above threshold in terms of $V_g,\ V_s,\ V_d$ (all voltages are referenced to the bulk), and the parameters and constants given above. Leave out the drain conductance Early effect in this equation. Assume $\kappa=1$ and that $V_{Tp}<0$.

```
For triode: I_{ds}=\beta(V_g-Vs-V_{Tp})(V_d-V_s)
For saturation: I_{ds}=\frac{1}{2}\beta(V_g-Vs-V_{Tp})^2
The formulae are the same, but the resulting graph is mirrored!
```

• For nFET, sketch graphs of I_{ds} vs the V_d for several gate voltages V_g above threshold, with $V_s=0$. Indicate the ohmic and saturation regions and the behavior of the saturation voltage V_{dsat} as the gate overdrive voltage increases.

```
import numpy as np
import matplotlib.pyplot as plt
v_t = 0.8
v_s = 0
beta = 1
for v_g in np.arange(1, 2, 0.1):
    v_d1 = np.arange(0, 1, 0.001)
    v_d2 = np.arange(0, 1, 0.001)
    i_ds1 = beta*(v_g - v_s - v_t)*(v_d1 - v_s)
    i_ds2 = np.repeat(beta*0.5*(v_g - v_s - v_t)**2, 1/0.001)
```

```
index = next(filter(lambda i_ds: abs(i_ds[1][0]-i_ds[1][1]) < 0.0001, enumerate(zip(i_plt.plot(v_d1[:index], i_ds1[:index], 'b')
    plt.plot(v_d2[index:], i_ds2[index:], 'r')
    plt.text(1.07, i_ds2[-1], f"$V_g = {v_g:.2f}$V")
    plt.title(f"$I_ds$ with $V_t = 0.8V, V_s = 0V, \\beta = 1$")
    plt.xlabel("$V_d[V]$")
    plt.ylabel("$I_{ds}[A]$")
    plt.legend(["ohmic", "saturation"])
plt.show()</pre>
```




The saturation voltage increases with the overdrive voltage

• For nFET, derive an expression for the current I_{ds} in the ohmic region in terms of V_g and $V_{ds} \equiv V_d - V_s$. You may assume that $V_s = 0$. Sketch a graph of I_{ds} vs V_g , showing V_{T0} and an expression for the slope.

$$I_{ds} = eta(V_q - V_{T0})V_d$$


```
In [67]:
          import numpy as np
          import matplotlib.pyplot as plt
          v t = 0.8
          v s = 0
          beta = 1
          v d = 0.4
          v g = np.arange(0.0, 2, 0.1)
          i ds = beta*(v g - v s - v t)*(v d - v s)
          i ds = np.array([max(id, 0) for id in i ds])
          plt.plot(v g, i ds, label="$I {ds}$")
          plt.vlines(v t, -0.01, v d, colors="y", linestyles="dashed", label="$V {t0}$")
          plt.xlabel("$V g[V]$")
          plt.ylabel("$I {ds}[A]$")
          plt.title("$I {ds}$ for $V t = 0.8V, V d = 0.4V, V s = 0V, \beta = 1$. Slope is $V d \be
          plt.legend()
          plt.show()
```



• For nFET, state the drain voltage condition for above-threshold saturation and derive an expression for the saturation current I_{dsat} in terms of V_g . Sketch a graph of $\sqrt{I_{dsat}}$ vs V_g with $V_s=0$, showing V_{T0} and an expression for the slope. Do not consider the Early effect here.

$$I_{dsat}=rac{1}{2}eta(V_g-V_{T0})^2$$

```
In [84]:
          import numpy as np
          import matplotlib.pyplot as plt
          v t = 0.8
          v s = 0
          beta = 1
          v g = np.arange(0.0, 2, 0.1)
          sqrt i dsat = np.sqrt(beta)*0.25*(v g - v s - v t)
          sqrt i dsat = np.array([max(id, 0) for id in sqrt i dsat])
          plt.plot(v g, sqrt i dsat, label="$\\sqrt{I {dsat}}$")
          plt.vlines(v t, -0.01, v d, colors="y", linestyles="dashed", label="$V {t0}$")
          plt.xlabel("$V g[V]$")
          plt.ylabel(r"$\sqrt{I {dsat}}[\sqrt{A}]$")
          plt.title(r"$I {ds}$ for $V t = 0.8V, V s = 0V, \beta = 1$. Slope is \frac{1}{4}\sqrt{0}
          plt.legend()
          plt.show()
```



• Calculate C_{ox} for the classchip from the values given above. What is C_{ox} per square micron in fF?

$$egin{aligned} C_{ox} &= rac{\epsilon_{ox}}{t_{ox}} \ C_{ox} &= rac{3.9 imes \epsilon_0}{t_{ox}} \ C_{ox} &= rac{3.9 imes 8.86 imes 10^{-12} rac{\mathrm{F}}{\mathrm{m}}}{3.8 imes 10^{-9} \mathrm{m}} \ C_{ox} &= 0.009093 rac{\mathrm{F}}{\mathrm{m}^2} = 9093 rac{\mathrm{fF}}{\mu \mathrm{m}^2} \end{aligned}$$

• Write the expression for the drain current in saturation including the Early effect, using I_{dsat} to represent the saturation current in the absence of the Early effect. Use V_E to represent the Early voltage.

$$I_{ds} = I_{dsat}(1+rac{V_d-V_s}{V_E})$$

4 Setup

4.1 Connect the device

```
In [2]:
         # import the necessary library to communicate with the hardware
         #import sys
         #sys.path.append('/home/junren/software/CoACH Teensy interface/build/pc/pyplane')
         import pyplane
         import time
In [3]:
         # create a Plane object and open the communication
         if 'p' not in locals():
            p = pyplane.Plane()
                 p.open('/dev/ttyACM0') # Open the USB device ttyACM0 (the board).
             except RuntimeError as e:
                 print(e)
         # Note that if you plug out and plug in the USB device in a short time interval, the opera
         # then you may get error messages with open(...ttyACMO). So please avoid frenquently plugo
In [4]:
        p.get firmware version()
        (1, 8, 3)
Out[4]:
In [5]:
         # Send a reset signal to the board, check if the LED blinks
         p.reset(pyplane.ResetType.Soft)
        <TeensyStatus.Success: 0>
Out[5]:
In [6]:
         # NOTE: You must send this request events every time you do a reset operation, otherwise
         # Because the class chip need to handshake with some other devices to get the communication
         p.request events(1)
In [7]:
         # Try to read something, make sure the chip responses
         p.read current(pyplane.AdcChannel.GO0 N)
```


```
Out[7]: 1.8530273848682555e-07

In [7]: # If any of the above steps fail, delete the object, and restart the kernel # del p
```

4.2 Configurations for N-FET

```
In [8]:
# uses schemdraw, you may have to install it in order to run it on your PC
import schemdraw.elements as elm
d = schemdraw.Drawing()
Q = d.add(elm.NFet, reverse=True)
d.add(elm.Dot, xy=Q.gate, lftlabel='gate=AINO')
d.add(elm.Dot, xy=Q.drain, toplabel='drain=GO22')
d.add(elm.Dot, xy=Q.source, botlabel='source=GO20')
d.draw()
```

Out[8]:



To cancel out the leakage current and shunt resistance, you may need to do a subtraction.

$$I_{ds} = I_{GO20} - I_{GO20}|_{V_{gs}=0}$$

Note: It's better to measure source because its leakage is constant in this lab

You have to set the input voltage demultiplexer by sending a configuration event:

• Check the configuration is correct. If the measured result is not as expected, try sending the configration event again.

```
In [10]:  # set source voltage
    vs = 0.0
    p.set_voltage(pyplane.DacChannel.GO20 , vs)
    print(f"The source voltage is set to {vs:.2f} V")
```

The source voltage is set to 0.00 ${\tt V}$

```
p.set_voltage(pyplane.DacChannel.GO22 , vd)
print(f"The drain voltage is set to {vd:.2f} V")

The drain voltage is set to 1.80 V

In [12]:  # set gate voltage
    vg = 1.0
    p.set_voltage(pyplane.DacChannel.AINO, vg)
    print(f"The gate voltage is set to {vg:.2f} V")

The gate voltage is set to 1.00 V

In [13]:  # read I_{ds}
    I_s = p.read_current(pyplane.AdcChannel.GO20_N)  #source
    print(f"The measured source current is {I s} A")
```

#drain

The measured source current is 1.8554686903371476e-05 A The measured drain current is 2.0117187887080945e-05 A

I d = p.read current(pyplane.AdcChannel.G022)

print(f"The measured drain current is {I d} A")

- Question: Check if the measured currents change with different gate voltages?
 - Yes, a higher gate voltage will cause a higher current.

4.3 Configurations for P-FET

In [11]: # set drain voltage vd = 1.8

```
In [14]:
# uses schemdraw, you may have to install it in order to run it on your PC
import schemdraw.elements as elm
d = schemdraw.Drawing()
Q = d.add(elm.PFet, reverse=True, bulk=True)
d.add(elm.Dot, xy=Q.gate, lftlabel='gate=AINO')
d.add(elm.Dot, xy=Q.bulk, rgtlabel='bulk=AIN1')
d.add(elm.Dot, xy=Q.drain, botlabel='drain=GO21')
d.add(elm.Dot, xy=Q.source, toplabel='source=GO23')
d.draw()
```

Out[14]:

Hint: To cancel out the leakage current and shunt resistance, you may need to do a subtraction:

$$I_{ds} = I_{GO23} - I_{GO23}|_{V_{gs} = 0}$$

Note: It's better to measure source because its leakage is constant in this lab. Also think about the difference of V_{qs} between PMOS and NMOS?

You have to choose the input voltage demultiplexer by sending a configuration event (make sure LED1

blinks):

• Check the configuration is correct. If the measured result is not as expected, try sending the event again.

```
again.
In [16]:
          # set trial voltages
          Vs p = 1.8
          Vd p = 0.0
          Vg p = 1.0
          # set bulk voltage
          # If the bulk voltage is not the source voltage, we will get an np junction
          # If the bulk is lower than the source voltage, we will get the wrong flow of current
          # So if we want to change the threshold, we could set the bulk voltage a bit higher than
          # But the bulk voltage should always be the highest (in PFET)
          Vb p = Vs p
          print("The bulk voltage is set to {} V".format(Vb p))
          p.set voltage(pyplane.DacChannel.AIN1, Vb p)
          time.sleep(0.05) # wait 0.05s for it to settle
          # set source voltage
          p.set voltage(pyplane.DacChannel.GO23 , Vs p)
          print("The source voltage is set to {} V".format(Vs p))
          time.sleep(0.05) # wait 0.05s for it to settle
          # set drain voltage
          p.set voltage(pyplane.DacChannel.GO21 , Vd p)
          print("The drain voltage is set to {} V".format(Vd p))
          time.sleep(0.05) # wait for it to settle
          # set gate voltage
          p.set voltage(pyplane.DacChannel.AINO, Vg p)
          print("The gate voltage is set to {} V".format(Vg p))
         The bulk voltage is set to 1.8 V
         The source voltage is set to 1.8 V
         The drain voltage is set to 0.0 \rm V
         The gate voltage is set to 1.0 \rm V
In [17]:
         # read I {ds}
          Is p = p.read current(pyplane.AdcChannel.GO23)
          print(f"The measured source current of PMOS is {Is p} A")
          Id p = p.read current(pyplane.AdcChannel.GO21 N)
          print(f"The measured drain current of PMOS is {Id p} A")
         The measured source current of PMOS is 9.992675768444315e-05 A
         The measured drain current of PMOS is 8.544922138753464e-07 A
```

5 Ohmic region

In this experiment you will characterize the *linear* dependence of the current on the gate voltage in the strong-inversion ohmic region.

5.1 N-FET

```
In [18]:
# uses schemdraw, you may have to install it in order to run it on your PC
import schemdraw
import schemdraw.elements as elm
d = schemdraw.Drawing()
Q = d.add(elm.NFet, reverse=True)
d.add(elm.Dot, xy=Q.gate, lftlabel='gate=AINO')
d.add(elm.Dot, xy=Q.drain, toplabel='drain=G022')
d.add(elm.Dot, xy=Q.source, botlabel='source=G020')
d.draw()
```

Out[18]:

```
gate=AIN0 - source=GO20
```

- (a) Configure the chip following Section 4.2 if you haven't
- **(b)** Measure I_{ds} as a function of V_q in ohmic region

What will be the fixed value for source and drain voltages?

Answer:

```
In [148... # set source voltage
    Vs = 0.0
    p.set_voltage(pyplane.DacChannel.Go20 , Vs)

Out[148... 0.0

In [152... # set drain voltage
    Vd = 0.2
    p.set_voltage(pyplane.DacChannel.Go22 , Vd)

Out[152... 0.19882699847221375
```

• For very close voltages, you may want to call get_set_voltage to check the actual output of the

```
DAC.
```

```
In [128... # get set voltage
    Vs_n = p.get_set_voltage(pyplane.DacChannel.GO20)
    print("The source voltage is set to {} V".format(Vs_n))

# get set voltage
    Vd_n = p.get_set_voltage(pyplane.DacChannel.GO22)
    print("The drain voltage is set to {} V".format(Vd_n))
The source voltage is set to 0.49970680475234985 V
The drain voltage is set to 1.7982406616210938 V
```

• Data aquisition


```
In [153...
```

```
# sweep gate voltage
import time
import numpy as np
# Get the leakage current, Read Ids=Ids0 at Vg = 0
p.set voltage(pyplane.DacChannel.AINO, 0.0)
time.sleep(0.5) # wait 0.5 second for it to settle
Is0 n = p.read current(pyplane.AdcChannel.GO20 N)
print(f"Offset IsO n: {IsO n} A")
Vgs = np.arange(0.0, 1.8, 0.1)
Ids = []
for Vg in Vgs:
    # set gate voltage
    p.set voltage(pyplane.DacChannel.AINO, Vg)
    print(f"The gate voltage is set to {Vg:.2f} V") ## print the gate voltage
    time.sleep(0.05) # wait for it to settle
    # read I {ds}
    Id = p.read current(pyplane.AdcChannel.GO20 N)
    print(f"The measured source current is {Id} A") ## print the raw data
    # substract leakage current
    Id -= Is0 n
    print(f"The leakage corrected Ids is {Id}")
    Ids.append(Id)
```

```
Offset IsO n: 1.367187451251084e-06 A
The gate voltage is set to 0.00 V
The measured source current is 1.6601562720097718e-06 A
The leakage corrected Ids is 2.929688207586878e-07
The gate voltage is set to 0.10 V
The measured source current is 7.080078034960025e-07 A
The leakage corrected Ids is -6.591796477550815e-07
The gate voltage is set to 0.20 V
The measured source current is 4.1503906800244295e-07 A
The leakage corrected Ids is -9.52148383248641e-07
The gate voltage is set to 0.30 V
The measured source current is 8.78906234902388e-07 A
The leakage corrected Ids is -4.88281216348696e-07
The gate voltage is set to 0.40 V
The measured source current is 2.19726558725597e-07 A
The leakage corrected Ids is -1.147460892525487e-06
```

```
The measured source current is 3.41796862812771e-07 A
         The leakage corrected Ids is -1.025390588438313e-06
         The gate voltage is set to 0.60 \rm V
         The measured source current is 7.568359592369234e-07 A
         The leakage corrected Ids is -6.103514920141606e-07
         The gate voltage is set to 0.70 V
         The measured source current is 6.83593725625542e-07 A
         The leakage corrected Ids is -6.83593725625542e-07
         The gate voltage is set to 0.80 V
         The measured source current is 5.102539034851361e-06 A
         The leakage corrected Ids is 3.735351583600277e-06
         The gate voltage is set to 0.90 V
         The measured source current is 7.69042981119128e-06 A
         The leakage corrected Ids is 6.3232423599401955e-06
         The gate voltage is set to 1.00 V
         The measured source current is 1.3720703464059625e-05 A
         The leakage corrected Ids is 1.235351601280854e-05
         The gate voltage is set to 1.10 V
         The measured source current is 1.7797850887291133e-05 A
         The leakage corrected Ids is 1.643066343604005e-05
         The gate voltage is set to 1.20 V
         The measured source current is 2.2045898731448688e-05 A
         The leakage corrected Ids is 2.0678711280197604e-05
         The gate voltage is set to 1.30 V
         The measured source current is 2.4243163352366537e-05 A
         The leakage corrected Ids is 2.2875975901115453e-05
         The gate voltage is set to 1.40 V
         The measured source current is 2.8271484552533366e-05 A
         The leakage corrected Ids is 2.6904297101282282e-05
         The gate voltage is set to 1.50 V
         The measured source current is 3.059082155232318e-05 A
         The leakage corrected Ids is 2.9223634101072093e-05
         The gate voltage is set to 1.60 V
         The measured source current is 3.427734554861672e-05 A
         The leakage corrected Ids is 3.291015809736564e-05
         The gate voltage is set to 1.70\ \mathrm{V}
         The measured source current is 3.527832086547278e-05 A
         The leakage corrected Ids is 3.3911133414221695e-05
In [154...
          # plot
          from matplotlib import pyplot as plt
          plt.plot(Vgs, Ids, label="$I {ds}$")
          plt.legend()
          plt.ylabel("$I {ds}[A]$")
          plt.xlabel("$V {g}[V]$")
          plt.show()
```

The gate voltage is set to 0.50 V



```
In [155...
            if the data looks nice, save it!
           # example :
          Lab2 data nFETVgIds = [Vgs,Ids]
           # save to csv file
          np.savetxt('./data/Lab2 data nFETVgIds.csv', Lab2 data nFETVgIds, delimiter=',')
In [149...
          Vgs, Ids = np.loadtxt('./data/Lab2 data nFETVgIds.csv', delimiter=',')
In [150...
           # extract the valid range
          v t0 = next(Vg for Vg, Id in zip(Vgs, Ids) if Id > 1e-6)
          print(f"Threshold value is at Vg = {v t0}")
          ohmic start index = Vgs.tolist().index(v t0)
          Threshold value is at Vg = 0.8
In [151...
           # fit in the valid range (you may want to go back and add the fitted line in the plot)
          plt.plot(Vgs[ohmic start index:], Ids[ohmic start index:], label="$I {ds}$")
          plt.legend()
          plt.ylabel("$I {ds}[A]$")
          plt.xlabel("$V {g}[V]$")
          plt.show()
             3.5
             3.0
             2.5
          (<sub>15</sub>[A]
            2.0
            1.5
            1.0
             0.5
```

(c) Determine V_{T0} and β for both devices by fitting your data to the expression derived in the prelab

1.6

1.4

1.2

 $V_o[V]$

0.8

1.0

```
print(f"v_t0: {v_t0}")

v_t0: 0.8

In [153... # beta => m/Vd
    delta_Ids = Ids[-1] - Ids[ohmic_start_index]
    delta_Vgs = Vgs[-1] - Vgs[ohmic_start_index]
    m = delta_Ids / delta_Vgs
    Vd = 1.8
    Vs = 0.5
    Vds = Vd - Vs
    beta_n = m/Vds

print(f"Beta: {beta_n}")
```

Beta: 2.5791266521898644e-05


v t0 = Vgs[ohmic start index]

V TO

In [152...

```
For triode: I_{ds}=eta(V_g-V_s-V_{Tn})(V_d-V_s)
For saturation: I_{ds}=rac{1}{2}eta(V_g-V_s-V_{Tn})^2
```

```
In [156...
    plt.plot(Vgs[ohmic_start_index:], Ids[ohmic_start_index:], label="real $I_{ds}$")
    Vs = 0.5
    Ids_approx = m*(Vgs[ohmic_start_index:] - Vs - v_t0) + Ids[ohmic_start_index + 4]
    plt.plot(Vgs[ohmic_start_index:], Ids_approx, label="approximate $I_{ds}$")
    plt.legend()
    plt.ylabel("$I_{ds}[A]$")
    plt.xlabel("$V_{g}[V]$")
    plt.show()
```



5.2 P-FET

- (a) Configure the chip following Section 4.3 if you haven't
- (b) Measure I_{ds} as a function of V_{g} in ohmic region
 - What will be the fixed value for bulk, source and drain voltages?

```
In [6]:
    # uses schemdraw, you may have to install it in order to run it on your PC
    import schemdraw
    import schemdraw.elements as elm
```

```
d = schemdraw.Drawing()
Q = d.add(elm.PFet, reverse=True, bulk=True)
d.add(elm.Dot, xy=Q.gate, lftlabel='gate=AINO')
d.add(elm.Dot, xy=Q.bulk, rgtlabel='bulk=AIN1')
d.add(elm.Dot, xy=Q.drain, botlabel='drain=GO21')
d.add(elm.Dot, xy=Q.source, toplabel='source=GO23')
d.draw()
```

Out[6]:

In [7]:

```
gate=AIN0 drain=GO21
```

p.reset(pyplane.ResetType.Soft)

Send a reset signal to the board, check if the LED blinks

```
<TeensyStatus.Success: 0>
 Out[7]:
 In [8]:
          # Configure PMOS, set the demultiplexer
          events = [pyplane.Coach.generate aerc event( \
              pyplane.Coach.CurrentOutputSelect.SelectLine5, \
              pyplane.Coach.VoltageOutputSelect.NoneSelected, \
              pyplane.Coach.VoltageInputSelect.SelectLine1, \
              pyplane.Coach.SynapseSelect.NoneSelected, 0)]
          p.send coach events (events)
In [38]:
          # set bulk voltage
          p.set voltage(pyplane.DacChannel.AIN1, 1.8)
          time.sleep(0.05) # wait for it to settle
          # set source voltage
          p.set voltage(pyplane.DacChannel.GO23, 1.8)
          # set drain voltage
          vd = p.set voltage(pyplane.DacChannel.GO21, 0.8)
          # Print I ds for checking
          Ids = p.read current(pyplane.AdcChannel.GO21 N)
          print(f"Ids: {Ids}")
```

• For very close voltages, you may want to call get_set_voltage to check the actual output of the DAC.

```
In [37]: | # get set voltage
          Vs n = p.get set voltage(pyplane.DacChannel.GO23)
          print("The source voltage is set to {} V".format(Vs n))
          # get set voltage
          Vd n = p.get set voltage(pyplane.DacChannel.GO21)
          print("The drain voltage is set to {} V".format(Vd n))
         NameError
                                                    Traceback (most recent call last)
         <ipython-input-37-ca4dc64ea83c> in <module>
               1 # get set voltage
         ---> 2 Vs n = p.qet set voltage(pyplane.DacChannel.GO23)
               3 print("The source voltage is set to {} V".format(Vs n))
               5 # get set voltage
         NameError: name 'p' is not defined

    Data aguisition

In [45]:
          # sweep gate voltage
          # sweep gate voltage
          import time
          import numpy as np
          # Get the leakage current, Read Ids=Ids0 at Vg = 0
          p.set voltage(pyplane.DacChannel.AINO, 0.0)
          time.sleep(0.5) # wait 0.5 second for it to settle
          Is0 n = p.read current(pyplane.AdcChannel.GO21 N)
          print(f"Offset IsO n: {IsO n} A")
          Vgs = np.arange(0.0, 1.8, 0.1)
          Ids = []
          for Vg in Vgs:
              # set gate voltage
              p.set voltage(pyplane.DacChannel.AINO, Vg)
```

```
print(f"The gate voltage is set to {Vg:.2f} V") ## print the gate voltage
    time.sleep(0.05) # wait for it to settle
    # read I {ds}
    Id = p.read current(pyplane.AdcChannel.GO21 N)
    print(f"The measured source current is {Id} A") ## print the raw data
    # substract leakage current
    Id -= Is0 n
    print(f"The leakage corrected Ids is {Id}")
    Ids.append(Id)
Offset IsO n: 2.6977539164363407e-05 A
The gate voltage is set to 0.00 V
The measured source current is 2.8588867280632257e-05 A
The leakage corrected Ids is 1.6113281162688509e-06
The gate voltage is set to 0.10 V
The measured source current is 2.5219726012437604e-05 A
The leakage corrected Ids is -1.7578131519258022e-06
```

The gate voltage is set to 0.20 V

The gate voltage is set to $0.30\ V$


The measured source current is 2.2167969291331246e-05 A The leakage corrected Ids is -4.80956987303216e-06

The measured source current is 1.4868163816572633e-05 A

```
The gate voltage is set to 0.40 V
The measured source current is 1.540527409815695e-05 A
The leakage corrected Ids is -1.1572265066206455e-05
The gate voltage is set to 0.50 V
The measured source current is 1.220703143189894e-05 A
The leakage corrected Ids is -1.4770507732464466e-05
The gate voltage is set to 0.60 V
The measured source current is 8.15429666545242e-06 A
The leakage corrected Ids is -1.8823242498910986e-05
The gate voltage is set to 0.70 V
The measured source current is 6.665039109066129e-06 A
The leakage corrected Ids is -2.0312500055297278e-05
The gate voltage is set to 0.80 V
The measured source current is 4.638671725842869e-06 A
The leakage corrected Ids is -2.2338867438520538e-05
The gate voltage is set to 0.90 V
The measured source current is 2.050781176876626e-06 A
The leakage corrected Ids is -2.492675798748678e-05
The gate voltage is set to 1.00 V
The measured source current is 2.6855468604480848e-06 A
The leakage corrected Ids is -2.4291992303915322e-05
The gate voltage is set to 1.10 V
The measured source current is 3.8818361645098776e-06 A
The leakage corrected Ids is -2.309570299985353e-05
The gate voltage is set to 1.20 \rm V
The measured source current is 3.5400389606365934e-06 A
The leakage corrected Ids is -2.3437500203726813e-05
The gate voltage is set to 1.30 V
The measured source current is 3.344726565046585e-06 A
The leakage corrected Ids is -2.363281259931682e-05
The gate voltage is set to 1.40 V
The measured source current is 4.1259763747802936e-06 A
The leakage corrected Ids is -2.2851562789583113e-05
The gate voltage is set to 1.50 V
The measured source current is 5.859375050931703e-06 A
The leakage corrected Ids is -2.1118164113431703e-05
The gate voltage is set to 1.60 V
The measured source current is 6.127929736976512e-06 A
The leakage corrected Ids is -2.0849609427386895e-05
The gate voltage is set to 1.70 V
The measured source current is 2.6855468604480848e-06 A
The leakage corrected Ids is -2.4291992303915322e-05
 # plot
from matplotlib import pyplot as plt
plt.plot(Vgs, Ids, label="$I {ds}$")
plt.legend()
plt.ylabel("$I {ds}[A]$")
plt.xlabel("$V {g}[V]$")
plt.show()
```

The leakage corrected Ids is -1.2109375347790774e-05


In [46]:



```
In [266...
# extract the valid range
v_t0 = next(Vg for Vg, Id in zip(Vgs, Ids) if Id < -2.3e-5)
print(f"Threshold value is at Vg = {v_t0}")
ohmic_end_index = Vgs.tolist().index(v_t0)</pre>
```

Threshold value is at Vg = 0.9

```
In [267...
# fit in the valid range (you may want to go back and add the fitted line in the plot)
plt.plot(Vgs[:ohmic_end_index], Ids[:ohmic_end_index], label="$I_{ds}$")
plt.legend()
plt.ylabel("$I_{ds}[A]$")
plt.xlabel("$V_{g}[V]$")
plt.show()
```




(c) Determine V_{T0} and β for both devices by fitting your data to the expression derived in the prelab

```
In [268...
          # V TO
          v t0 = Vgs[ohmic end index]
          print(f"v t0: {v t0}")
         v t0: 0.9
In [269...
          # beta => m/Vd
          delta Ids = Ids[ohmic end index] - Ids[0]
          delta Vgs = Vgs[ohmic end index] - Vgs[0]
          m = delta Ids / delta Vgs
          Vs = 1.8
          Vd = 0.8
          Vds = Vd - Vs
          beta p = m / Vds
          print(f"Beta: {beta p}")
         Beta: 2.9486762337506258e-05
```

For triode: $I_{ds} = eta(V_q - V_s - V_{Tp})(V_d - V_s)$

For saturation: $I_{ds}=rac{1}{2}eta(V_g-V_s-V_{Tp})^2$

```
In [274...
plt.plot(Vgs[:ohmic_end_index], Ids[:ohmic_end_index], label="real $I_{ds}$")
# + v_t0 since v_t0 > 0
Ids_approx = m*(Vgs[:ohmic_end_index] - Vs + v_t0) - abs(Ids[ohmic_end_index])
plt.plot(Vgs[:ohmic_end_index], Ids_approx, label="approximate $I_{ds}$")
plt.legend()
plt.ylabel("$I_{ds}[A]$")
plt.xlabel("$V_{g}[V]$")
plt.show()
```




5.3 Comparisons

Include a single plot showing the curves for both devices.

```
In [134...
# plot both Ids vs | Vgs|
Vgs, Ids_n = np.loadtxt('./data/Lab2_data_nFETVgIds.csv', delimiter=',')
_, Ids_p = np.loadtxt('./data/Lab2_data_pFETVgIds.csv', delimiter=',')
plt.plot(Vgs, Ids_n, label="nFET")
```

```
plt.plot(Vgs, Ids_p, label="pFET")
plt.xlabel = "$V_{gs}$"
plt.ylabel = "$I_{ds}$"
plt.vlines(0.85, min(Ids_p), max(Ids_n), linestyles='dashed', colors="g", label="Averaged plt.legend()
plt.show()
```



• What is the ratio between β for the 2 devices? Does it make sense?

```
In [188...
    ratio = beta_n / beta_p
    print(f"Beta_n: {beta_n}")
    print(f"Beta_p: {beta_p}")
    print(f"Ratio: {ratio}")
```

Beta_n: 2.5791266521898644e-05 Beta_p: 2.9486762337506258e-05 Ratio: 0.8746727167496766

Ideally, the ratio should be 1. It is not however, since our pFET measurements suffered from multiple hardware defects, according to our TA.

ullet Is the relationship between I_{ds} and $V_{gs}-V_T$ really linear? What is likely the cause of any discrepancy?

It seems to form a slight parabola. I guess this happens because we are getting close to the maximum current that can flow to the channel. At some point, the gate is bound to have diminishing returns.

5.4 Effective surface mobility (optional)

Hint: Use the V_{T0} you obtained in the last experiments but assume β changes with V_{gs} (thus μ_n and μ_p changes). No need to measure again.

```
In []: # plot mu vs Vgs for both devices in the same figure
```

- Why does the mobility peak and then decay instead of remaining constant?
- What is the ratio between the peak mobilities for electrons and holes?

• How different are these values from the bulk mobilities for electrons (1350 ${
m cm^2/V/s}$) and holes (480 ${
m cm^2/V/s}$)?

6 Drain Current in the saturation region

In this experiment you will characterize the *quadratic* dependence of the current on the gate voltage in the saturation region.

6.1 N-FET

- (a) Configure the chip following Section 4.2 if you haven't
- **(b)** Measure I_{ds} as a function of V_q in saturation region
 - What will be the fixed value for source and drain voltages?

```
In [21]:
          ## configure NMOS
          # set the demultiplexer, NMOS
          events = [pyplane.Coach.generate aerc event( \
              pyplane.Coach.CurrentOutputSelect.SelectLine5, \
              pyplane.Coach.VoltageOutputSelect.NoneSelected, \
              pyplane.Coach.VoltageInputSelect.SelectLine2, \
              pyplane.Coach.SynapseSelect.NoneSelected, 0)]
          p.send coach events(events)
In [22]:
          # set source voltage
          p.set voltage(pyplane.DacChannel.GO20, 0.0)
Out[22]:
In [23]:
          # set drain voltage
                                 ######1.8
          p.set voltage(pyplane.DacChannel.GO22, 1.8)
         1.7982406616210938
Out[23]:
```

Data aquisition

```
print(f"The gate voltage is set to {Vg:.2f} V") ## print the gate voltage

time.sleep(0.05) # wait for it to settle
# read I_{ds}
Id = p.read_current(pyplane.AdcChannel.GO20_N)

print(f"The measured source current is {Id} A") ## print the raw data

# substract leakage current
Id -= IsO_n
print(f"The leakage corrected Ids is {Id}")
Ids.append(Id)
```


```
Offset IsO n: 2.4414063659605745e-07 A
The gate voltage is set to 0.00 V
The measured source current is 7.568359592369234e-07 A
The leakage corrected Ids is 5.126953226408659e-07
The gate voltage is set to 0.10 V
The measured source current is 1.4892577837599674e-06 A
The leakage corrected Ids is 1.24511714716391e-06
The gate voltage is set to 0.20 V
The measured source current is 4.6386719532165444e-07 A
The leakage corrected Ids is 2.19726558725597e-07
The gate voltage is set to 0.30 V
The measured source current is 1.8310546465727384e-06 A
The leakage corrected Ids is 1.586914009976681e-06
The gate voltage is set to 0.40 V
The measured source current is 2.5390625069121597e-06 A
The leakage corrected Ids is 2.2949218703161023e-06
The gate voltage is set to 0.50 V
The measured source current is 1.56249996052793e-06 A
The leakage corrected Ids is 1.3183593239318725e-06
The gate voltage is set to 0.60 V
The measured source current is 3.344726565046585e-06 A
The leakage corrected Ids is 3.1005859284505277e-06
The gate voltage is set to 0.70 V
The measured source current is 1.3916015859649633e-06 A
The leakage corrected Ids is 1.1474609493689059e-06
The gate voltage is set to 0.80 V
The measured source current is 6.6162110670120455e-06 A
The leakage corrected Ids is 6.372070430415988e-06
The gate voltage is set to 0.90 V
The measured source current is 1.0498047231521923e-05 A
The leakage corrected Ids is 1.0253906594925866e-05
The gate voltage is set to 1.00 V
The measured source current is 1.799316487449687e-05 A
The leakage corrected Ids is 1.7749024237900812e-05
The gate voltage is set to 1.10 V
The measured source current is 2.426757782814093e-05 A
The leakage corrected Ids is 2.4023437191544872e-05
The gate voltage is set to 1.20 V
The measured source current is 3.752441261895001e-05 A
The leakage corrected Ids is 3.728027198235395e-05
The gate voltage is set to 1.30 V
The measured source current is 4.9194335588254035e-05 A
The leakage corrected Ids is 4.895019495165798e-05
The gate voltage is set to 1.40 V
The measured source current is 6.0913087509106845e-05 A
The leakage corrected Ids is 6.066894687251079e-05
The gate voltage is set to 1.50 V
The measured source current is 7.68554673413746e-05 A
The leakage corrected Ids is 7.661132670477855e-05
The gate voltage is set to 1.60 V
The measured source current is 9.09912123461254e-05 A
```

```
The gate voltage is set to 1.70 V
         The measured source current is 9.912109089782462e-05 A
         The leakage corrected Ids is 9.887695026122856e-05
In [25]:
           # plot
          from matplotlib import pyplot as plt
          plt.plot(Vgs, Ids, label="$I {ds}$")
          plt.legend()
          plt.ylabel("$I {ds}[A]$")
          plt.xlabel("$V {g}[V]$")
          plt.show()
            0.00010
                        las
            0.00008
            0.00006
          lds[A]
            0.00004
            0.00002
            0.00000
                         0.25
                                      0.75
                   0.00
                                0.50
                                            1.00
                                                  1.25
                                                        1.50
                                                              1.75
                                        V_o[V]
In [99]:
           # if the data looks nice, save it!
           # example :
          Lab2 data nFETVgIds = [Vgs,Ids]
           # save to csv file
          np.savetxt('./data/Lab2 data nFETVgIds saturated.csv', Lab2 data nFETVgIds, delimiter=','
In [231...
          Vgs, Ids = np.loadtxt('./data/Lab2 data nFETVgIds saturated.csv', delimiter=',')
In [232...
           # extract the valid range and plot sqrt(Ids) vs Vgs
          v t0 = next(Vg for Vg, Id in zip(Vgs, Ids) if Id > 1e-5)
          print(f"Threshold value is at Vg = {v t0}")
          sat start index = Vgs.tolist().index(v t0)
         Threshold value is at Vg = 0.9
In [233...
           # fit in the valid range (you may want to go back and add the fitted line in the plot)
          plt.plot(Vgs[sat start index:], Ids[sat start index:], label="$I {ds}$")
          plt.legend()
          plt.ylabel("$I {ds}[A]$")
```

The leakage corrected Ids is 9.074707170952934e-05

plt.xlabel("\$V {g}[V]\$")

plt.show()



(c) Determine V_{T0} and β for both devices by fitting your data to the expression derived in the prelab

```
In [234... # V_T0
v_t0 = Vgs[sat_start_index]
print(f"v_t0: \{v_t0\}")

v_t0: 0.9

For triode: I_{ds} = \beta(V_g - V_s - V_{Tn})(V_d - V_s)
For saturation: I_{ds} = \frac{1}{2}\beta(V_g - V_s - V_{Tn})^2

I_{dsat} = \frac{1}{2}\beta(V_g - V_s - V_{T0})^2
```

```
I_{dsat} = \frac{1}{2} \beta (V_g - V_s - V_{T0})^2

\Rightarrow \sqrt{I_{dsat}} = \frac{1}{\sqrt{2}} \sqrt{\beta} (V_g - V_s - V_{T0})

m := \text{slope of } \sqrt{I_{dsat}} (V_g) = \frac{1}{\sqrt{2}} \sqrt{\beta}


\Rightarrow \beta = 2m^2
```

```
In [246...
# beta
delta_Ids = np.sqrt(Ids[-1]) - np.sqrt(Ids[sat_start_index])
delta_Vgs = Vgs[-1] - Vgs[sat_start_index]
m = delta_Ids / delta_Vgs
beta_n_sat = 2*m**2
print(f"Beta: {beta_n_sat}")
```

Beta: 0.00014202515231445965

```
In [254...
plt.plot(Vgs[sat_start_index:], Ids[sat_start_index:], label="real $I_{ds}$")
Ids_approx = 0.5*beta_n_sat*(Vgs[sat_start_index:] - v_t0)**2 + Ids[sat_start_index]
plt.plot(Vgs[sat_start_index:], Ids_approx, label="approximate $I_{ds}$")

plt.legend()
plt.ylabel("$I_{ds}[A]$")
plt.xlabel("$V_{g}[V]$")
plt.show()
```



6.2 P-FET

- (a) Configure the chip following Section 4.3 if you haven't
- (b) Measure I_{ds} as a function of V_q in ohmic region
 - What will be the fixed value for bulk, source and drain voltages?

```
In [27]:
          # Send a reset signal to the board, check if the LED blinks
          p.reset(pyplane.ResetType.Soft)
         <TeensyStatus.Success: 0>
Out[27]:
In [28]:
          # Configure PMOS, set the demultiplexer
          events = [pyplane.Coach.generate aerc event( \
              pyplane.Coach.CurrentOutputSelect.SelectLine5, \
              pyplane.Coach.VoltageOutputSelect.NoneSelected, \
              pyplane.Coach.VoltageInputSelect.SelectLine1, \
              pyplane.Coach.SynapseSelect.NoneSelected, 0)]
          p.send coach events (events)
In [29]:
          # set bulk voltage
          p.set voltage(pyplane.DacChannel.AIN1, 1.8)
          time.sleep(0.05)
                             # wait for it to settle
          # set source voltage
          p.set voltage(pyplane.DacChannel.G023, 1.8)
          # set drain voltage
          p.set voltage(pyplane.DacChannel.GO21, 0.0)
          # Print I ds for checking
          Ids = p.read current(pyplane.AdcChannel.GO21 N)
          print(f"Ids: {Ids}")
```

Ids: 2.8686523364740424e-05

 For very close voltages, you may want to call get_set_voltage to check the actual output of the DAC.

```
In [30]: # get set voltage
    Vs_n = p.get_set_voltage(pyplane.DacChannel.GO23)
    print("The source voltage is set to {} V".format(Vs_n))

# get set voltage
    Vd_n = p.get_set_voltage(pyplane.DacChannel.GO21)
    print("The drain voltage is set to {} V".format(Vd_n))
```

The source voltage is set to 1.7982406616210938 V The drain voltage is set to 0.0 V $\,$


Data aguisition

```
In [31]:
          # sweep gate voltage
          import time
          import numpy as np
          # Get the leakage current, Read Ids=Ids0 at Vg = 0
          p.set voltage(pyplane.DacChannel.AINO, 0.0)
          time.sleep(0.5) # wait 0.5 second for it to settle
          Is0 n = p.read current(pyplane.AdcChannel.GO21 N)
          print(f"Offset Is0 n: {Is0 n} A")
          Vgs = np.arange(0.0, 1.8, 0.1)
          Ids = []
          for Vg in Vgs:
              # set gate voltage
              p.set voltage(pyplane.DacChannel.AINO, Vg)
              print(f"The gate voltage is set to {Vg:.2f} V") ## print the gate voltage
              time.sleep(0.05) # wait for it to settle
              # read I {ds}
              Id = p.read current(pyplane.AdcChannel.GO21 N)
              print(f"The measured source current is {Id} A") ## print the raw data
              # substract leakage current
              Id -= Is0 n
              print(f"The leakage corrected Ids is {Id}")
              Ids.append(Id)
```

```
Offset IsO n: 2.9443359380820766e-05 A
The gate voltage is set to 0.00\ \mathrm{V}
The measured source current is 2.922363273683004e-05 A
The leakage corrected Ids is -2.1972664399072528e-07
The gate voltage is set to 0.10 V
The measured source current is 2.4047851184150204e-05 A
The leakage corrected Ids is -5.395508196670562e-06
The gate voltage is set to 0.20 V
The measured source current is 2.2167969291331246e-05 A
The leakage corrected Ids is -7.27539008948952e-06
The gate voltage is set to 0.30 V
The measured source current is 1.6674805010552518e-05 A
The leakage corrected Ids is -1.2768554370268248e-05
The gate voltage is set to 0.40 V
The measured source current is 1.5039062418509275e-05 A
The leakage corrected Ids is -1.4404296962311491e-05
The gate voltage is set to 0.50 V
The measured source current is 1.1987304787908215e-05 A
The leakage corrected Ids is -1.745605459291255e-05
The gate voltage is set to 0.60 V
The measured source current is 8.813476597424597e-06 A
```

```
The leakage corrected Ids is -2.062988278339617e-05
The gate voltage is set to 0.70 V
The measured source current is 6.713867151120212e-06 A
The leakage corrected Ids is -2.2729492229700554e-05
The gate voltage is set to 0.80 V
The measured source current is 5.419921762950253e-06 A
The leakage corrected Ids is -2.4023437617870513e-05
The gate voltage is set to 0.90 V
The measured source current is 3.1738281336401997e-07 A
The leakage corrected Ids is -2.9125976567456746e-05
The gate voltage is set to 1.00 V
The measured source current is 1.416015606992005e-06 A
The leakage corrected Ids is -2.802734377382876e-05
The gate voltage is set to 1.10 V
The measured source current is 2.075195425277343e-06 A
The leakage corrected Ids is -2.7368163955543423e-05
The gate voltage is set to 1.20 V
The measured source current is 8.78906234902388e-07 A
The leakage corrected Ids is -2.8564453145918378e-05
The gate voltage is set to 1.30 V
The measured source current is 9.521484116703505e-07 A
The leakage corrected Ids is -2.8491210969150416e-05
The gate voltage is set to 1.40 V
The measured source current is 2.2460937998403097e-06 A
The leakage corrected Ids is -2.7197265580980456e-05
The gate voltage is set to 1.50 V
The measured source current is 1.3916015859649633e-06 A
The leakage corrected Ids is -2.8051757794855803e-05
The gate voltage is set to 1.60 \rm V
The measured source current is 1.3427734302240424e-06 A
The leakage corrected Ids is -2.8100585950596724e-05
The gate voltage is set to 1.70 V
The measured source current is 6.347656267280399e-07 A
The leakage corrected Ids is -2.8808593754092726e-05
```

In [33]: # plot from matplotlib import pyplot as plt plt.plot(Vgs, Ids, label="\$I_{ds}\$") plt.legend() plt.ylabel("\$I_{ds}[A]\$") plt.xlabel("\$V_{g}[V]\$") plt.show()



```
In [35]:  # if the data looks nice, save it!
    # example :
```

```
Lab2_data_pFETVgIds = [Vgs,Ids]
# save to csv file
np.savetxt('./data/Lab2_data_pFETVgIds_saturated.csv', Lab2_data_pFETVgIds, delimiter=',')
```


• Data aquisition

```
import numpy as np
import matplotlib.pyplot as plt
Vgs, Ids = np.loadtxt('./data/Lab2_data_pFETVgIds_saturated.csv', delimiter=',')
In [258...
```

In [258...
extract the valid range and plot sqrt(Ids) vs Vgs
v_t0 = next(Vg for Vg, Id in zip(Vgs, Ids) if Id < -2.3e-5)
print(f"Threshold value is at Vg = {v_t0}")
ohmic_end_index = Vgs.tolist().index(v_t0)</pre>

Threshold value is at Vg = 0.8

```
In [259...
# fit in the valid range (you may want to go back and add the fitted line in the plot)
plt.plot(Vgs[:ohmic_end_index], Ids[:ohmic_end_index], label="$I_{ds}$")
plt.legend()
plt.ylabel("$I_{ds}[A]$")
plt.xlabel("$V_{g}[V]$")
plt.show()
```



(c) Determine V_{T0} and β for both devices by fitting your data to the expression derived in the prelab

```
In [260...
# V_T0
v_t0 = Vgs[ohmic_end_index]
print(f"v_t0: {v_t0}")
```

v_t0: 0.8

For triode: $I_{ds}=eta(V_g-V_s-V_{Tn})(V_d-V_s)$ For saturation: $I_{ds}=rac{1}{2}eta(V_g-V_s-V_{Tn})^2$

$$I_{ds} = \frac{1}{2}\beta(V_g - V_s - V_{T0})^2 \ \Rightarrow \sqrt{I_{dsat}} = \frac{1}{\sqrt{2}}\sqrt{\beta}(V_g - V_s - V_{T0})$$


```
m:=	ext{slope of }\sqrt{	ext{I}_{	ext{dsat}}}(	ext{V}_{	ext{g}})=rac{1}{\sqrt{2}}\sqrt{eta} \ \Rightarrow eta=2m^2
```

```
In [261...
# beta
delta_Ids = np.sqrt(abs(Ids[ohmic_end_index])) - np.sqrt(abs(Ids[0]))
delta_Vgs = Vgs[ohmic_end_index] - Vgs[0]
m = delta_Ids / delta_Vgs
beta_p_sat = 2*m**2
print(f"Beta: {beta_p_sat}")
```

Beta: 6.140040032243991e-05

```
In [264...
plt.plot(Vgs[:ohmic_end_index], Ids[:ohmic_end_index], label="real $I_{ds}$")
Vs = 1.8
# + v_t0 since v_t0 > 0
Ids_approx = abs(0.5*beta_p_sat*(Vgs[:ohmic_end_index] - Vs + v_t0)**2) - abs(Ids[ohmic_end_index], Ids_approx, label="approximate $I_{ds}$")

plt.legend()
plt.ylabel("$I_{ds}[A]$")
plt.xlabel("$V_{g}[V]$")
plt.show()
```



6.3 Comparisons

- Are the measurements of V_{T0} and β from the saturation measurement consistent with the values obtained in the ohmic region?
 - V_{T0} is more or less the same, but eta varies greatly
- Which is a better approximation, the linear one or the quadratic?

The linear line fits better. This is probably so since the quadratic approximation squares any inaccuracies. In fact, when I testwise plotted the root of the collected data and the root of the approximation, they matched quite well.

7 Early effect

This experiment studies how Early voltage scales with transistor current; in particular, how valid are the simple assumptions about channel length modulation?

You only need to do N-FET

(a) Measure I_{ds} vs V_{ds} for different V_{qs}

```
In [8]:
          # Send a reset signal to the board, check if the LED blinks
          p.reset(pyplane.ResetType.Soft)
         <TeensyStatus.Success: 0>
 Out[8]:
 In [9]:
          # Configure PMOS, set the demultiplexer
          events = [pyplane.Coach.generate aerc event( \
              pyplane.Coach.CurrentOutputSelect.SelectLine5, \
              pyplane.Coach.VoltageOutputSelect.NoneSelected, \
              pyplane.Coach.VoltageInputSelect.SelectLine2, \
              pyplane.Coach.SynapseSelect.NoneSelected, 0)]
          p.send coach events(events)
In [10]:
          # set source voltage
          p.set voltage(pyplane.DacChannel.GO20, 0.0)
Out[10]:
```

Data aquisition


```
In [18]:
          # sweep gate voltage
          import time
          import numpy as np
          # Get the leakage current, Read Ids=Ids0 at Vg = 0
          p.set voltage(pyplane.DacChannel.AINO, 0.0)
          time.sleep(0.5) # wait 0.5 second for it to settle
          Is0 n = p.read current(pyplane.AdcChannel.GO21 N)
          print(f"Offset Is0 n: {Is0 n} A")
          Vds = np.arange(0.0, 1.8, 0.1)
          Vgs = np.arange(0.8, 1.8, 0.2)
          Ids = \{\}
          for Vg in Vgs:
              Ids[Vg] = []
          for Vd in Vds:
              for Vq in Vqs:
                  p.set voltage(pyplane.DacChannel.G022, Vd)
                  # Get the leakage current, Read Ids=Ids0 at Vg = 0
                  p.set voltage(pyplane.DacChannel.AINO, 0.0)
                  time.sleep(0.5) # wait 0.5 second for it to settle
                  Is0 n = p.read current(pyplane.AdcChannel.GO21 N)
                  p.set voltage(pyplane.DacChannel.AINO, Vg)
                  time.sleep(0.05) # wait for it to settle
                  # read I {ds}
```

```
Id = p.read_current(pyplane.AdcChannel.GO20_N)

# substract leakage current
Id -= Is0_n
Ids[Vg].append(Id)
```

Offset IsO_n: 6.103515488575795e-07 A

Include a single plot showing all data on a semilogy plot.




```
In [25]: # if the data looks nice, save it!
# example :
for Vg, current_Ids in Ids.items():
    Lab2_data_nFETVgIds = [Vds,current_Ids]
    # save to csv file
    np.savetxt(f'./data/early/Lab2_data_nFETVgIds_{Vg:.2f}.csv', Lab2_data_nFETVgIds, del:
```

- ullet Can you see how the saturation voltage increases with the gate overdrive V_G-V_T in strong inversion?
 - Yes, each line plotted with a higher V_G but constant V_T is clearly higher on the graph.

(b) Compute the Early voltage

• Fit a line to the "flat" part of each curve. Select a range of drain voltages to fit the line and use the same range for each curve, because the Early effect is actually curved in reality, and what you are actually seeing is the start of Drain Induced Barrier Lowering (DIBL) or impact ionization.


```
In [406...
          Ids count = len(Vds)
          low index = int(Ids count * 0.8)
          high index = Ids count - 1
          ms = [(current Ids[high index] - current Ids[low index])/(Vds[high index] - Vds[low index]
          y 0s = [current Ids[low index] - m*Vds[low index] for m, current Ids in zip(ms, Ids.values
          x = np.arange(-80, 10, 0.01)
          curves = [x * m + y_0 \text{ for } m, y_0 \text{ in } zip(ms, y_0s)]
          colors = ["blue", "y", "g", "orangered", "purple"]
          V es = []
          for (Vg, curve), color in zip(zip(Vgs, curves), colors):
              V e = next (Vd for Vd, y in zip(x, curve) if y \geq= -1e-9)
              V es.append(-V e)
              plt.plot(x, curve, label=f"$V g={Vg:.2f}$", color=color)
              plt.plot(V e, 0, "x", color=color)
          plt.axhline(y=0, color='k', linewidth=0.5)
          plt.xlabel("$V {ds}[V]$")
          plt.ylabel("$I {ds}[A]$")
          plt.legend()
          plt.show()
```



• Plot the Early voltage vs drain current on a semilogx scale.

```
In [417...
x = np.arange(0, 100, 0.01)
Idsats = [current_Ids[-1] for current_Ids in Ids.values()]

plt.semilogx(Idsats, V_es, label="Early voltage")
plt.xlabel("$I_{dsat}[A]$")
plt.ylabel("$V_E[V]$")
plt.legend()
plt.show()
```



• Comment on your results: How constant is the Early voltage with drain current? Speculate on the reasons for your observations.

Not that constant, but it stays within a single order of magnitude. When the Early voltage goes down, it means that the saturation region is less flat, so the Early effect (or in this case DIBL) is increasing. So our highest Early effect is at about $27\mu\mathrm{A}$ in the graph above. There, the effective length of the channel is the smallest because we have the strongest reversebias. Then, it decreases again. So I postulate that an initial increase in V_{OD} , which leads to a higher I_{dsat} , causes the increasingly high shortening of the effective channel length until the V_{OD} is high enough that the depletion layer caused by the reverse-bias is no longer observable since the mobile carriers are in free flow.

8 Congratulations

If you did everything in this lab, you have done a lot! This is probably the most difficult but also one of the most important labs, because practical and intuitive knowledge of transistor characteristics is crucial in understanding and synthesizing new circuits.

9 What we expect

How transistors work above threshold.

What is the linear or triode region and what is the saturation region?

How does the linear region depend on gate and threshold voltage?

What is the overdrive?

What is the specific current?

How the Early effect comes about?

Typical values for Early voltage.

How to sketch graphs of transistor current vs gate voltage and drain-source voltage.

How above-threshold transistors go into saturation and why the saturation voltage is equal to the gate overdrive. Can you write the above-threshold current equations?

How does above-threshold current depend on W/L , C_{ox} , and mobility μ ?

How do transconductance and drain resistance combine to generate voltage gain? And what is the intrinsic voltage gain of a transistor?

What effect does velocity saturation have on transistor operation, specifically, how does it change the relation between saturation current and gate voltage? What is DIBL (drain induced barrier lowering) and II (impact ionization)?

What is the dominant source of mismatch?

How does transistor mismatch scale with transistor size?

What are typical values of transistor threshold voltage mismatch?