
ACK: Some of these slides are based on Stallings


COMPUTER SYSTEMS ORGANIZATION

Input/Output -- Spring 2011 -- IIIT-H -- Suresh Purini

The Big Picture: Where are we now?


Input and Output





System Bus Consists of:

- Address lines
- Data lines
- Control lines



Typical Control Lines:

Memory write

I/O read

Memory read


Transfer ACK


□ I/O write


Bus request

- Bus grant
- Interrupt request
- Interrupt ACK
- Clock

Basic Components of a Computer and their Interconnection









The 8085 Bus Structure


The 8-bit 8085 CPU (or MPU – Micro Processing Unit) communicates with the other units using a 16-bit address bus, an 8-bit data bus and a control bus.



8085 Functional Block Diagram



The 8085 Microprocessor




Input/Output Problems

- Wide variety of peripherals
 - Delivering different amounts of data
 - At different speeds
 - In different formats
- Could be slower/faster than CPU and/or RAM
- Need I/O modules (with their Device Drivers and the corresponding Operating System support)

Interface to CPU and Memory


I/O Device Interface • Interface to one or more peripherals




Interface to CPU and Memory

I/O Device Interface


Interface to one or more peripherals



Typical Signal Lines for I/O Modules (Device Controllers)





We need a device drive which knows how to interface with the Device Controller




I/O Module Functions

- Control & Timing
- CPU Communication
- Device Communication
- Data Buffering
- Error Detection







Floppy Disk Controller



		100 1	
Control Signal	Action by the device	Status Signal	Action by the device
Drive Select	FDD gets logically connected	Track 0	Read/write head is positioned over the track 0
Head Select	FDD selects either the top or bottom head	Write Protect	FDD is write protected
		Ready	FDD is ready for operation
Direction	Indicate the direction of head movement (inward or outward)	•••••	•••••
Step	Move one track		

Interacting with I/O Devices





Input Output Techniques

- Programmed I/O
- □ Interrupt driven
- Direct Memory Access (DMA)

I/O Steps

- □ CPU checks I/O module device status
- □ I/O module returns status
- □ If ready, CPU requests data transfer
- □ I/O module gets data from device
- □ I/O module transfers data to CPU
- Variations for output, DMA, etc.


Programmed I/O

- CPU has direct control over I/O
 - Sensing status
 - Read/write commands
 - Transferring data
- CPU waits for I/O module to complete operation
- Wastes CPU time

Programmed I/O - detail

- CPU requests I/O operation
- I/O module performs operation
- I/O module sets status bits
- CPU checks status bits periodically
- I/O module does not inform CPU directly
- I/O module does not interrupt CPU
- CPU may wait or come back later

Programmed I/O



Next Instruction

I/O Mapping

- Memory mapped I/O
 - Devices and memory share an address space
 - I/O looks just like memory read/write
 - No special commands for I/O
 - Large selection of memory access commands available
- Isolated I/O (I/O Mapped I/O)
 - Separate address spaces
 - Need I/O or memory select lines
 - Special commands for I/O
 - Limited set


Interrupt Driven I/O

- Overcomes CPU waiting
- □ No repeated CPU checking of device
- □ I/O module interrupts when ready

Interrupt Driven I/O Basic Operation

- CPU issues read command
- I/O module gets data from peripheral whilst CPU does other work
- I/O module interrupts CPU
- CPU requests data
- I/O module transfers data

Interrupt Driven I/O




Next Instruction

CPU Viewpoint

- Issue read command
- □ Do other work
- Check for interrupt at end of each instruction cycle
- □ If interrupted:-
 - Save context (registers)
 - Process interrupt
 - Fetch data & store

Interrupt

Processing



Design Issues

- How do you identify the module issuing the interrupt?
- How do you deal with multiple interrupts?
 - □ i.e. an interrupt handler being interrupted

Identifying Interrupting Module

- □ Different line for each module
 - PC
 - □ Limits number of devices
- Software poll
 - CPU asks each module in turn
 - Slow

Software Poll





Figure 3a. Polled Method

Identifying Interrupting Module

- Daisy Chain or Hardware poll
 - Interrupt Acknowledge sent down a chain
 - Module responsible places vector on bus
 - CPU uses vector to identify handler routine



- Bus Master
 - Module must claim the bus before it can raise interrupt

Interrupt Processing in x86




Figure 3b. Interrupt Method


Example

- 80x86 has one interrupt line
- 8086 based systems use one 8259A interrupt controller
- 8259A has 8 interrupt lines

Sequence of Events

- 8259A accepts interrupts
- 8259A determines priority
- 8259A signals 8086 (raises INTR line)
- CPU Acknowledges
- 8259A puts correct vector on data bus
- CPU processes interrupt

PC Interrupt Layout






Figure 4a. 8259A Block Diagram




Figure 5. 8259A Interface to Standard System Bus






Figure 7.9 Use of the 82C59A Interrupt Controller


Taxonomy of Interrupts in Pentium




Software Interrupts are Synchronous Events whereas Hardware Interrupts are Asynchronous Events.

Interacting with I/O Devices





Direct Memory Access



I/O Techniques Summary

	No Interrupts	Use of Interrupts
I/O-to-memory Transfer through Processor	Programmed I/O	Interrupt-driven I/O
Direct I/O-to-memory transfer		Direct Memory Access