COMPUTER SYSTEMS ORGANIZATION

Computer Arithmetic -- Spring 2010 -- IIIT-H -- Suresh Purini

Unsigned and Signed Integers

Signed or Unsigned Integers – Doesn't Matter! They still need to be represented as a sequence of bits.

- Consider sequences of w-bits. (Ex: 0101 is a 4-bit sequence)
- There are 2^w possible such sequences.
- It is up to us to interpret each of these sequences in the way we would like to.
- In other words we can associate decimal values to these n-bit strings according to our convenience.

Unsigned Integers

Unsigned Integer Interpretation for n-bit strings:

$$B2U_{w}: \{ 0, 1 \}^{w} \rightarrow \{ 0, ..., 2^{w} - 1 \}$$

$$B2U_w(\vec{x}) \quad \doteq \quad \sum_{i=0}^{w-1} x_i 2^i$$

Ex:
$$B2U_4(0101) = 5$$
, $B2U_4(1001) = 9$, ...

- $U_{w-max} = B2U_{w}(111..1) = 2^{w} 1$ (Max Integer Value)
- $U_{w-min} = B2U_{w}(000....0) = 0$ (Min Integer Value)

Signed Integers - Sign-Magnitude Representation

Sign-Magnitude Integer Interpretation for w-bit strings:

$$B2S_{w}: \{ 0, 1 \}^{w} \rightarrow \{ -2^{w-1}+1, ..., 0, ..., 2^{w-1}-1 \}$$

$$B2S_w(\vec{x}) \doteq (-1)^{x_{w-1}} \cdot \left(\sum_{i=0}^{w-2} x_i 2^i\right)$$

Ex:
$$B2S_4(0101) = 5$$
, $B2S_4(1001) = -1$, $(w-1)^{th}$ bit is the sign-bit. $B2S_4(0000) = 0$, $B2S_4(1000) = -0$

- $S_{w-max} = B2S_{w}(011..1) = 2^{w-1} 1$ (Max Integer Value)
- $S_{w-min} = B2S_{w}(100....0) = -2^{w-1} + 1$ (Min Integer Value)

Signed Integers - One's Complement Representation

One's complement Integer Interpretation for w-bit strings:

$$B2O_{w}: \{ 0, 1 \}^{w} \to \{ -2^{w-1}+1, \dots 0, \dots, 2^{w-1}-1 \}$$

$$B2O_{w}(\vec{x}) \doteq -x_{w-1}(2^{w-1}-1) + \sum_{i=0}^{w-2} x_{i}2^{i}$$

Ex:
$$B2O_4(0101) = 5$$
, $B2S_4(1001) = -6$, $B2O_4(0000) = 0$, $B2S_4(1111) = -0$

- $O_{w-max} = B2O_{w}(011..1) = 2^{w-1} 1$ (Max Integer Value)
- $O_{w-min} = B2O_{w}(100....0) = -2^{w-1} + 1$ (Min Integer Value)

What is the Shortcut for converting Decimal to One's Complement and vice-versa?

Signed Integers – Two's Complement Representation

Two's complement Integer Interpretation for w-bit strings:

$$B2T_w : \{ 0, 1 \}^w \rightarrow \{ -2^{w-1}, ..., 0, ..., 2^{w-1}-1 \}$$


$$B2T_w(\vec{x}) \doteq -x_{w-1}2^{w-1} + \sum_{i=0}^{w-2} x_i 2^i$$

Ex:
$$B2T_4(0101) = 5$$
, $B2T_4(1001) = -7$, $B2OT_4(0000) = 0$, $B2S_4(1111) = -1$

- $T_{w-max} = B2T_{w}(011..1) = 2^{w-1} 1$ (Max Integer Value)
- $T_{w-min} = B2O_{w}(100....0) = -2^{w-1}$ (Min Integer Value)


What is the Shortcut for converting Decimal to Two's Complement and vice-versa?

Unsigned and Two's Complement Representations



Unsigned and Signed (2's Complement) Integer Addition

Row ID	Binary	Unsigned	2's Complement
R _o	000	0	0
R ₁	001	1	1
R ₂	010	2	2
R ₃	011	3	3
R ₄	100	4	-4
R ₅	101	5	-3
R ₆	110	6	-2
R ₇	111	7	-1



1.
$$R_2 + R_4 = R_6$$

1. $010 + 100 = 110$

$$2. \quad 2 + 4 = 6$$

3.
$$2 + (-4) = -2$$

2.
$$R_6 + R_7 = R_5$$

Two's

1.
$$110 + 111 = 1101$$

2.
$$6 + 7 = 5 (13 \mod 8)$$

3.
$$-2 + (-1) = -3$$


3.
$$R_2 + R_3 = R_5$$

1.
$$010 + 011 = 101$$

$$2. \quad 2 + 3 = 5$$

$$3. \quad 2 + 3 = -3$$


Unsignef



Overflow in Unsigned Integer Addition

- W-bit Unsigned Integer Addition
 - Overflow: When a carry-bit onto (w+1)th bit position is generated.


$$x +_{w}^{u} y = \begin{cases} x + y, & x + y < 2^{w} \\ x + y - 2^{w}, & 2^{w} \le x + y < 2^{w+1} \end{cases}$$



Overflow in Signed (2's Complement) Integer Addition

W-bit signed addition

- Overflow
 - Two positive integers are added and the result is negative
 - Two negative integers are added and the result is positive



$$x +_{w}^{t} y = \begin{cases} x + y - 2^{w}, & 2^{w-1} \le x + y \\ x + y, & -2^{w-1} \le x + y < 2^{w-1} \end{cases}$$
 Positive Normal Negative

Positive Overflow Normal Negative Overflow