

Intro to Instrumentation and Field Measurements in Remote Sensing

Javier Concha and Paul Romanczyk



Digital Imaging and Remote Sensing Lab
Chester F. Carlson Center for Imaging Science
Rochester Institute of Technology

January 8, 2015

Presented for 2015 Intersession Term

Outline

① Introduction

② Background

③ Taking Measurements

④ DIRS Instruments

Outline

① Introduction

② Background

③ Taking Measurements

④ DIRS Instruments

Course Goals

- Learn the importance of field measurements
- Learn how to take field measurements
- Learn about DIRS instruments

Course Description

- Friday: Introduction
- Monday: Introduction (con't) and DIRS instruments exhibition
- Tuesday: Lab: Reflectance measurements
- Wednesday: Lab: LIDAR measurements

Definitions

- **Remote Sensing:**

“Remote sensing is the science of obtaining information about objects or areas from a distance, typically from aircraft or satellites.”

- **Field Measurements or Groundtruth or Ground-based data or reference data or ancillary data:**

“Observations or measurements made at or near the surface of the earth in support of remote sensing.”

Motivation

Why is it important?


- Validation: comparison to know how close a model is to the field measurements (accuracy)
- Calibration or Correction: adjust model or instrument to be more precise (data fitting)
- Data collection to get characteristics of target, materials, etc.

Motivation Examples

Include:

- Javier's example (over water mea.)
- Paul's example (LIDAR and trees?)

Field Data Collection Area of Study



Field Data Collection (con't)


Area of Study

R·I·T

Rochester Institute of Technology




Field Data Collection (con't)



Water Samples




Lab Analysis



Water Leaving
Reflectance

Spectroradiometer



Backscattering


Field Data Collection (con't)

Lab Measurements

R·I·T

Rochester Institute of Technology

Spectrophotometer



IOPs

Hydrolight



Filtration and Spectrophotometric Analysis



Concentrations

Field Data Collection (con't)

2013 and 2014 Seasons

R·I·T

Rochester Institute of Technology

| | | IOPs | | Concentrations | | Reflectances | | Backscattering | |
|------|--------|-------|------|----------------|------|--------------|------|----------------|------|
| Date | | Ponds | Lake | Ponds | Lake | Ponds | Lake | Ponds | Lake |
| 2013 | 25-Aug | ✓ | ✗ | ✓ | ✗ | ✗ | ✗ | ✗ | ✗ |
| | 19-Sep | ✓ | ✓ | ✓ | ✓ | ✗ | ✓ | ✓ | ✓ |
| | 26-Sep | ✓ | ✓ | ✓ | ✓ | ✗ | ✓ | ✗ | ✓ |
| 2014 | 17-May | ✓ | ✗ | ✓ | ✗ | ✓ | ✗ | ✓ | ✗ |
| | 02-Jun | ✗ | ✓ | ✗ | ✓ | ✗ | ✓ | ✗ | ✓ |
| | 11-Jul | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✗ | ✓ |
| | 28-Aug | ✗ | ✓ | ✗ | ✓ | ✗ | ✗ | ✗ | ✗ |
| | 29-Sep | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |

Outline

① Introduction

② Background


③ Taking Measurements

④ DIRS Instruments

Examples of Kind of Measurements

- Reflectance: Radiometer
- Concentration: Spectrophotometer
- Location: GPS
- Structure: LIDAR
- Leaf Area Index (LAI): Ceptometer

Radiometric Quantities: Radiance



ΔQ : radian energy
incident

Δt : time interval


ΔA : surface area at
location (x,y,z)

$\Delta\Omega$: solid angle in
direction (θ,φ)

$\Delta\lambda$: photons wavelength
interval

$$L(x, y, z, t, \theta, \varphi, \lambda) \equiv \frac{\Delta Q}{\Delta t \Delta A \Delta \Omega \Delta \lambda} \quad [Js^{-1} m^{-2} sr^{-1} nm^{-1}] \quad (1)$$


Radiometric Quantities: Radiance



- ΔQ : radian energy incident
- Δt : time interval
- ΔA : surface area at location (x,y,z)
- $\Delta\Omega$: solid angle in direction (θ,φ)
- $\Delta\lambda$: photons wavelength interval

$$L(x, y, z, t, \theta, \varphi, \lambda) \equiv \frac{\partial^4 Q}{\partial t \partial A \partial \Omega \partial \lambda} \quad [Js^{-1} m^{-2} sr^{-1} nm^{-1}] \quad (1)$$

Radiance Sensor



(Source: [Mobley, 2010])

Radiometric Quantities: Irradiance

Spectral downwelling scalar irradiance at depth z :

$$E_{od}(z, \lambda) = \int_{2\pi_d} L(z, \theta, \varphi, \lambda) d\Omega \quad [Wm^{-2}nm^{-1}] \quad (2)$$

Spectral upwelling scalar irradiance at depth z :


$$E_{ou}(z, \lambda) = \int_{2\pi_u} L(z, \theta, \varphi, \lambda) d\Omega \quad [Wm^{-2}nm^{-1}] \quad (3)$$

Spectral scalar irradiance at depth z :

$$E_o(z, \lambda) \equiv E_{od}(z, \lambda) + E_{ou}(z, \lambda) \quad (4)$$

$$= \int_{4\pi} L(z, \theta, \varphi, \lambda) d\Omega \quad (5)$$

Scalar Irradiance Sensor



(Source: [Mobley, 2010])

Radiometric Quantities: Irradiance


Spectral downwelling plane irradiance at depth z :

$$E_d(z, \lambda) = \int_{2\pi_d} L(z, \theta, \varphi, \lambda) |\cos\theta| d\Omega \quad [Wm^{-2}nm^{-1}] \quad (6)$$

Photosynthetic available radiation, **PAR**:

$$PAR(z) \equiv \int_{350nm}^{700nm} \frac{\lambda}{hc} E_o(z, \lambda) d\lambda \quad [photons s^{-1}m^{-2}] \quad (7)$$

Planar Irradiance Sensor



(Source: [Mobley, 2010])

Reflectance

- **Irradiance reflectance:**

$$R(z, \lambda) \equiv \frac{E_u(z, \lambda)}{E_d(z, \lambda)} \quad (8)$$

- **Remote sensing reflectance (water):**

$$R_{rs}(\theta, \varphi, \lambda) \equiv \frac{L_w(\theta, \varphi, \lambda)}{E_d(\lambda)} \quad [sr^{-1}] \quad (9)$$

where L_w is the **water-leaving radiance**

- **Bidirectional Reflectance Distribution Function (BRDF):**

$$r_{BRDF} = \frac{L(\theta_o, \phi_o)}{E(\theta_i, \phi_i)} \quad [sr^{-1}] \quad (10)$$

Outline

① Introduction

② Background

③ Taking Measurements

④ DIRS Instruments

Diffuse white reference panel (Spectralon)


R·I·T

Rochester Institute of Technology

- For a Lambertian surface:

$$L = \frac{E_d r}{\pi} \Rightarrow E_d = \frac{L\pi}{r}$$

- For spectralon $r \approx 1$
($\approx 100\%$)
 $\Rightarrow E_d = L\pi$



Reflectance

- **Reflectance:** $R(z, \lambda) \equiv \frac{L_u(z, \lambda)}{E_d(z, \lambda)}$
- Two measurements:
 - E_d : Spectralon
 - L_u : Target or sample

Remote-Sensing Reflectance


- 3 measurements:
 - L_g (spectralon)
 - $L_t = L_r + L_w$ (water)
 - L_{sky}


- Remote-sensing reflectance:

$$\begin{aligned} R_{rs} &= L_w/E_d \\ &= (L_t - L_r)/E_d \end{aligned}$$

with $L_r = 0.028 * L_{sky}$

- $E_d = L_g * \pi$
- ϕ : azimuthal angle
- θ : zenith angle





Things to consider for a field campaign

- have a good datasheet
- download and look data ASAP
- tools for in-field repairs and cleaning
- water, food, field clothes, first aid
- plan collection ahead of time
- write down procedure
- setting up plots/sites
- take pictures
- read manual
- charge batteries
- check batteries
- check instrument in advance
- The data should be taken as close to the time of acquisition as possible (due to inevitable landscape changes)

Field Campaigns

- Brings theory to practice
- It is FUN!

SHOW PICTURES HERE!

Outline

① Introduction

② Background

③ Taking Measurements

④ DIRS Instruments

DIRS Lab Instruments

- ASD
- SVC
- RIT LIDAR
- GRIT
- WASP
- GPS
- HydroScat-2
- AccuPAR LP-80
- WASP
- WASP Lite
- MISI
- Thermistor
- Camera
- Tape measures


Data Extraction

- Data in proprietary format
- Translate or export to ASCII (text file)
- Text files manipulation (IDL, Matlab, Python, C++, bash).

Thanks for your attention!

QUESTIONS?


Javier A. Concha
jxc4005@rit.edu



(09/19/2013)

Thanks for your attention!
QUESTIONS?

Javier A. Concha
jxc4005@rit.edu



References



[[Mobley, 2010]

Ocean optics web book.

[http://www.oceanopticsbook.info/.](http://www.oceanopticsbook.info/)

]Mobley, C. D. (2010).