SCOPF Problem Formulation: Challenge 1

Grid Optimization Competition

Updated: April 9, 2019

Contents

1	Bac	kground	6
2	Sym	abol Reference	8
3	Mod	del Formulation	18
	3.1	Objective Definition	18
	3.2	Primary Optimization Variable Bounds in the Base Case	20
	3.3	Line Flow Definitions in the Base Case	21
	3.4	Transformer Flow Definitions in the Base Case	21
	3.5	Bus Power Balance Constraints in the Base Case	22
	3.6	Line Current Ratings in the Base Case	23
	3.7	Transformer Power Ratings in the Base Case	23
	3.8	Primary Optimization Variable Bounds in Contingencies	23
	3.9	Line Flow Definitions in Contingencies	24
	3.10	Transformer Flow Definitions in Contingencies	24
	3.11	Bus Power Balance Constraints in Contingencies	25
	3.12	Line Current Ratings in Contingencies	26
	3.13	Transformer Power Ratings in Contingencies	26
	3.14	Generator Real Power Contingency Response	26
		3.14.1 Logical Formulation	27
		3.14.2 Projection Formulation	27
		3.14.3 Mixed Integer Programming Formulation	27
	3.15	Generator Reactive Power Contingency Response	29
		3.15.1 Formulation with Logical Constraints	29

		3.15.2	Formulation with Min and Max Operators	30
		3.15.3	Formulation with Binary Variables	30
	3.16	Optim	ization Model	31
	3.17	Deviat 000195	tions from the Focused Formulation Presented in ARPA-E DE-FOA- 52	32
$\mathbf{A}_{]}$	ppen	dices		32
\mathbf{A}	Inpu	ıt Dat	a Format	33
	A.1	Introd	uction	33
		A.1.1	Input Data Files	33
		A.1.2	General Format of Data Files	33
		A.1.3	Restrictions on Data File Formats Imposed by the GO Competition Challenge 1	34
		A.1.4	Notation Used in Input Data Format Description	35
		A.1.5	Reading the Data Files	35
	A.2	Power	Flow Raw Data File (case.raw)	36
		A.2.1	Case Identification Data	37
		A.2.2	Bus Data	37
		A.2.3	Load Data	38
		A.2.4	Fixed Bus Shunt Data	39
		A.2.5	Generator Data	40
		A.2.6	Non-Transformer Branch Data	41
		A.2.7	Transformer Data	43
		A.2.8	Switched Shunt Data	45
	A.3	Genera	ator Cost Data File (case.rop)	46
		A 3 1	Generator Dispatch Units	47

		A.3.2	Active Power Dispatch Tables	48
		A.3.3	Piecewise Linear Cost Curve Tables	48
	A.4	Unit Ir	nertia and Governor Response Data File (case.inl)	49
	A.5	Contin	gency Description Data File (case.con)	50
		A.5.1	Branch Out-of-Service Event	53
		A.5.2	Generator Out-of-Service Event	54
В	Data	a Cons	truction Reference Table	55
\mathbf{C}	Con	structi	on of Primitive Data from Input Data Files	59
	C.1	Initial	Parameter Values prior to Reading Data	59
	C.2	Case Io	dentification Data from RAW	60
	C.3	Bus Da	ata from RAW	60
	C.4	Load I	Data from RAW	61
	C.5	Fixed S	Shunt Data from RAW	61
	C.6	Genera	ator Data from RAW	61
	C.7	Line D	ata from RAW	62
	C.8	Transfe	ormer Data from RAW	63
	C.9	Switch	ed Shunt Data from RAW	64
	C.10	Genera	ator Cost Data from ROP	64
	C.11	Partici	pation Factor Data from INL	65
	C.12	Contin	gency Data from CON	65
D	Con	structi	on of Further Data	67
	D.1	Constr	aint Violation Penalty Parameters	67
	D.2	Genera	ator Real Power Contingency Response Data	69

	D.3	Construction of c^{slack}	69
	D.4	Given Base Case Operating Point	69
\mathbf{E}	Solu	ation Output	70
	E.1	Solution Normalization for Output Files	70
	E.2	Solution File Format Description	71
	E.3	Sample Solution Output Files	72
F	Solu	ition Evaluation	74
	F.1	Procedure	74
	F.2	Solution Score	77
\mathbf{G}	Cha	ange Log	78
	G.1	November 1, 2018	78
	G.2	November 14, 2018	78
	G.3	November 30, 2018	78
	G.4	March 29, 2019	79
	G.5	April 9 2019	79

1 Background

This document contains the official formulation that will be used for evaluation in Challenge 1 of the Grid Optimization (GO) Competition. Minor changes may occur within the formulation. Entrants will be notified when a new version is released. Changes are not expected to be of any significance, to cause a change in approach for the Entrants.

This formulation builds upon the formulation published in ARPA-E DE-FOA-0001952. Entrants will be judged based on the current official formulation posted on the GO Competition website (this document, which is subject to change), not the formulation posted in DE-FOA-0001952. Entrants are permitted and encouraged to use any alternative problem formulation and modeling convention within their own software (such as convex relaxation, decoupled power flow formulations, current-voltage formulations, etc.) in an attempt to produce an exact or approximate solution to this particular mathematical program. However, the judging of all submitted approaches must conform to the official formulation presented here.

The following mathematical programming problem is a type of a security-constrained (AC based) optimal power flow, or SCOPF. There are many ways to formulate the SCOPF problem; this document presents multiple equivalent options for specified constraints. Entrants are strongly encouraged to study this formulation precisely and to engage with the broader community if anything is not clear (please see the FAQs and forum on the GO Competition website, https://gocompetition.energy.gov/).

This SCOPF problem is defined to be an alternating current (AC) formulation, which is based on a bus-branch power system network model and considers security constraints. In general, Entrants are tasked with determining the optimal dispatch and control settings for power generation and grid control equipment in order to minimize the cost of operation, subject to pre- and post-contingency constraints. Feasible solutions must conform to operating standards including, but not limited to: minimum and maximum bus voltage magnitude limits, minimum and maximum real and reactive power generation from each generator, thermal transmission constraints, proxy stability constraints, and constraints to ensure the reliability of the system while responding to unexpected events (i.e., a contingency). Feasible solutions must also include contingency modeling to describe the response of generators and transmission elements to changes from the pre-contingency base case. This formulation allows for real and reactive power nodal violations as well as branch (transmission line and transformer) overloading; however, violations will be penalized in the objective function.

Features that are not modeled within this SCOPF include transformer tap settings, phase angle regulators, various flexible AC transmission system (FACTS) devices, or switchable shunts. Please note that shunts are included but we are not precisely modeling the binary nature of switchable shunts; rather, these are modeled using continuous variables.

Challenge 1 will include power system network models that vary in size of the network flow problem (number of nodes and branches) as well as the number of contingencies. The largest

models will reach to at least the size of the largest regional transmission organization within the United States. The problem presented here is a single period problem. The modeling of the pre-contingency base case is a reflection of the first stage of a two-stage mathematical program whereas the post-contingency state represents the second stage. Unit commitment (the commitment/decommitment of generators) is not included in the formulation and fast-start generators are not acknowledged as an available post-contingency response; only units that are online initially may respond. Post-contingency generator response (i.e., activation of contingency reserve) is dictated by an offline policy: generators must follow their predefined participation factor unless they reach an operational limit. As such, this problem does not fully optimize the second-stage recourse decision variables but rather forces them to follow this offline policy. Challenge 2 will likely expand upon Challenge 1 by considering more advanced modeling of power flow equipment (transformers, phase shifters, FACTS), the grid itself (e.g., bus-breaker models), and a more detailed representation of the flexibility available to respond during a contingency (e.g., generator response and modeling of recourse decision variables and limits).

2 Symbol Reference

Units, notation, and the general nomenclature are given Tables (1, 2, 3, 4, 5, 6, 7, 8). These tables list sets, indices, subsets and special set elements, data parameters, and variables. As much as possible, the notation follows the following convention. (1) A symbol consists of a main letter with attached notation such as subscripts, superscripts, oversets, and undersets. (2) Two symbols with the same main letter but different attached notation are different symbols. (3) The main letters of symbols generally follow conventions common in the optimal power flow literature and the optimization literature, though other letters are used where there is no established convention.

Units of measurement are listed in Table (1). Attached notation convention is given in Table (2). Main letter convention is given in Table (3). Sets are given in Table (4). Indices are given in Table (5). Subsets and distinguished set elements are given in Table (6). Parameters are given in Table (7) and variables are given in Table (8).

Table 1: Units of measurement

Unit	Description
1	dimensionless. Dimensionless real number quantities are indicated by a unit of 1.
bin	binary. Binary quantities, i.e. taking values in $\{0,1\}$, are indicated by a unit of bin.
h	hour. In the physical unit convention and the per unit convention, time is expressed in h.
deg	degree. In the physical unit convention, angles are expressed in deg.
USD	US dollar. Cost, penalty, and objective values are expressed in USD.
kV	kilovolt. In the physical unit convention, voltage magnitude is expressed in kV.
MVAR	megavolt-ampere-reactive. In the physical unit convention, reactive power is expressed in MVAR.
MVAR at 1 p.u. voltage	megavolt-ampere-reactive at unit voltage. In the physical unit convention, susceptance is expressed in MVAR at 1 p.u. voltage, meaning the susceptance is such as to yield a reactive power flow equal to the indicated amount when the voltage is equal to 1 p.u.
MW	megawatt. In the physical unit convention, real power is expressed in MW.

Table 1: Continued

Unit	Description
MW at 1 p.u. voltage	megawatt at unit voltage. In the physical unit convention, conductance is expressed in MW at 1 p.u. voltage, meaning the conductance is such as to yield a real power flow equal to the indicated amount when the voltage is equal to 1 p.u.
p.u.	per unit. Real and reactive power, voltage magnitude, conductance, susceptance can be expressed in a per unit system under given base values, and the unit is denoted by p.u.
rad	radian. In the per unit convention, angles are expressed in rad.

Table 2: Attached notation

example	description
w_{\square}	subscript is used for an index in a set.
w^{\square}	superscript is used for description of a symbol.
\overline{w}	overline is used for an upper bound.
\underline{w}	underline is used for a lower bound.
$ ilde{w}$	overset \sim indicates a unit base value.
w^0	superscript 0 indicates a value in a given operating point.
w^o	superscript o indicates the origin (from, sending) bus of a branch.
w^d	superscript d indicates the destination (to, receiving) bus of a branch.
w^+	superscript + indicates an upper bound violation, the positive part of an equality constraint violation, or an upper bound slack.
w^-	superscript — indicates a lower bound violation, or a lower bound slack.
\hat{w}	overset ^ indicates a value reported in a solution file, possibly in different units from the corresponding value in the model.
${\mathcal W}$	primitive index sets are denoted by a caligraphic capital letter.
$W \subset \mathcal{W}$	subsets are denoted by the same letter as the corresponding primitive index set, in italic.
$w \in \mathcal{W}$	set elements are denoted by the same letter as the corresponding primitive index set, in lower case italic.
w'	set elements are primed to denote different elements of the same set.

Table 3: Main letter convention

main letter	description
\overline{a}	area
b	susceptance
c	cost, penalty, objective
e	transmission line (arc in a transmission network)
f	transformer (arc in a transmission network)
g	conductance (also generator: when g appears with a subscript, it is a conductance value)
g	generator (also conductance: when g appears as an element of a set, it is a generator)
h	point on a cost function
i	bus (node in a transmission network)
k	contingency
n	segment number for the piecewise linear penalty cost function for violations (constraint relaxations)
p	real power
q	reactive power
R	apparent current rating (current magnitude); used as data label in the Appendices, the interpretation is context dependent.
s	apparent power (power magnitude)
t	interpolation coeficient
v	voltage magnitude
x	binary variables
α	participation factor
Δ	post-contingency (adjusted) real power response for generators following
θ	bus voltage angle or transformer shift angle
λ	constraint violation penalty coefficient
σ	violation or slack variable relative to a constraint
au	tap ratio

Table 4: Primitive index sets

Symbol	Description
$\overline{\mathcal{A}}$	set of areas
${\cal E}$	set of lines (nontransformer branches)
${\cal F}$	set of transformers (2-winding only)
${\cal G}$	set of generators
${\cal H}$	set of cost function sample points
${\cal I}$	set of buses
$\mathcal K$	set of contingencies
\mathcal{N}	set of segments in the piecewise linear penalty cost function for violations (constraint relaxations)

Table 5: Indices

Symbol	Description
$a \in \mathcal{A}$	area indices
$e \in \mathcal{E}$	line indices
$f \in \mathcal{F}$	transformer indices
$g \in \mathcal{G}$	generator indices
$h \in \mathcal{H}$	cost function sample point indices
$i \in \mathcal{I}$	bus indices
$k \in \mathcal{K}$	contingency indices
$n \in \mathcal{N}$	segment indices for the piecewise linear penalty cost function for violations (constraint relaxations)

Table 6: Subsets and distinguished set elements

Symbol	Description
C	area of bus i contingent areas in contingency k , i.e., areas containing a bus with a connected generator, line, or transformer that goes out of service in contingency k

Table 6: Continued

Symbol	Description
$E \subset \mathcal{E}$	lines active in the base case
$E_i^d \subset \mathcal{E}$	lines with destination bus $i, E_i^d = \{e \in E : i_e^d = i\}$
$E_i^o \subset \mathcal{E}$	lines with origin bus $i, E_i^o = \{e \in E : i_e^o = i\}$
$E_k \subset \mathcal{E}$	lines active in contingency k
$E_{ik}^d \subset \mathcal{E}$	lines active in contingency k with destination bus i, $E_{ik}^d = E_i^d \cap E_k$
$E^o_{ik} \subset \mathcal{E}$	lines active in contingency k with origin bus $i, E_{ik}^o = E_i^o \cap E_k$
$F \subset \mathcal{F}$	transformers active in the base case
$F_i^d \subset \mathcal{F}$	transformers with destination bus $i, F_i^d = \{f \in F : i_f^d = i\}$
$F_i^o \subset \mathcal{F}$	transformers with origin bus $i, F_i^o = \{f \in F : i_f^o = i\}$
$F_k \subset \mathcal{F}$	transformers active in contingency k
$F_{ik}^d \subset \mathcal{F}$	transformers active in contingency k with destination bus $i, F_{ik}^d = F_i^d \cap F_k$
$F_{ik}^o \subset \mathcal{F}$	transformers active in contingency k with origin bus $i, F_{ik}^o = F_i^o \cap F_k$
$G \subset \mathcal{G}$	generators active in the base case
$G_i \subset \mathcal{G}$	generators connected to bus $i, G_i = \{g \in G : i_g = i\}$
$G_k \subset \mathcal{G}$	generators active in contingency k
$G_k^P \subset \mathcal{G}$	generators participating in real power response in contingency k
$G_{ik} \subset \mathcal{G}$	generators active in contingency k and connected to bus i , $G_{ik} = G_i \cap G_k$
$H_g \subset \mathcal{H}$	cost function sample points for generator g
$I_a \subset \mathcal{I}$	buses in area $a, I_a = \{i \in \mathcal{I} : a_i = a\}$
$i_e^d \in \mathcal{I}$	destination bus of line e
$i_e^o \in \mathcal{I}$	origin bus of line e
$i_f^d \in \mathcal{I}$	destination bus of transformer f
$i_f^o \in \mathcal{I}$	origin bus of transformer f
$i_g \in \mathcal{I}$	bus that generator g is connected to
id_g	ID of generator g (2-character string)

Table 7: Data parameters

Symbol	Description
b_e	line e series susceptance (p.u.)

Table 7: Continued

Symbol	Description			
b_e^{CH}	line e total charging susceptance (p.u.)			
b_f	transformer f series susceptance (p.u.)			
b_f^M	transformer f magnetizing susceptance (p.u.)			
\overline{b}_{i}^{CS} \underline{b}_{i}^{CS}	bus i maximum controllable shunt susceptance (p.u.)			
\underline{b}_i^{CS}	bus i minimum controllable shunt susceptance (p.u.)			
b_i^{FS}	bus i fixed shunt susceptance (p.u.)			
c^{slack}	the objective value of a certain easily constructed feasible solution $(\mathrm{USD/h})$			
c_{gh}	generation cost of generator g at sample point h (USD/h)			
g_e	line e series conductance (p.u.)			
g_f	transformer f series conductance (p.u.)			
g_f^M	transformer f magnetizing conductance (p.u.)			
g_i^{FS}	bus i fixed shunt conductance (p.u.)			
M	a large constant used in the big-M mixed integer programming formulation of generator real power contingency response (p.u.)			
\underline{M}	a constant such that for any $M \ge \underline{M}$ the mixed integer programming formulation of generator real power response is valid. (p.u.)			
M^P	a large constant used in the big-M mixed integer programming formulation of generator real power contingency response (p.u.)			
\underline{M}^P	a constant such that for any $M^P \ge \underline{M}^P$ the mixed integer programming formulation of generator real power response is valid. (p.u.)			
M^Q	a large constant used in the big-M mixed integer programming formulation of generator reactive power contingency response (p.u.)			
\underline{M}^Q	a constant such that for any $M^Q \ge \underline{M}^Q$ the mixed integer programming formulation of generator reactive power response is valid. (p.u.)			
M^v	a large constant used in the big-M mixed integer programming formulation of generator reactive power contingency response (p.u.)			
\underline{M}^v	a constant such that for any $M^v \ge \underline{M}^v$ the mixed integer programming formulation of generator reactive power response is valid. (p.u.)			
\overline{p}_g	generator g real power maximum (p.u.)			
\underline{p}_g	generator g real power minimum (p.u.)			
p_{gh}	real power output of generator g at sample point h (p.u.)			
p_i^L	bus i constant real power load (p.u.)			
\overline{q}_g	generator g reactive power maximum (p.u.)			

Table 7: Continued

Symbol	Description		
\underline{q}_g	generator g reactive power minimum (p.u.)		
q_i^L	bus i constant reactive power load (p.u.)		
\overline{R}_e	line e apparent current maximum in base case (p.u.)		
\overline{R}_e^K	line e apparent current maximum in contingencies		
$ ilde{s}$	system power base (MVA)		
\overline{s}_f	transformer f apparent power maximum in base case (p.u.)		
\overline{s}_f^K	transformer f apparent power maximum in contingencies (p.u.)		
\tilde{v}_i	bus i voltage base (kV)		
\overline{v}_i	bus i voltage magnitude maximum in the base case (p.u.)		
\underline{v}_i	bus i voltage magnitude minimum in the base case (p.u.)		
\overline{v}_i^K	bus i voltage magnitude maximum in contingencies (p.u.)		
\underline{v}_i^K	bus i voltage magnitude minimum in contingencies (p.u.)		
α_g	participation factor of generator g in real power contingency response (1)		
δ	weight on base case in objective (1)		
$ heta_f$	transformer f phase angle (rad)		
λ_n^P	objective coefficient on real power power constraint violations for segment n in the piecewise linear penalty cost function (USD/p.uh)		
λ_n^Q	objective coefficient on real power power constraint violations for segment n in the piecewise linear penalty cost function (USD/p.uh)		
λ_n^S	objective coefficient on apparent power constraint violations for segment n in the piecewise linear penalty cost function (USD/p.uh)		
$\overline{\sigma}_{en}^{S}$	segment n upper bound corresponding to the piecewise linear penalty cost function for line e apparent current rating violation (p.u.)		
$\overline{\sigma}_{fn}^{S}$	segment n upper bound corresponding to the piecewise linear penalty cost function for transformer f apparent power rating violation (p.u.)		
$\overline{\sigma}_{ekn}^{S}$	segment n upper bound corresponding to the piecewise linear penalty cost function for line e contingency k apparent current rating violation (p.u.)		
$\overline{\sigma}_{fkn}^{S}$	segment n upper bound corresponding to the piecewise linear penalty cost function for transformer f contingency k apparent power rating violation (p.u.)		
$\overline{\sigma}_{in}^{P+}$	segment n upper bound corresponding to the piecewise linear penalty cost function for bus i real power balance violation positive part, i.e., excess real power flowing into bus i (p.u.)		

Table 7: Continued

Symbol	Description
$\overline{\sigma}_{in}^{P-}$	segment n upper bound corresponding to the piecewise linear penalty cost function for bus i real power balance violation negative part, i.e., excess real power flowing out of bus i (p.u.)
$\overline{\sigma}_{in}^{Q+}$	segment n upper bound corresponding to the piecewise linear penalty cost function for bus i reactive power balance violation positive part (p.u.)
$\overline{\sigma}_{in}^{Q-}$	segment n upper bound corresponding to the piecewise linear penalty cost function for bus i reactive power balance violation negative part (p.u.)
$\overline{\sigma}_{ikn}^{P+}$	segment n upper bound corresponding to the piecewise linear penalty cost function for bus i contingency k real power balance violation positive part (p.u.)
$\overline{\sigma}_{ikn}^{P-}$	segment n upper bound corresponding to the piecewise linear penalty cost function for bus i contingency k real power balance violation negative part (p.u.)
$\overline{\sigma}_{ikn}^{Q+}$	segment n upper bound corresponding to the piecewise linear penalty cost function for bus i contingency k reactive power balance violation positive part (p.u.)
$\overline{\sigma}_{ikn}^{Q-}$	segment n upper bound corresponding to the piecewise linear penalty cost function for bus i contingency k reactive power balance violation negative part (p.u.)
$ au_f$	transformer f tap ratio (1)

Table 8: Optimization variables

Symbol	Description
b_i^{CS}	bus i controllable shunt susceptance (p.u.)
b_{ik}^{CS}	bus i contingency k controllable shunt susceptance (p.u.)
c	total objective (USD/h)
c_g	generation cost of generator g (USD/h)
c^{σ}	total constraint violation penalty in base case (USD/h)
c_k^{σ}	total constraint violation penalty in contingency k (USD/h)
p_e^d	line e real power from destination bus into line (p.u.)

Table 8: Continued

Symbol	Description			
p_e^o	line e real power from origin bus into line (p.u.)			
p_{ek}^d	line e contingency k real power from destination bus into line (p.u.)			
p_{ek}^o	line e contingency k real power from origin bus into line (p.u.)			
p_f^d	transformer f real power from destination bus into transformer (p.u.)			
p_f^o	transformer f real power from origin bus into transformer (p.u.)			
p_{fk}^d	transformer f contingency k real power from destination bus into transformer (p.u.)			
p_{fk}^o	transformer f contingency k real power from origin bus into transformer (p.u.)			
p_g	generator g real power output (p.u.)			
p_{gk}	generator g contingency k real power output (p.u.)			
q_e^d	line e reactive power from destination bus into line (p.u.)			
q_e^o	line e reactive power from origin bus into line (p.u.)			
q_{ek}^d	line e contingency k reactive power from destination bus into line (p.u.)			
q_{ek}^o	line e contingency k reactive power from origin bus into line (p.u.)			
q_f^d	transformer f reactive power from destination bus into transformer (p.u.)			
q_f^o	transformer f reactive power from origin bus into transformer (p.u.)			
q_{fk}^d	transformer f contingency k reactive power from destination bus into transformer (p.u.)			
q_{fk}^o	transformer f contingency k reactive power from origin bus into transformer (p.u.)			
q_g	generator g reactive power output (p.u.)			
q_{gk}	generator g contingency k reactive power output (p.u.)			
t_{gh}	coefficient of sample point h for generator g solution as a point on generation cost function (1)			
v_i	bus i voltage magnitude (p.u.)			
v_{ik}	bus i contingency k voltage magnitude (p.u.)			
x_{gk}^{P+}	generator g contingency k binary variable indicating positive slack in upper bound on real power output (bin)			
x_{gk}^{P-}	generator g contingency k binary variable indicating positive slack in lower bound on real power output (bin)			
x_{gk}^{Q+}	generator g contingency k binary variable indicating positive slack in upper bound on reactive power output (bin)			

Table 8: Continued

Symbol	Description
x_{gk}^{Q-}	generator g contingency k binary variable indicating positive slack in lower bound on reactive power output (bin)
Δ_k	contingency k scale factor on generator participation factors definining generator real power contingency response (p.u.)
$ heta_i$	bus i voltage angle (rad)
$ heta_{ik}$	bus i contingency k voltage angle (rad)
σ_{en}^S	line e apparent current rating violation for segment n in the piecewise linear penalty cost function (p.u.)
σ^S_{ekn}	line e contingency k apparent current rating violation for segment n in the piecewise linear penalty cost function (p.u.)
σ_{fn}^S	transformer f apparent power rating violation for segment n in the piecewise linear penalty cost function (p.u.)
σ^S_{fkn}	transformer f contingency k apparent power rating violation for segment n in the piecewise linear penalty cost function (p.u.)
σ_{in}^{P+}	bus i real power balance violation positive part, i.e., excess real power flowing into bus i , for segment n in the piecewise linear penalty cost function (p.u.)
σ_{in}^{P-}	bus i real power balance violation negative part, i.e., excess real power flowing out of bus i , for segment n in the piecewise linear penalty cost function (p.u.)
σ_{in}^{Q+}	bus i reactive power balance violation positive part for segment n in the piecewise linear penalty cost function (p.u.)
σ_{in}^{Q-}	bus i reactive power balance violation negative part for segment n in the piecewise linear penalty cost function (p.u.)
σ^{P+}_{ikn}	bus i contingency k real power balance violation positive part for segment n in the piecewise linear penalty cost function (p.u.)
σ^{P-}_{ikn}	bus i contingency k real power balance violation negative part for segment n in the piecewise linear penalty cost function (p.u.)
σ^{Q+}_{ikn}	bus i contingency k reactive power balance violation positive part for segment n in the piecewise linear penalty cost function (p.u.)
σ^{Q-}_{ikn}	bus i contingency k reactive power balance violation negative part for segment n in the piecewise linear penalty cost function (p.u.)

3 Model Formulation

3.1 Objective Definition

The objective (for minimization) is the sum of generator real power output costs in the base case, and a weighted sum of soft constraint violation penalties in the base case and contingencies:

$$c = \sum_{g \in G} c_g + \delta c^{\sigma} + (1 - \delta) / |\mathcal{K}| \sum_{k \in \mathcal{K}} c_k^{\sigma}$$
(1)

Generator real power output cost is defined by a cost function given as a set of sample points, modeled by interpolating the cost to the sample points in the cost space and the real power output to the sample points in the real power output space, with common interpolation coefficients. Generator cost interpolation to sample points:

$$c_g = \sum_{h \in H_g} c_{gh} t_{gh} \quad \forall g \in G \tag{2}$$

Generator real power output interpolation to sample points:

$$\sum_{h \in H_q} p_{gh} t_{gh} = p_g \quad \forall g \in G \tag{3}$$

Generator cost interpolation coefficient bounds:

$$0 \le t_{gh} \quad \forall g \in G, h \in H_g \tag{4}$$

Generator cost interpolation coefficient normalization:

$$\sum_{h \in H_g} t_{gh} = 1 \quad \forall g \in G \tag{5}$$

The total constraint violation penalty in the base case and in contingencies includes penalties on violations of bus real and reactive power balance, penalties on violations of line apparent current ratings, and penalties on violations of transformer apparent power ratings. The penalty is given by a piecewise linear cost function for the violation cost terms - where a small penalty price is applied to minor violations followed by a more stringent penalty price for moderate violations and then an extremely severe penalty for all remaining violations (i.e., it is likely to have 3 segments, indexed by n in this formulation). The first two segments will follow existing industry practices related to constraint relaxations and the chosen penalty prices. The last price will be substantially higher to encourage the approach to not have significant violations. The penalties in the base case and contingencies are given by:

$$c^{\sigma} = \sum_{n \in \mathbb{N}} \left[\lambda_n^P \sum_{i \in \mathcal{I}} (\sigma_{in}^{P+} + \sigma_{in}^{P-}) + \lambda_n^Q \sum_{i \in \mathcal{I}} (\sigma_{in}^{Q+} + \sigma_{in}^{Q-}) + \lambda_n^S \sum_{e \in E} \sigma_{en}^S + \lambda_n^S \sum_{f \in F} \sigma_{fn}^S \right]$$
(6)

$$c_k^{\sigma} = \sum_{n \in N} \left[\lambda_n^P \sum_{i \in \mathcal{I}} (\sigma_{ikn}^{P+} + \sigma_{ikn}^{P-}) + \lambda_n^Q \sum_{i \in \mathcal{I}} (\sigma_{ikn}^{Q+} + \sigma_{ikn}^{Q-}) + \lambda_n^S \sum_{e \in E_k} \sigma_{ekn}^S + \lambda_n^S \sum_{f \in F_k} \sigma_{fkn}^S \right] \quad \forall k \in \mathcal{K}$$

$$(7)$$

Violations in each segment of the piecewise linear cost function are represented by overall violation variables (i.e., not indexed by n) for the remaining constraints in this formulation:

$$\sigma_i^{P+} = \sum_{n \in N} \sigma_{in}^{P+} \quad \forall i \in \mathcal{I}$$
(8)

$$\sigma_{ik}^{P+} = \sum_{n \in \mathbb{N}} \sigma_{ikn}^{P+} \quad \forall i \in \mathcal{I}, k \in \mathcal{K}$$
(9)

$$\sigma_i^{P-} = \sum_{n \in N} \sigma_{in}^{P-} \quad \forall i \in \mathcal{I}$$
 (10)

$$\sigma_{ik}^{P-} = \sum_{n \in N} \sigma_{ikn}^{P-} \quad \forall i \in \mathcal{I}, k \in \mathcal{K}$$

$$\tag{11}$$

$$\sigma_i^{Q+} = \sum_{n \in \mathbb{N}} \sigma_{in}^{Q+} \quad \forall i \in \mathcal{I}$$
 (12)

$$\sigma_{ik}^{Q+} = \sum_{n \in \mathbb{N}} \sigma_{ikn}^{Q+} \quad \forall i \in \mathcal{I}, k \in \mathcal{K}$$
(13)

$$\sigma_i^{Q-} = \sum_{n \in \mathbb{N}} \sigma_{in}^{Q-} \quad \forall i \in \mathcal{I}$$
 (14)

$$\sigma_{ik}^{Q^{-}} = \sum_{n \in \mathbb{N}} \sigma_{ikn}^{Q^{-}} \quad \forall i \in \mathcal{I}, k \in \mathcal{K}$$

$$\tag{15}$$

$$\sigma_e^S = \sum_{n \in N} \sigma_{en}^S \quad \forall e \in E \tag{16}$$

$$\sigma_{ek}^{S} = \sum_{n \in N} \sigma_{ekn}^{S} \quad \forall e \in E, k \in \mathcal{K}$$

$$\tag{17}$$

$$\sigma_f^S = \sum_{n \in N} \sigma_{fn}^S \ \forall f \in F$$
 (18)

$$\sigma_{fk}^{S} = \sum_{n \in N} \sigma_{fkn}^{S} \quad \forall f \in F, k \in \mathcal{K}$$

$$\tag{19}$$

Bounds on violation variables for each segment are established based on the following equations. Each segment slack variable is non-negative with a lower bound of zero and an upper bound that varies based on the n segment. While the presented formulation here is generic, the GO Competition Challenge 1 will likely set the upper bounds for each segment to be a percentage of the corresponding transmission transfer limit (line current limit or transformer power limit) or a fixed MW and MVAr value for the node balance violations.

$$0 \le \sigma_{in}^{P+} \le \overline{\sigma}_{in}^{P+} \quad \forall i \in \mathcal{I}, n \in N \tag{20}$$

$$0 \le \sigma_{ikn}^{P+} \le \overline{\sigma}_{in}^{P+} \quad \forall i \in \mathcal{I}, n \in N, k \in \mathcal{K}$$
 (21)

$$0 \le \sigma_{in}^{P-} \le \overline{\sigma}_{in}^{P-} \quad \forall i \in \mathcal{I}, n \in N$$
 (22)

$$0 \le \sigma_{ikn}^{P-} \le \overline{\sigma}_{in}^{P-} \quad \forall i \in \mathcal{I}, n \in N, k \in \mathcal{K}$$
 (23)

$$0 \le \sigma_{in}^{Q+} \le \overline{\sigma}_{in}^{Q+} \quad \forall i \in \mathcal{I}, n \in N$$
 (24)

$$0 \le \sigma_{ikn}^{Q+} \le \overline{\sigma}_{in}^{Q+} \quad \forall i \in \mathcal{I}, n \in N, k \in \mathcal{K}$$
 (25)

$$0 \le \sigma_{in}^{Q^{-}} \le \overline{\sigma}_{in}^{Q^{-}} \quad \forall i \in \mathcal{I}, n \in N$$
 (26)

$$0 \le \sigma_{ikn}^{Q^-} \le \overline{\sigma}_{in}^{Q^-} \quad \forall i \in \mathcal{I}, n \in N, k \in \mathcal{K}$$
 (27)

$$0 \le \sigma_{en}^{S+} \le \overline{\sigma}_{en}^{S+} \quad \forall e \in E, n \in N \tag{28}$$

$$0 \le \sigma_{ekn}^{S+} \le \overline{\sigma}_{en}^{S+} \quad \forall e \in E, n \in N, k \in \mathcal{K}$$
 (29)

$$0 \le \sigma_{fn}^{S+} \le \overline{\sigma}_{fn}^{S+} \quad \forall f \in F, n \in N \tag{30}$$

$$0 \le \sigma_{fkn}^{S+} \le \overline{\sigma}_{fn}^{S+} \quad \forall f \in F, n \in N, k \in \mathcal{K}$$
(31)

3.2 Primary Optimization Variable Bounds in the Base Case

Bounds on voltage in the base case are given by:

$$\underline{v}_i \le v_i \le \overline{v}_i \quad \forall i \in \mathcal{I}$$
 (32)

Bounds on real power in the base case are given by:

$$p_{g} \le p_{g} \le \overline{p}_{g} \quad \forall g \in G \tag{33}$$

No real power is produced by generators that are not active in the base case:

$$p_g = 0 \quad \forall g \in \mathcal{G} \setminus G \tag{34}$$

Bounds on reactive power in the base case are given by:

$$\underline{q}_g \le q_g \le \overline{q}_g \quad \forall g \in G \tag{35}$$

No reactive power is produced by generators that are not active in the base case:

$$q_q = 0 \quad \forall g \in \mathcal{G} \setminus G \tag{36}$$

Bounds on shunt susceptance in the base case are given by:

$$\underline{b}_{i}^{CS} \le b_{i}^{CS} \le \overline{b}_{i}^{CS} \quad \forall i \in \mathcal{I}$$

$$(37)$$

3.3 Line Flow Definitions in the Base Case

Real and reactive power flows into a line at the origin buses in the base case are defined by:

$$p_e^o = g_e v_{i_e^o}^2 + (-g_e \cos(\theta_{i_e^o} - \theta_{i_e^d}) - b_e \sin(\theta_{i_e^o} - \theta_{i_e^d})) v_{i_e^o} v_{i_e^d} \quad \forall e \in E$$
(38)

$$q_e^o = -(b_e + b_e^{CH}/2)v_{i_e^o}^2 + (b_e \cos(\theta_{i_e^o} - \theta_{i_e^d}) - g_e \sin(\theta_{i_e^o} - \theta_{i_e^d}))v_{i_e^o}v_{i_e^d} \quad \forall e \in E$$
(39)

Real and reactive power flows into a line at the destination buses in the base case are defined by:

$$p_e^d = g_e v_{i_e^d}^2 + (-g_e \cos(\theta_{i_e^d} - \theta_{i_e^o}) - b_e \sin(\theta_{i_e^d} - \theta_{i_e^o})) v_{i_e^o} v_{i_e^d} \quad \forall e \in E$$
(40)

$$q_e^d = -(b_e + b_e^{CH}/2)v_{i_e^d}^2 + (b_e \cos(\theta_{i_e^d} - \theta_{i_e^o}) - g_e \sin(\theta_{i_e^d} - \theta_{i_e^o}))v_{i_e^o}v_{i_e^d} \quad \forall e \in E$$

$$(41)$$

3.4 Transformer Flow Definitions in the Base Case

Real and reactive power flows into a transformer at the origin buses in the base case are defined by:

$$p_f^o = (g_f/\tau_f^2 + g_f^M)v_{i_f^o}^2 + (-g_f/\tau_f\cos(\theta_{i_f^o} - \theta_{i_f^d} - \theta_f) - b_f/\tau_f\sin(\theta_{i_f^o} - \theta_{i_f^d} - \theta_f))v_{i_f^o}v_{i_f^d} \ \forall f \in F$$

$$(42)$$

$$q_f^o = -(b_f/\tau_f^2 + b_f^M)v_{i_f^o}^2 + (b_f/\tau_f\cos(\theta_{i_f^o} - \theta_{i_f^d} - \theta_f) - g_f/\tau_f\sin(\theta_{i_f^o} - \theta_{i_f^d} - \theta_f))v_{i_f^o}v_{i_f^d} \quad \forall f \in F$$
(43)

Real and reactive power flows into a transformer at the destination buses in the base case are defined by:

$$p_f^d = g_f v_{i_f}^2 + (-g_f/\tau_f \cos(\theta_{i_f^d} - \theta_{i_f^o} + \theta_f) - b_f/\tau_f \sin(\theta_{i_f^d} - \theta_{i_f^o} + \theta_f)) v_{i_f^o} v_{i_f^d} \quad \forall f \in F$$

$$(44)$$

$$q_f^d = -b_f v_{i_f^d}^2 + (b_f/\tau_f \cos(\theta_{i_f^d} - \theta_{i_f^o} + \theta_f) - g_f/\tau_f \sin(\theta_{i_f^d} - \theta_{i_f^o} + \theta_f)) v_{i_f^o} v_{i_f^d} \quad \forall f \in F$$
(45)

3.5 Bus Power Balance Constraints in the Base Case

Bus real power balance constraints ensure that all real power output from generators at a given bus sum to all real power flows into other grid components at the bus. Nonegative variables σ_i^{P+} and σ_i^{P-} represent the positive and negative parts of the net imbalance. These constraint violation variables (also called slack variables) appear in the objective with penalty coefficients.

$$\sum_{g \in G_i} p_g - p_i^L - g_i^{FS} v_i^2
- \sum_{e \in E_i^o} p_e^o - \sum_{e \in E_i^d} p_e^d - \sum_{f \in F_i^o} p_f^o - \sum_{f \in F_i^d} p_f^d = \sigma_i^{P+} - \sigma_i^{P-} \quad \forall i \in \mathcal{I}$$
(46)

$$\sigma_i^{P+} \ge 0 \ \forall i \in \mathcal{I}$$
 (47)

$$\sigma_i^{P-} \ge 0 \ \forall i \in \mathcal{I}$$
 (48)

Bus reactive power balance constraints are similar with soft constraint violation variables σ_i^{Q+} and σ_i^{Q-} :

$$\sum_{g \in G_i} q_g - q_i^L - (-b_i^{FS} - b_i^{CS}) v_i^2
- \sum_{e \in E_i^o} q_e^o - \sum_{e \in E_i^d} q_e^d - \sum_{f \in F_i^o} q_f^o - \sum_{f \in F_i^d} q_f^d = \sigma_i^{Q+} - \sigma_i^{Q-} \quad \forall i \in \mathcal{I}$$
(49)

$$\sigma_i^{Q+} \ge 0 \quad \forall i \in \mathcal{I}$$
 (50)

$$\sigma_i^{Q-} \ge 0 \quad \forall i \in \mathcal{I} \tag{51}$$

3.6 Line Current Ratings in the Base Case

Line current ratings in the base case at the origin bus, with soft constraint violation variables σ_e^S , are given by:

$$\sqrt{(p_e^o)^2 + (q_e^o)^2} \le \overline{R}_e v_{i_e^o} + \sigma_e^S \quad \forall e \in E$$

$$(52)$$

$$\sigma_e^S > 0 \ \forall e \in E$$
 (53)

Line current ratings in the base case at the destination bus, with soft constraint violation variables σ_e^S , are given by:

$$\sqrt{(p_e^d)^2 + (q_e^d)^2} \le \overline{R}_e v_{i_e^d} + \sigma_e^S \quad \forall e \in E \tag{54}$$

3.7 Transformer Power Ratings in the Base Case

Transformer power ratings in the base case at the origin bus, with soft constraint violation variables σ_f^S , are given by:

$$\sqrt{(p_f^o)^2 + (q_f^o)^2} \le \overline{s}_f + \sigma_f^S \quad \forall f \in F$$
(55)

$$\sigma_f^S \ge 0 \ \forall f \in F \tag{56}$$

Transformer power ratings in the base case at the destination bus, with soft constraint violation variables σ_f^S , are given by:

$$\sqrt{(p_f^d)^2 + (q_f^d)^2} \le \overline{s}_f + \sigma_f^S \quad \forall f \in F$$

$$(57)$$

3.8 Primary Optimization Variable Bounds in Contingencies

Bounds on voltage in each contingency are given by:

$$\underline{v}_i^K \le v_{ik} \le \overline{v}_i^K \quad \forall k \in \mathcal{K}, i \in \mathcal{I}$$
 (58)

Bounds on real power generation in each contingency are given by:

$$\underline{p}_g \le p_{gk} \le \overline{p}_g \quad \forall k \in \mathcal{K}, g \in G_k \tag{59}$$

No real power is produced by generators that are not active in each contingency:

$$p_{gk} = 0 \quad \forall k \in \mathcal{K}, g \in \mathcal{G} \setminus G_k \tag{60}$$

Bounds on reactive power generation in each contingency are given by:

$$\underline{q}_{g} \le q_{gk} \le \overline{q}_{g} \quad \forall k \in \mathcal{K}, g \in G_{k} \tag{61}$$

No reactive power is produced by generators that are not active in each contingency:

$$q_{gk} = 0 \quad \forall k \in \mathcal{K}, g \in \mathcal{G} \setminus G_k \tag{62}$$

Bounds on shunt susceptance in each contingency are given by:

$$\underline{b}_{i}^{CS} \le b_{ik}^{CS} \le \overline{b}_{i}^{CS} \quad \forall k \in \mathcal{K}, i \in \mathcal{I}$$

$$(63)$$

3.9 Line Flow Definitions in Contingencies

Real and reactive power flows into a line at the origin bus each contingency are defined by:

$$p_{ek}^{o} = g_{e}v_{i_{e}k}^{2} + (-g_{e}\cos(\theta_{i_{e}k} - \theta_{i_{e}k}) - b_{e}\sin(\theta_{i_{e}k} - \theta_{i_{e}k}))v_{i_{e}k}v_{i_{e}k} \ \forall k \in \mathcal{K}, e \in E_{k}$$
(64)

$$q_{ek}^{o} = -(b_e + b_e^{CH}/2)v_{i_e^{o}k}^2 + (b_e \cos(\theta_{i_e^{o}k} - \theta_{i_e^{o}k}) - g_e \sin(\theta_{i_e^{o}k} - \theta_{i_e^{o}k}))v_{i_e^{o}k}v_{i_e^{o}k} \quad \forall k \in \mathcal{K}, e \in E_k$$
(65)

Real and reactive power flows into a line at the destination bus in each contingency are defined by:

$$p_{ek}^{d} = g_{e}v_{i_{e}^{d}k}^{2} + (-g_{e}\cos(\theta_{i_{e}^{d}k} - \theta_{i_{e}^{o}k}) - b_{e}\sin(\theta_{i_{e}^{d}k} - \theta_{i_{e}^{o}k}))v_{i_{e}^{o}k}v_{i_{e}^{d}k} \quad \forall k \in \mathcal{K}, e \in E_{k}$$

$$(66)$$

$$q_{ek}^{d} = -(b_{e} + b_{e}^{CH}/2)v_{i_{e}^{d}k}^{2} + (b_{e}\cos(\theta_{i_{e}^{d}k} - \theta_{i_{e}^{o}k}) - g_{e}\sin(\theta_{i_{e}^{d}k} - \theta_{i_{e}^{o}k}))v_{i_{e}^{o}k}v_{i_{e}^{d}k} \quad \forall k \in \mathcal{K}, e \in E_{k}$$
(67)

3.10 Transformer Flow Definitions in Contingencies

Real and reactive power flows into a transformer at the origin bus in each contingency are defined by:

$$p_{fk}^{o} = (g_f/\tau_f^2 + g_f^M)v_{i_f^o k}^2$$

$$+ (-g_f/\tau_f \cos(\theta_{i_f^o k} - \theta_{i_f^d k} - \theta_f) - b_f/\tau_f \sin(\theta_{i_f^o k} - \theta_{i_f^d k} - \theta_f))v_{i_f^o k}v_{i_f^d k}$$

$$\forall k \in \mathcal{K}, f \in F_k$$

$$(68)$$

$$q_{fk}^{o} = -(b_{f}/\tau_{f}^{2} + b_{f}^{M})v_{i_{f}^{o}k}^{2} + (b_{f}/\tau_{f}\cos(\theta_{i_{f}^{o}k} - \theta_{i_{f}^{d}k} - \theta_{f}) - g_{f}/\tau_{f}\sin(\theta_{i_{f}^{o}k} - \theta_{i_{f}^{d}k} - \theta_{f}))v_{i_{f}^{o}k}v_{i_{f}^{d}k} \forall k \in \mathcal{K}, f \in F_{k}$$
(69)

Real and reactive power flows into a transformer at the destination bus in each contingency are defined by:

$$p_{fk}^{d} = g_f v_{i_f^d k}^2$$

$$+ (-g_f/\tau_f \cos(\theta_{i_f^d k} - \theta_{i_f^o k} + \theta_f) - b_f/\tau_f \sin(\theta_{i_f^d k} - \theta_{i_f^o k} + \theta_f)) v_{i_f^o k} v_{i_f^d k}$$

$$\forall k \in \mathcal{K}, f \in F_k$$

$$(70)$$

$$q_{fk}^{d} = -b_f v_{i_f^d k}^2$$

$$+ (b_f / \tau_f \cos(\theta_{i_f^d k} - \theta_{i_f^o k} + \theta_f) - g_f / \tau_f \sin(\theta_{i_f^d k} - \theta_{i_f^o k} + \theta_f)) v_{i_f^o k} v_{i_f^d k}$$

$$\forall k \in \mathcal{K}, f \in F_k$$

$$(71)$$

3.11 Bus Power Balance Constraints in Contingencies

Bus real power balance constraints in each contingency with soft constraint violation variables σ_{ik}^{P+} and σ_{ik}^{P-} are given by:

$$\sum_{g \in G_{ik}} p_{gk} - p_i^L - g_i^{FS} v_{ik}^2 \\
- \sum_{e \in E_{ik}^o} p_{ek}^o - \sum_{e \in E_{ik}^d} p_{ek}^d - \sum_{f \in F_{ik}^o} p_{fk}^o - \sum_{f \in F_{ik}^d} p_{fk}^d = \sigma_{ik}^{P^+} - \sigma_{ik}^{P^-} \quad \forall k \in \mathcal{K}, i \in \mathcal{I}$$
(72)

$$\sigma_{ik}^{P+} \ge 0 \quad \forall k \in \mathcal{K}, i \in \mathcal{I}$$
 (73)

$$\sigma_{ik}^{P-} \ge 0 \quad \forall k \in \mathcal{K}, i \in \mathcal{I}$$
 (74)

Bus reactive power balance constraints in each contingency with soft constraint violation variables σ_{ik}^{Q+} and σ_{ik}^{Q-} are given by:

$$\sum_{g \in G_{ik}} q_{gk} - q_i^L - (-b_i^{FS} - b_{ik}^{CS}) v_{ik}^2 - \sum_{e \in E_{ik}^o} q_{ek}^o - \sum_{e \in E_{ik}^d} q_{ek}^d - \sum_{f \in F_{ik}^o} q_{fk}^o - \sum_{f \in F_{ik}^d} q_{fk}^d = \sigma_{ik}^{Q+} - \sigma_{ik}^{Q-} \quad \forall k \in \mathcal{K}, i \in \mathcal{I}$$
(75)

$$\sigma_{ik}^{Q+} \ge 0 \quad \forall k \in \mathcal{K}, i \in \mathcal{I}$$
 (76)

$$\sigma_{ik}^{Q-} \ge 0 \quad \forall k \in \mathcal{K}, i \in \mathcal{I}$$
 (77)

3.12 Line Current Ratings in Contingencies

Line current ratings at the origin bus in each contingency with soft constraint violation variables σ_{ek}^{S} are modeled by:

$$\sqrt{(p_{ek}^o)^2 + (q_{ek}^o)^2} \le \overline{R}_e^K v_{i_e^o k} + \sigma_{ek}^S \quad \forall k \in \mathcal{K}, e \in E_k$$

$$(78)$$

$$\sigma_{ek}^S \ge 0 \quad \forall k \in \mathcal{K}, e \in E_k \tag{79}$$

Line current ratings at the destination bus in each contingency with soft constraint violation variables σ_{ek}^S are modeled by:

$$\sqrt{(p_{ek}^d)^2 + (q_{ek}^d)^2} \le \overline{R}_e^K v_{i_e^d k} + \sigma_{ek}^S \quad \forall k \in \mathcal{K}, e \in E_k$$

$$\tag{80}$$

3.13 Transformer Power Ratings in Contingencies

Transformer power ratings in each contingency at the origin bus with soft constraint violation variables $\sigma_f^S k$, are given by:

$$\sqrt{(p_{fk}^o)^2 + (q_{fk}^o)^2} \le \overline{s}_f^K + \sigma_{fk}^S \quad \forall k \in \mathcal{K}, f \in F_k$$
(81)

$$\sigma_{fk}^S \ge 0 \ \forall k \in \mathcal{K}, f \in F_k$$
 (82)

Transformer power ratings in each contingency at the destination bus with soft constraint violation variables $\sigma_f^S k$, are given by:

$$\sqrt{(p_{fk}^d)^2 + (q_{fk}^d)^2} \le \overline{s}_f^K + \sigma_{fk}^S \quad \forall k \in \mathcal{K}, f \in F_k$$
(83)

3.14 Generator Real Power Contingency Response

The real power output p_{gk} of a generator g in a contingency k is subject to constraints linking it to the base case value p_q .

A generator that is online in a contingency but is not selected to respond to that contingency maintains its real power output from the base case:

$$p_{qk} = p_q \quad \forall k \in \mathcal{K}, g \in G_k \setminus G_k^P \tag{84}$$

A generator that does respond to a given contingency adjusts its real power output according to its predefined (offline) participation factor until it hits an operational bound (min or max capacity). The real power output of a responding generator g in contingency k is $p_g + \alpha_g \Delta_k$, if the generator is following its required participation factor. The actual real power output p_{gk} must be equal to this value unless the generator were to violate its min production or maximum capacity. The generator must operate at its lower bound when the predefined participation factor response would force it to violate its min production level and the generator must operate at its maximum capacity when the predefined participation factor response would force it to violate its upper bound.

Given this conceptual definition of generator real power contingency response, we give several mathematical formulations, including a formulation using logical constraints, a formulation using the projection operator, and a big-M mixed integer programming formulation.

3.14.1 Logical Formulation

In this section we formulate generator real power contingency response using a disjunction of linear constraints. This formulation most clearly expresses the constraints that we want to impose on the solution.

$$\left\{ \underline{p}_{g} \leq p_{gk} \leq \overline{p}_{g} \quad \text{and } p_{gk} = p_{g} + \alpha_{g} \Delta_{k} \right\} \quad \text{or}
\left\{ p_{gk} = \overline{p}_{g} \quad \text{and } p_{gk} \leq p_{g} + \alpha_{g} \Delta_{k} \right\} \quad \text{or}
\left\{ p_{gk} = \underline{p}_{g} \quad \text{and } p_{gk} \geq p_{g} + \alpha_{g} \Delta_{k} \right\}$$

$$(85)$$

3.14.2 Projection Formulation

In this section we formulate generator real power contingency response using the projection operator Π . This formulation is equivalent to the logic based presentation in the preceding section but it may not be easy to implement in standard optimization tools.

$$p_{gk} = \prod_{[\underline{p}_g, \overline{p}_g]} (p_g + \alpha_g \Delta_k) \quad \forall k \in \mathcal{K}, g \in G_k^P$$
(86)

Equation (86) is an equivalent reformulation of (85).

3.14.3 Mixed Integer Programming Formulation

In this section, we reformulate the generator real power contingency response using the big-M mixed integer programming (MIP) technique. This approach requires the determination of a large multiplier, the big-M value, and that value must be sufficiently large enough to ensure that the MIP formulation is equivalent to the preceding two formulations. Such an MIP formulation is easier to implement within standard optimization modeling tools. First let M^P and M denote large positive constants, left unspecified here. Then introduce binary variables x_{gk}^{P+} and x_{gk}^{P-} :

$$x_{ak}^{P+} \in \{0,1\} \quad \forall k \in \mathcal{K}, g \in G_k^P \tag{87}$$

$$x_{ak}^{P-} \in \{0,1\} \quad \forall k \in \mathcal{K}, g \in G_k^P \tag{88}$$

Then, equation (89) is written such that it is inactive if $x_{gk}^{P+} = 1$. When $x_{gk}^{P+} = 0$, equations (59,89) force $p_{gk} = \overline{p}_q$.

$$\overline{p}_g - p_{gk} \le M^P x_{gk}^{P+} \quad \forall k \in \mathcal{K}, g \in G_k^P$$
(89)

Equation (90) is written such that it is inactive if $x_{gk}^{P-} = 1$. When $x_{gk}^{P-} = 0$, equations (59,90) force $p_{gk} = \underline{p}_g$.

$$p_{gk} - p_{gk} \le M^P x_{gk}^{P-} \quad \forall k \in \mathcal{K}, g \in G_k^P$$

$$\tag{90}$$

Equation (91) is written such that it is inactive if $x_{gk}^{P+} = 0$. When $x_{gk}^{P+} = 1$, p_{gk} is forced to be equal to or greater than the desired real power response, $p_g + \alpha_g \Delta_k$, dictated by the predefined participation factor, α_g .

$$p_g + \alpha_g \Delta_k - p_{gk} \le M(1 - x_{gk}^{P+}) \quad \forall k \in \mathcal{K}, g \in G_k^P$$

$$\tag{91}$$

Equation (92) is written such that it is inactive if $x_{gk}^{P-} = 0$. When $x_{gk}^{P-} = 1$, p_{gk} is forced to be equal to or less than the desired real power response, $p_g + \alpha_g \Delta_k$, dictated by the predefined participation factor, α_g .

$$p_{gk} - p_g - \alpha_g \Delta_k \le M(1 - x_{gk}^{P-}) \quad \forall k \in \mathcal{K}, g \in G_k^P$$

$$\tag{92}$$

Since there exists \underline{M}^P and \underline{M} such that for all $M^P \geq \underline{M}^P$ and $M \geq \underline{M}$, equations (87, 88, 89, 90, 91, 92) create an equivalent reformulation of (85). Table (3.14.3) shows simplified equations (89, 90, 91, 92) for all combinations of binary variables x_{gk}^{P+} and x_{gk}^{P-} . The gray highlighted cells are the inactive constraints under the specified solution for the binary vriables. The first row, when $x_{gk}^{P+}=1$ and $x_{gk}^{P-}=1$, represents the case when the generator precisely follows the predefined participation factor response, which is the first state described by (85). The second row, when $x_{gk}^{P+}=0$ and $x_{gk}^{P-}=1$, represents the case when the participation factor response would require the generator to violate its maximum capacity; therefore, the generator operates instead at its max output. This is the second state defined by (85). The third row, when $x_{gk}^{P+}=1$ and $x_{gk}^{P-}=0$, represents the case when the participation factor response would require the generator to violate its minimum capacity; therefore, the generator operates instead at its min output. This is the third and final state defined by (85). The last row represents an invalid (infeasible) solution for the binary variables; based on the defined equations, it is not possible for both binary variables to take on a value of zero. This infeasibility is directly imposed as can be seen by the resulting inequalities in the last row that simultaneously force the generator's real power production to be below its min capacity and above its max capacity. Entrants may choose to add a combinatorial cut that directly excludes this state, though such a constraint is not necessary to obtain a valid solution.

Table 9: Equations (89, 90, 91, 92) under all combinations of binary variables x_{gk}^{P+} and x_{gk}^{P-} values. All equations in Table (3.14.3) are written $\forall k \in \mathcal{K}, g \in G_k^P$. M^P and M are sufficiently large such that when they appear in the simplified equations (89, 90, 91, 92), the constraints will not be binding in any feasible solution; these constraints have been shaded gray in Table (3.14.3).

,	<i>J</i>		\			
	x_{gk}^{P+}	x_{gk}^{P-}	(89)	(90)	(91)	(92)
	1	1	$p_{gk} \ge -M^P + \overline{p}_g$	$p_{gk} \le M^P + \underline{p}_g$	$p_{gk} \ge p_g + \alpha_g \Delta_k$	$p_{gk} \le p_g + \alpha_g \Delta_k$
	0	1	$p_{gk} \ge \overline{p}_g$	$p_{gk} \le M^P + \underline{p}_g$	$p_{gk} \ge -M + p_g + \alpha_g \Delta_k$	$p_{gk} \le p_g + \alpha_g \Delta_k$
	1	0	$p_{gk} \ge -M^P + \overline{p}_g$	$p_{gk} \leq \underline{p}_g$	$p_{gk} \ge p_g + \alpha_g \Delta_k$	$p_{gk} \le M + p_g + \alpha_g \Delta_k$
	0	0	$p_{gk} \ge \overline{p}_g$	$p_{gk} \leq \underline{p}_q$	$p_{gk} \ge -M + p_g + \alpha_g \Delta_k$	$p_{gk} \le M + p_g + \alpha_g \Delta_k$

3.15 Generator Reactive Power Contingency Response

A generator g that is active during a contingency k tries to maintain the base case (precontingency) voltage magnitude at its bus, i_g , by adjusting its reactive power output. The generator will do all that it can to maintain this voltage magnitude. If the bus voltage magnitude drops below its base case magnitude, then the generator reactive power must be at its upper bound, reflecting that it has exhausted its ability to increase voltage. Similarly if the bus voltage magnitude is higher than the base case magnitude, then the generator reactive power must be at its lower bound. In power systems, this is referred to as PV/PQ switching; the generator's bus is providing adequate voltage control then it is acting as a PV bus as there is sufficient reactive power to maintain the voltage. If there is insufficient reactive power to maintain the voltage, the bus is deemed to be a PQ bus in this case and the reactive power injection is fixed (in this special case, the reactive power is fixed to either the generator's reactive power lower or upper bound).

Given this conceptual definition of generator reactive power contingency response, we give several mathematical formulations, including a formulation using logical constraints, a formulation using min and max functions, and a big-M mixed integer programming formulation.

3.15.1 Formulation with Logical Constraints

In this section, we formulate generator reactive power contingency response using a disjunction of linear constraints.

$$\left\{ \underline{q}_{g} \leq q_{gk} \leq \overline{q}_{g} \quad \text{and } v_{igk} = v_{ig} \right\} \quad \text{or}
\left\{ q_{gk} = \overline{q}_{g} \quad \text{and } v_{igk} \leq v_{ig} \right\} \quad \text{or}
\left\{ q_{gk} = \underline{q}_{g} \quad \text{and } v_{igk} \geq v_{ig} \right\}$$

$$(93)$$

3.15.2 Formulation with Min and Max Operators

In this section, we formulate generator reactive power contingency response using min and max functions.

$$\min\{\max\{0, v_{i_q} - v_{i_q k}\}, \max\{0, \overline{q}_q - q_{g k}\}\} = 0 \quad \forall k \in \mathcal{K}, g \in G_k$$
(94)

$$\min\{\max\{0, v_{i_g k} - v_{i_g}\}, \max\{0, q_{g k} - \underline{q}_{g}\}\} = 0 \quad \forall k \in \mathcal{K}, g \in G_k$$
(95)

Equations (94, 95) are an equivalent reformulation of (93).

3.15.3 Formulation with Binary Variables

In this section, we formulate generator reactive power contingency response using the big-M mixed integer programming technique. First let M^Q and M^v be large positive constants. Then introduce binary variables x_{qk}^{Q+} and x_{qk}^{Q-} :

$$x_{gk}^{Q+} \in \{0,1\} \quad \forall k \in \mathcal{K}, g \in G_k \tag{96}$$

$$x_{qk}^{Q-} \in \{0,1\} \quad \forall k \in \mathcal{K}, g \in G_k \tag{97}$$

Then equation (98) is written such that it is inactive if $x_{ik}^{Q+} = 1$. When $x_{ik}^{Q+} = 0$, equations (61,98) force $q_{gk} = \overline{q}_q$.

$$\overline{q}_g - q_{gk} \le M^Q x_{qk}^{Q+} \quad \forall k \in \mathcal{K}, g \in G_k$$

$$\tag{98}$$

Equation (99) is written such that it is inactive if $x_{ik}^{Q^-} = 1$. When $x_{ik}^{Q^-} = 0$, equations (61,99) force $q_{gk} = \underline{q}_g$.

$$q_{gk} - \underline{q}_g \le M^Q x_{gk}^{Q^-} \quad \forall k \in \mathcal{K}, g \in G_k$$

$$\tag{99}$$

The following two equations then handle the voltage.

Equation (100) is inactive if $x_{ik}^{Q+} = 0$. When $x_{ik}^{Q+} = 1$, v_{igk} is bounded below by v_{ig} .

$$v_{i_g} - v_{i_g k} \le M^v (1 - x_{g k}^{Q+}) \quad \forall k \in \mathcal{K}, g \in G_k$$
 (100)

For equation (101), it is inactive if $x_{ik}^{Q-} = 0$. When $x_{ik}^{Q-} = 1$, v_{igk} is bounded above by v_{ig} .

$$v_{i_q k} - v_{i_q} \le M^v (1 - x_{q k}^{Q^-}) \quad \forall k \in \mathcal{K}, g \in G_k$$

$$\tag{101}$$

Since there exists \underline{M}^Q and \underline{M}^v such that for all $M^Q \geq \underline{M}^Q$ and $M^v \geq \underline{M}^v$, the equations (96, 97, 98, 99, 100, 101) are an equivalent reformulation of (93). Table (3.15.3) shows simplified equations (98, 99, 100, 101) for all combinations of binary variables x_{gk}^{P+} and x_{gk}^{P-} . The gray highlighted cells are the inactive constraints under the specified solution for the binary variables.

The first row, when $x_{gk}^{Q^+} = 1$ and $x_{gk}^{Q^-} = 1$, the generator has sufficient enough reactive power support to maintain the bus voltage magnitude at the pre-contingency voltage set point, i.e., $v_{i_gk} = v_{i_g}$; this corresponds to the first state described by (93). The second row represents the second state in (93); with $x_{gk}^{Q^+} = 0$ and $x_{gk}^{Q^-} = 1$, $q_{gk} = \overline{q}_g$ due to (61,98) and v_{i_gk} must be bounded above by v_{i_g} , (101), signifying that the generator ran out of reactive

Table 10: Equations (3.15.3) shows simplified equations (98, 99, 100, 101) under all combinations of binary variables x_{gk}^{Q+} and x_{gk}^{Q-} values. All equations in Table (3.15.3) are written $\forall k \in \mathcal{K}, g \in G_k$. M^Q and M^v are sufficiently large such that when appear in the simplified equations (3.15.3) shows simplified equations (98, 99, 100, 101), the constraints will not be binding in any feasible solution; these constraints have been shaded gray in Table (3.15.3).

x_{gk}^{Q+}	x_{gk}^{Q-}	(98)	99)	(100)	(101)
1	1	$q_{gk} \ge -M^Q + \overline{q}_g$	$q_{gk} \le M^Q + \underline{q}_g$	$v_{i_g k} \ge v_{i_g}$	$v_{i_g k} \le v_{i_g}$
0	1	$q_{gk} \ge \overline{q}_g$	$q_{gk} \le M^Q + \underline{q}_g$	$v_{i_g k} \ge -M^v + v_{i_g}$	$v_{i_g k} \le v_{i_g}$
1	0	$q_{gk} \ge -M^Q + \overline{q}_g$	$q_{gk} \le \underline{q}_g$	$v_{i_g k} \ge v_{i_g}$	$v_{i_g k} \le M^v + v_{i_g}$
0	0	$q_{gk} \ge \overline{q}_g$	$q_{gk} \leq \underline{q}_g$	$v_{i_g k} \ge -M^v + v_{i_g}$	$v_{i_g k} \le M^v + v_{i_g}$

power support and could not maintain the post-contingency bus voltage magnitude at the pre-contingency voltage set point. The third row represents the third state in (93); with $x_{gk}^{Q^+} = 1$ and $x_{gk}^{Q^-} = 0$, $q_{gk} = \underline{q}_g$ due to (61,99) and v_{igk} must be bounded below by v_{ig} , (100), signifying that the generator could not reduce the post-contingency bus voltage magnitude to the pre-contingency voltage set point. The last row represents an invalid (infeasible) solution for the binary variables; based on the defined equations, it is not possible for both binary variables to take on a value of zero. This infeasibility is directly imposed as can be seen by the resulting inequalities in the last row that simultaneously force the generator's reactive power production to be below its min capacity and above its max capacity. Entrants could choose to add a combinatorial cut that directly excludes this state, though such a constraint is not necessary to obtain a valid solution.

3.16 Optimization Model

The objective is to minimize c.

The variables are: $(c, c_g, c^{\sigma}, c_k^{\sigma}, t_{gh}, \Delta_k, v_i, \theta_i, b_i^{CS}, \sigma_i^{P+}, \sigma_i^{P-}, \sigma_i^{Q+}, \sigma_i^{Q-}, \sigma_e^{S}, \sigma_f^{S}, p_g, q_g, p_e^{o}, p_e^{d}, q_e^{o}, q_e^{d}, p_f^{o}, p_f^{d}, q_f^{o}, q_f^{d}, v_{ik}, \theta_{ik}, b_{ik}^{CS}, \sigma_{ik}^{P+}, \sigma_{ik}^{P-}, \sigma_{ik}^{Q+}, \sigma_{ik}^{Q-}, \sigma_{ek}^{S}, \sigma_{fk}^{S}, p_{gk}, q_{gk}, p_{ek}^{o}, p_{ek}^{d}, q_{ek}^{o}, q_{ek}^{d}, p_{fk}^{o}, p_{fk}^{d}, q_{fk}^{o}, q_{fk}^{d}).$

The constraints are: (1, 2, 3, 4, 5, 6, 7, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 80, 78, 79, 81, 82, 83, 84, 85, 93).

3.17 Deviations from the Focused Formulation Presented in ARPA-E DE-FOA-0001952

The formulation presented in ARPA-E DE-FOA-0001952 served to give applicants an idea of the structure of the full formulation presented here. In general, this official formulation expands upon the focused formulation presented in ARPA-E DE-FOA-0001952 by including transformers and shunt elements and providing detailed mathematical structure for generator real and reactive power response to contingencies. However, this formulation incorporates some notational deviations from the focused formulation presented in ARPA-E DE-FOA-0001952, which are noted below.

- 1. In the focused formulation presented in ARPA-E DE-FOA-0001952, slack variables representing soft constraint violations are represented by s_{\square}^{\square} . In this formulation, these variables are represented by $\sigma_{\square}^{\square}$.
- 2. In the focused formulation presented in ARPA-E DE-FOA-0001952, the objective function explicitly contains cost terms for real power generation in the base case as well as explicitly contains penalties for nodal real and reactive power violations and branch overloading in the base case and contingencies. In this formulation, the objective function includes the cost of real power generation in the base case (c_g) as well as dummy variables for the cost of real and reactive nodal violations and branch overloading in the base case (c^{σ}) and the cost of real and reactive nodal violations and branch overloading in the contingencies (c_k^{σ}) . The dummy variables c^{σ} and c_k^{σ} are explicitly defined in equations (6) and (7).
- 3. In the focused formulation presented in ARPA-E DE-FOA-0001952, superscripts + and are used to represent origin (+) and destination (-) buses. In this formulation, the superscripts o and d are used to denote origin (o) and destination (d) buses.

A Input Data Format

A.1 Introduction

The Grid Optimization Competition (GO Competition) Challenge 1 uses a set of four files for the input data of each problem instance. The input files are formatted according to industry standard data file formats used with a popular power system software package. This section gives a description of these formats. This information is intended for use by GO Competition Challenge 1 Entrants. The industry standard data formats include some data elements that are not used by the GO Competition Challenge 1 and do not otherwise need to be understood by Entrants. These elements are not described in detail, so this section cannot be viewed as a full format specification of the industry standard formats. Rather it is a format specification of the aspects of these formats that are relevant to the GO Competition Challenge 1.

A.1.1 Input Data Files

The data for each problem instance are contained in the following input data files:

```
case.raw Power Flow Raw Data File (RAW)
case.rop Generator Cost Data File (ROP)
case.inl Unit Inertia and Governor Response Data File (INL)
case.con Contingency Description Data File (CON)
```

A.1.2 General Format of Data Files

Each data file is structured as a sequence of one or more data sections in a fixed order. The RAW and ROP data files have multiple sections, the INL and CON files have only one. Each section is a table. Each section table has a number of records. Each record has a number of lines. Typically, each record has exactly one line, and exceptions to this are identified in this document. Each line is a comma-separated list of fields, ending with a newline or endline character after the last field, not a comma. Blank space characters within a line are ignored. Each field can be either a number or a string enclosed in matching quotes. The end of each section is indicated by a line with initial character '0' (numeric zero), although this is not strictly enforced for the last section which may terminate with an end of file. In some cases

a line with an initial character '0' does not mark the end of a section but instead constitutes actual data, and these exceptions are identified in this document. The sections appear in a prescribed order, and empty sections are not skipped. The multi-section data files are terminated by a line with initial character 'Q', although this too is not strictly enforced and the file may simple terminate with end of file.

The CON file is somewhat different. The multi-line records are terminated with the characters END in columns 1-3 instead of an initial zero. Like the INL file, it too is just one section and therefore no section end line is required but the last line may be END. It uses string tokens separated by spaces. Keywords are used to structure each record and each line in each record. Commas and quote marks are not needed and therefore are not permitted.

A.1.3 Restrictions on Data File Formats Imposed by the GO Competition Challenge 1

The standard data file formats allow for many alternatives. As much as possible these alternatives are not allowed by the GO Competition Challenge 1.

Many features of the standard format are not used by the GO Competition Challenge 1. These include certain data sections, fields, and flag values. Features that are not used by the GO Competition Challenge 1 are identified as such in this document.

The standard format provides default values for some fields. The GO Competition Challenge 1 does not use default values, so fields whose values are used by the GO Competition Challenge 1 are not left blank. String fields that are not used by the GO Competition Challenge 1 are filled by an empty string (''). Numeric fields that are not used by the GO Competition Challenge 1 are filled by a digit 0.

The standard format allows fields to be separated by commas or spaces. The GO Competition Challenge 1 uses only comma separators, not spaces. The Contingency Case Description Data File is an exception, as it uses spaces as token separators.

The standard format allows strings to be enclosed in matching single quotes or in matching double quotes. The GO Competition Challenge 1 uses matching single quotes only. The Contingency Case Description Data File is an exception, as the string tokens do not contain spaces or special characters, and therefore need not be enclosed by quotes, so the GO Competition Challenge 1 requires that no quotes be used here.

The standard format allows for strings to be used instead of numbers in some fields containing names or identifiers of power system elements. For the purposes of the GO Competition Challenge 1, all fields allowed by the standard format to be numbers must be numbers. String fields are identified as such in this document.

A.1.4 Notation Used in Input Data Format Description

Individual data items are annotated in this document to indicate special ways they are to be treated.

- * An asterisk (*) is used to indicate that a particular data item is used by the GO Competition Challenge 1.
- X A field name is underlined to indicate that the field is a key field in the table being described. Concatenating all key fields in a given table record yields a single key so each record in the table has a unique key. For example, the key fields in the Generator Data section are I and ID, so each generator has a unique value of (I, ID), though two different generators may have the same value of I or the same value of ID.
- ' 'A field name is enclosed in matching single quotes (' ') to indicate that the field contains string data.
- ¹ A field name is enclosed in matching single quotes ('') with a preceding superscript 1 if the field contains short string data, i.e. a string of one or two characters, all upper case letters or digits.
- Field names are separated by commas (,) in the description of the table format to indicate that fields are separated by commas in the table. The Contingency Description Data File uses tokens separated by spaces, not commas, so commas are not used in the description of its format.

Please note that not all data items mentioned in the following sections are used by the GO Competition Challenge 1. Fields which are not used by the Go Competition Challenge 1 are not marked with an asterisk and can be ignored by Entrants. They are listed in this document because they are fields in the input files.

A.1.5 Reading the Data Files

The general structure of the data files, together with the restrictions placed by the GO Competition Challenge 1, imply that the data files can be read easily by CSV packages in a variety of programming languages. We note, for example, the CSV packages used by Python and Julia, Java has equivalent options, and MATLAB has csvread (though this is limited to numeric data only, and entrants would need to work around this restriction). The GO Competition team has written a Python module, data.py, to read and parse these files.

This code is available to entrants at https://gocompetition.energy.gov/challenges/challenge-1/evaluation/. This code is also used by the solution evaluation procedure.

A.2 Power Flow Raw Data File (case.raw)

The sections (data tables) are:

```
*Case Identification Data
```

Area Interchange Data

Two-Terminal DC Transmission Line Data

Voltage Source Converter (VSC) DC Transmission Line Data

Transformer Impedance Correction Tables

Multi-Terminal DC Transmission Line Data

Multi-Section Line Grouping Data

Zone Data

Interarea Transfer Data

Owner Data

FACTS Device Data

*Switched Shunt Data

GNE Device Data

Induction Machine Data

^{*}Bus Data

^{*}Load Data

^{*}Fixed Bus Shunt Data

^{*}Generator Data

^{*}Non-Transformer Branch Data

^{*}Transformer Data

A.2.1 Case Identification Data

The Case Identification Data section consists of a single record with exactly 3 lines, in the following format:

IC, *SBASE, REV, XFRRAT, NXFRAT, BASFRQ 'CASELINE2' 'CASELINE3'

The Case Identification Data fields are:

IC -

*SBASE System MVA base, in MVA.

REV -

XFRRAT -

NXFRAT -

BASFRQ -

'CASELINE2' -

'CASELINE3' -

A.2.2 Bus Data

Each bus in the system is described by a bus record with the following format:

*I, 'NAME', BASKV, IDE, *AREA, ZONE, OWNER, *VM, *VA, *NVHI, *NVLO, *EVHI, *EVLO

The Bus Data fields are:

*I Bus number Allowable range integer 1 through 999997. Referenced by fields I, J, and BUS in the Load Data (Section A.2.3), Fixed Bus Shunt Data (Section A.2.4), Generator Data (Section A.2.5), Non-Transformer Branch Data (Section A.2.6), Transformer Data (Section A.2.7), Switched Shunt Data (Section A.2.8), and Generator Dispatch Units (Section A.3.1) sections, the Unit Inertia and Governor Response Data File (Section A.4), and the Branch Out-of-Service Event (Section A.5.1), and Generator Out-of-Service Event (section A.5.2), records.

'NAME' -

BASKV -

IDE -

*AREA Area number of the area containing bus I. Positive integer.

ZONE -

OWNER -

*VM bus voltage magnitude in pu.

*VA bus voltage angle in degrees.

*NVHI Normal voltage magnitude high limit in pu.

*NVLO Normal voltage magnitude low limit in pu.

*EVHI Emergency voltage magnitude high limit in pu.

*EVLO Emergency voltage magnitude low limit in pu.

A.2.3 Load Data

Each load record has the following format:

 $^*\underline{I},$ $^{*1}^.\underline{ID}^.,$ *STATUS, AREA, ZONE, *PL, *QL, IP, IQ, YP, YQ, OWNER, SCALE, INTRPT

The Load Data fields are:

*<u>I</u> Bus number. Refers to field I in the Bus Data section (Section A.2.2).

*1'<u>ID</u>' Identifier. One- or two-character string used to distinguish among multiple

loads at a single bus.

*STATUS status, binary. 1 indicates in service, 0 out of service.

AREA -

ZONE -

*PL Active power component of constant power load, in MW.

*QL Reactive power component of constant power load, in Mvar.

IP -

IQ –

YP -

YQ -

OWNER -

SCALE -

INTRPT -

A.2.4 Fixed Bus Shunt Data

Each fixed shunt is represented by a record in the following format:

The Fixed Bus Shunt Data fields are:

*I Bus number. Refers to field I in the Bus Data section (Section A.2.2).

*1'<u>ID</u>' Identifier. One- or two-character string used to distinguish among multiple fixed shunts at a single bus.

- *STATUS binary status indicator, 1 indicating in service, 0 out of service.
- *GL Active component of shunt admittance to ground, in MW at 1 pu voltage.
- *BL Reactive component of shunt admittance to ground, in Mvar at 1 pu voltage.

A.2.5 Generator Data

Each generator is represented by a record in the following format:

```
*<u>I</u>, *1'<u>ID</u>', *PG, *QG, *QT, *QB, VS, IREG, MBASE, ZR, ZX, RT, XT, GTAP, *STAT, RMPCT, *PT, *PB, O1, F1, O2, F2, O3, F3, O4, F4, WMOD, WPF
```

The Generator Data fields are:

- *I bus number. Refers to field I in the Bus Data section (section A.2.2).
- *1'<u>ID</u>' identifier. one- or two-character string used to distinguish among multiple generators at a bus. Referenced by fields ID and GENID in the Generator Dispatch Units section (Section A.3.1), the Unit Inertia and Governor Response Data File (Section A.4), and the Generator Out-of-Service Event record (Section A.5.2).
- *PG generator real power output, in MW.
- *QG generator reactive power output, in MVar.
- *QT maximum generator reactive power output, in Mvar.
- *QB minimum generator reactive power output, in Mvar.
- VS -
- IREG -
- MBASE -
- ZR -
- ZX -
- RT -

XT GTAP *STAT generator status, binary. 1 indicates in service, 0 out of service. RMPCT *PTmaximum generator active power output, MW.

*PB minimum generator active power output, MW.

O1 F1O2F2

F3

О3

04 F4

WMOD WPF

A.2.6 Non-Transformer Branch Data

Each non-transformer branch is represented by a record in the following format:

*<u>I</u>, *<u>J</u>, *1'<u>CKT</u>', *R, *X, *B, *RATEA, RATEB, *RATEC, GI, BI, GJ, BJ, *ST, MET, LEN, O1, F1, O2, F2, O3, F3, O4, F4

The Non-Transformer Branch Data fields are:

- $\underline{\mathrm{I}}^*$ origin bus number. Refers to field I in the Bus Data section (Section A.2.2).
- $*_{\underline{J}}$ destination bus number. not equal to I. Refers to field I in the Bus Data section (Section A.2.2).

*1'CKT' circuit identifier. one- or two-character string used to distinguish among multiple branches between I and J. Referenced by field CKT in the Branch Out-of-Service record (Section A.5.1). If the first character of CKT is one of @, *, >, then the branch is treated in a special way. the GO Competition Challenge 1 does not use these special treatments, and CKT should be consistent with this. Among all branches (non-transformer or transformer) between buses I and J (from I to J or from J to I), the value of CKT identifies each branch uniquely.

*R branch resistance, pu.

*X branch reactance, pu. allowable range nonzero real numbers.

*B total branch charging susceptance, pu.

*RATEA line rating in the base case, current expressed as MVA at bus base voltage of origin and destination buses. Origin and destination buses of a non-transformer branch must have equal base voltages.

RATEB -

* RATEC line rating in contingency cases, current expressed as MVA at bus base voltage of origin and destination buses. Origin and destination buses of a non-transformer branch must have equal base voltages.

GI -

BI –

GJ -

BJ -

*ST status, binary. 1 indicates in service, 0 out of service.

MET -

LEN -

O1 –

F1 -

O2 -

F2 -

O3 –

F3 -

O4 -

F4 -

A.2.7 Transformer Data

Any three-winding transformer can be represented as a configuration of two-winding transformers, and all three-winding transformers present in the problem instances considered by GOComp are represented in this way. Therefore the RAW data file will contain only two-winding transformers, and the data formant of a three-winding transformer is not described here.

Each (two-winding) transformer is represented by a record consisting of four lines of data in the following format:

```
*<u>I</u>, *<u>J</u>, K, *1'<u>CKT</u>', CW, CZ, CM, *MAG1, *MAG2, NMETR, 'NAME', *STAT, O1, F1, O2, F2, O3, F3, O4, F4, 'VECGRP'
```

*R12, *X12, SBASE12

*WINDV1, NOMV1, *ANG1, *RATA1, RATB1, *RATC1, COD1, CONT1, RMA1, RMI1, VMA1, VMI1, NTP1, TAB1, CR1, CX1, CNXA1

*WINDV2, NOMV2

The Transformer Data fields are:

$*\underline{\mathrm{I}}$	origin (winding 1) bus number. References field I in the Bus Data section
	(Section A.2.2).

*<u>J</u> destination (winding 2) bus number. References field I in the Bus Data section (Section A.2.2).

K -

*1'CKT' circuit identifier. one- or two-character string used to distinguish among multiple branches between I and J. Referenced by field CKT in the Branch Out-of-Service record (Section A.5.1).

CW – CZ –

CM -

*MAG1 transformer magnetizing conductance connected to ground at bus I, in pu on system MVA base

*MAG2transformer magnetizing susceptance connected to ground at bus I, in pu on system MVA base **NMETR** 'NAME' *STAT status, binary. 1 indicates in service, 0 out of service. O1 F1O2F2О3 F3 04 F4'VECGRP' *R12 transformer resistance, in pu on system MVA base and winding voltage *X12 transformer reactance, in pu on system MVA base and winding voltage base SBASE12 winding 1 off-nominal turns ratio in pu of winding 1 bus voltage base. *WINDV1 NOMV1 *ANG1 winding 1 phase shift angle in degress. allowable range (-180.0, 180.0]*RATA1 winding 1 three-phase power rating, in MVA RATB1 * RATC1 three-phase power rating in contingencies, in MVA COD1 CONT1 RMA1 RMI1 VMA1 VMI1 NTP1

TAB1

CR1 – CX1 –

CNXA1

*WINDV2 winding 2 off-nominal turns ratio in pu of winding 2 bus voltage base.

NOMV2 -

A.2.8 Switched Shunt Data

Each switched shunt (i.e. a bus with a set of switched shunt blocks connected to it) is represented by a record in the following format:

```
*<u>I</u>, MODSW, ADJM, *STAT, VSWHI, VSWLO, SWREM, RMPCT, 'RMIDNT', *BINIT, *N1, *B1, *N2, *B2, *N3, *B3, *N4, *B4, *N5, *B5, *N6, *B6, *N7, *B7, *N8, *B8
```

The Switched Shunt Data fields are:

*I bus number of bus that this shunt is connected to. References field I in the Bus Data section (Section A.2.2).

MODSW -

ADJM -

*STAT status, binary. 1 indicates in service, 0 out of service.

VSWHI –
VSWLO –
SWREM –
RMPCT –
'RMIDNT' –

*BINIT Initial switched shunt susceptance, in Mvar at unit voltage

*N1 number of steps in block 1, nonnegative integer

*B1	susceptance of each step in block 1, in Mvar at unit voltage $$
*N2	number of steps in block 2, nonnegative integer
*B2	susceptance of each step in block 2, in Mvar at unit voltage
*N3	number of steps in block 3, nonnegative integer
*B3	susceptance of each step in block 3, in Mvar at unit voltage
*N4	number of steps in block 4, nonnegative integer
*B4	susceptance of each step in block 4, in Mvar at unit voltage
*N5	number of steps in block 5, nonnegative integer
*B5	susceptance of each step in block 5, in Mvar at unit voltage
*N6	number of steps in block 6, nonnegative integer
*B6	susceptance of each step in block 6, in Mvar at unit voltage
*N7	number of steps in block 7, nonnegative integer
*B7	susceptance of each step in block 7, in Mvar at unit voltage
*N8	number of steps in block 8, nonnegative integer
*B8	susceptance of each step in block 8, in Mvar at unit voltage

A.3 Generator Cost Data File (case.rop)

Sections:

Modification Code

Bus Voltage Attributes

Adjustable Bus Shunts

Bus Loads

Adjustable Bus Load Tables

*Generator Dispatch Units

*Active Power Dispatch Tables

Generator Reserve Units

Generation Reactive Capability

Adjustable Branch Reactance

*Piecewise Linear Cost Curve Tables

Piecewise Quadratic Cost Curve Tables

Polynomial & Exponential Cost Curve Tables

Period Reserves

Branch Flows

Interface Flows

Linear Constraint Dependencies

A.3.1 Generator Dispatch Units

Each generator dispatch data record is in the following format:

*BUS, *1'GENID', DISP, *DSPTBL

The fields are

*BUS Bus number. Refers to field I in the Bus Data section (Section A.2.2)

*1'GENID' 1- or 2- character string used to identify a generator at a bus having

multiple generators

DISP -

*DSPTBL Active power dispatch table number, positive integer, refers to field TBL in

the Active Power Dispatch Tables section (Section A.3.2)

A.3.2 Active Power Dispatch Tables

Each active power dispatch table record is in the following format:

*TBL, PMAX, PMIN, FUELCOST, CTYP, STATUS, *CTBL

The fields are:

*TBL active power dispatch table number, positive integer. Referenced by

DSPTBL field in Generator Dispatch Units section (Section A.3.1).

PMAX -

PMIN -

FUELCOST -

CTYP – STATUS –

*CTBL Cost curve table number, positive integer, refers to field LTBL in the

Piecewise Linear Cost Curve Tables section (Section A.3.3), referenced by field DSPTBL in the Generator Dispatch Units section (Section A.3.1).

A.3.3 Piecewise Linear Cost Curve Tables

Each piecewise linear cost curve table record is a multiline record in the following format:

```
*LTBL, 'LABEL', *NPAIRS
```

*X1, *Y1

. . .

*XN, *YN

where the number of lines is NPAIRS + 1. The fields are:

LTBL Piecewise linear cost table number. Positive integer referenced by field CTBL in the Active Power Dispatch Tables section (Section A.3.2)

'LABEL' -

NPAIRS Number of points (X,Y) on the cost function provided in this record, positive integer

Xi X-coordinate of pair i in 1, ..., NPAIRS, in MW. Note that Xi may take the value 0. This does not indicate a section end line. The value of NPAIRS indicates the number of lines containing (Xi, Yi), and therfore the number of lines in which an initial character '0' does not indicate a section end line.

Yi Y-coordinate of pair i in 1, ..., NPAIRS, in USD/h

A.4 Unit Inertia and Governor Response Data File (case.inl)

There is just one section. Each nonzero generator participation factor is listed in a record in the following format:

The fields are:

 $*\underline{I}$ bus number. Refers to field I in Bus Data section (Section A.2.2).

*1'<u>ID</u>' identifier. Refers to field ID in Generator Data section (Section A.2.5).

H -

PMAX -

PMIN -

*R Governor permanent droop, in pu on MBASE base. Nonnegative real number. Note: In the industry standard data format adopted by the GO Competition, this field is referred to as governor permanent droop, and its value is expressed in the per unit convention. However the GO Competition treats this field as a dimensionless real number and takes it as the participation factor α_g for generator g = (I, ID) in post-contingency redispatch.

D –

A.5 Contingency Description Data File (case.con)

The contingency description data file consists of multiple lines of text. The text consists of string tokens separated by blank space. The string tokens do not contain blank space, so no quotation marks are needed or allowed. This file can be read as CSV with blank space as the separator.

Each string token is either a keyword or a data field. The keywords valid for this data format (with those used by the GO Competition Challenge 1 indicated by *), are:

*CONTINGENCY

*END

DISCONNECT

*OPEN

TRIP

*BRANCH

LINE

*FROM

*BUS

 $^{*}TO$

*CIRCUIT

CKT

CLOSE

THREEWINDING

AT

MULTITERMDC VSCDC FACTS SET MWAMPS KV **GENERATION** LOAD SHUNT PERCENT DISPATCH MVAR CHANGE ALTER MODIFY ВҮ INCREASE RAISE DECREASE REDUCE MOVE *REMOVE MACHINE INDUCMACHINE *UNIT ADD SWSHUNT TIE

SINGLE

BREAKER

BLOCK

TWOTERMDC

DOUBLE
BUSDOUBLE
PARALLEL
IN
AREA
ZONE
OWNER
SYSTEM
SUBSYSTEM
3WLOWVOLTAGE
SKIP
Each contingency case is defined in a block structure, which consists of $N+2$ lines of text where N is an integer in $\{0,\ldots,32\}$, in the following format:
Start Line
Event Line 1
•••
Event Line N
End Line
The line after a contingency End Line can be either: (1) another contingency Start Line indicating the start of a new contingency, or (2) another End Line indicating the end of the Contingency Case Description Data File.
The format of an End Line is
END

The format of a Start Line is

CONTINGENCY *LABEL

The non-keyword Start Line and fields are:

*LABEL contingency case identifier, unquoted string

Event lines can take several different formats. the GO Competition Challenge 1 uses only a narrow set of formats, corresponding to the following types of events:

Branch Out-of-Service Event

Generator Out-of-Service Event

The GO Competition Challenge 1 uses only contingencies defined by either exactly one generator outage, or exactly one line outage, or exactly one transformer outage. Therefore each contingency case has at most 1 event line.

A.5.1 Branch Out-of-Service Event

A non-transformer or two-winding transformer branch may be placed out of service with an event line in the following format:

OPEN BRANCH FROM BUS *I TO BUS *J CIRCUIT *1 CKT

The branch out-of-service event fields are:

- *I origin bus number. Refers to field I in Bus Data section (Section A.2.2).
- *<u>J</u> destination bus number. Refers to field I in Bus Data section (Section A.2.2).
- *1<u>CKT</u> circuit identifier, 1- or 2-character string with only digits and upper case letters. Refers to field CKT in Non-transformer Branch Data (Section A.2.6) and Transformer Data (Section A.2.7) sections.

A.5.2 Generator Out-of-Service Event

A generator can be placed out of service by an event line in the following format:

REMOVE UNIT *1<u>ID</u> FROM BUS *<u>I</u>

The generator out-of-service event fields are:

- *I bus number. Refers to field I in Bus Data section (Section A.2.2).
- *1<u>ID</u> generator identifier within bus I. Refers to field ID in Generator Data section (Section A.2.5).

B Data Construction Reference Table

Sections (C) and (D) contain detailed instructions on the construction of the data of the competition problem formulation from the input data files. In this section we give a convenient summary of these instructions. For each data item in the competition problem formulation, Table (49) supplies references to the equations and sections of this document containing these instructions. Not all symbols used have an explicit definition provided in this document, and no reference is given for these.

Table 49: Index to detailed parameter definitions

Symbol	Defining equations, tables, and text
$\mathcal A$	Equations (111, 114)
${\cal E}$	Equations (105, 140)
${\cal F}$	Equations (107, 149)
${\cal G}$	Equations (103, 130)
${\cal H}$	Equations (109, 170)
${\cal I}$	Equations (102, 113)
$\mathcal K$	Equations (110, 174)
$\mathcal N$	Equation (182)
$a_i \in \mathcal{A}$	Equation (115)
$A_k \subset \mathcal{A}$	Equation (198)
$E \subset \mathcal{E}$	Equations (106, 148)
$E_i^d \subset \mathcal{E}$	$E_i^d = \{e \in E : i_e^d = i\}$
$E_i^o \subset \mathcal{E}$	$E_i^o = \{e \in E : i_e^o = i\}$
$E_k \subset \mathcal{E}$	Equations (175, 178)
$E_{ik}^d \subset \mathcal{E}$	$E_{ik}^d = E_i^d \cap E_k$
$E_{ik}^o \subset \mathcal{E}$	$E_{ik}^o = E_i^o \cap E_k$
$F \subset \mathcal{F}$	Equations (108, 160)
$F_i^d \subset \mathcal{F}$	$F_i^d = \{ f \in F : i_f^d = i \}$
$F_i^o \subset \mathcal{F}$	$F_i^o = \{f \in F : i_f^o = i\}$
$F_k \subset \mathcal{F}$	Equations (176, 179)
$F_{ik}^d \subset \mathcal{F}$	$F_{ik}^d = F_i^d \cap F_k$
$F_{ik}^o \subset \mathcal{F}$	$F_{ik}^o = F_i^o \cap F_k$
$G \subset \mathcal{G}$	Equations (104, 139)
$G_i \subset \mathcal{G}$	$G_i = \{g \in G : i_g = i\}$

Table 49: Continued

Symbol	Defining equations, tables, and text
$G_k \subset \mathcal{G}$	Equations (177, 180)
$G_k^P \subset \mathcal{G}$	
$G_{ik} \subset \mathcal{G}$	$G_{ik} = G_i \cap G_k$
$H_g \subset \mathcal{H}$	Equation (169)
$I_a \subset \mathcal{I}$	$I_a = \{i \in \mathcal{I} : a_i = a\}$
$i_e^d \in \mathcal{I}$	Equation (142)
$i_e^o \in \mathcal{I}$	Equation (141)
$i_f^d \in \mathcal{I}$	Equation (151)
$i_f^o \in \mathcal{I}$	Equation (150)
$i_g \in \mathcal{I}$	Equation (131)
id_g	Equation (132)
b_e	Equation (144)
b_e^{CH}	Equation (145)
b_f	Equation (155)
b_f^M	Equation (153)
$ar{b}_i^{CS} \ \underline{b}_i^{CS}$	Equations (165, 166, 167)
\underline{b}_{i}^{CS}	Equations (165, 166, 168)
b_i^{FS}	Equations (127, 129)
c^{slack}	Section (D.3)
c_{gh}	Equation (172)
g_e	Equation (143)
g_f	Equation (154)
g_f^M	Equation (152)
g_i^{FS}	Equations (126, 128)
M	Entrant defined
\underline{M}	
M^P	Entrant defined
\underline{M}^P	
M^Q	Entrant defined
\underline{M}^Q	
M^v	Entrant defined
$\underline{\underline{M}^v}$	

Table 49: Continued

Symbol	Defining equations, tables, and text
$\overline{\overline{p}_g}$	Equation (137)
\underline{p}_g	Equation (138)
p_{gh}	Equation (171)
p_i^L	Equations (122, 124)
\overline{q}_g	Equation (135)
	Equation (136)
$rac{q}{g_g} \ q_i^L \ \overline{R}_e$	Equations (123, 125)
\overline{R}_e	Equation (146)
\overline{R}_e^K $ ilde{s}$	Equation (147)
\widetilde{s}	Equation (112)
\overline{s}_f	Equation (158)
\overline{s}_f^K	Equation (159)
\overline{v}_i	Equation (118)
\underline{v}_i	Equation (119)
$\frac{\underline{v}_i}{\overline{v}_i^K}$	Equation (120)
\underline{v}_i^K	Equation (121)
α_g	Equation (173)
δ	Equation (181)
$ heta_f$	Equation (157)
λ_n^P	Table (50) and Equation(183)
λ_n^Q	Table (50) and Equation(184)
λ_n^S	Table (50) and Equation(185)
$\overline{\sigma}_{en}^{S}$	Table (50) and Equation(186)
$\overline{\sigma}_{fn}^S$	Table (50) and Equation(187)
$\overline{\sigma}_{ekn}^{S}$	Table (50) and Equation(188)
$\overline{\sigma}_{fkn}^{S}$	Table (50) and Equation(189)
$\overline{\sigma}_{in}^{P+}$	Table (50) and Equation(190)
$\overline{\sigma}_{in}^{P-}$	Table (50) and Equation(191)
$\overline{\sigma}_{in}^{Q+}$	Table (50) and Equation(192)
$\overline{\sigma}_{in}^{Q-}$	Table (50) and Equation(193)

Table 49: Continued

Symbol	Defining equations, tables, and text
$\overline{\sigma}_{ikn}^{P+}$	Table (50) and Equation(194)
$\overline{\sigma}_{ikn}^{P-}$	Table (50) and Equation(195)
$\overline{\sigma}_{ikn}^{Q+}$	Table (50) and Equation(196)
$\overline{\sigma}_{ikn}^{Q-}$	Table (50) and Equation(197)
$ au_f$	Equation (156)

C Construction of Primitive Data from Input Data Files

This appendix explains how to form the data of the GO Competition Challenge 1 problem formulation from the raw data that is read from the input files. The format of the input files is described in section (A). Names of fields read from the input files are written in upper case Roman font. E.g. SBASE is the name of the field of the Case Identification Data table of the RAW file that contains power units base, in MVA, and the value read from this field is denoted by \tilde{s} in the model formulation. These field names are specified in the input file description document.

To form the model data, we first specify initial values of the data in subsection (C.1). Then for each table contained in the input files, in subsections (C.2, C.3, C.4, C.5, C.6, C.7, C.8, C.9, C.10, C.11, C.12) we give instructions on modifying these values as each record is read from the table.

C.1 Initial Parameter Values prior to Reading Data

Prior to reading data, we initialize some parameters and sets to certain values. These initial values are updated as data is read. E.g. some sets are initialized as empty sets, and elements are added to them as they are read from the data files. This initialization is specified here:

$$\mathcal{I} = \{\} \tag{102}$$

$$\mathcal{G} = \{\} \tag{103}$$

$$G = \{\} \tag{104}$$

$$\mathcal{E} = \{\} \tag{105}$$

$$E = \{\} \tag{106}$$

$$\mathcal{F} = \{\} \tag{107}$$

$$F = \{\} \tag{108}$$

$$\mathcal{H} = \{\} \tag{109}$$

$$\mathcal{K} = \{\} \tag{110}$$

$$\mathcal{A} = \{\} \tag{111}$$

C.2 Case Identification Data from RAW

On reading field SBASE from the first record in the Case Identification Data section of the RAW file, set

$$\tilde{s} = \text{SBASE}$$
 (112)

C.3 Bus Data from RAW

For each record in the Bus Data section of the RAW file, read fields I, AREA, VM, VA, NVHI, NVLO, EVHI, EVLO, then set i = I, a = AREA, and set

$$\mathcal{I} := \mathcal{I} \cup \{i\} \quad \text{buses} \tag{113}$$

$$\mathcal{A} := \mathcal{A} \cup \{a\} \tag{114}$$

$$a_i = a$$
 area (115)

$$v_i^0 = VM \qquad vm \tag{116}$$

$$\theta_i^0 = VA va (117)$$

$$\overline{v}_i = \text{NVHI}$$
 nvhi (118)

$$\underline{v}_i = \text{NVLO} \quad \text{nvlo}$$
 (119)

$$\overline{v}_i^K = \text{EVHI}$$
 evhi (120)

$$\underline{v}_i^K = \text{EVLO}$$
 evlo (121)

C.4 Load Data from RAW

Initialize the load data by

$$p_i^L = 0$$
 for all $i \in \mathcal{I}$

$$q_i^L = 0$$
 for all $i \in \mathcal{I}$

For each record in the Load Data section of the RAW file, read fields I, STATUS, PL, QL. If STATUS = 1, then set i = I, and set

$$p_i^L := p_i^L + PL/\tilde{s}$$
 pl (124)

$$q_i^L := q_i^L + QL/\tilde{s}$$
 q^1 (125)

C.5 Fixed Shunt Data from RAW

Initialize the fixed shunt parameters by

$$g_i^{FS} = 0$$
 for all $i \in \mathcal{I}$

$$b_i^{FS} = 0$$
 for all $i \in \mathcal{I}$ (127)

For each record in the Fixed Shunt Data section of the RAW file, read fields I, STATUS, GL, BL. If STATUS = 1, then set i = I, and set

$$g_i^{FS} := g_i^{FS} + GL/\tilde{s} \qquad gs \tag{128}$$

$$b_i^{FS} := b_i^{FS} + BL/\tilde{s} \qquad \text{bs} \tag{129}$$

C.6 Generator Data from RAW

For each record in the Generator Data section of the RAW file, read fields I, ID, PG, QG, QT, QB, STAT, PT, PB, then set i = I, id = ID g = (i, id), and set

$$\mathcal{G} := \mathcal{G} \cup \{g\} \tag{130}$$

$$i_g = i (131)$$

$$id_g = id (132)$$

$$p_g^0 = PG/\tilde{s} Pg (133)$$

$$q_g^0 = \mathrm{QG}/\tilde{s} \tag{134}$$

$$\overline{q}_q = \mathrm{QT}/\tilde{s}$$
 qghi (135)

$$\underline{q}_q = \mathrm{QB}/\tilde{s}$$
 qglo (136)

$$\overline{p}_g = \text{PT}/\tilde{s}$$
 pghi (137)

$$\underline{p}_{q} = PB/\tilde{s}$$
 pglo (138)

and if STAT = 1 set

$$G := G \cup \{g\} \tag{139}$$

C.7 Line Data from RAW

For each record in the Nontransformer Branch Data section of the RAW file, read fields I, J, CKT, R, X, B, RATEA, RATEC, ST, then set i = I, i' = J, id = CKT, and e = (i, i', id), and set

$$\mathcal{E} := \mathcal{E} \cup \{e\} \tag{140}$$

$$i_e^o = i ag{141}$$

$$i_e^d = i' (142)$$

$$g_e = R/(R^2 + X^2)$$
 (143)

$$b_e = -X/(R^2 + X^2) (144)$$

$$b_e^{CH} = B ag{145}$$

$$\overline{R}_e = \text{RATEA}/\tilde{s}$$
 (146)

$$\overline{R}_e^K = \text{RATEC}/\tilde{s} \tag{147}$$

and if ST = 1, set

$$E := E \cup \{e\} \tag{148}$$

C.8 Transformer Data from RAW

For each record in the Transformer Data section of the RAW file, read fields I, J, CKT, MAG1, MAG2, STAT, R12, X1-2, WINDV1, ANG1, RATA1, RATC1, WINDV2, then set i = I, i' = J, id = CKT, f = (i, i', id), and set

$$\mathcal{F} := \mathcal{F} \cup \{f\} \tag{149}$$

$$i_f^o = i (150)$$

$$i_f^d = i' (151)$$

$$g_f^M = \text{MAG1} \tag{152}$$

$$b_f^M = \text{MAG2} \tag{153}$$

$$g_f = (R12)/((R12^2 + (X12)^2))$$
 (154)

$$b_f = -(X12)/((R12)^2 + (X12)^2)$$
(155)

$$\tau_f = \text{WINDV1/WINDV2} \tag{156}$$

$$\theta_f = \text{ANG1} * \pi/180 \tag{157}$$

$$\overline{s}_f = \text{RATA1/\tilde{s}} \tag{158}$$

$$\overline{s}_f^K = \text{RATC1}/\tilde{s} \tag{159}$$

and if STAT = 1, set

$$F := F \cup \{f\} \tag{160}$$

C.9 Switched Shunt Data from RAW

Initialize the switched shunt parameters by

$$\bar{b}_i^{CS} = 0$$
 for all $i \in \mathcal{I}$

$$\underline{b}_{i}^{CS} = 0$$
 for all $i \in \mathcal{I}$

$$b_i^{CS0} = 0$$
 for all $i \in \mathcal{I}$ (163)

For each record in the Switched Shunt Data section of the RAW file, read fields I, STAT, BINIT, N1, B1, ..., N8, B8. If STAT = 1, then set i = I, and set

$$b_i^{CS0} = \text{BINIT}/\tilde{s} \tag{164}$$

$$BL_1 = N1 \times B1/\tilde{s}$$

$$\cdots$$

$$BL_8 = N8 \times B8/\tilde{s}$$
(165)

$$NBL = \begin{cases} \max\{l \in \{1, \dots, 8\} : BL_{l'} \neq 0 \text{ for all } l' \in \{1, \dots, l\}\} & \text{if } BL_1 \neq 0 \\ 0 & \text{if } BL_1 = 0 \end{cases}$$
 (166)

$$\overline{b}_i^{CS} = \sum_{l:1 \le l \le NBL} \max\{0, BL_l\} \tag{167}$$

$$\underline{b}_i^{CS} = \sum_{l:1 \le l \le NBL} \min\{0, BL_l\} \tag{168}$$

C.10 Generator Cost Data from ROP

In the ROP file, for each record in the Generator Dispatch Units section, read fields BUS, GENID, and DSPTBL, then read fields TBL and CTBL from the record in the Active Power Dispatch Tables section with TBL = DSPTBL, then read fields LTBL, NPAIRS, X1,

Y1, ..., XN, YN from the record in the Piecewise Linear Cost Curve Tables section with LTBL = CTBL, then set i = I, id = GENID, g = (i, id), N = NPAIRS, and set

$$H_g = \{1, \dots, N\} \tag{169}$$

$$\mathcal{H} := \mathcal{H} \cup H_g \tag{170}$$

define p_{gh} for $h \in H_g$ by

$$p_{g,1} = X1/\tilde{s}$$
...
$$p_{g,N} = XN/\tilde{s}$$
(171)

and define c_{gh} for $h \in H_g$ by

$$c_{g,1} = Y1$$

$$\dots$$

$$c_{g,N} = YN$$
(172)

Note that X1, ..., XN are not reactance values, and Y1, ..., YN are not admittance values. These fields are the X and Y coordinates of points on a curve, as defined in the input file description, Section (A.3.3).

C.11 Participation Factor Data from INL

For each record in the INL file, read fields I, ID, R, and set i = I, id = ID, g = (i, id), then set

$$\alpha_g = R \tag{173}$$

Note that field R in the INL file is different from the branch resistance fields R in the RAW file and is not a resistance. In the industry standard data format adapted by the GO Competition, the INL field R represents the governor permanent droop of a generator. However, in the GO Competition the INL field R is used as the participation factor for a generator in post-contingency redispatch and is a dimensionless, nonnegative, real number.

C.12 Contingency Data from CON

In the CON file, read the Contingency Case Data Description records one at a time. For each record read, do the following:

Suppose the field LABEL is read from the start line of the record. Let k = LABEL. Set

$$\mathcal{K} := \mathcal{K} \cup \{k\} \tag{174}$$

Prior to reading the rest of the record, set initial values, which will be updated as the record is read:

$$E_k = E ag{175}$$

$$F_k = F (176)$$

$$G_k = G (177)$$

The rest of the record contains exactly one contingency event Line and then a contingency record end line. The contingency event is either (1) a Branch Out-of-Service Event or (2) a Generator Out-of-Service Event.

Suppose the Contingency Event is a Branch Out-of-Service Event. Then read fields I, J, CKT and set i = I, i' = J, id = CKT. It can be assumed that either $(i, i', id) \in \mathcal{E}$ or $(i, i', id) \in \mathcal{F}$ but not both. If $(i, i', id) = e \in \mathcal{E}$ then set

$$E_k := E_k \setminus \{e\} \tag{178}$$

If $(i, i', id) = f \in \mathcal{F}$ then set

$$F_k := F_k \setminus \{f\} \tag{179}$$

If the Contingency Event is a Generator Out-of-Service Event read fields I, ID, set i = I, id = ID, g = (i, id) and set

$$G_k := G_k \setminus \{g\} \tag{180}$$

D Construction of Further Data

Some data for the GO Competition Challenge 1 model formulation is not directly translated from data read from the input files. In some cases this further data is defined in the symbol reference tables in the formulation, section (2), and no additional definition of this data appears here. In other cases the construction of this further data is more extensive or otherwise needs to be explained outside of the symbol reference tables. The definition this further data is given here.

D.1 Constraint Violation Penalty Parameters

The weight on the base case in the objective is given by

$$\delta = 1/2 \tag{181}$$

The set of penalty function segments is given by

$$\mathcal{N} = \{1, 2, 3\} \tag{182}$$

To define the constraint violation penalty function parameters, we define the these parameters in the data units convention in table (50).

Table 50: Constraint violation penalty function parameters

Symbol	Unit	n = 1	n=2	n=3
$PViolMax_n$	MW	2	50	∞
$QViolMax_n$	MVar	2	50	∞
$SViolMax_n$	MVA	2	50	∞
$PViolCost_n$	USD/MW -h	1e3	5e3	1e6
$QViolCost_n$	USD/MVar-h	1e3	5e3	1e6
$SViolCost_n$	$\mathrm{USD}/\mathrm{MVA}\text{-}\mathrm{h}$	1e3	5e3	1e6

Then we convert to the model units convention:

$$\lambda_n^P = PViolCost_n\tilde{s} \tag{183}$$

$$\lambda_n^Q = QViolCost_n\tilde{s} \tag{184}$$

$$\lambda_n^S = SViolCost_n\tilde{s} \tag{185}$$

$$\overline{\sigma}_{en}^{S} = SViolMax_{n}/\tilde{s} \tag{186}$$

$$\overline{\sigma}_{fn}^S = SViolMax_n/\tilde{s} \tag{187}$$

$$\overline{\sigma}_{ekn}^S = SViolMax_n/\tilde{s} \tag{188}$$

$$\overline{\sigma}_{fkn}^{S} = SViolMax_n/\tilde{s} \tag{189}$$

$$\overline{\sigma}_{in}^{P+} = PViolMax_n/\tilde{s} \tag{190}$$

$$\overline{\sigma}_{in}^{P-} = PViolMax_n/\tilde{s} \tag{191}$$

$$\overline{\sigma}_{in}^{Q+} = QViolMax_n/\tilde{s} \tag{192}$$

$$\overline{\sigma}_{in}^{Q^{-}} = QViolMax_{n}/\tilde{s} \tag{193}$$

$$\overline{\sigma}_{ikn}^{P+} = PViolMax_n/\tilde{s} \tag{194}$$

$$\overline{\sigma}_{ikn}^{P-} = PViolMax_n/\tilde{s} \tag{195}$$

$$\overline{\sigma}_{ikn}^{Q+} = QViolMax_n/\tilde{s} \tag{196}$$

$$\overline{\sigma}_{ikn}^{Q^{-}} = QViolMax_{n}/\tilde{s} \tag{197}$$

The parameters defined in table (50) appear in the Evaluation code (https://gocompetition.energy.gov/challenges/challenge-1/evaluation) used to score solutions. The parameters appear as Python variables base_case_penalty_weight (eqn. (181)), and penalty_block_pow_x_coef and penalty_block_pow_max (table (50)) in the routine evaluation.py.

D.2 Generator Real Power Contingency Response Data

Every contingency is defined by the outage of exactly one generator, line, or transformer. An area a is contingent in a contingency k if the generator, line or transformer that is out of service in k is connected to a bus in area a. That is, the set A_k of contingent areas in contingency k is defined by:

$$A_{k} = \begin{cases} \{a_{i_{g}}\} & \text{if } g \in G \setminus G_{k} \\ \{a_{i_{e}^{o}}, a_{i_{e}^{d}}\} & \text{if } e \in E \setminus E_{k} \\ \{a_{i_{f}^{o}}, a_{i_{f}^{d}}\} & \text{if } f \in F \setminus F_{k} \end{cases}$$

$$(198)$$

For a given contingency, the generators participating in real power response are those that are active and connected to buses in the contingent areas:

$$G_k^P = \{ g \in G_k : a_{ig} \in A_k \} \quad \forall k \in K$$

$$\tag{199}$$

D.3 Construction of c^{slack}

A solution violating a hard constraint is assigned a score of c^{slack} (see section (F.1) and scoring description at https://gocompetition.energy.gov/challenges/challenge-1/scoring/).

For this we construct a solution that is feasible to all hard constraints and set c^{slack} as the resulting objective value. Here we specify this construction. A python code implementing the construction of this solution is available to entrants at https://github.com/GOCompetition/WorstCase.

For each variable in v_i , p_g , q_g , set the variable to the midpoint of its lower and upper bounds. Set $b^{CS}=0$. Set $v_{ik}=v_i$, $b_{ik}^{CS}=b_i^{CS}$. For $g\in G_k$, set $p_{gk}=p_g$, $q_{gk}=q_g$. For $g\in G\setminus G_k$, set $p_{gk}=0$, $q_{gk}=0$. Set $\Delta_k=0$. Evaluate generator costs. Evaluate flows on shunts, lines, and transformers. Evaluate line and transformer flow limit violations. Evaluate bus power imbalances. Note that generator real and reactive power contingency response constraints are satisfied. Apply penalty coefficients to all constraint violations. Compute the objective value as the sum of all generator costs and constraint violation penalties. Set c^{slack} to this computed objective value.

D.4 Given Base Case Operating Point

A given base case operating point is available to Entrants in the data files. This point is represented by v_i^0 , θ_i^0 , b_i^{CS0} , p_g^0 , q_g^0 . This point can be used as a start point for various algorithms. In general we make no assertion of feasibility or optimality for this point.

E Solution Output

The solution is written to two solution files, a base case solution file solution1.txt and a contingency solution file solution2.txt (contingencies). The base case solution file contains the values of the primary optimization variables corresponding to the base case. The contingency solution file contains the values of the primary optimization variables corresponding to the contingencies.

E.1 Solution Normalization for Output Files

As in the data files, the values in the solution files are reported in the data unit convention, i.e. per unit voltage magnitude, deg, MW, MVAR, MVAR at 1 p.u. Specifically, the base case solution file contains \hat{v}_i , $\hat{\theta}_i$, \hat{b}_i^{CS} , \hat{p}_g , \hat{q}_g , and the contingency solution file contains \hat{v}_{ik} , $\hat{\theta}_{ik}$, \hat{b}_{gk}^{CS} , \hat{p}_{gk} , \hat{q}_{gk} , $\hat{\Delta}_k$. The conversion from model units to data units is:

$$\hat{v}_i = v_i \quad \forall i \in \mathcal{I} \tag{200}$$

$$\hat{\theta}_i = (180/\pi)\theta_i \quad \forall i \in \mathcal{I} \tag{201}$$

$$\hat{b}_i^{CS} = \tilde{s}b_i^{CS} \quad \forall i \in \mathcal{I}$$

$$\hat{p}_g = \tilde{s}p_g \quad \forall g \in \mathcal{G} \tag{203}$$

$$\hat{q}_g = \tilde{s}q_g \quad \forall g \in \mathcal{G} \tag{204}$$

$$\hat{v}_{ik} = v_{ik} \quad \forall k \in K, i \in \mathcal{I} \tag{205}$$

$$\hat{\theta}_{ik} = (180/\pi)\theta_{ik} \quad \forall k \in \mathcal{K}, i \in \mathcal{I}$$
(206)

$$\hat{b}_{ik}^{CS} = \tilde{s}b_{ik}^{CS} \quad \forall k \in K, i \in I \tag{207}$$

$$\hat{p}_{gk} = \tilde{s}p_{gk} \quad \forall k \in \mathcal{K}, g \in \mathcal{G}$$
 (208)

$$\hat{q}_{gk} = \tilde{s}q_{gk} \quad \forall k \in \mathcal{K}, g \in \mathcal{G}$$
 (209)

$$\hat{\Delta}_k = \tilde{s}\Delta_k \quad \forall k \in \mathcal{K} \tag{210}$$

E.2 Solution File Format Description

Each solution file contains a sequence of sections. Each section is marked by a start line starting with two hyphen characters ('--'). After the start line is a table of comma separated values, including a header row followed by a number of data rows. The sections appear in a fixed order specified in this document. The fields in each section data table appear in a fixed order specified in this document. The text in a section start line after '--' is not read by the solution evaluation code and therefore can be any text. The text in a section table header row is not read by the solution evaluation code and therefore can be any text.

The base case solution file contains the following sections, in order: the bus section, and the generator section.

Each data row of the bus section contains the following fields, in order: bus number i (positive integer), voltage magnitude \hat{v}_i , voltage angle $\hat{\theta}_i$, controllable shunt susceptance \hat{b}_i^{CS} . Every bus $i \in \mathcal{I}$ should be reported in exactly one row of the bus section.

Each data row of the generator section contains the following fields, in order: bus number i_g (positive integer), unit id id_g (1- or 2-character string), real power output \hat{p}_g , reactive power output \hat{q}_g . Every generator $g \in \mathcal{G}$ should be reported in exactly one row of the generator section.

For each contingency $k \in \mathcal{K}$, the following for sections appear in the contingency solution file, in order: contingency section, bus section, generator section, delta section. After the delta section of one contingency, the contingency section of the next contingency starts.

The contingency section data table for contingency $k \in \mathcal{K}$ contains exactly one row, with exactly one field, containing k (the string contingency label).

The bus section of contingency k is formatted like the bus section of the base case solution file. Each record contains the following fields, in order: bus number i (positive integer), voltage magnitude \hat{v}_{ik} , voltage angle $\hat{\theta}_{ik}$, controllable shunt susceptance \hat{b}_{ik}^{CS} . Every bus $i \in \mathcal{I}$ should be reported in exactly one row of the bus section.

The generator section of contingency k is formatted like the generator section of the base case solution file. Each record contains the following fields, in order: bus number i_g (positive integer), unit id id_g (1- or 2-character string), real power output \hat{p}_{gk} , reactive power output \hat{q}_{gk} . Every generator $g \in \mathcal{G}$ should be reported in exactly one row of the generator section.

The delta section of contingency k contains exactly one row, with exactly one field, Δ_k .

```
--bus section
i, v(p.u.), theta(deg), bcs(MVAR at v = 1 p.u.)
1, 1.01, 5.0, 10.0
2, 0.99, 0.0, 0.0
--generator section
i, id, p(MW), q(MVAR)
1, '1', 100.0, 10.0
1, '2', 50.0, 0.0
```

Figure 1: solution1.txt

E.3 Sample Solution Output Files

A sample solution1.txt file is shown in Figure 1, and a sample solution2.txt file is shown in Figure 2.

```
--contingency
label
'G-1-1'
--bus section
i, v(p.u.), theta(deg), bcs(MVAR at v = 1 p.u.)
1, 1.02, 5.0, 10.0
2, 0.98, 0.0, 0.0
--generator section
i, id, p(MW), q(MVAR)
1, '1', 150.0, -10.0
1, '2', 0.0, 0.0
--delta section
delta(MW)
50.0
--contingency
label
'L-1-2-1'
--bus section
i, v(p.u.), theta(deg), bcs(MVAR at v = 1 p.u.)
1, 1.005, 0.0, 0.0
2, 0.995, 0.0, 0.0
--generator section
i, id, p(MW), q(MVAR)
1, '1', 130.0, 0.0
1, '2', 40.0, 0.0
--delta section
delta(MW)
-30.0
```

Figure 2: solution2.txt

F Solution Evaluation

A solution is evaluated by a Python code written for the competition. This code is available to entrants at https://gocompetition.energy.gov/challenges/challenge-1/evaluation. The main procedure is contained in evaluation.py, and this module uses the data reading code data.py.

F.1 Procedure

The evaluation procedure is:

Read solution. The primary optimization variables and binary variables are read from the solution files in the data unit convention, i.e. as \hat{v}_i , $\hat{\theta}_i$, \hat{b}_i^{CS} , \hat{p}_g , \hat{q}_g , \hat{v}_{ik} , $\hat{\theta}_{ik}$, \hat{b}_{ik}^{CS} , \hat{p}_{gk} , \hat{q}_{gk} , $\hat{\Delta}_k$. If incorrect formatting prevents reading these values, then the solution is deemed infeasible.

Convert units. The primary optimization variables are converted to the model unit convention, i.e. to v_i , θ_i , b_i^{CS} , p_g , q_g , v_{ik} , θ_{ik} , b_{ik}^{CS} , p_{gk} , q_{gk} , Δ_k , using (200, 201, 202, 203, 204, 205, 206, 207, 208, 209, 210)

Check bounds. Check bounds (32, 33, 34, 35, 36, 37, 58, 59, 60, 61, 62, 63) on v_i , p_g , q_g , b_i^{CS} , v_{ik} , p_{gk} , q_{gk} , b_{ik}^{CS} . If any violation $> 10^{-4}$ is found, then the solution is deemed infeasible.

Compute flows. Use (38, 39, 40, 41, 42, 43, 44, 45, 64, 65, 66, 67, 68, 69, 70, 71) to compute the values of p_e^o , p_e^d , q_e^o , q_e^d , p_f^o , q_f^d , q_f^o , q_f^d , p_{ek}^o , p_{ek}^d , q_{ek}^o , q_{ek}^d , p_{fk}^o , q_{fk}^d , q_{fk}^o .

Compute flow bound violations. Use (52, 53, 54, 55, 56, 57, 78, 79, 80, 81, 82, 83) to compute minimal σ_e^S , σ_e^S , σ_f^S , σ_e^S , σ_{ek}^S , σ_{fk}^S , σ_{fk}^S .

Compute generator contingency real power output. Compute p_{gk} from (84, 86), overwriting the value provided in the solution file. These computed values of p_{gk} are used in assessing power balance constraints. Here we are using the projection formulation of generator real power response to contingencies, and not the other equivalent formulations.

Compute balance violations. Use (46, 47, 48, 49, 50, 51, 72, 73, 74, 75, 76, 77) to compute minimal $\sigma_i^{P+}, \ \sigma_i^{P-}, \ \sigma_i^{Q+}, \ \sigma_{ik}^{Q-}, \ \sigma_{ik}^{P+}, \ \sigma_{ik}^{Q-}, \ \sigma_{ik}^{Q-}, \ \sigma_{ik}^{Q+}, \ \sigma_{ik}^{Q-}$.

Check generator reactive power contingency response. Check generator reactive power contingency response using the min/max constraints (94, 95). Here we are using the min/max formulation of generator reactive power response to contingencies, not the other equivalent formulations. If any violation $> 10^{-4}$ is found then the solution is deemed infeasible.

Compute the objective. Use (6, 8, 10, 12, 14, 16, 18, 20, 22, 24, 26, 28, 30) to compute minimal c^{σ} . Use (7, 9, 11, 13, 15, 17, 19, 21, 23, 25, 27, 29, 31) to compute minimal c_k^{σ} . Use (3, 4, 5) and convexity of generator cost functions to compute t_{gh} . Use (2) to compute

 c_g . Use (1) to compute the objective value c.

Outputs. There are two main outputs: feasibility, which is a boolean value, and the objective c, which is a real value in USD/h. In addition, a detailed output file (details.csv) is written in CSV format, giving the index and value of the maximum violation of each type of constraint in the base case and each contingency.

The detailed output file has a header row, then a row for the base case, then one row for each contingency. Each row is a comma separated list of fields. A description of each field is given in Table (51). The table gives references to the most relevant equations in the formulation, specified by the equation numbers in parentheses. Most of the fields come in (idx, val) pairs, where idx refers to the index or key of the maximum violation in a class of constraints, and val refers to the value of the maximum violation. Most of the fields apply to the individual contingency or base case specified in the current row. The one exception is the 'obj' field, which gives the cumulative objective value for the base case and all contingencies up through the current row.

Table 51: Evaulation detailed output file fields

Field Name	Description
ctg	contingency label for the current contingency, empty if base case
infeas	binary indicator of infeasibility for the base case or contingency of the current row - 1 indicates infeasible
pen	penalty value (USD/h) on soft constraint violations in the base case or current contingency $(1, 6, 7)$
cost	generator cost value (USD/h) (base case only), 0 in contingencies $(1, 2, 3, 4, 5)$
obj	objective value (USD/h), equal to generator costs plus penalties, cumulative (i.e. base case plus all contingencies through the current row) (1)
vmax-idx	bus number of maximum violation of bus voltage magnitude upper bounds $(32, 58)$
vmax-val	value (p.u.) of maximum violation of bus voltage magnitude upper bounds (32, 58)
vmin-idx	bus number of maximum violation of bus voltage magnitude lower bounds $(32, 58)$
vmin-val	value (p.u.) of maximum violation of bus voltage magnitude lower bounds (32, 58)
bmax-idx	bus number of maximum violation of switched shunt susceptance upper bounds (37, 63)
bmax-val	value (p.u.) of maximum violation of switched shunt susceptance upper bounds $(37,63)$

Table 51: Continued

Field Name	Description
bmin-idx	bus number of maximum violation of switched shunt susceptance lower bounds (37, 63)
bmin-val	value (p.u.) of maximum violation of switched shunt susceptance lower bounds (37, 63)
pbal-idx	bus number of maximum violation of real power balance contraints (46, 72)
pbal-val	value (p.u.) of maximum violation of real power balance contraints (46, 72)
qbal-idx	bus number of maximum violation of reactive power balance contraints $(49, 75)$
qbal-val	value (p.u.) of maximum violation of reactive power balance contraints (49, 75)
pgmax-idx	bus and unit id of maximum violation of generator real power upper bounds (33, 34, 59, 60)
pgmax-val	value (p.u.) of maximum violation of generator real power upper bounds (33, 34, 59, 60)
pgmin-idx	bus and unit id of maximum violation of generator real power lower bounds (33, 34, 59, 60)
pgmin-val	value (p.u.) of maximum violation of generator real power lower bounds (33, 34, 59, 60)
qgmax-idx	bus and unit id of maximum violation of generator reactive power upper bounds (35, 36, 61, 62)
qgmax-val	value (p.u.) of maximum violation of generator reactive power upper bounds (35, 36, 61, 62)
qgmin-idx	bus and unit id of maximum violation of generator reactive power lower bounds (35, 36, 61, 62)
qgmin-val	value (p.u.) of maximum violation of generator reactive power lower bounds (35, 36, 61, 62)
qvg1-idx	bus and unit id of maximum violation of generator pv/pq switching constraints of type 1 (undervoltage implies reactive power at max) (94)
qvg1-val	value (p.u.) of maximum violation of generator pv/pq switching constraints of type 1 (undervoltage implies reactive power at max) (94)
qvg2-idx	bus and unit id of maximum violation of generator pv/pq switching constraints of type 2 (overvoltage implies reactive power at min) (95)
qvg2-val	value (pu.) of maximum violation of generator pv/pq switching constraints of type 2 (overvoltage implies reactive power at min) (95)

Table 51: Continued

Field Name	Description
lineomax-idx	origin destination and circuit id of maximum violation of line origin flow bounds $(52, 78)$
lineomax-val	value (p.u.) of maximum violation of line origin flow bounds (52, 78)
linedmax-idx	origin destination and circuit id of maximum violation of line destination flow bounds (54, 80)
linedmax-val	value (p.u.) of maximum violation of line destination flow bounds (54, 80)
xfmromax-idx	origin destination and circuit id of maximum violation of transformer origin flow bounds (55, 83)
xfmromax-val	value (p.u.) of maximum violation of transformer origin flow bounds (55, 83)
xfmrdmax-idx	origin destination and circuit id of maximum violation of transformer destination flow bounds (57, 81)
xfmrdmax-val	value (p.u.) of maximum violation of transformer destination flow bounds (57, 81)

F.2 Solution Score

Each submitted solution is assigned a score. If no solution is submitted within the required time limit, or the solution files are unreadable, or the solution is infeasible, then the score is c^{slack} . If the solution is feasible with objective value c, then the score is $\min(c, c^{slack})$. The scores of all the submitted algorithms on all the problem scenarios are the fundamental inputs to the algorithm scoring procedure, which is documented in https://gocompetition.energy.gov/challenges/challenge-1/scoring/.

G Change Log

Changes to this document after its first posting will be listed here with references to where they appear in the document.

G.1 November 1, 2018

Added table of contents and appendices.

Added id_g to the symbol reference, in Table (6). This symbol is needed to write the solution files.

Fixed some unit descriptions. Some units were missing time, measured in hours (h). This has been added where needed. This change does not affect the equations of the formulation or of the processing of input data into the data of the formulation. It only affects the clarity of the interpretation of the variables and parameters of the model.

G.2 November 14, 2018

Corrected an error in the interpretation of the STATUS field (and other analogous fields with different names) in the Load, Fixed Shunt, and Switched Shunt sections of the RAW file. Previously the STATUS field was ignored. Now we specify that among all loads, fixed shunts, and switched shunts, only those with STATUS = 1 should be added to the model. The changed text appears in sections (C.4, C.5, C.9)

G.3 November 30, 2018

The interpretation of the R field of the INL file is clarified in sections (A.4, C.11). Specifically, this field is taken as the participation factor of a generator in post-contingency real power output response, which is a dimensionless, nonnegative, real number. The interpretation of R in Table 3 is excluded from its interpretation in the Appendices.

It can be assumed that any (I, ID, CKT) appearing in a record of the CON file appears also in the RAW file as either a line (non-transformer branch) or a transformer but not both. This assumption is posted in section (C.12).

G.4 March 29, 2019

The construction of \overline{b}_i^{CS} and \underline{b}_i^{CS} from data files (C.9) was missing an initialization step. This initialization step was added. The effect of this step is that, for any bus i, if there are no active switched shunt elements connected to i, then we have $\overline{b}_i^{CS} = 0$ and $\underline{b}_i^{CS} = 0$. Cf. equations (161, 162).

Documentation of the evaluation code output file (details.csv) was added to section (F.1). Cf. table (51).

An entry for σ_{fn}^S was added to table (8)

References to K and I were corrected to K and I.

Multi-indices ekn or fkn were previously sometimes written as enk or fnk. All instances of enk (resp. fnk) have been corrected to ekn (fkn).

The vague term "responsive" has been corrected to "active" at the start of section (3.15).

The symbol G_k^P has been corrected to G_k in the caption of table (3.15.3).

Equation (7) previously used k incorrectly as both a free index and an index of summation. The summation was removed.

The treatment of hard constraint violations in the evaluation procedure is modified, where hard constraints are those constraints that do not use penalty variables. A tolerance of 10^{-4} p.u. will be used in determining whether these violations constitute infeasibility. Specifically, any violation of a hard constraint $> 10^{-4}$ p.u. will result in infeasibility, and any violation of a hard constraint $\le 10^{-4}$ p.u. will be ignored. This is equivalent to truncating the floating point representation of the violation to 4 digits after the decimal point. The solution procedure is modified to reflect this practice. This change is made in the description of the evaluation procedure (appendix F.1) and in the evaluation code itself (https://github.com/GOCompetition/Evaluation).

G.5 April 9, 2019

In section (C.9), no initial value of b_i^{CS0} was provided, so this symbol was left undefined for buses i with no fixed shunts present and in service. This has been corrected by specifying that b_i^{CS0} takes the initial value 0 prior to reading any switched shunt records.

In section (C.9), for each record for an in service switched shunt, a local variable NBL is defined giving the number of valid blocks. The expression for NBL was not well defined in the case where at least one of the fields N1 and B1 is 0. This has been corrected by specifying that NBL = 0 in this case and that the original definition of NBL applies in the

case where N1 and B1 are both nonzero.