

USB I/O Data Sheet

802x00 802600 USB Chip 16 Bit IO SOIC24 802300 USB Chip 12 Bit IO DIP20 802200 USB Chip 12 Bit IO SOIC20

802x70 802270 USB Chip 10 Bit IO SOIC18 802370 USB Chip 10 Bit IO DIP18 802670 USB Chip 16 Bit IO SOIC24 802770 USB Chip 16 Bit IO DIP24

Delcom Products 200 William Street Port Chester, NY 10573 914-934-5170 914-934-5171 Fax www.delcom-products.com


Contents

- 1.0 Functional Overview
- 2.0 Pin Definitions
- 3.0 Pin Descriptions
- 4.0 Features
 - 4.1 Write Strobe
 - 4.2 Clock Generator
 - 4.3 Port Setup
 - 4.4 Read Buffer
 - 4.5 Scratch Pad
 - 4.6 Event Counter
 - 4.7 Status LED
 - 4.8 RS232 Serial Port
 - 4.9 I²C Port
 - 4.10 64 Bit Read/Write IO Command
 - 4.11 SPI Port
- **5.0** Firmware Commands
 - 5.1 General
 - 5.2 Command Packet Format
 - **5.3** Write Commands
 - **5.4** Read Commands
- 6.0 Typical Schematic
- 7.0 Specifications
 - 7.1 Absolute Maximum Ratings
 - 7.2 Electrical Characteristics
- 8.0 Package Diagrams
- 9.0 Ordering Information
- 10.0 Firmware Release Notes
- 11.0 TroubleShooting
- **12.0** Notes
 - 12.1 Power Notes
 - 12.2 Interfacing Notes

1.0 Functional Overview

The Delcom USB IO chips provide a preprogrammed low cost solution to USB peripherals. These chips are based on the CypressTM CY7C63xxx and the CY7C637xx USB chips. The USB IO chip are preprogrammed with to support USB connectivity. The chips conform to the USB 1.1 standard.

The data sheets describes both the 802x00 and 802x70 USB chips. For new designs it is recommended to use the newer 802x70 USB chips.



For more information on this device see CypressTM data sheet CY7C63000A, available on our website.

2.0 Pin Definitions

Name	I/O	802200	802600	Description	
		802300			
		20-Pin	24-Pin		
P0.0	I/O	1	1	Port 0 bit 0 (I2C SCLK)	
P0.1	I/O	2	2	Port 0 bit 1 (I2C SDA)	
P0.2	I/O	3	3	Port 0 bit 2	
P0.3	I/O	4	4	Port 0 bit 3	
P0.4	I/O	20	24	Port 0 bit 4	
P0.5	I/O	19	23	Port 0 bit 5 (SPI MISO)	
P0.6	I/O	18	22	Port 0 bit 6 (SPI MOSI)	
P0.7	I/O	17	21	Port 0 bit 7 (SPI SCLK)	
P1.0	I/O	5	5	Port 1 bit 0	
P1.1	I/O	16	20	Port 1 bit 1	
P1.2	I/O	6	6	Port 1 bit 2	
P1.3	I/O	15	19	Port 1 bit 3	
P1.4	I/O	-	7	Port 1 bit 4	
P1.5	I/O	-	18	Port 1 bit 5	
P1.6	I/O	-	8	Port 1 bit 6	
P1.7	I/O	-	17	Port 1 bit 7	
XTALIN	I	10	12	Clock In*	
XTALOUT	О	11	13	Clock Out*	
CEXT	I/O	9	11	Wake Up Pin	
D+	I/O	14	16	USB Data +	
D-	I/O	13	15	USB Data -	
Vpp	-	8	10	Programming voltage, Connect to Vss	
Vcc	-	12	14	Voltage Supply	
Vss	-	7	9	Ground	

3.0 Pin Descriptions

Name	Description			
Vcc	Voltage Supply. Nominal 5V, Range 4.0Volts to 5.25Volts			
Vss	Ground. Connect to ground			
XtalIn	Clock Input			
XtalOut	Clock Output			
P0.0-7	Port 0. Low Current GPIO. Programmable sink current & pullup.			
P1.0-7	Port 1. High Current GPIO. Programmable sink current & pullup.			
D+,D-	USB data lines. Requires an external 7.5K resistor connected to D- to Vcc.			
Vpp, Cext	Unused pins. Vpp connect to ground. Cext leave open.			

^{*}Note - The 802x00 chips require a external 6MHz ceramic resonator as it's clock source. The 802x70 chips do not require an external oscillator.

4.0 Programmed Features

The USB I/O chip provides general 8 bit input output commands as well as individual set and reset commands of each pin.

4.1 Write Strobe

The write strobe feature allows the USB I/O chip to interface to another device by using a standard 8-bit data bus with a strobe pin. The data is placed on port 0 and the strobe is selectable on one of the port 1 pins. Theses functions allow one to eight data bytes to be sent on either a positive and negative strobe (pulse). The write strobe functions support an optional acknowledge signal.

4.2 Clock Generator

This function generates a clock source with variable frequency and duty cycle. Up to four separate clocks can be configured. The clock outputs can be selected on port 1 pins 0 through 3.

4.3 Port Setup

These features allow the user to set the programmable output sink current and enable/disable the port pin pull up resistor. Each port pin is of a open collector type. The sink current level can be set in 16 levels. Each port pin has a pull up resistor of 16Kohms that can be enabled or disabled.

4.4 Read Buffer

This feature allows the USB I/O chip to interface to a device using a standard 8-bit data bus and a read strobe pin. Data is read on port 0 with a read strobe (pulse) on one of the selectable port 1 pins. The data read buffer is 7 bytes deep. If the read data buffer is full, new data will not be accepted and the over flow flag will be set. Note this function cannot be used while the RS232 functions are in uses.

4.5 Scratch Pad

The scratch pad allows the user to write 8 bytes of user defined information in to the USB I/O device. This area can be used for storing user variables, states or other information. Note this function cannot be used while the RS232 functions are in uses.

4.6 Event Counter

The event counter feature allows the counting of events on one of the port 0 pins. The resolution of the counter is 4 bytes. The active level on the count pins is user selectable.

4.7 Status Led

The status led feature toggles a port pin when there is activity on the USB bus. The feature is only available on pin P1.3. The pin goes low while the USB I/O chip is processing the USB command. The active low pulse is short and therefore may requires a pulse stretcher circuit in order to view.

4.8 RS232 Serial Port

The RS232 functions allow the chip to interface to a RS232 compliant device. Currently the baud rate is fixed at 2400bit/sec with 8 data bit, one stop bit and no parity. To use the RS232 function first enable it with commands 10-40, then use command 10-50 to send data and 11-50 to receive data. You can check the internal buffer count with command 11-9. The RS232 pins are fixed with transmit at port 0 pin 7, receive at port 0 pin 6 and clear to send at port 0 pin 5. This commands supports a maximum transfer of 7 bytes per command.

4.9 I²C Port

The I2C functions allow the chip to interface to an I2C compliant device. The I2C port supports the standard clock rate of 100KHz. The SCLK signal is on port 0 pin 0 and the SDA signal is on port o pin 1.

There are four commands associated with the I2C port. They are 10-60 Write, 10-61 Selective read setup, 11-60 Read and 11-61 Selective read. This command supports a maximum transfer of eight bytes per command.

4.10 64 Bit Read/Write command

The 64 bit read/write commands allows the user to read or write 64 bits (8 Bytes) of data with one command. This commands requires extra hardware. See the USB64BIO-Sch.pdf schematic on our website.

4.11 SPI Port

Available in 802x70 chips only.

The SPI functions allow the chip to interface to an SPI compliant device. The I2C port supports a variable clock period from 20ns to 5.1ms. The default clock is 200ns and can be changed with command 10-91. There are three SPI commands they are 10-90 Write SPI Data, 11-90 Read SPI Data and 11-91 Write 8 bits Read 1-64 bits. The SCLK signal is on port 0 pin 7, the MOSI signal is on port 0 pin 6 and the MISO signal is on port 0 pin 5. This command supports a maximum transfer of eight bytes per command.

5.0 Firmware Commands

5.1 General

All commands are passed to the USB I/O device in a command packet. The command is filled and sent to the USB I/O device using the DeviceIOControl WindowsTM function in the Setupapi.dll. Alternatively you can uses the DelcomDLL which has specific functions already defined. See the USB I/O Programming Manual and the Delcom DLL Manual available on our web site for more information.

All command packets are at least 8 byte long (16 bytes Max) and all receive data is 8 bytes long.

5.2 Command Packet Format:

Recipient Byte Always 8 for the USB IO device.

Device Model Byte Always 18 for the USB IO device

Major CommandByteSee BelowMinor CommandByteSee BelowData LSBByteSee BelowData MSBByteSee Below

Length Short (2 Bytes) Length of DataExtension.

DataExtension 0-8 Bytes – (Optional) Version 5 and up.

5.3 Write Commands

Command Number Data		Data				
Major	Minor	Length	Command Description	-		
10	-	-	WRITE FUNCTIONS			
_	_	_	Port Write Functions			
10	0	0	Dummy command. Does nothing, used for testing.			
10	1	0	Writes the LSB to port 0. Port 0 is defaulted high after reset.			
10	2	0	Writes the LSB to port 1. Port 1 is defaulted high after reset.			
10	10	0	Writes the LSB to port 0 and the MSB to port 1.			
10	11	0	Sets or resets the port 0 pins individually. The LSB resets the corresponding port pin(s) and the MSB sets the corresponding port pin(s) on port 0. Resetting the port pin(s) takes precedence over setting the bits.			
10	12	0	Sets or resets the port 1 pins individually. The LSB resets the corresponding port pin(s) and the MSB sets the corresponding port pin(s) on port 1. Resetting the port pin(s) takes precedence over setting the bits.			
10	13	0	Write strobe high function. This commands writes the LSB to port 0 and then toggles the corresponding pin marked in the MSB byte high then low. See Write strobe function sequence below.			
10	14	0	Write strobe low function. This commands writes the LSB to port 0 and then toggles the corresponding pin marked in the MSB byte low then high. See Write strobe function sequence below. Write strobe function sequence. This command produces the following sequence; 1) Data in LSB is written to Port 0. 2) The strobe pin is set active for 1.5ms. If the acknowledge pin is enabled the strobe pin will wait while the acknowledge pin is held low (See command 10-40 bit 3). 3) Then the strobe pin is made non-active. 4) And finally 0xFF is written to Port 0. The strobe pin and the data on port 0 must be initially preset before using this function.			
10	15	1-8	Write 8-byte strobe high function. This commands writes the Data Extension data to port 0 and then toggles the corresponding pin marked in the MSB byte high then low and then delays for the specified time set in the LSB	5		
10	16	1-8	byte. See Write 8-byte strobe function sequence below. Write8-byte strobe low function. This commands writes the Data Extension data to port 0 and then toggles the corresponding pin marked in the MSB byte low then high and then delays for the specified time set in the LSB byte. See Write 8-byte strobe function sequence below.	5		
			Write 8-byte strobe function sequence. This command produces the following sequence; 1) Data in Data Extension is written to Port 0 LSB first. 2) The strobe pin is set active for 1.5us. If the acknowledge pin is enabled the strobe pin will wait while the acknowledge pin is held low (See command 10-40 bit 3). 3) Then the strobe pin is made non-active. 4) And finally 0xFF is written to Port 0. 4) System then delays for the specified time set in Data LSB byte. 5) Then the process is repeated till all data bytes in the Data Extension have been sent. The delay is equal to 8.25us+(0.75us*DelayValue) Example: Command 8,18,10,15,10,1,4,0,0,0,0 will send 4 bytes of data (all zeros here) on a high strobe on pin one of port one with a delay of 15.75us. The strobe pin and the data on port 0 must be initially preset before using this function.	5		
10	17	8	Write 64 Bit Command. This command writes 8 bytes of data to the external hardware latches. The data is passed in the data extension registers. The LSB of the data extension is written to address zero. This commands requires external hardware. See USB64BIO-Sch.pdf on our website.			
10	19	0	Loads the Clock Generator Global Pre-scalar value. Default value is 10, range = 1 to 255. This value is passed in the LSB register. Increasing this number decreases all the clock function frequencies.			
10	20	0	Enables or disables the clock generator on port 1. The lower nibble of the LSB disables the corresponding port pin(s) and the lower nibble of the MSB enables the corresponding port pin(s). Disabling the port pin(s) takes			
10	21	0	precedence over enabling. Loads the frequency and duty cycle for port 1 pin 0. See below for format.			
10	22	0	Loads the frequency and duty cycle for port 1 pin 1. See below for format.			
10	23	0	Loads the frequency and duty cycle for port 1 pin 2. See below for format.			
10	24	0	Loads the frequency and duty cycle for port 1 pin 3. See below for format. Frequency and duty format. The LSB sets the period when the port pin is high and the MSB sets the period when the port pin is low. The resolution of the period is 10ms. The resolution of the duty cycle is 0.39 percent. The minimum clock frequency is 25.6 seconds at 50% duty. The maximum clock frequency is 100ms			
10	25	0	at 50% duty. Clock pins can be preset to a predefined state <i>Synchronizes the clock generation</i> . This command synchronizes all the clock generators to start at an initial phase delay, see below. The lower nibble of the LSB enables this function on the corresponding pins P1.0 to P1.3. The lower nibble of the MSB presets the initial value on the corresponding pins P1.0 to P1.3. Initial phase delay resolution is in 10ms and is passed in the LSB register. Initial phase delay registers are cleared after this command is sent. Therefore the initial phase delay registers must be set each time this command is called.			
10	26	0	Load initial phase delay on port 1 pin 0. See Synchronies function above.			
10	27	0	Load initial phase delay on port 1 pin 1. See Synchronies function above.			
10	28	0	Load initial phase delay on port 1 pin 2. See Synchronies function above.			
10	29	0	Load initial phase delay on port 1 pin 3. See Synchronies function above.			
10	30	0	Port Setup Functions Enable or disable port 0 pull up resistors. A low bit in the LSB enable the corresponding port 0 pull up. A high bit in LSB disables the corresponding port 0 pull up. The pull up resistor value is 16K. Default value is			
10	31	0	0x00, all port 0 pull ups enabled. Enable or disable port 1 pull up resistors. A low bit in the LSB enables the corresponding port 1 pull up. A high bit in LSB disables the corresponding port 1 pull up. The pull up resistor value is 16K. Default value is 0x00, all port 1 pull ups enabled.			
10	32	0	0x00, all port 1 pull ups enabled. Setup port 0 pins sink current level. This functions sets the current sinking level of the port 0. The maximum			

10	60	1-8	Write to the I2C Port					6
			MSB and LSB bytes s is in the remaining 7 t 8,18,0,0,6,5,1,2,3,4,5	should be zero. The da bytes. Issuing this com	ta count is in the LSB	byte (first byte of the atus register (see 11-9	he Data Extension. The DataExt) and the data 9). Example command	
10	50	1-8		m-eng.com/download	s/cy7c637xx-B.pdf for	more GPIO details.		5
			Maximum cumulative Maximum cumulative		for all GPIO is 30mA.	DIIVE / CIVIOS		
			1	1	High (50mA) Sink / CMOS	High (30mA) Drive / CMOS	-1.000	
			1	0	Low (2mA) Sink / CMOS	Pull up (14K) / CMOS	Default / Boot up Mode	
					Sink / CMOS	Drive / CMOS		
			0	0	Hi-Z / CMOS Medium (8mA)	Hi-Z / TTL High (30mA)		
			0	0	data out is low	data out is high Hi-Z / TTL		
			Mode 1 Value	Mode 0 Value	Port type when	Port type when		802x70
			GPIO Mode table		-	· ·	O Mode table below.	502X70
10	48	0	Configures Port 1 GP. The LSB data parame		. Each bit represents a	port pin. See the GPI	O Mode table below.	802x70
10	40		The LSB data parame	ter is the value passed	. Each bit represents a	port pin. See the GPI	O Mode table below.	802x70
10	47	0	Configures Port 1 GP	IO – Mode 0 Register				802x70
10	46	0	Configures Port 0 GP	IO – Mode 1 Register	. Each bit represents a	•		802-70
10	43	0	Configures Port 0 GP The LSB data parame	_	. Each bit represents a	port pin. See the GPI	O Mode table below.	802x70
10	45	0			errupt Edge. 1= Rising	edge, 0=Falling edge	.	802x70
10	44	0		The LSB Data parameter sets the Port 0 Interrupt Edge. 1= Rising edge, 0=Falling edge. 802x70 Set Port 1 Interrupt Edge.				
10	43	0		Set Port 0 Interrupt Edge.				
			for future compatibili	ty.	us are reserved for full	те иприешенканоп ап	ia snoura de set to zero	
			low. Version 8.	lementation These bi	ts are reserved for futu	re implementation an	nd should be set to zero	
			available on pin P1.2	~ .	write strobe will be ex		- 1	
					xed 2400 baud rate. Ve rite strobe functions 13		mowledge nin is only	
			available on this pin.	•			nons are present. Omy	
					ten to this control regis 1.3) will toggle low wh		tions are present. Only	
10	40	0					t in this register controls	
			configured by the pul	ups command 10-30 erwise the active trans	and 10-31. If the pull- sition is from low to hig	ups are enabled then	the active transition is	
					B data byte disabled the son the enabled pin or		rresponding pin on port	
10	38	0			nand sets up the event c	ounter. LSB data byt	e enables this function	
				or information. Defau	eratch pad area is 8 byte lted to all 0x00 on boot		n be used for storing on cannot be used while	
10	37	0			he scratch pad. The M			
			high. The read buffer	is only 7 bytes deep.	Default is 0x00, read bused while the RS232 f	ouffer disabled. See r		
							10-30 and 10-31. If the transition is from low to	
10	33	0	strobe in presented on	the configured strobe		B will enable the cor	respond pin on port 1 to	
- 10	35	-		ation. This command	Feature commands	d the current values	on nort O when a read	
			LSB Data parameter i 0-100.	s the port pin number,	range is 0-3. The MS	B Data parameter is t	he PWM value, range is	
10	34	U		n P1.3 can be placed is	PWM mode by writin			802x70
10	34	0	is enabled, for examp	le if the Vcc is 5volts	a port pin would source		* *	
					est current level and a g. Both ports can only		highest current level. /16K when the pull up	
			MSB selects the pin 0	and a 7 in the MSB s	elects pin 7. The lower	nibble of LSB sets t	he current sinking level	
			for port 1 is 0x00. Se Setup port pin sink cu		selects which pin to se	et the sinking current	level on. A zero in the	
	23	v	current sinking ability	of port 1 is 24mA and			mA. The default value	
10	33	0	for port 0 is 0x00. See		nctions sets the current	sinking level of the r	port 0. The maximum	
					id the minimum curren	t sinking ability is 0.5	3mA. The default value	

current sinking ability of port 0 is 1.5mA and the minimum current sinking ability is 0.3mA. The default value

			This command write the data found in the data extension to the I2C device. The device address/command is set in the Data LSB byte and the number of bytes to send is set in the Data MSB byte. If an error occurs bit 4/7 of byte 7 is set, else reset. See command 11-9.	
10	61	0	12C Selective Read Setup	6
			This commands setups the selective read command 11-61. The Data LSB should be set to the device	
			address/command and the Data MSB should be set to the selective read address. See 11-61 for more	
			information.	
10	90	0-8	Write to the SPI port	15
			This commands writes up to 8 bytes of data (passed in the DataExt) to the SPI port. The number of bit to write	802x70
			is passed in the LSB Byte, range is 1-64. Also see command 11-91	
10	91	0	Setup SPI Port	15
			This command configures the SPI CLK timing. The LSB byte specify the SPI clock period. Default is 10 and	802x70
			the units are 20us.	


5.4 Read Commands

Command Number Data		Data			
Major	Minor	Length	Command Description		
11	-	-	READ FUNCTIONS All read functions return 8 bytes. See individual commands for format.		
11	0	0	Read ports 0 and port 1. The first byte (LSB) will contain the current value on port 0 and the second byte (MSB) will contain the current value on port 1.		
11	1	0	Reads port 0 with High strobe. Reads the current data on port 0 with a high strobe on pin X on port 1. The LSB		
11	2	0	sets up which pin is to be used for the high strobe. See Read port 0 with strobe sequence below. <i>Reads port 0 with Low strobe.</i> Reads the current data on port 0 with a low strobe on pin X on port 1. The LSB sets up which pin is to be used for the low strobe. See Read port 0 with strobe sequence below. <i>Read port 0 with strobe sequence.</i> These commands produce the following sequence; 1) The selected strobe pin is made active. 2)Micro waits 1.5ms. 3) Data is latch from port 0 and stored. 4) The strobe pin is released. The strobe pin and the data on port 0 must to preset before using this function. Default is 0x00, command disabled.		
11	5	0	Reads the Read Buffer. This command is setup with the read Buffer Setup Command(10-35). The LSB byte returned is the read buffer status byte, it will contain the number of bytes available in the read buffer. The next 7 bytes contain the data. The read data buffer is only 7 bytes deep. Data is filled from byte 1 to byte 7. If the read data buffer is full and another read strobe is presented then the read buffer status byte will be set to 0xFF and the new data byte would be lost. The user must check the read status byte to if; new data is present, not present or present with data over run. This commands resets the read status byte to zero. Note this function cannot be used when the RS232 function is in use.		
11	7	0	Reads the 8 bytes in the scratch pad area. Default values are zero.		
11	8	0	Reads the event counter value. This command returns the 4 byte event counter value and then resets the counter. If the counter over flows then the over flow status byte will be set to 0xFF otherwise it will be 0x0. The event counter is returned in the first 4 bytes and the over flow byte is in the 5 byte.		
11	9	0	Reads system variables. This function returns the following system variables. Byte0: Control Register. Byte1: Clock Generator Pre-Scalar. Byte2: Port 0 Pull Up Register. Byte3: Port 1 Pull Up Register. Byte4: USB Port Address. Byte5: RS232 Rx Status. Returns the available data count in the lower nibble. Bit 7of 7 is set on Rx Buffer overflow and bit 6/7 is set on Rx framing error. Byte6: RS232 Tx Status. The lower nibble returns the number of data bytes still pending in the Tx buffer. Bit 7of 7 is set on a Tx buffer overflow. Byte7: Bit 4/7 is set if an I2C error is detected. This bit is update each time an I2C function is called.		
11	10	0	Reads the firmware information. Byte 0-3: Unique Device Serial Number. DWORD Little Endian. Byte 4: Firmware Version. Byte 5: Firmware Date. Byte 6: Firmware Month. Byte 7: Firmware Year.		
11	12	0	Reads 8 bytes of memory data. This is peek functions used only for firmware debugging. The LSB data bytes contains the start address of the 8 returned bytes.		
11	17	1-8	Read 64 Bit Command. This command reads 8 bytes of data from the external hardware. The LSB of the returned	8	
11	18	1-8	data is address zero. This commands requires external hardware. See USB64BIO-Sch.pdf on our website. Write 2 bytes, Read 8 byte Command. This command reads 8 bytes of data from the external hardware, similar to the above command. But the data in DataLSB and DataMSB is write to the write address latch 0 and 1 respectively. This command was added to increase through put. This commands requires external hardware. See USB64BIO-Sch.pdf on our website.	10	
11	50	0	Reads the RS232 Rx Buffer. This byte returns 8 bytes, the first byte is the Rx Buffer Status and data count and the remaining bytes are the RS232 data bytes. The Rx buffer is 7 bytes deep and is in LSB first order. The Rx Status and data count byte are cleared when this command is issued. The lower nibble of the status byte contains the Rx buffer data length count, pin 70f 7 of the rx status byte is set on an Rx overflow and pin 6 of 7 is set on a Rx framing error. Note you can read both the Rx Status and Tx Status bytes with command 11-9 without clearing there content.		

11	60	0	Reads from the I2C Port. Reads 1 to 8 bytes of data from the I2C port. The device address/command is set in the data LSB byte and the number of requested bytes to read is set in the data MSB byte. If an error occurs bit 4/7 of byte 7 is set, else reset. See command 11-9.	6
11	61	0	Selective Reads from the I2C Port. This function sends a selective read command to the device, allowing the selective address to be sent before the read command is sent. This command is typically used in nonvolatile RAM type device such as the Xicor X24C04. The device address/command is set in the data LSB and the number of bytes requested is set in the data MSB byte. The selective address is setup with command 10-61. This command produces the following sequence; start, device address from 10-61 LSB byte is sent, selective address byte from 10-61 MSB byte is sent, start is sent again, the device address/command (LSB data from this command) is sent, then the data from the device is read and returned to the user. If an error occurs bit 4/7 of byte 7 is set, else reset. See command 11-9.	6
11	90	0-8	Read SPI Data	15
			Reads up to 8 bytes (64bits) of data from the SPI port. To read data from the SPI port first send the 10-90 Write SPI data command and then send this command. This command only returns the SPI data from the last 10-90 command issued. LSB and MSB bytes not used.	802x70
11	91	0-8	Write 1Byte Read 1-64 bits SPI	15
			Writes 1 byte of SPI data with 64 clocks and then returns 64bits (8Bytes) of data. This command simultaneously writes/reads to increase through put. The LSB byte should be set to the number of clocks required. The MSB byte should be sent to the byte to write. The write size limited to 1 byte.	802x70

6.0 Typical Schematic

Note - External oscillator not required on 802x70 chips.



7.0 Specifications

7.1 Absolute Maximum Ratings

Storage Temperature

Operating Temperature

Vss relative to Vcc

DC Input Voltage

DC voltage on HiZ pins

-65C to +150C

-0C to +70C

-0.5V to +7.0V

-0.5V to Vcc+0.5V

Max Current Summed on Port1 pins60maMax Current Summed on Port0 pins10maPower Dissipation300mWStatic Discharge Voltage>2000VLatch Up Current200mA


7.2 Electrical Characteristics

Vcc Operating Current25mAVcc Limits4 to 5.25VPort 0 Max Current Sink1.5mAPort 0 Min Current Sink0.3mAPort 1 Max Current Sink24mAPort 1 Min Current Sink4.8mAPull Up Resistor16Kohms

Input Hysteresis Voltages P0 &P1 Min6% Max12% Vcc

Packet Bandwidth 100 Packet/sec

8.0 Package Diagrams



20 pin DIP 0.300" also available.

9.0 Ordering Information

Order Number	Number GPIO	Package Type
802600*	16	24 Pin (300Mil) SOIC
802300*	12	20 Pin (0.300") DIP
802200*	12	20 Pin (300Mil) SOIC
802270	10	18 Pin (300Mil) SOIC
802370	10	18 Pin (0.300") DIP
802670	16	24 Pin (300Mil) SOIC
802770	16	24 Pin (0.300") DIP

^{*} Not recommended for new designs

10.0 Firmware Release Notes

Version 2 - Added data strobe functions.

Version 3 - Added event counter function.

Version 4 - Fixed error with USB enumeration

Version 5 - Added RS232 and 8 byte Strobe Functions.

Version 6 - Added I²C communication functions.

Version 7 - Added buzzer functions.

Version 8 - Added 64 Bit Rd/Wr & Acknowledge pin.

Version 9 - Fixed error with RS232 Rx function.

Version 10 - Added 11-18 write 2 bytes & read 8 byte command.

Version 11 - I2C fixed, regarding data contention during the ACK bit.

Version 12 - 2005-05-25 Fixed I2C Stop condition introduced in v11. Changed I2C Start to SDA high, then SCLK high to improve Selective reads. Added command 11-62 - Selective read 16 bit, same as 11-61 but 16bit instead of 8bit address.

Version 12 - 2005-06-16 Added PWM functions on pins P1.0, P1.1 and P1.2, 78.125Hz used for LED dimming, Default to 100(OFF) is USBIO and 80 in LAMP Firmware only.

Version 13 - 2005-06-29 Added I2C clock stretching option to read and write commands. Maximum clock stretch per clock is 615us.

Version 14 - 2005-09-19 Re-added command 11-18 that was dropped in version 11 by mistake.

Version 15 - 2005-11-10 Added SPI support - P0.7=SPICLK P0.6=MOSI P0.7=MISO

- Change port configuration to first write 0xFF to the data latch and then change the mode to open drain. Before the port mode was changed before the port data latch was set. This caused a momentary low on the output pins.

Version 16 - 2005-11-16 Added string LUT max index test, code now returns a NAK if index is invalid. Before this fix the USB host could request a index to string passed the end of the table, this would cause the code to jump to a unknown location.

11.0 Trouble Shooting

If Windows does not see the USB device in the Windows Device Manager or it is listed as an 'Unknown device' then you have a hardware problem. Most common errors are; Reserved D+/D-(green/white) wires, 7.5K 1% resistor on incorrect pin, Missing +5Volts or Ground, and VPP pin not tied to ground. Make sure your cuicuit matches the USBIODEVSCH.pdf schematic available on the web.

12.0 Notes

12.1 Power Notes

When the device boots up the total current consumed by the device should be at a minimum to comply with the USB standard.

Cable length and cable size should be selected in order to maintain an operating voltage at the USB I/O chip of at least 4Volts.

This device can be used in a self-powered mode or with an external power supply if more than 450mA is required by user. When using external power supplies, connect the USB I/O chip Vcc to the USB supplied power and run the user added circuitry off the external power supply. Do not connect the USB Vcc and external power supplies together, only connect the grounds.

12.2 Interfacing

When interfacing the USB I/O chip to other circuitry, one must be careful not to over load the current on the pins and not to exceed the voltage on the pins. If the voltage or current is greater than and/or less than the levels on the USB I/O chip, you will have to add some sort of buffering or interfacing. For example most relays require more than 25mA to actuate the relay, and the USB I/O device can only sink 25mA. Therefore a current amplifier is required, such as a transistor. When working with excessive currents, voltages or with high EMI circuits it is recommended that you use relays and/or opto-couplers to isolate the circuits. See 'Interfacing to USB I/O Devices' on the website.