SECTION 26 2816.02 - FUSES

PART 1 - GENERAL

1.1 **RELATED DOCUMENTS**

A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

1.2 **SUMMARY**

- Α. This Section includes the following:
 - Cartridge fuses rated 600 V and less for use in switches. 1
 - 2. Spare-fuse cabinets.

1.3 RELATED WORK SPECIFIED ELSEWHERE

A. See Section - "Short Circuit and Protective Device Coordination Study."

1.4 **SUBMITTALS**

- A. Product Data: Include the following for each fuse type indicated:
 - Dimensions and manufacturer's technical data on features, performance, electrical characteristics, and ratings.
 - 2. Let-through current curves for fuses with current-limiting characteristics.
 - Time-current curves, coordination charts and tables, and related data. 3.
 - Fuse size for elevator feeders and elevator disconnect switches.
- В. Ambient Temperature Adjustment Information: If ratings of fuses have been adjusted to accommodate ambient temperatures, provide list of fuses with adjusted ratings.
 - For each fuse having adjusted ratings, include location of fuse, original fuse rating, local ambient temperature, and adjusted fuse rating.
 - Provide manufacturer's technical data on which ambient temperature adjustment calculations are 2. based.
- C. Operation and Maintenance Data: For fuses to include in emergency, operation, and maintenance manuals.
 - In addition to items specified in Division 01 Section "Operation and Maintenance Data," include the following:
 - Let-through current curves for fuses with current-limiting characteristics. a.
 - Time-current curves, coordination charts and tables, and related data. b.
 - Ambient temperature adjustment information. C.

1.5 QUALITY ASSURANCE

- Source Limitations: Obtain fuses from a single manufacturer. A.
- В. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, Article 100, by a testing agency acceptable to authorities having jurisdiction, and marked for intended use.
- C. Comply with NEMA FU 1.
- D. Comply with NFPA 70.

1.6 PROJECT CONDITIONS

Where ambient temperature to which fuses are directly exposed is less than 40 deg F (5 deg C) or more A. than 100 deg F (38 deg C), apply manufacturer's ambient temperature adjustment factors to fuse ratings.

FUSES 26 2816.02 - 1

COORDINATION 1.7

A. Coordinate fuse ratings with utilization equipment nameplate limitations of maximum fuse size.

PART 2 - PRODUCTS

2.1 **MANUFACTURERS**

- Available Manufacturers: Subject to compliance with requirements, manufacturers offering products that A. may be incorporated into the Work include, but are not limited to, the following:
- В. Manufacturers: Subject to compliance with requirements, provide products by one of the following:
 - Cooper Bussman, Inc.
 - Eagle Electric Mfg. Co., Inc.; Cooper Industries, Inc. 2.
 - Ferraz Shawmut, Inc. 3.
 - 4. Tracor, Inc.; Littelfuse, Inc. Subsidiary.

2.2 **CARTRIDGE FUSES**

Characteristics: NEMA FU 1, nonrenewable cartridge fuse; class and current rating indicated; voltage A. rating consistent with circuit voltage.

2.3 SPARE-FUSE CABINET

- A. Cabinet: Wall-mounted, 0.05-inch- (1.27-mm-) thick steel unit with full-length, recessed piano-hinged door and key-coded cam lock and pull.
 - Size: Adequate for storage of spare fuses specified with 15 percent spare capacity minimum.
 - Finish: Gray, baked enamel. 2.
 - Identification: "SPARE FUSES" in 1-1/2-inch- (38-mm-) high letters on exterior of door. 3.
 - Fuse Pullers: For each size of fuse. 4.
 - Place in the main electrical room. 5

PART 3 - EXECUTION

3.1 **EXAMINATION**

- Examine utilization equipment nameplates and installation instructions. Install fuses of sizes and with A. characteristics appropriate for each piece of equipment.
- B. Evaluate ambient temperatures to determine if fuse rating adjustment factors must be applied to fuse ratings.
- C. Proceed with installation only after unsatisfactory conditions have been corrected.

3.2 **FUSE APPLICATIONS**

- A. Motor Branch Circuits: Class RK1 or RK5, time delay.
- В. Other Branch Circuits: Class RK1, time delay or RK5, time delay.

3.3 INSTALLATION

- A. Install fuses in fusible devices. Arrange fuses so rating information is readable without removing fuse.
- B. Install spare-fuse cabinet(s).

FUSES 26 2816.02 - 2

3.4 IDENTIFICATION

A. Install labels indicating fuse replacement information on inside door of each fused switch.

END OF SECTION

FUSES 26 2816.02 - 3