Diamond DA40 XLS (GFC700, A.C.)

Initial

Check performance: Weather and Density Altitude Weight and Balance Flight Plan — File as reg. Papers (AROW, VOR) - Check Fire Extinguisher — Check Control Lock - Remove Master - On Flaps — Set to T/O, then LDG Pilot Pedals - Adiust Hobbs & Tach — Check vs. log Lights - Check Int./Ext. Fuel Gauges - Check level Master - Off

Exterior

Check quantity and quality: Fuel — Sump and measure Oil - Check (4-8 at, ideal 6 at) Remove and stow:

Pitot cover Cowl pluas Tie-downs

Chocks Check for damage and debris: Caps/Drains/Vents Propeller and Spinner

Air Intakes Exhaust Canopy Stall Orifice

Surfaces and Controls Pitot and Static Ports Gear/Tires/Brakes

Antennas

Final walk around — Complete

Interior

Passengers: Briefing - Complete Headsets - Connect Seatbelts - On ELT - Set to ARM Circuit Breakers — Check Front Canopy — Close Rear Door — Close Pedals - Adjust Fuel - Set to fullest tank

Brakes - Check

Pre-Engine Start

Electrical - Check all off Propeller - Set to high RPM Mixture - Set to idle cutoff Master - On Flaps — Up XPDR - Select VFR MFD - Select "Engine" Page Fuel Totalizer - Set Beacon - On Prop - Clear

Engine Start Cold Start

Throttle - Open halfway Fuel Pump - On

Mixture - Set to rich for 3-5 sec. Throttle - Open slightly

Hot Start Throttle - Open slightly

Fuel Pump - On Mixture - Set to rich for 3 sec.

Once Engine Starts

Ignition — Turn to start Mixture - Set to rich Throttle - Set to 1000 RPM Oil Pressure - Check Voltage - Check Annunciators — Check Fuel Pump - Off Mixture — Lean for ground ops

Pre-Taxi / Taxi

Avionics Master — On Intercom — Test w/ passengers Radio - Test at un-towered field Pitot Heat - On Autopilot - Test Lights — On as reg. ATIS / AWOS — Listen and note Altimeters - Set and check Clearance - Request as req. Transponder — Set code Radio - Set departure freq. Radio - Ready to taxi Mixture - Richen slightly for taxi Brakes - Test Check instruments: Altimeters - Correct HSI and Compass — Correct

Airspeeds — Zero

Run-up

Brakes - Set Trim - Set to T/O Flight Controls — Free & Correct Alternate Air - Test, Close Annunciations - None Fuel Tank - Switch Fuel Pump — On Mixture — Set to best power Throttle - Set to 2000 RPM Propeller - Cycle 3 times: RPM Decrease Manifold Pressure Increase Oil Pressure Decrease Ignition — Test L & R Magnetos Alternator Load — Check Fuel/Oil Pressure - Check Oil Temperature — Check Throttle - Test Idle Throttle Friction — Check/Set

Pre-takeoff

FMS Flight Plan - Activated CDI Nav Source — Set as req. Transponder - Check code Flans - Set to T/O Fuel Pump — On Front Canopy — Locked Rear Door - Locked Air Conditioning — Off as req. Lights — On as reg. Radio — Ready for departure

In-flight checklists →

Securing

Transponder — Set to VFR ELT - Verify silent Throttle — Set to 1000 RPM Hobbs/Tach & Fuel - Note Ignition — Check ground as reg. Liahts — Off Avionics Master - Off Mixture - Lean to cutoff Ianition — Off Pedals - Adjust for control lock Master - Off Control Lock, Covers — Install Tie-downs - Install

Diamond DA40 XLS (GFC700, A.C.)

Takeoff

Time - Note Landing Light — On Mixture — Set as reg. for alt. Throttle - Set to full RPM - Check <= 2700 RPM Oil Pressure - Check Brakes - Belease Rotate at 60 KIAS Initial climb at 67 KIAS Flaps — Up at safe altitude Fuel Pump — Off >1,000' AGL Continue climb at 76 KIAS

Climb

Cruise climb at 76 KIAS Landing Light - Off Mixture — Lean as reg. for alt. Oil Temperature — Check CHT - Check Fuel Pump - On >10.000' MSL

Cruise

Propeller - Set to 2450 RPM Fuel Pump - On >10.000' MSL Mixture - Lean for alt. Fuel Tank — Switch as reg.

Descent

Fuel Tank - Set to fullest tank Fuel Pump - Off <10,000' MSL Mixture — Set richer as req. ATIS / AWOS — Listen and note Altimeters — Set for destination Radio - Call as reg.

Constant Airspeed Descent

AS - Maintain ~130 KIAS VS - Maintain ~500 fpm Propeller — Set to 2200 RPM Throttle — Set to 15" or as req.

Low Airspeed, Steep Descent

AS - Maintain ~80 KIAS VS - Maintain ~500 fpm Propeller — Set to 1800 RPM Throttle - Set to 10" or as req

High Airspeed, Shallow Descent

AS - Maintain <178 KIAS VS — Maintain as rea. Propeller — Set to 2450 RPM Throttle - Set to full

Pre-landing

Seatbelts - On Landing Light — On Fuel Pump - On Mixture - Set for alt. Flaps - Set to T/O at 108 KIAS Air Conditioning — Off as reg.

Landing

Flaps - Set to LDG at 91 KIAS Approach at 73 KIAS

Go Around

Mixture - Set richer as rea. Propeller — Set to high RPM Throttle - Set to full Flaps — Set to T/O Initial climb at 67 KIAS

After Landing

Flaps - Up Pitot Heat - Off Fuel Pump - Off Lights — Set as reg. Mixture — Lean for ground ops Trim - Set to T/O Air Conditioning — On as req.