1. Conductors have how many valence electrons in their atoms?	(c) The voltage required for a diode to operate.
(a) Three to four	(d) The ratio of heat to amps characteristic.
(b) Five to seven	8. The polarity of a diode can be confirmed by:
(c) Eight	(a) Using a voltmeter
(d) One or two	(b) Using an ohmmeter
2. Examples of semiconductor materials are:	(c) Using an ammeter
<ul><li>(a) Copper and iron</li><li>(b) Silicon and germanium</li></ul>	<ul><li>(d) Using a caliper</li><li>9. LEDs emit light by which process?</li></ul>
(c) Arsenic and gallium	(a) Photosynthesis
(d) Hydrogen and oxygen	(b) Electroluminescence
3. P-type and N-type materials are made by:	<ul><li>(c) Entropy</li><li>(d) Combustion</li></ul>
(a) Adding electrons directly to the semiconductor.	10. Calculate the required resistance of a current
(b) Removing electrons directly from the semiconductor.	limiting resistor needed for a LED operated at 15mA with a 12V DC source.
(c) Doping the semiconductor with a substance that has five or three valence electrons.	<ul> <li>(a) 600 Ω</li> <li>(b) 800 Ω</li> <li>(c) 5 Ω</li> </ul>
(d) Running a current through the semiconductor.	(d) 90 Ω
4. A PN junction is what kind of electronic device?	11. Transistors are made by joining
4. A I is junction is what kind of electronic device:	(a) three layers of semiconductor materials

(a) Diode

(b) Rectifier

(c) OR gate

5. \_\_\_\_\_ is the process of turning \_\_\_\_\_.

(b) Rectification, AC into DC

(c) Rectification, DC into AC

rectifiers used in electronic circuits.

7. Peak inverse voltage (PIV) is

(a) Commutation, voltage into current

(d) Inversion, capacitance into inductance

6. Bridge rectifiers are the most common type of

(a) The reverse bias at which break over oc-

(b) The forward bias at which the diode con-

(d) SCR

(a) True

(b) False

ducts.

- g
  - three layers of semiconductor materials.

- (b) two layers of semiconductor materials.
- (c) four layers of semiconductor materials.
- (d) a capacitor and inductor in series.
- 12. FET devices are used in applications requiring low-impedance input and/or high power consumption.
  - (a) True
  - (b) False
- 13. Phase controls use SCRs to
  - (a) Vary the timing of a switch.
  - (b) Align the phases of current and voltage.
  - (c) Vary the amount of power delivered to a load.
  - (d) Ensure lights on a circuit all turn on at the same time.
- 14. Diacs can be thought of as AC switches and triacs can be used in phase control applications.
  - (a) True
  - (b) False

- 15. PC (Printed Circuit Boards) use \_\_\_\_\_ instead of wires to electrically connect components.
  - (a) tin foil bonded strips glued to the board
  - (b) chemically etched copper circuits
  - (c) gold solder lines laid onto the board
  - (d) None of the above.
- 16. An integrated circuit (IC) is
  - (a) a hermetically sealed case containing a tiny wafer of semiconductor material.
  - (b) a PNPN connection.
  - (c) an operational amplifier.
  - (d) a device that uses optical transmission paths to transfer a signal.
- 17. A major advantage of microprocessors is its ability to provide very precise control.
  - (a) True
  - (b) False
- 18. Exmamples of safe ESD working practices include:
  - (a) Working in a carpeted area, using zip-lock bags
  - (b) Working in an area with tape, cardboard and plastic boxes.
  - (c) Using a ESD grounding strap, grounded work surface and ESD bags

- (d) Using radios, and non-ESD devices in the same work area.
- 19. Op amps have which qualities?
  - (a) High input impedance, low output impedance, low gain.
  - (b) Low input impedance, high output impedance, low gain.
  - (c) Low input impedance, low output impedance, high gain.
  - (d) High input impedance, low output imepdance, high gain.
- 20. Which gate gives a 0 only when both inputs are 1?
  - (a) XAND
  - (b) XOR
  - (c) NAND
  - (d) OR
- 21. Which gate gives a 1 only when both inputs are 0?
  - (a) NAND
  - (b) NOR
  - (c) AND
  - (d) OR