

Installation Guide



© Rei VILO, 2010-2012

Website http://sites.google.com/site/vilorei/

GitHub repository https://github.com/rei-vilo/embedXcode

Wundekit workspace http://www.wunderkit.com

How to Help!



Contribute to the project on GitHub.



Help me buy books on Xcode through my amazon Wish List.

Summary

1.	Installation			
2.	Create a New Project4			
3.	Project Configuration			
	3.1. Declare Sketch .pde File as C++ File	6		
	3.2. Declare User's Sketchbook	8		
	3.3. Add User's Libraries	9		
	3.4. Declare Sources for Code-Sense	11		
4.	Change the Board14			
5.	Re-Indexing Keywords15			
6.	Add a File19			
7.	Code-Sense Features			
	References			
9.	Version History20			


1. Installation

Before installing the template, here are the pre-requisites:

For all boards:

- Install Arduino 0023.
- · Launch it.
- Define the path of the sketchbook in the menu Arduino > Preferences > Sketchbook location.

Arduino provides the reference for code-sense.



- If chipKIT boards are to be used, install Mpide 0023.
- · Launch it.
- Define the path of the sketchbook in the menu Mpide > Preferences > Sketchbook location.

For other boards with a Processing-based IDE, same procedure:

- Install the corresponding Processing-based IDE.
- Launch it.
- Define the path of the sketchbook.
- Additionally, develop a specific makefile and adapt the Step1 makefile.












Now, the template can be installed:

Check and create ~/Library/Developer/Xcode

Copy the folder Templates into ~/Library/Developer/Xcode



2. Create a New Project


Call the menu File > New > New Project... or press 分彩N.


Select embedXcode > embedXcode.

Type in the name of the project.

Select the board on the drop-down list.

Click on Next to save.





3. Project Configuration

The template doesn't define all the parameters, so some of them need to be set manually.


The goal is to have the following work done by the template, provided the right keywords are known.

3.1. Declare Sketch .pde File as C++ File

The sketch . pde file is considered as plan text. For code-sense, it should be declared as C++ file.


Select the sketch . pde file.

In the right-most column,



Click on the drop-down list of File Type. Select C++ source.

Now, the sketch is considered as C++ code for code-sense.





3.2. Declare User's Sketchbook


The user's sketchbook is a folder where the user's sketches are saved, among them the libraries in a dedicated sub-folder Libraries.

Select the project and the Build Settings pane.

At the very bottom, double-click on SKETCHB00K_DIR and either type in the name of the folder or drag-and-drop it from a Finder window.

The ~ character is accepted.

If no sketchbook is defined, SKETCHB00K_DIR takes the value defined for Arduino or chipKIT during the installation process.



3.3. Add User's Libraries


Open the Sketchbook group on the project hierarchy. Right-click to obtain the contextual menu.

Choose Add file to...


Select the Library sub-folder on the sketchbook folder, tick Add to target > Index and validate with Add.

Both Create group for any added folders and Create folder references for any added folders are relevant.

Don't tick Copy items into destination group's folder (in needed) to avoid duplicating files.



The project hierarchy shows all your libraries.



3.4. Declare Sources for Code-Sense


Standard C++ keywords are already known, but not the Arduino and user's library keywords.

So Xcode needs to be taught where to find them.

Select the target Index and the Build Phases pane.

Build Phases **Build Rules** PROJECT mbed 140 Q Target Dependencies (0 items) ▼ Compile Sources (80 items) Compiler Flags main.cpp ...in embed140 O Serial EEPROM.cpp ...in embed140/Arduino/libraries/EEPROM O Upload Client.cpp ...in embed140/Arduino/libraries/Ethernet O Clean Ethernet.cpp ...in embed140/Arduino/libraries/Ethernet Make Server.cpp ...in embed140/Arduino/libraries/Ethernet Build Udp.cpp ...in embed140/Arduino/libraries/Ethernet socket.cpp ...in embed140/Arduino/libraries/Ethernet/utility w5100.cpp ...in embed140/Arduino/libraries/Ethernet/utility Firmata.cpp ...in embed140/Arduino/libraries/Firmata LiquidCrystal.cpp ...in embed140/Arduino/libraries/LiquidCryst File.cpp ...in embed140/Arduino/libraries/SD SD.cpp ...in embed140/Arduino/libraries/SD G Sd2Card.cpp ...in embed140/Arduino/libraries/SD/utility SdFile.cpp ...in embed140/Arduino/libraries/SD/utility SdVolume.cpp ...in embed140/Arduino/libraries/SD/utility

Go a the bottom of the list and click on the + button.



A list shows up.



Select all the .h and .cpp files and click on Add.




You're ready now!

4. Change the Board


To change the board, select the project and the Info pane.

Info PROJECT **Build Settings** ▶ Deployment Target ▼ Configurations **TARGETS** Name Based on Configuration File Index ▶ Debug No Configurations Set Boards **▶** Release No Configurations Set O All + - | Serial O Upload Command-line builds use Release + Clean **▼** Localizations Make Language Resources Build English 0 Files Localized

A drop-down list shows the boards available.



Just select one.



5. Re-Indexing Keywords

If code-sense doesn't work, we need to force a re-indexing of the key words.

To do so, first close the project.

Call the menu Window > Organiser and select the Projects pane.




Select then the project.

The index is saved within the Derived Data folder. Click on the Delete button to delete them.

Confirm the deletion.

Load the project.





There's no code-sense yet: everything is in black-and-white, except standard C++ keywords.

The index is being built.



When the index is built, code-sense shows pretty colours.

```
mbed200 - embed200.pde
                                        Build Serial: Succeeded | Yesterday at 21:59
                        No Issues
                    Breakpoints
IIII | ◀ ▶ | 🚵 embed200 ⟩ 🗀 embed200 ⟩ 🔜 embed200.pde ⟩ No Selection
          embedXcode
 // Core library
#include "WProgram.h"
 // Include application, user and local libraries #include "LocalLibrary.h"
     // Define variables and constants
     // Add setup code
    void setup() {
          Serial.begin(19200);
Serial.print("\n\n\n***\n");
     // Add loop code
void loop() {
     Serial.print(".");
    delay(100);
```

6. Add a File

Call the menu File > New > New File... or press #N

Select embedXcode and then Header File, C++ file or Library.



Library creates a header file and a C++ code file with the #include statement ready!

#include "LocalLibrary.h"

7. Code-Sense Features

Apart from pretty colours on the code and enhanced visibility, code-sense brings:

· auto-completion,

```
// Include application, user and local libraries
#include "LocalLibrary.h"
#include "IZC_Serial.h

// De IZC_Serial.h

IZC_Stepper.h

// Add setup code
void setup() {
Serial.begin(19200);
Serial.print("NnNnewsho");
```

- · code-snippets and check-as-you-type code monitoring,
- click-to-definition

8. References

See documents on the About folder for additional contributions and detailed references.

9. Version History

Release	Date	Content
1	Feb 15, 2012	Initial release
2	Feb 18, 2012	embedXcode 2 release