Arduino ABC Take a good start with Arduino

Jean-François Poilprêt Passionate Hobbyist



Agenda

- Arduino, what's that?
- What can you do with Arduino?
- How to start?
- Arduino UNO guts
- Arduino Tools
- Hello, Arduino!
- Electronics Basics: crash course
- Sensors & Actuators
- Practical experiments: digital & analog, inputs & outputs
- Arduino «shields»
- Arduino limits
- Useful links



Arduino, what's that?

- "Arduino is an <u>open-source</u> electronics <u>platform</u> based on easy-touse <u>hardware and software</u>. It's intended for <u>anyone</u> making interactive projects."
- Initially a project for IDII lvrea students (2005)
- Objectives
 - Cheap board to learn electronics
 - Quick to start with
 - Possible to "build your own"
- Open Source Hardware (Arduino boards schematics)
- Open Source Software (Arduino tools and libraries)
- Today, Arduino is an "ecosystem"
 - Many different kinds of boards
 - Many libraries for all kinds of devices
 - Community: web site, forums, fairs...



























What can you do with Arduino?

- Robots!
- Wearables
- Light decorations
- All kinds of alarms
- Weather stations
- Music
- Games
- ...
- Your imagination is the limit!








How to start?

- Afford a starter kit
 - Arduino Starter Kit
 - Sparkfun Inventor Kit
 - Fritzing Creator Kit
 - Adafruit Experimentation Kit
- Get comfortable with a breadboard




Afford a few often useful tools













Arduino UNO guts (board)



Arduino UNO guts (MCU)



- Atmel ATmega 328 P
 - RISC CPU 8-bits 16 MHz
 - Flash (programs) 32 KB
 - SRAM (live data) 2 KB
 - EEPROM (non volatile data) 1 KB
 - 20 Logical IO
 - 6 Analog Inputs
 - 3 Timers
 - USART: serial communication
 - SPI/TWI: interfaces bus

Arduino Tools

- MCU can be programmed in C, C++ or assembly
 - ATmel build tools (command-line): avr-g++, avr-gcc, avr-as, avr-ld...
- Arduino IDE integrates
 - Code editor (C/C++)
 - Builder
 - Uploader
 - Serial Monitor
- Arduino Libraries
 - Simplify developing programs (aka "sketches") for Arduino
 - Allow the same source code to target different boards (different hardware)
- Arduino "bootloader" (flashed on Arduino Boards MCU)
 - Allows new programs upload via USB
 - Starts your programs after reset
- Other tools exist (advanced only):
 - Eclipse plugin
 - ATmel Studio (Windows only)

Hello, Arduino!

- Simplest Arduino experiment
 - No additional hardware required!
 - Uses "pin 13" on-board LED
- Connect the board through USB
- Open Arduino IDE
 - Select Arduino type and port
 - Type first "sketch" in C language
 - Save it → new folder created with ".ino" source file
 - Build it → check size
 - Upload to board
- Arduino Sketch fundamentals:
 - void setup()
 - void loop()
 - pinMode()
 - digitalWrite()
 - delay()


Electronics Basics (1/2)

- Measures
 - U, V: voltage in Volt
 - I: current, intensity in Ampère
 - P: power in Watt
 - R: resistance in Ohm Ω
- Electric Circuit
 - A path (or network) through which current (electrons) can flow
 - Circuit must have a Voltage source (e.g. battery)
- Fundamental Laws
 - Ohm Law: U = R I



- Kirchoff's Current Law (nodal rule): $\sum I_k = 0$
- Kirchoff's Voltage Law (mess rule): ∑U_k = 0
- All 3 laws are constantly applied together






Electronics Basics (2/2)




Voltage Generator













Switch / Button












- Vf (forward voltage) is a constant depending on the diode model
- LED
 - Vf depends on LED color and model
 - Current must be limited to protect the LED





- "Hello Arduino" circuit (on-board, simplified)
 - P13 outputs either 0V or 5V
 - Why 1kΩ resistor?
 - Vf = $2.0V \rightarrow i = (5-2) / 1000 = 3mA$



Sensors & Actuators


- Sensors: devices to capture a physical property
 - Button
 - Temperature
 - Light
 - Flexion
 - Movement...
- Actuators: devices to act on environment
 - LED
 - Relay
 - DC motor
 - Servo motor
 - Stepper motor
 - Displays (LED, LCD)...





Experiment #1 – Digital inputs

- Do something if button pushed
 - Read button state (HIGH / LOW)
 - Echo state to serial monitor
- © Circuit #1.1
 - Problem? floating input!
- #1.2 with pull-up resistor




- #1.3 internal pull-up resistor
- #1.4 button bouncing issue
 - Hardware debouncing
 - Software debouncing


- Digital Levels in Volt:
 - 0 (LOW) \rightarrow 0 1.67V (5V/3)
 - 1 (HIGH) \rightarrow 3.3 (2x5V/3) 5V
 - 1.67 3.3V → undefined!
- Digital input API
 - pinMode(pinNum, INPUT)
 - digitalRead(pinNum)
 - pinMode(pinNum, INPUT PULLUP)
- Serial monitor API
 - Serial.begin(baudRate)
 - Serial.println(text)

Experiment #2 – Distance Meter

- Use an ultrasonic sensor
 - Datasheet
 - Trigger pin
 - Echo pin
 - Range: 2cm 4m
- Circuit #2.1



- #2.2 Distance calculation
 - Sound celerity ≈ 340m/s
 dist (mm) = echo(μs) x 340 x 1'000 / 1'000'000 / 2
- #2.3 Timeout (distance > 4m)
 - If distance > 4m
 - pulseIn will block 1s!
 - specify timeout TO ≈ 23'530μs
 TO = 2 x 4 / 340 x 1'000'000




- Digital input API
 - pinMode(pinNum, OUTPUT)
 - pinMode(pinNum, INPUT)
 - pulseIn(pinNum, level)
 - pulseIn(pinNum, level, to)
- Timing API
 - delayMicroseconds(time)

Experiment #3 – Analog inputs

 R_1

 R_2


- Variable resistance sensors
 - Light, Force, Flexion...
- Flexion sensor datasheet
 - Low accuracy (30%)!
- Arduino analog inputs
 - Measure voltage (0 5V)
 - How to measure resistance then?
- Voltage Divider
 - $V_{out} = V_{in} \times R_2 / (R_1 + R_2)$
 - R₁: flex sensor
 - R₂: 47kΩ optim. for largest range
- Circuit #3.1: calibration
 - 0° → 133
 - 90° > 85
- #3.2: convert V_{out} to angle



- -Flat Resistance: 25K Ohms
- -Resistance Tolerance: ±30%
- -Bend Resistance Range: 45K to 125K Ohms (depending on bend radius)
- -Power Rating : 0.50 Watts continuous. 1 Watt Peak
- Analog input API
 - analogRead(pinNum)
 - Returns int [0;1023]
- Utility API
 - map(value, srcLow, srcHigh, dstLow, dstHigh)

Experiment #4 – Analog outputs


- Display colors on a LED
 - 3 LED (R,G,B) in one
 - Common anode
 - Datasheet




- Forward Voltage (RGB): (1.9, 3.0, 3.0)V
- Max Forward Current (RGB): (20, 20, 20)mA
- Max Luminosity (RGB): (2800, 6500, 1200)mcd

Circuit

- Only Analog Output (~) pins
- Resistors to limit current
- Ohm law:
 - Red: I = 3.1 / 560 = 5.5mA
 - Green, Blue: 2 / 560 = 3.6mA
- Analog output uses PWM
- Pulse-Width Modulation






- Analog output API
 - analogWrite(pinNum, value)


Experiment #4 – Analog outputs

- Drive a DC Motor
 - Vary voltage > vary speed
- Caution! High current!
 - Can't drive directly from Arduino!
 - Use a transistor.
- Lenz's Law* > Back emf!
 - Fly-back diode
 - Circuit
 - Pin 3 ~
 - Analog output uses PWM —
 - Pulse-Width Modulation




Free-run speed @ 6V: 11500 rpm Free-run current @ 6V: 70 mA Stall current @ 6V: 800 mA





Characteristic	Symbol	Value	Unit
Collector - Emitter Voltage	V _{CEO}	40	Vdc
Collector - Base Voltage	V _{CBO}	75	Vdc
Emitter-Base Voltage	V _{EBO}	6.0	Vdc
Collector Current - Continuous	Ic	600	mAdc
Collector Current - Continuous	Ic	600	mAdc


- Analog output API
 - analogWrite(pinNum, value)



Buses – I²C & SPI

- Devices can perform complex functions & need complex communication with an MCU:
 - 3 axes accelerometer, IO multiplexers, LCD displays, Flash IC, SD Card, RTC...
- I²C & SPI are "standard" buses for electronic devices to interact

uС



SPI



- By Philips, standardized
- N Masters, P Slaves (address)
- 2 wires
- Connection wires need pull-up
- Half-duplex communication
- Speed: 100/400kHz (Arduino)
- Rather simple API
 - #include <Wire.h>

- By Motorola, de facto standard
- 1 Master, N Slaves
- (3 + N) wires
- Direct connection wiring
- Full-duplex communication
- Speed: up to 4MHz (Arduino)
- Rather simple API
 - #include <SPI.h>

Experiment #5 – I²C Real Time Clock

Keep accurate date/time

even when switched off

IC DS1307 + breakout board

I²C based, 100kHz, slave only

Imposed address: 0x68

Supply voltage: 5V

Time stored in "registers"

Reading Time =

Write address 1st register to read

Read all registers

Circuit

- I²C uses A4 (SDA) & A5 (SCL)
- Pullup resistors (4.7kΩ each)





Figure 6. Data Read (Write Pointer, Then Read)—Slave Receive and Transmit



Wire API

- Wire.begin()
- Wire.beginTransmission(addr)
- Wire.write(byte)
- Wire.endTransmission()
- Wire.requestFrom(addr, size)
- Wire.read()

Arduino «shields»

- Shields are boards that "plug" on an Arduino board
- You can piggy-pack several shields on the same Arduino board
- Official Arduino shields
- Third-party shields
- Various kinds
 - Ethernet
 - WIFI
 - Motors
 - GSM
 - Prototype...












- Easy to use but rather expensive
- Conflicts (pins sharing) between several boards



Arduino limits (& workarounds)

- Clock speed: 16MHz
 - Generally not a problem unless you need image processing...
 - If needed, use 2nd processor (e.g. Raspberry Pi) for heavy processing
- Flash (program) size: 32KB
 - Linker is smart enough to remove unused functions from final binary
 - Rule of thumb: remove all libs you don't use
- SRAM (data) size: 2KB
 - Don't use dynamic memory allocation
 - Remove useless global variables; prefer local variables
 - Put literal strings to Flash
- Power consumption:
 - Advanced: use ATmel MCU sleep modes
- IO pins number
 - Use "shift register" IC (present in most starter kits)
 - Use IO multiplexer IC (uses I²C bus)

Electronics Pitfalls

- Voltage drops due to high current consumption
 - Experiment #2.4: distance detector + LED display
 - Strange values can appear due to voltage drop!
 - Separate power sources (keep common ground)
 - Use decoupling capacitor
 - A capacitor is like an accumulator that loads & unloads charges very quickly



- Mixing voltages may fry your Arduino or other circuits
- Voltage adapters: various kinds with different advantages
- Switching high-currents
 - Directly plugging high-current devices to Arduino will fry it!
 - Transistors, Darlington (cascaded transistors), "Drivers"
 - → MOSFET
- Self inductance back emf when motors switched off
 - Can burn your complete circuit (very high voltage in short time)
 - Fly back diode



What I wish I had time to talk about...

- MOSFET Vs. Transistors to drive higher current devices
- Capacitors (always useful in electronics)
- Experiment driving a servo motor
- Experiment driving a stepper motor
- Interrupts on pin level changes
- More details about Arduino memory organization, tips and tricks
- ...
- All that might be in a future Arduino Advanced Talk...

Useful links

- Where to buy Arduino in Switzerland
 - http://www.play-zone.ch/
 - http://boxtec.ch/
 - http://www.conrad.ch/
- Arduino reference, Q&A
 - http://arduino.cc/
 - http://arduino.stackexchange.com/
- Major contributors
 - http://www.adafruit.com/
 - https://www.sparkfun.com/
- Interesting sites
 - Debouncing: http://www.ikalogic.com/de-bouncing-circuits/
 - Memory: https://learn.adafruit.com/memories-of-an-arduino/you-know-you-have-a-memory-problem-when-dot-dot-dot
 - Several advanced topics:
 http://www.gammon.com.au/forum/bbshowpost.php?bbtopic_id=123

Thank you!

Contact:

Jean-François Poilprêt



@jfpoilpret



https://github.com/jfpoilpret/arduino-talks



https://www.linkedin.com/pub/jean-francois-poilpret