6502 Stack

Philipp Koehn

2 March 2018





c64 emulator

PEEK and POKE



• POKE: directly write into memory

• PEEK: directly read memory value

- Example: write into screen memory
 - POKE 1024,1
 writes letter A into top left corner
 - PRINT PEEK(1024)
 returns 1

Character Encoding in Screen Memory



• What is the character encoding in screen memory?

• Let's write a program

Address	Bytes	Command
4200	A2 00	LDX #00
4202	8A	TXA
4203	9D 00 04	STA 0400,X
4206	E8	INX
4207	D 0 F9	BNE 4202
4209	60	RTS

• Run from BASIC: SYS 16896

Screenshot



```
000
                             VICE: C64 emulator
                                     0400,X
                                     4202
     READY.
PRINT PEEK(1100)
76
     READY.
POKE 53280,3
     READY.
```



stack

Stack



• Useful data structure

- LIFO: Last in, first out
 - PUSH 5
 - PUSH 2
 - PULL ightarrow 2
 - PULL \rightarrow 5



6502 Stack in Memory



• 2nd page in memory reserved ("page" = 256 bytes)

- Stack pointer
 - current free position
 - an address, e.g., 01FF
 - register in CPU

01FF	
01FE	
01FD	
01FC	
01FB	
01FA	
0 1F9	
0 1F8	
01F7	
0 1F6	
0 1F5	
01F4	
0 1F3	
0 1F2	
0100	



• PUSH 0A

\Rightarrow	01FF	
	01FE	
	01FD	
	01FC	
	01FB	
	01FA	
	0 1F9	
	01F8	
	01F7	
	01F6	
	01F 5	
	01F4	
	01F 3	
	01F2	
	0100	



- PUSH OA
 - store 0A to 01FF
 - decrease stack pointer to 01FE

	01FF	0A
\Rightarrow	01FE	
	01FD	
	01FC	
	01FB	
	01FA	
	0 1F9	
	01F8	
	01F7	
	0 1F6	
	0 1F5	
	01F4	
	01F 3	
	01F2	
	0100	



- PUSH OA
 - store 0A to 01FF
 - decrease stack pointer to 01FE
- PUSH 55

	01FF	0A
\Rightarrow	01FE	
	01FD	
	01FC	
	01FB	
	01FA	
	0 1F9	
	01F8	
	0 1F7	
	0 1F6	
	0 1F5	
	01F4	
	0 1F3	
	0 1F2	
	0100	
		<u> </u>



- PUSH 0A
 - store 0A to 01FF
 - decrease stack pointer to 01FE
- PUSH 55
 - store 55 to 01FE
 - decrease stack pointer to 01FD

	01FF	0A
	01FE	55
\Rightarrow	01FD	
	01FC	
	01FB	
	01FA	
	0 1F9	
	0 1F8	
	01F7	
	0 1F6	
	01F 5	
	01F4	
	0 1F3	
	01F2	
	0100	



- PUSH 0A
 - store 0A to 01FF
 - decrease stack pointer to 01FE
- PUSH 55
 - store 55 to 01FE
 - decrease stack pointer to 01FD
- PULL

	01FF	0A
	01FE	55
\Rightarrow	01FD	
	01FC	
	01FB	
	01FA	
	0 1F9	
	01F8	
	01F7	
	0 1F6	
	01F5	
	01F4	
	0 1F3	
	01F2	
	0100	



- PUSH 0A
 - store 0A to 01FF
 - decrease stack pointer to 01FE
- PUSH 55
 - store 55 to 01FE
 - decrease stack pointer to 01FD
- PULL
 - increase stack pointer to 01FE
 - retrieve 55 from 01FE

01FF	0A
01FE	55
01FD	
01FC	
01FB	
01FA	
0 1F9	
01F8	
01F7	
0 1F6	
0 1F5	
01F4	
0 1F3	
0 1F2	
0100	



- PUSH 0A
 - store 0A to 01FF
 - decrease stack pointer to 01FE
- PUSH 55
 - store 55 to 01FE
 - decrease stack pointer to 01FD
- PULL
 - increase stack pointer to 01FE
 - retrieve 55 from 01FE
- PUSH 42

	01FF	0A
•	01FE	55
	01FD	
	01FC	
	01FB	
	01FA	
	0 1F9	
	0 1F8	
	01F7	
	0 1F6	
	0 1F5	
	01F4	
	0 1F3	
	01F2	
	0100	



• PUSH OA

- store 0A to 01FF
- decrease stack pointer to 01FE
- PUSH 55
 - store 55 to 01FE
 - decrease stack pointer to 01FD
- PULL
 - increase stack pointer to 01FE
 - retrieve 55 from 01FE
- PUSH 42
 - store 42 to 01FE
 - decrease stack pointer to 01FD

01FF	0A
01FE	42
01FD	
01FC	
01FB	
01FA	
0 1F9	
01F8	
01F7	
0 1F6	
01F5	
01F4	
01F 3	
01F2	
0100	



6502 stack instructions

Basic Stack Manipulation



• Accumulator

- PHA: push accumulator to stack

PLA: pull accumulator from stack

• Processor status (flags)

– PHP: push processor status to stack

- PLP: pull processor status from stack



• Stack is a good place to safely store register values

• Example

```
PHA
TXA
PHA
TYA
PHA
(some code that changes registers)
PLA
TAY
PLA
TAX
PLA
(all registers back to original state)
```

Stack Pointer Instructions



- Read out stack pointer
- TSX: transfer stack pointer to X register
- TXS: transfer X register to stack pointer

Warning





- Stack is not very big (256 bytes)
- Too heavy use may lead to stack overflow



sub routines

Subroutines



- Subroutines are small programs that do common things
 - for instance: write a character at current cursor position
 - this is in the C64 kernel at address FFD2

• Naive usage

LDA #41
JMP FFD2

• Why won't that work? Subroutine does not know where to return to

Solution



- Use the stack!
- Jump to subroutine
 - store current program counter to stack
 - jump to subroutine address
- Return from subroutine
 - retrieve return address from stack
 - jump to retrieved address

6502 Subroutine Instructions



• JSR: Jump to subroutine

• RTS: Return from subroutine



• 4400 LDA #41

• 4402 JSR FFD2

	01FF	0A
	01FE	55
\Rightarrow	01FD	
	01FC	
	01FB	
	01FA	
	0 1F9	
	0 1F8	
	01F7	
	0 1F6	
	01F 5	
	01F4	
	0 1F3	
	01F2	
	0100	



- 4400 LDA #41
- 4402 JSR FFD2
 - program counter is 4405
 - store program counter

	01FF	0A
	01FE	55
	01FD	44
	01FC	05
\Rightarrow	01FB	
	01FA	
	0 1F9	
	01F8	
	01F7	
	01F6	
	01F 5	
	01F4	
	01F 3	
	01F2	
	0100	



- 4400 LDA #41
- 4402 JSR FFD2
 - program counter is 4405
 - store programm counter
- FFD2 JMP (0326)
- F1CA ...
- F207 RTS

	01FF	0A
	01FE	55
	01FD	44
	01FC	05
\Rightarrow	01FB	
	01FA	
	0 1F9	
	0 1F8	
	01F7	
	01F6	
	01F 5	
	01F4	
	01F 3	
	01F2	
	0100	



- 4400 LDA #41
- 4402 JSR FFD2
 - program counter is 4405
 - store programm counter
- FFD2 JMP (0326)
- F1CA ...
- F207 RTS
 - retrieve program counter from stack
 - jump to retrieved address
- 4405 ...

0A
55
44
05



example

Recursion



• Recursively calling subroutines

• Canonical example: Fibonacci numbers

$$f(x) = f(x-1) + f(x-2)$$

0, 1, 1, 2, 3, 5, 8, 13, 21, 34, 55, 89, 144, 233, ...

 \bullet $\lim_{x \to \infty} \frac{f(x+1)}{f(x)}$ is Golden Ratio

Code



```
START
       TXA
       BNE M01
                   ; f(0) = 0? no, continue
       RTS
                   ; yes
M01
       DEX
                   ; prepare for f(x-1) call
       BNE M02
                   ; f(1) = 1? no, continue
       RTS
                   ; yes
                   : save X on stack
M02
       TXA
       PHA
       JSR START ; result of f(x-1) in accumulator
                   ; let's put f(x-1) aside
       TAY
       PLA
                   ; get X back from stack
       TAX
       TYA
                   ; get f(x-1) back
                   : save that for now on stack
       PHA
                   ; prepare f(x-2)
       DEX
       ISR START
       STA TEMP
                   ; store f(x-2) for addition
                   : f(x-1) from stack
       PLA
       CI.C
       ADC TEMP ; f(x-1) + f(x-2)
       RTS
```



some more instructions

Logic



• Standard Boolean operations

- AND: bitwise AND

- ORA: bitwise OR

- EOR: bitwise XOR

• Operations impact negative and zero flag

• BIT: bitwise AND, but do not store result

Compare



- Compare register value
 - CMP: compare accumulator
 - CPX: compare X register
 - CPY: compare Y register
- Does not change register value
- Sets flags as in a subtraction (e.g., if values match, set zero flag)



some quirky things

Decimal Mode



• Decimal mode: pretend that hex numbers are really decimal numbers

LDA #07 CLC ADC #04

- Normally results in OB
- But in decimal mode: result 11
- Instructions
 - SED: set decimal mode
 - CLD: clear decimal mode

NOP



• NOP: No Operation

• Does nothing

• Useful as filler e.g., when deleting instructions