

# Cortex-M0+ Exceptions and Interrupts

Ravi Suppiah Lecturer, NUS SoC



#### Overview



- Exception and Interrupt Concepts
  - Entering an Exception Handler
  - Exiting an Exception Handler
- Cortex-M0+ Interrupts
  - Using Port Module and External Interrupts
- Timing Analysis
- Program Design with Interrupts
  - Sharing Data Safely Between ISRs and Other Threads
- Sources
  - Cortex M0+ Device Generic User Guide DUI0662
  - Cortex M0+ Technical Reference Manual DUI0484







# EXCEPTION AND INTERRUPT CONCEPTS



## Example System with Interrupt







- Goal: Change color of RGB LED when switch is pressed
- Will explain details of interfacing with switch and LEDs in GPIO module later
- Need to add external switch



#### How to Detect Switch is Pressed?




- Polling use software to check it
  - Slow need to explicitly check to see if switch is pressed
  - Wasteful of CPU time the faster a response we need, the more often we need to check
  - Scales badly difficult to build system with many activities which can respond quickly. Response time depends on all other processing.
- Interrupt use special hardware in MCU to detect event, run specific code (interrupt service routine - ISR) in response
  - Efficient code runs only when necessary
  - Fast hardware mechanism
  - Scales well
    - ISR response time doesn't depend on most other processing.
    - Code modules can be developed independently



## Interrupt or Exception Processing Sequence



- Other code (background) is running
- Interrupt trigger occurs
- Processor does some hard-wired processing
- Processor executes ISR (foreground), including return-from-interrupt instruction at end
- Processor resumes other code





## Interrupts




- Hardware-triggered asynchronous software routine
  - Triggered by hardware signal from peripheral or external device
  - Asynchronous can happen anywhere in the program (unless interrupt is disabled)
  - Software routine Interrupt service routine runs in response to interrupt
- Fundamental mechanism of microcontrollers
  - Provides efficient event-based processing rather than polling
  - Provides quick response to events regardless\* of program state, complexity, location
  - Allows many multithreaded embedded systems to be responsive without an operating system (specifically task scheduler)



## Example Program Requirements & Design





- Req I: When Switch SW is pressed, ISR will increment count variable
- Req2: Main code will light LEDs according to count value in binary sequence (Blue: 4, Green: 2, Red: I)





## **CORTEX-M0+ INTERRUPTS**



## Microcontroller Interrupts




- Types of interrupts
  - Hardware interrupts
    - Asynchronous: not related to what code the processor is currently executing
    - Examples: interrupt is asserted, character is received on serial port, or ADC converter finishes conversion
  - Exceptions, Faults, software interrupts
    - Synchronous: are the result of specific instructions executing
    - Examples: undefined instructions, overflow occurs for a given instruction
  - We can enable and disable (mask) most interrupts as needed (maskable), others are non-maskable
- Interrupt service routine (ISR)
  - Subroutine which processor is forced to execute to respond to a specific event
  - After ISR completes, MCU goes back to previously executing code



## Nested Vectored Interrupt Controller





- NVIC manages and prioritizes external interrupts for Cortex-M0+
- Interrupts are types of exceptions
  - Exceptions 16 through 16+N
- Modes
  - Thread Mode: entered on Reset
  - Handler Mode: entered on executing an exception
- Privilege level
- Stack pointers
  - Main Stack Pointer, MSP
  - Process Stack Pointer, PSP
- Exception states: Inactive, Pending, Active



## Some Interrupt Sources (Partial)


		100		-	National University of Singapore
Vector Start Address	Vector #	IRQ	Source	Description	of Singapore
0x0000_0004	1		ARM Core	Initial program counter,	/ Reset
0x0000_0008	2		ARM Core	Non-maskable interrupt	
0x0000_0040-4C	16-19	0-3	Direct Memory Access Controller	Transfer complete or err	or
0x0000_0058	22	6	Power Management Controller	Low voltage detection	
0x0000_0060-64	24-25	8-9	I <sup>2</sup> C Modules	Status and error	
0x0000_0068-6C	26-27	10-11	SPI Modules	Status and error	
0x0000_0070-78	28-30	12-14	UART Modules	Status and error	
0x0000_00B8	46	30	Port Control Module	Port A Pin Detect	
0x0000_00BC	47	31	Port Control Module	Port D Pin Detect	

Up to 32 non-core vectors, 16 core vectors From KL25 Sub-Family Reference Manual, Table 3-7



#### What's in the Vector Table?







## **NVIC** Registers and State

IPR1IRQ7reservedIRQ6reservedIRQ5reservedIRQ4reservedIPR2IRQ11reservedIRQ10reservedIRQ9reservedIRQ8reservedIPR3IRQ15reservedIRQ14reservedIRQ13reservedIRQ12reservedIPR4IRQ19reservedIRQ18reservedIRQ17reservedIRQ16reservedIPR5IRQ23reservedIRQ22reservedIRQ21reservedIRQ20reservedIPR6IRQ27reservedIRQ26reservedIRQ25reservedIRQ24reserved	Bits	31:30	29:24	23:22	21:16	15:14	13:8	7:6	5:0  National Unof Singap
IPR2IRQ11reservedIRQ10reservedIRQ9reservedIRQ8reservedIPR3IRQ15reservedIRQ14reservedIRQ13reservedIRQ12reservedIPR4IRQ19reservedIRQ18reservedIRQ17reservedIRQ16reservedIPR5IRQ23reservedIRQ22reservedIRQ21reservedIRQ20reservedIPR6IRQ27reservedIRQ26reservedIRQ25reservedIRQ24reserved	IPR0	IRQ3	reserved	IRQ2	reserved	IRQ1	reserved	IRQ0	reserved
IPR3IRQ15reservedIRQ14reservedIRQ13reservedIRQ12reservedIPR4IRQ19reservedIRQ18reservedIRQ17reservedIRQ16reservedIPR5IRQ23reservedIRQ22reservedIRQ21reservedIRQ20reservedIPR6IRQ27reservedIRQ26reservedIRQ25reservedIRQ24reserved	IPR1	IRQ7	reserved	IRQ6	reserved	IRQ5	reserved	IRQ4	reserved
IPR4IRQ19reservedIRQ18reservedIRQ17reservedIRQ16reservedIPR5IRQ23reservedIRQ22reservedIRQ21reservedIRQ20reservedIPR6IRQ27reservedIRQ26reservedIRQ25reservedIRQ24reserved	IPR2	IRQ11	reserved	IRQ10	reserved	IRQ9	reserved	IRQ8	reserved
IPR5IRQ23reservedIRQ22reservedIRQ21reservedIRQ20reservedIPR6IRQ27reservedIRQ26reservedIRQ25reservedIRQ24reserved	IPR3	IRQ15	reserved	IRQ14	reserved	IRQ13	reserved	IRQ12	reserved
IPR6 IRQ27 reserved IRQ26 reserved IRQ25 reserved IRQ24 reserved	IPR4	IRQ19	reserved	IRQ18	reserved	IRQ17	reserved	IRQ16	reserved
	IPR5	IRQ23	reserved	IRQ22	reserved	IRQ21	reserved	IRQ20	reserved
IPR7 IRQ31 reserved IRQ30 reserved IRQ29 reserved IRQ28 reserved	IPR6	IRQ27	reserved	IRQ26	reserved	IRQ25	reserved	IRQ24	reserved
	IPR7	IRQ31	reserved	IRQ30	reserved	IRQ29	reserved	IRQ28	reserved

- Priority allows program to prioritize response if both interrupts are requested simultaneously
  - IPR0-7 registers: two bits per interrupt source, four interrupt sources per register
  - Set priority to 0 (highest priority), 64, 128 or 192 (lowest)
  - CMSIS: NVIC\_SetPriority(IRQnum, priority), with priority set as 0, 1, 2 or 3



## **NVIC** Registers and State

Nus National University of Singapore

- Enable Allows interrupt to be recognized
  - Accessed through two registers (set bits for interrupts)
    - Set enable with NVIC\_ISER, clear enable with NVIC\_ICER
  - CMSIS Interface: NVIC\_EnableIRQ(IRQnum), NVIC\_DisableIRQ(IRQnum)
- Pending Interrupt has been requested but is not yet serviced
  - CMSIS: NVIC\_SetPendingIRQ(IRQnum), NVIC\_ClearPendingIRQ(IRQnum)



## Core Exception Mask Register



- Similar to "Global interrupt disable" bit in other MCUs
- PRIMASK Exception mask register (CPU core)
  - Bit 0: PM Flag
    - Set to I to prevent activation of all exceptions with configurable priority
    - Clear to 0 to allow activation of all exceptions
  - Access using CPS, MSR and MRS instructions
  - Use to prevent data race conditions with code needing atomicity

#### CMSIS-CORE API

- void \_\_\_enable\_irq() clears PM flag
- void \_\_\_disable\_irq() sets PM flag
- uint32\_t \_\_get\_PRIMASK() returns value of PRIMASK
- void \_\_set\_PRIMASK(uint32\_t x) sets PRIMASK to x



#### **Prioritization**



- Exceptions are prioritized to order the response simultaneous requests (smaller number = higher priority)
- Priorities of some exceptions are fixed
  - Reset: -3, highest priority
  - NMI: -2
  - Hard Fault: I
- Priorities of other (peripheral) exceptions are adjustable
  - Value is stored in the interrupt priority register (IPR0-7)
  - 0×00
  - 0x40
  - 0x80
  - 0xC0



## Special Cases of Prioritization



- Simultaneous exception requests?
  - Lowest exception type number is serviced first
- New exception requested while a handler is executing?
  - New priority higher than current priority?
    - New exception handler preempts current exception handler
  - New priority lower than or equal to current priority?
    - New exception held in pending state
    - Current handler continues and completes execution
    - Previous priority level restored
    - New exception handled if priority level allows






## EXAMPLE USING PORT MODULE AND EXTERNAL INTERRUPTS



## Refresher: Program Requirements & Design






- ReqI: When Switch SW is pressed, ISR will increment count variable
- Req2: Main code will light LEDs according to count value in binary sequence (Blue: 4, Green: 2, Red: I)
- \*Req3: Main code will toggle its debug line DBG\_MAIN each time it executes
- \*Req4: ISR will raise its debug line DBG\_ISR (and lower main's debug line DBG\_MAIN) whenever it is executing



### **KL25Z GPIO Ports with Interrupts**


- Port A (PTA) through Port E (PTE)
- Not all port bits are available (packagedependent)
- Ports A and D support interrupts





## FREEDOM KL25Z Physical Set-up







## Building a Program – Break into Pieces

National University of Singapore

- First break into threads, then break thread into steps
  - Main thread:
    - First initialize system
      - initialize switch: configure the port connected to the switches to be input
      - initialize LEDs: configure the ports connected to the LEDs to be outputs
      - initialize interrupts: initialize the interrupt controller
  - Then repeat
    - Update LEDs based on count
  - Switch Interrupt thread:
    - Update count
- Determine which variables ISRs will share with main thread
  - This is how ISR will send information to main thread
  - Mark these shared variables as volatile (more details ahead)
  - Ensure access to the shared variables is atomic (more details ahead)



#### Where Do the Pieces Go?



- main
  - top level of main thread code
- switches
  - #defines for switch connections
  - declaration of count variable
  - Code to initialize switch and interrupt hardware
  - ISR for switch
- LEDs
  - #defines for LED connections
  - Code to initialize and light LEDs
- debug\_signals
  - #defines for debug signal locations
  - Code to initialize and control debug lines



## Configure MCU to Respond to the Interrupt



- Set up peripheral module to generate interrupt
  - We'll use Port Module in this example


Set up NVIC

- Set global interrupt enable
  - Use CMSIS Macro \_\_enable\_irq();
  - This flag does not enable all interrupts; instead, it is an easy way to disable interrupts
    - Could also be called "don't disable all interrupts"



#### Port Module






- Port Module connects external pins to NVIC (and other devices)
- Relevant registers
  - PCR Pin control register (32 per port)
    - Each register corresponds to an input pin
  - ISFR Interrupt status flag register (one per port)
    - Each bit corresponds to an input pin
    - Bit is set to 1 if an interrupt has been detected



## Pin Control Register



- ISF indicates if interrupt has been detected different way to access same data as ISFR
- IRQC field of PCR defines behavior for external hardware interrupts
- Can also trigger direct memory access (not covered here)

IRQC	Configuration			
0000	Interrupt Disabled			
••••	DMA, reserved			
1000	Interrupt when logic zero			
1001	Interrupt on rising edge			
1010	Interrupt on falling edge			
1011	Interrupt on either edge			
1100	Interrupt when logic one			
•••	reserved			



#### Let's examine the Code...

- Setup LED's and Switch
  - Clock Gating
  - MUX Setting
  - Data Direction
  - Pull-Up Enable
  - Set Interrupt Priority
  - Enable Interrupt



## Write Interrupt Service Routine



- No arguments or return values void is only valid type
- Keep it short and simple
  - Much easier to debug
  - Improves system response time
- Name the ISR according to CMSIS-CORE system exception names
  - PORTD\_IRQHandler, RTC\_IRQHandler, etc.
  - The linker will load the vector table with this handler
- Clear pending interrupts
  - Call NVIC\_ClearPendingIRQ(IRQnum)
- Read interrupt status flag register to determine source of interrupt
- Clear interrupt status flag register by writing to PORTD->ISFR



### **ISR**



```
void PORTD_IRQHandler(void) {
      // clear pending interrupts
      NVIC_ClearPendingIRQ(PORTD_IRQn);
      if ((PORTD->ISFR & MASK(SW_POS))) {
            count++;
      // clear status flags
      PORTD->ISFR = 0xffffffff;
```



## Evaluate Basic Operation



- Build program
- Load onto development board
- Start debugger
- Run
- Press switch, verify LED changes color



### **Examine Saved State in ISR**



- Set breakpoint in ISR
- Run program
- Press switch, verify debugger stops at breakpoint
- Examine stack and registers






## **TIMING ANALYSIS**



## Big Picture Timing Behavior






- Switch was pressed for about 0.21 s
- ISR runs in response to switch signal's falling edge
- Main seems to be running continuously (signal toggles between I and 0)
  - Does it really?



### Visualizing the Timing of Processor Activities





 Indicate CPU activity by controlling debug output signals (GPIO)

```
while (1) {
   DEBUG_PORT->PTOR = MASK(DBG_MAIN_POS);
   control_RGB_LEDs(count&1, count&2, count&4);
}
```



## Interrupt Response Latency



- Latency = time delay
- Why do we care?
  - This is overhead which wastes time, and increases as the interrupt rate rises
  - This delays our response to external events, which may or may not be acceptable for the application, such as sampling an analog waveform
- How long does it take?
  - Finish executing the current instruction or abandon it
  - Push various registers on to the stack, fetch vector
    - C<sub>IntResponseOvhd</sub>: Overhead for responding to each interrupt)
  - If we have external memory with wait states, this takes longer



## Maximum Interrupt Rate



- We can only handle so many interrupts per second
  - F<sub>Max Int</sub>: maximum interrupt frequency
  - F<sub>CPU</sub>: CPU clock frequency
  - C<sub>ISR</sub>: Number of cycles ISR takes to execute
  - C<sub>Overhead:</sub> Number of cycles of overhead for saving state, vectoring, restoring state, etc.
  - $F_{Max Int} = F_{CPU}/(C_{ISR} + C_{Overhead})$
  - Note that model applies only when there is one interrupt in the system
- When processor is responding to interrupts, it isn't executing our other code
  - U<sub>Int</sub>: Utilization (fraction of processor time) consumed by interrupt processing
  - $U_{lnt} = 100\% *F_{lnt} * (C_{lSR} + C_{Overhead}) / F_{CPU}$
  - CPU looks like it's running the other code with CPU clock speed of (I-U<sub>Int</sub>)\*F<sub>CPU</sub>





## PROGRAM DESIGN WITH INTERRUPTS



## Program Design with Interrupts



- How much work to do in ISR?
- Should ISRs re-enable interrupts?
- How to communicate between ISR and other threads?
  - Data buffering
  - Data integrity and race conditions



#### How Much Work Is Done in ISR?



- Trade-off: Faster response for ISR code will delay completion of other code
- In system with multiple ISRs with short deadlines, perform critical work in ISR and buffer partial results for later processing





# SHARING DATA SAFELY BETWEEN ISRS AND OTHER THREADS



#### Overview



- Volatile data can be updated outside of the program's immediate control
- Non-atomic shared data can be interrupted partway through read or write, is vulnerable to race conditions



#### **Definitions**



- Race condition: Anomalous behavior due to unexpected critical dependence on the relative timing of events. Result of example code depends on the relative timing of the read and write operations.
- Critical section: A section of code which creates a possible race condition. The code section can only be executed by one process at a time. Some synchronization mechanism is required at the entry and exit of the critical section to ensure exclusive use.



## The End!

Thank You!

