Computertechnik

Jil Zerndt, Lucien Perret January 2025

Computer Engineering

What is Computer Engineering?


Computer Engineering is where microelectronics and software meet. It involves:

- Architecture and organization of computer systems
- Combines hardware and software to implement a computer
- Applications in embedded systems, information technology, and technical/scientific tools

Basic Hardware Components

A computer system consists of four fundamental components:

- CPU (Central Processing Unit): Processes instructions and data
- Memory: Stores instructions and data
- Input/Output: Interface to external devices
- System Bus: Electrical connection between components



CPU Components

The CPU contains several key components:


- Core Registers: Fast but limited storage inside CPU
- ALU (Arithmetic Logic Unit): Performs arithmetic and logic operations
- Control Unit: Reads and executes instructions
- Bus Interface: Connects CPU to system bus

Memory Types

- Main Memory (Arbeitsspeicher):
 - Connected through System-Bus
 - Access to individual bytes
 - Volatile: SRAM, DRAM
 - Non-volatile: ROM, Flash
- Secondary Storage:
 - Connected through I/O
 - Access to blocks of data
 - Non-volatile
 - Examples: HDD, SSD, CD, DVD

Program Translation Process

Translation from source code to executable involves four steps:



1. Preprocessor:

- Text processing
- · Includes header files
- Expands macros
- Output: Modified source program

2. Compiler:

- Translates C to assembly
- CPU-specific code generation
- Output: Assembly program

3. Assembler:

- · Converts assembly to machine code
- Creates relocatable object file
- Output: Binary object file

4. Linker:

- Merges object files
- Resolves dependencies
- Creates executable program
- Output: Executable file

Program Compilation Process

To compile and link a program:

- 1. Create source files (.c) and header files (.h)
- 2. Run preprocessor to expand includes and macros
- 3. Compile source files to object files
- 4. Link object files and libraries
- 5. Test executable

Simple Program Translation - From Source to Executable

```
#include <stdio.h>
#define MAX 100

int main(void) {
    printf("Max is %d\n", MAX);
    return 0;
}
```

Translation steps:

- 1. Preprocessor expands include and replaces MAX with 100
- 2. Compiler converts to assembly language
- 3. Assembler creates object file
- 4. Linker combines with C library to create executable

Computer Engineering

What is Computer Engineering?

Computer Engineering is where microelectronics and software meet. It involves:

- Architecture and organization of computer systems
- Combines hardware and software to implement a computer
- Applications in embedded systems, information technology, and technical/scientific tools
- Historical development spanning over 70 years:
 - 1940s: Relay/vacuum tubes
 - 1950s: Transistors
 - 1970s: Integrated circuits (CMOS)
 - Present: Complex microprocessors with billions of transistors


Early Computing Milestones

- 1943: First electronic computer ENIAC (18,000 tubes, 30 tons, 140 kW)
- 1947: First transistor at Bell Labs
- 1971: First microprocessor Intel 4004 (2300 transistors)
- 1978: Intel 8086 (29,000 transistors)
- Modern processors: Over 5 billion transistors

Basic Hardware Components

A computer system consists of four fundamental components:

- CPU (Central Processing Unit): Processes instructions and data
- Memory: Stores instructions and data
- Input/Output: Interface to external devices
- System Bus: Electrical connection between components
 - Address lines: Select memory location
 - Data lines: Transfer data (8/16/32/64 bits)
 - Control signals: Coordinate operations



CPU Components

The CPU contains several key components:

- Core Registers: Fast but limited storage inside CPU
- ALU (Arithmetic Logic Unit): Performs arithmetic and logic operations
- Control Unit:
 - Reads and executes instructions
 - Controls program flow
 - Manages instruction pipeline
- Bus Interface: Connects CPU to system bus

von Neumann Architecture

The fundamental architecture used in most computers:

- Single memory for both data and instructions
- Sequential instruction execution
- Components:
 - Control unit
 - ALU
 - Memory
 - Input/Output
- Key limitation: Memory bottleneck ("von Neumann bottleneck")

Memory Types

- Main Memory (Arbeitsspeicher):
 - Connected through System-Bus
 - Access to individual bytes
 - Volatile:
 - * SRAM (Static RAM) faster, more expensive
 - * DRAM (Dynamic RAM) needs refresh, cheaper
 - Non-volatile:
 - * ROM factory programmed
 - * Flash in-system programmable

• Secondary Storage:

- Connected through I/O
- Access to blocks of data
- Non-volatile
- Examples: HDD, SSD, CD, DVD
- Slower but cheaper than main memory

Memory Addressing

- Each byte in memory has a unique address
- Address space depends on address bus width:
 - 8-bit address bus: 256 bytes (2⁸)
 - 16-bit address bus: 64 KB (2¹⁶)
 - 32-bit address bus: 4 GB (2^{32})
- Memory map shows allocation of address ranges

Program Translation Process

Translation from source code to executable involves four steps:



1. Preprocessor:

- Text processing
- Includes header files (#include)
- Expands macros (#define)
- Output: Modified source program (.i)

2. Compiler:

- Translates C to assembly
- CPU-specific code generation
- Optimization (if enabled)
- Output: Assembly program (.s)

3. Assembler:

- Converts assembly to machine code
- Creates relocatable object file
- Generates symbol table
- Output: Binary object file (.o)

4. Linker:

- Merges object files
- Resolves dependencies
- Relocates addresses
- Links with libraries
- Output: Executable file (.axf)

Program Compilation Process

To compile and link a program:

- 1. Create source files (.c) and header files (.h)
- 2. Run preprocessor to expand includes and macros
- 3. Compile source files to object files
- 4. Link object files and libraries
- 5. Test executable

Common compiler flags:

- -c: Compile only, don't link
- -o: Specify output file name
- -O[0-3]: Optimization level
- -g: Include debug information

Simple Program Translation - From Source to Executable

```
// source.c
#include <stdio.h>
#define MAX 100

int main(void) {
   printf("Max is %d\n", MAX);
   return 0;
}
```

After preprocessing (.i):

```
// Contents of stdio.h included here
int main(void) {
    printf("Max is %d\n", 100);
    return 0;
}
```

Assembly output (.s):

```
AREA |.text|, CODE, READONLY
EXPORT main
main

PUSH {LR}
LDR R0, =string1
LDR R1, =100
BL printf
MOVS R0, #0
POP {PC}
ALIGN
string1 DCB "Max is %d\n",0
END
```

Host vs Target Development

When developing for embedded systems:

- Host: Development computer where code is written and compiled
- Target: Embedded system where code will run
- Cross-compilation: Compiling on host for different target architecture
- Tool chain: Complete set of development tools (compiler, linker, debugger)

Understanding assembly language is important because it:

- Helps understand machine-level operation
- · Aids in debugging and optimization
- Required for system programming
- · Essential for security analysis

Cortex-M Architecture

Core Architecture Overview

The ARM Cortex-M is a 32-bit processor architecture designed for embedded systems:

- Load/store architecture
- 32-bit data path
- Thumb instruction set
- · Hardware multiply and optional divide

Core Registers

The Cortex-M has 16 core registers, each 32-bit wide:

- R0-R7: Low registers general purpose
- R8-R12: High registers general purpose
- R13 (SP): Stack Pointer temporary storage
- R14 (LR): Link Register return address from procedures
- R15 (PC): Program Counter address of next instruction

ALU and Flags

The Arithmetic Logic Unit (ALU) is 32-bit wide and supports:


- Arithmetic operations (add, subtract, multiply)
- Logic operations (AND, OR, XOR)
- Compare operations
- Shift and rotate operations

The Application Program Status Register (APSR) contains flags:

- N: Negative result
- Z: Zero result
- C: Carry from operation
- V: Overflow occurred

Instruction Set

The Cortex-M uses 16-bit Thumb instructions:



Main instruction types:


- Data Transfer: Move, Load, Store operations
- Data Processing: Arithmetic, logical, shift operations
- Control Flow: Branch and function calls

Basic Assembly Program Structure Example of a simple assembly program:

1	Label	Instr.	Operands	Comments
2	demoprg	MOVS	RO,#0xA5	;copy 0xA5 into R0
3		MOVS	R1,#0x11	;copy 0x11 into R1
4		ADDS	RO, RO, R1	;add RO and R1, store in RO
- 1				

Assembly Program Sections

Program memory is organized in sections:



Directives for initialized data:

- DCB: Define Constant Byte (8-bit)
- **DCW**: Define Constant Half-Word (16-bit)
- DCD: Define Constant Word (32-bit)

Directive for uninitialized data:

• SPACE: Reserve specified number of bytes

Data Definition Memory layout for different data types:

1	var1	DCB	0 x 1 A	;single byte
2	var2	DCB	0x2B,0x3C,0x4D,0x5E	; byte array
3	var3	DCW	0x6F70,0x8192	;half-words
4	var4	DCD	0xA3B4C5D6	;word
5	data	SPACE	100	;reserve 100 bytes

Creating Assembly Programs

Steps to create an assembly program:

- 1. Define program sections (CODE, DATA)
- 2. Declare any external symbols (IMPORT/EXPORT)
- 3. Define initialized data using DCx directives
- 4. Reserve uninitialized data using SPACE
- 5. Write program code using proper instruction syntax
- 6. End program with END directive

Cortex-M Architecture

Core Architecture Overview

The ARM Cortex-M is a 32-bit processor architecture designed for embedded systems:

- Load/store architecture
- 32-bit data path
- Thumb instruction set
- Hardware multiply and optional divide
- Harvard architecture variant (separate instruction and data buses)
- Designed for embedded applications:
 - Low cost and power consumption
 - Real-time capabilities
 - Interrupt handling
 - Debug support

Core Registers

The Cortex-M has 16 core registers, each 32-bit wide:

- R0-R7: Low registers general purpose
- Used by most instructions
- Parameter passing in functions (R0-R3)
- Results returned in R0
- R8-R12: High registers general purpose
 - Limited instruction support
 - Often used for temporary storage
- R13 (SP): Stack Pointer
 - Points to current stack position
 - Must be word-aligned (multiple of 4)
- R14 (LR): Link Register
 - Stores return address for function calls
 - Can be saved to stack for nested calls
- R15 (PC): Program Counter
 - Points to next instruction
 - Auto-incremented during execution

ALU and Flags

The Arithmetic Logic Unit (ALU) is 32-bit wide and supports:

- Arithmetic operations:
 - Addition (ADD, ADC)
 - Subtraction (SUB, SBC)
 - Multiplication (MUL)
 - Division (Optional)
- Logic operations:
 - AND, ORR, EOR (XOR)
 - BIC (Bit Clear)
 - MVN (NOT)
- Shift and rotate operations
- Compare operations

The Application Program Status Register (APSR) contains flags:

- N: Set when result is negative (bit 31 = 1)
- **Z**: Set when result is zero
- C: Set on carry or borrow
- V: Set on signed overflow

Instruction suffix 'S' (e.g., ADDS) updates these flags.


Flag Usage Examples

After arithmetic operations with 'S' suffix:

```
MOVS
        RO, #0xFF
                      ; R0 = 255 (max)
    unsigned 8-bit)
        RO, #1
ADDS
                     ; RO = O, Z=1, C=1
    (overflow)
MOVS
        R0, #0x7F
                     ; R0 = 127 (max signed
    8-bit)
ADDS
        RO, #1
                     ; RO = 128, N=1, V=1
    (signed overflow)
MOVS
        RO, #5
SUBS
        RO, #10
                     ; R0 = -5, N=1, C=0
    (borrow)
```

Instruction Set

The Cortex-M uses 16-bit Thumb instructions:



Main instruction types:

- Data Transfer:
 - MOV/MOVS Register to register
 - LDR/STR Memory access
 - PUSH/POP Stack operations
 - LDM/STM Multiple register transfer
- Data Processing:
 - ADD/SUB Arithmetic
 - AND/ORR/EOR Logical
 - LSL/LSR/ASR Shifts
- CMP/CMN Compare
- Control Flow:
 - B Branch
 - BL Branch with Link
 - BX Branch and Exchange
 - Conditional variants (BEQ, BNE, etc.)

Common Instruction Formats

Register operations:

```
ADDS RO, R1, R2 ; R0 = R1 + R2
MOVS RO, R1 ; R0 = R1
ANDS RO, R1 ; R0 = R0 & R1
```

Immediate values:


```
MOVS RO, #100 ; Load immediate value
ADDS RO, RO, #1 ; Add immediate
CMP RO, #10 ; Compare with
immediate
```

Memory access:

```
LDR RO, [R1] ; Load from memory
STR RO, [R1, #4] ; Store with offset
LDRB RO, [R1] ; Load byte
```

Assembly Program Sections

Program memory is organized in sections:



Code Section (CODE):

- Contains program instructions
- Usually read-only
- Placed in Flash memory
- Can contain constants (literal pool)

Data Section (DATA):

- Contains global/static variables
- Read-write access
- Placed in RAM
- Initialized at startup

Stack Section:

- Dynamic memory allocation
- Used for local variables
- Function call management
- Function can management
- Grows downward in memory

Writing Assembly Programs

Steps for creating an assembly program:

1. Setup sections:

```
AREA |.text|, CODE, READONLY
AREA |.data|, DATA, READWRITE
```

2. Declare external symbols:

3. Define data:

```
AREA |.data|, DATA, READWRITE
var1 DCD 0x1234 ; Word
array SPACE 100 ; Reserve space
```

4. Write code:

```
AREA |.text|, CODE, READONLY
ENTRY; Program entry
main
; Your code here
END
```

Complete Program Example

Program to sum array elements:

```
AREA
             |.text|, CODE, READONLY
     EXPORT
             array_sum
 array_sum
     MOVS
             R2, #0
                              ; Initialize sum
     MOVS
             R3, #0
                              ; Initialize index
7 100p
     LDR
                              ; Load array element
             R1, [R0, R3]
     ADDS
             R2. R2. R1
                              : Add to sum
     ADDS
             R3, R3, #4
                              ; Next element
     CMP
             R3, #16
                              ; Check if done
     BLT
             loop
                             ; Continue if not
                              ; Return sum
     MOVS
             RO, R2
     BX
             LR
                             ; Return
     END
```

Common Assembly Patterns

1. Loop with counter:

```
MOVS RO, #0 ; Initialize counter loop ; Loop body ADDS RO, #1 ; Increment CMP RO, #10 ; Check condition BLT loop ; Branch if less than
```

2. Memory copy:

```
: R0 = source, R1 = destination, R2 = count
copy_loop
   LDR
            R3, [R0], #4
                            ; Load and increment
   STR
            R3, [R1], #4
                            : Store and
       increment
   SUBS
            R2, #1
                            ; Decrement counter
   BNE
                            ; Continue if not
            copy_loop
       done
```

3. Function call with parameters:

```
MOVS RO, #1 ; First parameter
MOVS R1, #2 ; Second parameter
BL function ; Call function
; Result in RO
```

Data Transfer

Data Transfer Overview

ARM Cortex-M uses a load/store architecture:

- Memory can only be accessed through load and store instructions
- All other operations work on registers
- · Various addressing modes for flexible memory access

Load Instructions

Main load instructions for moving data into registers:

- MOVS (Move and Set flags):
 - Register to Register: MOVS R1, R2
 - 8-bit immediate: MOVS R1, #0x1C
 - Constant: MOVS R1, #MyConst
- LDR (Load Register):
 - 32-bit literal: LDR R1, #0xA1B2C3D4
 - PC-relative: LDR R1, [PC, #12]
 - Pseudo instruction: LDR R1, =MyConst
- Register indirect: LDR R1, [R2]
- LDRB (Load Register Byte):
 - Loads 8-bit value
 - Bits 31 to 8 are set to zero
- LDRH (Load Register Half-word):
 - Loads 16-bit value
 - Bits 31 to 16 are set to zero

Store Instructions

Instructions for storing data from registers to memory:

- **STR** (Store Register):
 - Basic store: STR R1, [R2]
 - With offset: STR R1, [R2, #0x04]
- **STRB** (Store Register Byte):
 - Stores lowest 8 bits of register
- STRH (Store Register Half-word):
 - Stores lowest 16 bits of register

Memory Access Example

Loading and storing array elements:

```
00000000 11223344 my array
                                       0x11223344
                                DCD
00000004 55667788
                                DCD
                                       0x55667788
00000008 99AABBCC
                                       0x99AABBCC
                   AREA myCode, CODE, READONLY
                                                      Not content of my array,
                                                      but address of my_array
                   : load base and offset registers
0000007C 4906
                          R1,=my array ; load address of array
0000007E 4B07
                         R3,=0x08
                   ; indirect addressing
00000080 680C
                          R4, [R1]
                                           base R1
00000082 6840
                          R5, [R1, #0x04] ; base R1, immediate offset
                  LDR
```

R6, [R1, R3]


; base R1, offset R3

AREA my data, DATA, READWRITE

Memory Layout Example

00000084 58CE

Memory layout for array elements and instructions:



Size considerations:

- Array elements: 3 * 4 Bytes
- Instructions: 5 * 2 Bytes
- Literals (0x08): 1 * 4 Bytes

Memory Access Patterns

Steps for accessing memory:

- 1. Determine required data size (byte, half-word, word)
- 2. Choose appropriate load/store instruction
- 3. Calculate correct memory address
- 4. Consider alignment requirements
- 5. Load/store data using proper addressing mode

Basic Data Transfer Operations Common data transfer operations:

```
;Load operations
2 MOVS R1, #42 ;Load immediate value
3 MOVS R2, R1 ;Copy register
4 LDR R3, =0x1234 ;Load 32-bit constant
5 LDR R4, [R3] ;Load from memory
6 LDRB R5, [R3, #1] ;Load byte with offset
7 s;Store operations
9 STR R1, [R2] ;Store word
10 STRB R1, [R2, #4] ;Store byte with offset
11 STRH R1, [R2, R3] ;Store half-word with register offset
```

Data Transfer

Data Transfer Overview

ARM Cortex-M uses a load/store architecture:

- Memory can only be accessed through load and store instructions
- All other operations work on registers
- Various addressing modes for flexible memory access:
 - Immediate offset: Fixed displacement from base
 - Register offset: Variable displacement using register
 - Pre-indexed: Address calculated before access
 - Post-indexed: Address calculated after access

Load Instructions

Main load instructions for moving data into registers:

- MOVS (Move and Set flags):
 - Register to Register: MOVS R1, R2
- 8-bit immediate: MOVS R1, #0x1C
- Constant: MOVS R1, #MyConst
- Limitations: Only 8-bit immediates, only low registers
- LDR (Load Register):
 - 32-bit literal: LDR R1, #0xA1B2C3D4
 - PC-relative: LDR R1, [PC, #12]
 - Pseudo instruction: LDR R1, =MyConst
 - Register indirect: LDR R1, [R2]
 - Immediate offset: LDR R1, [R2, #4]
 - Register offset: LDR R1, [R2, R3]
- LDRB/LDRH (Load Byte/Half-word):
 - Zero extension to 32 bits
 - Common for arrays of bytes/shorts
- LDRSB/LDRSH (Load Signed Byte/Half-word):
 - Sign extension to 32 bits
 - Used for signed small integers

Load Instruction Examples

```
; MOV examples
        R1, #0xFF
                        ; Load immediate 255
MOVS
MOVS
        R2, R1
                        ; Copy R1 to R2
: LDR examples
        R1, =0x12345678; Load 32-bit
    constant
        R2, [R1]
                        ; Load from address
LDR
   in R1
LDR
        R3, [R1, #4]
                        ; Load with offset
        R4, [R1, R2]
                        ; Load with
    register offset
; Byte/Half-word loads
        R1, [R2]
                        ; Load unsigned byte
LDRB
      R1, [R2]
                        ; Load signed byte
LDRSB
LDRH
        R1, [R2]
                        ; Load unsigned
   half-word
LDRSH R1, [R2]
                        ; Load signed
   half-word
```

Store Instructions

Instructions for storing data from registers to memory:

- **STR** (Store Register):
 - Basic store: STR R1, [R2]
 - With immediate offset: STR R1, [R2, #0x04]
 - With register offset: STR R1, [R2, R3]
 - Word-aligned addresses only
- **STRB** (Store Register Byte):
 - Stores lowest 8 bits of register
 - No alignment requirements
- STRH (Store Register Half-word):
 - Stores lowest 16 bits of register
 - Must be half-word aligned

Accessing Array Elements

Steps for array access:

- 1. Calculate element offset:
- Byte array: offset = index
- Half-word array: offset = index * 2
- Word array: offset = index * 4
- 2. Choose appropriate instruction:
- LDRB/STRB for byte arrays
- LDRH/STRH for half-word arrays
- LDR/STR for word arrays

Example implementation:

```
; Access array[i] where i is in R1
; Array base address in RO
; For byte array
        R2, [R0, R1]
                        ; R2 = array[i]
; For half-word array
        R2, R1, #1
                        : R2 = i * 2
LDRH
        R3, [R0, R2]
                        ; R3 = array[i]
; For word array
LSLS
        R2, R1, #2
                        ; R2 = i * 4
LDR
        R3, [R0, R2]
                        ; R3 = array[i]
```

Multiple Data Transfer Loading/Storing multiple registers:

```
; Store multiple registers
PUSH
       {RO-R3, LR}
                       ; Push registers to
   stack
; Load multiple registers
       {RO-R3, PC}
                       ; Pop and return
; Load multiple memory locations
       RO!, {R1-R4} : Load 4 words.
   update RO
; Store multiple memory locations
       RO!, {R1-R4} ; Store 4 words,
    update RO
```

Memory Alignment

Important alignment rules:

- Word access (LDR/STR):
 - Address must be multiple of 4
 - Misaligned access causes fault
- Half-word access (LDRH/STRH):
- Address must be multiple of 2
- Byte access (LDRB/STRB):
- No alignment requirements
- Stack operations:
 - SP must be word-aligned
 - PUSH/POP automatically maintain alignment

Common Data Transfer Patterns

1. Copy memory block:

```
; R0 = source, R1 = dest, R2 = count
loop
    LDR
            R3, [R0], #4
                             ; Load and increment
            R3, [R1], #4
                             : Store and
        increment
    SUBS
            R2, #1
                             : Decrement counter
    BNE
                            ; Continue if not
            loop
        zero
```

2. Initialize memory block:

```
; R0 = start, R1 = value, R2 = count
loop
    STR
            R1, [R0], #4
                             ; Store and
        increment
    SUBS
            R2, #1
                             ; Decrement counter
    BNE
            loop
                            ; Continue if not
        zero
```

3. Search memory:

```
; RO = start, R1 = value to find, R2 = count
loop
            R3, [R0], #4
                             ; Load and increment
    LDR
            R3. R1
                             ; Compare with value
    CMP
            found
                             ; Branch if found
    BEQ
                             ; Decrement counter
    SUBS
            R2, #1
    BNE
            loop
                            ; Continue if not
not_found
    : Handle not found case
found
    ; Handle found case
```

Load/Store vs Register Memory Architecture

Two main approaches to memory access:

- Load/Store Architecture (ARM Cortex-M):
 - Memory accessed only with load/store operations
 - Data processing only between registers
 - Steps: Load operands \rightarrow Execute \rightarrow Store result
- Register Memory Architecture (e.g., Intel x86):
 - Operations can use memory operands directly
 - Results can be written directly to memory

 - More flexible but more complex instructions

LDR Pseudo Instructions

The LDR pseudo instruction LDR Rx, =value is expanded by the assembler:

- 1. For literal values:
- Assembler creates 'literal pool' at convenient location
- Allocates and initializes memory with DCD directive
- Uses PC-relative addressing to access value
- 2. For addresses:
- Places address in literal pool
- Generates PC-relative load instruction

Example:

```
LDR R1, =0xFF55AABO ; Pseudo
instruction
; Assembler converts to:
LDR R1, [PC, #offset]
...

DCD 0xFF55AABO ; In literal pool
```

Pseudo Instruction vs Direct Load The difference between LDR forms:

```
LDR R5, mylita ; Loads value at mylita 2 LDR R5, =mylita ; Loads address of mylita 3 mylita DCD 0xFF001122 ; Data definition
```

First instruction loads 0xFF001122, second loads address of mylita.

Multiple Register Transfer

LDM (Load Multiple) and STM (Store Multiple):

- Load/store multiple registers in one instruction
- More efficient than individual loads/stores
- Used for stack operations (PUSH/POP)
- Register list specified in curly braces

Example:

```
LDM R0!, {R1-R4} ; Load 4

consecutive words

R0!, {R1-R4} ; Store 4

consecutive words
```

Multi-Word Data Transfer

For transferring data larger than 32 bits:

1. Loading 96-bit value:

```
; Load 96-bit value from memory
; R3(MSW), R2, R1(LSW) contain result
; Memory address in R6
LDM R6, {R1-R3} ; Load all words at once

; Alternative using individual loads:
LDR R1, [R6] ; Load LSW
LDR R2, [R6, #4] ; Load middle word
LDR R3, [R6, #8] ; Load MSW
```

2. Storing 96-bit value:

```
; Store 96-bit value to memory
; R3(MSW), R2, R1(LSW) contain data
; Memory address in R6
STM
        R6, \{R1-R3\}
                        ; Store all words
    at once
: Alternative using individual stores:
        R1, [R6]
                        ; Store LSW
STR
        R2, [R6, #4]
                        ; Store middle word
STR
        R3, [R6, #8]
                        : Store MSW
```

Stack Access Instructions

Special variants of LDM/STM for stack operations:

- PUSH {register list}:
 - Decrements SP
 - Stores registers
 - Example: PUSH {RO-R3, LR}
- POP {register list}:
 - Loads registers
 - Increments SP
 - Example: POP {RO-R3, PC}

Important considerations:

- Always check alignment requirements
- Be aware of endianness (STM32 is little-endian)
- Consider using multiple register transfer for efficiency
- Manage literal pool placement in code
- · Stack operations must maintain SP word alignment

Arithmetic Operations

Processor Status Flags

APSR (Application Program Status Register) contains important flags affected by arithmetic operations:

- N (Negative): Set when result's MSB = 1, used for signed operations
- \mathbf{Z} (Zero): Set when result = 0, used for both signed/unsigned
- C (Carry): Set when unsigned overflow occurs
- V (Overflow): Set when signed overflow occurs

Instructions ending with 'S' modify these flags:

• ADDS, SUBS, MOVS, LSLS

Basic Arithmetic Instructions

Core arithmetic operations:

- ADD/ADDS: Addition (A + B)
- **ADCS**: Addition with Carry (A + B + c)
- **ADR**: Address to Register (PC + A)
- SUB/SUBS: Subtraction (A B)
- **SBCS**: Subtraction with carry/borrow (A B !c)
- **RSBS**: Reverse Subtract $(-1 \cdot A)$
- MULS: Multiplication $(A \cdot B)$

Two's Complement

For negative numbers:

- Two's complement: A = !A + 1
- Used for representing signed numbers
- Enables using same hardware for addition and subtraction

Carry and Overflow


Unsigned Operations:

- Addition: C = 1 indicates carry (result too large)
- Subtraction: C = 0 indicates borrow (result negative)

Signed Operations:


- Addition: V = 1 if overflow with operands of same sign
- Subtraction: V = 1 if overflow with operands of opposite signs

Multi-Word Addition Adding 96-bit values using ADCS:



```
ADDS R1, R1, R4 ; Add least significant words
ADCS R2, R2, R5 ; Add middle words with carry
ADCS R3, R3, R6 with carry
```

Multi-Word Subtraction Subtracting 96-bit values using SBCS:



```
SUBS R1, R1, R4; Subtract least significant words

SBCS R2, R5; Subtract middle words with borrow


SBCS R3, R3, R6; Subtract most significant words with borrow
```

Addition and Subtraction Examples Addition with carry (13d + 7d):

```
1101 (13d)
0111 (7d)
----
1 0100 (20d = 16d + 4d)
```

Subtraction with borrow (6d - 14d):

```
0110 (6d)
+ 0010 (TC of 14d)
----
1000 (8d - 16d = -8d)
```



Arithmetic Operations

Steps for arithmetic operations:

- 1. Determine if operation is signed or unsigned
- 2. Choose appropriate instruction (with or without 'S')
- 3. Consider potential carry/overflow conditions
- 4. For multi-word operations:
 - Start with least significant words
 - Use carry-aware instructions for higher words
 - Track flags through operation
- 5. Check relevant flags after operation

ALU Operation Fundamentals

The Arithmetic Logic Unit (ALU) processes data:

- 32-bit wide data processing unit
- Fixed point operations only (no floating point)
- Flag outputs indicate operation results
- Can perform both signed and unsigned operations
- Same hardware used for addition and subtraction

Addition Operations

Addition instructions and their uses:

- ADDS Rd, Rn, Rm
 - Rd = Rn + Rm
 - Updates flags
- Only low registers
- ADD Rd, Rm
- Rd = Rd + Rm
- No flag updates
- Can use high registers
- ADDS Rd, #imm
 - Rd = Rd + immediate
 - 8-bit immediate value only

Example encodings:

Subtraction Operations

Subtraction instructions and their uses:

- SUBS Rd, Rn, Rm
 - Rd = Rn Rm
 - Updates flags
 - Only low registers
- SUBS Rd, #imm
 - Rd = Rd immediate
 - 8-bit immediate value
- RSBS Rd, Rn, #0
 - Rd = -Rn (2's complement)
 - Special case for negation

Example encodings:

```
; Different SUB variants

SUBS R1, R2, R3 ; R1 = R2 - R3

SUBS R1, #100 ; R1 = R1 - 100

RSBS R1, R2, #0 ; R1 = -R2
```

Overflow Detection

Steps to detect overflow in arithmetic operations:

- 1. For unsigned arithmetic (using C flag):
- Addition: Check C flag (C=1 means overflow)
- Subtraction: Check C flag (C=0 means underflow)
- 2. For signed arithmetic (using V flag):
- Addition: Check V flag for same-sign operands
- Subtraction: Check V flag for opposite-sign operands

Example:

```
; Unsigned overflow detection
ADDS
        RO. R1
                         ; Perform addition
BCS
        overflow
                         ; Branch if carry
    set
; Signed overflow detection
        RO, R1
                         ; Perform addition
ADDS
BVS
        overflow
                         : Branch if
    overflow set
```

Flag Usage Examples of flag behavior:

```
; Zero flag example
MOVS
        RO, #5
SUBS
        RO, #5
                         ; Z=1 (result is
    zero)
; Negative flag example
        RO, #1
MOVS
SUBS
        RO, #2
                        ; N=1 (result is
    negative)
; Carry flag example
        RO, #0xFF
MOVS
        RO, #1
ADDS
                        ; C=1 (unsigned
    overflow)
; Overflow flag example
        R0, #0x7F
                        ; Max positive 8-bit
MOVS
ADDS
        RO, #1
                        : V=1 (signed
    overflow)
```

Number Circles and Two's Complement

Understanding arithmetic wrap-around:

- Fixed number of bits creates circular number space
- Addition moves clockwise on number circle
- Subtraction moves counter-clockwise
- Two's complement:
 - Invert all bits (one's complement)
 - Add 1 to result
 - Enables using addition hardware for subtraction

Example for 4-bit numbers:

```
Positive: 0000 to 0111 (0 to 7)
Negative: 1000 to 1111 (-8 to -1)
```

Multi-Word Arithmetic

Guidelines for operations on large numbers:

1. Addition sequence:

```
; 64-bit addition (R1:R0 + R3:R2)
        RO, R2
                        ; Add low words
ADDS
ADCS
        R1, R3
                        ; Add high words
   with carry
```

2. Subtraction sequence:

```
; 64-bit subtraction (R1:R0 - R3:R2)
                        ; Subtract low words
SUBS
        RO, R2
SBCS
        R1, R3
                        ; Subtract high
    words with borrow
```

3. Important considerations:

- Start with least significant words
- Use carry-aware instructions for higher words
- Ensure proper register allocation
- Track flags through entire operation

Multiplication Simple multiplication examples:

```
; Basic multiplication
MULS
        RO, R1, RO
                        ; R0 = R1 * R0
; Multiply by constant using shifts
        RO, RO, #2
                        : R0 = R0 * 4
; Multiply by 10 (8 + 2)
LSLS
        R1, R0, #3
                        ; R1 = R0 * 8
LSLS
        R2, R0, #1
                        ; R2 = R0 * 2
ADDS
        RO, R1, R2
                        : R0 = R0 * 10
```

Logic, Shift and Rotate Instructions

Logic Instructions


Base logic operations (affect only N and Z flags):

- ANDS: Bitwise AND (Rdn & Rm, a & b)
- BICS: Bit Clear (Rdn & !Rm, a & b)
- **EORS**: Exclusive OR (Rdn \$Rm, a ∧ b)
- MVNS: Bitwise NOT (!Rm, a)
- ORRS: Bitwise OR (Rdn # Rm, a | b)

Shift and Rotate Instructions

Shift operations for binary manipulation:

- LSLS: Logical Shift Left $(2^n \cdot Rn, 0 \to LSB)$
- LSRS: Logical Shift Right $(2^{-n} \cdot Rn, 0 \to MSB)$
- **ASRS**: Arithmetic Shift Right $(R^{-n}, \pm MSB \rightarrow MSB)$
- **RORS**: Rotate Right (LSB \rightarrow MSB)



Integer Casting

Extension (adding bits):

- Zero Extension (unsigned):
 - Fill left bits with zero
 - Example: $1011 \to 00001011$
- Sign Extension (signed):
 - Copy sign bit to the left
 - Example: $1011 \rightarrow 11111011$

Truncation (removing bits):

- Signed: May change sign
- Unsigned: Results in modulo operation

Integer Ranges by Word Size 8-bit integers:

- Unsigned: 0 to 255 (0x00 to 0xFF)
- Signed: -128 to 127 (0x80 to 0x7F)

16-bit integers:

- Unsigned: 0 to 65,535 (0x0000 to 0xFFFF)
- Signed: -32,768 to 32,767 (0x8000 to 0x7FFF)

32-bit integers:

- Unsigned: 0 to 4,294,967,295 (0x00000000 to 0xFFFFFFFF)
- Signed: -2,147,483,648 to 2,147,483,647 (0x80000000 to 0x7FFFFFFFF)

Logical Operations Common logic operations:

```
; Logic operations
ANDS RO, R1
                    ; RO = RO AND R1
BICS RO, R1
                    ; RO = RO AND NOT R1
EORS RO, R1
                    ; RO = RO XOR R1
MVNS RO, R1
                    ; RO = NOT R1
ORRS RO, R1
                    ; RO = RO OR R1
; Shift operations
LSLS RO, R1, #2
                    ; R0 = R1 \ll 2 (multiply by 4)
LSRS RO, R1, #1
                    : R0 = R1 >> 1 (divide by 2)
ASRS RO, R1, #2
                    ; R0 = R1 >> 2 (signed divide
    bv 4)
RORS RO, R1, #1
                    ; Rotate R1 right by 1 bit
```

Using Logic and Shift Instructions

Steps for bit manipulation:

- 1. Identify required operation (AND, OR, XOR, NOT, shift)
- 2. Choose appropriate instruction
- 3. Consider effect on flags if relevant
- 4. For shifts:
 - LSLS for multiplication by 2^n
 - LSRS for unsigned division by 2^n
 - ASRS for signed division by 2^n
- 5. For logic:
 - ANDS for bit masking
 - ORRS for bit setting
 - BICS for bit clearing
 - EORS for bit toggling

Flag Behavior with Logic Instructions

Logic instructions only affect N and Z flags:

- N flag: Set to bit 31 of result (MSB)
- Z flag: Set if result is zero
- C flag: Unchanged
- V flag: Unchanged

Special case for shift/rotate:

- C flag: Set to last bit shifted out
- N,Z flags: Set based on result
- V flag: Unchanged

Bit Manipulation Techniques

Common operations on individual bits:

1. Set specific bits:

```
; Set bits 0 and 4
MOVS
        R1, #0x11
                        ; Mask: 0001 0001
ORRS
        RO. R1
                        : Set bits in RO
```

2. Clear specific bits:

```
: Clear bits 1 and 5
MOVS
        R1, #0x22
                        ; Mask: 0010 0010
BICS
        RO. R1
                        : Clear bits in RO
```

3. Toggle specific bits:

```
; Toggle bits 2,3,4
MOVS
        R1, #0x1C
                         ; Mask: 0001 1100
EORS
        RO. R1
                         ; Toggle bits in RO
```

4. Test specific bits:

```
; Test bit 3
                        ; Mask: 0000 1000
MOVS
        R1, #0x08
ANDS
        R2. R0. R1
                        : Test bit
BEQ
        bit_is_clear
                        ; Branch if bit was
   0
```

Shift Operations for Arithmetic Using shifts for multiplication and division:

```
; Multiplication by powers of 2
        RO, RO, #1
                        ; R0 = R0 * 2
        RO, RO, #2
LSLS
                       ; R0 = R0 * 4
        RO, RO, #3
LSLS
                       ; R0 = R0 * 8
; Division by powers of 2
        RO, RO, #1
                       : R0 = R0 / 2
    (unsigned)
        RO, RO, #1
                       ; R0 = R0 / 2
    (signed)
; Multiply by 10 (8 + 2)
       R1. R0. #3
LSLS
                      : R1 = R0 * 8
ADDS
        RO, RO, R1
                       ; R0 = R0 + (R0 *
    8) = R0 * 9
ADDS
        RO, RO, RO
                       : R0 = R0 * 2 = R0
   * 10
```

Sign Extension Instructions

Instructions for extending smaller values:

- SXTB: Sign extend byte to word
 - Takes lowest byte
- Copies bit 7 to bits 31-8
- SXTH: Sign extend half-word to word
 - Takes lowest half-word
 - Copies bit 15 to bits 31-16
- UXTB: Zero extend byte to word
 - Takes lowest byte
 - Sets bits 31-8 to zero
- UXTH: Zero extend half-word to word
- Takes lowest half-word
- Sets bits 31-16 to zero

Type Conversion Examples Examples of common type conversions:

```
; Sign extension examples
        RO, R1
                        ; Sign extend byte
SXTH
        RO . R1
                        ; Sign extend
   half-word
; Zero extension examples
        RO. R1
                        : Zero extend byte
UXTH
        RO, R1
                        ; Zero extend
   half-word
; Manual sign extension
LSLS
        RO, RO, #24
                        ; Shift left 24 bits
        RO, RO, #24
                        ; Arithmetic shift
ASRS
   right 24
```

Type Conversion Guidelines

Steps for safe type conversion:

- 1. For unsigned to larger unsigned:
- Use zero extension (UXTB, UXTH)
- Or use LSLS followed by LSRS
- 2. For signed to larger signed:
- Use sign extension (SXTB, SXTH)
- Or use LSLS followed by ASRS
- 3. For reducing size (truncation):
- Use AND with appropriate mask
- Or store using STRB/STRH
- Check for potential data loss

Example:

```
: Convert 8-bit to 32-bit
MOVS
        RO, #0xFF
                        ; Load 8-bit value
SXTB
        R1, R0
                        ; Signed extension
UXTB
        R2. R0
                        ; Unsigned extension
: Truncate 32-bit to 8-bit
                        ; Create mask
MOVS
        R1, #0xFF
ANDS
        RO. R1
                        : Truncate to 8 bits
```


Important considerations:

- · Always consider signedness of values
- Check for potential overflow in arithmetic shifts
- Remember carry flag behavior in shifts
- Use appropriate extension for data type
- Consider performance impact of shifts vs multiply

Control Structures

Branch Instructions

Branch instructions control program flow:



Selection (IF-ELSE)

```
Assume: nr in R1
int32 t nr;
                                    isPositive in R2
int32 t isPositive;
                                         R1,#0x00
                                  CMP
if (nr >= 0) {
                                  BLT
                                         else
    isPositive = 1;
                                  MOVS
                                         R2,#1
                                  B -
                                         end if
else {
                           else
    isPositive = 0;
                                  MOVS
                                          R2,#0
                           end if
```

Switch Statement Implementation C code example:

```
uint32_t result, n;
switch (n) {
    case 0:
        result += 17;
        break;
    case 1:
        result += 13;
        //fall through
    case 3:
    case 5:
        result += 37;
        break;
    default:
        result = 0;
}
```

Assembly implementation with jump table:


```
NR_CASES
            EQU
case_switch CMP
                    R1, #NR CASES
            BHS
                     case_default
            LSLS
                    R1, #2
                                   ; * 4
            LDR
                    R7, =jump_table
            LDR
                    R7, [R7, R1]
            ADDS
                    R2, R2, #17
case_0
                     end_sw_case
            В
case 1
            ADDS
                    R2, R2, #13
case_3_5
            ADDS
                    R2, R2, #37
            В
                     end sw case
case_default MOVS
                    R2, #0
end sw case ...
jump_table DCD
                     case_0
            DCD
                     case 1
            DCD
                     case_default
            DCD
                    case 3 5
            DCD
                     case_default
            DCD
                     case_3_5
```

Loop Types

Three main types of loops:

```
int32_t nr;
int32_t sum;
...
sum = 0;
do {
    sum += nr;
} while (sum < 100);</pre>
```

Do-While (Post-Test Loop):



While (Pre-Test Loop):



Implementing Control Structures

Steps for implementing control structures:

- 1. Choose appropriate control structure:
 - If-then-else for simple decisions
 - Switch for multiple cases with same variable
 - Loops for repeated operations
- 2. For switches:
 - Create jump table
 - Calculate offset based on case value
 - Handle default case
- 3. For loops:
 - Initialize counter/condition
 - Place condition check appropriately
 - Ensure proper exit condition
 - Update variables correctly

Basic Control Structures Example implementations:

```
; If-then-else
    CMP
            RO, #0
                        ; Compare value
            else_label ; Branch if equal
    BEQ
    ; then code
    В
            endif_label
else_label
   ; else code
endif_label
            while cond ; Jump to condition
while_loop
    ; loop body
while_cond
    CMP
            RO, #10
                        ; Check condition
    BLT
            while loop ; Branch if less than
    ; Do-while loop
do_loop
    ; loop body
    CMP
            RO, #10
                        ; Check condition
    BLT
            do loop
                        ; Branch if less than
```

Branch Instruction Types

Classification of branch instructions:

- 1. Based on Condition:
- Unconditional:
 - B Branch always
 - BL Branch with Link
 - BX Branch and Exchange
- Conditional:
 - Flag-dependent (EQ, NE, CS, CC, etc.)
 - Arithmetic (HI, LS, GE, LT, etc.)
- 2. Based on Target Address:
- Direct: Target address in instruction
- Indirect: Target address in register
- Relative: Offset from current PC
- Absolute: Complete target address

Selection Implementation

Guidelines for implementing if-then-else structures:

1. Simple if-then:

```
; if (x > 0) { x++; }

CMP R0, #0 ; Compare x with 0

BLE endif ; Skip if x <= 0

ADDS R0, #1 ; x++
```

2. if-then-else:

```
; if (x > y) \{ x = y; \} else \{ y = x; \} 
            RO, R1
                           ; Compare x and y
            else part
                            ; Branch if x <= y
   BLE
   MOVS
            RO, R1
                           ; Then part: x = y
                           ; Skip else part
   В
            endif
else_part
            R1, R0
                           ; Else part: y = x
   MOVS
endif
```

3. Nested if:

```
; if (x > 0) {
         if (y > 0) {
             x = y;
   ; }
   CMP
            RO, #0
                            ; Check x > 0
            endif outer
   BLE
   CMP
            R1, #0
                            ; Check y > 0
            endif inner
   BLE
   MOVS
            RO, R1
                            ; x = y
endif_inner
endif outer
```

Loop Implementation

Templates for different loop types:

1. While loop:

2. Do-while loop:

```
; do { x++; } while (x < 10);

do_loop

ADDS R0, #1; ; x++;

CMP R0, #10; Check x < 10;

BLT do_loop; Continue if true
```

3. For loop:

```
; for (i = 0; i < 10; i++)
    MOVS
            RO, #0
                            ; i = 0
    В
            for_cond
for_loop
    ; Loop body
            RO, #1
    ADDS
                            ; i++
for_cond
    CMP
            RO, #10
                            ; Check i < 10
    BLT
            for_loop
                            ; Continue if true
```

Switch Implementation

Steps for implementing switch statements:

1. Range check and table access:

```
RO, #MAX_CASES ; Check range
BHS
        default case
                       ; If too high,
   default
LSLS
        RO, #2
                        ; Multiply by 4
LDR
        R1, =jump_table ; Load table address
ADD
       R1, R0
                       ; Add offset
LDR
        R1, [R1]
                       ; Load target
   address
        R1
                        ; Branch to case
BX
```

2. Jump table structure:

```
jump_table
DCD case_0 ; Case 0 handler
DCD case_1 ; Case 1 handler
DCD default_case ; Default handler
; ... more cases
```

3. Case handlers:

```
case_0
; Handle case 0
B switch_end
case_1
; Handle case 1
B switch_end
default_case
; Handle default case
switch_end
```

```
; for (i = 0; i < 5; i++) {
          if (i == 2) continue;
          for (j = 0; j < 3; j++) {
              if (i == 1) break:
              sum += i + j;
    ; }
    MOVS
            RO, #0
                             : i = 0
outer loop
    CMP
            RO, #2
                             ; Check i == 2
    BEO
            outer_continue
                            ; Skip if i == 2
                             ; j = 0
    MOVS
            R1, #0
inner_loop
    CMP
                             ; Check j == 1
            R1, #1
    BEO
            outer continue : Break to outer
        loop
    ADDS
            R2, R0, R1
                            ; Calculate i + j
    ADDS
            R4. R4. R2
                             ; Add to sum
    ADDS
            R1, #1
                             ; j++
    CMP
            R1, #3
                            ; Check j < 3
    BI.T
            inner_loop
                             : Continue inner
        loop
outer_continue
    ADDS
                             ; i++
            RO, #1
    CMP
            RO, #5
                            ; Check i < 5
    BLT
            outer_loop
                             : Continue outer
        loop
```

Subroutines and Stack

Subroutine Basics

Key elements of subroutines:

- Label to identify subroutine entry point
- Return instruction (BX LR) to exit
- Proper register management

Simple Subroutine Multiply by 3 implementation:

```
MulBy3 MOV R4, R0 ; Save input value LSLS R0, #1 ; Multiply by 2 ADD R0, R4 ; Add original value BX LR ; Return
```

Stack Operations

Stack characteristics:

- Stack Area: Continuous RAM section
- Stack Pointer (SP): R13, points to last written value
- Direction: Full-descending (grows toward lower addresses)
- Alignment: Word-aligned (4 bytes)
- Data Size: 32-bit words only

Main operations:

- PUSH: Decrements SP, then stores words
- POP: Loads words, then increments SP

Stack constraints:

- Number of PUSH and POP operations must match
- SP must stay between stack-limit and stack-base

```
ADDR LED 31 0
                          0x60000100
                                          Save LR and registers used
LED PATTERN
                          0xA55A5AA5
                                         by subroutine
subrExample
                          {R4,R5,LR}
                 ; write pattern to LEDs
                 LDR
                          R4,=ADDR LED 31 0
                 LDR
                          R5,=LED PATTERN
                                                 Call another subroutine
                 STR
                          R5, [R4]
                 BL
                          write7seg
                                         Restore registers and PC
```

Stack Operations Implementation PUSH implementation:

```
; PUSH {R2,R3,R6}

SUB SP, SP, #12 ; Reserve stack space

STR R2, [SP] ; Store R2

STR R3, [SP, #4] ; Store R3

STR R6, [SP, #8] ; Store R6
```

POP implementation:

```
; POP {R2,R3,R6}

LDR R2, [SP] ; Restore R2

LDR R3, [SP, #4] ; Restore R3

LDR R6, [SP, #8] ; Restore R6

ADD SP, SP, #12 ; Free stack space
```

Using Subroutines and Stack

Steps for implementing subroutines:

- 1. Define subroutine entry point with label
- 2. Save registers that will be modified
 - Use PUSH at start
 - Include LR if calling other subroutines
- 3. Implement subroutine logic
- 4. Restore registers in reverse order
 - Use POP before return
 - Can return using POP ..., PC if LR was saved
- 5. Return using BX LR if LR wasn't saved

Important considerations:

- · Always maintain stack alignment
- Match PUSH/POP pairs exactly
- Be careful with SP manipulation
- Consider nesting depth for stack space

Call and Return Mechanism

Basic subroutine mechanics:

- BL (Branch with Link):
- Stores current PC in LR (R14)
 - Branches to subroutine address
 - Direct and relative addressing
- BLX (Branch with Link and Exchange):
 - Similar to BL but with register-specified target
 - Indirect and absolute addressing
- Return:
 - Using BX LR
 - Or POP ..., PC if LR was saved

Nested Subroutine Calls Example of nested calls:

```
main
    BL
                             ; Call proc_a
            proc_a
    ; continue main
proc_a
    PUSH
            {LR}
                             ; Save return
        address
            proc_b
    BL
                             ; Call proc b
    POP
            {PC}
                             : Return to main
proc_b
    PUSH
            {LR}
                             : Save return
        address
    BL
                             ; Call proc_c
            proc_c
    POP
            {PC}
                             ; Return to proc_a
proc_c
    ; Do something
    BX
                             ; Return to proc b
```

Stack Frame Structure

Components of a stack frame:

- Saved Registers:
- Caller-saved (R0-R3, R12)
- Callee-saved (R4-R11)
- Link register (LR)
- Local Variables:
 - Allocated on stack if needed
 - Word-aligned access
- Parameters:
 - Beyond R0-R3 if needed
 - Pushed by caller

Stack Frame Management

Steps for function prologue and epilogue:

1. Function Prologue:

```
PUSH {R4-R7, LR} ; Save registers
SUB SP, SP, #locals ; Allocate local
vars
```

2. Function Epilogue:

```
ADD SP, SP, #locals; Deallocate locals POP {R4-R7, PC}; Restore and return
```

3. Stack frame access:

```
; Access local variables

STR R0, [SP, #0] ; First local

STR R1, [SP, #4] ; Second local

; Access parameters

LDR R0, [SP, #20] ; First stack

parameter
```

Stack Instructions

Special stack manipulation instructions:

- ADD/SUB SP:
 - Immediate offset 0-508
 - Must be multiple of 4
- SP-relative LDR/STR:
 - Immediate offset 0-1020
 - Used for frame access
- PUSH/POP:
 - Multiple register transfer
 - Maintains alignment
 - Can include PC/LR

Function Implementation Patterns

Common implementation patterns:

1. Simple function:

```
func PUSH {LR} ; Save return address ; Function body POP {PC} ; Return
```

2. Function with locals:

```
func PUSH {R4, LR} ; Save registers
SUB SP, #8 ; Space for locals
; Function body
ADD SP, #8 ; Remove locals
POP {R4, PC} ; Return
```

3. Function with parameters:

```
; RO-R3 = first 4 parameters
; [SP] = fifth parameter

func PUSH {R4-R6, LR}; Save registers
LDR R4, [SP, #16]; Load 5th param
; Function body
POP {R4-R6, PC}; Return
```

Stack Frame Layout Example of complete function:

```
; int calc(int a, int b, int c)
2; a in RO, b in R1, c in R2
                  {R4-R6, LR}; Save registers
3 calc
          ; Save parameters
          MOVS
                  R4. R0
                              : Save a
                  R5. R1
          MOVS
                              : Save b
          MOVS
                  R6, R2
                              ; Save c
          ; Call helper function
          MOVS
                  RO. R4
                              ; First param
          BL
                  helper
                              ; Call helper
          ; Continue calculation
          ADDS
                  RO. R5
                              ; Add b
                              ; Add c
          ADDS
                  RO. R6
          POP
                  {R4-R6, PC}; Return
```

Stack usage considerations:

- Monitor stack depth in nested calls
- Always maintain 8-byte alignment for SP
- Consider register usage to minimize stack operations
- Be aware of stack space in interrupt handlers
- Document stack requirements for functions

Parameter Passing

Parameter Passing Methods

Data can be passed between functions through:

- Registers: Fast, limited number available
- Global Variables: Shared memory space
- Stack:
 - Caller: PUSH parameters onto stack
 - Callee: Access via LDR from stack

ARM Procedure Call Standard

Parameter Passing:

- First four arguments use R0-R3
- Additional parameters go on stack

Return Values:


- Small Values ($\leq 32 \text{ bits}$):
 - Return in R0
 - Zero/sign extend if needed
- Double Word (64 bits): R0/R1
- 128-bit Values: R0-R3
- Larger Values:
 - Store in memory
 - Return pointer in R0

Register Usage:

- **R0-R3**: Arguments/results (caller-saved)
- R4-R11: Local variables (callee-saved)
- R12: IP scratch register
- R13: SP stack pointer
- R14: LR link register
- R15: PC program counter

Subroutine Call - Caller Side

Pattern as used by the compiler. Manually written assembly code may be slightly different



Reentrancy

Handling recursive function calls:

- Each call needs its own data set
- Registers/globals get overwritten
- Solution: Use stack for local storage

Parameter Passing Methods Global variable approach (not recommended):

```
.data
value DCD 0 ; Global variable

.text
func LDR R0, =value ; Load address
LDR R1, [R0] ; Get value
; Process value
STR R1, [R0] ; Store result
```

Register-based approach (preferred):

```
func PUSH {R4, LR} ; Save registers ; R0 contains input parameter  
MOV R4, R0 ; Save parameter ; Process value in R4  
MOV R0, R4 ; Set return value  
POP {R4, PC} ; Restore and return
```

Implementing Function Calls

Steps for calling functions:

- 1. Caller's responsibilities:
 - Place parameters in R0-R3
 - Push additional parameters on stack
 - Save caller-saved registers if needed
- 2. Callee's responsibilities:
 - Save callee-saved registers used
 - Save LR if making other calls
 - Process parameters
 - Place return value in R0
 - Restore saved registers

Important considerations:

- Avoid global variables for parameter passing
- Use registers for efficiency
- Follow ARM calling convention strictly
- Consider stack usage in recursive functions

Parameter Passing by Value vs. Reference

Two main approaches:

- Pass by Value:
 - Copies value to function
 - Changes don't affect original
 - Default in C
 - Example: Simple types, integers
- Pass by Reference:
 - Passes memory address
 - Changes affect original value
 - In C: Using pointers
 - Example: Arrays, large structures

Example implementation:

```
; Pass by value
func1
        PUSH
                {LR}
        ADDS
                             ; Modify parameter
                RO, #1
        POP
                {PC}
                             ; Original unchanged
: Pass by reference
func2
        PUSH
                {LR}
        LDR
                R1, [R0]
                             ; Load from address
        ADDS
                R1, #1
                             ; Modify value
        STR
                R1, [R0]
                             ; Store back to
            address
        POP
                 {PC}
                             ; Original changed
```

Data Structure Access Working with structures and arrays:

```
typedef struct {
    uint32_t minutes;
    uint32_t seconds;
} time_t;

time_t time;
```

Assembly implementation:

```
; Access structure members
                               ; Get structure
              RO, =time
          address
              R1, [R0, #0]
                               ; Load minutes
      LDR
              R2, [R0, #4]
      LDR
                               ; Load seconds
      ; Modify structure
      ADDS
              R2, #1
                               ; Increment seconds
      CMP
              R2, #60
                               ; Check for overflow
      BLT
              store back
      MOVS
              R2, #0
                               ; Reset seconds
      ADDS
              R1, #1
                               ; Increment minutes
12 store_back
      STR
              R1, [R0, #0]
                               ; Store minutes
      STR
              R2, [R0, #4]
                               ; Store seconds
```

Stack Frame Organization

Complete stack frame layout:

- Previous Stack Frame:
- Local variables
 - Saved registers

• Current Frame:

- Arguments 5+
- Return address (LR)
- Saved registers (R4-R11)
- Local variables
- Temporary storage
- Next Frame:
 - Space for called functions

Recursive Function Implementation Factorial calculation:

```
| ; uint32_t factorial(uint32_t n)
2; Input in RO, result in RO
 factorial
      PUSH
              {R4, LR}
                               ; Save registers
      MOVS
              R4. R0
                               ; Save n
                               : Check base case
      CMP
              R4, #1
                               ; Return 1 if n <= 1
      BLE
              fact end
      SUBS
              RO, R4, #1
                               ; n-1
      BL
              factorial
                               ; Recursive call
      MULS
              RO, R4, RO
                               ; n * factorial(n-1)
 fact_end
      POP
              {R4, PC}
                               ; Restore and return
```

Function Parameter Guidelines

Best practices for parameter passing:

- 1. Register Usage:
- R0-R3: First four parameters
- R0: Return value
- R4-R11: Preserve if used
- 2. Stack Usage:
- Additional parameters pushed right to left
- Maintain 8-byte alignment
- Caller responsible for cleaning up stack
- 3. Memory Structures:
- Pass pointers for large structures
- Use registers for small values
- Consider alignment requirements

Example implementation:

```
; void func(int a, int b, int c, int d, int e)
: First four params in RO-R3, fifth on stack
func
        PUSH
                {R4-R6, LR}; Save registers
        ; Save parameters
        MOV
                R4, R0
                             ; Save a
        MOV
                R5. R1
                            ; Save b
        MOV
                R6, R2
                            ; Save c
        : R3 contains d
        LDR
                RO, [SP, #16]; Load e from
            stack
        ; Function body
        POP
                 {R4-R6. PC} : Return
```

Complex Parameter Example Function with mixed parameter types:

```
typedef struct {
    int32_t x;
    int32_t y;
} point_t;

int32_t calculate(point_t* p, int32_t scale,
    int32_t* result);
```

Assembly implementation:

```
RO = point_t* p
2 ; R1 = scale
3 ; R2 = result pointer
4 calculate
      PUSH
              \{R4-R5, LR\}
                              ; Save registers
      ; Load structure members
              R4, [R0, #0]
                               ; Load p->x
              R5, [R0, #4]
      LDR
                               ; Load p->y
      : Perform calculation
      MULS
              R4, R1, R4
                               ; x * scale
      MULS
              R5, R1, R5
                               ; v * scale
      ; Store result
      STR
              R4, [R2, #0]
                               : *result = x
      ADDS
              RO, R4, R5
                               ; Return sum
      POP
              \{R4-R5, PC\}
                               : Return
```

Modular Coding and Linking

Modular Programming Overview

Program code is divided into modules with:

- Each source file compiled into separate object file
- All object files linked into single executable
- Clear interfaces between modules

```
main.c
                                                              square.c
uint32 t square(uint32 t v);
                                          Preprocessor
                                                              Preprocessor
int main (void)
                                           Compiler
                                                               Compiler
    while(1) {
                                          Assembler
                                                               Assembler
        LED = square (DIPSW) :
                                                              square.o
                                           main.o
                       square.c
                                                      Linker
uint32 t square(uint32 t v)
    return v * v;
                                                 program.axf
```

Benefits of Modular Programming

Key advantages:

• Team Development:

- Multiple developers working on same codebase
- Clear ownership of modules
- Code Organization:
 - Logical partitioning of functionality
 - Easier code reuse

• Development Efficiency:

- Individual module testing
- Faster compilation (only changed modules)
- Reusable library creation
- Language Integration:
 - Mix C and assembly modules
 - Language-specific optimizations

Module Linkage

Keywords for controlling module interfaces:

- EXPORT: Make symbol available to other modules
- IMPORT: Use symbol from another module
- Internal symbols: Neither IMPORT nor EXPORT

```
usable outside of module main
 ; main.s
        AREA myCode, CODE, READONLY
        EXPORT main
        IMPORT square <
                           from module square
        PROC
 main
        LDR
                  r0,a adr
                  r0,[r0,#0]; a
        LDR
        BL
                  square
        ENDP
 a adr DCD
                  a
 b adr DCD
                  b
        AREA myData, DATA
                  0x00000005
        DCD
7b
                  0x00000007
        DCD
```

Object Files

ELF format contains:


- Code Section:
 - Program code and constants
- Based at address 0x0
- Data Section:
 - Global variables
 - Based at address 0x0
- Symbol Table:
 - All symbols and their attributes
 - Global/local status
 - References to external symbols
- Relocation Table:
 - Instructions for adjusting addresses
 - Applied during linking process

Linker Operation

Main tasks:

- Merge code sections from all objects
- Merge data sections from all objects
- Resolve symbol references between modules
- Relocate addresses to final positions

Output is ARM Executable File (AXF):



Module Interface Example

```
; Module A - Defining function
AREA myCode, CODE, READONLY
EXPORT myFunction; Make available externally
myFunction

PUSH {LR}
; function code here
POP {PC}

; Module B - Using function
AREA myCode, CODE, READONLY
IMPORT myFunction; Use external function

BL myFunction; Call the function
```

Creating Modular Programs

Steps for modular development:

- 1. Design module structure:
 - Identify clear boundaries
 - Define interfaces
- 2. Create individual modules:
 - Declare IMPORT/EXPORT
 - Implement functionality
- 3. Compile modules separately
- 4. Link modules:
 - Resolve references
 - Create executable
- 5. Test integrated system

Guidelines for Modular Programming

Key design principles:

- High Cohesion:
 - Group related functionality together
 - Each module fulfills a single defined task
 - Lean external interface
- · Low Coupling:
 - Minimize dependencies between modules
 - Clear and minimal interfaces
 - Easy to modify individual modules
- Information Hiding:
 - Split interface from implementation
 - Don't expose unnecessary details
 - Maintain freedom to change internals

Symbol Resolution and Relocation

Steps in linking process:

1. Symbol Resolution:

```
; In module1.s

AREA |.text|, CODE, READONLY

EXPORT func1

func1

; function code

; In module2.s

AREA |.text|, CODE, READONLY

IMPORT func1

BL func1; Reference to resolve
```

2. Relocation:

```
; Before relocation
BL func1; Relative offset
; After relocation
BL 0x08000234; Absolute address
```

Linkage Types in C

Three types of linkage:

- External Linkage:
 - Global names available to all modules
 - Default for functions and global variables
 - Example:

• Internal Linkage:

- Names only available within module
- Created using 'static' keyword
- Example:

```
static int module_var;  // Internal
linkage
static void local_func(void); // Internal
linkage
```

· No Linkage:

- Local variables and function parameters
- Scope limited to block
- Example:

Object File Structure Example of complete object file:

```
File sections:
1. '.text' section (Code):
0x00000000: 4604
                           r4, r0
0x00000002: 0040
                  LSLS
                           r0, r0, #1
0x00000004: 4420
                           r0.r4
2. '.data' section:
0x00000000: Initial values for global data
3. Symbol table:
   Name
             Value
                              Binding
   myFunc
             0x0000
                     CODE
                             Global
   extVar
             0x0000
                     DATA
                             Reference
4. Relocation entries:
Offset
        Type
                       Symbol
0x0006
         R_ARM_REL32 extVar
```

Library Creation and Use

Steps for creating and using libraries:

1. Create library source files:

```
// lib.h
void lib_func(int x);

// lib.c
void lib_func(int x) {
    // Implementation
}
```

2. Compile to object files:

```
armcc -c lib.c -o lib.o
```

3. Create static library:

```
armar --create libmy.a lib.o
```

4. Link with library:

```
armlink main.o libmy.a -o program.axf
```

Tool Chain Components

Essential tools for development:

- Compiler (armcc):
- Translates C to assembly
- Performs optimizations
- Generates object files
- Assembler (armasm):
 - Processes assembly code
 - Creates object files
 - Handles directives
- Linker (armlink):
 - Combines object files
 - Resolves references
 - Creates executable
- Library Manager (armar):
 - Creates/maintains libraries
 - Adds/removes object files
 - Archives multiple objects

Important considerations:

- Use consistent naming conventions
- · Document module interfaces clearly
- Consider initialization dependencies
- Test modules independently
- Maintain version control
- Document build requirements

Exceptional Control Flow

Exception Types

Two main categories of exceptions:

Interrupt Sources:

- Peripherals requesting immediate CPU attention
- Software-generated interrupts
- Asynchronous to instruction execution


System Exceptions:

- Reset: Processor restart
- NMI: Non-maskable Interrupt (cannot be ignored)
- Faults: Undefined instructions, errors
- System Calls: OS services (SVC and PendSV)

Interrupt Control

PRIMASK register controls interrupt handling:

- Single bit controls all maskable interrupts
- Reset state: PRIMASK = 0 (interrupts enabled)
- Control methods:
 - Assembly: CPSID i (disable), CPSIE i (enable)
 - C: __disable_irq(), __enable_irq()



Context Storage

Interrupt handling requires automatic context saving:

ISR Entry:

- Stores on stack:
 - xPSR, PC, LR, R12
 - R0-R3 (caller-saved registers)
- Stores EXC RETURN in LR


ISR Exit:

- Via BX LR or POP ..., PC
- Restores from stack:
 - R0-R3, R12, LR, PC
 - xPSR

Polling vs Interrupts

Polling Approach:

- Periodic status register checks
- Synchronous with main program
- Advantages:
 - Simple implementation
 - Predictable timing
 - No extra hardware needed
- Disadvantages:
 - CPU wastes time waiting
 - Reduced system throughput
 - Longer response times



Intornint

Interrupt Approach:

- Hardware-triggered event handling
- Asynchronous to main program
- Advantages:
 - Efficient CPU usage
 - Quick response times
 - Better system throughput
- Disadvantages:

main()

imit/\.

- More complex implementation
- Harder to debug
- Timing less predictable

Basic ISR Implementation

```
; Interrupt Service Routine
EXPORT MyISR

MyISR

PUSH {R4-R7, LR} ; Save registers

; Handle interrupt here
; R0-R3 already saved automatically

POP {R4-R7, PC} ; Restore and return
```

Implementing Interrupt Handlers

Steps for implementing interrupt handlers:

- 1. Define interrupt vector
- 2. Save necessary context
- 3. Handle the interrupt
- 4. Clear interrupt flag
- 5. Restore context
- 6. Return from interrupt

 $Important\ considerations:$

- Keep ISRs short
- · Handle critical tasks only
- Be aware of nested interrupts
- Protect shared resources

NVIC (Nested Vectored Interrupt Controller)

Key components and functionality:

- Interrupt States:
 - **Inactive**: Not active and not pending
 - **Pending**: Waiting to be serviced
 - **Active**: Currently being serviced
 - Active and Pending: Being serviced with new request
- Control Registers:
 - Interrupt Enable (IE)
 - Interrupt Pending (IP)
 - Interrupt Active (IA)
 - Priority Level (PL)

Interrupt Control Registers

Important NVIC registers:

1. Enable/Disable Registers:

```
SETENAO EQU OxEOOOE100
                           ; Enable interrupts
                           ; Disable interrupts
CLRENAO EQU OxEO00E180
; Enable IRQ3
LDR
        RO. = SETENAO
MOVS
        R1, #(1<<3)
STR
        R1, [R0]
; Disable IRQ3
LDR
        RO, = CLRENAO
MOVS
        R1, #(1<<3)
STR
        R1, [R0]
```

2. Pending Registers:

```
SETPENDO EQU 0xE000E200
                           ; Set pending
CLRPENDO EQU 0xE000E280
                           ; Clear pending
; Set IRQ3 pending
LDR
        RO, =SETPENDO
MOVS
        R1, #(1<<3)
STR
        R1, [R0]
; Clear IRQ3 pending
        RO, = CLRPENDO
LDR
MOVS
        R1, #(1<<3)
STR
        R1, [R0]
```

Priority System

Interrupt priority handling:

- Priority Levels:
 - -0-255 (lower number = higher priority)
 - Fixed priorities for system exceptions
 - Programmable priorities for IRQs
- Preemption:
 - Higher priority interrupts can preempt lower
 - Same priority follows FIFO

Example priority setting:

```
// Set priority for IRQ3
NVIC_SetPriority(IRQ3_IRQn, 2);

// Get priority
uint32_t prio = NVIC_GetPriority(IRQ3_IRQn);
```

Exception Vector Table

Setup and usage:

1. Vector table structure:

```
AREA RESET, DATA, READONLY
__Vectors
   DCD
            __initial_sp
                                ; Top of Stack
   DCD
           Reset Handler
                                ; Reset
   DCD
           NMI Handler
                               : NMI
   DCD
           HardFault_Handler ; Hard Fault
   DCD
                               ; Reserved
   DCD
           0
                               : Reserved
   DCD
           0
                               ; Reserved
   ; ... more vectors
           IRQ0_Handler
   DCD
                               ; IRQO
   DCD
           IRQ1 Handler
                               ; IRQ1
```

2. Handler implementation:

```
AREA |.text|, CODE, READONLY

IRQO_Handler PROC
EXPORT IRQO_Handler
PUSH {R4-R7,LR}
; Handle interrupt
POP {R4-R7,PC}
ENDP
```

Nested Interrupts Example Implementation with different priorities:

```
// Initialize interrupts
 void init_interrupts(void) {
      // Enable interrupts
      NVIC_EnableIRQ(IRQO_IRQn);
      NVIC_EnableIRQ(IRQ1_IRQn);
      // Set priorities
      NVIC_SetPriority(IRQO_IRQn, 1); // Higher
      NVIC_SetPriority(IRQ1_IRQn, 2); // Lower
      // Enable global interrupts
       __enable_irq();
15 // Higher priority ISR
16 void IRQO_Handler(void) {
      // Handle high priority interrupt
      // Can't be interrupted by IRQ1
19 }
21 // Lower priority ISR
void IRQ1_Handler(void) {
      // Handle low priority interrupt
      // Can be interrupted by IRQO
25 }
```

Data Consistency

Handling shared data access:

- Race Conditions:
 - Main program and ISR accessing same data
 - Interrupts during multi-step operations
- Solutions:
 - Disable interrupts during critical sections
 - Use atomic operations
 - Implement proper synchronization

Example protection:

CMSIS Functions for Interrupt Control

Standard CMSIS functions for interrupt handling:

- NVIC_EnableIRQ(IRQn): Enable specific interrupt
- NVIC Disable IRQ (IRQn): Disable specific interrupt
- NVIC_DISABLETRY(TRUN): Disable specific interrupt
 NVIC_SetPendingIRQ(IRQn): Set interrupt pending
- NVIC ClearPendingIRQ(IRQn): Clear pending status
- NVIC SetPriority(IRQn, priority): Set priority
- NVIC_GetPriority(IRQn): Read priority

Example usage:

```
void init_timer_interrupt(void) {
    // Enable timer interrupt
    NVIC_EnableIRQ(TIM2_IRQn);

    // Set priority
    NVIC_SetPriority(TIM2_IRQn, 2);

    // Configure timer
    // ...
    // Enable global interrupts
    __enable_irq();
}
```

Increasing System Performance


Performance Optimization Trade-offs

Optimizing for	Drawbacks on
Higher speed	Power, cost, chip area
Lower cost	Speed, reliability
Zero power consumption	Speed, cost
Super reliable	Chip area, cost, speed
Temperature range	Power, cost, lifetime

Instruction Set Architectures

RISC (Reduced Instruction Set Computer):

- Few instructions with uniform format
- Fast decoding, simple addressing
- Less hardware \rightarrow higher clock rates
- More chip space for registers (up to 256)
- Load-store architecture reduces memory access
- CPU works at full speed on registers
- Enables shorter, efficient pipelines




CISC (Complex Instruction Set Computer):

- More complex instruction set
- Lower memory usage for programs
- Potential performance gain for short programs
- More complex hardware required

Computer Architectures


Von Neumann Architecture:

- Single memory for program and data
- Single bus system between CPU and memory



Harvard Architecture:

- Separate program and data memories
- Two sets of address/data buses
- · Originally from Harvard Mark I



Pipelining


Process of fetching next instruction while current one decodes:





Pipeline Stages (Example):

- Fetch (Fe): Read instruction 3ns
- Decode (De): Process instruction 4ns
- Execute (Ex): Execute and writeback 5ns



Advantages:

- Uniform execution time per stage
- Significant performance improvement
- Simpler hardware per stage

Disadvantages:

- Blocking stages affect whole pipeline
- Memory access conflicts between stages

Pipeline Performance

Without pipelining:

$$\frac{\text{Instructions}}{\text{second}} = \frac{1}{\text{Instruction delay}}$$

With pipelining:


$$\frac{\text{Instructions}}{\text{second}} = \frac{1}{\text{Max stage delay}}$$

Note: Pipeline must be filled first

Pipeline Execution

Optimal Case:

- Register-only operations
- 6 instructions in 6 cycles
- CPI = 1 (Cycles Per Instruction)




LDR Special Case:

- 6 instructions in 7 cycles due to memory access
- Pipeline stalls for memory read
- CPI = 1.2

Pipeline Hazards and Optimization

Control Hazards:

- Branch decisions in execute stage
- Pipeline stalls for taken branches





Optimization Techniques:

- Branch prediction based on history
- Instruction prefetch
- Out-of-order execution

Optimization Limits:

- Security vulnerabilities (Meltdown, Spectre)
- $\bullet\,$ Complex optimizations increase risk

Parallel Computing

Different approaches to parallelism:

- Vector Processing: Single instruction processes multiple data
- Multithreading: Multiple threads share CPU
- Multicore: Multiple CPU cores on one chip
- Multiprocessor: Multiple CPUs in system

Optimizing System Performance

Steps for performance optimization:

- 1. Analyze performance bottlenecks
- 2. Choose appropriate architecture:
- RISC vs CISC based on application
- Consider memory architecture
- 3. Implement pipelining:
 - Balance stage delays
 - · Handle hazards appropriately
- 4. Consider parallelization options
- 5. Evaluate security implications

Performance Growth Overview

Historical development:

- Early improvements:
 - Increasing clock frequencies
 - Better manufacturing processes
- Smaller transistor sizes
- Modern improvements:
 - Advanced architectural concepts (RISC, Pipelining)
 - Multiple cores
 - Specialized hardware units
- Current limitations:
 - Power density
 - Heat dissipation
 - Memory wall
 - Parallelization overhead

System Level Optimization

Different approaches to improve performance:

- External Factors:
 - Better compiler optimization
 - Improved algorithms
 - Efficient software design
- System Level Factors:
 - Special Purpose Units (e.g., Crypto, Video)
- Multiple Processors
- Bus Architecture optimization
- Faster peripheral components

• CPU Improvements:

- Increased Clock Speed
- Cache Memory
- Multiple Cores
- Pipeline Optimization
- Branch Prediction
- Out-of-Order Execution

Pipeline Performance Calculation

For a processor with n pipeline stages:

Without pipelining:

- Time per instruction = Sum of all stage delays
- Performance = $\frac{1}{\text{Total delay}}$

With pipelining:

- Time per instruction = Longest stage delay
- Initial latency = n cycles
- Throughput = $\frac{1}{\text{Max stage delay}}$

Example calculation:

- Stage delays: Fe=3ns, De=4ns, Ex=5ns
- Without pipeline: 12ns per instruction
- With pipeline: 5ns per instruction after filling
- Performance improvement: 2.4×

Pipeline Hazards Three types of pipeline hazards:

1. Structural Hazards:

```
LDR RO, [R1]
                 ; Needs memory access
LDR R2, [R3]
                 ; Also needs memory access
; Memory system can't handle both at once
```

2. Data Hazards:

```
ADDS RO, R1, R2 ; RO gets new value
ADDS R3, R0, R4; Uses R0 before ready
; Second instruction must wait
```

3. Control Hazards:

```
CMP
     RO, #0
                 ; Compare
BEQ
     target
                 ; Branch if equal
     R1, R2, R3; May be unnecessary
SUB R4. R5. R6 : May be unnecessary
target
; Pipeline must flush if branch taken
```

Parallel Processing Models

SISD (Single Instruction Single Data):

- Traditional sequential processing
- One instruction processes one data item
- Example: Basic scalar processor

SIMD (Single Instruction Multiple Data):

- Vector processing
- One instruction processes multiple data items
- Examples: MMX, SSE, AVX instructions

MIMD (Multiple Instruction Multiple Data):

- True parallel processing
- Multiple processors execute different instructions
- Example: Multicore systems

Performance Optimization Guidelines

Steps for system optimization:

1. Analyze Requirements:

- Performance targets
- Power constraints
- Cost limitations
- Reliability needs

2. Choose Architecture:

- · RISC vs CISC
- Memory architecture
- Pipeline depth
- Parallelization approach

3. Optimize Implementation:

- Balance pipeline stages
- Implement hazard handling
- Consider branch prediction
- Optimize memory access

4. Security Considerations:

- Evaluate optimization risks
- Consider side-channel attacks
- Balance performance and security

Multicore vs Multiprocessor Kev differences:

- Multicore:
 - Multiple CPU cores on single chip
 - Shared cache and memory interface
 - Lower communication overhead
 - More power efficient

• Multiprocessor:

- Multiple separate CPU chips
- Independent caches
- Higher communication overhead
- More scalable for large systems

