A MODEL-DRIVEN DEVELOPMENT AND VERIFICATION APPROACH FOR MEDICAL DEVICES

by

Jakub Jedryszek

B.S., Wroclaw University of Technology, Poland, 2012

B.A., Wroclaw University of Economics, Poland, 2012

A THESIS

submitted in partial fulfillment of the requirements for the degree

MASTER OF SCIENCE

Department of Computing and Information Sciences College of Engineering

> KANSAS STATE UNIVERSITY Manhattan, Kansas

> > 2014

Approved by:

Major Professor John Hatcliff

Copyright

Jakub Jedryszek

2014

Abstract

Medical devices are safety-critical systems whose failure may put human life in danger. They are becoming more advanced and thus more complex. This leads to bigger and more complicated code-bases that are hard to maintain and verify. Model-driven development provides high-level and abstract description of the system in the form of models that omit details, which are not relevant during the design phase. This allows for certain types of verification and hazard analysis to be performed on the models. These models can then be translated into code. However, errors that do not exist in the models may be introduced during the implementation phase. Automated translation from verified models to code may prevent to some extent.

This thesis proposes approach for model-driven development and verification of medical devices. Models are created in AADL (Architecture Analysis & Design Language), a language for software and hardware architecture modeling. AADL models are translated to SPARK Ada, contract-based programming language, which is suitable for software verification. Generated code base is further extended by developers to implement internals of specific devices. Created programs can be verified using SPARK tools.

A PCA (Patient Controlled Analgesia) pump medical device is used to illustrate the primary artifacts and process steps. The foundation for this work is "Integrated Clinical Environment Patient-Controlled Analgesia Infusion Pump System Requirements" document and AADL Models created by Brian Larson. In addition to proposed model driven development approach, a PCA pump prototype was created using the BeagleBoard-xM device as a platform. Some components of PCA pump prototype were verified by SPARK tools and Bakar Kiasan.

Table of Contents

Ta	able (of Contents	viii
Li	st of	Figures	xii
Li	st of	Tables	xiv
\mathbf{A}	cknov	wledgements	xiv
D	edica	tion	xv
1	Intr	roduction	1
	1.1	Motivation	2
	1.2	Technologies	3
	1.3	Goals	4
	1.4	Contribution	5
	1.5	Organization	5
	1.6	Terms and Acronyms	6
2	Bac	kground	8
	2.1	Integrated Clinical Environment	8
	2.2	Medical Device Coordination Framework	10
	2.3	AADL	11
		2.3.1 OSATE	14
	2.4	BLESS	15

	2.5	SPAR	K Ada	16
		2.5.1	GNAT compiler	21
		2.5.2	GNAT Programming Studio (GPS)	22
		2.5.3	Ravenscar Tasking Subset	22
	2.6	SPAR	K Ada Verification	28
		2.6.1	SPARK Examiner	30
		2.6.2	SPARK Simplifier	34
		2.6.3	ZombieScope	34
		2.6.4	ViCToR	35
		2.6.5	Proof Checker	35
		2.6.6	SPARKSimp Utility	35
		2.6.7	Proof Obligation Summarizer (POGS)	36
		2.6.8	AUnit	36
		2.6.9	Sireum Bakar	37
		2.6.10	GNAT Prove	40
	2.7	AADL	A/BLESS to SPARK Ada code generation	40
		2.7.1	Ocarina	41
		2.7.2	RAMSES	41
3	PC	A Pum	າກ	42
•	3.1		Pump Requirements Document	45
	3.2		Pump AADL/BLESS Models	48
	3.3	Beagle	Board-XM	53
4	AA	\mathbf{DL}/\mathbf{BI}	LESS to SPARK Ada translation	55
	4.1	AADL	/BLESS to SPARK Ada mapping	55
		4.1.1	Data types mapping	56

		4.1.2	AADL ports mapping	66
		4.1.3	Thread to task mapping	69
		4.1.4	Subprograms mapping	69
		4.1.5	Feature groups mapping	70
		4.1.6	AADL package to SPARK Ada package mapping	71
		4.1.7	AADL property set to SPARK Ada package mapping	74
		4.1.8	BLESS mapping	74
	4.2	Port-b	ased communication	76
		4.2.1	Threads communication	76
		4.2.2	Systems communication	84
	4.3	Auton	natic translator	88
5	PC	A pum	p prototype implementation and code generation	90
	5.1	Runni	ng SPARK Ada programs on BeagleBoard-xM	90
		5.1.1	Odometer	92
		5.1.2	Multitasking applications	96
		5.1.3	Controlling PCA pump actuator	101
	5.2	Imple	mentation based on Requirements Document and AADL models	107
	5.3	Code	generation from AADL/BLESS models	109
	5.4	Imple	mentation for generated code	109
	5.5	Comm	nunication with MDCF	109
6	Ver	ificatio	\mathbf{n}	110
	6.1	Verific	ation of implemented prototype	110
	6.2	Monit	oring dosed amount	111
	6.3	Verific	ation of generated code	131
		6.3.1	Adding implementation to generated code	131

	6.4 AUnit tests	131
	6.5 gnatPROVE?	133
7	Summary	134
8	Future work	135
Bi	bliography	137
\mathbf{A}	Simplified PCA Pump AADL/BLESS models	142
В	PCA Pump Prototype - simple, working example	143
С	$PCA\ Pump\ Prototype\ \textbf{-}\ translated\ from\ AADL/BLESS$	144
D	PCA Pump - dose monitor module	145

List of Figures

2.1	ICE Closed Loop Control	9
2.2	MDCF architecture and example app virtual machine (lower right) \dots	11
2.3	AADL Application Software Components	12
2.4	AADL model of simple thermometer	13
2.5	Developer responsibility in Ada ¹	17
2.6	Relationship of the Examiner and Proof Tools ²	29
2.7	Run SPARK Make	32
2.8	Examiner Properties	32
2.9	Bakar Kiasan report	39
3.1	Patient Controlled Analgesia (PCA) pump	42
3.2	Alaris Pump	43
3.3	Standard Process Control Loop	43
3.4	PCA Pump system	44
3.5	Open PCA Pump concept	46
3.6	Open PCA Pump AADL model	49
3.7	BeagleBoard-xM	53
3.8	An example of PWM duty cycles	54
4.1	Example of port communication between threads	77
4.2	Example of two way port communication between threads in different packages	81
4.3	Example of port communication between systems	84

5.1	Edit Project Properties	91
5.2	Project Main files	92

List of Tables

2.1	Fundamental SPARK annotations	19
2.2	Sample SPARK 2005 to 2014 mapping	20
4.1	Base AADL types to SPARK mapping	59
4.2	AADL/BLESS enumeration types to SPARK mapping	63
4.3	AADL types to SPARK mapping: Subtypes	64
4.4	AADL arrays to SPARK Ada mapping	65
4.5	AADL struct to SPARK Ada record mapping	66
4.6	AADL to SPARK ports mapping	67
4.7	AADL threads to SPARK Ada tasks mapping	69
4.8	AADL subprograms to SPARK Ada subprograms mapping	70
4.9	AADL property set to SPARK Ada package mapping	74
4.10	BLESS to SPARK contracts mapping	75
4.11	${\bf AADL\ threads\ communication\ to\ SPARK\ Ada\ tasks\ communication\ translation}$	78
4.12	AADL threads communication to SPARK Ada tasks communication transla-	
	tion (multiple packages)	79

Acknowledgments

Say thank you for everybody involved directly and indirectly.

Dedication

For my family, mentors and all people who inspired me directly or indirectly in things I am doing. I also dedicate this thesis to everyone who have supported me throughout the process.

Chapter 1

Introduction

Software is present in all aspects of our life. From the simple program in alarm clock to iPad, through cars, refrigerators and computers. Furthermore, our lives are getting more and more depended on Software. Usually when we think about Software, we think about Applications for PC or Smart Phone. E.g. Calculator, Word processor or Stock Market application. In this case, rapid development and smooth operation is a key. However, there is also another, very important class of Software: Safety Critical Systems. It comprises software for Airplanes, Medical Devices, Satellites or Rockets.

Software Engineering for Real-Time and Safety-Critical Systems is very different than creating Business applications. In both types of software we want to ensure correctness and security. However, in each of them, to different extent. In case of mentioned Word processor, software assurance is not critical. When it crashes, it can be restarted. In worst case scenario, some part of work might be lost. Airplane software crash may put human life in danger or even cause the death. Thus for Safety-Critical systems, the security and correctness are crucial. Behind these reasons, different Software Design methodology and different properties of programming language and its tools are needed.

The most important part of Safety-Critical Systems Design is hazard analysis. How to avoid unintentional states and how to recover from them. Hazard can cause incident or

accident. Former is an event, which not cause a loss (but undesired), and could lead to accident. Latter cause the loss (and it is also undesired). Hazard analysis can be done manually by human or automatically by software tools. AADL, BLESS and SPARK Ada contains variety of them.

1.1 Motivation

[IF FIRST=BETTER] Nowadays, medical devices works rather independently. It leads to many accidents, which could have been avoided by their interoperability. For example some drug (e.g. morphine), which is delivered by Patient-controlled analgesia (PCA) pump after surgery, can cause low oxygen level or even lack of pulse. That can lead to patient's death. PCA pump does not monitor oxygen level, but Oxygen monitoring device does. If these two devices are organized in centralized system, which implements safety interlock mechanism to shutdown the pump when low oxygen level is detected, accident can be avoided.

In order to communicate, devices have to use compatible interfaces and protocols. There is a concept of "Integrated Clinical Environment" (ICE). It is series of standards, which describes medical device integration and interoperability. SAnToS lab created Medical Device Coordination Framework (MDCF), which is prototype implementation of ICE. Standards are captured not only as requirement documents, but also in software and hardware models form. It allows different medical devices, created by different vendors, to be connected and work under supervision of centralized system.

[ELSE] There are many accidents where Medical Devices are involved. Very often, the reason is the lack of communication between them. Drug dosed by PCA Pump may affect patient's level of oxygen and carbon dioxide level. Thus adequate monitoring of patient's levels of oxygen and carbon dioxide is required. Moreover, integrated system, which will take adequate action in case of hazard is needed. The solution for such a problem is "Integrated Clinical Environment" (ICE). SAnToS Lab at Kansas State University, in

cooperation with University of Pennsylvania are working on Medical Device Coordination Framework (MDCF) [HKL⁺12], which is prototype implementation of ICE. It is an open source framework for coordinating multiple medical devices to work together.

Devices working under MDCF have to satisfy some requirements. To make Developer's life easier, the requirements are not only in documentation, but also in form of software and hardware models. Model Driven Development in this case means that there from base models for medical devices development, from which skeleton code can be generated. Developers extend and customize generated code for specific device. In the same fashion like File > 'New Java project' create code skeleton, File > 'New Medical device project' will create code structure which has to be implemented. The ultimate goal is to create set of models for different medical devices, which can be automatically translated to code.

[END IF]

PCA pump prototype created in this thesis is as an example of Medical Device, which ultimately will work under MDCF.

1.2 Technologies

AADL (Architecture Analysis & Design Language) is modeling language for representing hardware and software. It is used for real-time, safety critical and embedded systems. AADL allows for the description of both software and hardware parts of a system. It is used to describe architecture, but AADL allows to add behavioral extensions through annex languages. BLESS (Behavior Language for Embedded Systems with Software) is AADL annex sub language defining behavior of components. The goal of BLESS is automatically-checked correctness proofs of AADL models of embedded electronic systems with software.

Ada is one of the most popular (along with C/C++) programming language targeted at embedded and real-time systems. SPARK Ada is subset of Ada, designed for the development of safety and security critical systems. It contains subset, which allows to reason

about and prove correctness of program and its entities. There are also SPARK tools for software verification.

1.3 Goals

The initial goals, which most of them is accomplished are as follows:

- identify PCA Pump and Infusion pumps properties and internals required for implementation
- SPARK Ada cross-compilation for ARM-device (BeagleBoard-xM)
- implement PCA Pump based on Brian Larson's Requirement Document [LHC13]
- develop AADL/BLESS to SPARK Ada mapping
- mock PCA Pump AADL/BLESS models in SPARK Ada (based on created mapping and implementation)
- implement not generated part (based on implementation) [NOT ACCOMPLISHED REMOVE?]
- create AADL/BLESS to SPARK Ada translator [NOT ACCOMPLISHED RE-MOVE?]
- Use SPARK tool set for software verification:
 - SPARK Examiner
 - SPARK Simplifier
 - Proof Obligation Summarizer (POGS)
 - Bakar Kiasan
 - GNATprove

1.4 Contribution

This thesis demonstrates how AADL/BLESS models can be mapped to SPARK Ada. Additionally it presents current possibilities and limitations of SPARK Ada language, Ravenscar profile and SPARK verification tools. The main contributions of this thesis are as follows:

- Review of PCA Pump Requirements document [LHC13]
- Cross-compilation and testing of SPARK Ada 2005 and 2014 code on BeagleBoard-xM platform
- Implementation of PCA Pump based on Requirements document [LHC13] and AADL/B-LESS models, which validates them
- Creation of PCA pump prototype
- Analysis of different PCA pump implementation possibilities
- AADL/BLESS to SPARK Ada translation schemes
- Practical demonstration of SPARK 2005 verification tools: its capabilities and limitations

1.5 Organization

The thesis is organized in 8 [fix this: how to count all chapters?] chapters:

- Chapter 1 is the problem description and summary of contribution which has been made.
- Chapter 2 is Background that gives details about ICE, MDCF, Model Driven Development, AADL/BLESS, SPARK Ada and available tools for such environment.
- Chapter 3 describes Patient-Controlled Analgesia (PCA) pump.

- Chapter 4 presents mappings from AADL/BLESS to SPARK Ada.
- Chapter 5 describes the implementation of PCA Pump Prototype. Faced issues and design decisions made.
- Chapter 6 describes verification of implemented PCA Pump Prototype.
- Chapter 7 summarizes all work which has been done in this thesis.
- Chapter 8 is the future work that can be done on this topic.

1.6 Terms and Acronyms

- AADL Architecture Analysis & Design Language
- BLESS Behavioral Language for Embedded Systems with Software
- ICE Integrated Clinical Environment
- MDCF Medical Device Coordination Framework
- PCA Patient-Controlled Analgesia (pump)
- FDA Food and Drug Administration
- **GPS** GNAT Programming Studio
- GCC GNU Compiler Collection
- GUI Graphical user interface
- VC Verification Condition
- **DPC** Dead Path Conjecture
- **POGS** Proof Obligation Summarizer

- \bullet \mathbf{VTBI} Volume to be infused
- $\bullet~{\rm KVO}$ Keep Vein Open

Chapter 2

Background

This chapter is a brief introduction of all technologies and tools used in this thesis. There are: AADL modeling language, BLESS (AADL annex language), SPARK Ada programming language and its verification tools. There is also an overview of the context in which this work has been made: Integrated Clinical Environment standard (ICE) and PCA Pump (ICE compliant device). This is followed by main topic of the thesis: code generation from AADL and analysis of existing AADL translators (Ocarina, RAMSES).

2.1 Integrated Clinical Environment

Idea of "Integrated Clinical Environment" (ICE) was initiated by Dr. Julian Goldman from Center for Integration of Medicine & Innovative Technology. The main idea is to create environment of medical devices network. It will allow clinician and software system to make decisions based not only on output from one device, but from all of them together. ICE purpose is to solve current issues with medical devices, which usually operate independently. It requires more human attention and control through checking output of every device manually and then making decision. ICE will make it easier, e.g. by introducing alarms, which can not only indicate problem but also interact with other devices and make decision

automatically. E.g. when PCA Pump infuse some drug to patient's vein and Pulse Oximeter detects low oxygen level, ICE can coordinate PCA pump shutdown.

Moreover, ICE comprises components that may be implemented by different vendors. Such components are medical devices and applications to supervise them. Figure 2.1 presents high overview of ICE system. Medical devices (PCA Pump, Respiratory Rate Monitor and Pulse Oximeter) are connected to the system. All of them are monitored and controlled. There is communication between devices and ICE, in order to exchange data between them and Electronic Medical Record (EMR) Database. Informations in EMR comprises drug library, patient's medical records, monitoring logs etc. ICE can make decisions (such as PCA Pump shutdown) based on that informations.




Figure 2.1: ICE Closed Loop Control

[ADD MORE INFORMATION?]

2.2 Medical Device Coordination Framework

Medical Device Coordination Framework (MDCF), jointly developed by SAnToS lab (Kansas State University) and University of Pennsylvania is prototype implementation of ICE. It is an open, experimental platform to bring together academic researchers, industry vendors, and government regulators. Project is response to request from Food and Drug Administration (FDA) to build a prototype of ICE. Medical Devices, which are ICE compliant can be connected to MDCF. The framework enables Medical Devices interoperability. MDCF is designed to illustrate by example the issues related to functional concepts, safety, security, verification and certification.

The goals of MDCF project comprises:

- Open source infrastructure
- Meet performance requirements of realistic clinical scenarios
- Provide middleware with reliability, real-time, security
- Provide an effective app programming model and development environment with integrated verification/validation support and construction of regulatory artifacts
- Support evaluation of device interfacing concepts
- Illustrate how to support real and mock devices
- Illustrate envisioned regulatory oversight and 3rd party certification

In this thesis, part of penultimate point will be illustrated. For now, MDCF use only mock devices, which are Java desktop applications. PCA Pump Prototype aim to be first real-device.

MDCF uses publish-subscribe architecture for communication between components: apps and devices. Figure 2.2 presents MDCF structure. Devices, like PCA pump, are clients.

MDCF Server is integration layer which comprises Core and applications working in top of it. [HLW12].




Figure 2.2: MDCF architecture and example app virtual machine (lower right)

[ADD MORE INFORMATION?]

2.3 AADL

AADL stands for Architecture Analysis & Design Language. It is used to model embedded and real-time systems. AADL allows for the description of both software and hardware parts of a system. It can be used not only for design phase of software development process, but also for analysis, verification or code generation.

AADL has its roots in DARPA¹ funded research. The first version (1.0) was approved in 2004 under technical leadership of Peter Feiler². AADL is develop by SAE AADL committee³. AADL version 2.0 was published in January 2009. The most recent version (2.1)

¹http://www.darpa.mil

²http://wiki.sei.cmu.edu/aadl/index.php/The_Story_of_AADL/

³https://wiki.sei.cmu.edu/aadl/index.php/Main Page

was published in September 2012⁴.

AADL is a language for Model-Based Engineering [FG13]. It can be represented in textual and graphical form. There are tools, like OSATE (see section 2.3.1), which transforms textual representation into graphical or XML.

AADL contains entities for modeling software and hardware components. It allows to create interactions and dependencies between them.


AADL Execution Platform Components and Devices:

- Processor / Virtual Processor Provides thread scheduling and execution services
- Memory provides storage for data and source code
- Bus / Virtual Bus provides physical/logical connectivity between execution platform components
- Device interface to external environment


Application Software Components of AADL (figure 2.3):

- System hierarchical organization of components
- Process protected address space
- Thread group logical organization of threads
- Thread a schedulable unit of concurrent execution
- Data potentially sharable data
- Subprogram callable unit of sequential code





Process



Data



Figure 2.3: AADL Application Software Components

⁴https://wiki.sei.cmu.edu/aadl/index.php/Standardization

An example AADL model is shown in graphical representation, in the figure 2.4. Its textual representation is presented in listing 2.3.




Figure 2.4: AADL model of simple thermometer

```
package Thermometer
public
with Base_Types;
  {\bf system\ patient\_thermometer}
  end patient_thermometer;
  system implementation patient_thermometer.impl
  subcomponents
    thermomether : device thermometer_device.impl;
    opi : device operator_interface.impl;
  {\bf connections}
    tdn : port thermomether.temp -> opi.display;
  end \ {\tt patient\_thermometer.impl;}
  device operator_interface
  features
    display : in data port Base_Types::Integer;
  end operator_interface;
  device implementation operator_interface.impl
  end\ {\tt operator\_interface.impl;}
  {f device} thermometer_device
  features
    temp : out data port Base_Types::Integer;
  end\ {\tt thermometer\_device;}
  device implementation thermometer_device.impl
  end thermometer_device.impl;
end Thermometer;
```

Listing 2.1: AADL model of simple thermometer

Recently AADL becomes a new market standard. There are lots of tools for AADL models analysis, such as: OSATE (see section 2.3.1, STOOD⁵, ADELE⁶, Cheddar⁷, AADLInspector⁸ or Ocarina⁹.

What is important, AADL is for architectural description. It should not be compared with UML suites, which allows to link with source code.

AADL can be extended with the following methods:

- user-defined properties: user can extend the set of applicable properties and add their own to specify their own requirements
- language annexes (the core language is enhanced by annex languages that enrich the architecture description. For now, the following annexes have been defined):
 - Behavior annex: add components behavior with state machines (e.g. BLESS)
 - Error-model annex: specifies fault and propagation concerns
 - ARINC653 annex: defines modelling patterns for modelling avionics system
 - Data-Model annex: describes the modelling of specific data constraint with AADL

More details about AADL can be found in Peter Feiler's book "Model-Based Engineering with AADL" [FG13].

2.3.1 OSATE

Open Source AADL Tool Environment (OSATE) is a set of plug-ins on top of the open-source Eclipse platform. It provides a tool set for front-end processing of AADL models. OSATE

⁵http://www.ellidiss.com/products/stood

⁶https://wiki.sei.cmu.edu/aadl/index.php/Adele

⁷http://beru.univ-brest.fr/ singhoff/cheddar

⁸http://www.ellidiss.com/products/aadl-inspector

⁹http://www.openaadl.org

is developed mainly by SEI (Software Engineering Institute - Carnegie Mellon University)¹⁰. Latest available version of OSATE in the time when this work was published is OSATE2¹¹.

OSATE relies on EMF, UML2 and Xtext¹². It comprises e.g. AADL project wizard, AADL Navigator and AADL syntax analyzer. OSATE enables conversion of AADL in textual representation into graphical. There are also plug-ins for OSATE, like BLESS¹³ or OCARINA¹⁴.

2.4 BLESS

BLESS (Behavior Language for Embedded Systems with Software) is AADL annex sublanguage defining behavior of components. The goal of BLESS is automatically-checked correctness proofs of AADL models of embedded electronic systems with software.

BLESS contains three AADL annex sub-languages:

- Assertion it can be attached individually to AADL features (e.g. ports)
- subBLESS can be attached only to subprograms; it has only value transformations and Assertions without time expressions
- BLESS it can be attached to AADL thread, device or system components; it contains states, transitions, timeouts, actions, events and Assertions with time expressions

BLESS annex subclauses can be added to AADL models transparently to other uses of the system architecture. It includes a verification-condition (VC) generation framework and an accompanying proof tool that enables engineers to prove VCs via proof scripts build from system axioms and rules from a user-customizable rule library. [LCH13]

¹⁰http://www.aadl.info/aadl/currentsite/tool/osate.html

¹¹https://wiki.sei.cmu.edu/aadl/index.php/Osate_2

¹²http://www.eclipse.org/Xtext/

¹³http://bless.santoslab.org/node/5

¹⁴http://libre.adacore.com/tools/ocarina/

The BLESS tool framework is implemented as a publicly available open source plug-in for OSATE (mentioned in section 2.3.1). It includes an editor for BLESS specifications and an environment operating the BLESS proof engine. [LCH13]

Some BLESS constructs can be translated into SPARK contracts, which is part of this thesis. Additionally, BLESS allows to model behavior of components.

[MORE DETAILS? EXAMPLES?]

2.5 SPARK Ada

First version of Ada programming language - Ada 83 - was designed to meet the US Department of Defense Requirements formalized in "Steelman" document ¹⁵. Since that time, Ada evolved. There were Ada 95, Ada 2005 and Ada 2012 (released in December 10, 2012) ¹⁶. Ada is actively used in many Real-World projects ¹⁷, e.g. Aviation (Boeing ¹⁸), Railway Transportation, Commercial Rockets, Satellites and even Banking. One of the main goals of Ada is to ensure software correctness and safety. Due to this requirements, Ada minimize developer responsibility in comparison to other programming languages (see figure 2.5). It is achieved not only by language capabilities, but also by tools for verification.

SPARK is a programming language and static verification technology designed specifically for the development of high integrity software. It is a "safe" subset of Ada designed to be susceptible to formal methods, accompanied with a set of approaches and tools. SPARK 2005 does not include constructs such as pointers, dynamic memory allocation or recursion [IEC+06]. Using SPARK, a developer takes a Z specification and performs a stepwise refinement from the specification to SPARK code. For each refinement step a tool is used to

¹⁵http://www.adahome.com/History/Steelman/steelman.htm

¹⁶http://www.ada2012.org

¹⁷http://www.seas.gwu.edu/ mfeldman/ada-project-summary.html

¹⁸http://archive.adaic.com/projects/atwork/boeing.html

¹⁹http://www.slideshare.net/AdaCore/ada-2012




Figure 2.5: Developer responsibility in Ada^{19} .

produce verification conditions (VC's), which are mathematical theorems. If the VC's can be proved then the refinement step will be known to be valid. However if the VC's cannot be proved then the refinement step may be erroneous²⁰. Sample Verification Condition contains checks for:

- array index out of range
- type range violation
- division by zero
- numerical overflow

[Add more examples where SPARK is used?]

SPARK provides a significant degree of automation in proving exception freedom [IEC⁺06]. Some Ada constructs are excluded from SPARK to make static analysis feasible [IEC⁺06].

²⁰http://www.dwheeler.com/lovelace/s17s4.htm

Additionally SPARK contains tool-set for software verification (see section 2.6). In real-world applications, the embedded critical components are written in SPARK while the non-critical components are written in Ada.

First version of SPARK was based on Ada 83. The second version (SPARK 95) - on Ada 95. SPARK 2005 is based on Ada 2005. It is a subset of Ada 2005 with annotations. The annotation language support flow analysis and formal verification. Annotations are encoded in Ada comments (via the prefix --#). It makes every SPARK 2005 program, valid Ada 2005 program. SPARK annotations contains code contracts, which are analyzed by verification tools, but ignored by Ada compiler.

Listing 2.5 presents simple procedure with code contracts. It increments variable given as parameter by 1. The derives clause specify variable dependency. It future value depends on its current value. There is precondition saying that the value has to be lower than maximum value of Integer type. There is also post condition, which states that the value of variable (given as parameter) after the procedure execution has to be equal to its previous value incremented by 1 ('~' attached to variable means value of this variable, before procedure execution).

```
procedure Increment (X : in out Integer);
--# derives X from X;
--# pre X < Integer'Last;
--# post X = X~ + 1;</pre>
```

Listing 2.2: Sample SPARK procedure with code contracts

SPARK 2014²¹ (based on Ada 2012) is under development. There is partial tool support (in GNAT Programming Studio), but some language features are still not supported. It is worth to mention, that Ada 2012 contains code contracts (which was inspired by previous versions of SPARK). Thus SPARK 2014 is just a subset of Ada 2012. [DEL+14] It contains all features of Ada 2012 except:

²¹http://www.spark-2014.org

- Access types (pointers)
- Exceptions
- Aliasing between variables
- Concurrency features of Ada (Tasking) it's part of SPARK 2014 road-map to include support for tasking in the future, although likely not this year
- Side effects in expressions and functions

Table 2.1 presents fundamental SPARK 2005 annotations and their equivalents in SPARK 2014 and Ada 2012.

Table 2.1: Fundamental SPARK annotations

SPARK 2005	SPARK 2014	Description
# global	Global	list of used global variables within subprogram
# derives	Depends	describe dependencies between variables
# own	Abstract_State	declare variables defined in package body
# initializes	initializes	indicates variables, which are initialized
# inherit	not needed	allows to access entities of other packages
# pre	Pre	pre condition
		Continued on next page

Table 2.1 – continued from previous page

SPARK 2005	SPARK 2014	Description
# post	Post	post condition
# assert	Assert	assertion

Sample mapping from SPARK 2005 to 2014 is shown in the table 2.2. Complete mapping can be found in SPARK 2014 documentation²² [AL14].

Table 2.2: Sample SPARK 2005 to 2014 mapping.

SPARK 2005	SPARK 2014
# global in out X, Y;	with Global => (In_Out => (X, Y));
# derives X from Y &# Y from X;	Depends => (X => Y,
# pre Y /= 0 and # X > Integer'First;	<pre>with Pre => Y /= 0 and X > Integer'First;</pre>
# post X = Y~ and Y = X~;	with Post => (X = Y'Old and Y = X'Old);

The previous example (listing 2.5) translated to SPARK 2014 is shown in figure 2.5.

```
procedure Increment (X : in out Integer)
with Depends => (X => X),
   Pre => (X < Integer'Last),
   Post => (X = X'Old + 1);
```

 $^{^{22}} http://docs.adacore.com/spark2014-docs/html/lrm/mapping-spec.html$

Listing 2.3: Sample SPARK 2014 procedure and Code Contracts

It is possible to mix SPARK 2014 with Ada 2012. However, only the part which is SPARK 2014 compliant will be verified. As mentioned before, usually SPARK is used in the most critical parts of Software Systems [Cha00]. It means, that some part is written in e.g. Ada or C++ and the rest in SPARK. The reason of that is the SPARK limitation and lack of necessity to verify some not safety-critical modules. SPARK 2014 does not contains Examiner like SPARK 2005. Instead, proofs are made by gnatPROVE (see section 6.5).

The most popular IDE for SPARK Ada is GNAT Programming Studio²³ (see section 2.5.2). There is also Ada plug-in for Eclipse - GNATbench²⁴ created by AdaCore.

2.5.1 GNAT compiler

GNAT compiler is Ada compiler created by AdaCore²⁵. It is part of GNU Compiler Collection (GCC). The GNU Compiler Collection includes front ends for C, C++, Objective-C, Fortran, Java, Ada, and Go. It is one of the most popular compiler systems. It is included in all Linux distributions. GNU is open source, published on GNU General Public License. GCC is divided into front end and back end. It allows to create new front end for some language and reuse existing back end.

GNAT supports Ada 2012, Ada 2005, Ada 95 and Ada 83. The front-end and run-time are written in Ada. To make compilation easier, GNAT provides gnatmake tool. It takes as an argument project file (.gpr) or main program file (file, which contains main procedure) and builds entire program automatically. gnatmake invokes GCC to perform the actual compilation. It check all dependencies contained in .ali files. Each invocation of GCC produce object file (.o) and Ada Library Information file (.ali). Once compilation is done, gnatmake invokes gnatbind

²³http://libre.adacore.com/tools/gps

²⁴https://www.adacore.com/gnatpro/toolsuite/gnatbench/

²⁵http://www.adacore.com

tool to check consistency and generate a main program. Then gnatlink performs linking using binding output and all object files.

GNAT compiler is available for all most popular platforms: Windows, Linux and MacOS. AdaCore, released also GNAT cross-compiler for ARM devices. However, for now, the compilation has to be done on 32-bit Linux platform.

2.5.2 GNAT Programming Studio (GPS)

GNAT Programming Studio (GPS) is Integrated development environment for SPARK Ada. It allows to easily manage and compile SPARK Ada projects using .gpr file. GPS includes set of verification tools. More precisely GUI for setting up their options, running them and analyze results. Additionally, it enables to create plug-ins using Python and PyGTK²⁶. Sireum Bakar (developed by SAnToS lab) is GPS plug-in written in Python and PyGTK. The same with other plug-ins created by AdaCore like SPARK Examiner or GNATprove.

There are two versions of GPS: free (GPL) and commercial (Pro). There are version for all most popular platforms: Windows, Linux and MacOS.

2.5.3 Ravenscar Tasking Subset

The Ravenscar Profile provides a subset of the tasking facilities of Ada95 and Ada 2005 suitable for the construction of high-integrity concurrent programs [Tea12]. RavenSPARK is SPARK subset of the Ravenscar Profile. The Ravenscar Profile is a subset of the tasking model, restricted to meet the real-time community requirements for determinism, schedulability analysis and memory-boundedness, as well as being suitable for mapping to a small and efficient run-time system that supports task synchronization and communication, and which could be certifiable to the highest integrity levels. The concurrency model promoted by the Ravenscar Profile is consistent with the use of tools that allow the static properties of

²⁶http://docs.adacore.com/gps-docs/users guide/ build/html/extending.html

programs to be verified. Potential verification techniques include information flow analysis, schedulability analysis, execution-order analysis and model checking. These techniques allow analysis of a system to be performed throughout its development life cycle, thus avoiding the common problem of finding only during system integration and testing that the design fails to meet its non-functional requirements. [AB04]

Ravenscar profile is available in SPARK 2005, but not yet in SPARK 2014²⁷ [AL14]. Default profile (sequential) does not enable tasking. In other words, SPARK tools cannot analyze and reason about concurrent programs if Ravenscar profile flag is not provided.

To create a task, the task type has to be declared and task variable of this type. Ravenscar does not allows dynamic task creation. Thus, all tasks have to exists for the full lifetime of the program. [AW01] Tasks can be declared only in packages. Not in subprograms or in other tasks. [Bar13] The priority of each tasks has to be specified by pragma Priority. The range of available priority values is specified in the system package. The default range is 1 to 63. Listing 2.5.3 shows sample package with two tasks.

```
package Some_Pkg
--# own task t1 : Task1;
--# task t2 : Task2;
is
  task type Task1
  is
   pragma Priority(10);
  end Task1;

task type Task2
  is
   pragma Priority(9);
  end Task2;
end Some_Pkg;
```

Listing 2.4: Sample tasks

Declared tasks have to be implemented in the package body (listing 2.5.3).

```
package body Some_Pkg
is
  t1 : Task1;
  t2 : Task2;
```

²⁷http://docs.adacore.com/spark2014-docs/html/lrm/tasks-and-synchronization.html

```
task body Task1
is
begin
loop
-- implementation;
end loop;
end Task1;

task body Task2
is
begin
loop
-- implementation;
end loop;
end Task2;
end Some_Pkg;
```

Listing 2.5: Sample tasks body

There are two ways to access variable in different tasks:

- It has to be protected object
- It has to be atomic type

Protected object encapsulate variable, in such a way that it is accessible, only through protected subprograms. This mechanism use locking, to ensure atomicity. Protected type declaration is similar to task: specification and body has to be defined. Listing 2.5.3 shows sample tasks with protected type Integer_Store, which enable to share Integer variable between tasks. What is important, protected type has to be declared before tasks, which will use it. Otherwise, it will be not visible for them.

```
package Some_Pkg
--# own protected Shared_Var : Integer_Store (Priority => 11);
--# task t1 : Task1;
--# task t2 : Task2;
is

   protected type Integer_Store
   is
     pragma Priority (11);

   function Get return Integer;
     --# global in Integer_Store;

   procedure Put(X : in Integer);
     --# global out Integer_Store;
     --# derives Integer_Store from X;
   private
```

```
TheStoredData : Integer := 0;
end Integer_Store;

task type Task1
    --# global out Shared_Var;
is
    pragma Priority(10);
end Task1;

task type Task2
    --# global in Shared_Var;
is
    pragma Priority(9);
end Task2;
end Some_Pkg;
```

Listing 2.6: Sample tasks with protected object

Protected type body also has to be defined in package body (listing 2.5.3).

```
package body Some_Pkg
   Shared_Var : Integer_Store;
   t1 : Task1;
   t2 : Task2;
   protected body Integer_Store is
       function Get return Integer
        --# global in TheStoredData;
       is
       begin
           return TheStoredData;
       end Get;
       procedure Put(X : in Integer)
       --# global out TheStoredData;
       --# derives TheStoredData from X;
       is
       begin
           TheStoredData := X;
       end Put;
   end Integer_Store;
   task body Task1
   is
   begin
           Shared_Var.Put(5);
       end loop;
   end Task1;
   task body Task2
       Local_Var : Integer;
   begin
           Local_Var := Shared_Var.Get;
       end loop;
   end Task2;
end Some_Pkg;
```

Listing 2.7: Sample tasks with protected object body

Task1 is writing to shared_var and Task2 is reading shared_var. The highest priority is assigned to protected object, to ensure atomicity during operations on it. The lowest priority is assigned to Task2, which is reading shared_var. Reading is usually less expensive operation than writing. Thus, to avoid starvation, Task1 has higher priority than Task2. Notice, that shared_var is declared in package body, but refined in package specification.

Protected variables may not be used in proof contexts. Thus, if we try to use protected variable in proofs (pre- or postcondition), then SPARK Examiner returns following error: Semantic Error 940 - Variable is a protected own variable. Protected variables may not be used in proof contexts. Formal reasoning about interactions and especially temporal properties require other techniques such as model checking and lie outside the scope of SPARK [Bar13]. To preserve opportunity to use pre- and postconditions, atomic types have to be used.

To declare atomic type, pragma Atomic has to be used. However, there is restriction, that pragma Atomic cannot be applied to predefined type such as Integer. Thus, custom type has to be defined. It can be just rename of Integer. Then pragma Atomic can be applied on this type. Listing 2.5.3 presents previous example with atomic types instead of protected objects.

```
package Some_Pkg
-- # own Shared_Var;
       task t1 : Task1;
--#
--#
        task t2 : Task2;
--# initializes Shared_Var;
    type Int32 is new Integer;
    task type Task1
      --# global out Shared_Var;
        pragma Priority(10);
   end Task1;
    task type Task2
      --# global in Shared_Var;
       pragma Priority(9);
    end Task2;
end Some_Pkg;
```

```
package body Some_Pkg
   Shared_Var : Int32 := 0;
   t1 : Task1;
   t2: Task2;
   task body Task1
   is
   begin
        loop
            Shared_Var := 5;
        end loop;
   end Task1;
   task body Task2
        Local_Var : Integer;
   begin
           Local_Var := Integer(Shared_Var);
        end loop;
   end Task2;
end Some_Pkg;
```

Listing 2.8: Sample tasks with atomic type

It is important to mention, that pragma Atomic does not guaranty atomicity. In most cases, atomic types should not be used for tasking. Instead, protected types should be used. When an object is declared as atomic, it just means that it will be read from or written to memory atomically. The compiler will not generate atomic instructions or memory barriers when accessing to that object. pragma Atomic force compiler only to:

- check if architecture guarantees atomic memory loads and stores,
- disallow some compiler optimizations, like reordering or suppressing redundant accesses to the object

Another important thing in tasking is Time library: Ada.Real_Time. It allows to run task periodically, using delay until statement, which suspends task until specified time. To use delay in the task, it has to be declared in declare annotation: --# declare delay; [Bar13].

Details about tasking in SPARK are well described in Chapter 8 of [Bar13]. The "Guide for the use of the Ada Ravenscar profile in high integrity systems" [AB04] and the official

Ravenscar Profile documentation (which includes examples) [Tea12] is another good source. The limitations of Tasking in SPARK are reviewed in Audsley's and Welllings' paper [AW01].

2.6 SPARK Ada Verification

The goal of software verification is to assure software correctness and lack of errors. There are two types of verification:

- dynamic performed during the execution of software, e.g. unit tests
- static achieved by formal methods, mathematical calculations and logical evaluations

Dynamic verification starts with a set of possible test cases, simulates the system on each input, and observes the behavior. In general, it does not cover all possible executions. On the other hand, static verification establishes correctness for all possible execution sequences. Static and dynamic verification can be mixed, e.g. by generating test cases with static verification tools and then proving correctness with unit tests during runtime [DRH07].

Techniques for Static Verification:

- Formal verification: prove mathematically that the program is correct this can be difficult for large programs.
- Correctness by construction: follow a well- defined methodology for constructing programs.
- Model checking: enumerate all possible executions and states, and check each state for correctness.

SPARK consists of a verification tool-set:

• SPARKMake - generates index file (.idx) and meta file (.smf)

²⁸http://docs.adacore.com/sparkdocsdocs/Examiner UM.htm




Figure 2.6: Relationship of the Examiner and Proof Tools²⁸.

- Examiner check syntax, generates Verification Conditions (VCs) and Dead Path Conjectures (DPCs), and discharge (prove) them
- Simplifier simplify and discharge VCs, which are not discharged by Examiner
- ZombieScope find dead paths
- ViCToR translate VCs and DPCs to format acceptable by SMT solver and prove correctness using specified SMT solver
- SPARKSimp runs Simplifier or/and ZombieScope

- POGS produces verification report
- Proof Checker discharge VCs or DPCs not discharged by Examiner and Simplifier

Relationships between tools and verification flow is presented on figure 2.6. SPARK proof tools use FDL as the modeling language.

2.6.1 SPARK Examiner

The main SPARK verification tool is Examiner. It supports several levels of analysis:

- checking of SPARK language syntactic and static semantic rules
- data flow analysis
- data and information flow analysis
- formal program verification via generation of verification conditions
- proof of absence of run-time errors
- dead path analysis

There is also an option to make the Examiner perform syntax checks only. Using this option on a source file does not require access to any other units on which the file depends, so files can be syntax checked on an individual basis. This allows any syntax errors to be corrected before the file is included in a complex examination. This option must only be used as a pre-processor: the absence of syntax errors does NOT indicate that the source text is a legal SPARK program. [Teal1b] [THIS PART IS COPY AND PASTE FROM Examiner doc - is it ok?]

[Put here some examples? E.g.: method without contract, examine, add specification, pass Examiner.]

Examiner can perform data and information analysis of Ravenscar programs in exactly the same manner as for sequential programs [Tea12]. Unfortunately it does not allow protected objects in proof annotations (pre- and post-conditions) as mentioned in section 2.5.3.

When some parts of the system are written in full Ada (with non-valid SPARK constructs), then Examiner returns error. Ada parts can be excluded from Examiner analysis using --# hide annotation. Then, only a warning is returned by Examiner: 10 - The body of subprogram Main is hidden - hidden text is ignored by the Examiner.

Examiner use SPARK index file (.idx) - generated by sparkmake tool - to locate files necessary for verification. [Bar13]

Examiner can be used with spark command and appropriate flags described in Examiner Manual [Teal1b].

To use Examiner in GNAT Programming Studio:

- Run SPARK Make: right click on project / SPARK / SPARK Make (figure 2.7)
- Set SPARK index file (to spark.idx generated by SPARKMake) (figure 2.8)
- (optionally) set configuration file (e.g. Standard.ads)
- Choose appropriate version of SPARK (95 or 2005)
- Choose mode: Sequential (for single tasking programs) or Ravenscar (for multitasking programs)

To generate verification conditions (VCs), the -vcg switch has to be used. It can be set in GNAT Programming Studio (Project / Edit project properties / Switches / Examiner / Generate VCs). In addition to verification conditions, Examiner can check dead path conjectures (DPCs). It checks, whether all of the program is useful. To generate dead path conjectures, the -dpc switch has to be used. It can be also set in GNAT Programming Studio (Project / Edit project properties / Switches / Examiner / Generate DPCs).




Figure 2.7: Run SPARK Make




Figure 2.8: Examiner Properties

Flow analysis

There are two types of flow analysis:

- Data flow analysis:
 - Checks input/output behavior of parameters and variables.

- Checks initialization of variables.
- Checks that changed and imported variables are used later (possibly as output variables).
- Information flow analysis verifies interdependencies between variables.

In data flow analysis, Examiner checks if input parameters are not modified, but used at least once (in at least one branch of program). In the same factor, output parameters cannot be read (before initialization) and has to be initialized (in all branches of program). Input/output parameters has to be both read and write (changed). In similar way, Examiner verify the global variables (specified in annotations). Functions can use only input parameters and can only read global variables. Therefore functions do not have side effects.

Global variables defined in package body (thus private) has to be declared by --# own annotation in package specification. If variable is also initialized, --# initializes annotation has to be used. In Ada, to use package in another package, with clause has to be used. In SPARK Ada, additionally --# inherits annotation has to be specified.

In information flow analysis, dependencies between variables are analyzed. These dependencies are specified by --# derives annotation.

Verification conditions

To generate verification conditions, two kinds of annotations are relevant for Examiner:

- preconditions: --# pre
- postconditions: --# post

Notion of pre- and postconditions represents Hoare logic. More precisely, Hoare triple:

$$\{P\}C\{Q\}\tag{2.1}$$

P and Q are assertions. C is a command (action) performed between them. P is precondition and Q is post-condition.

Additionally, assertions (--# assert) and checks (--# check) can be specified in procedure body. Then additional verification conditions are generated.

Functions does not have side effects (as stated in 2.6.1), thus only precondition can be applied. However, there is annotation --# return, which specify function return value.

Verification conditions are generated depended on number of paths in subprogram. Analysis is performed backwards, in other words: we start from post-conditions and consider what must holds before. Flow analysis is well described in chapter 11 of [Bar13].

If preconditions are not present, then the formula expresses that the post-condition holds always.

2.6.2 SPARK Simplifier

Simplifier, simplify verification conditions (VCs) generated by Examiner. It can also discharge (prove correctness) of those VCs, which are not proved by Examiner. [Tea11c] It takes as input .vcg files, .fdl files for its data declarations and - if available - proof-rule files (.rls, .rlu). Then it generates .siv files (simplified VCs) and .slg files (details about simplification, which has been made).

2.6.3 ZombieScope

ZombieScope is a SPARK tool, that analyze SPARK code to find dead paths, i.e. paths through the code that can never be executed. Program, which contains dead paths may not necessarily be incorrect, but a dead path is an indication of a potential code issue.

ZombieScope reads .dpc files generated by the Examiner. In order to generate dead path conjectures, -dpc flag has to be used or 'Generate DPCs' option has to be checked in Examiner

options, in GPS. It reads also .fal files for its data declarations and the .rls file for proofrules if present. ZombieScope generates two output files: .sdp file (dead path summary) and
.zlg file (details about underlying contradiction search performed). ZombieScope is invoked
by SPARKSimp by default and the summary file generated by POGS includes information
about the dead path analysis.

2.6.4 ViCToR

ViCToR is a tool to translate SPARK verification conditions (VCs), as generated by the Examiner, into SMT-LIB (file format used to communicate with SMT solvers). [Tea] SMT (Satisfiability Modulo Theories) solver is a tool for verification and proving the correctness of programs. ViCToR is integrated with SPARKSimp and POGS. To invoke ViCToR from SPARKSimp, flag -victor has to be used.

2.6.5 Proof Checker

Proof Checker is advanced verification tool, which require considerable experience in verification of SPARK programs. It is interactive program, which enables the user to direct the Checker to explore the use of various strategies and rules on the condition to be proved. Proof Checker can keep a log of the progress of a proof in plg file. It also keep command record in cmd file. More details about Proof Checker can be found in chapter 12 of [Bar13].

2.6.6 SPARKSimp Utility

SPARKSimp is a simple "make" style tool for the SPARK analysis tools. Currently, it supports the Simplifier, ZombieScope and ViCToR. It applies the Simplifier (and ViCToR, if requested) to all .vcg files and ZombieScope to all .dpc files, which it finds in a directory tree. [Tea10]

2.6.7 Proof Obligation Summarizer (POGS)

The Proof ObliGation Summarizer tool (POGS) reads and understands the structure of the verification conditions (.vcg files), their simplified version (.siv files) and dead path conjectures (.dpc files). It reports the status of proofs and dead path analyses in a human-readable, text form. [Teal1a]

2.6.8 AUnit

AUnit is Unit Test Framework for Ada language. It can be also applied for verify SPARK Ada programs. It was created based on Java JUnit (created by Kent Beck, Erich Gamma) and C++ CppUnit (created by M. Feathers, J. Lacoste, E. Sommerlade, B. Lepilleur, B. Bakker, S. Robbins) unit test frameworks [Ada14]. Similar like mentioned frameworks it enables simple test cases testing, fixtures, suites and provides reporting [Fal14]. As mentioned at the beginning of section 2.6 it is used mainly for dynamic verification.

GNAT Programming Studio can generate test cases skeleton for all subprograms. It can be generated using Tools -> GNATtest -> Generate unit test setup. This generator creates new project with AUnit tests. Project for which tests are generated is referenced in new generated project. In order to run tests, the test project has to be opened in GNAT Programming Studio. The project is created in [project_dir]/gnattest/harness/test_[proj_name].gpr. It generates empty (not implemented) test for each subprogram in project. To add/edit/remove tests or rename names, three files has to be edited:

- [some_package]-test_data-tests.ads
- [some_package]-test_data-tests.adb
- [some_package]-test_data-tests-suite.adb

Test has to be declared in [some_package]-test_data-tests.ads and implemented in [some_package]-test_data-tests.adb. Then it has to be added to test suite in [some_package]-test_data-tests-suite.adb file.

Tests can be also created manually. Then the AUnit distribution has to be referenced in project file and all test cases (and suits) has to be implemented by hand.

2.6.9 Sireum Bakar

Sireum²⁹ is a long-term research conducted by SAnToS lab at Kansas State University. Its goal is to develop an over-arching software analysis platform that incorporates various static analysis techniques such as data-flow framework, model checking, symbolic execution, abstract interpretation, and deductive reasoning techniques (e.g., using weakest precondition calculation). It can be used to build various kinds of software static analyzers for different kinds of properties.

It uses the Pilar language [SC12] as intermediate representation. Any language which can be translated to Pilar can be analyzed by Sireum. For now, there is translator for SPARK and Java.

Bakar is a toolset for analyzing SPARK Ada programs (Bakar means "spark" in Indonesian). Sireum Bakar currently includes:

- Kiasan functional behaviors verification tool
- Alir information flow analysis tool

Sireum distribution is available for Windows (32-bit, 64-bit), Linux (32-bit, 64-bit) and MacOS (64-bit). It can be downloaded from http://www.sireum.org/.

²⁹http://www.sireum.org/

Bakar Kiasan

Bakar Kiasan [BHR⁺11] is a fully automated tool for verifying functional behaviors of SPARK programs specified as software contract (Kiasan means "symbolic" in Indonesian). Kiasan use symbolic execution technique. It provides various helpful feedback including generation of counter example for contract refutation, test cases for an evidence of contract satisfaction, verification reports, visual graphs illustrating pre/post states of SPARK procedures/functions, etc. It is much easier for hazard analysis than e.g. analysis of .vcg files generated by SPARK Examiner.

There exists Kiasan Plug-in for GNAT Programming Studio (GPS). Version 1, for GPS 5, supports SPARK 2005. Version 2, for GPS 6, which supports 2014 is under development. Both plug-ins are created by author of this thesis in Python and PyGTK. There is also plug-in for Eclipse, but only for SPARK 2005 programs.

Bakar Kiasan does not support Ravenscar profile. Thus, it can be used only for sequential programs verification. Figure 2.9 depicts sample Kiasan analysis result. Kiasan window has two parts: list of units (packages and subprograms) and analysis cases with pre and post states. Every unit has associated statistics:

- \bullet T# Test cases (expected behavior)
- E# Exception cases (unexpected behavior)
- Instruction coverage amount of code covered by Kiasan analysis
- Branch coverage number of branches covered by analysis (0% in 100% instruction coverage means, that there is no branches in analyzed unit)
- Time in which analysis was performed

After double click on some unit, code which is executed during execution of this unit is highlighted. Additionally below the list of units, there is a combo box which contains all test cases associated with selected (by double click) unit. Once, some case is selected, code coverage equivalent to this test case is highlighted. Additionally, below combo box, there are states of unit execution. On the left hand side, there is pre-state, and on the right hand side there post-state of analysis. Variables with red font color, in post-state, are those which are changed in result of unit execution. The new created variables (during unit execution) are blue, but there are not present in figure 2.9.




Figure 2.9: Bakar Kiasan report

Bakar Kiasan is useful especially, for solving verification issues. It can generate counter examples, which help to fix the code. [add screenshot with error case and discuss result?]

Bakar Alir

Alir is an information flow analysis tool for reasoning about SPARK's derive clauses/information flow (Alir means "flow" in Indonesian). Alir visualizes information flows to ease engineers in understanding information dependencies crucial for specifying and verifying SPARK's derive clauses. It provides various configurable intra-procedural and interprocedural analyses. The inter-procedural analyses are control flow analysis, reaching definition analysis and data dependence analysis. The inter-procedural analysis in Alir includes building, System Dependence Graph (SDG), slicing and chopping on SDG. [Thi11]

2.6.10 GNAT Prove

GNATprove ³⁰ is a formal verification tool for SPARK 2014 programs. It is based on the GNAT compiler. GNATprove interprets SPARK Ada annotations exactly like they are interpreted at run time during tests. It can prove that subprograms respect their contracts, expressed as preconditions and postconditions in the syntax of Ada 2012. The tool automatically discovers the subset of subprograms which can be formally analyzed. GNATprove is currently available for x86 linux, x86 windows and x86-64 linux.

[Add more details? Some example like in Kiasan section?]

2.7 AADL/BLESS to SPARK Ada code generation

The ultimate goal of long term research, this thesis is part of, is AADL (with BLESS) to SPARK Ada translation. Prototyping Embedded Systems using AADL lasts for a few years [CB09]. There are already existing tools, which performs code generation based on AADL:

• Ocarina

³⁰http://www.open-do.org/projects/hi-lite/gnatprove/

• Ramses

2.7.1 Ocarina

Ocarina [LZPH09] is a tool suite, which contains plug-ins for code generation, model checking and analysis. The code generation plug-in generates code from an AADL architecture model to an Ada or C application running on top of PolyORB framework. In this context, PolyORB acts as both the distribution middleware and execution runtime on all targets supported by PolyORB. Ocarina is written in Ada.

There is plug-in for OSATE (see section 2.3.1), which enables code generation. Example AADL models, suitable for being an input of Ocarina are available on github repository: https://github.com/yoogx/polyorb-hi-ada/tree/master/examples/aadlv2.

Since mid-2009, Telecom ParisTech is no longer involved in Ocarina, and is developing another AADL tool-chain, based on Eclipse, codenamed RAMSES [Hug13].

[Include some examples and generated code? E.g. prod-cons example?]

2.7.2 RAMSES

RAMSES (Refinement of AADL Models for Synthesis of Embedded Systems) is a model transformation and code generation tool. It is written in Java. RAMSES produces C code, but does not generate Ada. It simplify AADL models, in order to generate C code. Simplified AADL models contain behavior annex subclauses. RAMSES can be used as OSATE plug-in or standalone application.

[I didn't find much about RAMSES online...]

Chapter 3

PCA Pump

Patient Controlled Analgesia (PCA) pump is a medical device, which allows the patient to self-administer small doses of narcotics (usually Morphine, Dilaudid, Demerol, or Fentanyl). PCA pumps are commonly used after surgery to provide a more effective method of pain control than periodic injections of narcotics. A continuous infusion (called a basal rate) permits the patient to receive a continuous infusion of pain medication. There is no need for a clinician to administer it. Patient can also request additional boluses, but only in specified intervals. It prevents from over infusion. In addition to basal and patient bolus, clinician can also request bolus called clinician bolus or square bolus.



Figure 3.1: Patient Controlled
Analgesia (PCA) pump

Figure 3.1 shows LifeCare PCA pump. On the left hand side, there is drug reservoir.

On the right - clinician panel, which allows to control the pump. Figure 3.2 shows PCA

Pump, made by company Alaris.



Figure 3.2: Alaris Pump

PCA Pump is safety-critical device which works in standard process control loop depicted in the figure 3.3. The controller obtains information about (observes) the process state from measured variables (feedback) and uses this information to initiate action by manipulating controlled variables to keep the process operating within predefined limits or set points (the goal) despite disturbances to the process. Such as different air pressure or device position (gravity impact). In general, the maintenance of any open-

system hierarchy (either biological or man-made) will require a set of processes in which there is communication of information for regulation or control. [Lev12]




Figure 3.3: Standard Process Control Loop.

PCA Pump actuator is motor, which pump drug to the patient's vein. Controlled process is dosing the drug. Sensors measure amount of dosed drug. They might be used for double-check if ordered (by controller) amount of drug was appropriately delivered. Sometimes there might be some distrubances caused by mechanical issues and environmental conditions. Controller issues appropriate actions based on informations from sensors and clinician or patient's commands. High level overview of PCA Pump is depicted in the figure 3.4.




Figure 3.4: PCA Pump system

One of the hazards of using PCA pumps, is that there is inadequate monitoring of patient's levels of oxygen and carbon dioxide. Nursing staff on general medical units typically track respiration rate and other vital signs every four hours, which is not enough. There should be a way to monitor levels continuously. Additionally, it can be hard to tell if a person's breathing rate is dangerously low in certain circumstances. There are cases, where

lack of monitoring carbon dioxide level caused death.¹

Another hazard is human mistake. For example, there is a case when nurse used a 5 mg/mL morphine cassette because a 1 mg/mL cassette was not available, but she programmed PCA Pump like for 1 mg/mL concentration. In addition to lack of monitoring of the pulse, patient died.²

As mentioned in chapter 2, the solution to that problem is medical devices interoperability. In addition, less human error-prone device is needed. It can be assured by using more than one system for their detection.

3.1 PCA Pump Requirements Document

Requirements of "Open Source PCA Pump" [LHC13] are captured in "Integrated Clinical Environment Patient-Controlled Analgesia Infusion Pump System Requirements" document [Lar14] created by Brian Larson. It is formalized set of capabilities, which Open PCA Pump should have, based on consultations with domain experts, FDA and Brian Larson's expertise gained while he was working in the medical device industry.

Conceptual model of Open PCA pump is depicted in the figure 3.5. As mentioned earlier, the pump is connected to ICE so it may be integrated with ICE apps and displays. The interface must provide prescription and patient information, current status to be displayed remotely on a supervisor user interface, and a means to stop infusing upon human command, or determination of an ICE app. Such an ICE app could monitor a patient's blood oxygenation and pulse rate, stopping the pump if depressed respiratory function is indicated. [Lar14]

Additionally, it cooperates with Drug Library, which contains information about drugs and its properties (like concentration). Data needed for pump operation, are captured on

¹http://abcnews.go.com/Health/parents-warn-pca-pumps-daughters-death/story?id=16796805

²http://webmm.ahrq.gov/case.aspx?caseID=291




Figure 3.5: Open PCA Pump concept

electronic prescription, which contains:

- Patient's name
- Drug name
- Drug code
- Drug concentration
- Initial volume of drug in the vial
- Basal flow rate the rate of continuous infusion

- Volume to be infused (VTBI) on patient's request
- Maximum amount of drug allowed per hour
- Minimum time between patient boluses
- Date, in which prescription has been filled
- Prescribing physician's name
- Pharmacist name

Pain medication is prescribed by a licensed physician, which is dispensed by the hospital's pharmacy. The drug is placed into a vial labeled with the name of the drug, its concentration, the prescription, and the intended patient. A clinician loads the drug into the pump, and attaches it to the patient. The pump infuses a prescribed basal flow rate which may be augmented by a patient-requested bolus or a clinician-requested bolus. This allows additional pain medication in response to patient need within safe limits. [Lar14]

Prescription captures all data needed for basal infusion and patient requested boluses (referred as bolus). In addition to that, Open PCA Pump allows Clinician Requested Bolus (referred as square bolus). In order to do that, clinician has to enter the time (through PCA Pump panel) in which VTBI, specified in prescription, will be infused.

There can occur situations in which the maximum drug amount infused may exceed the allowed limit. E.g. when clinician issues too many square boluses. In such case, pump is switched to Keep Vein Open (KVO) mode, which has 1 ml/hr drug rate. Pump switches to KVO rate also when ICE interface request it. It may happen e.g. if patient's oxygen level is low. To recover from KVO state, pump has to be restarted by clinician in order to continue operation. In Summary, Open PCA Pump has following modes:

Stopped

- Basal rate
- Patient's bolus (bolus)
- Clinician bolus (square bolus)
- Keep Vein Open (KVO)

There are also other scenarios, which are captured by Requirements Document [Lar14], like scanner to enable automatic entry of patient's and prescription data, occlusion detection, hardware errors alarms etc. Detailed overview of Open PCA Pump Requirements can be found in [LHC13].

[MORE DETAILS ABOUT PUMP?] [ADD STATE MACHINE IMAGE, LIKE IN UMINN REQ COD?]

3.2 PCA Pump AADL/BLESS Models

In addition to PCA Pump Requirements Document [Lar14], Brian Larson created AADL model with formal behavioral specifications written in his BLESS framework. AADL model, graphical representation is depicted on figure 3.6.

AADL model captures structure of device. BLESS - its behavior. Listing 3.2 shows Rate_Controller thread from PCA_Operation component with BLESS assertions in thread declaration and BLESS behavioral description in thread implementation. The thread declaration contains input and output ports. In addition to some of them, BLESS assertions are present. Assertions are defined in BLESS annex in thread implementation. In addition to assertions, states and transitions defined in thread implementation can potentially be translated into working SPARK Ada program. Presence of timing properties in states and transitions makes translation extremely difficult, thus there are omitted in this thesis and only assertions are considered. [TRUNCATE CODE LISTING?]




Figure 3.6: Open PCA Pump AADL model

```
thread Rate_Controller
features
   Infusion_Flow_Rate: out data port PCA_Types::Flow_Rate
      {BLESS::Assertion => "<<:=PUMP_RATE()>>";};
   System_Status: out event data port PCA_Types::Status_Type;
    Begin_Infusion: in event port
      {BLESS::Assertion => "<<Rx_APPROVED()>>";};
   Begin_Priming: in event port;
   End_Priming: in event port;
   Halt_Infusion: in event port;
   Square_Bolus_Rate: in data port PCA_Types::Flow_Rate
      {BLESS::Assertion => "<<:=SQUARE_BOLUS_RATE>>";};
   Patient_Bolus_Rate: in data port PCA_Types::Flow_Rate
      {BLESS::Assertion => "<<:=PATIENT_BOLUS_RATE>>";};
   Basal_Rate: in data port PCA_Types::Flow_Rate
      {BLESS::Assertion => "<<:=BASAL_RATE>>";};
    VTBI: in data port PCA_Types::Drug_Volume
      {BLESS::Assertion => "<<:=VTBI>>";};
   HW_Detected_Failure: in event port;
   Stop_Pump_Completely: in event port;
   Pump_At_KVO_Rate: in event port;
   Alarm : in event data port PCA_Types::Alarm_Type;
   Warning : in event data port PCA_Types::Warning_Type;
   Patient_Request_Not_Too_Soon: in event port
      {BLESS::Assertion => "<<:=PATIENT_REQUEST_NOT_TOO_SOON(now)>>";};
   Door_Open: in data port Base_Types::Boolean;
   Pause_Infusion: in event port;
   Resume_Infusion: in event port;
   CP_Clinician_Request_Bolus: in event port;
   CP_Bolus_Duration: in event data port ICE_Types::Minute;
   Near_Max_Drug_Per_Hour: in event port --near maximum drug infused in any hour
      {BLESS::Assertion => "<<PATIENT_NEAR_MAX_DRUG_PER_HOUR()>>";};
   Over_Max_Drug_Per_Hour: in event port --over maximum drug infused in any hour
      {BLESS::Assertion => "<<PATIENT_OVER_MAX_DRUG_PER_HOUR()>>";};
   ICE_Stop_Pump: in event port;
  properties
   Thread_Properties::Dispatch_Protocol => Aperiodic;
end Rate_Controller;
thread implementation Rate_Controller.imp
annex BLESS
{**
assert.
-- the infusion flow rate shall be:
-- =0, after stop pump completely (from safety architecture),
       clinician pressed stop button
-- =KVO rate, after KVO rate command, or
      exceeded max drug per hour
--
       some alarms,
-- =max rate, during patient-requested infusion
-- =square bolus rate, during clinician-commanded infusion
-- =priming rate during pump priming
-- =basal rate, otherwise
<<HALT : :(la=SafetyPumpStop) or (la=StopButton) or (la=EndPriming)>> --pump at 0 if stop button, or
  safety architecture says, or done priming
<<KVO_RATE : :(la=KVOcommand) or (la=KVOalarm) or (la=TooMuchJuice)>> --pump at KVO rate when commanded,
  some alarms, or excedded hourly limit
<<PB_RATE : :la=PatientButton>> --patient button pressed, and allowed
<<CCB_RATE : :(la=StartSquareBolus) or (la=ResumeSquareBolus)>> --clinician-commanded bolus start or
  resumption after patient bolus
<<PRIME_RATE : :la=StartPriming>> --priming pump
<<BASAL_RATE : :(la=StartButton) or (la=ResumeBasal) or (la=SquareBolusDone)>> --regular infusion
<<PUMP_RATE : :=
  (HALT()) \rightarrow 0,
                                                      --no flow
```

```
(KVO_RATE()) -> PCA_Properties::KVO_Rate,
                                                      --KVO rate
  (PB_RATE()) -> Patient_Bolus_Rate, --maximum infusion upon patient request
  (CCB_RATE()) -> Square_Bolus_Rate,
                                                   --square bolus rate=VTBI/duration, from data port
  (PRIME_RATE()) -> PCA_Properties::Prime_Rate,
                                                      --pump priming
  (BASAL_RATE()) -> Basal_Rate
                                                      --basal rate, from data port
invariant <<true>>
variables
  --time of last action
 tla :BLESS_Types::Time := 0;
 la : --last action
   enumeration (
     SafetyStopPump, --safety architecture found a problem
     StopButton, --clinician pressed stop button

KVOcommand, --from control panel (clinician) or ICE (app) to pump Keep-vein-open rate
                     --some alarms should pump at KVO rate
     KVOalarm,
      TooMuchJuice, --exceeded max drug per hour, pump at KVO until prescription and patient are re-
  authenticated
     PatientButton, --patient requested drug
     ResumeSquareBolus, --infusion of VTBI finished, resume clinician-commanded bolus
     ResumeBasal, --infusion of VTBI finished, resume basal-rate
     StartSquareBolus, --begin clinician-commanded bolus
     {\tt SquareBolusDone, --infusion \ of \ VTBI \ finished}
     StartPriming, --begin pump/line priming, pressed prime button again, or time-out
                      --start pumping at basal rate
     StartButton
   );
 pb_duration : BLESS_Types::Time --patient button duration = VTBI/Patient_Bolus_Rate
   <<PB_DURATION : :pb_duration=(VTBI/Patient_Bolus_Rate)>>;
  PowerOn : initial state;
                                 --power-on
  WaitForRx : complete state; --wait for valid prescription
  CheckPBR : state --check Patient_Bolus_Rate is positive
   <<Rx_APPROVED()>>;
 RxApproved : complete state --prescription verified
   <<Rx_APPROVED() and PB_DURATION()>>;
  Priming : complete state
                              --priming the pump, 1 ml in 6 sec
    <<(la=StartPriming) and (Infusion_Flow_Rate@now = PCA_Properties::Prime_Rate) and PB_DURATION()>>;
  WaitForStart : complete state --wait for clinician to press 'start' button
   <<HALT() and (Infusion_Flow_Rate@now=0) and PB_DURATION()>>;
 PumpBasalRate : complete state --pumping at basal rate
   <>((la=StartButton) or (la=ResumeBasal)) and (Infusion_Flow_Rate@now=Basal_Rate@now) and PB_DURATION()
  PumpPatientButtonVTBI : complete state --pumping patient-requested bolus
   <<(la=PatientButton) and PB_DURATION()
      and (Infusion_Flow_Rate@now=Patient_Bolus_Rate)>>;
 PumpCCBRate : complete state --pumping at clinician-commanded bolus rate
   <>(((la=StartSquareBolus) or (la=ResumeSquareBolus)) and (Infusion_Flow_Rate@now=Square_Bolus_Rate@now)
  and PB_DURATION()>>;
 PumpKVORate : complete state
                                 --pumping at keep-vein-open rate
    <<((la=KVOcommand) or (la=KVOalarm) or (la=TooMuchJuice)) and PB_DURATION()
     and (Infusion_Flow_Rate@now=PCA_Properties::KVO_Rate)>>;
  PumpingSuspended : complete state --clinician pressed 'stop' button
   <<((la=StopButton) or (la=SafetyStopPump)) and (Infusion_Flow_Rate@now=0)>>;
  Crash : final state; --abnormal termination
 Done : final state
                       --normal termination
    <<Infusion_Flow_Rate@now=0>>;
transitions
--wait for valid prescription
 go : PowerOn-[ true ]->WaitForRx{};
--prescription validated
 rxo : WaitForRx-[ on dispatch Begin_Infusion ]-> CheckPBR{};
  pbr0 : CheckPBR-[ Patient_Bolus_Rate<=0 ]->Crash{}; --bad Patient_Bolus_Rate
 pbrok : CheckPBR-[ Patient_Bolus_Rate>0 ]->RxApproved
    {<<Rx_APPROVED() and (Patient_Bolus_Rate>0)>> --likely will change from logic variable to predicate
```

```
Rx_APPROVED()
     pb_duration := VTBI/Patient_Bolus_Rate --calculate patient bolus duration
      --note division without knowing divsor is non-zero; should generate additional proof obligations for
  assignment using division
   <<Rx_APPROVED() and PB_DURATION()>>};
--clinician press 'prime' button
 rxpri : RxApproved-[ on dispatch Begin_Priming ]-> Priming
   {
   la :=StartPriming
       <<Begin_Priming@now and Rx_APPROVED() and (la = StartPriming) and PB_DURATION()>>
   Infusion_Flow_Rate!(PCA_Properties::Prime_Rate) --infuse at prime rate
       <<(la = StartPriming) and Rx_APPROVED() and PB_DURATION() and
         (Infusion_Flow_Rate@now=PCA_Properties::Prime_Rate)>>
--priming done, wait for start
 prd: Priming-[ on dispatch End_Priming or timeout (Begin_Priming) PCA_Properties::Prime_Time sec]->
  WaitForStart
   la:=EndPriming
     <<HALT() and PB_DURATION()>> --and Begin_Priming timed out
   Infusion_Flow_Rate!(0) --stop priming flow
     <<HALT() and (Infusion_Flow_Rate@now=0) and PB_DURATION()>>
   };
--prime again
 pri: WaitForStart-[ on dispatch Begin_Priming ]-> Priming
   Ł
   la:=StartPriming
       <<Begin_Priming@now and PB_DURATION() and PRIME_RATE()>>
   Infusion_Flow_Rate!(PCA_Properties::Prime_Rate) --infuse at prime rate
       <<PRIME_RATE() and PB_DURATION() and
         (Infusion_Flow_Rate@now=PCA_Properties::Prime_Rate)>>
--clinician press 'start' button after priming
 sap: WaitForStart-[ on dispatch Begin_Infusion ]-> PumpBasalRate --start after priming
   {
   la:=StartButton
     <<(la=StartButton) and Begin_Infusion@now and PB_DURATION()>>
   Infusion_Flow_Rate!(Basal_Rate) --infuse at basal rate
     <<(la=StartButton) and (Infusion_Flow_Rate@now=Basal_Rate@now) and PB_DURATION()>>
--Patient_Request_Bolus during basal rate infusion
 pump basal rate:
 PumpBasalRate-[ on dispatch Patient_Request_Not_Too_Soon]-> PumpPatientButtonVTBI
   {
   la := PatientButton
     <<(la=PatientButton) and Patient_Request_Bolus@now and PB_DURATION()>>
   Infusion_Flow_Rate!(Patient_Bolus_Rate)
                                             --infuse at patient button rate
     <<(la=PatientButton) and PB_DURATION()
       and (Infusion_Flow_Rate@now=Patient_Bolus_Rate)>>
   }; --end of pump_basal_rate
--VTBI delivered
 vtbi delivered:
 PumpPatientButtonVTBI -[ on dispatch timeout (Infusion_Flow_Rate) pb_duration ms ]-> PumpBasalRate
   {
   la:=ResumeBasal
   <<(la=ResumeBasal) and PB_DURATION()>> --and timeout of patient button duration
   Infusion_Flow_Rate!(Basal_Rate) --infuse at basal rate
     <>(la=ResumeBasal) and (Infusion_Flow_Rate@now=Basal_Rate@now) and PB_DURATION()>>
   }; --end of vtbi_delivered
```

```
**};
end Rate_Controller.imp;
```

Listing 3.1: Rate_Controller thread from PCA_Operation component with BLESS assertions

3.3 BeagleBoard-XM

For Research and MDCF purposes, BeagleBoardxM (an open-source hardware single-board computer produced by Texas Instruments), has been chosen as hardware platform for PCA pump prototyping.

BeagleBoard-xM is Embedded device with AM37x 1GHz ARM processor (Cortex-A8 compatible). It has 512 MB RAM, 4 USB 2.0 ports, HDMI port, 28 General-purpose input/output (GPIO) ports and Linux Operating System (on microSD card). Moreover there is PWM support, which enables control of pump actuator.



Figure 3.7: BeagleBoard-xM

Pulse-width modulation (PWM) is a

technique for controlling analog circuits with a processor's digital outputs. The average value of voltage (and current) fed to the electrical load is controlled by turning the switch between supply and load on and off at a fast pace. The longer the switch is on compared to the off periods, the higher the power supplied to the load. Proportion of on and off periods is called the duty cycle and is expressed in percent. 100% means all the time on, 0% - all the time off. Figure 3.8 shows 10%, 30%, 50% and 90% duty cycles.

There is no existing SPARK Ada compiler running on ARM system. Hence, to compile




Figure 3.8: An example of PWM duty cycles

SPARK Ada program for ARM device, cross-compiler is needed. There is GNAT compiler [Hor09] created by AdaCore, but there was no cross-compiler for ARM. However, AdaCore was actively developing cross-compiler. They had working version in 2013, but tested only on their target Android-based device. In cooperation with AdaCore, cross-compiler for ARM was bundled and tested on BeagleBoard-xM. For now, GNAT cross-compiler works only on Linux 32-bit operating system.

In addition to USB ports, BeagleBoard-xM has also serial port and Ethernet port. It allows to copy programs compiled on Linux, using all three types of ports.

Chapter 4

AADL/BLESS to SPARK Ada

translation

This chapter presents created AADL/BLESS to SPARK Ada translation schemes (4.1), proposed port communication (4.2) and discuss design of automatic translator, which can be created based on translation schemes (4.3). Related work in code generation from AADL, but to Java has been done in [PHR].

4.1 AADL/BLESS to SPARK Ada mapping

Mapping of AADL models to SPARK Ada is driven by "Architecture analysis & Design Language (AADL) V2 Programming Language Annex Document" [SCD14]. This document was discussed during AADL User Days in Valencia (February 2013)¹ and in Jacksonville, FL (April 2013)². Ocarina tool suite (based on older AADL annex documents [HZPK08]) and its examples³ was also helpful in understanding of AADL to Ada translation. Mapping

 $^{^{1}} http://www.aadl.info/aadl/downloads/committee/feb2013/presentations/13_02_04-AADL-Code\%20Generation.pdf$

²https://wiki.sei.cmu.edu/aadl/images/8/8a/Constraint Annex April22.v3.pdf

 $^{^3}$ https://github.com/yoogx/polyorb-hi-ada/tree/master/examples/aadlv2

of BLESS assertions was created in consultation with Brian Larson (BLESS creator).

4.1.1 Data types mapping

One of core AADL packages is Base_Types. It defines fundamental data types for AADL. Its definition is shown in listing 4.1.1.

```
package Base_Types
public
  with Data_Model;
  data Boolean
  properties
   Data_Model::Data_Representation => Boolean;
  end Boolean;
 data Integer
 properties
   Data_Model::Data_Representation => Integer;
 end Integer;
 -- Signed integer of various byte sizes
 data Integer_8 extends Integer
 properties
   Data_Model::Number_Representation => Signed;
   Source_Data_Size => 1 Bytes;
 end Integer_8;
  data Integer_16 extends Integer
 properties
   Data_Model::Number_Representation => Signed;
   Source_Data_Size => 2 Bytes;
  end Integer_16;
  data Integer_32 extends Integer
  properties
   Data_Model::Number_Representation => Signed;
   Source_Data_Size => 4 Bytes;
 end Integer_32;
 data Integer_64 extends Integer
   Data_Model::Number_Representation => Signed;
   Source_Data_Size => 8 Bytes;
 end Integer_64;
 -- Unsigned integer of various byte sizes
 data Unsigned_8 extends Integer
   Data_Model::Number_Representation => Unsigned;
   Source_Data_Size => 1 Bytes;
  end Unsigned_8;
  data Unsigned_16 extends Integer
 properties
```

```
Data_Model::Number_Representation => Unsigned;
   Source_Data_Size => 2 Bytes;
  end Unsigned_16;
  data Unsigned_32 extends Integer
  properties
   Data_Model::Number_Representation => Unsigned;
   Source_Data_Size => 4 Bytes;
 end Unsigned_32;
  data Unsigned_64 extends Integer
 properties
   Data_Model::Number_Representation => Unsigned;
   Source_Data_Size => 8 Bytes;
  end Unsigned_64;
  data Natural extends Integer
 properties
   Data_Model::Integer_Range => 0 .. Max_Target_Integer;
 end Natural;
  data Float
 properties
   Data_Model::Data_Representation => Float;
 end Float;
  {f data} Float_32 extends Float
 properties
   Data_Model::IEEE754_Precision => Simple;
   Source_Data_Size => 4 Bytes;
 end Float_32;
 data Float_64 extends Float
 properties
   Data_Model::IEEE754_Precision => Double;
   Source_Data_Size => 8 Bytes;
 end Float_64;
  data Character
 properties
   Data_Model::Data_Representation => Character;
  end Character;
  data String
 properties
   Data_Model::Data_Representation => String;
 end String;
end Base_Types;
```

Listing 4.1: AADL Base Types package

In Ada 2012, and thus SPARK 2014, there is package Interfaces, which allows for easy mapping of AADL Base_Types package. Mapping proposed in Annex Document [SCD14] is presented on listing 4.1.1.

```
with Interfaces;

package Base_Types is
```

```
type AADL_Boolean is new Standard.Boolean;
 type AADL_Integer is new Standard.Integer;
 type Integer_8 is new Interfaces.Integer_8;
 type Integer_16 is new Interfaces.Integer_16;
 type Integer_32 is new Interfaces.Integer_32;
 type Integer_64 is new Interfaces.Integer_64;
 type Unsigned_8 is new Interfaces.Unsigned_8;
 type Unsigned_16 is new Interfaces.Unsigned_16;
 type Unsigned_32 is new Interfaces.Unsigned_32;
 type Unsigned_64 is new Interfaces.Unsigned_64;
 type AADL_Natural is new Standard.Integer; -- XXX incomplete range?
 type AADL_Float is new Standard.Float;
 type Float_32 is new Interfaces.IEEE_Float_32;
 type Float_64 is new Interfaces.IEEE_Float_64;
   type AADL_Character is new Standard.Character;
end Base_Types;
```

Listing 4.2: Mapping of Base_ Types for SPARK 2014

Target language for this thesis is SPARK 2005. SPARK 2014 tools and especially multitasking capabilities were not ready, during the time when this thesis was written. Types: Float, Character and String are also not part of this thesis, because of verification tools limitation. Thus, only Integer, Enumeration, Boolean and Record types are taken into account in mappings.

Each type is translated into simple type definition and protected type. Then it can be used in multitasking programs with Ravescar Profile. For every protected type only setter (Put) and getter (Get) subprograms are defined. It can be extended by developer during development phase. Protected objects can be also removed if they are not needed. Default value for priority, for each generated type is 10. It can be changed during development phase according to implementation details. Types: Integer, Boolean and Natural are already defined in SPARK Ada, thus only protected objects are generated for them. AADL Base_Types mapping to SPARK 2005 is presented in table 4.1.

Table 4.1: Base AADL types to SPARK mapping.

AADL	SPARK Ada
<pre>data Integer properties Data_Model::Data_Representation => Integer; end Integer;</pre>	<pre>protected type Integer_Store is pragma Priority (10); function Get return Integer; # global in Integer_Store; procedure Put(X : in Integer); # global out Integer_Store; # derives Integer_Store from X; private TheStoredData : Integer := 0; end Integer_Store;</pre>
<pre>data Integer_16 extends Integer properties Data_Model:: Number_Representation => Signed; Source_Data_Size => 2 Bytes; end Integer_16;</pre>	<pre>type Integer_16 is new Integer range -2**(2*8-1) 2**(2*8-1-1); protected type Integer_16_Store is pragma Priority (10); function Get return Integer_16; # global in Integer_16_Store; procedure Put(X : in Integer_16); # global out Integer_16_Store; # derives Integer_16_Store from X; private TheStoredData : Integer_16 := 0; end Integer_16_Store; protected body Integer_16_Store is function Get return Integer_16 # global in TheStoredData; is begin return TheStoredData; end Get; procedure Put(X : in Integer_16) # global out TheStoredData; # derives TheStoredData from X; is begin TheStoredData := X; end Put; end Integer_16_Store;</pre>
	Continued on next page

Table 4.1 – continued from previous page

<pre>data Unsigned_16 extends Integer properties Data_Model:: Number_Representation => Unsigned; Source_Data_Size => 2 Bytes; end Unsigned_16;</pre>	<pre>type Unsigned_16 is new Integer range 0 2**(2*8-1); protected type Unsigned_16_Store is pragma Priority (10); function Get return Unsigned_16; # global in Unsigned_16_Store; procedure Put(X : in Unsigned_16); # global out Unsigned_16_Store;</pre>
	# global out Unsigned_16_Store;# derives Unsigned_16_Store from X; private TheStoredData : Unsigned_16 := 0; end Unsigned_16_Store; protected body Unsigned_16_Store is function Get return Unsigned_16# global in TheStoredData; is
	<pre>begin return TheStoredData; end Get; procedure Put(X : in Unsigned_16) # global out TheStoredData; # derives TheStoredData from X;</pre>
	is begin TheStoredData := X; end Put; end Unsigned_16_Store;

Table 4.1 – continued from previous page

data Type_With_Range properties Data_Model:: Data_Representation => Integer; Data_Model::Base_Type => (classifier (Base_Types:: Unsigned_16)); Data_Model:Integer_Range => 01000; end Type_With_Range; end Type_With_Range; type Type_With_Range is new Integer range 0 1000; protected type Type_With_Range_Store is pragma Priority (10); function Get return Type_With_Range;# global in Type_With_Range_Store;# derives Type_With_Range_Store;# derives Type_With_Range_Store from X; private TheStoredData : Type_With_Range_Store is function Get return Type_With_Range_Store;# derives Type_With_Range_Store is function Get return Type_With_Range.Store;# global out Type_With_Range_Store is function Get return Type_With_Range := 0; end Unsigned_16_Store; protected body Type_With_Range_Store is function Get return Type_With_Range := 0; end Unsigned_16_Store; protected body Type_With_Range := 0; end Unsigned_16_Store; protected body Type_With_Range := 0; end Unsigned_16_Store; protected body Type_With_Range := 0; end Unsigned_16_Store; protected type Type_With_Range_Store is function Get return Type_With_Range;# global out Type_With_Range.Store;# derives Type_With_Range_Store;# global out TheStoredData; is begin TheStoredData := X; end Put; seen Type_With_Range Store Integer
end Type_With_Range_Store;

Type range is defined using AADL properties: Data_Model::Number_Representation, Source_Data_Size and Data_Model::Integer_Range. When Data_Model::Integer_Range property is not specified, then range is calculated. In case of Integer representation range starts from negative value, for Unsigned - from 0. Maximum value for Integer is calculated using the formula 4.1.

$$Integer_[Number_Of_Bytes * 8]_Max = 2^{Number_Of_Bytes*8-1} - 1 \tag{4.1}$$

The minimum value formula for Integer (4.2) and maximum value for Unsigned (4.3) use similar strategy.

$$Integer_[Number_Of_Bytes * 8]_Min = -2^{Number_Of_Bytes*8-1}$$
 (4.2)

$$Unsigned_[Number_Of_Bytes * 8]_Max = 2^{Number_Of_Bytes * 8} - 1$$
 (4.3)

Mapping for enumeration types, presented on table 4.2, is pretty straightforward. BLESS properties are ignored in translation. In addition to simple types, protected types are generated.

Continued on next page

Table 4.2 – continued from previous page

	1 0
\mathbf{AADL}	SPARK Ada

Table 4.2: AADL/BLESS enumeration types to SPARK mapping.

AADL	SPARK Ada
<pre>data Enum_Type properties BLESS::Typed=>"enumeration (Enumerator1, Enumerator2, Enumerator3)"; Data_Model::Data_Representation => Enum; Data_Model::Enumerators => ("Enumerator1", " Enumerator2", "Enumerator3"); end Enum_Type;</pre>	<pre>type Enum_Type is (Enumerator1, Enumerator2,</pre>

Sometimes it is pragmatic to define a type, which has exactly the same range like some already existing type. Especially when it is used for some specific calculations. E.g. measuring the speed. Let's say, that Unsigned_16 was used. Then, during development of next car model, it becomes not enough. In case when e.g. speed_Type is not defined, there are two possible resolutions. First: change definition (range) of Unsigned_16. That is bad choice,

especially because its name specify the range. Another reason: it might be used not only for measuring the Speed, but maybe also for fuel level, which range is still fine. Second option is to change Unsigned_16 to e.g. Unsigned_32 everywhere in Speed Control Module (and maybe also in some external modules). When speed_Type is defined and used everywhere for speed units, then only definition of speed_Type has to be changed. To define type, using existing type in AADL, derived type (defined with extends keyword) or Data_Model::Base_Type property can be used. Translation to SPARK Ada is shown in table 4.3. There are two ways to define type based on some other type in SPARK Ada:

- subtype it is compatible with its parent, in other words: parent type variable can be assigned to it, if its value is in the subtype range
- derived type it is incompatible with its parent (parent type variable cannot be assigned to it), but inherits its primitive operations

Table 4.3: AADL types to SPARK mapping: Subtypes.

AADL	SPARK Ada
<pre>data Speed_Type extends Base_Types::Integer end Speed_Type;</pre>	<pre>subtype Speed_Type is Base_Types.Integer;</pre>
<pre>data Speed_Type properties BLESS::Typed=>"integer"; Data_Model::Base_Type => (classifier(Base_Types::Unsigned_16)); end Speed_Type;</pre>	type Speed_Type is new Base_Types.Unsigned_16;

AADL array type can be defined using property Data_Model::Data_Representation. In addition to that, size for array has to be specified by Data_Model::Dimension property. Sample mapping

of array of 10 integers is shown in table 4.4.

Table 4.4: AADL arrays to SPARK Ada mapping

AADL	SPARK Ada
<pre>data Some_Array properties BLESS::Typed => "array [10] of Base_Types:: Integer_32"; Data_Model::Data_Representation => Array; Data_Model::Base_Type => (classifier(Base_Types::Integer_32)); Data_Model::Dimension => (10); end Some_Array;</pre>	<pre>subtype Some_Array_Index is Integer range 1 10; type Some_Array is array (Some_Array_Index) of Base_Types.Integer_32; protected type Some_Array_Store is pragma Priority (10); function Get(Ind : in Integer) return Base_Types.Integer_32; # global in Some_Array_Store; procedure Put(Ind : in Integer; Val : in Base_Types.Integer_32); # global in out Some_Array_Store; # derives Some_Array_Store from Some_Array_Store, Ind, Val; private TheStoredData : Some_Array := Some_Array'(others => 0); end Some_Array_Store; protected body Some_Array_Store is function Get(Ind : in Integer) return Base_Types.Integer_32 # global in TheStoredData; is begin return TheStoredData(Ind); end Get; procedure Put(Ind : in Integer; Val : in Base_Types.Integer_32) # global in out TheStoredData; # derives TheStoredData from TheStoredData, Ind, Val; is begin TheStoredData(Ind) := Val; end Put; end Some_Array_Store;</pre>

AADL v2 allows to create struct data types, using Data_Model::Data_Representation => Struct.

AADL Struct is mapped to SPARK Ada record type. The mapping is presented in table

Table 4.5: AADL struct to SPARK Ada record mapping

AADL	SPARK Ada
<pre>data Some_Record_Type properties BLESS::Typed => "record (Field1 : Base_Types::Integer_32; Field2 : Base_Types::Boolean; Field3 : Base_Types::Unsigned_32;); Data_Model::Data_Representation => Struct; Data_Model::Element_Names => ("Field1", "Field2", "Field3"); Data_Model::Base_Type => (classifier(Base_Types::Integer_32), classifier(Base_Types::Boolean), classifier(Base_Types::Unsigned_32)); end Some_Record_Type;</pre>	<pre>type Some_Record_Type is record Field1 : Integer_32; Field2 : Boolean; Field3 : Unsigned_32; end record;</pre>

Data types translations are created based on Brian Larson's AADL/BLESS models of PCA Pump. They are syntacticly verified with SPARK Examiner. During development of types mapping, SPARK Examiner was helpful also for detecting inconsistencies in AADL models. Eg. it detected redundancy in enumerators. Both Alarm_Type and Warning_Type contained No_Alarm enumerator, which was a bug. All enumerators, for all types have to be unique. Thus Warning_Type should have No_Warning enumerator instead.

4.1.2 AADL ports mapping

Proposed ports mapping shown in table 4.6 is based on AADL runtime services from Annex 2 to "Programming Language Annex Document" [SCD14]. Additionally, the mapping contains SPARK 2005 contracts. Data types used by ports has to be defined earlier, to be visible. Moreover, for port communication, protected types are used, to enable concurrency.

Table 4.6: AADL to SPARK ports mapping. $\,$

AADL/BLESS	SPARK Ada
Port_Name : in data port Port_Type;	spec (.ads):# own protected Port_Name : Port_Type_Store(Priority => 10) procedure Receive_Port_Name;# global out Port_Name; body (.adb): Port_Name : Port_Type_Store; procedure Receive_Port_Name is begin TODO: implement receiving Port_Name value e.g.: Port_Name.Put(Some_Pkg.Get_Port_Name); end Receive_Port_Name;
Port_Name : out data port Port_Type;	spec (.ads)# own protected Port_Name : Port_Type_Store(Priority => 10) procedure Get_Port_Name(Port_Name_Out : out Port_Type);# global in Port_Name;# derives Port_Name_Out from Port_Name; body (.adb): Port_Name : Port_Type_Store; procedure Get_Port_Name(Port_Name_Out : out Port_Type) is begin Port_Name_Out := Port_Name.Get; end Get_Port_Name;
Port_Name : in event port;	spec (.ads) procedure Put_Port_Name; body (.adb): procedure Put_Port_Name is begin TODO: implement event handler end Put_Port_Name;
	Continued on next page

Table 4.6 – continued from previous page

AADL/BLESS	SPARK Ada
,	
Port_Name : out event port;	spec (.ads) procedure Send_Port_Name;
	body (.adb): procedure Send_Port_Name
	is begin
	TODO: implement receiving Port_Name value e.g.: Some_Pkg.Put_Port_Name; end Send_Port_Name;
Port_Name : in event data port Port_Type;	spec (.ads)# own protected Port_Name : Port_Type_Store(Priority => 10);
	<pre>procedure Put_Port_Name(Port_Name_In : Port_Type);# global out Port_Name;# derives Port_Name from Port_Name_In;</pre>
	body (.adb): Port_Name : Port_Type_Store;
	<pre>procedure Put_Port_Name (Port_Name_In : Port_Type) is begin</pre>
	<pre>Port_Name.Put(Port_Name_In); end Put_Port_Name;</pre>
David Warra	
Port_Name : out event data port Port_Type;	spec (.ads)# own protected Port_Name : Port_Type_Store(Priority => 10);
	<pre>procedure Send_Port_Name; # global in Port_Name;</pre>
	body (.adb): Port_Name : Port_Type_Store;
	procedure Send_Port_Name is
	<pre>begin TODO: implement receiving Port_Name value e.g.:</pre>
	Some_Pkg.Put_Port_Name(Port_Name); end Send_Port_Name;

4.1.3 Thread to task mapping

AADL Threads are mapped into SPARK Ada tasks according to table 4.7. Communication between threads is described in section 4.2.1.

Table 4.7: AADL threads to SPARK Ada tasks mapping.

,	SPARK Ada
package Some_Pkg	package Some_Pkg
thread Some_Thread	is
features	task type Some_Thread
Some_Port : out data port Port_Type;	# global out Some_Port;
end Some_Thread;	is
	pragma Priority(10);
thread implementation Some_Thread.imp	end Some_Thread;
end Some_Thread.imp;	end Some_Pkg;
end Some_Pkg;	
	package body Some_Pkg
	is
	st : Some_Thread;
	task body Some_Thread
	is
	begin
	loop
	implementation
	end loop;
	end Some_Thread;
	end Some_Pkg;

4.1.4 Subprograms mapping

Mappings of subprograms is also straightforward. However, it is different than mapping proposed in "AADL Code Generation Annex" [SCD14]. It does not use renames clause, but mapping directly to subprogram specification and body. For now, body is empty, because behavior (implementation) is not captured. Subprogram mapping should be revised and consulted with AADL committee members, in order to understand their design decisions.

Table 4.8: AADL subprograms to SPARK Ada subprograms mapping.

AADL/BLESS	SPARK Ada
subprogram sp features e : in parameter T; s : out parameter T; end sp;	<pre>procedure sp(e : in T; s : out T); procedure sp(e : in T; s : out T) is begin # implementation end sp;</pre>

4.1.5 Feature groups mapping

In SPARK Ada there are nested packages and child packages. Sample nested packages are shown in listing 4.1.5. Equivalent child packages are shown in listing 4.1.5. The name of a child package consists of the parent unit's name followed by the child package's identifier, separated by a period (dot) '.'. Calling convention is the same for child and nested packages (e.g. p.n in listings 4.1.5 and 4.1.5). However, there is a difference between nested packages and child packages. In nested package, declarations become visible as they are introduced, in textual order. For example, in listing 4.1.5 spec n cannot refer to m in any way. In case of child packages, with certain exceptions, all the functionality of the parent is available to a child and parent can access all its child packages. More precisely: all public and private declarations of the parent package are visible to all child packages. Private child package can be accessed only from parent's body.

```
package P is
   D: Integer;

-- a nested package:
   package N is
    X: Integer;
   private
    Foo: Integer;
   end N;

E: Integer;
private
   -- nested package in private section:
   package M is
    Y: Integer;
private
   Bar: Integer;
```

```
end M;
end P;
```

Listing 4.3: Nested packages in SPARK Ada

```
package P is
  D: Integer;
   E: Integer;
end P;
   a child package:
package P.N is
   X: Integer;
 private
   Foo: Integer;
end P.N;
-- a child private package:
private package M is
  Y: Integer;
private
 Bar: Integer;
end M;
```

Listing 4.4: Child packages in SPARK Ada

There was an idea to create child package to encapsulate one feature group in it. However, SPARK Ada does not allow to access child packages private part from parent. Thus, it will require to expose feature group internal variable as public. It is definitely not good solution. Thus, feature group is translated with prefix Feature_Group_Name_*. Feature group mapping is presented in section 4.1.6, in listings 4.1.6 and 4.1.6.

4.1.6 AADL package to SPARK Ada package mapping

On listing 4.1.6, there is sample AADL package with system. It contains all types of ports described in section 4.1.2 and one feature group with two ports as example of feature group mapping.

```
package Some_Pkg
public
with Base_Types;

feature group Some_Features
features
  Some_Out_Port: out data port Base_Types::Integer;
```

```
Some_In_Port: in data port Base_Types::Integer;
end Some_Features;

system Some_System
features
   Some_Feature_Group : feature group Some_Features;

In_Data_Port : in data port Base_Types::Integer;
Out_Data_Port : out data port Base_Types::Integer;
In_Event_Port : in event port;
Out_Event_Port : out event port;
In_Event_Data_Port : in event data port Base_Types::Integer;
Out_Event_Data_Port : out event data port Base_Types::Integer;
end Some_System;
end Some_Pkg;
```

Listing 4.5: Sample AADL package with system

For now, only single process SPARK Ada application is considered. Thus, ports are exposed only on system level. Communication between threads in process will be realized by protected objects and only SPARK annotations and data types will be needed as described in section 4.1.3. Based on ports mapping, presented in section 4.1.2, translation to SPARK Ada package is shown in listing 4.1.6.

```
package Some_Pkg
--# own Some_Features_Some_Out_Port : Integer;
--#
       Some_Features_Some_In_Port : Integer;
       In_Data_Port : Integer;
--#
--#
       Out_Data_Port : Integer;
--#
       In_Event_Data_Port : Integer;
       Out_Event_Data_Port : Integer;
--# initializes Some_Features_Some_Out_Port,
              Some_Features_Some_In_Port,
--#
--#
               In_Data_Port,
--#
               Out Data Port.
--#
               In_Event_Data_Port,
--#
               Out_Event_Data_Port;
   function Some_Features_Get_Some_Out_Port return Integer;
   --# global in Some_Features_Some_Out_Port;
   procedure Some_Features_Receive_Some_In_Port;
    --# global out Some_Features_Some_In_Port;
   procedure Receive_In_Data_Port;
    --# global out In_Data_Port;
   function Get_Out_Data_Port return Integer;
   --# global in Out_Data_Port;
   procedure Put_In_Event_Port;
   procedure Send_Out_Event_Port;
```

```
procedure Put_In_Event_Data_Port(In_Event_Data_Port_In : Integer);
   --# global out In_Event_Data_Port;
   --# derives In_Event_Data_Port from In_Event_Data_Port_In;
   procedure Send_Out_Event_Data_Port;
    --# global in Out_Event_Data_Port;
end Some_Pkg;
package body Some_Pkg
is
   Some_Features_Some_Out_Port : Integer := 0;
   Some_Features_Some_In_Port : Integer := 0;
   In_Data_Port : Integer := 0;
   Out_Data_Port : Integer := 0;
   In_Event_Data_Port : Integer := 0;
   Out_Event_Data_Port : Integer := 0;
   function Some_Features_Get_Some_Out_Port return Integer
   is
   begin
       return Some_Features_Some_Out_Port;
   end \ {\tt Some\_Features\_Get\_Some\_Out\_Port};
   procedure Some_Features_Receive_Some_In_Port
   is
   begin
       -- implementation
   end Some_Features_Receive_Some_In_Port;
   procedure Receive_In_Data_Port
   begin
        -- implementation
   end Receive_In_Data_Port;
   function Get_Out_Data_Port return Integer
   is
       return Out_Data_Port;
   end Get_Out_Data_Port;
   procedure Put_In_Event_Port
   begin
        -- implementation
   end Put_In_Event_Port;
   procedure Send_Out_Event_Port
   is
   begin
        -- implementation
   end Send_Out_Event_Port;
   procedure Put_In_Event_Data_Port(In_Event_Data_Port_In : Integer)
   begin
       In_Event_Data_Port := In_Event_Data_Port_In;
   end Put_In_Event_Data_Port;
   procedure Send_Out_Event_Data_Port
   is
   begin
        -- implementation
   end Send_Out_Event_Data_Port;
```

end Some_Pkg;

Listing 4.6: Translation of sample AADL package from listing 4.1.6

4.1.7 AADL property set to SPARK Ada package mapping

There is no equivalent construct for AADL property set in SPARK Ada. Thus property set is mapped to SPARK Ada package. In this thesis, only properties of type constant addlinteger are considered. There are issues with using non-constant types in SPARK Ada package (e.g. when using them in some type definition). Table 4.9 shows sample property set mapping to SPARK Ada package.

Table 4.9: AADL property set to SPARK Ada package mapping

AADL	SPARK Ada
<pre>property set Some_Properties is Some_Property1 : constant aadlinteger => 10; Some_Property2 : constant aadlinteger => 27 applies to (all); Some_Property3 : constant aadlinteger =></pre>	<pre>package Some_Properties is Some_Property1 : constant Integer := 10; Some_Property2 : constant Integer := 27; Some_Property3 : constant Integer := Some_Property1; end Some_Properties;</pre>

In AADL, all declarations must have an applies to clause. It is ignored in resulted SPARK Ada translation. However, it can be used in the future e.g. for automatic generation of with clauses.

4.1.8 BLESS mapping

In cooperation with Brian Larson, translations for BLESS assertions, invariant, pre- and postconditions were created. Table 4.10 presents their mapping to SPARK Ada. Generated (translated) code may not be complete. Then developer's effort to implement missing parts

will be required. E.g. when assertion is specified in AADL/BLESS model, but not defined, it has to be implemented.

Table 4.10: BLESS to SPARK contracts mapping

${ m AADL/BLESS}$	SPARK Ada
BLESS::Assertion=>"< <cond1()>>"</cond1()>	# assert COND1;
<pre>thread Some_Thread features Some_Port : out event port {BLESS:Assertion => "<<(Var1 < Var2 and COND2())</pre>	<pre>task body Some_Thread is begin loop # assert (Var1 < Var2 and COND2); end loop; end Some_Thread;</pre>
<pre>thread implementation Some_Thread.imp annex BLESS {** invariant <<(Some_Var < Other_Var)>> **}; end Some_Thread.imp;</pre>	<pre>task body Some_Thread is begin loop # assert (Some_Var < Other_Var); end loop; end Some_Thread;</pre>
<pre>thread implementation Some_Thread.imp annex BLESS {** assert <<state1 :="" :cond1()="" cond2()="" or="">> <<var :="</td"><td><pre>task body Some_Thread is begin loop # assert (COND1 or COND2) #</pre></td></var></state1></pre>	<pre>task body Some_Thread is begin loop # assert (COND1 or COND2) #</pre>
	Continued on next page

Table 4.10 – continued from previous page

${ m AADL/BLESS}$	SPARK Ada
<pre>subprogram Some_Subprogram features param : out parameter Base_Types::Integer; annex subBless {** pre <<(param > 0)>> post <<(param = 0)>> **}; end Some_Subprogram;</pre>	<pre>procedure Some_Subprogram(Param : in out Integer) ;# pre Param > 0;# post Param = 0;</pre>

4.2 Port-based communication

Communication between AADL components is realized by ports. AADL ports can be declared in subprograms, threads, processes, systems and other entities. In this section communication between threads in single-process SPARK Ada application (4.2.1) and concept of communication between two systems (4.2.2) are presented.

4.2.1 Threads communication

Example of communication between threads, in single process is depicted in the figure 4.2.1. There are two threads (some_thread and other_thread) in one process. AADL model and its translation to SPARK Ada is presented in the table 4.11. Connection between threads has to be specified in process implementation. Based on mappings from section 4.1, protected object is defined, but subprograms are skipped, because communication takes place only internally. The result of translation consists of two tasks and private global protected object, which enable communication between them. Additionally, both tasks has global annotation (one with out mode, other with in mode), which announce use of protected object in their bodies.




Figure 4.1: Example of port communication between threads

Threads can be also placed in different packages. The same example of two threads within one process, but in different packages is presented in table 4.12. In this case, subprograms present in mapping table, in section 4.2 are also present in resulted translation. Moreover, body of procedure Receive_Some_Port is implemented as a result of defined connection between threads in the process implementation, in AADL model.

```
Table 4.11: AADL threads communication to SPARK Ada tasks communication translation
AADL/BLESS SPARK Ada
SPARK Ada
  package Some_Pkg
                                                        with Base_Types;
  public
                                                        --# inherit Base_Types;
  with Base_Types;
                                                        package Some_Pkg
                                                        --# own task st : Some_Thread;
    process Some_Proc
                                                        --#
                                                                task ot : Other_Thread;
                                                                protected Some_Port : Base_Types.
    end Some_Proc;
                                                        --#
                                                            Integer_Store (Priority => 10);
    process implementation Some_Proc.imp
                                                        is
    subcomponents
      some_thread: thread Some_Thread.imp;
                                                        private
      other_thread: thread Other_Thread.imp;
                                                           task type Some_Thread
                                                           --# global out Some_Port;
      connection: port some_thread.Some_Port ->
                                                              pragma Priority (10);
       other_thread.Some_Port;
    end Some_Proc.imp;
                                                           end Some_Thread;
    thread Some_Thread
                                                           task type Other_Thread
      features
                                                           --# global in Some_Port;
        Some_Port : out data port Base_Types::
                                                              pragma Priority (10);
       Integer;
    end Some_Thread;
                                                           end Other_Thread;
                                                        end Some_Pkg;
    thread implementation Some_Thread.imp
    end Some_Thread.imp;
                                                        package body Some_Pkg
                                                        is
    thread Other_Thread
                                                           st : Some_Thread;
      features
                                                           ot : Other_Thread;
        Some_Port : in data port Base_Types::Integer
                                                           Some_Port : Base_Types.Integer_Store;
    end Other_Thread;
                                                           task body Some_Thread
    thread implementation Other_Thread.imp
                                                           begin
    end Other_Thread.imp;
                                                              loop
                                                                  - implementation
                                                              end loop;
  end Some_Pkg;
                                                           end Some_Thread;
                                                           task body Other_Thread
                                                           begin
                                                                  - implementation
                                                              end loop;
                                                           end Other_Thread;
                                                        end Some_Pkg;
```

Table 4.12: AADL threads communication to SPARK Ada tasks communication translation (multiple packages)

AADL/BLESS SPARK Ada $\mathbf{with}\ \mathtt{Base_Types};$ package Pkg1 public --# inherit Base_Types; with Base_Types, Pkg2; package Pkg1 -- # own task st : Some_Thread; process Some_Proc protected Some_Port : Base_Types.Integer_Store (Priority => end Some_Proc; 10): process implementation procedure Get_Some_Port(Some_Port_Out : out Integer); Some_Proc.imp --# global in Some_Port; --# derives Some_Port_Out from Some_Port; subcomponents some_thread: thread Some_Thread.imp; other_thread: thread Pkg2:: $task\ type\ Some_Thread$ Other_Thread.imp; --# global out Some_Port; connections pragma Priority (10); connection: port some_thread. Some_Port -> other_thread. end Some_Thread; Some_Port; end Pkg1; end Some_Proc.imp; package body Pkg1 thread Some_Thread features st : Some_Thread; Some_Port : out data port Some_Port : Base_Types.Integer_Store; Base_Types::Integer; end Some_Thread; procedure Get_Some_Port(Some_Port_Out : out Integer) isthread implementation Some_Thread.imp Some_Port_Out := Some_Port.Get; end Some_Thread.imp; end Get_Some_Port; task body Some_Thread begin loop -- implementation end loop; end Some_Thread; end Pkg1; Continued on next page

Table 4.12 – continued from previous page

AADL/BLESS	SPARK Ada
·	
package Pkg2	with Base_Types;
public	with Pkg1;
with Base_Types;	# inherit Base_Types,
	# Pkg1;
thread Other_Thread	package Pkg2
features	# own task ot : Other_Thread;
Some_Port : in data port	# protected Some_Port : Base_Types.Integer_Store (Priority =>
Base_Types::Integer;	10); is
end Other_Thread;	procedure Receive_Some_Port;
thread implementation	
	# global out Some_Port;# in Pkg1.Some_Port;
Other_Thread.imp end Other_Thread.imp;	# in Pkg1.Some_Port;
end Pkg2;	private
enu ragz,	task type Other_Thread
	# global in Some_Port;
	is
	pragma Priority (10);
	end Other_Thread;
	end Pkg2;
	package body Pkg2 is
	ot : Other_Thread;
	Some_Port : Base_Types.Integer_Store;
	procedure Receive_Some_Port is
	Temp: Integer; begin
	Pkg1.Get_Some_Port(Temp);
	Some_Port.Put(Temp);
	end Receive_Some_Port;
	task body Other_Thread
	is
	begin
	loop
	implementation
	end loop;
	end Other_Thread;
	end Pkg2;

In the given example, communication is one way: from Pkg1 package to Pkg2 package. Thus, Pkg1 package does not need to know that Pkg2 package exists. In other words: it does not need to "with" it. However, if two way communication is needed (between Pkg1 to Pkg2), then Pkg1 package has to "with" Pkg2 package. It is not a case in first example, where communication between threads take place in the same package. Modified model of second

example, with communication from Pkg2 to Pkg1, is depicted in the figure 4.2.1 and presented in listing 4.2.1.




Figure 4.2: Example of two way port communication between threads in different packages

```
package Pkg1TwoWay
public
with Base_Types, Pkg2TwoWay;
  process Some_Proc
 end Some_Proc;
 process implementation Some_Proc.imp
 subcomponents
   some_thread: thread Some_Thread.imp;
   other_thread: thread Pkg2TwoWay::Other_Thread.imp;
 connections
   connection: port some_thread.Some_Port -> other_thread.Some_Port;
   connection2: port some_thread.Other_Port -> other_thread.Other_Port;
 end Some_Proc.imp;
 thread Some_Thread
   features
     Some_Port : out data port Base_Types::Integer;
     Other_Port : in data port Base_Types::Integer;
  end Some_Thread;
  thread implementation Some_Thread.imp
 end Some_Thread.imp;
end Pkg1TwoWay;
package Pkg2TwoWay
public
with Base_Types;
 thread Other_Thread
   features
     Some_Port : in data port Base_Types::Integer;
     Other_Port : out data port Base_Types::Integer;
  end Other_Thread;
 thread implementation Other_Thread.imp
  end Other_Thread.imp;
end Pkg2TwoWay;
```

Listing 4.7: AADL model of two way port communication threads in different packages

This model, translated to SPARK Ada is presented in listing 4.2.1. It will not compile. GNAT compiler returns circular unit dependency error. Additionally verification with SPARK Examiner returns error: Semantic Error 135 - The package Pkg2TwoWay is undeclared or not visible, or there is a circularity in the list of inherited packages. Now, the problem is that two-way communication is allowed in AADL, but not in SPARK, nor even in Ada. This require further investigation, which is omitted in this thesis.

```
with Base_Types;
with Pkg2TwoWay;
--# inherit Base_Types,
__#
           Pkg2TwoWay;
package Pkg1TwoWay
-- # own task st : Some_Thread;
--#
       protected Some_Port : Base_Types.Integer_Store (Priority => 10);
--#
       protected Other_Port : Base_Types.Integer_Store (Priority => 10);
is
   procedure Get_Some_Port(Some_Port_Out : out Integer);
   --# global in Some_Port;
   --# derives Some_Port_Out from Some_Port;
   procedure Receive_Other_Port;
   --# global out Other_Port;
   --#
             in Pkg2TwoWay.Other_Port;
private
   task type Some_Thread
   --# global out Some_Port;
      pragma Priority (10);
   end Some_Thread;
end Pkg1TwoWay;
package body Pkg1TwoWay
   st : Some_Thread;
   Some_Port : Base_Types.Integer_Store;
   Other_Port : Base_Types.Integer_Store;
   procedure Get_Some_Port(Some_Port_Out : out Integer)
   is
   begin
      Some_Port_Out := Some_Port.Get;
   end Get_Some_Port;
   procedure Receive_Other_Port
      Temp : Integer;
   begin
      Pkg2TwoWay.Get_Other_Port(Temp);
      Other_Port.Put(Temp);
   end Receive_Other_Port;
   task body Some_Thread
   begin
      loop
```

```
-- implementation
        null;
     end loop;
  end Some_Thread;
end Pkg1TwoWay;
with Base_Types;
with Pkg1TwoWay;
--# inherit Base_Types,
--#
          Pkg1TwoWay;
package Pkg2TwoWay
--# own task ot : Other_Thread;
     protected Some_Port : Base_Types.Integer_Store (Priority => 10);
       protected Other_Port : Base_Types.Integer_Store (Priority => 10);
--#
is
  procedure Receive_Some_Port;
   --# global out Some_Port;
             in Pkg1TwoWay.Some_Port;
  procedure Get_Other_Port(Other_Port_Out : out Integer);
  --# global in Other_Port;
  --# derives Other_Port_Out from Other_Port;
private
  task type Other_Thread
   --# global in Some_Port;
     pragma Priority (10);
   end Other_Thread;
end Pkg2TwoWay;
package body Pkg2TwoWay
  ot : Other_Thread;
  Some_Port : Base_Types.Integer_Store;
  Other_Port : Base_Types.Integer_Store;
   procedure Receive_Some_Port
     Temp : Integer;
  begin
     Pkg1TwoWay.Get_Some_Port(Temp);
     Some_Port.Put(Temp);
   end Receive_Some_Port;
  procedure Get_Other_Port(Other_Port_Out : out Integer)
  begin
     Other_Port_Out := Other_Port.Get;
   end Get_Other_Port;
   task body Other_Thread
   begin
     loop
         -- implementation
        null;
     end loop;
  end Other_Thread;
end Pkg2TwoWay;
```

Listing 4.8: Two way port communication translated to SPARK Ada

4.2.2 Systems communication

This section is a concept, how communication between different systems can look like. AADL system consists of process(es) and process consists of threads. Ports would be exposed by package if they are specified in system entity. Communication between two systems cab be described by another system. Figure 4.2.2 presents communication between two systems: panel and pump. AADL model of this system comprises 3 packages: Main, Panel and Pump. They are presented in listing 4.2.2. Panel package has one thread Panel_Thread with two out ports: event port and event data port. Both ports are exposed by process panel_process and then by system panel. Pump package has similar structure, but two in ports. Both are also exposed by process (pump_process) and system (pump). Connection between these two packages are defined in Main package.




Figure 4.3: Example of port communication between systems

```
package Panel
public
with Base_Types;

thread Panel_Thread
features
   Start_Button_Pressed: out event port;
   Flow_Rate: out event data port Base_Types::Integer;
end Panel_Thread;

thread implementation Panel_Thread.imp
end Panel_Thread.imp;

process panel_process
```

```
features
     Start_Button_Pressed: out event port;
     Flow_Rate: out event data port Base_Types::Integer;
  end panel_process;
 process implementation panel_process.imp
   subcomponents
     panel_thread: thread Panel_Thread.imp;
   connections
     sbp: port panel_thread.Start_Button_Pressed->Start_Button_Pressed;
     fr: port panel_thread.Flow_Rate->Flow_Rate;
 end panel_process.imp;
 system panel
   features
     Start_Button_Pressed: out event port;
     Flow_Rate: out event data port Base_Types::Integer;
 end panel;
 system implementation panel.imp
   subcomponents
     panel_process: process panel_process.imp;
   connections
     sbp: port panel_process.Start_Button_Pressed->Start_Button_Pressed;
     fr: port panel_process.Flow_Rate->Flow_Rate;
 end panel.imp;
end Panel;
package Pump
public
with Base_Types;
  thread Rate_Controller
   features
     Start_Button_Pressed: in event port;
     Flow_Rate: in event data port Base_Types::Integer;
  end Rate_Controller;
  thread implementation Rate_Controller.imp
  end Rate_Controller.imp;
  process pump_process
   features
     Start_Button_Pressed : in event port;
     Flow_Rate: in event data port Base_Types::Integer;
 end pump_process;
 process implementation pump_process.imp
   subcomponents
     Rate_Controller: thread Rate_Controller.imp;
   connections
     sbp: port Start_Button_Pressed->Rate_Controller.Start_Button_Pressed;
     fr: port Flow_Rate->Rate_Controller.Flow_Rate;
 end pump_process.imp;
  system pump
   features
     Start_Button_Pressed : in event port;
     Flow_Rate: in event data port Base_Types::Integer;
  end pump;
  system implementation pump.imp
   subcomponents
     pump_process : process pump_process.imp;
```

```
connections
     sbp: port Start_Button_Pressed->pump_process.Start_Button_Pressed;
     fr: port Flow_Rate->pump_process.Flow_Rate;
 end pump.imp;
end Pump;
package Main
public
with Pump,
 Panel;
  system main
  end main:
  system implementation main.imp
   subcomponents
     panel: system Panel::panel.imp;
     pump: system Pump::pump.imp;
     sbp2sbp: port panel.Start_Button_Pressed->pump.Start_Button_Pressed;
     fr2fr: port panel.Flow_Rate->pump.Flow_Rate;
  end main.imp;
end Main;
```

Listing 4.9: AADL model of port communication between systems

Based on mappings from section 4.1, conforming SPARK Ada code is presented in listing 4.2.2. There are two packages: Panel and Pump. Main package is omitted. Both contain procedures representing ports interfaces, according to ports mapping from section 4.1.2. Additionally, both consists of empty thread declarations and bodies, which conforms to translations from section 4.1.3. However, in this case, both packages will work in different systems, thus different processes. To enable communication between different systems, deployment methodology and the middle-ware layer has to be created. It will allow not only for system to system communication, but also for communication with devices. It is omitted in this thesis.

```
with Pump;
with Base_Types;
--# inherit Pump,
--# Base_Types;
package Panel
--# own task pt : Panel_Thread;
--# protected Flow_Rate : Base_Types.Integer_Store (Priority => 10);
is
    procedure Send_Start_Button_Pressed;

procedure Send_Flow_Rate;
--# global in Flow_Rate;
--# out Pump.Flow_Rate;
```

```
private
   task type Panel_Thread
   --# global in out Flow_Rate;
       pragma Priority (10);
   end Panel_Thread;
end Panel;
package body Panel
is
   pt : Panel_Thread;
   Flow_Rate : Base_Types.Integer_Store;
   procedure Send_Start_Button_Pressed
   is
   begin
       Pump.Put_Start_Button_Pressed;
   end Send_Start_Button_Pressed;
   procedure Send_Flow_Rate
       Flow_Rate_Temp : Integer;
   begin
       Flow_Rate_Temp := Flow_Rate.Get;
       Pump.Put_Flow_Rate(Flow_Rate_Temp);
   end Send_Flow_Rate;
   task body Panel_Thread
   begin
     loop
        -- implementation
     end loop;
   end Panel_Thread;
end Panel;
with Base_Types;
--# inherit Base_Types;
package Pump
--# own task rc : Rate_Controller;
--# protected Flow_Rate : Base_Types.Integer_Store (Priority => 10);
   procedure Put_Start_Button_Pressed;
   procedure Put_Flow_Rate(Flow_Rate_In : Integer);
   --# global out Flow_Rate;
   --# derives Flow_Rate from Flow_Rate_In;
   task type Rate_Controller
   --# global in out Flow_Rate;
       pragma Priority (10);
   end Rate_Controller;
end Pump;
package body Pump
   rc : Rate_Controller;
   Flow_Rate : Base_Types.Integer_Store;
   procedure Put_Start_Button_Pressed
   is
   begin
```

```
-- TODO: implement event handler
end Put_Start_Button_Pressed;

procedure Put_Flow_Rate(Flow_Rate_In : Integer)
is
begin
    Flow_Rate.Put(Flow_Rate_In);
end Put_Flow_Rate;

task body Rate_Controller
is
begin
    loop
    -- implementation
    end loop;
end Rate_Controller;
end Pump;
```

Listing 4.10: Port communication translated to SPARK Ada

4.3 Automatic translator

The ultimate goal is to create translator, which performs translations described in 4.1 and 4.2 automatically. Automatic translator should enable translation of entire model and parts of the model. Initially, translator should support only subset of AADL entities: the system, process, thread, subprogram and port communication. The following functions should be supported:

- data types translation (as described in section 4.1.1)
- threads to tasks translation (as described in 4.1.3)
- single ports translation (based on section 4.1.2)
- subprogram to procedure/function translation (based on section 4.1.4)
- single package translation with system, which contains ports and feature groups (as described in section 4.1.6)
- property set mapping to SPARK Ada package (like in section 4.1.7)

Second step, would be to introduce BLESS support. Which means, add supported BLESS constructs described in section 4.1.8:

- assertions for threads
- pre- and postconditions for subprograms

Recommended way to create translator is to parse AADL models, create Abstract Syntax Tree (AST) and emit code using Visitor pattern. Parser and AST can be generated using ANTLR⁴ (Another Tool for Language Recognition) and its grammar development environment ANTLRWorks⁵. ANTLR 4 (with ANTLRWorks 2) enable automatic AST creation and handle left recursion, which makes parser development much easier and faster. Another tool, Xtext⁶ can be also used (instead of ANTLR) for parser and AST generator. For emitting code, StringTemplate⁷ (template engine for generating code) can be used.

Development should be performed incrementally. From adding translation for the simplest constructs, like data types or single ports, to port communication and BLESS. First step, would be AADL grammar development. It is recommended to initially, specify only part of required AADL subset and then extend it incrementally. In order to do that, AADL Syntax Card⁸ might be helpful. During translator development unit testing and Test Driven Development is recommended. Translation schemes can be used as input and expected output of particular test cases. It will help to ensure correctness of translator while working on new features support.

⁴http://www.antlr.org/

⁵http://tunnelvisionlabs.com/products/demo/antlrworks

⁶http://www.eclipse.org/Xtext/index.html

⁷http://www.stringtemplate.org/

⁸https://wiki.sei.cmu.edu/aadl/images/d/d2/AADL V2.1 Syntax Card.pdf

Chapter 5

PCA pump prototype implementation and code generation

This chapter describes running SPARK Ada programs on BeagleBoard-xM platform (3.3), implementation details of PCA pump prototype (5.2)), code generation from simplified AADL/BLESS models of PCA pump (5.3) and overview of not generated parts, which has to be implemented by developer (5.4). All programs presented in this section works the same on Intel processor (PC or MacBook) and on BeagleBoard-xM (ARM device).

5.1 Running SPARK Ada programs on BeagleBoard-xM

To run SPARK Ada program on BeagleBoard-xM, it has to be cross-compiled. As an IDE for SPARK Ada development, GNAT Programming Studio (GPS) is used (see section 2.5.2). To create "Hello, World!" application, new Ada project has been created (choosing Project/New... from the menu). Then main.adb file, with procedure Main printing "Hello, World!" in standard output, was added. The code is presented in listing 5.1. It is valid Ada 2005 and Ada 2012 code.

with Ada.Text_IO;

```
procedure Main
is
begin
    Ada.Text_IO.Put_Line("Hello, World!");
end Main;
```

Listing 5.1: "Hello World" in Ada

The main file has to be always specified in project file (.gpr) in order to compile and link application, which can be runnable. It can be done in Project/Edit Project Properties (figure 5.1), tab: Main files (figure 5.1) or directly in project file (.gpr).




Figure 5.1: Edit Project Properties

To enable cross-compilation, for current version of cross-compiler, environmental variable \\senv_prefix has to be set to directory, which contains /1ib and /usr directories. Latter should also contains /usr/lib and /usr/include subdirectories. After mentioned directories has been copied into /home/super/angstrom-arm directory, \\senv_prefix has been exported with following command: export env_prefix=/home/super/angstrom-arm. Entire project can be compiled and linked with following command: arm-linux-gnueabi-gnatmake -d -Phelloworld.gpr (where helloworld.gpr is GNAT Programming Studio project file). Additional flags can be specified in command line or directly in project file (manually or through GNAT Programming Studio Interface).




Figure 5.2: Project Main files

More complex example, which takes advantage of SPARK contracts is presented in section 5.1.1.

5.1.1 Odometer

Odometer is a simple SPARK Ada program, which implements basic functions of standard Odometer. Listing 5.1.1 shows Odometer in SPARK 2005. In addition to Odometer

```
package Odometer
--# own
--# Trip,
                  -- number of meters so far on this trip (can be reset to 0).
--# Total
                 -- total meters traveled of vehicle since the last factory-reset.
--#
    : Natural; -- has range 0 .. Integer'Last.
--# initializes Trip,
--#
                Total:
is
    \mathbf{procedure} \mathbf{Zero\_Trip}; -- sets \mathsf{Trip} to 0 and clears all saved \mathsf{Trip} marks.
    --# global out Trip;
    --# derives Trip from ;
    --# post Trip = 0;
    function Read_Trip return Natural; -- returns value of Trip.
    --# global in Trip;
    --# return Trip;
    function Read_Total return Natural; -- returns value of Total
    --# global in Total;
    --# return Total;
```

```
procedure Inc; -- increments each of Trip and Total by 1.
   --# global in out Trip, Total;
   --# derives Trip from Trip & Total from Total;
   -- # pre Trip < Integer'Last and Total < Integer'Last;
    --# post Trip = Trip~ + 1 and Total = Total~ + 1;
end Odometer;
package body Odometer is
   Trip : Natural := 0;
   Total : Natural := 0;
   procedure Zero_Trip is
   begin
       Trip := 0;
   end Zero_Trip;
   function Read_Trip return Natural is
   begin
       return Trip;
   end Read_Trip;
   function Read_Total return Natural is
       return Total;
   end Read_Total;
   procedure Inc is
   begin
       Trip := Trip + 1;
       Total := Total + 1;
   end Inc;
end Odometer;
```

Listing 5.2: SPARK 2005 code: Odometer

There are 4 subprograms (2 procedures and 2 functions), which are globally available (through other packages and program units):

- zero_Trip procedure reset Odometer to 0
- Read_Trip function returns current distance
- Read Total function returns total distance traveled
- Inc procedure increment total and current distance by 1

Given program contains code contracts. Tough it does not matter in compilation phase, it shows that SPARK verification tools can be used for given example.

Annotation global means that subprogram uses some global variable. Postfix in, out or in out means that particular variable is read, write or read and write respectively. Annotation

derives says that some variable value depends on other variables. E.g. in procedure Inc variable Trip is dependent on its current value (before procedure call). Annotations pre and post define pre- and postconditions of procedure. We can see, that in Zero_Trip procedure postcondition requires that variable Trip is equal to 0. In procedure Inc, postconditions requires that variables Trip and Total are incremented by 1 ('~' is the value of variable before procedure call). Annotation own expose private variables for use in public methods specification. Annotation initializes ensures that given variables are initializes.

In order to test Odometer package in runtime, the Main procedure has been created. It is presented in listing 5.1.1.

```
with Ada.Text_IO;
with Odometer;
procedure Main
begin
   Ada.Text_IO.Put_Line("Trip: " & Natural', Image(Odometer.Read_Trip));
   Ada.Text_IO.Put_Line("Total: " & Natural', Image(Odometer.Read_Total));
   Odometer.Inc:
   Ada.Text_IO.Put_Line("Trip: " & Natural', Image(Odometer.Read_Trip));
   Ada.Text_IO.Put_Line("Total: " & Natural'Image(Odometer.Read_Total));
   Odometer.Zero_Trip;
   Ada.Text_IO.Put_Line("Trip: " & Natural'Image(Odometer.Read_Trip));
   Ada.Text_IO.Put_Line("Total: " & Natural', Image(Odometer.Read_Total));
   Odometer.Inc;
   Ada.Text_IO.Put_Line("Trip: " & Natural'Image(Odometer.Read_Trip));
   Ada.Text_IO.Put_Line("Total: " & Natural'Image(Odometer.Read_Total));
end Main;
```

Listing 5.3: Main procedure for Daometer package

Odometer in SPARK 2005 works fine on BeagleBoard-xM. In order to test SPARK 2014 program, SPARK 2005 annotations has been converted into Ada 2012 contracts. Listing 5.4 presents Odometer in SPARK 2014.

```
package Odometer
with Abstract_State => (Trip_State, Total_State)
is
   function Trip_State return Integer
   with Convention => Ghost,
   Global => (Input => Trip_State);
```

```
function Total_State return Integer
    with Convention => Ghost,
    Global => (Input => Total_State);
   procedure Zero_Trip -- sets Trip to 0
    with Global => (Output => (Trip_State)),
    Depends => (Trip_State => null),
    Post => Trip_State = 0;
   function Read_Trip return Natural -- returns value of Trip.
    with Global => (Input => Trip_State),
    Post => Read_Trip'Result = Trip_State;
   function Read_Total return Natural -- returns value of Total
    with Global => (Input => Total_State),
    Post => Read_Total'Result = Total_State;
   procedure Inc -- increments each of Trip and Total by 1.
    with Global => (In_Out => (Trip_State, Total_State)),
    Depends => (Trip_State => Trip_State, Total_State => Total_State),
    Pre => Trip_State < Integer'Last and Total_State < Integer'Last,</pre>
    Post => Trip_State = Trip_State'0ld + 1 and Total_State = Total_State'0ld + 1;
end Odometer;
package body Odometer
with
 Refined_State => (Trip_State => (Trip),
                   Total_State => (Total))
  Trip : Natural;
  Total : Natural;
   function Trip_State return Integer
    with Refined_Global => (Input => Trip)
  begin
     return Trip;
   end Trip_State;
   function Total_State return Integer
    with Refined_Global => (Input => Total)
   is
   begin
     return Total;
   end Total_State;
   procedure Zero_Trip
    with Refined_Global => (Output => Trip),
    Refined_Depends => (Trip => null)
   is
   begin
     Trip := 0;
   end Zero_Trip;
   function Read_Trip return Natural
    with Refined_Global => (Input => Trip)
   begin
     return Trip;
   end Read_Trip;
   function Read_Total return Natural
    with Refined_Global => (Input => Total)
```

```
begin
    return Total;
end Read_Total;

procedure Inc
    with Refined_Global => (In_Out => (Trip, Total)),
    Refined_Depends => (Trip => Trip, Total => Total)
is
begin
    Trip := Trip + 1;
    Total := Total + 1;
end Inc;
end Odometer;
```

Listing 5.4: SPARK 2014 code: Odometer

Odometer example was created to check possible limitations and issues related to different platform (ARM-based). No limitations were found.

5.1.2 Multitasking applications

In Ada World, concurrency is referred as tasking and the task is the same construct as the thread in other programming languages. In section 5.1.1, single-tasking application was tested. This section presents simple Ada multitasking application and multitasking version of Odometer in SPARK 2005 from section 5.1.1. Both applications compiles correctly and works as expected on BeagleBoard-xM platform.

Ada multitasking application

Listing 5.1.2 presents a simple multitasking application printing numbers in different time intervals, in Ada 2005. It is also valid code for Ada 2012. There are 3 tasks:

- Main task
- S (type: seconds) simple counter printing numbers form 1 to 10 in every second
- T (type: Tenth_Seconds) simple counter printing numbers from 0.1 to 10 in every 0.1 second

```
with Ada.Text_IO;
use Ada.Text_IO;
with Ada.Float_Text_IO;
procedure Main is
   task type Seconds is
   end Seconds;
   task type Tenth_Seconds is
   end Tenth_Seconds;
   S : Seconds;
   T : Tenth_Seconds;
   task body Seconds is
   begin
       for I in 1..10 loop
            delay Standard.Duration(1);
           Put_Line(Integer', Image(I));
        end loop;
   end Seconds;
   task body Tenth_Seconds is
   begin
       for I in 1..100 loop
            Ada.Float_Text_IO.Put(Float(I)/Float(10), AFT=>2, EXP=>0);
           Put_Line("");
        end loop;
   end Tenth_Seconds;
begin
   Put_Line("Started");
end Main;
```

Listing 5.5: Simple multitask application in Ada

The program works as expected on BleagleBoard-xM. This is not valid SPARK program though. As mentioned in section 2.5.3, tasks can be declared only in packages. Not in

SPARK Ada multitasking application

As mentioned in section 2.5.3, in SPARK 2005 multitasking is possible with Ravenscar Profile. Default profile - sequential - does not enable tasking. In other words, SPARK tools cannot analyze and reason about programs if Ravenscar profile flag is not provided. In SPARK 2014 - for now tasking is not possible. It's part of SPARK 2014 road map to include support for tasking in the future. Thus, only SPARK 2005 application was tested.

Tested, multitasking application is extended version of Odometer presented in listing 5.1.1. It has additional variable speed, procedure set_speed and new task: Drive. Thus, in total it has two tasks:

- Main
- Drive

The Drive task increase Total and Trip variables by Speed (m/s) in every second. Extended Odometer is presented in listing 5.1.2.

```
--# inherit Ada.Real_Time;

package Odometer

--# own Trip: Distance;

--# Total: Distance;

--# Speed: Meters_Per_Second;

--# task d: Drive;

--# initializes Trip,

--# Total,

--# Speed;

is

type Distance is range Natural'First .. Natural'Last;

pragma Atomic (Distance);

type Meters_Per_Second is range Natural'First .. Natural'Last;

pragma Atomic (Meters_Per_Second);
```

```
procedure Zero_Trip; -- sets Trip to 0 and clears all saved Trip marks.
    --# global out Trip;
    --# derives Trip from ;
    --# post Trip = 0;
    function Read_Trip return Distance; -- returns value of Trip.
    --# global in Trip;
    --# return Trip;
    function Read_Total return Distance; -- returns value of Total
    --# global in Total;
    --# return Total;
    \mathbf{procedure} Inc; -- increments each of Trip and Total by 1.
    --# global in out Trip, Total;
    --# derives Trip from Trip & Total from Total;
    --# pre Trip < Distance'Last and Total < Distance'Last;
    --# post Trip = Trip~ + 1 and Total = Total~ + 1;
    procedure Set_Speed(New_Speed : Meters_Per_Second);
    --# global out Speed;
    --# derives Speed from New_Speed;
    --# post Speed = New_Speed;
private
    task type Drive
    --# global in
                     Speed;
    --#
             in out Trip;
             in out Total;
    --#
              in Ada.Real_Time.ClockTime;
    --#
    is
       pragma Priority(10);
    end Drive;
end Odometer;
with Ada.Real_Time;
use type Ada.Real_Time.Time;
package body Odometer is
   Trip : Distance := 0;
```

```
Total : Distance := 0;
Speed : Meters_Per_Second := 0;
d : Drive;
procedure Zero_Trip is
begin
   Trip := 0;
end Zero_Trip;
function Read_Trip return Distance is
begin
   return Trip;
end Read_Trip;
function Read_Total return Distance is
begin
   return Total;
end Read_Total;
procedure Inc is
begin
   Trip := Trip + 1;
   Total := Total + 1;
end Inc;
procedure Set_Speed(New_Speed : Meters_Per_Second)
begin
   Speed := New_Speed;
end Set_Speed;
task body Drive
is
   Release_Time : Ada.Real_Time.Time;
   Period : constant Integer := 1000; -- update in every second
begin
   loop
       Release_Time := Ada.Real_Time.Clock + Ada.Real_Time.Milliseconds(Period);
       delay until Release_Time;
```

```
-- each time round, increase Trip and Total

for I in Meters_Per_Second range 0 .. Speed loop

Inc;

end loop;

end loop;

end Drive;

end Odometer;
```

Listing 5.6: Multitasking Odometer

There are two ways to access protected variable in task body:

- It has to be protected object
- It has to be atomic type

Protected variables may not be used in proof contexts. Thus, if we try to use protected variable in proofs (pre- or postcondition), then we get semantic error: Trip is a protected own variable. To preserve pre- and postconditions from original Odometer, atomic types (Distance and Meters_Per_Second) has been used. The capability to specify pre- and postconditions has been preserved, but now application is not thread safe.

5.1.3 Controlling PCA pump actuator

PCA pump prototype created as part of this thesis interacts with external device (physical pump) through General-purpose input/output (GPIO) pin. To control the pump, Pulse width modulation (described in 3.3) is used. BeagleBoard-xM has 28 GPIO pins. Three of them are PWM enable (pin 4 - mapped as GPIO_144, pin 6 - GPIO_146 and pin 10 - GPIO_145). All of these pins allow to control external device by specifying frequency and duty cycle. However it requires PWM driver¹. PWM can be also simulated manually. To run the pump, pin has to be turned on and off with specified frequency. In order to do that, sleep function can be used.

¹http://beagleboard.org/project/PWM+driver+for+Beagle+Board/

GPIO ports interact with the BeagleBoard platform through memory maps. This means that turning particular pin on or off is achieved by writing values into a memory segment associated with the pin. Memory segment is further mapped into file system. Memory maps are synchronized via continuous refresh loops.

Pin, used for controlling PCA pump, is the pin 14 (mapped as GPIO_162). It is mapped into directory /sys/class/gpio/gpio162/. To turn pin on, file /sys/class/gpio/gpio162/value has to contain '1'. To turn it off - '0'. Pump is also connected to ground (GND). In that purpose pin 28 is used. Listing 5.1.3 shows simple bash script, which turns pin on and off every second. Before pin can be used, it has to be opened by writing pin mapping number (in this case: 162 for pin 14) into /sys/class/gpio/export file. When communication is over, connection should be closed with writing the same value to file /sys/class/gpio/unexport.

```
#!/bin/sh

cleanup() { # Release the GPIO port
    echo 162 > /sys/class/gpio/unexport
    exit
}

echo 162 > /sys/class/gpio/export # open port

trap cleanup SIGINT # call cleanup on Ctrl-C

while [ "1" = "1" ]; do
    echo "1" > /sys/class/gpio/gpio162/direction
    sleep 1
    echo "0" > /sys/class/gpio/gpio162/direction
    sleep 1
    done
```

Listing 5.7: Turning pin on and off

Initial tests of interaction with pump actuator has been made in bash and Java, because it does not require cross-compilation. Bash script runs natively on Angstrom Linux. Java application - on JVM distribution for Angstrom.

BeagleBoard-xM with Linux Angstrom allows to install software packages using package manager opkg². Packages feeds can be found on http://feeds.angstrom-distribution.org/feeds and set in .conf files in /etc/opkg directory. In this thesis ... version of Angstrom has been used and thus following feeds:

ullet

ullet

ullet

•

ullet

•

http://feeds.angstrom-distribution.org/feeds/core/ipk/eglibc/armv7a-vfp-neon/ Once, feeds are set, it is recommended to update list of available packages with command: opkg update. To update all installed packages, following command has to be used: opkg upgrade. To install Java runtime-environment (JVM), the following command can be used: opkg install openjdk-6-java. Java Development Kit, which contains Java compiler and allows to compiler Java programs on BeagleBoard, can be installed with: opkg install openjdk-6-jdk.

The same program, but working for 20 seconds and terminating, written in Java is presented in listing 5.1.3. Setting 'high' (1) for 1 second and 'low' (0) also for 1 second gives 50% duty cycle.

```
import java.io.*;

public class PcaMain {
  public static void main(String[] args) throws IOException, InterruptedException {
    final String GPIO = "162";
```

²http://wiki.openwrt.org/doc/techref/opkg

```
final String BASE_DIR = "/sys/class/gpio";
   WriteToFile(BASE_DIR+"/export", GPIO);
   WriteToFile(BASE_DIR+"/gpio"+GPIO+"/direction", "out");
   for(int i=0; i<10; ++i) {</pre>
            WriteToFile(BASE_DIR+"/gpio"+GPIO+"/value", "1");
            Thread.sleep(1000);
     WriteToFile(BASE_DIR+"/gpio"+GPIO+"/value", "0");
            Thread.sleep(1000);
   WriteToFile(BASE_DIR+"/unexport", GPIO);
 }
 public static void WriteToFile(String filename, String content) throws IOException {
   File file = new File(filename);
   if (!file.exists()) {
     file.createNewFile();
   PrintWriter writer = new PrintWriter(filename, "UTF-8");
   writer.println(content);
   writer.close();
 }
}
```

Listing 5.8: Turning pin on and off

The same program written in Ada is presented in listing 5.1.3.

```
with Ada.Real_Time;
use type Ada.Real_Time.Time;
package Pca_Pump is
    procedure Start_Pump;
    procedure Stop_Pump;
    procedure Run_Pump(N: in Integer);
    procedure Write_Signal(Signal: in Integer);
end Pca_Pump;

with Ada.Strings.Unbounded;
use type Ada.Strings.Unbounded;
with Ada.Text_IO.Unbounded_IO;
use type Ada.Text_IO;
```

```
package body Pca_Pump
is
   procedure Start_Pump is
           : Ada.Text_IO.File_Type;
      Data : Unbounded_String := To_Unbounded_String("pumping");
      File_Export : Ada.Text_IO.File_Type;
      File_Direction : Ada.Text_IO.File_Type;
      Create(File_Export, Ada.Text_IO.Out_File, "/sys/class/gpio/export");
      Put_Line(File_Export, "162");
      Close(File_Export);
      Create(File_Direction, Ada.Text_IO.Out_File, "/sys/class/gpio/gpio162/direction");
      Put_Line(File_Direction, "out");
      Close(File_Direction);
      Create(F, Ada.Text_IO.Out_File, "/home/root/pump_status.txt");
      Unbounded_IO.Put_Line(F, Data);
      Put_Line("Pumping...");
      Close(F);
   end Start_Pump;
   procedure Stop_Pump is
           : Ada.Text_IO.File_Type;
      Data : Unbounded_String := To_Unbounded_String("IDLE");
      File_Unexport : Ada.Text_IO.File_Type;
   begin
      Create(File_Unexport, Ada.Text_IO.Out_File, "/sys/class/gpio/unexport");
      Put_Line(File_Unexport, "162");
      Close(File_Unexport);
      Create(F, Ada.Text_IO.Out_File, "/home/root/pump_status.txt");
      Unbounded_IO.Put_Line(F, Data);
      Put_Line("Stopped");
      Close(F);
   end Stop_Pump;
   procedure Run_Pump(N: in Integer) is
```

```
Interval: constant Ada.Real_Time.Time_Span := Ada.Real_Time.Milliseconds(100);
      Next_Time: Ada.Real_Time.Time;
   begin
      Next_Time := Ada.Real_Time.Clock;
      Start_Pump;
      for I in Integer range 1 .. N*1000 loop
   Next_Time := Next_Time + Interval;
         Write_Signal(1);
         delay until Next_Time;
         Next_Time := Next_Time + Interval;
         Write_Signal(0);
         delay until Next_Time;
      end loop;
      Stop_Pump;
   end Run_Pump;
   {\bf procedure} \ {\tt Write\_Signal} \ ({\tt Signal} \ : \ {\bf in} \ {\tt Integer}) \ {\bf is}
      Filename : String := "/sys/class/gpio/gpio162/value";
      File : Ada.Text_IO.File_Type;
      Data : Unbounded_String;
   begin
      Ada.Text_IO.Open (File => File,
                         Mode => Ada.Text_IO.Out_File,
                         Name => Filename);
      if Signal = 1 then
         Data := To_Unbounded_String("1");
      else
         Data := To_Unbounded_String("0");
      end if;
      Unbounded_IO.Put_Line(File, Data);
      Ada.Text_IO.Close(File);
   end Write_Signal;
end Pca_Pump;
```

Listing 5.9: Turning pin on and off

5.2 Implementation based on Requirements Document and AADL models

The first step, was to check if implementation of PCA Pump specified in Requirements Document is feasible. Especially whether it will work on BeagleBoard-xM device. To do that, simple version of PCA Pump based on Requirements Document has been created. Only two AADL threads are implemented: Rate_Controler and Max_Drug_Per_Hour_Watcher in stripped version. Thus, pump has three tasks in total:

- main task interface for controlling and monitoring the pump
- Rate_Controller control the speed of infusion rate
- Max_Drug_Per_Hour_Watcher control over infusion

Open PCA pump, according to requirements document [Lar14], has 5 operational modes:

- Stopped: F = 0ml/hr
- Keep Vein Open (KVO): F = 0.1ml/hr
- Basal infusion: $F = F_{Basal}$
- Patient bolus: $F = F_{Basal} + F_{Bolus}$
- Clinician bolus: $F = F_{Basal} + F_{Square_{Bolus}}$ (square bolus is calculated value: VTBI divided by the duration chosen by the clinician)

Requirements document does not specify implementation details. One of implementation decisions, which had to be made was to decide how basal infusion will work. One solution was to run actuator continuously on speed calculated based on current flow rate. Another solution was to dose drug in 0.1 ml increments. This is how CADD-Prizm Ambulatory

Infusion Pump [Med10] works and this implementation was chosen. It allows for easier bolus monitoring and calculations. Pump engine controller is separated module. It is written in Ada, so it will not be verified with SPARK tools. Using increments, instead of continues speed allows to issue request of 0.1 ml dose to engine module, and it is its responsibility to deliver requested amount of dose. Performing calculations based on speed changes would be much more complicated. For monitoring, amount of drug dosed in last hour (to guard against over infusion), array with size = (60 * 60) has been created. Its elements represents all seconds of last hour. Last element is incremented once request to the engine is issued. This is done in Rate_Controller task. Max_Drug_Per_Hour_Watcher checks dosed amount by summing all elements. It also shifts array in every second, so doses older than 1 hour are not take into account anymore.

To avoid using floating point types, internal calculations are in micro liters: 1 micro liter $(\mu l) = 0.001 \text{ ml}$, thus 1 ml = $1000 \mu l$.

In real-world applications, the embedded critical components are written in SPARK while the non-critical components are written in Ada. Components written in Ada should be hidden for SPARK Examiner with --# hide annotation or being separated entities on which SPARK tools are not run. PCA motor is separated entity.

Code listing of implemented PCA pump along with mapped types is attached in appendix ${\bf B}$

//summary The biggest challenge during PCA Pump development was the SPARK limitations. There are many common libraries, which cannot be verified by SPARK tools. Thus it required to isolate some functionalities or implement them in different way. An example might be reading and writing numbers to standard input.

5.3 Code generation from AADL/BLESS models

PCA Pump prototype was mocked using translations schemes from chapter 4.

The original models were simplified and truncated for the purpose of this thesis. Finally only PCA_Operation module with 3 threads (Max_Drug_Per_Hour_Watcher, Rate_Controller, Patient_Bolus_Checker), types definitions (Base_Types, PCA_Types, ICE_Types, Bless_Types) and property set PCA_Properties were used as the source for code translation.

[code listings of aadl model]

Skeleton code 'generated' from simplified AADL models. Then implemented.

Show generated code.

5.4 Implementation for generated code

5.5 Communication with MDCF

BB has Ethernet, communication can go through it.

GNAT.Sockets

Chapter 6

Verification

The strategy for Software Verification using SPARK tools is as follows. First, Examiner is run. It generates and discharge some Verification Conditions (VCs). Next, SPARKSimp. It runs Simplifier to simplify and discharge some (or all) VCs, which were not discharged by Examiner. Along with Simplifier, ZombieScope runs to find dead paths. SPARKSimp can also run Victor (and it is in this case) to discharge VCs not discharged by Examiner nor Simplifier. To get summary of results, POGS report is generated. In case, when not all Verification Conditions are discharged, analysis continues with Bakar Kiasan. After fixes made with Kiasan help, Examiner and SPARKSimp tools are run again to confirm correctness.

An overview of verification contracts and annotations can be found in chapter 12 of Barnes' book [Bar13].

6.1 Verification of implemented prototype

During PCA Pump prototype implementation, syntax was regularly check with SPARK Examiner.

First run

```
---- BEGIN PROOF SUMMARY ----

VCs discharged: 556

VCs false: 2

VCs undischarged: 37

Warnings: No

Errors: YES
---- END PROOF SUMMARY ----
```

Listing 6.1: POGS report for PCA Pump prototype

Two false VCs applies to status_store protected type's subprograms: Put and Get. Error?

The same implementation like for other enumeration types.

POGS report is not included here, because it has almost 3000 lines.

There is 37 undischarged VCs. As mentioned in chapter 2.6.9, Bakar Kiasan does not support Ravenscar profile. Thus, to be able to analyze monitoring dosed amount of drug, separate module was created. Verification process of this module is described in section 6.2.

6.2 Monitoring dosed amount

Verification of module responsible for tracking dosed amount of drug. Isolated to verify, because of Ravenscar limitations. Sequential.

Code:

```
package Pca_Pump
--# own Dosed;
--# Dose_Volume;
--# initializes Dosed,
--# Dose_Volume;
is
    subtype Integer_Array_Index is Integer range 1 .. 60*60;
    type Integer_Array is array (Integer_Array_Index) of Integer;

procedure Increase_Dosed;
```

```
--# global in out Dosed;
--# in Dose_Volume;
--# derives Dosed from Dosed, Dose_Volume;

function Read_Dosed return Integer;
--# global in Dosed;

procedure Move_Dosed;
--# global in out Dosed;
--# derives Dosed from Dosed;
end Pca_Pump;
```

Listing 6.2: Dose monitor module specification

```
package body Pca_Pump
is
   Dosed : Integer_Array := Integer_Array'(others => 0);
   Dose_Volume : Integer := 1;
   procedure Increase_Dosed
   is
   begin
       Dosed(Integer_Array_Index'Last) := Dosed(Integer_Array_Index'Last) + Dose_Volume;
   end Increase_Dosed;
   function Read_Dosed return Integer
       Result : Integer := 0;
   begin
       for I in Integer_Array_Index loop
            --# assert I > 1 -> Result >= Dosed(I-1);
           Result := Result + Dosed(I);
       end loop;
       return Result;
   end Read_Dosed;
   procedure Move_Dosed
   \mathbf{begin}
```

Listing 6.3: Dose monitor module body

Verification with Examiner, Simplifier, ZombieScope, Victor, POGS and then Bakar Kiasan. SPARKSimp run Simplifier and Victor with command sparksimp -victor.

Examiner: No errors or warnings

[REMOVE] SPARKSimp:

```
gnatspark sparksimp -P/Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/
    pca_verification.gpr
sparksimp -victor
SPARKSimp GPL 2012
Copyright (C) 2012 Altran Praxis Limited, Bath, U.K.
Simplifier binary located at: /Users/jj/Sireum/apps/spark/2012/bin/spadesimp
ZombieScope binary located at: /Users/jj/Sireum/apps/spark/2012/bin/zombiescope
Victor binary located at: /Users/jj/Sireum/apps/spark/2012/bin/victor
Files to be simplified are:
/Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/increase_dosed.dpc,
    1474 bytes
/Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/increase_dosed.vcg,
/Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/move_dosed.dpc, 6072
/Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/move_dosed.vcg, 9612
/Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/read_dosed.dpc, 3089
/Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/read_dosed.vcg, 5189
     bytes
```

```
6 files require processing
Job-ID Status
                 Filename
    1 Started - ZOMBIESCOPE - /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/
    Pca_Verification/pca_pump/increase_dosed.dpc
    1 Finished 0: 0: 0.10
    2 Started - SIMPLIFY - /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/
    pca_pump/increase_dosed.vcg
    2 Finished 0: 0: 0.12
    3 Started - ZOMBIESCOPE - /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/
    Pca_Verification/pca_pump/move_dosed.dpc
    3 Finished 0: 0: 0.17
    4 Started - SIMPLIFY - /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/
    pca_pump/move_dosed.vcg
    4 Finished 0: 0: 0.18
    5 Started - ZOMBIESCOPE - /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/
    Pca_Verification/pca_pump/read_dosed.dpc
                 0: 0: 0.18
    5 Finished
    6 Started - SIMPLIFY - /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/
    pca_pump/read_dosed.vcg
    6 Finished 0: 0: 0.17
    7 Started - VICTOR - /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/
    pca_pump/increase_dosed.vcg
    7 Finished 0: 0: 0.08
    8 Started - VICTOR - /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/
    pca_pump/move_dosed.vcg
    8 Finished 0: 0: 0.02
    9 Started - VICTOR - /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/
    pca_pump/read_dosed.vcg
    9 Finished 0: 0: 0.36
Total elapsed time: 0: 0: 1.39
[2014-07-01 14:45:00] process terminated successfully (elapsed time: 01.53s)
```

Listing 6.4: SPARKSimp output

[truncate?]POGS Report:

```
Semantic Analysis Summary
```

```
POGS GPL 2012
            Copyright (C) 2012 Altran Praxis Limited, Bath, U.K.
Summary of:
Verification Condition files (.vcg)
Simplified Verification Condition files (.siv)
Victor result files (.vct)
Riposte result files (.rsm)
Proof Logs (.plg)
Dead Path Conjecture files (.dpc)
Summary Dead Path files (.sdp)
"status" column keys:
   1st character:
       '-' - No VC
        'S' - No SIV
        'U' - Undischarged
        'E' - Proved by Examiner
        'I' - Proved by Simplifier by Inference
        'X' - Proved by Simplifier by Contradiction
        'P' - Proved by Simplifier using User Defined Proof Rules
        'V' - Proved by Victor
        '0' - Proved by Riposte
        'C' - Proved by Checker
        'R' - Proved by Review
        'F' - VC is False
    2nd character:
        '-' - No DPC
        'S' - No SDP
        'U' - Unchecked
        'D' - Dead path
        'L' - Live path
in the directory:
/ Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca\_Verification
Summary produced: 01-JUL-2014 14:43:18.04
```

```
\label{lem:file_file_file} File_{\tt Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca-pump/increase\_dosed.}
   vcg
procedure Pca_Pump.Increase_Dosed
VCs generated 01-JUL-2014 14:42:26
VCs simplified 01-JUL-2014 14:43:04
File \ / Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca\_Verification/pca\_pump/increase\_dosed.
DPCs generated 01-JUL-2014 14:42:26
DPC ZombieScoped 01-JUL-2014 14:43:0
VCs for procedure_increase_dosed :
______
| # | From | To
                            | Proved By
                                             | Dead Path | Status |
I------
| 1 | start | rtc check @ 9 | Undischarged
                                             | Unchecked | UU |
| 2 | start | assert @ finish | Examiner
                                             File /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/move_dosed.vcg
procedure Pca_Pump.Move_Dosed
VCs generated 01-JUL-2014 14:42:26
VCs simplified 01-JUL-2014 14:43:04
File \ / Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca\_Verification/pca\_pump/move\_dosed.dpc
DPCs generated 01-JUL-2014 14:42:26
DPC ZombieScoped 01-JUL-2014 14:43:0
VCs for procedure_move_dosed :
 _____
| # | From | To
                           | Proved By
                                             | Dead Path | Status |
```

2				@ 26		ference	Unch	ecked	l I	J
	start	rt	c check	0.00						
3				@ 26	In	ference	Unch	ecked	l I	J
	start	1	assert	@ 27	In	ference	Live		l II	
4	27	1	assert	@ 27	In	ference	Live		l II	
5	27	rt	c check	@ 28	In	ference	Unch	ecked	l I	J
6	start	rt	c check	@ 30	In	ference	Unch	ecked	l I	J
7	27	rt	c check	@ 30	In	ference	Unch	ecked	l I	J
8	start	1	assert	@ finish	Ex	aminer	Dead		l El)
9	27	1	assert	@ finish	Ex	aminer	Live		l El	
			Read_Do							
s ger s sin le /\	nerated nplifie	01-J d 01-	UL-2014 JUL-201 rnal/VM	14:42:26 4 14:43:08 S/shared/a 4 14:42:26	aadl-m	uedical/pca-pu	ump-beagleb	oard/Pe	ca_Ve:	rifi
Cs ger Cs sin ile /\ PCs ge	mplifie Volumes enerate	01-J d 01- /Exte	UL-2014 JUL-201 rnal/VM JUL-201 1-JUL-2	4 14:43:08 S/shared/a 4 14:42:26 014 14:43 ed :	aadl-m 3 3:0			oard/P	ca_Ve:	rifi
CS ger le /VCS ger le /\text{VCS ger le /\	aplifie Volumes enerate abieSco funct From	01-J /Exte d 01-	UL-2014 JUL-201 rnal/VM JUL-201 1-JUL-2 ead_dose	4 14:43:08 S/shared/a 4 14:42:26 014 14:43 ed :	aadl-m 3 3:0 Pr	oved By	Dead	Path	 Sta	us
Lie /\text{V} Zom	mplifie folumes enerate thicker funct From	01-J d 01- /Exte d 01- pped 0	UL-2014 JUL-201 rnal/VM JUL-201 1-JUL-2 ead_dose	4 14:43:08 S/shared/a 4 14:42:26 014 14:43 ed :	aadl-m 3:0 Pr		Dead	Path	 Sta	us.
CS george C Zon #	replifie Volumes Enerate AbieSco funct From start	01-J d 01- /Exte d 01- pped 0	UL-2014 JUL-201 rnal/VM JUL-201 1-JUL-2 ead_dose	4 14:43:08 S/shared/a 4 14:42:26 014 14:43 ed :	aadl-m 3 3:0 Pr In	oved By	Dead	Path	 Sta 	us.
Cs ger Cs sin ile /V PCs ger Cs for #	rolumes enerate dubieScore funct From start	01-J d 01- /Exte d 01- To	UL-2014 JUL-201 rnal/VM JUL-201 1-JUL-2 ead_dose assert assert	4 14:43:08 S/shared/a 4 14:42:26 014 14:43 ed : 0 17 0 17	aadl-m 3 3:0 Pr In Un	oved By	Dead Live Live	Path	Sta II	us

The following subprograms have undischarged VCs (excluding those prove	d false):
<pre>1 /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/P .vcg</pre>	ca_Verification/pca_pump/increase_dosed
2 /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/P	ca_Verification/pca_pump/read_dosed.vcg
Proof strategies used by subprograms	
Total subprograms with at least one VC proved by examiner:	2
Total subprograms with at least one VC proved by simplifier:	2
Total subprograms with at least one VC proved by contradiction:	0
Total subprograms with at least one VC proved with user proof rule:	0
Total subprograms with at least one VC proved by Victor:	0
Total subprograms with at least one VC proved by Riposte:	0
Total subprograms with at least one VC proved using checker:	0
Total subprograms with at least one VC discharged by review:	0
Maximum extent of strategies used for fully proved subprograms:	
Total subprograms with proof completed by examiner:	0
Total subprograms with proof completed by simplifier:	1
Total subprograms with proof completed with user defined rules:	0
Total subprograms with proof completed by Victor:	0
Total subprograms with proof completed by Riposte:	0
Total subprograms with proof completed by checker:	0
Total subprograms with VCs discharged by review:	0
Overall subprogram summary:	
Total subprograms fully proved:	1
Total subprograms with at least one undischarged VC:	2 <<<
Total subprograms with at least one false VC:	0
Total subprograms for which VCs have been generated:	3
ZombieScope Summary:	
Total subprograms for which DPCs have been generated:	3

```
Total number subprograms with dead paths found:
                                                       1
Total number of dead paths found:
VC summary:
Note: (User) denotes where the Simplifier has proved VCs using one or
    more user-defined proof rules.
Total VCs by type:
              Total Examiner Simplifier Undisc.
Assert/Post
                          3
              0
Precondition
                0
Check stmnt.
             7
                         0
Runtime check
Refinem. VCs
Inherit. VCs
_____
Totals:
                15
                         3
%Totals:
                         20%
                                 60%
                                         20%
======= End of Semantic Analysis Summary ==============
```

Listing 6.5: POGS report

```
pca-pump-verification-step1.png
problem: Integer'First = Integer'Last = 1:O
solution: added standard.ads:
e Standard is

pe Integer is range -2**31 .. 2**31-1;
andard;

pca-pump-verification-step2.png
Introduce type Drug Volume Change Integer_Array to Doses_Array because it is not array of
```

integers anymore.

Result: no lower overflow in Increase_Dosed. Only upper overflow left.

pca-pump-verification-step3.png

Add contract to Increase_Dosed --# pre Read_Dosed(Dosed) <= Drug_Volume',Last - Dose_Volume; Examiner Error: Semantic Error 1 - The identifier Read_Dosed is either undeclared or not visible at this point

Moved Read_Dosed to be before Increase_Dosed. Examiner Error: pca_pump.ads:19:51: Semantic Error 35 - Binary operator is not declared for types Drug_Volume and Dose_Volume__type.

Declared Dose_Volume type in --# own: --# Dose_Volume : Drug_Volume;

Rerun Examiner and SPARKSimp: [truncate?]

```
Semantic Analysis Summary
                                POGS GPL 2012
            Copyright (C) 2012 Altran Praxis Limited, Bath, U.K.
Summary of:
Verification Condition files (.vcg)
Simplified Verification Condition files (.siv)
Victor result files (.vct)
Riposte result files (.rsm)
Proof Logs (.plg)
Dead Path Conjecture files (.dpc)
Summary Dead Path files (.sdp)
"status" column keys:
   1st character:
        '-' - No VC
        'S' - No SIV
        'U' - Undischarged
        'E' - Proved by Examiner
        'I' - Proved by Simplifier by Inference
        'X' - Proved by Simplifier by Contradiction
```

```
'P' - Proved by Simplifier using User Defined Proof Rules
      'V' - Proved by Victor
      '0' - Proved by Riposte
      'C' - Proved by Checker
      'R' - Proved by Review
      'F' - VC is False
   2nd character:
      '-' - No DPC
      'S' - No SDP
      'U' - Unchecked
      'D' - Dead path
      'L' - Live path
in the directory:
/Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca\_Verification
Summary produced: 02-JUL-2014 13:09:29.38
File \ / Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca\_Verification/pca\_pump/increase\_dosed.
procedure Pca_Pump.Increase_Dosed
VCs generated 02-JUL-2014 13:08:10
VCs simplified 02-JUL-2014 13:08:20
File \ / Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca\_Verification/pca\_pump/increase\_dosed.
DPCs generated 02-JUL-2014 13:08:10
DPC ZombieScoped 02-JUL-2014 13:08:2
VCs for procedure_increase_dosed :
_____
| # | From | To
                            | Proved By
                                              | Dead Path | Status |
I------
| 1 | start | rtc check @ 9 | Undischarged
                                              | Unchecked | UU |
| 2 | start | assert @ finish | Examiner
```

 $File \ / Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/move_dosed.vcg$ procedure Pca_Pump.Move_Dosed VCs generated 02-JUL-2014 13:08:10 VCs simplified 02-JUL-2014 13:08:20 File /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/move_dosed.dpc DPCs generated 02-JUL-2014 13:08:10 DPC ZombieScoped 02-JUL-2014 13:08:2 VCs for procedure_move_dosed : | # | From | To | Proved By | Dead Path | Status | l-----| Inference | Unchecked | IU | | 2 | start | rtc check @ 26 | Inference | Unchecked | | Live | 3 | start | assert @ 27 | Inference - 1 | Inference | 4 | 27 | assert @ 27 | Live | IL | rtc check @ 28 | Inference | Unchecked | | 6 | start | rtc check @ 30 | Inference | Unchecked | | 7 | 27 | rtc check @ 30 | Inference | Unchecked | | 8 | start | assert @ finish | Examiner Dead ED 9 | 27 | assert @ finish | Examiner | Live EL File /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/read_dosed.vcg function Pca_Pump.Read_Dosed VCs generated 02-JUL-2014 13:08:10 VCs simplified 02-JUL-2014 13:08:21 File /Volumes/External/VMS/shared/aadl-medical/pca-pump-beagleboard/Pca_Verification/pca_pump/read_dosed.dpc

DPCs generated 02-JUL-2014 13:08:10

	Zom	bieSco	ped 0	2-JUL-2	014 13:08	:2						
VCs	for			ead_dos								
#	ı	From	To	,		I	Proved By	I	Dead Path	.	Status	s
1		start					Inference				IL	 I
1 2	I	17	1	assert	@ 17	1	Inference	- 1	Live	1	IL	1
3	- 1	17	rt	c check	@ 18	1	Undischarged	1	Unchecked	1	UU	١
4	I						Inference					I
====		=====	====	======	=======	===		====		===		-==
Summ	nary	:										
The	fol	lowing	subp	rograms	have undi	sch	arged VCs (exclu	ding	those pro	vec	l false	e):
1	. /	Volume	c/Fvt									
			ъ/ цло	ernal/V	MS/shared/	aad	ll-medical/pca-pu	mp-be	eagleboard	/Pc	a_Veri	fi
	. v	cg	ъ, пк	ernal/V	MS/shared/	aad	ll-medical/pca-pu	mp-be	eagleboard	/Pc	ca_Veri	ifi
1		_					ll-medical/pca-pu					
	. /	Volume	s/Ext	ernal/V		aad						
Proc	of s	Volume	s/Ext ies u	ernal/V	MS/shared/ subprogram	aad s	ll-medical/pca-pu	- mp-be	eagleboard			
Proc	of s	Volume trateg	s/Ext	ernal/V	MS/shared/subprogram	aad s 	ll-medical/pca-pu	mp-be	eagleboard	/Pc	ca_Veri	
Procedure Total	of s	Volume trateg ubprog	s/Ext	ernal/Volumesed by with at	MS/shared/ subprogram t least one	aad s e V	ll-medical/pca-pu C proved by exami	mp-be	eagleboard	/Pc	ca_Veri	
Procedure Total	of salsals	Volume trateg ubprog	s/Ext ies u rams rams rams	sed by with at with at	MS/shared/subprogram t least one t least one	aad s e VO	C proved by exami	mp-be	eagleboard	/Pc	2 2	
Procedure Total Total Total	of s large state of s large s large state of	Volume trateg tubprog	ies u rams rams rams	ernal/V	MS/shared/ subprogram t least one t least one t least one	aaddss e VO e VO	C proved by control of the control o	mp-be	eagleboard	/Pc	2 2 0	
Procedure Total Total Total Total Total	of s il s il s il s	Volume trateg ubprog ubprog	s/Ext	sed by with at with at with at	MS/shared/subprogram t least one	aad s e V e V e V	C proved by exami	mp-be	eagleboard	/Pc	2 2 0	
Procedure Total To	of sold sold sold sold sold sold sold sold	trateg ubprog ubprog ubprog	s/Ext	ernal/V sed by with at with at with at with at with at	MS/shared/ subprogram t least one	aadd s s v v v v v v v v v v v v v v v v	C proved by control of proved by Victor of proved by Ripos	iner: lifie radic er pr	r: tion:	/Pc	2 2 0 0	
Proceedings of the Process of the Pr	of sols sals sals sals sals sals sals	Volume trateg ubprog ubprog ubprog ubprog	ies u rams rams rams rams rams rams rams	with at with at with at with at with at	subprogram t least one	aaddsss	C proved by control of the control o	mmp-be	r: tion: roof rule:	/Pc	2 2 0 0 0 0	
Procedure Proced	of sols sols sols sols sols sols sols so	Trateg ubprog ubprog ubprog ubprog ubprog ubprog	cies u crams crams crams crams crams crams crams crams crams	sed by with at	subprogram t least one	aadd ss s s s s s s s s s s s s s s s s	C proved by exami C proved by simpl C proved by contr C proved with us C proved by Victo C proved by Ripos C proved using ch	iner: Lifie eradic er pr pr: ste: necke	r: tion: rcoof rule: w:	/Pc	2 2 0 0 0	
Procedure Proced	of s l s l s l s l s l s l s l s	Volume trateg ubprog ubprog ubprog ubprog ubprog ubprog	rams rams rams rams rams rams rams rams	with at with at with at with at with at with at strateg.	subprogram t least one	aaddss e Vo e Vo e Vo e Vo e Vo	C proved by exami C proved by simpl C proved by contr C proved by Victo C proved by Ripos C proved using ch C discharged by r	iner: Lifie eradic er pr pr: ste: necke	r: tion: rcoof rule: w:	/Pc	2 2 0 0 0	
Prood Tota Tota Tota Tota Tota Tota Tota Tota	of s local	Tvolume trateg tubprog tubprog tubprog tubprog tubprog tubprog tubprog tubprog tubprog tubprog	cies u crams	ernal/V sed by with at strateg.	subprogram t least one	aaddss s s s voor voor voor setee	C proved by exami C proved by contr C proved by Victo C proved by Ripos C proved using ch C discharged by r	iner: Lifie eradic er pr pr: ste: necke	r: tion: rcoof rule: w:	/Pc	2 2 0 0 0 0	

Total subprograms					
1 13	with proof	completed b	y Victor:		0
Total subprograms	with proof	completed b	y Riposte:		0
Total subprograms	with proof	completed b	y checker:		0
Total subprograms	with VCs d	ischarged by	review:		0
Overall subprogra					
Total subprograms					1
Total subprograms	with at le	ast one undi	scharged V	C:	2
Total subprograms					0
Total subprograms	for which V	'Cs have been	n generated	l :	3
ZombieScope Summa	-				
 Total subprograms				.d.	3
Total number subp			•	· • •	1
_	_	_	. Iouna.		
	ead paths fo	ound:			1
VC summary:				od VCs using on	
VC summary: Note: (User) deno		e Simplifie			
VC summary: Note: (User) deno	tes where th	e Simplifie			
VC summary: Note: (User) deno more user-d	tes where the	e Simplifie			
VC summary: Note: (User) deno	tes where the efined proof	e Simplifie	r has prove		
VC summary: Note: (User) deno more user-d	tes where the efined proof	e Simplifie	r has prove	ed VCs using on	
VC summary: Note: (User) deno more user-d Total VCs by type	tes where the efined proof	ne Simplifie Trules.	r has prove	ed VCs using on	
VC summary: Note: (User) deno more user-d Total VCs by type	tes where the efined proofe: - Total F	ne Simplifie Trules. Examiner Sim	r has prove plifier 5	ed VCs using on Undisc. 0	
VC summary: Note: (User) deno more user-d Total VCs by type Assert/Post Precondition Check stmnt.	tes where the efined proof	ne Simplifie: Frules. Examiner Simplifie: 3 0	r has prove plifier 5	ed VCs using on Undisc. 0	
Note: (User) deno more user-d Total VCs by type Assert/Post Precondition	tes where the efined proof	ne Simplifie Frules. Examiner Sim 3 0	r has prove plifier 5 0	Undisc. 0 0 0	
VC summary: Note: (User) deno more user-d Total VCs by type Assert/Post Precondition Check stmnt. Runtime check Refinem. VCs	tes where the efined proof	e Simplifie: Trules. Examiner Simplifie: 3 0 0 0	plifier 5 0 5	Undisc. 0 0 0 2	
VC summary: Note: (User) deno more user-d Total VCs by type Assert/Post Precondition Check stmnt. Runtime check Refinem. VCs Inherit. VCs	tes where the efined proof	Examiner Sim	plifier 5 0 5 0	Undisc. 0 0 2 0 0	
VC summary: Note: (User) deno more user-d Total VCs by type Assert/Post Precondition Check stmnt. Runtime check Refinem. VCs Inherit. VCs	tes where the efined proof	ae Simplifie: Frules. Examiner Sim	plifier 5 0 5 0 0	Undisc. 0 0 0 2 0 0	

Listing 6.6: Second POGS report

Now, we can see progress. Only 2 VCs (13%) are undischarged in comparison to 3 (20%) previously.

Then rerun Kiasan.

pca-pump-verification-step4

Move_Dosed and Increase_Dosed are fine: no Exception cases.

Read_Dosed ConstraintError: the value being assigned to Result is too small. After look at the pre and post state it seems weird. After investigation and talk with Kiasan Developer, it was determined that there is a bug in Kiasan v1(for SPARK 2005). More precisely: checking overflows. For the purpose of verification p_{rug} _volume type range was changed to $0 - (2^{15} - 1)$. Negative values in this case are unnecessary. It will give range up to around 1000000. Which is sufficient even if calculations are made in micro liters (as it is in case of PCA Pump implementation). 10000000 micro liters is 1000 ml, which is 1 liter. Which is extreme amount of drug in case of PCA Pump, according to Requirement Document [LHC13]. The bug with type ranges is fixed in Kiasan v2 (for SPARK 2014).

Another problem is size of Dosed array (3600 elements). First of all, Kiasan array bound and loop bound has to be increased (from default 10). Another thing is computational complexity. The state space grow exponentially and it takes a lot of time to analyze array of 3600 elements. Thus for verification purposes array size was change to 60 elements. Along with increasing array bounds and loop bounds for Kiasan also to 60.

After rerun Kiasan, there is valid test case for Read_Dose, but there are also 59 Exception cases: Range violation (UPPER), which means there is possible overflow. One way to fix it is to add --# assume annotation to loop in function body, but Kiasan v1 does not support it. Another way is to add pre-condition, which assure, that sum of elements is lower than

Drug_Volume', Last. SPARK does not provide simple library for summing array (like Contracts for Java provide). Thus, this function has to be implemented. However, its implementation is the same like Read_Dosed. It sum all elements of array. Sum function specification and body is presented on listing 6.7.

```
function Sum(Arr : Doses_Array) return Drug_Volume;

function Sum(Arr : Doses_Array) return Drug_Volume

is

   Result : Drug_Volume := 0;

begin

  for I in Doses_Array_Index loop

    --# assert true;

   Result := Result + Arr(I);

  end loop;

  return Result;

end Sum;
```

Listing 6.7: Sum function for summing all elements of array

After rerun Kiasan, there is only valid test case.

pca-pump-verification-step5

The last thing which can be improved by code contracts is checking if Move_Dosed procedure works as expected. In that purpose three postconditions were added (listing 6.8). First checks if the last element is equal to 0. Second and third checks two possible scenarios:

- before running procedure, the first element is equal to 0: amount of dosed drug in last hour will not change after Dosed procedure execution
- the first element is greater than 0: after Dosed procedure execution, the amount of drug dosed in last hour will decrease, because first element value will no longer be in last hour range

```
--# post Dosed(Doses_Array_Index'Last) = 0
--# and (Dosed~(Doses_Array_Index'First)=0 -> Read_Dosed(Dosed~) = Read_Dosed(Dosed))
```

Listing 6.8: Postconditions added to Move_Dosed procedure

After adding these postconditions Kiasan generates 2 test cases to check both mentioned scenarios. There is no error cases, which means that procedure works as expected.

Better way to validate such requirements is Unit testing. In section 6.4, there is overview of unit tests created to test behavior described above.

Running Examiner and SPARKSimp after all changes (truncated result):

			0		 	marketing areer			~ '	(== ===	_
VCs	for	-		re_increas							_
#		From				Proved By					
						Undischarged					
						Examiner					
VCs	for	proce		re_move_do							
			I	То	I	Proved By	I	Dead Path	I		
ľ											
1						Inference					
1 2						Inference					
3						Inference					
4						Inference					1
5						Inference					1
						Inference Inference					1
1											1
1 0						Inference Undischarged					' '
1 9						ondischarged					'
VCs	for			n_read_dos							
#	ı		I	То	I	Proved By	I	Dead Path	I		
1		start				Inference				IL	-

3													
4	2 28	I	assert	@ 28		I	Inference]	Live	I	IL	1
# From To	3 28	rto	check	@ 29		I	Undischarged		1	Unchecked	I	UU	- 1
# From To	4 28	I	assert	@ fi	nish	I	Inference]	Live	I	IL	١
# From To													
# From To	VCs for functi												
1		l To				I	Proved By]	Dead Path	I	Statu	s
3													
Total VCs by type: Total Examiner Simplifier Undisc. Assert/Post 11 1 9 1 Precondition 0 0 0 0 Check stmnt. 0 0 0 0 Runtime check 8 0 5 3 Refinem. VCs 0 0 0 0 Inherit. VCs 0 0 0 0 0 Totals: 19 1 14 4 4 <	2 11	I	assert	@ 11		I	Inference]	Live	I	IL	I
Total VCs by type: Total Examiner Simplifier Undisc. Assert/Post 11 1 9 1 Precondition 0 0 0 0 Check stmnt. 0 0 0 0 Runtime check 8 0 5 3 Refinem. VCs 0 0 0 0 Inherit. VCs 0 0 0 0 Totals: 19 1 14 4 4 <<<	3 11	rto	check	0 12		I	Undischarged		1	Unchecked	Ī	UU	1
Total VCs by type: Total Examiner Simplifier Undisc. Assert/Post 11 1 9 1 Precondition 0 0 0 0 Check stmnt. 0 0 0 0 Runtime check 8 0 5 3 Refinem. VCs 0 0 0 0 Inherit. VCs 0 0 0 0 Totals: 19 1 14 4 4 <<<	4 11	I	assert	@ fi	nish	I	Inference]	Live	Ī	IL	I
Precondition 0 0 0 0 Check stmnt. 0 0 0 0 Runtime check 8 0 5 3 Refinem. VCs 0 0 0 0 Inherit. VCs 0 0 0 0 Totals: 19 1 14 4 4	·	-		Ex	aminer		Simplifier	Undisc	:.				
Check stmnt. 0 0 0 0 0 Runtime check 8 0 5 3 Refinem. VCs 0 0 0 0 Inherit. VCs 0 0 0 0	Assert/Post		11		1	L	9		1				
Runtime check 8 0 5 3 Refinem. VCs 0 0 0 0 Inherit. VCs 0 0 0 0	Precondition		0		0)	0		0				
Refinem. VCs 0 0 0 0 0 Inherit. VCs 0 0 0 0 0 Totals: 19 1 14 4 <<<	Check stmnt.		0		0)	0		0				
Inherit. VCs 0 0 0 0 0	Runtime check		8		0)	5		3				
Totals: 19 1 14 4 <<<	Refinem. VCs		0		0)	0		0				
Totals: 19 1 14 4 <<<	Inherit. VCs						-						
%Totals: 5% 74% 21%	Totals:									<<<			

Listing 6.9: Third POGS report

Now, there is 4 undischarged VCs, but total number of generated VCs is 19. In previous runs there was only 15. Thus there is 4 new VCs and 2 of them are undischarged. The reason is introduction of sum function of all subprograms which are using it. To confirm this, look at all undischarged VCs. Which is: 1st VC in increase_dosed.siv file (listing 6.10, 9th VC in move_dosed.siv file (listing 6.11, 3rd VC in read_dosed.vcg file (listing 6.12) and 3rd VC in sum.vcg file (listing 6.13). They conform to subprograms: Increase_Dosed, Move_Dosed, Read_Dosed and

sum respectively.

```
procedure_increase_dosed_1.
H1:
       read_dosed(dosed) <= 32767 - dose_volume .</pre>
       for_all(i__1 : integer, 1 <= i__1 and i__1 <= 60 -> 0 <= element(
H2:
          dosed, [i_1] and element(dosed, [i_1]) <= 32767).
Н3:
       dose_volume >= 0 .
H4:
       dose\_volume <= 32767 .
H5:
       integer__size >= 0 .
H6:
       drug_volume__size >= 0 .
H7:
       drug_volume__base__first <= drug_volume__base__last .</pre>
H8:
       doses_array_index__size >= 0 .
H9:
       drug_volume__base__first <= 0 .</pre>
H10:
       drug_volume__base__last >= 32767 .
       element(dosed, [60]) + dose_volume <= 32767 .</pre>
C1:
```

Listing 6.10: Undischarged Verification Condition from increase dosed.siv file

```
procedure_move_dosed_9.
H1:
       element(dosed, [58]) = element(dosed, [59]) .
       for_all(i__1 : integer, 1 <= i__1 and i__1 <= 60 -> 0 <= element(
H2:
          dosed, [i_{--}1]) and element(dosed, [i_{--}1]) <= 32767) .
Н3:
       element(dosed, [60]) >= 0 .
H4:
       element(dosed, [60]) <= 32767 .
       integer__size >= 0 .
H6:
       drug_volume__size >= 0 .
H7:
       drug_volume__base__first <= drug_volume__base__last .</pre>
H8:
       doses_array_index__size >= 0 .
H9:
       drug_volume__base__first <= 0 .</pre>
H10:
       drug_volume__base__last >= 32767 .
C1:
       element(dosed~, [1]) = 0 -> read_dosed(dosed~) = read_dosed(update(
          update(dosed, [59], element(dosed, [60])), [60], 0)) .
C2:
       element(dosed~, [1]) > 0 -> read_dosed(dosed~) > read_dosed(update(
          update(dosed, [59], element(dosed, [60])), [60], 0)) .
```

Listing 6.11: Undischarged Verification Condition from move dosed.siv file

```
function_read_dosed_3.
H1: loop__1_i > 1 -> result >= element(dosed, [loop__1_i - 1]) .
```

```
H2:
       for_all(i___1 : integer, 1 <= i___1 and i___1 <= 60 -> 0 <= element(
          dosed, [i_{-1}]) and element(dosed, [i_{-1}]) <= 32767) .
Н3:
       sum(dosed) \le 32767.
H4:
       loop_1_i >= 1.
H5:
       loop_1_i <= 60.
H6:
       result >= 0 .
H7:
       result <= 32767 .
H8:
       integer\_size >= 0 .
Н9:
       drug_volume__size >= 0 .
H10:
       drug_volume__base__first <= drug_volume__base__last .</pre>
       doses_array_index__size >= 0 .
H11:
H12:
       drug_volume__base__first <= 0 .</pre>
       drug_volume__base__last >= 32767 .
H13:
C1:
       result + element(dosed, [loop_1_i]) <= 32767 .
```

Listing 6.12: Undischarged Verification Condition from read dosed.siv file

```
function_sum_3.
       for_all(i__1 : integer, 1 <= i__1 and i__1 <= 60 -> 0 <= element(arr,
H1:
          [i_1] and element(arr, [i_1]) <= 32767).
       loop_1_i >= 1.
H2:
Н3:
       loop_1_i <= 60.
H4:
       result >= 0.
H5:
       result <= 32767 .
H6:
       integer__size >= 0 .
H7:
       drug_volume__size >= 0 .
H8:
       drug_volume__base__first <= drug_volume__base__last .</pre>
H9:
       doses_array_index__size >= 0 .
H10:
      drug_volume__base__first <= 0 .</pre>
       drug_volume__base__last >= 32767 .
H11:
       result + element(arr, [loop__1_i]) <= 32767 .
C1:
```

Listing 6.13: Undischarged Verification Condition from sum.siv file

In Move_Dosed procedure, tools cannot prove implications in post conditions. Fortunately, it is already proved by Bakar Kiasan. The problem in Increase_Dosed, Read_Dosed and sum is the same. Tools cannot verify, that adding Result and some element of Dosed array will not cause

overflow. Bakar Kiasan can prove correctness of Increase_Dosed and Read_Dosed. However only, with assumption that sum is correct. sum cannot be proved by Bakar Kiasan. Four exception cases indicating possible overflow are generated. Thus, the only way to prove correctness of this module is to assume, that helper function sum is correct.

Complete code of module for dose monitoring can be found in D.

Unfortunately, introduced changes (pre- and postconditions) cannot be applied to PCA Pump prototype implementation, because - as mentioned in chapter 2.6 - protected objects cannot be used in proof annotations (pre- and postconditions).

This shows, how code implemented based on translation from AADL/BLESS can be verified using SPARK tools.

6.3 Verification of generated code

Raw, generated code cannot be verified, because Examiner return syntax errors. The reason is that some parts of code are not implemented. Especially, BLESS assertions, which are not even defined. In order to verify generated code, it has to be at least partially implemented.

6.3.1 Adding implementation to generated code

6.4 AUnit tests

Better way to prove expected behavior of Move_Dosed in Dose monitoring module is to create AUnit test. To check both behaviors of Move_Dosed procedure, two tests have been created:

- Test_Move_Dosed_First_Element_Zero first element is 0, then after execution of the procedure dosed amount of drug should be not changed
- Test_Move_Dosed_First_Element_Not_Zero first element is greater than 0, then after execution

of the procedure dosed amount of drug should be smaller than before

Both test cases are presented on listing 6.14.

```
procedure Test_Move_Dosed_First_Element_Zero (Gnattest_T : in out Test) is
 pragma Unreferenced (Gnattest_T);
 Pre_Sum : Pca_Pump.Drug_Volume := 0;
 Post_Sum : Pca_Pump.Drug_Volume := 0;
begin
 -- Arrange
 Pre_Sum := Pca_Pump.Read_Dosed;
 -- Act
 Pca_Pump.Move_Dosed;
 Post_Sum := Pca_Pump.Read_Dosed;
 -- Assert
 AUnit.Assertions.Assert
   (Post_Sum = Pre_Sum,
    "Total dose changed: " & Pca_Pump.Drug_Volume'Image(Pre_Sum) & " /= " & Pca_Pump.Drug_Volume'Image(
    Post_Sum));
end Test_Move_Dosed_First_Element_Zero;
procedure Test_Move_Dosed_First_Element_Not_Zero (Gnattest_T : in out Test) is
 pragma Unreferenced (Gnattest_T);
 Pre_Sum : Pca_Pump.Drug_Volume := 0;
 Post_Sum : Pca_Pump.Drug_Volume := 0;
begin
 -- Arrange
 Pca_Pump.Increase_Dosed;
 for I in Pca_Pump.Doses_Array_Index range 1 .. Pca_Pump.Doses_Array_Index'Last-1 loop
    Pca_Pump.Move_Dosed;
 end loop;
 Pre_Sum := Pca_Pump.Read_Dosed;
 -- Act
 Pca_Pump.Move_Dosed;
 Post_Sum := Pca_Pump.Read_Dosed;
  -- Assert
```

```
AUnit.Assertions.Assert

(Post_Sum < Pre_Sum,

"Total dose changed: " & Pca_Pump.Drug_Volume'Image(Pre_Sum) & " should be greater than " & Pca_Pump.

Drug_Volume'Image(Post_Sum));

end Test_Move_Dosed_First_Element_Not_Zero;
```

Listing 6.14: AUnit tests for Move_Dosed procedure

[add other test cases?]

6.5 gnatPROVE?

There is a new tool set "gnatPROVE" for SPARK 2014. It was not used because PCA Pump was developed in SPARK 2005. I CAN TRANSLATE SOME SINGLE FUNCTIONS AND USE GNAT PROVE TO VERIFY?

Chapter 7

Summary

What I have done.

The work is done for SPARK 2005. SPARK 2014 (especially taking) and its tools (such as gnatPROVE) were not ready at the time, when this thesis was written.

Issues:

- not many online resources - no access to industry code - everything (AADL, SPARK2014, BLESS, tools) is under development - hard to create running application - need to rely on some resources, which are not nessesarly up to date - AADL models don't contains subprograms, which would be useful in AADL2SPARK translator creation

Chapter 8

Future work

What has to be done now.

translation of BLESS state machine (issue: time notion): * states * transitions

The semantics of BLESS contain notions of time that make translation to SPARK difficult.

translations for SPARK 2014 (for now, thread -> task translation can be done in Ada 2012 and then Sparking Ada)

try to apply generics on types translation

try to apply child packages for feature

extend property set translation (only addlinteger and simple types are handled)

Translator: * it should ignore all not defined properties in data types translations

Decompose code (get rid of 1 big/huge package): * separate packages * child packages?

* maybe every thread should be in child package?

PCA Pump: * Interface to ICE * drug concentration * monitoring of infused drug by sensors

Two way communication between SPARK packages: circular dependency issue (4.2.1).

Interport connections: table 10-3 in AADL book (p.193) and 1 to many connections

(multiple events calling).

Add task periods

Automatic translator for sequential programs (without protected objects).

Bibliography

- [AB04] Tullio Vardanega Alan Burns, Brian Dobbing. Guide for the use of the ada ravenscar profile in high integrity systems. ACM SIGAda Ada Letters, 24(2):1–74, Juin 2004.
- [Ada14] AdaCore. Aunit cookbook. URL: http://docs.adacore.com/aunit-docs/aunit.html, Mars 2014.
- [AL14] AdaCore and Altran UK Ltd. Spark 2014 reference manual. URL: http://docs.adacore.com/spark2014-docs/html/lrm, 2011-2014.
- [AW01] Neil Audsley and Andy Wellings. Issues with using ravenscar and the ada distributed systems annex for high-integrity systems. In *IRTAW '00 Proceedings* of the 10th international workshop on Real-time Ada workshop, pages 33 39. ACM New York, NY, USA, 2001.
- [Bar13] John Barnes. SPARK The Proven Approach to High Integrity Software. Altran, 2013.
- [BHR⁺11] Jason Belt, John Hatcliff, Robby, Patrice Chalin, David Hardin, and Xianghua Deng. Bakar kiasan: Flexibe contract checking for critical systems using symbolic execution. In NASA Formal Methods, pages 58–72. Springer Berlin Heidelberg, 2011.
 - [CB09] Mohamed Yassin Chkouri and Marius Bozga. Prototypying of distributed embedded systems using aadl. In ACESMB 2009, Second International Workshop on

- Model Based Architecting and Construction of Embedded Systems, pages 65–79. Springer Berlin Heidelberg, 2009.
- [Cha00] Roderick Chapman. Industrial experience with spark. ACM SIGAda Ada Letters
 special issue on presentations from SIGAda 2000, XX(4):64–68, Décembre 2000.
- [DEL+14] Claire Dross, Pavlos Efstathopoulos, David Lesens, David Mentre, and Yannick Moy. Rail, space security: Three case studies for spark 2014. In ERTS 2014: Embedded Real Time Software and Systems, 2014.
- [DRH07] Xianghua Deng, Robby, and John Hatcliff. Kiasan/kunit: Automatic test case generation and analysis feedback for open object-oriented systems. In *Proceedings of the Testing: Academic and Industrial Conference Practice and Research Techniques MUTATION*, pages 3–12. IEEE Computer Society Washington, DC, 2007.
 - [Fal14] Ed Falis. Aunit tutorials. URL: http://libre.adacore.com/tools/aunit, Mars 2014.
 - [FG13] Peter H. Feiler and David P. Gluch. Model-Based Engineering with AADL. Addison-Wesley, 2013.
- [HKL+12] John Hatcliff, Andrew King, Insup Lee, Alasdair MacDonald, Anura Fernando, Michael Robkin, Eugene Vasserman, Sandy Weininger, and Julian M. Goldman. Rationale and architecture principles for medical application platforms. In Cyber-Physical Systems (ICCPS), 2012 IEEE/ACM Third International Conference on, pages 3 – 12. IEEE, 2012.
- [HLW12] John Hatcliff, Kejia Li, and Steve Warren. Component-based app design for platform-oriented devices in a medical device coordination framework. In *ACM SIGHIT International Health Informatics Symposium*, pages 343 352, 2012.

- [Hor09] Bartlomiej Horn. Ada'05 compiler for arm based systems. thesis, Technical University of Lodz, Poland, 2009.
- [Hug13] Jérôme Hugues. About ocarina. URL: http://www.openaadl.org/ocarina. html, 2013.
- [HZPK08] Jérôme Hugues, Bechir Zalila, Laurent Pautet, and Fabrice Kordon. From the prototype to the final embedded system using the ocarina and tool suite. ACM Transactions on Embedded Computing Systems, 7(4):237–250, Juilliet 2008.
- [IEC⁺06] Andrew Ireland, Bill J. Ellis, Andrew Cook, Roderick Chapman, and Janet Barnes. An integrated approach to high integrity software verification. *Journal of Automated Reasoning*, 36(4):379–410, Avril 2006.
 - [Lar14] Brian R. Larson. Integrated clinical environment patient-controlled analgesia infusion pump system requirements draft 0.10.1, Février 2014.
- [LCH13] Brian R. Larson, Patrice Chalin, and John Hatcliff. Bless: Formal specification and verification of behaviors for embedded systems with software. In NASA Formal Methods, pages 276–290. Springer Berlin Heidelberg, 2013.
 - [Lev12] Nancy G. Leveson. Engineering a Safer World. The MIT Press, 2012.
- [LHC13] Brian R. Larson, John Hatcliff, and Patrice Chalin. Open source patient-controlled analgesic pump requirements documentation. In *Software Engineering* in Health Care (SEHC), 2013 5th International Workshop, pages 28–34. Institute of Electrical and Electronics Engineers (IEEE), 2013.
- [LZPH09] Gilles Lasnier, Bechir Zalila, Laurent Pautet, and Jérôme Hugues. Ocarina: An environment for aadl models analysis and automatic code generation for high

- integrity applications. In *Reliable Software Technologies Ada-Europe 2009*, pages 237–250. Springer Berlin Heidelberg, 2009.
- [Med10] Smiths Medical. Cadd-prizm ambulatory infusion pump model 6100 and model 6101 technical manual. URL: http://www.smiths-medical.com/upload/products/pdf/cadd_prizm_vip_system/in19824.pdf, Novembre 2010.
 - [PHR] Sam Procted, John Hatcliff, and Robby. Towards an aadl-based definition of app architecture for medical application platforms. In *Proceedings of the 2014 Software Engineering in Health-care (SEHC) Workshop at the International Symposium on Foundations of Health Information Engineering and Systems (FHIES 2014)*.
 - [SC12] Loren Segal and Patrice Chalin. A comparison of intermediate verification languages: Boogie and sireum/pilar. In *Verified Software: Theories, Tools, Experiments*, pages 130–145. Springer, 2012.
- [SCD14] SAE AS-2C Architecture Description Language Subcommittee, Embedded Computing Systems Committee, and Aerospace Avionics Systems Division. Aerospace standard architecture analysis & design language (aadl) v2 programming language annex document draft 0.9, Avril 2014.
 - [Tea] SPARK Team. Victor wrapper user manual.
- [Tea10] SPARK Team. Sparksimp utility user manual. URL: http://docs.adacore.com/sparkdocs-docs/SPARKSimp_UM.htm, Novembre 2010.
- [Tea11a] SPARK Team. Pogs user manual. URL: http://docs.adacore.com/sparkdocs-docs/Pogs_UM.htm, Septembre 2011.

- [Tea11b] SPARK Team. Spark examiner user manual. URL: http://docs.adacore.com/sparkdocs-docs/Examiner_UM.htm, Décembre 2011.
- [Tea11c] SPARK Team. Spark simplifier user manual. URL: http://docs.adacore.com/sparkdocs-docs/Simplifier_UM.htm, Juin 2011.
- [Tea12] SPARK Team. The spark ravenscar profile. URL: http://docs.adacore.com/sparkdocs-docs/Examiner_Ravenscar.htm, 2012.
- [Thi11] Hariharan Thiagarajan. Dependence analysis for inferring information flow properties in spark ada programs. thesis, Kansas State University, 2011.

Appendix A

Simplified PCA Pump AADL/BLESS models

Content of this appendix.

Appendix B

PCA Pump Prototype - simple, working example

Content of this appendix.

Appendix C

 $\begin{aligned} & PCA\ Pump\ Prototype\ \textbf{-}\ translated\ from} \\ & AADL/BLESS \end{aligned}$

Appendix D

PCA Pump - dose monitor module

Final version of PCA_Verification and AUnit tests.