- All leaks resulting in the deposition of termiticide in locations other than those prescribed on this label must be cleaned up prior to leaving the application site. Do not allow people or pets to contact contaminated areas or to reoccupy the contaminated area until the clean-up is completed.
- Use anti-backflow equipment or procedures to prevent siphonage of pesticide back into water supplies.

Care should be taken that the treatment solution is not introduced into the gravel and/or pipe drainage system which may be located on the exterior of the foundation in close proximity to the footing of the structure.

SUBTERRANEAN TERMITE CONTROL (including Eastern, Western, and Formosan Termites)

USE DIRECTIONS

Whenever possible, make termite control applications near the structure foundation using soil injections.

Apply a 0.25%-0.50% emulsion to establish subsurface termite control barriers as specified on product labeling.

Consult State and local specifications for recommended distance of treatment areas from wells or, if such regulations do not exist, refer to Federal Housing Administration Specifications for guidance.

USE DILUTIONS

	Tank Size				
Emulsion	1 Gal		25 Gal		
Concentration (% active)	Demon Max	Water	Demon Max	Water	
0.25	1.3 fl oz	126.7 fl oz	32.0 fl oz	24.8 gal	
0.50	2.6 fl oz	125.4 fl oz	64.0 fl oz	24.5 gal	
1.00	5.1 fl oz	122.0 fl oz	128.0 fl oz	24.0 gal	

	Tank Size				
Emulsion	50 Gal		100 Gal		
Concentration (% active)	Demon Max	Water	Demon Max	Water	
0.25	0.5 gal	49.5 gal	1.0 gal	99.0 gal	
0.50	1.0 gal	49.0 gal	2.0 gal	98.0 gal	
1.00	2.0 gal	48.0 gal	4.0 gal	96.0 gal	

Common units of measure:

1 pint = 16 fluid ounces (fl oz)

1 gallon (gal) = 4 quarts (qt) = 8 pints (pt) = 128 fluid ounces (fl oz)

APPLICATION VOLUMES

To provide maximum control and protection against termite infestation, apply the specified volume of the finished water and active ingredient emulsion as set forth in the use directions section of this label. If soil will not accept the labeled application volume, the volume may be reduced provided there is a corresponding increase in concentration so that the amount of active ingredient applied to the soil remains the same. See **Volume Adjustment Chart** for specific information.

Note: Large reductions of application volume reduce the ability to obtain a continuous barrier. Variance is allowed when volume and concentration are consistent with label directed rates and a continuous barrier can still be achieved.

Note: When volume is reduced, the hole spacing for sub-slab injection and soil rodding may require similar adjustments to account for lower volume dispersal of the termiticide in the soil. Do not use volume adjustments at 1% for sub-slab injection.

Volume Adjustment Chart							
Volume Allowed	Rate (% Emulsion)						
Horizontal (gal emulsion/	0.25%	0.5%	1.0%				
10 sq ft)	1 gal	0.5-1 gal	0.25-0.5* gal				
Vertical (gal emulsion/ 10 linear ft)	4 gal	2-4 gal	1-2* gal				

^{*}Do not use volume adjustments at 1% for sub-slab injection.

PRECONSTRUCTION SUBTERRANEAN TERMITE TREATMENT

Effective preconstruction subterranean termite control requires the establishment of an unbroken vertical and/or horizontal chemical barrier between wood in the structure and the termite colonies in the soil.

USE RESTRICTIONS

- Prior to each application, applicators must notify the general contractor, construction superintendent, or similar responsible party of the intended termiticide application and intended sites of application and instruct the responsible person to notify construction workers and other individuals to leave the area to be treated during application and until the termiticide is absorbed into the soil.
- The treatment site must be covered prior to a rain event in order to prevent run-off of the pesticide into non-target areas.
- The applicator must either cover the soil her/himself or provide written notification of the requirement to the contractor on site and to the person commissioning the application (if different than the contractor). If notice is provided to the contractor or the person commissioning the application, then they are responsible under FIFRA to ensure that: 1) if the concrete slab cannot be poured over the treated soil within 24 hours of application, the treated soil is covered with a waterproof covering (such as polyethylene sheeting); and, 2) the treated soil is covered if precipitation is predicted to occur before the concrete slab is scheduled to be poured.
- Do not treat soil that is water-saturated or frozen.
- Do not treat when raining.
- Do not allow treatment to run off from the target area.
- Do not apply within 10 feet of storm drains. Do not apply within 25 feet of aquatic habitats (such as, but not limited to, lake, reservoirs, rivers, permanent streams, marshes or natural ponds, estuaries, and commercial fish farm ponds).
- Do not make on-grade applications when sustained wind speeds are above 10 mph (at application site) at nozzle-end height.

To meet Federal Housing Administration termite-proofing requirements, follow the latest edition of the Housing and Urban Development (H.U.D.) Minimum Property Standards.