ECE 362 Experiment 3: General Purpose I/O

Last Modified: 2019-09-08

1.0 Introduction

In this experiment, you will learn how to attach simple input devices (pushbuttons) and simple output devices (LEDs) to an STM32 development board. You will learn how to configure the General Purpose Input/Output (GPIO) subsystems. You will read values from and write values to these pins.

Step		Points
4.2	Prelab	30 points
6.1	Enabling the Clock to Ports	10 points
6.2	Configuring Pins as Outputs	10 points
6.3	Turning Output Pin On	10 points
6.4	Reading Input Pins	10 points
6.5	Wiring	10 points
6.6	Sequencing	10 points
7.0	Post lab submission	10 points
	Total	100 points

2.0 Objectives

- 1. Connect LEDs and buttons to the STM32F0 GPIO pins.
- 2. Configure the GPIO systems.
- 3. Read values from and write values to the GPIO pins.
- 4. Attach external circuitry to the GPIO pins.

3.0 Equipment and Software

- 1. Standard ECE362 Software Toolchain (Installation instructions available in Experiment 0: Getting Started)
- 2. STM32F0-DISCOVERY development board (For procurement instructions, see Experiment 0: Getting Started)

4.0 Prelab

- 4.1 Read section 5 of this document for background information
- 4.2 Complete the prelab questions on the course website

5.0 Background

Two steps are needed to configure I/O pins for use. First, the Reset & Clock Control subsystem must be configured to enable a port for use. This is done by turning on the specific bit in the AHBENR (Advanced High-Performance Bus Enable Register). In doing so, be sure not to turn OFF important bits such as the SRAMEN bit. Use your lecture notes to determine how to do this. For this lab, in particular, you should enable Ports B and C by ORing the appropriate values into the AHBENR register.

Second, an enabled port must have its pins configured as either inputs or outputs (or some other functions that we will use in future labs). For this lab, we will use Port B pins as inputs and Port C pins as outputs. For both ports there are some pins whose function you should not modify. In particular, you should not change PA13, PA14, PC13, PC14, or PC15 since these are used for the External Oscillator, Debugging, and Programming interfaces. Instead, use code from your lecture notes to learn how to work around those.

A functional diagram for an STM32F0 GPIO port is shown in Figure 1, below:




Figure 1. GPIO Pin Functional Diagram

6.0 Experiment

This experiment uses a pre-compiled object file that contains test functions to <u>automatically</u> test the subroutines you write for this lab. It is called autotest.o. To incorporate it into your System Workbench project, follow the instructions in the <u>ECE 362 References page</u> for <u>Adding a pre-compiled module to a project in System Workbench</u>. If you use the Lab03_Template zip file, it is configured for you.

6.1 Enabling the Clock to Ports

Using the main.s template file provided for this lab, fill in the assembly language procedure for *enable_ports*. This is should <u>enable the RCC clock</u> for both <u>Port C and Port B</u> without disabling other bits such as SRAMEN. Recall *what a subroutine is, how it needs to be written in assembly, do not forget to push and pop the right register(s).*

To test your assembly subroutine, uncomment the line "bl test_enable_ports" in main.s. A working enable_ports subroutine will blink the green LED once per second. **Demonstrate your completed work to your TA.**

<u>Hint:</u> When debugging your code, you may consult the "I/O Registers" tab in the Monitor window. This tab provides a hierarchical listing of all of the various peripherals utilized by the microcontroller and their sub-registers. By default their values are not shown; double clicking on a given entry will cause the debugger to track the values of that entry and its lower elements. Use this to confirm that the various registers you are writing to are taking on the values which you expect. An example of this is shown in Figure 2, below:




Figure 2. I/O Registers View

6.2 Configuring Pins as Outputs

For this section you will need to complete the subroutine *port_c_output* in main.s so that it configures <u>pins 0, 1, 2 and 3</u> of <u>Port C</u> as <u>outputs</u>. DO NOT change the configuration for pins 13, 14, and 15. *Once again, make sure to push and pop the right register(s)*.

To test your assembly subroutine, uncomment the line "bl test_port_c_output" in main.s. A working port_c_output subroutine will blink the blue LED once per second. **Demonstrate** your completed work to your TA.

6.3 Turning Output Pin On

For this section you will need to complete the subroutines *setpin* and *clrpin* in main.s. Each of these subroutines expects a pointer to the GPIOx register array to be passed as the first parameter (register R0). The second parameter (register R1) is the bit number to be set (by *setpin*) or cleared (by *clrpin*). The *setpin* subroutine sets the corresponding bit (given by register r1) in the GPIOx_ODR register. And *clrpin* subroutine clears the corresponding bit (given by register r1) in the GPIOx_ODR register.

Once your subroutines are implemented, uncomment "bl test_set_clrpin". A working subroutine will allow the code to turn the blue and green LEDs on and off, together, once per second. **Demonstrate your completed work to your TA.**

6.4 Reading Input Pins

Complete the subroutine *getpin* in main.s. This function accepts the GPIOx base address as parameter 1 (register R0) and a bit number as parameter 2 (register R1). It returns the value (in register r0) in GPIOx_IDR at the bit specified by r1. That is the subroutine should return 0x1 if the pin is high or 0x0 if the pin is low.

Once your subroutine is implemented, uncomment "bl test_getpin". A working subroutine will allow the code to turn on both the blue and green LEDs only when the user pushbutton is pressed. **Demonstrate your completed work to your TA.**

Continues on next page

6.5 Wiring

<u>Unplug the power from your STM32 first</u>, THEN wire your circuit as shown in Fig 3. When you have completed your wiring, show your circuit to your TA. Ensure that you connect the resistors for the buttons to the 3V (3.3V) power. In other words, SHOW YOUR WIRING TO YOUR TA BEFORE YOU PLUG IT BACK IN. To test you wiring uncomment "bl test_wiring". The right wiring will turn on the LED's in a binary sequence, and will stop when any one of the wired buttons is pressed and restarts as soon as one it's released.




Figure 3. Schematic for wiring LEDs and push buttons

6.6 Sequencing

For this section you will need to complete the *seq_led* subroutine. This subroutine should cycle/sequence through the LED's connected to PC0, PC1, PC2 and PC3. The subroutine must also be able to cycle in both directions, given the direction parameter.

This subroutine accepts two parameters (R0 and R1), R0 is a pointer to the GPIOx base address, R1 is the direction for the cycle/sequence. The *seq_led* subroutine will perform the following operations:

- 1) Read the current content of GPIOx ODR
- 2) If R1 == 1
 - a. Left shift the content by 1
 - b. Check if value exceeds 8
 - c. If so set it to 0x1 // Logic for cycling though the LED's
- 3) Else (R1 != 0)
 - a. Right shift the content by 1
 - b. Check if value is 0
 - c. If so set it to 0x8 // Logic for cycling though the LED's
- 4) Store the new value in ODR

Once you complete this section, uncomment "bl run_seq". A working subroutine will allow the code to turn on the next LED when you press on button, and turn on the previously lit LED when you press the other. The LEDs will cycle in a sequential fashion. **Demonstrate your completed work to your TA.**

Refer to the wiring diagram for the lab and answer the following questions

- 6.6.1 Remove C1, replace R1 with a wire, and run the sequencing routine. Do the LED's sequence correctly when you push the push buttons? Type your observation in your post lab write up.
- 6.6.2 What is the default mode of GPIO pins such as PB13 and PC2 (i.e. are they Input, Output, Analog or Alternate Function mode)?
- 6.6.3 With reference to the previous question, what document provides this default value information?
- 6.6.3 What would happen if MODER values of pins PA13, an PA14 are changed? <u>Try it with the I/O register debugger</u> and type your observation in your post lab write up.

7.0 Complete post lab and submit code

Submit your code and complete the post lab on the website. The portal for post-lab will close 10 minutes after your scheduled lab.