#### 1 Introduction

## 2 MLS/RK meshfree approximation

In accordance with Moving Least Square approximation (MLS) [1] or Reproducing Kernel approximation (RK) [2], the domain  $\Omega$  is discrete by a set of meshfree nodes  $\{x_I\}_{I=1}^{n_p}$ ,  $n_p$  is the total number of meshfree nodes. And then, a variable u in  $\Omega$  can be approximated as follow:

$$u^{h}(\boldsymbol{x}) = \sum_{I=1}^{n_{p}} \Psi_{I}(\boldsymbol{x}) d_{I}$$
(1)

where  $\Psi_I$  and  $d_I$  are the meshfree shape function and the nodal coefficient associated with meshfree node  $x_I$ . This RK shape function  $\Psi_I$  is constructed by the undetermined coefficient vector c, the basis function vector p and the kernel function  $\phi$ :

$$\Psi_I(\mathbf{x}) = \mathbf{c}^T(\mathbf{x})\mathbf{p}(\mathbf{x}_I - \mathbf{x})\phi(\mathbf{x}_I - \mathbf{x})$$
(2)

For instance in 2D case, the basis function vector  $\boldsymbol{p}$  contains the pth order complete monomials:

$$\mathbf{p}(\mathbf{x}) = \{1, \ x, \ y, \ x^2, \ \dots, \ y^p\}^T \tag{3}$$

The kernel function  $\phi$  determines the support size and continuity of shape function, and the cubic and quintic spline functions is chosen herein for elasticity problems and thin plate problems respectively.

$$\phi(\boldsymbol{x}_I - \boldsymbol{x}) = \varphi(\frac{x_I - x}{h_x})\varphi(\frac{y_I - y}{h_y})$$
(4)

where  $h_i$  is the

• Cubic spline function:

$$\varphi(r) = \frac{1}{3!} \begin{cases} (2 - 2r)^3 - 4(1 - 2r)^3, & r \le \frac{1}{2} \\ (2 - 2r)^3, & \frac{1}{2} < r \le 1 \\ 0, & r > 1 \end{cases}$$
 (5)

• Quintic spline function:

$$\varphi(r) = \frac{1}{5!} \begin{cases} (3-3r)^5 - 6(2-3r)^5 + 15(1-3r)^5, & r \le \frac{1}{3} \\ (3-3r)^5 - 6(2-3r)^5, & \frac{1}{3} < r \le \frac{2}{3} \\ (3-3r)^5, & \frac{2}{3} < r \le 1 \\ 0, & r > 1 \end{cases}$$
(6)

in which  $h_i$  is the support size in  $x_i$  axis direction.

The undetermined vector  $\boldsymbol{c}$  can be attain by enforcing the following consistency condition:

$$\sum_{I=1}^{n_p} \Psi_I(\boldsymbol{x}) \boldsymbol{p}(\boldsymbol{x}_I) = \boldsymbol{p}(\boldsymbol{x})$$
 (7)

or with a shift-form

$$\sum_{I=1}^{n_p} \Psi_I(\boldsymbol{x}) \boldsymbol{p}(\boldsymbol{x}_I - \boldsymbol{x}) = \boldsymbol{p}(\boldsymbol{0})$$
 (8)

substituting Eq.2 into the consistency condition leads to:

$$c(x) = A^{-1}(x)p(0) \tag{9}$$

with moment matrix  $\boldsymbol{A}$ 

$$\mathbf{A}(\mathbf{x}) = \sum_{I=1}^{n_p} \mathbf{p}^T (\mathbf{x}_I - \mathbf{x}) \mathbf{p}(\mathbf{x}_I - \mathbf{x}) \phi(\mathbf{x}_I - \mathbf{x})$$
(10)

It is noted that, to ensure the invertibility of moment matrix, a well-posed meshfree nodal distribution should be required, i.e. there should be sufficient meshfree nodes be covered by their support, as shown in Fig. ??. Under this circumstance,

$$||u - u^i||_{H_k} \le Ch^{p-k+1}|u|_{H_{p+1}}, \quad \forall k \le p+1$$
 (11)

# 3 Hellinger-Reissner based RK gradient smoothing meshfree formulation

#### 3.1 Elasticity problems

$$\mathcal{L}(\boldsymbol{\sigma}, \boldsymbol{u}) = \int_{\Omega} \frac{1}{2} \boldsymbol{\varepsilon}(\boldsymbol{\sigma}) : \boldsymbol{\sigma} d\Omega - \int_{\Gamma_{\boldsymbol{u}}} \boldsymbol{n} \cdot \boldsymbol{\sigma} \cdot \bar{\boldsymbol{u}} d\Gamma$$
$$- \int_{\Gamma_{\boldsymbol{t}}} \boldsymbol{u} \cdot (\boldsymbol{\sigma} \cdot \boldsymbol{n} - \bar{\boldsymbol{t}}) d\Gamma + \int_{\Omega} \boldsymbol{u} \cdot (\boldsymbol{\sigma} \cdot \nabla + \bar{\boldsymbol{b}}) d\Omega \quad (12)$$

where  $\varepsilon$  and  $\sigma$  stands for the strain and stress tensor respectively.  $\Gamma_u$  and  $\Gamma_t$  are the essential boundary and natural boundary satisfying that  $\Gamma_u \cup \Gamma_t = \partial \Omega$ ,  $\Gamma_u \cap \Gamma_t = \emptyset$ .  $\bar{u}$  and  $\bar{t}$  are the prescribed displacement and traction on  $\Gamma_u$  and  $\Gamma_t$ .  $\bar{b}$  denotes to the prescribed body force in  $\Omega$ . Introducing the standard variation argument to Eq.12 leads to the following HR weak form:

find 
$$\sigma, u \in H_1$$
  $a(\delta \sigma, \sigma) + b(\delta \sigma, u) = g(\delta \sigma) \quad \forall \delta \sigma \in H_1$   $b(\sigma, \delta u) = f(\delta u) \quad \forall \delta u \in H_1$  (13)

where  $a:L_2\times L_2\to\mathbb{R},\,b:L_2\times L_2\to\mathbb{R}$  are bilinear forms:

$$a(\delta \boldsymbol{\sigma}, \boldsymbol{\sigma}) = \int_{\Omega} \boldsymbol{\varepsilon}(\delta \boldsymbol{\sigma}) : \boldsymbol{\sigma} d\Omega$$
 (14)

$$b(\boldsymbol{\sigma}, \boldsymbol{u}) = -\int_{\Gamma} \boldsymbol{u} \cdot \boldsymbol{\sigma} \cdot \boldsymbol{n} d\Gamma + \int_{\Omega} \boldsymbol{u} \cdot \boldsymbol{\sigma} \cdot \nabla d\Omega + \int_{\Gamma_{\boldsymbol{u}}} \boldsymbol{u} \cdot \boldsymbol{\sigma} \cdot \boldsymbol{n} d\Gamma \qquad (15)$$

and g, f are the linear operators evaluated by

$$g(\delta \boldsymbol{\sigma}) = \int_{\Gamma_u} \boldsymbol{n} \cdot \delta \boldsymbol{\sigma} \cdot \bar{\boldsymbol{u}} d\Gamma \tag{16}$$

$$f(\delta \boldsymbol{u}) = -\int_{\Gamma_t} \delta \boldsymbol{u} \cdot \bar{\boldsymbol{t}} d\Gamma - \int_{\Omega} \delta \boldsymbol{u} \cdot \bar{\boldsymbol{b}} d\Omega$$
 (17)

In Hellinger-Reissner reproducing kernel gradient smoothing framework, the displacement  $\boldsymbol{u}$  is approximated by traditional meshfree shape functions, namely  $\boldsymbol{u}^h$ :

$$\boldsymbol{u}^{h}(\boldsymbol{x}) = \sum_{I=1}^{n_{p}} \Psi_{I}(\boldsymbol{x}) \boldsymbol{d}_{I}$$
 (18)

On the other hand, the components of stress tensor is assumed as a polynomial in each background cells:

$$\sigma_{ij}^{h}(\boldsymbol{x}) = \boldsymbol{q}^{T}(\boldsymbol{x})\boldsymbol{c}_{ij}, \quad \text{in } \Omega_{C}$$
(19)

$$\mathbf{q}(\mathbf{x}) = \{1, \ x, \ y, \ \dots, \ y^{p-1}\}^T \tag{20}$$

$$\sup_{\boldsymbol{\sigma}^h \in Q} \|\boldsymbol{\sigma} - \boldsymbol{\sigma}^h\|_e \le Ch^p |\boldsymbol{\sigma}| \tag{21}$$

#### 3.2 Thin plate problems

$$\mathcal{L}(\boldsymbol{M}, w) = \int_{\Omega} \frac{1}{2} \boldsymbol{\kappa}(\boldsymbol{M}) : \boldsymbol{M} d\Omega$$

$$- \int_{\Gamma_{w}} V_{\boldsymbol{n}}(\boldsymbol{M}) \bar{w} d\Gamma + \int_{\Gamma_{\theta}} M_{\boldsymbol{n}\boldsymbol{n}}(\boldsymbol{M}) \bar{\theta}_{\boldsymbol{n}} d\Gamma - P(\boldsymbol{M}) \bar{w}|_{\Gamma_{c}}$$

$$+ \int_{\Gamma_{M}} \theta_{\boldsymbol{n}}(w) (M_{\boldsymbol{n}\boldsymbol{n}} - \bar{M}_{\boldsymbol{n}\boldsymbol{n}}) d\Gamma - \int_{\Gamma_{V}} w(V_{\boldsymbol{n}} - \bar{V}_{\boldsymbol{n}}) d\Gamma$$

$$- w(P - \bar{P})|_{\Gamma_{p}} + \int_{\Omega} w(\nabla \cdot \boldsymbol{M} \cdot \nabla + \bar{q}) d\Omega$$

$$(22)$$

find 
$$\mathbf{M}, w \in H_2$$
 
$$a(\delta \mathbf{M}, \mathbf{M}) + b(\delta \mathbf{M}, w) = g(\delta \mathbf{M}) \quad \forall \delta \mathbf{M} \in L_2$$
$$b(\mathbf{M}, \delta w) = f(\delta w) \quad \forall \delta w \in H_2$$
 (23)

$$a(\delta \mathbf{M}, \mathbf{M}) = \int_{\Omega} \kappa(\delta \mathbf{M}) : \mathbf{M} d\Omega$$
 (24)

# 4 Error analysis for HR gradient smoothing meshfree formulation

### References

- [1] T. Belytschko, Y. Y. Lu, L. Gu, Element-free Galerkin methods 37 (2) 229—256. arXiv:10208278, doi:10.1002/nme.1620370205.
- [2] W. K. Liu, S. Jun, Y. F. Zhang, Reproducing kernel particle methods 20 (8-9) 1081-1106. doi:10.1002/fld.1650200824. URL https://doi.org/10.1002/fld.1650200824http://doi.wiley.com/10.1002/fld.1650200824