

Version: V1.1.2

Security Level: Confidential

Shenzhen Concox Information Technology Co., Ltd.

GPS Tracker Communication Protocol

(JM-VL03)

1



Change History

Author	Date	Version	Reviewed By	Approved By	Description
Bian Yutao	Dec. 9, 2015	1.0.0			Initial release
Bian Yutao	Mar. 3, 2017	1.1.0			Added plug-in module transparent protocol
Bian Yutao	Apr. 14, 2017	1.1.1			Added description of online command replies
Bian Yutao	Oct. 14, 2017	1.1.2			Synchronized audio recording protocol



Contents

ı.	Pro	tocol Packet Format	5
	1. F	Protocol Number Details	5
II.		otocol Packet Details	
		ogin Packet	
	a)	Login Packet	
	b)	Server Responding to Login Packet	
	2. F	leartbeat Packet	8
	a)	The terminal sends a heartbeat packet	8
	b)	Return packet (from server)	9
	3. (SPS Location Packet	10
	a)	Location packet (sent by terminal)	10
	b)	Return packet (from server)	12
	4. L	.BS Multi-Base Extended Information Packet	13
	a)	LBS extended information packet (sent by terminal)	13
	b)	Return packet (from server)	14
	5. <i>A</i>	Alarm Packet	15
	a)	Alarm packet (sent by terminal)	15
	b)	Return packet (from server)	19
	c)	Server returns the Chinese address	19
	d)	Server returns the English address	20
	6. (SPS Address Request Packet	
	a)	Address request packet (sent by terminal)	21
	b)	Server returns the Chinese address	21
	c)	Server returns the English address	22
	7. (Online Command	
	a)	The server sends an online command	
	b)	Return packet (from terminal)	
	c)	Return packet from terminal (Earlier Version)	25
	8. T	ime Calibration Packet	
	a)	Time calibration packet (sent by terminal)	
	b)	Return packet (from server)	
	9. I	nformation Transfer Packet	
	a)	Information transfer packet (sent by terminal)	
	b)	Return packet (from server)	
	10.	GPS Location Packet (4G Base Station, Protocol Number: 0xA0)	
	a)	Location packet (sent by terminal)	
	b)	Return packet (from server)	
	11.	LBS Multi-Base Extended Information Packet (4G Base Station, Protocol Number: 0xA1)	
	a)	LBS extended information packet (sent by terminal)	
	b)	Return packet (from server)	
	12.	Multi-fence Alarm Packet (4G Base Station, Protocol Number: 0xA4)	37



ć	a)	Alarm packet (sent by terminal)	.37
		Return packet (from server)	
(c)	Server returns the Chinese address	.40
(d)	Server returns the English address	.40
III.	A	Attachment	.42
1.	Δ	Attachment 1 CRC-ITU Algorithm in C (Fragments)	.42
2	Δ	Attachment 2 Services Flowchart	43



I. Protocol Packet Format

Format	Length (Byte)	Description
Start Bit	2	0x78 0x78 (1 byte) or 0x79 0x79 (2 bytes)
Packet Length 1 (2)		Length = Protocol number + Information content + Information sequence number (SN) + CRC
Protocol Number	1	It indicates the type of the transfer packet (see the following table for details).
Information Content	N	It is determined by different applications and their "protocol numbers".
Information SN 2		The SN will be automatically added by "1" for each data sending after power-on.
CRC 2		It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
Stop Bit 2 It is fixed at 0x0D 0x0A.		It is fixed at 0x0D 0x0A.

1. Protocol Number Details

Login Packet	0x01
GPS location packet (UTC)	0x22
Heartbeat Packet	0x13
Response to Online Command by Terminal	0x21
Alarm Data (UTC)	0x26
LBS Multi-base Extended Information Packet	0x28
GPS Address Request Packet (UTC)	0x2A
Online Command	0x80
Time Calibration Packet	0x8A
Information Transfer Packet	0x94
Chinese Address Packet	0x17
English Address Packet	0x97
GPS Location Packet (UTC, 4G Base Station Data)	0xA0
LBS Multi-base Extended Information Packet (4G)	0xA1
Multi-fence Alarm Packet (4G)	0xA4



II. Protocol Packet Details

1. Login Packet

Description:

- A login packet is used to establish connection between the terminal and the platform. It carries terminal information.
- When the GPRS link is established, the terminal will send a login packet to the server.
 If a return packet is received within 5 seconds, the link is through; otherwise, the terminal will continue to send login packets.
- If no return packet is received within 5 seconds, the terminal will regard it as response timeout.
- If the timeout counts reach 3, the terminal will enable timed restart.

a) Login Packet

Login Packet

		Length	Details
Start Bit		2	0x78 0x78
Pack	et Length	1	Length = Protocol number + Information content + Information SN + CRC
Protoc	ol Number	1	0x01
Terminal ID		8	Example: If the IMEI is 123456789123456, then the terminal ID is
	Terminarib	0	0x010x230x450x670x890x120x340x56.
Information	Type Identity	2	It is used to judge the type of a terminal.
Content	Code	2	it is used to judge the type of a terminal.
	Time	2	See the following table for details.
	Zone/Language	2	See the following table for details.
Inform	nation SN	2	The SN will be automatically added by "1" for each data sending after
IIIIOII	nation on	2	power-on.
			It is the CRC-ITU value from "Packet Length" to "Information SN". If the
CRC		2	receiver receives a packet that contains a CRC error, it ignores the error
			and discards the packet (See Attachment 1 for algorithm details).
Stop Bit		2	It is fixed at 0x0D 0x0A.

Example data: 78781101075253367890024270003201000512790D0A

Time Zone/Language

	ř—	
	15	
	14	
	13	
One and a half	12	It is a value calculated by avacading the time zone
	11	It is a value calculated by expanding the time zone by 100.
byte (bit15-bit4)	10	by 100.
	9	
	8	
	7	



	6					
	5					
	4					
	3	GMT				
Lower half byte	2	It	is not defined.			
(bit4-bit0)	1	Language select bit	1			
	0	Language select bit	0			

Bit3 0-----Eastern time

1-----Western time

If: the extended bit "0X32 0X00" refers to "GMT+8:00",

then the GTM in Hex is "0X0320", which is converted from "8*100=800".

The extended bit "0X4D 0XD8" refers to "GMT-12:45",

then the GTM in Hex is "0X04,0XDD", which is converted from "12.45*100=1245".

Here, to save 4 bytes, the calculation result shifts to the left for 4 bits cyclically and combines the eastern time, western time, and language select bit.

b) Server Responding to Login Packet

	Length	Details
Start Bit	2	0x78 0x78
Packet Length	1	Length = Protocol number + Information content + Information SN + CRC
Protocol Number	1 0x01	
Information SN	2	The SN will be automatically added by "1" for each data sending after
mormation Siv		power-on.
		It is the CRC-ITU value from "Packet Length" to "Information SN". If the
CRC	2	receiver receives a packet that contains a CRC error, it ignores the error and
		discards the packet (See Attachment 1 for algorithm details).
Stop Bit	2	It is fixed at 0x0D 0x0A.

Example data: 7878050100059FF80D0A



2. Heartbeat Packet

Description:

- The heartbeat packet is used to maintain GPRS link connectivity.
- When the GPRS link is established, the terminal will send a heartbeat packet to the server. If a return packet is received within 5 seconds, the link is through. In this case, new heartbeat packets will be sent in a timed manner.
- If no return packet is received within 5 seconds, the terminal will regard it as response timeout.
- If the timeout counts reach 3, the terminal will enable timed restart.

a) The terminal sends a heartbeat packet.

Heartbeat Packet

		Length	Details
Start Bit		2	0x78 0x78
Packet Length		1	Length = Protocol number + Information content + Information SN + CRC
Prot	ocol Number	1	0x13
	Terminal Information Content	1	See the following table for details.
Information Content	Voltage Level	1	0X00: No power (power off) 0x01: Battery extremely low (making calls or sending SMS's are impossible) 0x02: Battery very low (low battery alert will be triggered) 0x03: Battery low (the device can be used as usual) 0x04: Battery medium 0x05: Battery high 0x06: Battery extremely high
	GSM Signal Strength	1	0x00: No signal 0x01: Extremely weak signal 0x02: Weak signal 0x03: Good signal 0x04: Strong signal
	Language/Extended Port Status	2	Latter bit, where "0x01" refers to Chinese and "0x02" English.
Information SN		2	The SN will be automatically added by "1" for each data sending after power-on.
CRC		2	It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
	Stop Bit	2	It is fixed at 0x0D 0x0A.

Example data: 78780A134004040001000FDCEE0D0A



Terminal information content details

It occupies 1 byte and indicates various status information of the mobile phone.

В	it	Code Connotation
	Bit7	1: Cut off fuel/power
	DILI	0: Restore fuel/power
	Bit6	1: Position fixed
	DIIO	0: Not Positioned
	Bit3-Bit5	Extended bit
BYTE	Bit2	1: Charge with power connected
BITE		0: Charge with no power
		connected
	Bit1	1: ACC on
	DIU	0: ACC off
	Bit0	1: Defense on
	DILU	0: Defense off

b) Return packet (from server)

	Length	Details
Start Bit	2	0x78 0x78
Packet Length	1	Length = Protocol number + Information content + Information SN + CRC
Protocol Number	1	0x13
Information SN	2	The SN will be automatically added by "1" for each data sending after power-on.
		It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver
CRC	2	receives a packet that contains a CRC error, it ignores the error and discards the
		packet (See Attachment 1 for algorithm details).
Stop Bit	2	It is fixed at 0x0D 0x0A.

Example data: 78 78 05 13 01 00 E1 A0 0D 0A



3. GPS Location Packet

Description:

- The location packet carries the location data of the terminal.
- After the GPS module is positioned and the connection is established, the terminal will upload data about fixes by preset rules.
- After the connection is established and there are cache fixes, the terminal will upload these cache fixes.

a) Location packet (sent by terminal)

Location packet

	cation packet	Length	Details
9	Start Bit	2	0x78 0x78
Pac	ket Length	1	Length = Protocol number + Information content + Information SN + CRC
Proto	col Number	1	0x22 (UTC)
	Date and time	6	Year (1 byte) Month (1 byte) Day (1 byte) Hour (1 byte) Minute (1 byte) Second (1 byte) (which must convert to decimal)
	Number of Satellites	1	The first character refers to GPS Information Length; while the second character refers to Number of Satellites that involve in positioning (which must convert to decimal).
	Latitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
	Longitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
	Speed	1	It is a value in decimal.
	Course and Status	2	Convert to a 16-bit binary. Please calculate by bit (see the following table for details).
	MCC	2	Mobile Country Code (convert to decimal)
Information	MNC	1	Mobile Network Code (convert to decimal)
Content	LAC	2	Location Area Code (convert to decimal)
	CellID	3	Cell Tower ID (convert to decimal)
	ACC	1	It indicates the ACC status, where "00" means ACC off and "01" ACC on (unavailable on GT06)
	Data upload mode	1	The mode to upload GPS data points (unavailable on GT06) 0x00: Upload in fixed interval 0x01: Upload at fixed distance 0x02: Upload at cornering point 0x03: Upload upon ACC status change 0x04: Upload the last fix after the status changes from moving to still 0x05: Upload the last valid fix prior to network interruption and reconnection 0x06: Force to upload a GPS fix upon ephemeris refresh 0x07: Upload a fix upon key press



			0x08: Upload location information upon power-on
			0x09: Not used
			0x0A: Upload the last longitude and latitude and update the time after
			the device goes still
			0x0B: Parse the uploaded longitude and latitude packet over WiFi
			0x0C: Upload upon LJDW (immediate position) command
			0x0D: Upload the last longitude and latitude after the device goes still
			0x0E: GPSDUP upload (upload at a fixed interval in still state)
			0x0F: Exit tracking mode
	GPS data	1	0v00: Bool time upload: 0v01: Bo upload
	re-upload	ı	0x00: Real-time upload; 0x01: Re-upload
	Mileage statistics	4	Convert to decimal to get the result (For products without this feature,
	Mileage statistics	4	there is no such place in the packet)
Infor	mation CN	2	The SN will be automatically added by "1" for each data sending after
IIIIOI	Information SN		power-on.
	CRC		It is the CRC-ITU value from "Packet Length" to "Information SN". If the
			receiver receives a packet that contains a CRC error, it ignores the
			error and discards the packet (See Attachment 1 for algorithm details).
S	Stop Bit	2	It is fixed at 0x0D 0x0A.

Example data:


787822220F0C1D023305C9027AC8180C46586000140001CC00287D001F71000001000820860D0 A

i. Status and course details

This occupies 2 bytes to indicate the moving direction of the terminal. The value range is $0-360^{\circ}$. It regards due north as 0° and counts clockwise.

	r rogardo do	
	Bit7	0
	Bit6	0
		GPS
	Bit5	Real-time/Differe
		ntial Positioning
DVTF 1	Bit4	Positioned or Not
BYTE_1	Bit3	East/West
	DIIJ	longitude
	Bit2	South/North
		latitude
	Bit1	
	Bit0	
	Bit7	Course
	Bit6	
BYTE_2	Bit5	
	Bit4	
	Bit3	





For example: the value is 0x15 0x4C, the corresponding binary is 00010101 01001100, + BYTE_1 Bit7 0₊ BYTE_1 Bit6 0₊ BYTE_1 Bit5 0 (real time GPS)₽ BYTE_1 Bit4 1 (GPS has positioned)₽ BYTE_1 Bit3 0 (East Longitude)⊌ 1 (North Latitude)⊬ BYTE_1 Bit2 BYTE_1 Bit1 BYTE_1 Bit0 1₽ BYTE_2 Bit7 0₊ BYTE_2 Bit6 1₽ BYTE_2 Bit5 0 BYTE_2 Bit4 BYTE_2 Bit3 1₽ BYTE_2 Bit2 1₽ BYTE_2 Bit1 0₽ BYTE_2 Bit0 0₊

which means GPS tracking is on, real time GPS, location at north latitude, east longitude and the course is 332° .

b) Return packet (from server)

No return packet is required from the server.



4. LBS Multi-Base Extended Information Packet Description:

• It is used to transmit location information when the terminal doesn't locate.

a) LBS extended information packet (sent by terminal)

		Length	Details
Start Bit		2	0x78 0x78
D 1 (1 (1			Length = Protocol number + Information content +
Packet	Length	1	Information SN + CRC
Protocol	Number	1	0x28
			Year (1 byte) Month (1 byte) Day (1 byte) Hour (1 byte)
	UTC	6	Minute (1 byte) Second (1 byte) (which must convert to
			decimal)
	MCC	2	Mobile Country Code (convert to decimal)
	MNC	1	Mobile Network Code (convert to decimal)
	LAC	2	Location Area Code (convert to decimal)
	CI	3	Cell Tower ID (Cell ID) (convert to decimal)
			It indicates the signal strength of a cell. Its value range is
	RSSI	1	0x00–0xFF, where "0x00" indicates the signal is the
			weakest; while "0xFF" the strongest.
	NLAC1	2	Same as LAC
	NCI1	3	Same as CI
	NRSSI1	1	Same as RSSI
	NLAC2	2	Same as LAC
	NCI2	3	Same as CI
Information	NRSSI2	1	Same as RSSI
Content	NLAC3	2	Same as LAC
	NCI3	3	Same as CI
	NRSSI3	1	Same as RSSI
	NLAC4	2	Same as LAC
	NCI4	3	Same as CI
	NRSSI4	1	Same as RSSI
	NLAC5	2	Same as LAC
	NCI5	3	Same as CI
	NRSSI5	1	Same as RSSI
	NLAC6	2	Same as LAC
	NCI6	3	Same as CI
	NRSSI6	1	Same as RSSI
			It refers to the difference between the actual length of time
	Timing	1	that a signal takes to reach the base station from a mobile
	Advance		station and the length of time that a signal takes to reach
			the base station from a mobile station when the distance



			between the two is "0".
	1	2	Latter bit, where "0x01" refers to Chinese and "0x02"
	Language		English.
Informa	ntion SN	2	The SN will be automatically added by "1" for each data
IIIIOIIIIa	IIION SIN		sending after power-on.
			It is the CRC-ITU value from "Packet Length" to
C	000		"Information SN". If the receiver receives a packet that
CRC		2	contains a CRC error, it ignores the error and discards the
			packet (See Attachment 1 for algorithm details).
Stop Bit		2	It is fixed at 0x0D 0x0A.

Example data:

78783B2810010D02020201CC00287D001F713E287D001F7231287D001E232D287D001F4018000 0000000000000000000000000000Ff00020005B14B0D0A

b) Return packet (from server)No return packet is required from the server.



5. Alarm Packet

Description:

- It is used to transmit the terminal-defined alarm content.
- The server responds to the alarm content received and sends the address parsed from the longitude and latitude to the terminal.
- Then the terminal sends the address received to the preset SOS number.

a) Alarm packet (sent by terminal)

Alarm packet (single geofence)

		Length	Details
	Start Bit	2	0x78 0x78
Pa	Packet Length		Length = Protocol number + Information content + Information SN + CRC
Pro	tocol Number	1	0x26 (UTC)
	Date and time	6	Year (1 byte) Month (1 byte) Day (1 byte) Hour (1 byte) Minute (1 byte) Second (1 byte) (which must convert to decimal)
	Number of Satellites	1	The first character refers to GPS Information Length; while the second character refers to Number of Satellites that involve in positioning (which must convert to decimal).
	Latitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
	Longitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
	Speed	1	It is a value in decimal.
	Course and Status	2	Convert to a 16-bit binary. Please calculate by bit (see GPS location packet for details).
	LBS length	1	Total length of LBS information (Self-length + MCC + MNC + LAC + CellID)
Information	MCC	2	Mobile Country Code (convert to decimal)
Content	MNC	1	Mobile Network Code (convert to decimal)
	LAC	2	Location Area Code (convert to decimal)
	CellID	3	Cell Tower ID (convert to decimal)
	Terminal information	1	See the following table for details.
	Voltage Level	1	0X00: No power (power off) 0x01: Battery extremely low (making calls or sending SMS's are impossible) 0x02: Battery very low (low battery alert will be triggered) 0x03: Battery low (the device can be used as usual) 0x04: Battery medium 0x05: Battery high 0x06: Battery extremely high
	GSM signal strength	1	0x00: No signal 0x01: Extremely weak signal



			0x02: Weak signal
			0x03: Good signal
			0x04: Strong signal
	Alert and language	2	See the following table for details.
	Mileage statistics	4	Convert to decimal to get the result (For products without this
	Mileage statistics	<mark>4</mark>	feature, there is no such place in the packet)
Inf	formation SN	2	The SN will be automatically added by "1" for each data sending
IIII	ormation Siv		after power-on.
			It is the CRC-ITU value from "Packet Length" to "Information SN". If
	ODO		the receiver receives a packet that contains a CRC error, it ignores
CRC		2	the error and discards the packet (See Attachment 1 for algorithm
			details).
	Stop Bit	2	It is fixed at 0x0D 0x0A.

Example data:

787825260F0C1D030B26C9027AC8180C4658600004000901CC00287D001F718004041302000C4 72A0D0A

Alarm packet (multiple geofences)

	arm packet (mu	Length	Details
Start Bit		2	0x78 0x78
Pack	et Length	1	Length = Protocol number + Information content + Information SN + CRC
Protoc	ol Number	1	0x27 (UTC)
	Date and time	6	Year (1 byte) Month (1 byte) Day (1 byte) Hour (1 byte) Minute (1 byte)
	Date and time	0	Second (1 byte) (which must convert to decimal)
	Number of		The first character refers to GPS Information Length; while the second
	Satellites	1	character refers to Number of Satellites that involve in positioning (which
	Satemites		must convert to decimal).
	Latitude	4	It is a value calculated by converting to decimal which is further divided
	Latitude		by 1,800,000.
	Longitude	4	It is a value calculated by converting to decimal which is further divided
	Longitude		by 1,800,000.
Information	Speed	1	It is a value in decimal.
Content	Course and	2	Convert to a 16-bit binary. Please calculate by bit (see GPS location
	Status		packet for details).
	LBS length	1	Total length of LBS information (Self-length + MCC + MNC + LAC +
			CellID)
	MCC	2	Mobile Country Code (convert to decimal)
	MNC	1	Mobile Network Code (convert to decimal)
	LAC	2	Location Area Code (convert to decimal)
	CellID	3	Cell Tower ID (convert to decimal)
	Terminal	1	See the following table for details.
	information	'	dec the following table for details.



	Voltage Level	1	0X00: No power (power off) 0x01: Battery extremely low (making calls or sending SMS's are impossible) 0x02: Battery very low (low battery alert will be triggered) 0x03: Battery low (the device can be used as usual) 0x04: Battery medium 0x05: Battery high 0x06: Battery extremely high
	GSM signal strength	1	0x00: No signal 0x01: Extremely weak signal 0x02: Weak signal 0x03: Good signal 0x04: Strong signal
	Alert and language	2	See the following table for details.
	Fence No.	1	This byte is valid for geofence alerts. 0: Fence No. 1; 1: Fence No. 2;; FF: Invalid
	Mileage statistics	4	Convert to decimal to get the result (For products without this feature, there is no such place in the packet)
Information SN		2	The SN will be automatically added by "1" for each data sending after power-on.
	CRC		It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
Stop Bit		2	It is fixed at 0x0D 0x0A.

i. Terminal information details

Bit		Code Connotation
	D:17	1: Cut off fuel/power
	Bit7	0: Restore fuel/power
	Bit6	1: Position fixed
	Dito	0: Not Positioned
		100: SOS
BYTE	Bit3–Bit5	011: Low battery alert
DIIC		010: Power cutoff
		001: Vibrating alert
		000: Normal
	Bit2	1: Charge with power connected
	DILZ	0: Charge with no power connected
	Bit1	1: ACC on



	0: ACC off
Bit0	1: Defense on
DILU	0: Defense off

ii. Alarm and language details

Alarm and language details					
	0x00: Normal				
	0x01: SOS alert				
	0x02: Power cut alert				
	0x03: Vibrating alert				
	0x04: Entered fence alert				
	0x05: Left fence alert				
	0x06: Speed alert				
	0x09: Tow/theft alert				
	0x0A: Entered GPS blind spot alert				
	0x0B: Left GPS blind spot alert				
	0x0C: Powered on alert				
	0x0D: GPS first fix alert				
	0x0E: Low external battery alert				
	0x0F: External battery low voltage protection alert				
	0x10: SIM changed alert				
	0x11: Powered off alert				
Byte 1	0x12: Airplane mode on following external battery low voltage protection				
	0x13: Tamper alert				
	0x14: Door alert				
	0x15: Powered off due to low battery				
	0x16: Sound-control alert				
	0x17: Rogue base station detected alert				
	0x18: Cover removed alert				
	0x19: Low internal battery alert				
	0x20: Entered deep sleep mode alert				
	0x21: Reserved				
	0x22: Reserved				
	0x23: Fall alert				
	0x29: Harsh acceleration				
	0x2A: Sharp left cornering alert				
	0x2B: Sharp right cornering alert				
	0x2C: Collision alert				
	0x30: Harsh braking				
0x32: Device	0x32: Device unplugged alert				
unplugged alert	0xFF: ACC OFF				



	0xFE: ACC ON
	0x01: Chinese
Byte 2	0x02: English
	0x00: No response from the platform is required

Note: As alerts accumulate, the alerts and alarm bytes in the terminal information may overlap, in which case the alarm byte will be regarded as the baseline. That means when the alarm byte is "0x00", the alarm content in the terminal information can be determined.

b) Return packet (from server)

	Length	Details
Start Bit	2	0x78 0x78
Packet Length	1	Length = Protocol number + Information content + Information SN + CRC
Protocol Number	1	0x26 (UTC)
Information SN	2	The SN will be automatically added by "1" for each data sending after
illioillialioil Siv		power-on.
		It is the CRC-ITU value from "Packet Length" to "Information SN". If the
CRC	2	receiver receives a packet that contains a CRC error, it ignores the error
		and discards the packet (See Attachment 1 for algorithm details).
Stop Bit	2	It is fixed at 0x0D 0x0A.

Example data: 78780526001C9D860D0A

c) Server returns the Chinese address

		Length	Details
St	Start Bit		0x78 0x78
Pack	et Length	1	Length = Protocol number + Information content + Information SN + CRC
Protoc	ol Number	1	0x17
	Length	1	It is the length of the data between the server flag bit and the information
	Lengui	ı	SN.
	Server flag bit	4	It is used by the server to mark the specific alert.
	ALARMSMS	8	Alarm code flag (ASCII)
Information	&&	2	Alarm code flag (ASCII)
Content	Address	М	It is the address parend by the server (LINICODE)
	content		It is the address parsed by the server (UNICODE)
	&&	2	Separator (ASCII)
	Phone number	21	It is "0" for all uploaded alarm packets (ASCII)
	##	2	Separator (ASCII)
Inform	1.6 (1.0)		The SN will be automatically added by "1" for each data sending after
Information SN		2	power-on.
			It is the CRC-ITU value from "Packet Length" to "Information SN". If the
	CRC		receiver receives a packet that contains a CRC error, it ignores the error
			and discards the packet (See Attachment 1 for algorithm details).



Stop Bit	2	It is fixed at 0x0D 0x0A.
----------	---	---------------------------

Example data:

d) Server returns the English address

		Length	Details
St	Start Bit		0x79 0x79
Pack	et Length	2	Length = Protocol number + Information content + Information SN + CRC
Protoc	col Number	1	0x97
	Length	1	It is the length of the data between the server flag bit and the information
	Lengui	'	SN.
	Server flag bit	4	It is used by the server to mark the specific alert.
	ALARMSMS	8	Alarm code flag (ASCII)
Information	&&	2	Alarm code flag (ASCII)
Content	Address	М	It is the address pareed by the compar (LINICODE)
	content	IVI	It is the address parsed by the server (UNICODE)
	&&	2	Separator (ASCII)
	Phone number	21	It is "0" for all uploaded alarm packets (ASCII)
	##	2	Separator (ASCII)
Inform	nation CN	2	The SN will be automatically added by "1" for each data sending after
IIIIOII	Information SN		power-on.
			It is the CRC-ITU value from "Packet Length" to "Information SN". If the
	CRC		receiver receives a packet that contains a CRC error, it ignores the error
			and discards the packet (See Attachment 1 for algorithm details).
St	top Bit	2	It is fixed at 0x0D 0x0A.

Example data:



6. GPS Address Request Packet

Description:

- The user sends an address request command to the terminal, which sends an address request packet to the server to request for address parsing.
- Then the terminal sends the address parsed and returned by the server to the user.

a) Address request packet (sent by terminal)

		Length	Details
St	art Bit	2	0x78 0x78
Pack	et Length	1	Length = Protocol number + Information content + Information SN + CRC
Protoc	ol Number	1	0x2A
	Date and time	6	Year (1 byte) Month (1 byte) Day (1 byte) Hour (1 byte) Minute (1 byte) Second (1 byte) (which must convert to decimal)
	Number of Satellites	1	The first character refers to GPS Information Length; while the second character refers to Number of Satellites that involve in positioning (which must convert to decimal).
	Latitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
Information Content	Longitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
	Speed	1	It is a value in decimal.
	Course and Status	2	Convert to a 16-bit binary. Please calculate by bit (see GPS location packet for details).
	Phone number	21	Phone number
	Alert and language	2	Latter bit, where "0x01" refers to Chinese and "0x02" English.
Information SN		2	The SN will be automatically added by "1" for each data sending after power-on.
CRC		2	It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
St	op Bit	2	It is fixed at 0x0D 0x0A.

Example data:

78782E2A0F0C1D071139CA027AC8000C4658000014D83132353230313335333231373730373900 00000000001002A6ECE0D0A

b) Server returns the Chinese address

	Length	Details
Start Bit	2	0x78 0x78
Packet Length	1	Length = Protocol number + Information content + Information SN +
	ı	CRC



Protoc	ol Number	1	0x17
	Length	1	It is the length of the data between the server flag bit and the information SN.
	Server flag bit	4	It is used by the server to mark the specific alert.
	ADDRESS	7	Address request code flag (ASCII)
Information	&&	2	Separator (ASCII)
Information Content	Address content	M	It is the address parsed by the server (UNICODE)
	&&	2	Separator (ASCII)
	Phone number	21	It is the phone number used by the server to transmit back the terminal request packet (ASCII)
	##	2	Separator (ASCII)
Information SN		2	The SN will be automatically added by "1" for each data sending after power-on.
CRC		2	It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
St	Stop Bit		It is fixed at 0x0D 0x0A.

Example data:

78786E1768000000014144445245535326264F4D7F6E003A5E7F4E1C7701002E60E05DDE5E020 02E60E057CE533A002E4E915C71897F8DEF002E79BB60E05DDE5E025B665927655980B27EA60 03200357C73002E262638363133343231363332363939000000000000000023230016C1EC0D0A

c) Server returns the English address

C) Gerver	Tetarris trie Eriç	Length	Details
St	art Bit	2	0x79 0x79
Packet Length		2	Length = Protocol number + Information content + Information SN + CRC
Protoc	ol Number	1	0x97
	Length	1	It is the length of the data between the server flag bit and the information SN.
	Server flag bit	4	It is used by the server to mark the specific alert.
	ADDRESS	7	Address request code flag (ASCII)
l., f.,	&&	2	Separator (ASCII)
Information Content	Address content	М	It is the address parsed by the server (UNICODE)
	&&	2	Separator (ASCII)
	Phone number	21	It is the phone number used by the server to transmit back the terminal request packet (ASCII)
	##	2	Separator (ASCII)
Information SN		2	The SN will be automatically added by "1" for each data sending after power-on.



CRC	2	It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
Stop Bit	2	It is fixed at 0x0D 0x0A.

Example data:

797900BB9700B50000001414444524553532626004A004D00300031002D0038003900370033003 1003A0053004F005300200061006C00610072006D002E0068007400740070003A002F002F006D00 6100700073002E0067006F006F006C0065002E0063006F006D002F006D006100700073003F0 071003D004E00320032002E00350037003300350036002C0045003100310033002E003900320031 003700312626383631333432313633323639390000000000000000232300168EA50D0A



7. Online Command

Description:

- It is assigned by the server and used to control the terminal to execute tasks.
- The terminal then responds to the server with the execution results.
- a) The server sends an online command.

		Length	Details
Start Bit		2	0x78 0x78
Pack	et Length	1	Length = Protocol number + Information content + Information SN + CRC
Protoc	ol Number	1	0x80
	Length	1	Server flag bit + command content length
	Comicar Floor Dit	4	It is reserved for server recognition. The terminal returns to the server
Information	Server Flag Bit	4	the data it receives as it is in a return packet in binary.
Content	Command	N/I	It is a sharestar string in ACCII It is competible with CMC command
	Content	M	It is a character string in ASCII. It is compatible with SMS command.
	Language	2	Latter bit, where "0x01" refers to Chinese and "0x02" English.
Inform	nation CN	2	The SN will be automatically added by "1" for each data sending after
Information SN		2	power-on.
			It is the CRC-ITU value from "Packet Length" to "Information SN". If the
CRC		2	receiver receives a packet that contains a CRC error, it ignores the error
			and discards the packet (See Attachment 1 for algorithm details).
Stop Bit		2	It is fixed at 0x0D 0x0A.

Example data: 78780E800800000000736F732300016D6A0D0A

b) Return packet (from terminal)

Return packet sent by the terminal (universal command)

		Length	Details
St	art Bit	2	0x79 0x79
Pack	et Length	2	Length = Protocol number + Information content + Information SN + CRC
Protoc	ol Number	1	0x21
	Comios Flog Bit	4	It is reserved for server recognition. The terminal returns to the server the
Information	Server Flag Bit	4	data it receives as it is in a return packet in binary.
Information Content	Code	1	0X01: ASCII coding
Content	Code	1	0x02: UTF 16-BE coding
	Content	М	It refers to the data to be sent (by the coding format).
Inform	Information SN		The SN will be automatically added by "1" for each data sending after
IIIIOII			power-on.
CRC			It is the CRC-ITU value from "Packet Length" to "Information SN". If the
		2	receiver receives a packet that contains a CRC error, it ignores the error
			and discards the packet (See Attachment 1 for algorithm details).
Stop Bit		2	It is fixed at 0x0D 0x0A.



Example data:

7979009D21000000001426174746572793A342E3136562C4E4F524D414C3B20475052533A4C69 6E6B2055703B2047534D205369676E616C204C6576656C3A5374726F6E673B204750533A536561 726368696E6720736174656C6C6974652C20535653205573656420696E206669783A302830292C2 0475053205369676E616C204C6576656C3A3B204143433A4F46463B20446566656E73653A4F464 6002E26DF0D0A

c) Return packet from terminal (Earlier Version)

Return packet sent by the terminal (universal command)

		Length	Details	
St	Start Bit		0x78 0x78	
Pack	et Length	1	Length = Protocol number + Information content + Information SN + CRC	
Protoc	ol Number	1	0x15	
	Length	1	Server flag bit + command content length	
	Comios Flog Bit	4	It is reserved for server recognition. The terminal returns to the server the	
Information	Server Flag Bit	4	data it receives as it is in a return packet in binary.	
Content	Command	М	It is a sharpator string returned in ASCII sading	
	Content	IVI	It is a character string returned in ASCII coding.	
	Language	2	Chinese: 0x00 0x01; English: 0x00 0x02	
Inform	notion CN	2	The SN will be automatically added by "1" for each data sending after	
Iniom	Information SN		power-on.	
CRC			It is the CRC-ITU value from "Packet Length" to "Information SN". If the	
		2	receiver receives a packet that contains a CRC error, it ignores the error	
			and discards the packet (See Attachment 1 for algorithm details).	
Stop Bit		2	It is fixed at 0x0D 0x0A.	

Example data: 78 78 28 15 20 00 00 00 00 53 4F 53 31 3A 31 33 34 32 31 36 33 32 36 39 39 20 53 4F 53 32 3A 20 53 4F 53 33 3A 00 01 00 2A C3 9C 0D 0A



8. Time Calibration Packet

Description:

- The time calibration packet is sent by the terminal to the server upon power-on to request for time synchronization to resolve the issue of time error when the terminal is not positioned.
- The server responds with the correct UTC in correct format.

a) Time calibration packet (sent by terminal)

	Length	Details
Start Bit	2	0x78 0x78
Dooket Longth	4	Length = Protocol number + Information content + Information SN
Packet Length	1	+ CRC
Protocol Number	1	0x8A
Information SN	2	The SN will be automatically added by "1" for each data sending
IIIIOIIIIalioii Siv	2	after power-on.
	2	It is the CRC-ITU value from "Packet Length" to "Information SN".
CRC		If the receiver receives a packet that contains a CRC error, it
ONO	2	ignores the error and discards the packet (See Attachment 1 for
		algorithm details).
Stop Bit	2	It is fixed at 0x0D 0x0A.

Example data: 7878058A000688290D0A

b) Return packet (from server)

		Length	Details
St	art Bit	2	0x78 0x78
Packet Length		1	Length = Protocol number + Information content + Information
racki	et Length	1	SN + CRC
Protoc	ol Number	1	0x8A (UTC)
Information	Date and time	6	Year (1 byte) Month (1 byte) Day (1 byte) Hour (1 byte) Minute (1
Content	Date and time	O	byte) Second (1 byte) (which must convert to decimal)
Information SN		2	The SN will be automatically added by "1" for each data sending
			after power-on.
			It is the CRC-ITU value from "Packet Length" to "Information
	CRC	2	SN". If the receiver receives a packet that contains a CRC error,
CRC		-	it ignores the error and discards the packet (See Attachment 1
			for algorithm details).
Stop Bit		2	It is fixed at 0x0D 0x0A.

Example data: 78780B8A0F0C1D0000150006F0860D0A



9. Information Transfer Packet

Description:

• It is used to transmit all kinds of non-location data.

a) Information transfer packet (sent by terminal)

		Length	Details	
Start Bit		2	0x79 0x79	
Packet Length		2	Length = Protocol number + Information content +	
1 ack	et Lerigiii	2	Information SN + CRC	
Protoc	ol Number	1	0x94	
			00: 00: External battery voltage	
			01–03: Customized	
	Information		04: Terminal status synchronization	
			05: Door status	
	type	1	08: Self-check parameters	
Information	(sub-protocol No.)		09: Information of visible satellites	
Content			0A: ICCID information	
			1BRFID	
			To be added	
		N	Different content will be transmitted according to	
	Data content		different information types. For details, see the table	
			below.	
Inform	nation CN	2	The SN will be automatically added by "1" for each	
IIIIOII	Information SN		data sending after power-on.	
ana.			It is the CRC-ITU value from "Packet Length" to	
		2	"Information SN". If the receiver receives a packet that	
	CRC		contains a CRC error, it ignores the error and discards	
			the packet (See Attachment 1 for algorithm details).	
Stop Bit		2	It is fixed at 0x0D 0x0A.	

Example data:

7979007F9404414C4D313D43343B414C4D323D43433B414C4D333D34433B535441313D43303B4 459443D30313B534F533D2C2C3B43454E5445523D3B46454E43453D46656E63652C4F4E2C302 C32332E3131313830392C3131342E3430393236342C3430302C494E206F72204F55542C303B4D4 946493D4D4946492C4F4646000A061E0D0A

Transferred information content

When the information type is "00", it carries the voltage of the external battery, which is a 2-bit hex. The hex is then converted into a decimal and further divided by 100. Take "0x04,0x9F" for example, it is 1183 in decimal and is 11.83 after being divided by 100, which means the voltage of the external battery is 11.83V.

When the information type is "04", it carries the terminal status synchronization information and is of variable-length in ASCII coding.

Content IDs



Definition	ID
Alarm byte 1	ALM1
Alarm byte 2	ALM2
Alarm byte 3	ALM3
Alarm byte 4	ALM4
Status byte 1	STA1
SOS number	sos
Center number	CENTER
Geofence	FENCE
Fuel/power cutoff status	DYD
Mode	MODE

Bit	Definition	Remarks
bit7	Vibrating alert	1: ON; 0: OFF
bit6	Alert via GPRS	1: ON; 0: OFF
bit5	Alert via call	1: ON; 0: OFF
bit4	Alert via SMS	1: ON; 0: OFF
bit3	Tow/theft alert	1: ON; 0: OFF
bit2	Alert via GPRS	1: ON; 0: OFF
bit1	Alert via call	1: ON; 0: OFF
bit0	Alert via SMS	1: ON; 0: OFF

Bit	Definition	Remarks
bit7	Low internal battery alert	1: ON; 0: OFF
bit6	Alert via GPRS	1: ON; 0: OFF
bit5	Alert via call	1: ON; 0: OFF
bit4	Alert via SMS	1: ON; 0: OFF
bit3	Low external battery alert	1: ON; 0: OFF
bit2	Alert via GPRS	1: ON; 0: OFF
bit1	Alert via call	1: ON; 0: OFF
bit0	Alert via SMS	1: ON; 0: OFF

Bit	Definition	Remarks
bit7	Speed alert	1: ON; 0: OFF
bit6	Alert via GPRS	1: ON; 0: OFF
bit5	Alert via call	1: ON; 0: OFF
bit4	Alert via SMS	1: ON; 0: OFF
bit3	Power cut alert	1: ON; 0: OFF
bit2	Alert via GPRS	1: ON; 0: OFF
bit1	Alert via call	1: ON; 0: OFF



bit0	Alert via SMS	1: ON; 0: OFF	
		,	

Bit	Definition	Remarks
bit7	SOS alert	1: ON; 0: OFF
bit6	Alert via GPRS	1: ON; 0: OFF
bit5	Alert via call	1: ON; 0: OFF
bit4	Alert via SMS	1: ON; 0: OFF
bit3	Voice control alert	1: ON; 0: OFF
bit2	Alert via GPRS	1: ON; 0: OFF
bit1	Alert via call	1: ON; 0: OFF
bit0	Alert via SMS	1: ON; 0: OFF

♦ STA1 (status)

Bit	Definition	Remarks
bit7	Defense status	1: Defense on; 0: Defense off
bit6	Auto defense	1: ON; 0: OFF
bit5	Manual defense	1: ON; 0: OFF
	Remote	
bit4	cancellation of	1: ON; 0: OFF
	defense	
bit3	To be defined	
bit2	To be defined	
bit1	Tamper switch	1: Close; 0: Open
bit0	Tamper alert	1: ON; 0: OFF

♦ Fuel/power cutoff status

Bit	Definition	Remarks
bit7	Undefined	
bit6	Undefined	
bit5	Undefined	
bit4	Undefined	
	Delay execution	
bit3	because the speed is	1: Valid; 0: Invalid
	too high	
	Delay execution	
bit2	because the terminal is	1: Valid; 0: Invalid
	not positioned	
bit1	Cut fuel/power	1: Valid; 0: Invalid
bit0	Connect fuel/power	1: Valid; 0: Invalid

♦ SOS: It transmits in ASCII coding (multiple SOS numbers are separated by commas [,]).



- **♦** Center number: It transmits in ASCII coding.
- **♦** Geofence: It transmits in ASCII coding.
- ♦ Mode: It transmits in ASCII coding (parameters are separated by commas [,]).

Example:

ALM1=FF;ALM2=FF;ALM3=FF;STA1=CO;DYD=01;SOS=12345,2345,5678;CENTER=987654; FENCE=FENCE,ON,0,-22.277120,-113.516763,5,IN,1; MODE= MODE,1,20,500

Note: Not all of the content will be transmitted. The platform can parse according to bits. The content uploaded varies with products.

When the information type is "05", it carries the detection (door detection) status of the external I/O in hex.

Bit	Definition	Remarks
bit7	TBD	
bit6	TBD	
bit5	TBD	
bit4	TBD	
bit3	TBD	
bit2	I/O port status	1: High; 0: Low
bit1	Trigger status	1: Level high; 0: Level low
bit0	Door status	1: ON; 0: OFF

When the information type is "09", it carries the GPS status of the terminal in hex.

GPS module status	1	0x00: No such feature; 0x01: Satellite searching; 0x02: 2D positioning; 0x03: 3D positioning; 0x04: Sleeping
Number of satellites engaged in position fix	1	Based on this the number of transmission strength is determined.
GPS1 strength	1	Strength of GPS location satellite 1
GPS2 strength	1	Strength of visible satellite 2
Number of GPS satellites that are	1	Based on this the number of transmission strength is
visible but not engaged in position fix		determined.
Visible GPS1 Strength	1	Strength of visible satellite 1
Visible GPS2 strength	1	Strength of visible satellite 2
BDS module status	1	0x00: No such feature; 0x01: Satellite searching; 0x02: 2D positioning; 0x03: 3D positioning; 0x04: Sleeping
Number of BDS satellites engaged in	1	This is the basis for determining the volume of satellite
position fix		signal strength.
BDS1 strength	1	Strength of BDS location satellite 1
BDS2 strength	1	Strength of BDS location satellite 2



Number of BDS satellites that are	1	This is the basis for determining the volume of satellite
visible but not engaged in position fix		signal strength.
Visible BDS1 strength	1	Strength of visible satellite 1
Visible BDS2 strength	1	Strength of visible satellite 2
Extended bit length	1	It is reserved for feature expansion. If no extended bit is added, then it is "0x00" (Note: For future feature expansion, you are advised to reserve the extended bit during protocol debugging).
Extended bit	N	It changes as the extended bit length changes. When the extended bit length is "0x00", the extended bit will not be transmitted.

When the information type is "0A", it carries the ICCID information in hex.

IMEL	Example: If the IMEI is 123456789123456, then the terminal ID is	
IMEI 8		0x010x230x450x670x890x120x340x56.
IMSI	0	Example: If the IMEI is 123456789123456, then the terminal ID is
IMSI 8		0x010x230x450x670x890x120x340x56.
ICCID	10	Example: If the ICCID is 12345123456789123456, then the terminal ID is 0x12
ICCID	10	0x34 0x510x230x450x670x890x120x340x56.

When the information type is "0x10", it carries the Brazilian cost counter information in ASCII coding.

Transmitted information:

When the information type is "1B", it carries the RFID information in hex.

RFID 8	Example: If the RFID is 2345678912, then the terminal FRID is	
KFID	0	0x230x450x670x890x12.

b) Return packet (from server)

No response is required from the server.



10. GPS Location Packet (4G Base Station, Protocol Number: 0xA0) Description:

- The location packet carries the location data of the terminal.
- After the GPS module is positioned and the connection is established, the terminal will upload data about fixes by preset rules.
- After the connection is established and there are cache fixes, the terminal will upload these cache fixes.

a) Location packet (sent by terminal)

Location packet

		Length	Details
Start Bit		2	0x78 0x78
Packe	t Length	1	Length = Protocol number + Information content + Information SN + CRC
Protoco	l Number	1	0xA0 (UTC)
	Date and time	6	Year (1 byte) Month (1 byte) Day (1 byte) Hour (1 byte) Minute (1 byte) Second (1 byte) (which must convert to decimal)
	Number of Satellites	1	The first character refers to GPS Information Length; while the second character refers to Number of Satellites that involve in positioning (which must convert to decimal).
	Latitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
	Longitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
	Speed	1	It is a value in decimal.
	Course and Status	2	Convert to a 16-bit binary. Please calculate by bit (see Attachment 3).
	MCC	2	Mobile Country Code (convert to decimal)
Information	MNC	1 (or 2)	Mobile Network Code (see the following note for length detail)
Content	LAC	4	Location Area Code (convert to decimal)
	Cell ID	8	Cell Tower ID (convert to decimal)
	ACC 1		It refers to the ACC status, where "00" means ACC off and "01" ACC on (unavailable on GT06)
	Data upload mode	1	GPS data point upload type (unavailable on GT06) 0x00: Upload in fixed interval 0x01: Upload at fixed distance 0x02: Upload at cornering point 0x03: Upload upon ACC status change 0x04: Upload the last fix after the status changes from moving to still 0x05: Upload the last valid fix prior to network interruption and reconnection 0x06: Force to upload a GPS fix upon ephemeris refresh 0x07: Upload a fix upon key press



			0x08: Upload location information upon power-on 0x09: Not used 0x0A: Upload the last longitude and latitude and update the time after the device goes still 0x0B: Parse the uploaded longitude and latitude packet over WiFi 0x0C: Upload upon LJDW (immediate position) command 0x0D: Upload the last longitude and latitude after the device goes still 0x0E: GPSDUP upload (upload at a fixed interval in still state)
	GPS data re-upload	1	0x00: Real-time upload; 0x01: Re-upload (unavailable on GT06)
	Mileage statistics	4	Convert to decimal to get the result (for products without this feature, there is no such place in the packet)
Informa	ation SN	2	The SN will be automatically added by "1" for each data sending after power-on.
С	RC	2	It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
Sto	p Bit	2	It is fixed at 0x0D 0x0A.

Note: As the MNC of some countries occupies 2 bytes, we use the most significant bit (MSB) in MCC to differentiate the length of MNC. When the MSB in MCC is "1", the length of the MNC is "2". For shipped devices, Bit15 is "0" by default; while for newly-shipped devices, Bit15 is "1".

MCC bits


	Bit	Code Connotation
	Bit15	1: The length of MNC is 2
DVTE0	DILIO	0: The length of MNC is 1
BYTES	Bit0-bit14	MCC information

ii. Status and course details

This occupies 2 bytes to indicate the moving direction of the terminal. The value range is 0–360°. It regards due north as 0° and counts clockwise.

	Bit7	0	
	Bit6	0	
	Bit5	GPS Real-time/Differential Positioning	
BYTE 1	Bit4	Positioned or Not	
DITE_I	Bit3	East/West longitude	
	Bit2	South/North latitude	
	Bit1		
	Bit0	Course	
BYTE_2	Bit7	Course	
	Bit6		





For example: the value is 0x15 0x4C, the corresponding binary is 00010101 01001100,

```
BYTE_1 Bit7
BYTE_1 Bit6
                0
BYTE_1 Bit5
                0 (real time GPS)
BYTE_1 Bit4
                1 (GPS has positioned)
BYTE_1 Bit3
                0 (East Longitude)
BYTE_1 Bit2
                1 (North Latitude)
BYTE_1 Bit1
                0
BYTE_1 Bit0
                1
BYTE_2 Bit7
                0
BYTE_2 Bit6
                1
BYTE_2 Bit5
                              → Course 332° (0101001100 in binary, or 332 in decimal)
                0
BYTE_2 Bit4
                0
BYTE_2 Bit3
                1
BYTE_2 Bit2
                1
BYTE_2 Bit1
                0
BYTE_2 Bit0
                0
```

which means GPS tracking is on, real time GPS, location at north latitude, east longitude and the course is 332°.

b) Return packet (from server)



11. LBS Multi-Base Extended Information Packet (4G Base Station, Protocol Number: 0xA1)

Description:

• It is used to transmit location information when the terminal doesn't locate.

a) LBS extended information packet (sent by terminal)

		Length	Details
Start Bit		2	0x78 0x78
5 1 11 11		,	Length = Protocol number + Information content +
Pack	tet Length	1	Information SN + CRC
Protoc	col Number	1	0xA1
			Year (1 byte) Month (1 byte) Day (1 byte) Hour (1 byte)
	UTC	6	Minute (1 byte) Second (1 byte) (which must convert to
			decimal)
	MCC	2	Mobile Country Code (convert to decimal)
	MNC	1 (or 2)	Mobile Network Code (see the following note for length
	IVIIVO	1 (01 2)	detail)
	LAC	4	Location Area Code (convert to decimal)
	CI	8	Cell Tower ID (convert to decimal)
			It indicates the signal strength of a cell. Its value range is
	RSSI	1	0x00–0xFF, where "0x00" indicates the signal is the
			weakest; while "0xFF" the strongest.
	NLAC1	4	Same as LAC
	NCI1	8	Same as CI
	NRSSI1	1	Same as RSSI
	NLAC2	4	Same as LAC
Information	NCI2	8	Same as CI
Content	NRSSI2	1	Same as RSSI
	NLAC3	4	Same as LAC
	NCI3	8	Same as CI
	NRSSI3	1	Same as RSSI
	NLAC4	4	Same as LAC
	NCI4	8	Same as CI
	NRSSI4	1	Same as RSSI
	NLAC5	4	Same as LAC
	NCI5	8	Same as CI
	NRSSI5	1	Same as RSSI
	NLAC6	4	Same as LAC
	NCI6	8	Same as CI
	NRSSI6	1	Same as RSSI
			It refers to the difference between the actual length of time
	Timing Advance	1	that a signal takes to reach the base station from a mobile
			station and the length of time that a signal takes to reach

			the base station from a mobile station when the distance
			between the two is "0".
	Language	2	0x00 0x01: Chinese; 0x00 0x02: English
Infor	mation CNI	2	The SN will be automatically added by "1" for each data
IIIIOII	Information SN		sending after power-on.
CRC		2	It is the CRC-ITU value from "Packet Length" to
			"Information SN". If the receiver receives a packet that
			contains a CRC error, it ignores the error and discards the
			packet (See Attachment 1 for algorithm details).
S	top Bit	2	It is fixed at 0x0D 0x0A.

Note: As the MNC of some countries occupies 2 bytes, we use the MSB in MCC to differentiate the length of MNC. When the MSB in MCC is "1", the length of the MNC is "2". For shipped devices, Bit15 is "0" by default; while for newly-shipped devices, Bit15 is "1".

MCC bits

	Bit	Code Connotation
	Bit15	1: The length of MNC is 2
BYTES	DILIO	0: The length of MNC is 1
BITES	Bit0-bit14	MCC information

b) Return packet (from server)For 0x28, no return packet is required from the server.



12. Multi-fence Alarm Packet (4G Base Station, Protocol Number: 0xA4) Description:

- It is used to transmit the terminal-defined alarm content.
- The server responds to the alarm content received and sends the address parsed from the longitude and latitude to the terminal.
- Then the terminal sends the address received to the preset SOS number.

a) Alarm packet (sent by terminal)Alarm packet (multiple geofences)

		Length	Details
Start Bit		2	0x78 0x78
Packet Length		1	Length = Protocol number + Information content + Information SN + CRC
Protocol	Number	1	0xA4 (UTC)
	Date and time	6	Year (1 byte) Month (1 byte) Day (1 byte) Hour (1 byte) Minute (1 byte) Second (1 byte) (which must convert to decimal)
	Number of Satellites	1	The first character refers to GPS Information Length; while the second character refers to Number of Satellites that involve in positioning (which must convert to decimal).
	Latitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
	Longitude	4	It is a value calculated by converting to decimal which is further divided by 1,800,000.
	Speed	1	It is a value in decimal.
	Course and Status	2	Convert to a 16-bit binary. Please calculate by bit (see GPS location packet for details).
Information	LBS length	1	Total length of LBS information (Self-length + MCC + MNC + LAC + Cell ID)
Content	MCC	2	Mobile Country Code (convert to decimal)
	MNC	1 (or 2)	Mobile Network Code (see the following note for length detail)
	LAC	4	Location Area Code (convert to decimal)
	Cell ID	8	Cell Tower ID (convert to decimal)
	Terminal information	1	See the following table for details.
	Voltage Level	1	0X00: No power (power off) 0x01: Battery extremely low (making calls or sending SMS's are impossible) 0x02: Battery very low (low battery alert will be triggered) 0x03: Battery low (the device can be used as usual) 0x04: Battery medium 0x05: Battery high 0x06: Battery extremely high



	GSM signal strength	1	0x00: No signal 0x01: Extremely weak signal 0x02: Weak signal 0x03: Good signal 0x04: Strong signal
	Alert and language	2	See the following table for details.
	Fence No.	1	This byte is valid for geofence alerts. 0: Fence No. 1; 1: Fence No. 2;; FF: Invalid
Information SN		2	The SN will be automatically added by "1" for each data sending after power-on.
CRC		2	It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
Stop Bit		2	It is fixed at 0x0D 0x0A.

Note: As the MNC of some countries occupies 2 bytes, we use the MSB in MCC to differentiate the length of MNC. When the MSB in MCC is "1", the length of the MNC is "2". For shipped devices, Bit15 is "0" by default; while for newly-shipped devices, Bit15 is "1".

MCC bits

	Bit	Code Connotation
	Bit15	1: The length of MNC is 2
BYTES	DILIO	0: The length of MNC is 1
	Bit0-bit14	MCC information

iii. Terminal information details

	Bit	Code Connotation
	D#7	1: Cut off fuel/power
	Bit7	0: Restore fuel/power
	Bit6	1: Position fixed
	DILO	0: Not Positioned
		100: SOS
	Bit3–Bit5	011: Low battery alert
BYTE		010: Power cutoff
		001: Vibrating alert
		000: Normal
	Bit2	1: Charge with power connected
	DILZ	0: Charge with no power connected
	Bit1	1: ACC on
	DILI	0: ACC off



PitO	1: Defense on
Ыш	0: Defense off

iv. Alarm and language details

/. Alarm and langu	Alarm and language details					
	0x00: Normal					
	0x01: SOS alert					
	0x02: Power cut alert					
	0x03: Vibrating alert					
	0x04: Entered fence alert					
	0x05: Left fence alert					
	0x06: Speed alert					
	0x09: Tow/theft alert					
	0x0A: Entered GPS blind spot alert					
	0x0B: Left GPS blind spot alert					
	0x0C: Powered on alert					
	0x0D: GPS first fix alert					
	0x0E: Low external battery alert					
	0x0F: External battery low voltage protection alert					
	0x10: SIM changed alert					
	0x11: Powered off alert					
	0x12: Airplane mode on following external battery low voltage protection					
Duda 4	0x13: Tamper alert					
Byte 1	0x14: Door alert					
	0x15: Powered off due to low battery					
	0x16: Sound-control alert					
	0x17: Rogue base station detected alert					
	0x18: Cover removed alert					
	0x19: Low internal battery alert					
	0x20: Entered deep sleep mode alert					
	0x21: Reserved					
	0x22: Reserved					
	0x23: Fall alert					
	0x29: Harsh acceleration					
	0x2A: Sharp left cornering alert					
	0x2B: Sharp right cornering alert					
	0x2C: Collision alert					
	0x30: Harsh braking					
	0x32: Device unplugged alert					
	0xFF: ACC OFF					
	0xFE: ACC ON					



	0x01: Chinese
Byte 2	0x02: English
	0x00: No response from the platform is required

b) Return packet (from server)

	Length	Details
Start Bit	2	0x78 0x78
Packet Length	1	Length = Protocol number + Information content + Information SN + CRC
Protocol Number	1	0x26 (UTC)
Information SN	2	The SN will be automatically added by "1" for each data sending after power-on.
CRC	2	It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
Stop Bit	2	It is fixed at 0x0D 0x0A.

c) Server returns the Chinese address

		Length	Details
Start Bit		2	0x78 0x78
Packet Length		1	Length = Protocol number + Information content + Information SN + CRC
Protocol	Number	1	0x17
	Length		It is the length of the data between the server flag bit and the information SN.
	Server flag bit	4	It is used by the server to mark the specific alert.
	ALARMSMS	8	Alarm code flag (ASCII)
Information	&&	2	Alarm code flag (ASCII)
Content	Address content	M	It is the address parsed by the server (UNICODE)
	&&	2	Separator (ASCII)
	Phone number	21	It is "0" for all uploaded alarm packets (ASCII)
	##	2	Separator (ASCII)
Information SN		2	The SN will be automatically added by "1" for each data sending after power-on.
CRC			It is the CRC-ITU value from "Packet Length" to "Information SN". If
		0	the receiver receives a packet that contains a CRC error, it ignores
		2	the error and discards the packet (See Attachment 1 for algorithm
			details).
Stop Bit		2	It is fixed at 0x0D 0x0A.

d) Server returns the English address

	Length	Details
Start Bit	2	0x79 0x79



Packet Length		2	Length = Protocol number + Information content + Information SN + CRC
Protocol	Protocol Number		0x97
	Length	1	It is the length of the data between the server flag bit and the information SN.
	Server flag bit	4	It is used by the server to mark the specific alert.
lu formation	ALARMSM S	8	Alarm code flag (ASCII)
Information	&&	2	Alarm code flag (ASCII)
Content	Address content	M	It is the address parsed by the server (UNICODE)
	&&	2	Separator (ASCII)
	Phone number	21	It is "0" for all uploaded alarm packets (ASCII)
	##	2	Separator (ASCII)
Information SN		2	The SN will be automatically added by "1" for each data sending after power-on.
CRC		2	It is the CRC-ITU value from "Packet Length" to "Information SN". If the receiver receives a packet that contains a CRC error, it ignores the error and discards the packet (See Attachment 1 for algorithm details).
Stop Bit		2	It is fixed at 0x0D 0x0A.



III. Attachment

Attachment 1 CRC-ITU Algorithm in C (Fragments) staticconstU16crctab16[]= 0X0000, 0X1189, 0X2312, 0X329B, 0X4624, 0X57AD, 0X6536, 0X74BF, 0X8C48, 0X9DC1, 0XAF5A, 0XBED3, 0XCA6C, 0XDBE5, 0XE97E, 0XF8F7, 0X1081, 0X0108, 0X3393, 0X221A, 0X56A5, 0X472C, 0X75B7, 0X643E, 0X9CC9, 0X8D40, 0XBFDB, 0XAE52, OXDAED, OXCB64, OXF9FF, OXE876. 0X2102, 0X308B, 0X0210, 0X1399, 0X6726, 0X76AF, 0X4434, 0X55BD, 0XAD4A, 0XBCC3, 0X8E58, 0X9FD1, 0XEB6E, 0XFAE7, 0XC87C, 0XD9F5, 0X3183, 0X200A, 0X1291, 0X0318, 0X77A7, 0X662E, 0X54B5, 0X453C 0XBDCB, 0XAC42, 0X9ED9, 0X8F50, 0XFBEF, 0XEA66, 0XD8FD, 0XC974, 0X4204, 0X538D, 0X6116, 0X709F, 0X0420, 0X15A9, 0X2732, 0X36BB, 0XCE4C, 0XDFC5, 0XED5E, 0XFCD7, 0X8868, 0X99E1, 0XAB7A, 0XBAF3, 0X5285, 0X430C, 0X7197, 0X601E, 0X14A1, 0X0528, 0X37B3, 0X263A, 0XDECD, 0XCF44, 0XFDDF, 0XEC56, 0X98E9, 0X8960, 0XBBFB, 0XAA72, 0X6306, 0X728F, 0X4014, 0X519D, 0X2522, 0X34AB, 0X0630, 0X17B9 0XEF4E, 0XFEC7, 0XCC5C, 0XDDD5, 0XA96A, 0XB8E3, 0X8A78, 0X9BF1, 0X7387, 0X620E, 0X5095, 0X411C, 0X35A3, 0X242A, 0X16B1, 0X0738, 0XFFCF, 0XEE46, 0XDCDD, 0XCD54, 0XB9EB, 0XA862, 0X9AF9, 0X8B70, 0X8408, 0X9581, 0XA71A, 0XB693, 0XC22C, 0XD3A5, 0XE13E, 0XF0B7, 0X0840, 0X19C9, 0X2B52, 0X3ADB, 0X4E64, 0X5FED, 0X6D76, 0X7CFF, 0X9489, 0X8500, 0XB79B, 0XA612, 0XD2AD, 0XC324, 0XF1BF, 0XE036, 0X18C1, 0X0948, 0X3BD3, 0X2A5A, 0X5EE5, 0X4F6C, 0X7DF7, 0X6C7E, 0XA50A, 0XB483, 0X8618, 0X9791, 0XE32E, 0XF2A7, 0XC03C, 0XD1B5, 0X2942, 0X38CB, 0X0A50, 0X1BD9, 0X6F66, 0X7EEF, 0X4C74, 0X5DFD, 0XB58B, 0XA402, 0X9699, 0X8710, 0XF3AF, 0XE226, 0XD0BD, 0XC134, 0X39C3, 0X284A, 0X1AD1, 0X0B58, 0X7FE7, 0X6E6E, 0X5CF5, 0X4D7C, 0XC60C, 0XD785, 0XE51E, 0XF497, 0X8028, 0X91A1, 0XA33A, 0XB2B3, 0X4A44, 0X5BCD, 0X6956, 0X78DF, 0X0C60, 0X1DE9, 0X2F72, 0X3EFB, 0XD68D, 0XC704, 0XF59F, 0XE416, 0X90A9, 0X8120, 0XB3BB, 0XA232, 0X5AC5, 0X4B4C, 0X79D7, 0X685E, 0X1CE1, 0X0D68, 0X3FF3, 0X2E7A, 0XE70E, 0XF687, 0XC41C, 0XD595, 0XA12A, 0XB0A3, 0X8238, 0X93B1, 0X6B46, 0X7ACF, 0X4854, 0X59DD, 0X2D62, 0X3CEB, 0X0E70, 0X1FF9, 0XF78F, 0XE606, 0XD49D, 0XC514, 0XB1AB, 0XA022, 0X92B9, 0X8330, 0X7BC7, 0X6A4E, 0X58D5, 0X495C, 0X3DE3, 0X2C6A, 0X1EF1, 0X0F78, **}**; Calculate 16-bit CRC of the given-length data. U16GetCrc16(constU8*pData,intnLength) U16fcs=0xffff;//Initialize while(nLength>0){ fcs=(fcs>>8)^crctab16[(fcs^*pData)&0xff]; nLength--; pData++; return ~fcs; Negate



2. Attachment 2 Services Flowchart

