RISC-V OpenSBI v0.6

Generated by Doxygen 1.8.13

Contents

1	README	1
2	OpenSBI Contribution Guideline	5
3	OpenSBI Platform Support Guideline	7
4	OpenSBI Library Usage	9
5	OpenSBI Platform Firmwares	11
6	OpenSBI Firmware with Dynamic Information *FW_DYNAMIC*	13
7	OpenSBI Firmware with Jump Address *FW_JUMP*	15
8	OpenSBI Firmware with Payload *FW_PAYLOAD*	17
9	Linux as a direct payload to OpenSBI	19
10	U-Boot as a payload to OpenSBI	21
11	Andes AE350 SoC Platform	23
12	Ariane FPGA SoC Platform	25
13	OpenSBI Supported Platforms	27
14	QEMU RISC-V Virt Machine Platform	29
15	SiFive FU540 SoC Platform	33
16	Spike Simulator Platform	37

ii CONTENTS

17	T-HE	AD C91	0 Process	SO	r																			39
18	Data	Structu	ıre Index																					41
	18.1	Data S	tructures													 								41
19	File I	Index																						43
	19.1	File Lis	t													 								43
20	Data	Structu	ure Docum	ne	nt	atio	on																	45
	20.1	atomic	_t Struct R	Ref	fer	enc	e.									 						 		45
		20.1.1	Field Doo	cui	mε	enta	atioı	n								 						 		45
			20.1.1.1	C	OL	unte	er.									 						 		45
	20.2	fdt_hea	ader Struct	t F	₹ef	ere	nce	Э								 						 		45
		20.2.1	Field Doo	cui	me	enta	ation	n								 						 		46
			20.2.1.1	b	000	ot_c	pui	id_	_ph	างร						 						 		46
			20.2.1.2	la	ast	t_c	omp	p_\	vei	rsic	on					 						 		46
			20.2.1.3	n	na	gic										 						 		46
			20.2.1.4	C	off_	_dt_	_str	ing	дs							 						 		46
			20.2.1.5	C	off_	_dt_	_str	uc	t							 						 		46
			20.2.1.6	C	off_	_me	em_	_rs	vn	nap)					 						 		47
			20.2.1.7	s	size	e_c	lt_s	trir	ngs	s.	-					 						 		47
			20.2.1.8	S	siz(e_c	lt_s	tru	ıct							 						 		47
			20.2.1.9	t	ota	alsi	ze									 						 		47
			20.2.1.10) v	⁄er	sio	n .									 						 		47
	20.3	fdt_noc	de_header	r S	itru	ıct	Ref	ere	end	се						 						 		47
		20.3.1	Field Doo	cui	me	enta	atioi	n								 						 		47
			20.3.1.1	r	nar	ne										 						 		48
			20.3.1.2	t	ag											 						 		48
	20.4	fdt_pro	perty Stru	ıct	Re	efer	renc	се								 						 		48
		20.4.1	Field Doo	cui	mε	enta	atioı	n								 						 		48
			20.4.1.1	C	dat	a										 						 		48
			20.4.1.2	le	en											 						 		48

	20.4.1.3 nameoff	49
	20.4.1.4 tag	49
20.5 fdt_res	erve_entry Struct Reference	49
20.5.1	Field Documentation	49
	20.5.1.1 address	49
	20.5.1.2 size	49
20.6 fw_dyı	amic_info Struct Reference	49
20.6.1	Detailed Description	50
20.6.2	Field Documentation	50
	20.6.2.1 boot_hart	50
	20.6.2.2 magic	50
	20.6.2.3 next_addr	50
	20.6.2.4 next_mode	50
	20.6.2.5 options	51
	20.6.2.6 version	51
20.7 sbi_dli	st Struct Reference	51
20.7.1	Field Documentation	51
	20.7.1.1 next	51
	20.7.1.2 prev	51
20.8 sbi_ed	all_extension Struct Reference	52
20.8.1	Field Documentation	52
	20.8.1.1 extid_end	52
	20.8.1.2 extid_start	52
	20.8.1.3 handle	52
	20.8.1.4 head	52
	20.8.1.5 probe	53
20.9 sbi_fife	Struct Reference	53
20.9.1	Field Documentation	53
	20.9.1.1 avail	53
	20.9.1.2 entry_size	53

iv CONTENTS

20.9.1.3 num_entries	53
20.9.1.4 qlock	54
20.9.1.5 queue	54
20.9.1.6 tail	54
20.10sbi_ipi_event_ops Struct Reference	54
20.10.1 Detailed Description	54
20.10.2 Field Documentation	54
20.10.2.1 name	54
20.10.2.2 process	55
20.10.2.3 sync	55
20.10.2.4 update	55
20.11 sbi_platform Struct Reference	55
20.11.1 Detailed Description	55
20.11.2 Field Documentation	56
20.11.2.1 disabled_hart_mask	56
20.11.2.2 features	56
20.11.2.3 firmware_context	56
20.11.2.4 hart_count	56
20.11.2.5 hart_stack_size	56
20.11.2.6 name	56
20.11.2.7 opensbi_version	56
20.11.2.8 platform_ops_addr	57
20.11.2.9 platform_version	57
20.12sbi_platform_operations Struct Reference	57
20.12.1 Detailed Description	58
20.12.2 Field Documentation	58
20.12.2.1 console_getc	58
20.12.2.2 console_init	58
20.12.2.3 console_putc	58
20.12.2.4 early_exit	58

20.12.2.5 early_init	58
20.12.2.6 final_exit	58
20.12.2.7 final_init	59
20.12.2.8 get_tlbr_flush_limit	59
20.12.2.9 ipi_clear	59
20.12.2.10pi_exit	59
20.12.2.11ipi_init	59
20.12.2.12pi_send	59
20.12.2.13rqchip_exit	59
20.12.2.14rqchip_init	59
20.12.2.15misa_check_extension	60
20.12.2.16misa_get_xlen	60
20.12.2.17pmp_region_count	60
20.12.2.1&pmp_region_info	60
20.12.2.19system_reboot	60
20.12.2.20system_shutdown	60
20.12.2.21timer_event_start	60
20.12.2.22timer_event_stop	61
20.12.2.23timer_exit	61
20.12.2.24timer_init	61
20.12.2.25timer_value	61
20.12.2.26vendor_ext_check	61
20.12.2.27vendor_ext_provider	61
20.13sbi_scratch Struct Reference	61
20.13.1 Detailed Description	62
20.13.2 Field Documentation	62
20.13.2.1 fw_size	62
20.13.2.2 fw_start	62
20.13.2.3 hartid_to_scratch	62
20.13.2.4 next_addr	62

vi

20.13.2.6 next_mode 63 20.13.2.7 options 63 20.13.2.8 platform_addr 63 20.13.2.10 warmboot_addr 63 20.14.2.10 warmboot_addr 63 20.14.1.1 leid Documentation 64 20.14.1.1 asid 64 20.14.1.2 shart_mask 64 20.14.1.3 size 64 20.14.1.4 start 64 20.14.1.5 type 64 20.15.1 Detailed Description 65 20.15.1 Detailed Description 65 20.15.2 lield Documentation 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.16.2 Field Documentation 67 20.16.2 Field Documentation 67	20.13.2.5 next_arg1	 63
20.13.2.8 platform_addr 63 20.13.2.9 tmp0 63 20.13.2.10varmboot_addr 63 20.14.bib_tib_info Struct Reference 63 20.14.1 Field Documentation 64 20.14.1.1 asid 64 20.14.1.2 shart_mask 64 20.14.1.3 size 64 20.14.1.4 start 64 20.15.1b type 64 20.15.1b trap_info Struct Reference 65 20.15.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 tval 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.16.2.1 totalled Description 67 20.16.2 Field Documentation 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.13.2.6 next_mode	 63
20.13.2.9 tmp0 63 20.13.2.10warmboot_addr 63 20.14sbi_tib_info Struct Reference 63 20.14.1 Field Documentation 64 20.14.1.1 asid 64 20.14.1.2 shart_mask 64 20.14.1.3 size 64 20.14.1.4 start 64 20.14.1.5 type 64 20.15.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2 Field Documentation 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.13.2.7 options	 63
20.13.2.10warmboot_addr 63 20.14sbi_tlb_info Struct Reference 63 20.14.1 Field Documentation 64 20.14.1.1 asid 64 20.14.1.2 shart_mask 64 20.14.1.3 size 64 20.14.1.5 type 64 20.15.1.5 type 64 20.15.2.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.1.Detailed Description 67 20.16.2.Field Documentation 67 20.16.2.Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67 20.16.2.5 a4 67	20.13.2.8 platform_addr	 63
20.14sbi_tlb_info Struct Reference 63 20.14.1 Field Documentation 64 20.14.1.1 asid 64 20.14.1.2 shart_mask 64 20.14.1.3 size 64 20.14.1.4 start 64 20.14.1.5 type 64 20.15.1 petalled Description 65 20.15.2 Field Documentation 65 20.15.2 Field Documentation 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67 20.16.2.5 a4 67	20.13.2.9 tmp0	 63
20.14.1 Field Documentation 64 20.14.1.1 asid 64 20.14.1.2 shart_mask 64 20.14.1.3 size 64 20.14.1.4 start 64 20.15.1.5 type 64 20.15.2.6 lidl Description 65 20.15.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.2.1 ap 67 20.16.2.2 at 67 20.16.2.3 az 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.13.2.10warmboot_addr	 63
20.14.1.1 asid. 64 20.14.1.2 shart_mask 64 20.14.1.3 size. 64 20.14.1.4 start 64 20.14.1.5 type 64 20.15.bi_trap_info Struct Reference 65 20.15.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.2.1 ap 66 20.16.2 Field Documentation 67 20.16.2 Field Documentation 67 20.16.2.2 al 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.14sbi_tlb_info Struct Reference	 63
20.14.1.2 shart_mask 64 20.14.1.3 size 64 20.14.1.4 start 64 20.14.1.5 type 64 20.15.1 Detailed Description 65 20.15.1 Detailed Description 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.14.1 Field Documentation	 64
20.14.1.3 size 64 20.14.1.4 start 64 20.15.bi_trap_info Struct Reference 65 20.15.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.14.1.1 asid	 64
20.14.1.4 start 64 20.15.5bj_trap_info Struct Reference 65 20.15.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.14.1.2 shart_mask	 64
20.14.1.5 type 64 20.15sbi_trap_info Struct Reference 65 20.15.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.14.1.3 size	 64
20.15sbi_trap_info Struct Reference 65 20.15.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.2.5 tval2 Constitute Reference 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.14.1.4 start	 64
20.15.1 Detailed Description 65 20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.9 Field Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.14.1.5 type	 64
20.15.2 Field Documentation 65 20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16sbi_trap_regs Struct Reference 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.15sbi_trap_info Struct Reference	 65
20.15.2.1 cause 65 20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.2bi_trap_regs Struct Reference 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.15.1 Detailed Description	 65
20.15.2.2 epc 65 20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.15.2 Field Documentation	 65
20.15.2.3 tinst 65 20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.15.2.1 cause	 65
20.15.2.4 tval 65 20.15.2.5 tval2 66 20.16sbi_trap_regs Struct Reference 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.15.2.2 epc	 65
20.15.2.5 tval2 66 20.16sbi_trap_regs Struct Reference 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.15.2.3 tinst	 65
20.16sbi_trap_regs Struct Reference 66 20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.15.2.4 tval	 65
20.16.1 Detailed Description 67 20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.15.2.5 tval2	 66
20.16.2 Field Documentation 67 20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.16sbi_trap_regs Struct Reference	 66
20.16.2.1 a0 67 20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.16.1 Detailed Description	 67
20.16.2.2 a1 67 20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.16.2 Field Documentation	 67
20.16.2.3 a2 67 20.16.2.4 a3 67 20.16.2.5 a4 67	20.16.2.1 a0	 67
20.16.2.4 a3 67 20.16.2.5 a4 67	20.16.2.2 a1	 67
20.16.2.5 a4	20.16.2.3 a2	 67
	20.16.2.4 a3	 67
20.16.2.6 a5	20.16.2.5 a4	 67
	20.16.2.6 a5	 67

CONTENTS vii

;	20.16.2.7 a6	68
:	20.16.2.8 a7	68
:	20.16.2.9 gp	68
:	20.16.2.10mepc	68
:	20.16.2.11mstatus	68
:	20.16.2.12mstatusH	68
:	20.16.2.13ra	68
:	20.16.2.14s0	68
:	20.16.2.15s1	69
:	20.16.2.16s10	69
:	20.16.2.17s11	69
:	20.16.2.18s2	69
:	20.16.2.19s3	69
:	20.16.2.20s4	69
:	20.16.2.21s5	69
:	20.16.2.22s6	69
:	20.16.2.23s7	70
;	20.16.2.2468	70
;	20.16.2.2569	70
:	20.16.2.26sp	70
:	20.16.2.2710	70
:	20.16.2.281	70
:	20.16.2.292	70
:	20.16.2.303	70
:	20.16.2.31t4	71
:	20.16.2.325	71
:	20.16.2.336	71
:	20.16.2.34tp	71
:	20.16.2.35zero	71
20.17spinlock	x_t Struct Reference	71
20.17.1	Field Documentation	71
:	20.17.1.1 lock	71

viii CONTENTS

21	File Documentation	73
	21.1 docs/contributing.md File Reference	73
	21.2 docs/firmware/fw.md File Reference	73
	21.3 docs/firmware/fw_dynamic.md File Reference	73
	21.4 docs/firmware/fw_jump.md File Reference	73
	21.5 docs/firmware/fw_payload.md File Reference	73
	21.6 docs/firmware/payload_linux.md File Reference	73
	21.7 docs/firmware/payload_uboot.md File Reference	73
	21.8 docs/library_usage.md File Reference	73
	21.9 docs/platform/andes-ae350.md File Reference	73
	21.10docs/platform/ariane-fpga.md File Reference	73
	21.11docs/platform/platform.md File Reference	73
	21.12docs/platform/qemu_virt.md File Reference	73
	21.13docs/platform/sifive_fu540.md File Reference	74
	21.14docs/platform/spike.md File Reference	74
	21.15docs/platform/thead-c910.md File Reference	74
	21.16docs/platform_guide.md File Reference	74
	21.17include/sbi/fw_dynamic.h File Reference	74
	21.17.1 Macro Definition Documentation	75
	21.17.1.1 FW_DYNAMIC_INFO_BOOT_HART_OFFSET	75
	21.17.1.2 FW_DYNAMIC_INFO_MAGIC_OFFSET	75
	21.17.1.3 FW_DYNAMIC_INFO_MAGIC_VALUE	75
	21.17.1.4 FW_DYNAMIC_INFO_NEXT_ADDR_OFFSET	75
	21.17.1.5 FW_DYNAMIC_INFO_NEXT_MODE_M	75
	21.17.1.6 FW_DYNAMIC_INFO_NEXT_MODE_OFFSET	75
	21.17.1.7 FW_DYNAMIC_INFO_NEXT_MODE_S	76
	21.17.1.8 FW_DYNAMIC_INFO_NEXT_MODE_U	76
	21.17.1.9 FW_DYNAMIC_INFO_OPTIONS_OFFSET	76
	21.17.1.10FW_DYNAMIC_INFO_VERSION_MAX	76
	21.17.1.11FW_DYNAMIC_INFO_VERSION_OFFSET	76

21.17.2 Variable Documentation	76
21.17.2.1packed	76
21.18include/sbi/riscv_asm.h File Reference	77
21.18.1 Macro Definition Documentation	78
21.18.1.1ASM_STR	78
21.18.1.2 csr_clear	78
21.18.1.3 csr_read	78
21.18.1.4 csr_read_clear	79
21.18.1.5 csr_read_set	79
21.18.1.6 csr_set	79
21.18.1.7 csr_swap	80
21.18.1.8 csr_write	80
21.18.1.9 LGREG	80
21.18.1.10misa_extension	80
21.18.1.11PAGE_MASK	81
21.18.1.12PAGE_SHIFT	81
21.18.1.13PAGE_SIZE	81
21.18.1.14REG_L	81
21.18.1.15REG_S	81
21.18.1.16SZREG	81
21.18.1.17wfi	81
21.18.2 Function Documentation	82
21.18.2.1 csr_read_num()	82
21.18.2.2 csr_write_num()	82
21.18.2.3 misa_extension_imp()	82
21.18.2.4 misa_string()	83
21.18.2.5 misa_xlen()	84
21.18.2.6 pmp_get()	84
21.18.2.7 pmp_set()	85
21.19include/sbi/riscv_atomic.h File Reference	86

21.19.1 Macro Definition Documentation	 86
21.19.1.1 ATOMIC_INIT	 86
21.19.1.2 ATOMIC_INITIALIZER	 87
21.19.2 Function Documentation	 87
21.19.2.1 arch_atomic_cmpxchg()	 87
21.19.2.2 arch_atomic_xchg()	 87
21.19.2.3 atomic_add_return()	 87
21.19.2.4 atomic_clear_bit()	 88
21.19.2.5 atomic_raw_clear_bit()	 88
21.19.2.6 atomic_raw_set_bit()	 88
21.19.2.7 atomic_raw_xchg_uint()	 89
21.19.2.8 atomic_raw_xchg_ulong()	 89
21.19.2.9 atomic_read()	 89
21.19.2.10atomic_set_bit()	 90
21.19.2.11atomic_sub_return()	 90
21.19.2.12atomic_write()	 90
21.20include/sbi/riscv_barrier.h File Reference	 90
21.20.1 Macro Definition Documentation	 91
21.20.1.1smp_load_acquire	 91
21.20.1.2smp_store_release	 91
21.20.1.3 cpu_relax	 92
21.20.1.4 mb	 92
21.20.1.5 RISCV_ACQUIRE_BARRIER	 92
21.20.1.6 RISCV_FENCE	 92
21.20.1.7 RISCV_RELEASE_BARRIER	 92
21.20.1.8 rmb	 92
21.20.1.9 smp_mb	 92
21.20.1.10smp_rmb	 93
21.20.1.11smp_wmb	93
21.20.1.12wmb	 93

CONTENTS xi

21.21 include/sbi/riscv_encoding.h File Reference	93
21.21.1 Macro Definition Documentation	102
21.21.1.1 CAUSE_BREAKPOINT	102
21.21.1.2 CAUSE_FETCH_ACCESS	102
21.21.1.3 CAUSE_FETCH_GUEST_PAGE_FAULT	103
21.21.1.4 CAUSE_FETCH_PAGE_FAULT	103
21.21.1.5 CAUSE_HYPERVISOR_ECALL	103
21.21.1.6 CAUSE_ILLEGAL_INSTRUCTION	103
21.21.1.7 CAUSE_LOAD_ACCESS	103
21.21.1.8 CAUSE_LOAD_GUEST_PAGE_FAULT	103
21.21.1.9 CAUSE_LOAD_PAGE_FAULT	103
21.21.1.1©AUSE_MACHINE_ECALL	103
21.21.1.11CAUSE_MISALIGNED_FETCH	104
21.21.1.12CAUSE_MISALIGNED_LOAD	104
21.21.1.13CAUSE_MISALIGNED_STORE	104
21.21.1.14CAUSE_STORE_ACCESS	104
21.21.1.15CAUSE_STORE_GUEST_PAGE_FAULT	104
21.21.1.1@AUSE_STORE_PAGE_FAULT	104
21.21.1.17CAUSE_SUPERVISOR_ECALL	104
21.21.1.18CAUSE_USER_ECALL	104
21.21.1.19CSR_CYCLE	105
21.21.1.20CSR_CYCLEH	105
21.21.1.21CSR_DCSR	105
21.21.1.22CSR_DPC	105
21.21.1.23CSR_DSCRATCH	105
21.21.1.24CSR_FCSR	105
21.21.1.25CSR_FFLAGS	105
21.21.1.2@SR_FRM	105
21.21.1.27CSR_HCOUNTERNEN	106
21.21.1.28CSR_HEDELEG	106

xii CONTENTS

21.21.1.29CSR_HGATP
21.21.1.30CSR_HGEIE
21.21.1.31CSR_HGEIP
21.21.1.32CSR_HIDELEG
21.21.1.33CSR_HIE
21.21.1.34CSR_HIP
21.21.1.35CSR_HPMCOUNTER10
21.21.1.36CSR_HPMCOUNTER10H
21.21.1.37CSR_HPMCOUNTER11
21.21.1.38CSR_HPMCOUNTER11H
21.21.1.39CSR_HPMCOUNTER12
21.21.1.40CSR_HPMCOUNTER12H
21.21.1.41CSR_HPMCOUNTER13
21.21.1.42CSR_HPMCOUNTER13H
21.21.1.43CSR_HPMCOUNTER14
21.21.1.44CSR_HPMCOUNTER14H
21.21.1.45CSR_HPMCOUNTER15
21.21.1.46CSR_HPMCOUNTER15H
21.21.1.47CSR_HPMCOUNTER16
21.21.1.48CSR_HPMCOUNTER16H
21.21.1.49CSR_HPMCOUNTER17
21.21.1.50CSR_HPMCOUNTER17H
21.21.1.51CSR_HPMCOUNTER18
21.21.1.52CSR_HPMCOUNTER18H
21.21.1.53CSR_HPMCOUNTER19
21.21.1.54CSR_HPMCOUNTER19H
21.21.1.55CSR_HPMCOUNTER20
21.21.1.5@SR_HPMCOUNTER20H
21.21.1.57CSR_HPMCOUNTER21
21.21.1.58CSR_HPMCOUNTER21H

CONTENTS xiii

21.21.1.59CSR_HPMCOUNTER22
21.21.1.60CSR_HPMCOUNTER22H
21.21.1.61CSR_HPMCOUNTER23
21.21.1.62CSR_HPMCOUNTER23H
21.21.1.63CSR_HPMCOUNTER24
21.21.1.64CSR_HPMCOUNTER24H
21.21.1.65CSR_HPMCOUNTER25
21.21.1.66CSR_HPMCOUNTER25H
21.21.1.67CSR_HPMCOUNTER26
21.21.1.68CSR_HPMCOUNTER26H
21.21.1.69CSR_HPMCOUNTER27
21.21.1.70CSR_HPMCOUNTER27H
21.21.1.71CSR_HPMCOUNTER28
21.21.1.72CSR_HPMCOUNTER28H
21.21.1.73CSR_HPMCOUNTER29
21.21.1.74CSR_HPMCOUNTER29H
21.21.1.75CSR_HPMCOUNTER3
21.21.1.76CSR_HPMCOUNTER30
21.21.1.77CSR_HPMCOUNTER30H
21.21.1.78CSR_HPMCOUNTER31
21.21.1.79CSR_HPMCOUNTER31H
21.21.1.80CSR_HPMCOUNTER3H
21.21.1.81CSR_HPMCOUNTER4
21.21.1.82CSR_HPMCOUNTER4H
21.21.1.83CSR_HPMCOUNTER5
21.21.1.84CSR_HPMCOUNTER5H
21.21.1.85CSR_HPMCOUNTER6
21.21.1.86CSR_HPMCOUNTER6H
21.21.1.87CSR_HPMCOUNTER7
21.21.1.88CSR_HPMCOUNTER7H

xiv CONTENTS

21.21.1.89CSR_HPMCOUNTER8
21.21.1.90CSR_HPMCOUNTER8H
21.21.1.91CSR_HPMCOUNTER9
21.21.1.92CSR_HPMCOUNTER9H
21.21.1.93CSR_HSTATUS
21.21.1.94CSR_HTIMEDELTA
21.21.1.95CSR_HTIMEDELTAH
21.21.1.96CSR_HTINST
21.21.1.97CSR_HTVAL
21.21.1.98CSR_INSTRET
21.21.1.99CSR_INSTRETH
21.21.1.100SR_MARCHID
21.21.1.10CSR_MCAUSE
21.21.1.102SR_MCOUNTEREN
21.21.1.103SR_MCYCLE
21.21.1.10@SR_MCYCLEH
21.21.1.10 5 SR_MEDELEG
21.21.1.106SR_MEPC
21.21.1.107SR_MHARTID
21.21.1.108SR_MHPMCOUNTER10
21.21.1.109SR_MHPMCOUNTER10H
21.21.1.110SR_MHPMCOUNTER11
21.21.1.11 C SR_MHPMCOUNTER11H
21.21.1.11 @ SR_MHPMCOUNTER12
21.21.1.11 G SR_MHPMCOUNTER12H
21.21.1.11 @ SR_MHPMCOUNTER13
21.21.1.11 6 SR_MHPMCOUNTER13H
21.21.1.11 6 SR_MHPMCOUNTER14
21.21.1.11 © SR_MHPMCOUNTER14H
21.21.1.11 8 SR_MHPMCOUNTER15

CONTENTS xv

21.21.1.11 0 SR_MHPMCOUNTER15H	117
21.21.1.120SR_MHPMCOUNTER16	117
21.21.1.12 3 SR_MHPMCOUNTER16H	117
21.21.1.12 2 SR_MHPMCOUNTER17	117
21.21.1.123SR_MHPMCOUNTER17H	118
21.21.1.12@SR_MHPMCOUNTER18	118
21.21.1.12 5 SR_MHPMCOUNTER18H	118
21.21.1.126SR_MHPMCOUNTER19	118
21.21.1.12 7 SR_MHPMCOUNTER19H	118
21.21.1.128SR_MHPMCOUNTER20	118
21.21.1.129SR_MHPMCOUNTER20H	118
21.21.1.130SR_MHPMCOUNTER21	118
21.21.1.13 3 SR_MHPMCOUNTER21H	119
21.21.1.132SR_MHPMCOUNTER22	119
21.21.1.133SR_MHPMCOUNTER22H	119
21.21.1.13 4 SR_MHPMCOUNTER23	119
21.21.1.1 35 SR_MHPMCOUNTER23H	119
21.21.1.136SR_MHPMCOUNTER24	119
21.21.1.13 7 SR_MHPMCOUNTER24H	119
21.21.1.138SR_MHPMCOUNTER25	119
21.21.1.139SR_MHPMCOUNTER25H	120
21.21.1.140SR_MHPMCOUNTER26	120
21.21.1.14 0 SR_MHPMCOUNTER26H	120
21.21.1.14 2 SR_MHPMCOUNTER27	120
21.21.1.14 3 SR_MHPMCOUNTER27H	120
21.21.1.14 9 SR_MHPMCOUNTER28	120
21.21.1.14 6 SR_MHPMCOUNTER28H	120
21.21.1.146SR_MHPMCOUNTER29	120
21.21.1.14 7 SR_MHPMCOUNTER29H	121
21.21.1.148SR_MHPMCOUNTER3	121

xvi CONTENTS

21.21.1.14 9 SR_MHPMCOUNTER30
21.21.1.150SR_MHPMCOUNTER30H
21.21.1.15 3 SR_MHPMCOUNTER31
21.21.1.152SR_MHPMCOUNTER31H
21.21.1.153SR_MHPMCOUNTER3H
21.21.1.15 3 SR_MHPMCOUNTER4
21.21.1.155SR_MHPMCOUNTER4H
21.21.1.156SR_MHPMCOUNTER5
21.21.1.157SR_MHPMCOUNTER5H
21.21.1.158SR_MHPMCOUNTER6
21.21.1.159SR_MHPMCOUNTER6H
21.21.1.160SR_MHPMCOUNTER7
21.21.1.160SR_MHPMCOUNTER7H
21.21.1.162SR_MHPMCOUNTER8
21.21.1.163SR_MHPMCOUNTER8H
21.21.1.16 3 SR_MHPMCOUNTER9
21.21.1.165SR_MHPMCOUNTER9H
21.21.1.166SR_MHPMEVENT10
21.21.1.16 7 SR_MHPMEVENT11
21.21.1.168SR_MHPMEVENT1212
21.21.1.169SR_MHPMEVENT13
21.21.1.170SR_MHPMEVENT14
21.21.1.17 0 SR_MHPMEVENT15
21.21.1.17 2 SR_MHPMEVENT16
21.21.1.17 3 SR_MHPMEVENT17
21.21.1.17 3 SR_MHPMEVENT18
21.21.1.17 6 SR_MHPMEVENT19
21.21.1.176SR_MHPMEVENT20
21.21.1.17 7 SR_MHPMEVENT21
21.21.1.178SR_MHPMEVENT2212

CONTENTS xvii

21.21.1.179SR_MHPMEVENT23	125
21.21.1.180SR_MHPMEVENT24	125
21.21.1.180SR_MHPMEVENT25	125
21.21.1.182SR_MHPMEVENT26	125
21.21.1.18 3 SR_MHPMEVENT27	125
21.21.1.18 4 SR_MHPMEVENT28	125
21.21.1.18 5 SR_MHPMEVENT29	125
21.21.1.186SR_MHPMEVENT3	125
21.21.1.18 7 SR_MHPMEVENT30	126
21.21.1.188SR_MHPMEVENT31	126
21.21.1.189SR_MHPMEVENT4	126
21.21.1.190SR_MHPMEVENT5	126
21.21.1.19CSR_MHPMEVENT6	126
21.21.1.192SR_MHPMEVENT7	126
21.21.1.193SR_MHPMEVENT8	126
21.21.1.194SR_MHPMEVENT9	126
21.21.1.196SR_MIDELEG	127
21.21.1.196SR_MIE	127
21.21.1.19 7 SR_MIMPID	127
21.21.1.198SR_MINSTRET	127
21.21.1.199SR_MINSTRETH	127
21.21.1.200SR_MIP	127
21.21.1.20CSR_MISA	127
21.21.1.202SR_MSCRATCH	127
21.21.1.20 3 SR_MSTATUS	128
21.21.1.204SR_MSTATUSH	128
21.21.1.20 5 SR_MTINST	128
21.21.1.20 6 SR_MTVAL	128
21.21.1.207SR_MTVAL2	128
21.21.1.20 8 SR_MTVEC	128

xviii CONTENTS

21.21.1.209SR_MVENDORID
21.21.1.21 0 SR_PMPADDR0
21.21.1.21 C SR_PMPADDR1
21.21.1.21@SR_PMPADDR10
21.21.1.21 G SR_PMPADDR11
21.21.1.21@SR_PMPADDR12
21.21.1.21 6 SR_PMPADDR13
21.21.1.21 6 SR_PMPADDR14
21.21.1.21 © SR_PMPADDR15
21.21.1.21 8 SR_PMPADDR2
21.21.1.21 9 SR_PMPADDR3
21.21.1.220SR_PMPADDR4
21.21.1.22CSR_PMPADDR5
21.21.1.222SR_PMPADDR6
21.21.1.223SR_PMPADDR7
21.21.1.22 3 SR_PMPADDR8
21.21.1.225SR_PMPADDR9
21.21.1.226SR_PMPCFG0
21.21.1.227SR_PMPCFG1
21.21.1.228SR_PMPCFG2
21.21.1.229SR_PMPCFG3
21.21.1.230SR_SATP
21.21.1.23CSR_SCAUSE
21.21.1.232SR_SCOUNTEREN
21.21.1.233SR_SEPC
21.21.1.23 4 SR_SIE
21.21.1.236SR_SIP
21.21.1.236SR_SSCRATCH
21.21.1.23 7 SR_SSTATUS
21.21.1.238SR_STVAL

CONTENTS xix

21.21.1.23 9 SR_STVEC
21.21.1.24 0 SR_TDATA1
21.21.1.24 C SR_TDATA2
21.21.1.24 Q SR_TDATA3
21.21.1.24 3 SR_TIME
21.21.1.24 @ SR_TIMEH
21.21.1.246SR_TSELECT
21.21.1.246SR_UCAUSE
21.21.1.24 7 SR_UEPC
21.21.1.248SR_UIE
21.21.1.249SR_UIP
21.21.1.250SR_USCRATCH
21.21.1.25 C SR_USTATUS
21.21.1.2 52 SR_UTVAL
21.21.1.2 53 SR_UTVEC 134
21.21.1.25 3 SR_VSATP
21.21.1.256SR_VSCAUSE
21.21.1.256SR_VSEPC 134
21.21.1.25 7 SR_VSIE
21.21.1.258SR_VSIP
21.21.1.259SR_VSSCRATCH
21.21.1.260SR_VSSTATUS
21.21.1.26CSR_VSTVAL
21.21.1.262SR_VSTVEC
21.21.1.26 3 ET_RM
21.21.1.264ET_RS1
21.21.1.26 S ET_RS1S
21.21.1.26 G ET_RS2
21.21.1.26GET_RS2C
21.21.1.268ET_RS2S

21.21.1.269ET_SP
21.21.1.27 0 STATUS_SP2P
21.21.1.27#ISTATUS_SP2V
21.21.1.27/2/STATUS_SPRV
21.21.1.279STATUS_SPV
21.21.1.274STATUS_VTSR
21.21.1.275STATUS_VTVM
21.21.1.276MM_I
21.21.1.27MM_S
21.21.1.278NSN_16BIT_MASK
21.21.1.279NSN_32BIT_MASK
21.21.1.280NSN_IS_16BIT
21.21.1.28NSN_IS_32BIT
21.21.1.2812NSN_LEN
21.21.1.280NSN_MASK_C_FLD
21.21.1.284NSN_MASK_C_FLDSP
21.21.1.285\\ SN_MASK_C_FLW
21.21.1.286NSN_MASK_C_FLWSP
21.21.1.28TNSN_MASK_C_FSD
21.21.1.288NSN_MASK_C_FSDSP
21.21.1.289\SN_MASK_C_FSW
21.21.1.290\SN_MASK_C_FSWSP
21.21.1.29NSN_MASK_C_LD
21.21.1.29 t NSN_MASK_C_LDSP
21.21.1.298NSN_MASK_C_LW
21.21.1.294NSN_MASK_C_LWSP
21.21.1.295NSN_MASK_C_SD
21.21.1.296\SN_MASK_C_SDSP
21.21.1.29TNSN_MASK_C_SW
21.21.1.298NSN_MASK_C_SWSP

CONTENTS xxi

21.21.1.299NSN_MASK_FLD	140
21.21.1.300NSN_MASK_FLQ	140
21.21.1.30NSN_MASK_FLW	140
21.21.1.30 2 NSN_MASK_FSD	141
21.21.1.300NSN_MASK_FSQ	141
21.21.1.304NSN_MASK_FSW	141
21.21.1.30 5 \\SN_MASK_LB	141
21.21.1.306\SN_MASK_LBU	141
21.21.1.30 T NSN_MASK_LD	141
21.21.1.308JSN_MASK_LH	141
21.21.1.309\SN_MASK_LHU	141
21.21.1.31INSN_MASK_LW	142
21.21.1.31INSN_MASK_LWU	142
21.21.1.31 \(\text{21SN_MASK_SB}\)	142
21.21.1.31 \text{BISN_MASK_SD}	142
21.21.1.31MJSN_MASK_SH	142
21.21.1.31 \text{SN_MASK_SW}	142
21.21.1.31IBJSN_MASK_WFI	142
21.21.1.31INSN_MATCH_C_FLD	142
21.21.1.31 \(\text{NSN_MATCH_C_FLDSP}\)	143
21.21.1.31 \text{\text{B\text{\MATCH_C_FLW}}}	143
21.21.1.320NSN_MATCH_C_FLWSP	143
21.21.1.32NSN_MATCH_C_FSD	143
21.21.1.322NSN_MATCH_C_FSDSP	143
21.21.1.325NSN_MATCH_C_FSW	143
21.21.1.324NSN_MATCH_C_FSWSP	143
21.21.1.325\SN_MATCH_C_LD	143
21.21.1.326ISN_MATCH_C_LDSP	144
21.21.1.32NSN_MATCH_C_LW	144
21.21.1.328\SN_MATCH_C_LWSP	144

xxii CONTENTS

21.21.1.329NSN_MATCH_C_SD
21.21.1.330NSN_MATCH_C_SDSP
21.21.1.33NSN_MATCH_C_SW
21.21.1.332NSN_MATCH_C_SWSP
21.21.1.338NSN_MATCH_FLD
21.21.1.334NSN_MATCH_FLQ
21.21.1.335\SN_MATCH_FLW
21.21.1.336\SN_MATCH_FSD
21.21.1.33TNSN_MATCH_FSQ
21.21.1.338NSN_MATCH_FSW
21.21.1.339NSN_MATCH_LB
21.21.1.34NSN_MATCH_LBU
21.21.1.34NSN_MATCH_LD
21.21.1.342NSN_MATCH_LH
21.21.1.340NSN_MATCH_LHU
21.21.1.344NSN_MATCH_LW
21.21.1.345\\SN_MATCH_LWU
21.21.1.346\SN_MATCH_SB
21.21.1.34NSN_MATCH_SD
21.21.1.348\\ SN_MATCH_SH
21.21.1.349JSN_MATCH_SW 146
21.21.1.350NSN_MATCH_WFI
21.21.1.35RQ_M_EXT
21.21.1.352RQ_M_SOFT
21.21.1.35@RQ_M_TIMER
21.21.1.35\(\text{RQ}\)_S_EXT
21.21.1.35\text{IRQ_S_GEXT}
21.21.1.35@Q_S_SOFT 147
21.21.1.35TRQ_S_TIMER
21.21.1.35\(\mathbb{R}\text{Q_VS_EXT}\)

CONTENTS xxiii

21.21.1.359RQ_VS_SOFT	148
21.21.1.36@RQ_VS_TIMER	148
21.21.1.361OG_REGBYTES	148
21.21.1.3612/ASK_FUNCT3	148
21.21.1.360IP_MEIP	148
21.21.1.36 \(4 \)IP_MSIP	148
21.21.1.365 IP_MTIP	148
21.21.1.366/IP_SEIP	149
21.21.1.36VIIP_SGEIP	149
21.21.1.369/IP_SSIP	149
21.21.1.369IIP_STIP	149
21.21.1.370IIP_VSEIP	149
21.21.1.37MIP_VSSIP	149
21.21.1.37/2/IP_VSTIP	149
21.21.1.37/g/STATUS32_SD [1/2]	149
21.21.1.37M STATUS32_SD [2/2]	150
21.21.1.37/g/STATUS64_SD	150
21.21.1.37/d/STATUS_FS	150
21.21.1.37MSTATUS_MIE	150
21.21.1.37/8/STATUS_MPIE	150
21.21.1.37/9/STATUS_MPP	150
21.21.1.380/ISTATUS_MPP_SHIFT	150
21.21.1.38WISTATUS_MPRV	150
21.21.1.3812ISTATUS_MXR	151
21.21.1.389/STATUS_SD	151
21.21.1.3844STATUS_SIE	151
21.21.1.386/STATUS_SPIE	151
21.21.1.386/STATUS_SPIE_SHIFT	151
21.21.1.38V/ISTATUS_SPP	151
21.21.1.389/STATUS_SPP_SHIFT	151

xxiv CONTENTS

21.21.1.389/STATUS_SUM
21.21.1.390/STATUS_TSR
21.21.1.39MSTATUS_TVM
21.21.1.3902STATUS_TW
21.21.1.390/STATUS_UBE
21.21.1.39MSTATUS_XS
21.21.1.39%STATUSH_MBE
21.21.1.39%/STATUSH_MPV
21.21.1.39MSTATUSH_SBE
21.21.1.398MP_A
21.21.1.399MP_A_NA4
21.21.1.40@MP_A_NAPOT
21.21.1.40PMP_A_TOR
21.21.1.402MP_COUNT
21.21.1.408MP_L
21.21.1.40PMP_R
21.21.1.40BMP_SHIFT
21.21.1.4078MP_W
21.21.1.40 7 MP_X
21.21.1.40BRV_M
21.21.1.409RV_S
21.21.1.41PORV_U
21.21.1.41PTE_A
21.21.1.41 P2 TE_D
21.21.1.41 <mark>BTE_G</mark>
21.21.1.41PATE_PPN_SHIFT
21.21.1.41BTE_R
21.21.1.41RTE_SOFT
21.21.1.41PTE_TABLE
21.21.1.41RTE_U

CONTENTS xxv

21.21.1.41BTE_V
21.21.1.4289TE_W
21.21.1.42PTE_X
21.21.1.42BEG_MASK
21.21.1.42BEG_OFFSET
21.21.1.42AEG_PTR
21.21.1.428EGBYTES
21.21.1.428ISCV_PGLEVEL_BITS
21.21.1.42RISCV_PGSHIFT
21.21.1.428ISCV_PGSIZE
21.21.1.42 9 V_X
21.21.1.438VC_LD_IMM
21.21.1.43RVC_LDSP_IMM
21.21.1.43 2 VC_LW_IMM
21.21.1.438VC_LWSP_IMM
21.21.1.43AVC_RS1S
21.21.1.438VC_RS2
21.21.1.43 R VC_RS2S
21.21.1.43RVC_SDSP_IMM
21.21.1.438VC_SWSP_IMM
21.21.1.43 9 ATP32_ASID
21.21.1.44 S ATP32_MODE
21.21.1.44 S ATP32_PPN
21.21.1.44 2 ATP64_ASID
21.21.1.44 S ATP64_MODE
21.21.1.449ATP64_PPN
21.21.1.44 S ATP_MODE
21.21.1.44 6 ATP_MODE_OFF
21.21.1.44SATP_MODE_SV32
21.21.1.44 8 ATP_MODE_SV39

xxvi CONTENTS

21.21.1.44 9 ATP_MODE_SV48	160
21.21.1.459ATP_MODE_SV57	160
21.21.1.453ATP_MODE_SV64	160
21.21.1.45%2ET_RD	161
21.21.1.45 9 H_RD	161
21.21.1.459H_RS1	161
21.21.1.45 % H_RS2	161
21.21.1.45 6 H_RS2C	161
21.21.1.459HIFT_RIGHT	161
21.21.1.45 8 IP_SSIP	161
21.21.1.45 9 IP_STIP	162
21.21.1.469STATUS32_SD	162
21.21.1.463STATUS64_SD	162
21.21.1.46 2 STATUS64_UXL	162
21.21.1.46 3 STATUS_FS	162
21.21.1.469STATUS_MXR	162
21.21.1.46 5 STATUS_SD	162
21.21.1.46%STATUS_SIE	162
21.21.1.467STATUS_SPIE	163
21.21.1.46 8 STATUS_SPIE_SHIFT	163
21.21.1.46 9 STATUS_SPP	163
21.21.1.479STATUS_SPP_SHIFT	163
21.21.1.479STATUS_SUM	163
21.21.1.47 9 STATUS_XS	163
21.22include/sbi/riscv_fp.h File Reference	164
21.22.1 Macro Definition Documentation	165
21.22.1.1 GET_PRECISION	165
21.22.1.2 GET_RM	165
21.22.1.3 PRECISION_D	165
21.22.1.4 PRECISION_S	165

CONTENTS xxvii

xxviii CONTENTS

21.23.2.4raw_readw()	71
21.23.2.5raw_writeb()	71
21.23.2.6raw_writel()	71
21.23.2.7raw_writeq()	71
21.23.2.8raw_writew()	71
21.24include/sbi/riscv_locks.h File Reference	72
21.24.1 Macro Definition Documentation	72
21.24.1.1RISCV_SPIN_UNLOCKED	72
21.24.1.2 SPIN_LOCK_INIT	72
21.24.1.3 SPIN_LOCK_INITIALIZER	73
21.24.2 Function Documentation	73
21.24.2.1 spin_lock()	73
21.24.2.2 spin_lock_check()	74
21.24.2.3 spin_trylock()	75
21.24.2.4 spin_unlock()	76
21.25include/sbi/sbi_bitops.h File Reference	77
21.25.1 Macro Definition Documentation	79
21.25.1.1 ffz	79
21.25.2 Function Documentation	79
21.25.2.1ffs()	79
21.25.2.2fls()	79
21.25.2.3 ffs()	80
21.25.2.4 fls()	80
21.26include/sbi/sbi_bits.h File Reference	80
21.26.1 Macro Definition Documentation	80
21.26.1.1 BIT_MASK	80
21.26.1.2 BIT_WORD	81
21.26.1.3 EXTRACT_FIELD	81
21.26.1.4 INSERT_FIELD	81
21.27include/sbi/sbi_console.h File Reference	81

CONTENTS xxix

21.27.1 Macro Definition Documentation	182
21.27.1.1printf	182
21.27.2 Function Documentation	182
21.27.2.1printf() [1/3]	182
21.27.2.2printf() [2/3]	183
21.27.2.3 printf() [3/3]	183
21.27.2.4 sbi_console_init()	183
21.27.2.5 sbi_getc()	184
21.27.2.6 sbi_gets()	184
21.27.2.7 sbi_isprintable()	185
21.27.2.8 sbi_putc()	185
21.27.2.9 sbi_puts()	185
21.27.3 Variable Documentation	186
21.27.3.1 format	186
21.27.3.2 out_sz	186
21.28include/sbi/sbi_const.h File Reference	186
21.28.1 Macro Definition Documentation	187
21.28.1.1AC	187
21.28.1.2STR	187
21.28.1.3 _AC	187
21.28.1.4 _AT	187
21.28.1.5 _BITUL	188
21.28.1.6 _BITULL	188
21.28.1.7 _UL	188
21.28.1.8 _ULL	188
21.28.1.9 STRINGIFY	188
21.28.1.10UL	188
21.28.1.11ULL	188
21.29include/sbi/sbi_ecall.h File Reference	189
21.29.1 Macro Definition Documentation	190

21.29.1.1 SBI_ECALL_VERSION_MAJOR	190
21.29.1.2 SBI_ECALL_VERSION_MINOR	190
21.29.1.3 SBI_OPENSBI_IMPID	190
21.29.2 Function Documentation	190
21.29.2.1 sbi_ecall_find_extension()	190
21.29.2.2 sbi_ecall_handler()	191
21.29.2.3 sbi_ecall_init()	191
21.29.2.4 sbi_ecall_register_extension()	192
21.29.2.5 sbi_ecall_unregister_extension()	192
21.29.2.6 sbi_ecall_version_major()	193
21.29.2.7 sbi_ecall_version_minor()	193
21.29.3 Variable Documentation	194
21.29.3.1 ecall_base	194
21.29.3.2 ecall_ipi	194
21.29.3.3 ecall_legacy	194
21.29.3.4 ecall_rfence	194
21.29.3.5 ecall_time	194
21.29.3.6 ecall_vendor	194
21.30 include/sbi/sbi_ecall_interface.h File Reference	194
21.30.1 Macro Definition Documentation	195
21.30.1.1 SBI_EXT_0_1_CLEAR_IPI	195
21.30.1.2 SBI_EXT_0_1_CONSOLE_GETCHAR	195
21.30.1.3 SBI_EXT_0_1_CONSOLE_PUTCHAR	196
21.30.1.4 SBI_EXT_0_1_REMOTE_FENCE_I	196
21.30.1.5 SBI_EXT_0_1_REMOTE_SFENCE_VMA	196
21.30.1.6 SBI_EXT_0_1_REMOTE_SFENCE_VMA_ASID	196
21.30.1.7 SBI_EXT_0_1_SEND_IPI	196
21.30.1.8 SBI_EXT_0_1_SET_TIMER	196
21.30.1.9 SBI_EXT_0_1_SHUTDOWN	196
21.30.1.10SBI_EXT_BASE	196

CONTENTS xxxi

21.30.1.11SBI_EXT_BASE_GET_IMP_ID	97
21.30.1.128BI_EXT_BASE_GET_IMP_VERSION	97
21.30.1.13SBI_EXT_BASE_GET_MARCHID	97
21.30.1.14SBI_EXT_BASE_GET_MIMPID	97
21.30.1.15SBI_EXT_BASE_GET_MVENDORID	97
21.30.1.16SBI_EXT_BASE_GET_SPEC_VERSION	97
21.30.1.17SBI_EXT_BASE_PROBE_EXT	97
21.30.1.18SBI_EXT_IPI	97
21.30.1.19SBI_EXT_IPI_SEND_IPI	98
21.30.1.20SBI_EXT_RFENCE	98
21.30.1.21SBI_EXT_RFENCE_REMOTE_FENCE_I	98
21.30.1.22SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA	98
21.30.1.23SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA_VMID	98
21.30.1.24SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA	98
21.30.1.25SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA_ASID	98
21.30.1.26SBI_EXT_RFENCE_REMOTE_SFENCE_VMA	98
21.30.1.27SBI_EXT_RFENCE_REMOTE_SFENCE_VMA_ASID	99
21.30.1.28SBI_EXT_TIME	99
21.30.1.29SBI_EXT_TIME_SET_TIMER	99
21.30.1.30SBI_EXT_VENDOR_END	99
21.30.1.31SBI_EXT_VENDOR_START	99
21.30.1.32SBI_SPEC_VERSION_MAJOR_MASK	99
21.30.1.33SBI_SPEC_VERSION_MAJOR_OFFSET	99
21.30.1.34SBI_SPEC_VERSION_MINOR_MASK	99
21.31 include/sbi/sbi_emulate_csr.h File Reference	00
21.31.1 Function Documentation	00
21.31.1.1 sbi_emulate_csr_read()	01
21.31.1.2 sbi_emulate_csr_write()	01
21.32include/sbi/sbi_error.h File Reference	02
21.32.1 Macro Definition Documentation	02

xxxii CONTENTS

21.32.1.1 SBI_DE	ENIED	202
21.32.1.2 SBI_EF	FAIL	203
21.32.1.3 SBI_EI	LL	203
21.32.1.4 SBI_EI	NVAL	203
21.32.1.5 SBI_EI	0	203
21.32.1.6 SBI_EN	NODEV	203
21.32.1.7 SBI_EN	NOENT 2	203
21.32.1.8 SBI_EN	NOMEM	203
21.32.1.9 SBI_EN	NOSPC	203
21.32.1.10SBI_EN	NOSYS 2	204
21.32.1.11SBI_EN	NOTSUPP	204
21.32.1.125BI_ET	TIMEDOUT	204
21.32.1.13SBI_ET	TRAP	204
21.32.1.14SBI_EU	JNKNOWN	204
21.32.1.15SBI_IN	VALID_ADDR	204
21.32.1.16SBI_O	<	204
21.33include/sbi/sbi_fifo.h File I	Reference	205
21.33.1 Enumeration Type	e Documentation	206
21.33.1.1 sbi_fifo	_inplace_update_types	206
21.33.2 Function Docume	ntation	206
21.33.2.1 sbi_fifo	_avail()	206
21.33.2.2 sbi_fifo	_dequeue()	206
21.33.2.3 sbi_fifo	_enqueue()	207
21.33.2.4 sbi_fifo	_init()	208
21.33.2.5 sbi_fifo	_inplace_update()	209
21.33.2.6 sbi_fifo	_is_empty()	210
21.33.2.7 sbi_fifo	_is_full()	210
21.34include/sbi/sbi_hart.h File	Reference	211
21.34.1 Function Docume	ntation	212
21.34.1.1attrib	oute()	212

CONTENTS xxxiii

21.34.1.2 sbi_current_hartid()	212
21.34.1.3 sbi_hart_available_mask()	212
21.34.1.4 sbi_hart_delegation_dump()	213
21.34.1.5 sbi_hart_get_trap_info()	214
21.34.1.6 sbi_hart_id_to_scratch()	214
21.34.1.7 sbi_hart_init()	214
21.34.1.8 sbi_hart_mark_available()	215
21.34.1.9 sbi_hart_pmp_dump()	216
21.34.1.10sbi_hart_set_trap_info()	217
21.34.1.11sbi_hart_unmark_available()	217
21.34.1.12sbi_hart_wait_for_coldboot()	218
21.34.1.13sbi_hart_wake_coldboot_harts()	218
21.34.2 Variable Documentation	219
21.34.2.1 arg1	219
21.34.2.2 next_addr	219
21.34.2.3 next_mode	219
21.34.2.4 next_virt	219
21.35include/sbi/sbi_hfence.h File Reference	220
21.35.1 Function Documentation	220
21.35.1.1sbi_hfence_gvma_all()	220
21.35.1.2sbi_hfence_gvma_gpa()	221
21.35.1.3sbi_hfence_gvma_vmid()	221
21.35.1.4sbi_hfence_gvma_vmid_gpa()	221
21.35.1.5sbi_hfence_vvma_all()	222
21.35.1.6sbi_hfence_vvma_asid()	222
21.35.1.7sbi_hfence_vvma_asid_va()	222
21.35.1.8sbi_hfence_vvma_va()	223
21.36include/sbi/sbi_illegal_insn.h File Reference	223
21.36.1 Function Documentation	224
21.36.1.1 sbi_illegal_insn_handler()	224

CONTENTS XXXV

21.39.2 Function Documentation	239
21.39.2.1sbi_list_add()	239
21.39.2.2sbi_list_del()	240
21.39.2.3sbi_list_del_entry()	240
21.39.2.4 sbi_list_add()	241
21.39.2.5 sbi_list_add_tail()	241
21.39.2.6 sbi_list_del()	242
21.39.2.7 sbi_list_del_init()	242
21.40include/sbi/sbi_misaligned_ldst.h File Reference	243
21.40.1 Function Documentation	244
21.40.1.1 sbi_misaligned_load_handler()	244
21.40.1.2 sbi_misaligned_store_handler()	245
21.41 include/sbi/sbi_platform.h File Reference	246
21.41.1 Macro Definition Documentation	248
21.41.1.1 SBI_PLATFORM_DEFAULT_FEATURES	248
21.41.1.2 SBI_PLATFORM_DISABLED_HART_OFFSET	248
21.41.1.3 SBI_PLATFORM_FEATURES_OFFSET	248
21.41.1.4 SBI_PLATFORM_FIRMWARE_CONTEXT_OFFSET	248
21.41.1.5 SBI_PLATFORM_HART_COUNT_OFFSET	248
21.41.1.6 SBI_PLATFORM_HART_STACK_SIZE_OFFSET	249
21.41.1.7 sbi_platform_has_hart_hotplug	249
21.41.1.8 sbi_platform_has_mcounteren	249
21.41.1.9 sbi_platform_has_mfaults_delegation	249
21.41.1.10sbi_platform_has_pmp	249
21.41.1.11sbi_platform_has_scounteren	249
21.41.1.12sbi_platform_has_timer_value	249
21.41.1.13SBI_PLATFORM_NAME_OFFSET	250
21.41.1.14SBI_PLATFORM_OPENSBI_VERSION_OFFSET	250
21.41.1.15sbi_platform_ops	250
21.41.1.16SBI_PLATFORM_OPS_OFFSET	250

xxxvi CONTENTS

21.41.1.17sbi_platform_ptr	250
21.41.1.18sbi_platform_thishart_ptr	250
21.41.1.19SBI_PLATFORM_TLB_RANGE_FLUSH_LIMIT_DEFAULT	250
21.41.1.20SBI_PLATFORM_VERSION	251
21.41.1.21SBI_PLATFORM_VERSION_OFFSET	251
21.41.2 Enumeration Type Documentation	251
21.41.2.1 sbi_platform_features	251
21.41.3 Function Documentation	251
21.41.3.1 sbi_platform_console_getc()	251
21.41.3.2 sbi_platform_console_init()	252
21.41.3.3 sbi_platform_console_putc()	253
21.41.3.4 sbi_platform_early_exit()	253
21.41.3.5 sbi_platform_early_init()	254
21.41.3.6 sbi_platform_final_exit()	254
21.41.3.7 sbi_platform_final_init()	255
21.41.3.8 sbi_platform_hart_count()	255
21.41.3.9 sbi_platform_hart_disabled()	256
21.41.3.10sbi_platform_hart_stack_size()	257
21.41.3.11sbi_platform_ipi_clear()	257
21.41.3.12sbi_platform_ipi_exit()	258
21.41.3.13sbi_platform_ipi_init()	258
21.41.3.14sbi_platform_ipi_send()	259
21.41.3.15sbi_platform_irqchip_exit()	259
21.41.3.16sbi_platform_irqchip_init()	260
21.41.3.17sbi_platform_misa_extension()	261
21.41.3.18sbi_platform_misa_xlen()	261
21.41.3.19sbi_platform_name()	262
21.41.3.20sbi_platform_pmp_region_count()	262
21.41.3.21sbi_platform_pmp_region_info()	263
21.41.3.2&bi_platform_system_reboot()	264

CONTENTS xxxvii

	21.41.3.23sbi_platform_system_shutdown()	264
	21.41.3.24sbi_platform_timer_event_start()	265
	21.41.3.25sbi_platform_timer_event_stop()	265
	21.41.3.26sbi_platform_timer_exit()	266
	21.41.3.27sbi_platform_timer_init()	266
	21.41.3.28sbi_platform_timer_value()	267
	21.41.3.2%bi_platform_tlbr_flush_limit()	268
	21.41.3.30sbi_platform_vendor_ext_check()	268
	21.41.3.31sbi_platform_vendor_ext_provider()	269
21.41.4	Variable Documentation	270
	21.41.4.1packed	270
21.42include	/sbi/sbi_scratch.h File Reference	270
21.42.1	Macro Definition Documentation	271
	21.42.1.1 SBI_SCRATCH_EXTRA_SPACE_OFFSET	272
	21.42.1.2 SBI_SCRATCH_FW_SIZE_OFFSET	272
	21.42.1.3 SBI_SCRATCH_FW_START_OFFSET	272
	21.42.1.4 SBI_SCRATCH_HARTID_TO_SCRATCH_OFFSET	272
	21.42.1.5 SBI_SCRATCH_NEXT_ADDR_OFFSET	272
	21.42.1.6 SBI_SCRATCH_NEXT_ARG1_OFFSET	272
	21.42.1.7 SBI_SCRATCH_NEXT_MODE_OFFSET	272
	21.42.1.8 sbi_scratch_offset_ptr	273
	21.42.1.9 SBI_SCRATCH_OPTIONS_OFFSET	273
	21.42.1.10SBI_SCRATCH_PLATFORM_ADDR_OFFSET	273
	21.42.1.11SBI_SCRATCH_SIZE	273
	21.42.1.12sbi_scratch_thishart_arg1_ptr	273
	21.42.1.13sbi_scratch_thishart_offset_ptr	273
	21.42.1.14sbi_scratch_thishart_ptr	273
	21.42.1.15SBI_SCRATCH_TMP0_OFFSET	274
	21.42.1.16SBI_SCRATCH_WARMBOOT_ADDR_OFFSET	274
21.42.2	Enumeration Type Documentation	274

xxxviii CONTENTS

21.42.2.1 sbi_scratch_options
21.42.3 Function Documentation
21.42.3.1 sbi_scratch_alloc_offset()
21.42.3.2 sbi_scratch_free_offset()
21.42.4 Variable Documentation
21.42.4.1packed
21.43include/sbi/sbi_string.h File Reference
21.43.1 Function Documentation
21.43.1.1 sbi_memchr()
21.43.1.2 sbi_memcmp()
21.43.1.3 sbi_memcpy()
21.43.1.4 sbi_memmove()
21.43.1.5 sbi_memset()
21.43.1.6 sbi_strchr()
21.43.1.7 sbi_strcmp()
21.43.1.8 sbi_strcpy()
21.43.1.9 sbi_strlen()
21.43.1.10sbi_strncpy()
21.43.1.11sbi_strnlen()
21.43.1.12sbi_strrchr()
21.44include/sbi/sbi_system.h File Reference
21.44.1 Function Documentation
21.44.1.1 sbi_system_early_exit()
21.44.1.2 sbi_system_early_init()
21.44.1.3 sbi_system_final_exit()
21.44.1.4 sbi_system_final_init()
21.44.1.5 sbi_system_reboot()
21.44.1.6 sbi_system_shutdown()
21.45include/sbi/sbi_timer.h File Reference
21.45.1 Function Documentation

CONTENTS xxxix

21.45.1.1 sbi_timer_event_start()	85
21.45.1.2 sbi_timer_exit()	:85
21.45.1.3 sbi_timer_get_delta()	:86
21.45.1.4 sbi_timer_init()	:87
21.45.1.5 sbi_timer_process()	:87
21.45.1.6 sbi_timer_set_delta()	:88
21.45.1.7 sbi_timer_set_delta_upper()	:88
21.45.1.8 sbi_timer_value()	:88
21.45.1.9 sbi_timer_virt_value()	:89
21.46include/sbi/sbi_tlb.h File Reference	:89
21.46.1 Macro Definition Documentation	91
21.46.1.1 SBI_TLB_FIFO_NUM_ENTRIES	91
21.46.1.2 SBI_TLB_FLUSH_ALL	91
21.46.1.3 SBI_TLB_INFO_SIZE	91
21.46.2 Enumeration Type Documentation	91
21.46.2.1 sbi_tlb_info_types	91
21.46.3 Function Documentation	91
21.46.3.1 sbi_tlb_init()	92
21.46.3.2 sbi_tlb_request()	92
21.47include/sbi/sbi_trap.h File Reference	93
21.47.1 Macro Definition Documentation	95
21.47.1.1 SBI_TRAP_REGS_a0	95
21.47.1.2 SBI_TRAP_REGS_a1	95
21.47.1.3 SBI_TRAP_REGS_a2	95
21.47.1.4 SBI_TRAP_REGS_a3	95
21.47.1.5 SBI_TRAP_REGS_a4	95
21.47.1.6 SBI_TRAP_REGS_a5	:96
21.47.1.7 SBI_TRAP_REGS_a6	:96
21.47.1.8 SBI_TRAP_REGS_a7	:96
21.47.1.9 SBI_TRAP_REGS_gp	96

xI CONTENTS

21.47.1.10SBI_TRAP_REGS_last	296
21.47.1.11SBI_TRAP_REGS_mepc	296
21.47.1.12SBI_TRAP_REGS_mstatus	296
21.47.1.13SBI_TRAP_REGS_mstatusH	296
21.47.1.14SBI_TRAP_REGS_OFFSET	297
21.47.1.15SBI_TRAP_REGS_ra	297
21.47.1.16SBI_TRAP_REGS_s0	297
21.47.1.17SBI_TRAP_REGS_s1	297
21.47.1.18SBI_TRAP_REGS_s10	297
21.47.1.19SBI_TRAP_REGS_s11	297
21.47.1.20SBI_TRAP_REGS_s2	297
21.47.1.21SBI_TRAP_REGS_s3	298
21.47.1.22SBI_TRAP_REGS_s4	298
21.47.1.23SBI_TRAP_REGS_s5	298
21.47.1.24SBI_TRAP_REGS_s6	298
21.47.1.25SBI_TRAP_REGS_s7	298
21.47.1.26SBI_TRAP_REGS_s8	298
21.47.1.27SBI_TRAP_REGS_s9	298
21.47.1.28SBI_TRAP_REGS_SIZE	298
21.47.1.29SBI_TRAP_REGS_sp	299
21.47.1.30SBI_TRAP_REGS_t0	299
21.47.1.31SBI_TRAP_REGS_t1	299
21.47.1.32SBI_TRAP_REGS_t2	299
21.47.1.33SBI_TRAP_REGS_t3	299
21.47.1.34SBI_TRAP_REGS_t4	299
21.47.1.35SBI_TRAP_REGS_t5	299
21.47.1.36SBI_TRAP_REGS_t6	299
21.47.1.37SBI_TRAP_REGS_tp	300
21.47.1.38SBI_TRAP_REGS_zero	300
21.47.2 Function Documentation	300

CONTENTS xli

21.47.2.1 sbi_trap_handler()	300
21.47.2.2 sbi_trap_redirect()	301
21.47.3 Variable Documentation	302
21.47.3.1packed	102
21.48include/sbi/sbi_types.h File Reference	302
21.48.1 Macro Definition Documentation	303
21.48.1.1noreturn	303
21.48.1.2packed	303
21.48.1.3 CLAMP	304
21.48.1.4 container_of	304
21.48.1.5 FALSE	304
21.48.1.6 likely	304
21.48.1.7 MAX	304
21.48.1.8 MIN	304
21.48.1.9 NULL	305
21.48.1.10offsetof	305
21.48.1.11ROUNDDOWN	305
21.48.1.12ROUNDUP	305
21.48.1.13STR	305
21.48.1.14TRUE	305
21.48.1.15unlikely	305
21.48.1.16XSTR	306
21.48.2 Typedef Documentation	306
21.48.2.1 bool	306
21.48.2.2 int16_t	306
21.48.2.3 int32_t	306
21.48.2.4 physical_addr_t	306
21.48.2.5 physical_size_t	306
21.48.2.6 s16	306
21.48.2.7 s32	307

xlii CONTENTS

21.48.2.8 s8	307
21.48.2.9 size_t	307
21.48.2.10ssize_t	307
21.48.2.11u16	307
21.48.2.12,32	307
21.48.2.13.18	307
21.48.2.14uint16_t	307
21.48.2.15uint32_t	308
21.48.2.16uint8_t	308
21.48.2.17uintptr_t	308
21.48.2.1&ulong	308
21.48.2.19virtual_addr_t	308
21.48.2.20virtual_size_t	308
21.49include/sbi/sbi_unpriv.h File Reference	309
21.49.1 Macro Definition Documentation	309
21.49.1.1 DECLARE_UNPRIVILEGED_LOAD_FUNCTION	310
21.49.1.2 DECLARE_UNPRIVILEGED_STORE_FUNCTION	310
21.49.2 Function Documentation	310
21.49.2.1 sbi_get_insn()	310
21.50include/sbi/sbi_version.h File Reference	311
21.50.1 Macro Definition Documentation	311
21.50.1.1 OPENSBI_VERSION	311
21.50.1.2 OPENSBI_VERSION_MAJOR	312
21.50.1.3 OPENSBI_VERSION_MINOR	312
21.51 include/sbi_utils/irqchip/plic.h File Reference	312
21.51.1 Function Documentation	313
21.51.1.1 plic_cold_irqchip_init()	313
21.51.1.2 plic_fdt_fixup()	313
21.51.1.3 plic_set_ie()	314
21.51.1.4 plic_set_thresh()	314

CONTENTS xliii

21.51.1.5 plic_warm_irqchip_init()
21.52include/sbi_utils/serial/sifive-uart.h File Reference
21.52.1 Function Documentation
21.52.1.1 sifive_uart_getc()
21.52.1.2 sifive_uart_init()
21.52.1.3 sifive_uart_putc()
21.53include/sbi_utils/serial/uart8250.h File Reference
21.53.1 Function Documentation
21.53.1.1 uart8250_getc()
21.53.1.2 uart8250_init()
21.53.1.3 uart8250_putc()
21.54include/sbi_utils/sys/clint.h File Reference
21.54.1 Function Documentation
21.54.1.1 clint_cold_ipi_init()
21.54.1.2 clint_cold_timer_init()
21.54.1.3 clint_ipi_clear()
21.54.1.4 clint_ipi_send()
21.54.1.5 clint_ipi_sync()
21.54.1.6 clint_timer_event_start()
21.54.1.7 clint_timer_event_stop()
21.54.1.8 clint_timer_value()
21.54.1.9 clint_warm_ipi_init()
21.54.1.10clint_warm_timer_init()
21.55include/sbi_utils/sys/htif.h File Reference
21.55.1 Function Documentation
21.55.1.1 htif_getc()
21.55.1.2 htif_putc()
21.55.1.3 htif_system_down()
21.56lib/sbi/riscv_asm.c File Reference
21.56.1 Function Documentation

XIIV CONTENTS

21.56.1.1 csr_read_num()
21.56.1.2 csr_write_num()
21.56.1.3 ctz()
21.56.1.4 misa_extension_imp()
21.56.1.5 misa_xlen()
21.56.1.6 pmp_get()
21.56.1.7 pmp_set()
21.57lib/sbi/riscv_atomic.c File Reference
21.57.1 Macro Definition Documentation
21.57.1.1atomic_op_bit
21.57.1.2atomic_op_bit_ord
21.57.1.3axchg
21.57.1.4cmpxchg
21.57.1.5NOP
21.57.1.6NOT
21.57.1.7xchg
21.57.1.8 axchg
21.57.1.9 cmpxchg
21.57.1.10xchg
21.57.2 Function Documentation
21.57.2.1 arch_atomic_cmpxchg()
21.57.2.2 arch_atomic_xchg()
21.57.2.3 atomic_add_return()
21.57.2.4 atomic_clear_bit()
21.57.2.5 atomic_raw_clear_bit()
21.57.2.6 atomic_raw_set_bit()
21.57.2.7 atomic_raw_xchg_uint()
21.57.2.8 atomic_raw_xchg_ulong()
21.57.2.9 atomic_read()
21.57.2.10atomic_set_bit()

CONTENTS xlv

21.57.2.11atomic_sub_return()	37
21.57.2.12atomic_write()	37
21.58lib/sbi/riscv_locks.c File Reference	37
21.58.1 Function Documentation	18
21.58.1.1 spin_lock()	18
21.58.1.2 spin_lock_check()	39
21.58.1.3 spin_trylock()	10
21.58.1.4 spin_unlock()	11
21.59lib/sbi_console.c File Reference	2
21.59.1 Macro Definition Documentation	4
21.59.1.1 PAD_ALTERNATE	4
21.59.1.2 PAD_RIGHT	4
21.59.1.3 PAD_ZERO	4
21.59.1.4 PRINT_BUF_LEN	4
21.59.1.5 va_arg	4
21.59.1.6 va_end	4
21.59.1.7 va_start	ŀ5
21.59.2 Typedef Documentation	15
21.59.2.1 va_list	ŀ5
21.59.3 Function Documentation	ŀ5
21.59.3.1 print()	15
21.59.3.2 printc()	16
21.59.3.3 printi()	16
21.59.3.4 prints()	١7
21.59.3.5 sbi_console_init()	18
21.59.3.6 sbi_dprintf()	18
21.59.3.7 sbi_getc()	١9
21.59.3.8 sbi_gets()	50
21.59.3.9 sbi_isprintable()	50
21.59.3.10sbi_printf()	50

XIVI CONTENTS

21.59.3.11sbi_putc()
21.59.3.12sbi_puts()
21.59.3.13sbi_snprintf()
21.59.3.14sbi_sprintf()
21.59.4 Variable Documentation
21.59.4.1 console_out_lock
21.59.4.2 console_plat
21.60lib/sbi/sbi_ecall.c File Reference
21.60.1 Function Documentation
21.60.1.1 sbi_ecall_find_extension()
21.60.1.2 sbi_ecall_handler()
21.60.1.3 sbi_ecall_init()
21.60.1.4 sbi_ecall_register_extension()
21.60.1.5 sbi_ecall_unregister_extension()
21.60.1.6 sbi_ecall_version_major()
21.60.1.7 sbi_ecall_version_minor()
21.60.1.8 SBI_LIST_HEAD()
21.61lib/sbi/sbi_ecall_base.c File Reference
21.61.1 Function Documentation
21.61.1.1 sbi_ecall_base_handler()
21.61.1.2 sbi_ecall_base_probe()
21.61.2 Variable Documentation
21.61.2.1 ecall_base
21.62lib/sbi/sbi_ecall_legacy.c File Reference
21.62.1 Function Documentation
21.62.1.1 sbi_ecall_legacy_handler()
21.62.1.2 sbi_load_hart_mask_unpriv()
21.62.2 Variable Documentation
21.62.2.1 ecall_legacy
21.63lib/sbi/sbi_ecall_replace.c File Reference

CONTENTS xlvii

21.63.1 Function Documentation
21.63.1.1 sbi_ecall_ipi_handler()
21.63.1.2 sbi_ecall_rfence_handler()
21.63.1.3 sbi_ecall_time_handler()
21.63.2 Variable Documentation
21.63.2.1 ecall_ipi
21.63.2.2 ecall_rfence
21.63.2.3 ecall_time
21.64lib/sbi/sbi_ecall_vendor.c File Reference
21.64.1 Function Documentation
21.64.1.1 sbi_ecall_vendor_handler()
21.64.1.2 sbi_ecall_vendor_probe()
21.64.2 Variable Documentation
21.64.2.1 ecall_vendor
21.65lib/sbi/sbi_emulate_csr.c File Reference
21.65.1 Function Documentation
21.65.1.1 sbi_emulate_csr_read()
21.65.1.2 sbi_emulate_csr_write()
21.66lib/sbi/sbi_fifo.c File Reference
21.66.1 Function Documentation
21.66.1.1sbi_fifo_enqueue()
21.66.1.2sbi_fifo_is_empty()
21.66.1.3sbi_fifo_is_full()
21.66.1.4sbi_fifo_reset()
21.66.1.5 sbi_fifo_avail()
21.66.1.6 sbi_fifo_dequeue()
21.66.1.7 sbi_fifo_enqueue()
21.66.1.8 sbi_fifo_init()
21.66.1.9 sbi_fifo_inplace_update()
21.66.1.10sbi_fifo_is_empty()

xlviii CONTENTS

21.66.1.11sbi_fifo_is_full()	377
21.66.1.12sbi_fifo_reset()	377
21.67lib/sbi/sbi_hart.c File Reference	378
21.67.1 Macro Definition Documentation	379
21.67.1.1 COLDBOOT_WAIT_BITMAP_SIZE	379
21.67.2 Typedef Documentation	379
21.67.2.1 h2s	379
21.67.3 Function Documentation	379
21.67.3.1attribute()	379
21.67.3.2 delegate_traps()	380
21.67.3.3 fp_init()	380
21.67.3.4 log2roundup()	380
21.67.3.5 mstatus_init()	381
21.67.3.6 pmp_init()	381
21.67.3.7 sbi_current_hartid()	382
21.67.3.8 sbi_hart_available_mask()	382
21.67.3.9 sbi_hart_delegation_dump()	383
21.67.3.10sbi_hart_get_trap_info()	383
21.67.3.11sbi_hart_id_to_scratch()	384
21.67.3.12sbi_hart_init()	384
21.67.3.13sbi_hart_mark_available()	385
21.67.3.14sbi_hart_pmp_dump()	386
21.67.3.15sbi_hart_set_trap_info()	387
21.67.3.16sbi_hart_unmark_available()	387
21.67.3.17sbi_hart_wait_for_coldboot()	388
21.67.3.18sbi_hart_wake_coldboot_harts()	388
21.67.4 Variable Documentation	389
21.67.4.1 avail_hart_mask	389
21.67.4.2 avail_hart_mask_lock	389
21.67.4.3 coldboot_done	389

CONTENTS xlix

21.67.4.4 coldboot_lock	39
21.67.4.5 coldboot_wait_bitmap	39
21.67.4.6 trap_info_offset	90
21.68lib/sbi_illegal_insn.c File Reference	90
21.68.1 Typedef Documentation	90
21.68.1.1 illegal_insn_func)1
21.68.2 Function Documentation)1
21.68.2.1 sbi_illegal_insn_handler())1
21.68.2.2 system_opcode_insn()) 2
21.68.2.3 truly_illegal_insn()) 2
21.68.3 Variable Documentation	33
21.68.3.1 illegal_insn_table	33
21.69lib/sbi_init.c File Reference	93
21.69.1 Macro Definition Documentation) 4
21.69.1.1 BANNER)4
21.69.2 Function Documentation) 4
21.69.2.1 init_coldboot()) 4
21.69.2.2 init_warmboot()	96
21.69.2.3 sbi_boot_prints()	96
21.69.2.4 sbi_exit()) 7
21.69.2.5 sbi_init()	98
21.69.2.6 sbi_init_count()	9
21.69.3 Variable Documentation)0
21.69.3.1 coldboot_lottery)0
21.69.3.2 init_count_offset)0
21.70lib/sbi_ipi.c File Reference)0
21.70.1 Function Documentation)1
21.70.1.1 sbi_ipi_clear_smode())1
21.70.1.2 sbi_ipi_event_create())2
21.70.1.3 sbi_ipi_event_destroy())2

I CONTENTS

21.70.1.4 sbi_ipi_exit()	402
21.70.1.5 sbi_ipi_init()	403
21.70.1.6 sbi_ipi_process()	404
21.70.1.7 sbi_ipi_process_halt()	404
21.70.1.8 sbi_ipi_process_smode()	405
21.70.1.9 sbi_ipi_send()	405
21.70.1.10sbi_ipi_send_halt()	406
21.70.1.11sbi_ipi_send_many()	407
21.70.1.12sbi_ipi_send_smode()	407
21.70.2 Variable Documentation	408
21.70.2.1 ipi_data_off	408
21.70.2.2 ipi_halt_event	408
21.70.2.3 ipi_halt_ops	409
21.70.2.4 ipi_ops_array	409
21.70.2.5 ipi_smode_event	409
21.70.2.6 ipi_smode_ops	409
21.71 lib/sbi/sbi_misaligned_ldst.c File Reference	410
21.71.1 Function Documentation	410
21.71.1.1 sbi_misaligned_load_handler()	410
21.71.1.2 sbi_misaligned_store_handler()	411
21.72lib/sbi/sbi_scratch.c File Reference	412
21.72.1 Function Documentation	413
21.72.1.1 sbi_scratch_alloc_offset()	413
21.72.1.2 sbi_scratch_free_offset()	414
21.72.2 Variable Documentation	414
21.72.2.1 extra_lock	414
21.72.2.2 extra_offset	414
21.73lib/sbi/sbi_string.c File Reference	414
21.73.1 Function Documentation	415
21.73.1.1 sbi_memchr()	415

21.73.1.2 sbi_memcmp()	 415
21.73.1.3 sbi_memcpy()	 415
21.73.1.4 sbi_memmove()	 416
21.73.1.5 sbi_memset()	 416
21.73.1.6 sbi_strchr()	 416
21.73.1.7 sbi_strcmp()	 416
21.73.1.8 sbi_strcpy()	 417
21.73.1.9 sbi_strlen()	 417
21.73.1.10sbi_strncpy()	 417
21.73.1.11sbi_strnlen()	 417
21.73.1.12sbi_strrchr()	 418
21.74lib/sbi/sbi_system.c File Reference	 418
21.74.1 Function Documentation	 419
21.74.1.1 sbi_system_early_exit()	 419
21.74.1.2 sbi_system_early_init()	 419
21.74.1.3 sbi_system_final_exit()	 420
21.74.1.4 sbi_system_final_init()	 420
21.74.1.5 sbi_system_reboot()	 421
21.74.1.6 sbi_system_shutdown()	 421
21.75lib/sbi/sbi_timer.c File Reference	 422
21.75.1 Function Documentation	 423
21.75.1.1 get_ticks()	 423
21.75.1.2 sbi_timer_event_start()	 423
21.75.1.3 sbi_timer_exit()	 424
21.75.1.4 sbi_timer_get_delta()	 424
21.75.1.5 sbi_timer_init()	 425
21.75.1.6 sbi_timer_process()	 425
21.75.1.7 sbi_timer_set_delta()	 426
21.75.1.8 sbi_timer_set_delta_upper()	 426
21.75.1.9 sbi_timer_value()	 426

lii CONTENTS

21.75.1.10sbi_timer_virt_value()
21.75.2 Variable Documentation
21.75.2.1 time_delta_off
21.76lib/sbi/sbi_tlb.c File Reference
21.76.1 Function Documentation
21.76.1.1sbi_tlb_range_check()
21.76.1.2 sbi_tlb_entry_process()
21.76.1.3 sbi_tlb_flush_all()
21.76.1.4 sbi_tlb_hfence_gvma()
21.76.1.5 sbi_tlb_hfence_gvma_vmid()
21.76.1.6 sbi_tlb_hfence_vvma()
21.76.1.7 sbi_tlb_hfence_vvma_asid()
21.76.1.8 sbi_tlb_init()
21.76.1.9 sbi_tlb_local_flush()
21.76.1.10sbi_tlb_process()
21.76.1.11sbi_tlb_process_count()
21.76.1.12sbi_tlb_request()
21.76.1.13sbi_tlb_sfence_vma()
21.76.1.14sbi_tlb_sfence_vma_asid()
21.76.1.15sbi_tlb_sync()
21.76.1.16sbi_tlb_update()
21.76.1.17sbi_tlb_update_cb()
21.76.2 Variable Documentation
21.76.2.1 tlb_event
21.76.2.2 tlb_fifo_mem_off
21.76.2.3 tlb_fifo_off
21.76.2.4 tlb_ops
21.76.2.5 tlb_range_flush_limit
21.76.2.6 tlb_sync_off
21.77lib/sbi/sbi_trap.c File Reference

21.77.1 Function Documentation
21.77.1.1 sbi_trap_error()
21.77.1.2 sbi_trap_handler()
21.77.1.3 sbi_trap_redirect()
21.78lib/sbi_unpriv.c File Reference
21.78.1 Macro Definition Documentation
21.78.1.1 DEFINE_UNPRIVILEGED_LOAD_FUNCTION
21.78.1.2 DEFINE_UNPRIVILEGED_STORE_FUNCTION
21.78.2 Function Documentation
21.78.2.1 sbi_get_insn()
21.78.2.2 sbi_load_u64()
21.78.2.3 sbi_store_u64()
21.79lib/utils/irqchip/plic.c File Reference
21.79.1 Macro Definition Documentation
21.79.1.1 PLIC_CONTEXT_BASE
21.79.1.2 PLIC_CONTEXT_STRIDE
21.79.1.3 PLIC_ENABLE_BASE
21.79.1.4 PLIC_ENABLE_STRIDE
21.79.1.5 PLIC_PENDING_BASE
21.79.1.6 PLIC_PRIORITY_BASE
21.79.2 Function Documentation
21.79.2.1 plic_cold_irqchip_init()
21.79.2.2 plic_fdt_fixup()
21.79.2.3 plic_set_ie()
21.79.2.4 plic_set_priority()
21.79.2.5 plic_set_thresh()
21.79.2.6 plic_warm_irqchip_init()
21.79.3 Variable Documentation
21.79.3.1 plic_base
21.79.3.2 plic_hart_count

liv CONTENTS

21.79.3.3 plic_num_sources	451
21.80lib/utils/libfdt/fdt.c File Reference	452
21.80.1 Function Documentation	453
21.80.1.1 check_block_()	453
21.80.1.2 check_off_()	453
21.80.1.3 fdt_check_header()	454
21.80.1.4 fdt_check_node_offset_()	454
21.80.1.5 fdt_check_prop_offset_()	455
21.80.1.6 fdt_find_string_()	456
21.80.1.7 fdt_first_subnode()	456
21.80.1.8 fdt_header_size_()	457
21.80.1.9 fdt_move()	458
21.80.1.10fdt_next_node()	458
21.80.1.11fdt_next_subnode()	459
21.80.1.12fdt_next_tag()	460
21.80.1.13fdt_offset_ptr()	461
21.80.1.14fdt_ro_probe_()	462
21.81 lib/utils/libfdt/fdt.h File Reference	463
21.81.1 Macro Definition Documentation	463
21.81.1.1 FDT_BEGIN_NODE	463
21.81.1.2 FDT_END	463
21.81.1.3 FDT_END_NODE	464
21.81.1.4 FDT_MAGIC	464
21.81.1.5 FDT_NOP	464
21.81.1.6 FDT_PROP	464
21.81.1.7 FDT_TAGSIZE	464
21.81.1.8 FDT_V16_SIZE	464
21.81.1.9 FDT_V17_SIZE	464
21.81.1.10FDT_V1_SIZE	465
21.81.1.11FDT_V2_SIZE	465

21.81.1.12FDT_V3_SIZE
21.82lib/utils/libfdt/fdt_addresses.c File Reference
21.82.1 Function Documentation
21.82.1.1 fdt_address_cells()
21.82.1.2 fdt_cells()
21.82.1.3 fdt_size_cells()
21.83lib/utils/libfdt/fdt_empty_tree.c File Reference
21.83.1 Function Documentation
21.83.1.1 fdt_create_empty_tree()
21.84lib/utils/libfdt/fdt_overlay.c File Reference
21.84.1 Function Documentation
21.84.1.1 fdt_overlay_apply()
21.84.1.2 get_path_len()
21.84.1.3 overlay_adjust_local_phandles()
21.84.1.4 overlay_adjust_node_phandles()
21.84.1.5 overlay_apply_node()
21.84.1.6 overlay_fixup_one_phandle()
21.84.1.7 overlay_fixup_phandle()
21.84.1.8 overlay_fixup_phandles()
21.84.1.9 overlay_get_target()
21.84.1.10overlay_get_target_phandle()
21.84.1.11overlay_merge()
21.84.1.12overlay_phandle_add_offset()
21.84.1.13overlay_symbol_update()
21.84.1.14overlay_update_local_node_references()
21.84.1.15overlay_update_local_references()
21.85lib/utils/libfdt/fdt_ro.c File Reference
21.85.1 Function Documentation
21.85.1.1 fdt_check_full()
21.85.1.2 fdt_first_property_offset()

Ivi CONTENTS

21.85.1.3 fdt_get_alias()
21.85.1.4 fdt_get_alias_namelen()
21.85.1.5 fdt_get_max_phandle()
21.85.1.6 fdt_get_mem_rsv()
21.85.1.7 fdt_get_name()
21.85.1.8 fdt_get_path()
21.85.1.9 fdt_get_phandle()
21.85.1.10fdt_get_property()
21.85.1.11fdt_get_property_by_offset()
21.85.1.12/dt_get_property_by_offset_()
21.85.1.13fdt_get_property_namelen()
21.85.1.14fdt_get_property_namelen_()
21.85.1.15fdt_get_string()
21.85.1.16fdt_getprop()
21.85.1.17fdt_getprop_by_offset()
21.85.1.18fdt_getprop_namelen()
21.85.1.19fdt_mem_rsv()
21.85.1.20fdt_next_property_offset()
21.85.1.21fdt_node_check_compatible()
21.85.1.22fdt_node_depth()
21.85.1.23fdt_node_offset_by_compatible()
21.85.1.24fdt_node_offset_by_phandle()
21.85.1.25fdt_node_offset_by_prop_value()
21.85.1.26fdt_nodename_eq_()
21.85.1.27fdt_num_mem_rsv()
21.85.1.28fdt_parent_offset()
21.85.1.29fdt_path_offset()
21.85.1.30fdt_path_offset_namelen()
21.85.1.31fdt_string()
21.85.1.32fdt_string_eq_()

21.85.1.33fdt_stringlist_contains()	 509
21.85.1.34fdt_stringlist_count()	 510
21.85.1.35dt_stringlist_get()	 511
21.85.1.36dt_stringlist_search()	 511
21.85.1.37/dt_subnode_offset()	 512
21.85.1.38fdt_subnode_offset_namelen()	 513
21.85.1.39fdt_supernode_atdepth_offset()	 513
21.85.1.40nextprop_()	 514
21.86lib/utils/libfdt/fdt_rw.c File Reference	 515
21.86.1 Macro Definition Documentation	 517
21.86.1.1 FDT_RW_PROBE	 517
21.86.2 Function Documentation	 517
21.86.2.1 fdt_add_mem_rsv()	 517
21.86.2.2 fdt_add_property_()	 518
21.86.2.3 fdt_add_subnode()	 518
21.86.2.4 fdt_add_subnode_namelen()	 519
21.86.2.5 fdt_appendprop()	 519
21.86.2.6 fdt_blocks_misordered_()	 520
21.86.2.7 fdt_data_size_()	 521
21.86.2.8 fdt_del_mem_rsv()	 521
21.86.2.9 fdt_del_node()	 522
21.86.2.10fdt_delprop()	 522
21.86.2.11fdt_find_add_string_()	 523
21.86.2.12/dt_open_into()	 523
21.86.2.13fdt_pack()	 524
21.86.2.14fdt_packblocks_()	 524
21.86.2.15fdt_resize_property_()	 525
21.86.2.16fdt_rw_probe_()	 525
21.86.2.17fdt_set_name()	 526
21.86.2.18fdt_setprop()	 526

Iviii CONTENTS

21.86.2.19fdt_setprop_placeholder()	27
21.86.2.20dt_splice_()	27
21.86.2.21fdt_splice_mem_rsv_()	28
21.86.2.22/dt_splice_string_()	29
21.86.2.23fdt_splice_struct_()	29
21.87lib/utils/libfdt/fdt_strerror.c File Reference	30
21.87.1 Macro Definition Documentation	31
21.87.1.1 FDT_ERRTABENT	31
21.87.1.2 FDT_ERRTABSIZE	31
21.87.2 Function Documentation	31
21.87.2.1 fdt_strerror()	31
21.87.3 Variable Documentation	31
21.87.3.1 fdt_errtable	32
21.88lib/utils/libfdt/fdt_sw.c File Reference	32
21.88.1 Macro Definition Documentation	33
21.88.1.1 FDT_SW_PROBE	33
21.88.1.2 FDT_SW_PROBE_MEMRSV	33
21.88.1.3 FDT_SW_PROBE_STRUCT	34
21.88.2 Function Documentation	34
21.88.2.1 fdt_add_reservemap_entry()	34
21.88.2.2 fdt_begin_node()	35
21.88.2.3 fdt_create()	35
21.88.2.4 fdt_end_node()	36
21.88.2.5 fdt_find_add_string_()	36
21.88.2.6 fdt_finish()	37
21.88.2.7 fdt_finish_reservemap()	38
21.88.2.8 fdt_grab_space_()	38
21.88.2.9 fdt_property()	39
21.88.2.10fdt_property_placeholder()	40
21.88.2.11fdt_resize()	40

21.88.2.12/dt_sw_probe_()	541
21.88.2.13fdt_sw_probe_memrsv_()	541
21.88.2.14fdt_sw_probe_struct_()	541
21.89lib/utils/libfdt/fdt_wip.c File Reference	542
21.89.1 Function Documentation	542
21.89.1.1 fdt_node_end_offset_()	543
21.89.1.2 fdt_nop_node()	543
21.89.1.3 fdt_nop_property()	544
21.89.1.4 fdt_nop_region_()	545
21.89.1.5 fdt_setprop_inplace()	545
21.89.1.6 fdt_setprop_inplace_namelen_partial()	546
21.90lib/utils/libfdt/libfdt.h File Reference	546
21.90.1 Macro Definition Documentation	552
21.90.1.1 fdt_appendprop_string	552
21.90.1.2 fdt_boot_cpuid_phys	552
21.90.1.3 FDT_ERR_BADLAYOUT	553
21.90.1.4 FDT_ERR_BADMAGIC	553
21.90.1.5 FDT_ERR_BADNCELLS	553
21.90.1.6 FDT_ERR_BADOFFSET	553
21.90.1.7 FDT_ERR_BADOVERLAY	553
21.90.1.8 FDT_ERR_BADPATH	553
21.90.1.9 FDT_ERR_BADPHANDLE	553
21.90.1.10FDT_ERR_BADSTATE	553
21.90.1.11FDT_ERR_BADSTRUCTURE	554
21.90.1.12FDT_ERR_BADVALUE	554
21.90.1.13FDT_ERR_BADVERSION	554
21.90.1.14FDT_ERR_EXISTS	554
21.90.1.15FDT_ERR_INTERNAL	554
21.90.1.16FDT_ERR_MAX	554
21.90.1.17FDT_ERR_NOPHANDLES	554

IX

21.90.1.18-DI_ERR_NOSPACE	4ر
21.90.1.19FDT_ERR_NOTFOUND	55
21.90.1.20FDT_ERR_TRUNCATED	55
21.90.1.21FDT_FIRST_SUPPORTED_VERSION	55
21.90.1.22/dt_for_each_property_offset	55
21.90.1.23fdt_for_each_subnode	56
21.90.1.24fdt_get_header	56
21.90.1.25dt_last_comp_version	56
21.90.1.26FDT_LAST_SUPPORTED_VERSION	56
21.90.1.27dt_magic	56
21.90.1.28FDT_MAX_NCELLS	57
21.90.1.29dt_off_dt_strings	57
21.90.1.30fdt_off_dt_struct	57
21.90.1.31fdt_off_mem_rsvmap	57
21.90.1.32dt_property_string	57
21.90.1.33fdt_set_hdr	57
21.90.1.34fdt_setprop_empty	58
21.90.1.35dt_setprop_string	58
21.90.1.36dt_size_dt_strings	58
21.90.1.37/dt_size_dt_struct	58
21.90.1.38dt_totalsize	58
21.90.1.39'dt_version	58
21.90.2 Function Documentation	58
21.90.2.1 fdt32_ld()	59
21.90.2.2 fdt64_ld()	59
21.90.2.3 fdt_add_mem_rsv()	30
21.90.2.4 fdt_add_reservemap_entry()	31
21.90.2.5 fdt_add_subnode()	31
21.90.2.6 fdt_add_subnode_namelen()	32
21.90.2.7 fdt_address_cells()	32

21.90.2.8 fdt_appendprop()	33
21.90.2.9 fdt_appendprop_cell()	64
21.90.2.10fdt_appendprop_u32()	64
21.90.2.11fdt_appendprop_u64()	65
21.90.2.12fdt_begin_node()	65
21.90.2.13fdt_check_full()	66
21.90.2.14fdt_check_header()	66
21.90.2.15fdt_create()	67
21.90.2.16fdt_create_empty_tree()	68
21.90.2.17fdt_del_mem_rsv()	68
21.90.2.18fdt_del_node()	39
21.90.2.19fdt_delprop()	39
21.90.2.20fdt_end_node()	70
21.90.2.21fdt_finish()	70
21.90.2.22fdt_finish_reservemap()	71
21.90.2.23fdt_first_property_offset()	72
21.90.2.24fdt_first_subnode()	73
21.90.2.25dt_get_alias()	73
21.90.2.26fdt_get_alias_namelen()	74
21.90.2.27/dt_get_max_phandle()	75
21.90.2.28fdt_get_mem_rsv()	75
21.90.2.29fdt_get_name()	76
21.90.2.30fdt_get_path()	77
21.90.2.31fdt_get_phandle()	78
21.90.2.32/dt_get_property()	79
21.90.2.33fdt_get_property_by_offset()	79
21.90.2.34fdt_get_property_namelen()	30
21.90.2.35dt_get_property_w()	31
21.90.2.36fdt_get_string()	31
21.90.2.37fdt_getprop()	32

lxii CONTENTS

21.90.2.3&dt_getprop_by_offset()
21.90.2.39dt_getprop_namelen()
21.90.2.40fdt_getprop_namelen_w()
21.90.2.41fdt_getprop_w()
21.90.2.42/dt_header_size()
21.90.2.43dt_header_size_()
21.90.2.44fdt_move()
21.90.2.45dt_next_node()
21.90.2.46fdt_next_property_offset()
21.90.2.47/dt_next_subnode()
21.90.2.48fdt_next_tag()
21.90.2.49dt_node_check_compatible()
21.90.2.50fdt_node_depth()
21.90.2.51fdt_node_offset_by_compatible()
21.90.2.52/dt_node_offset_by_phandle()
21.90.2.53fdt_node_offset_by_prop_value()
21.90.2.54fdt_nop_node()
21.90.2.55dt_nop_property()
21.90.2.56dt_num_mem_rsv()
21.90.2.57/dt_offset_ptr()
21.90.2.58fdt_offset_ptr_w()
21.90.2.59'dt_open_into()
21.90.2.60fdt_overlay_apply()
21.90.2.61fdt_pack()
21.90.2.62/dt_parent_offset()
21.90.2.63'dt_path_offset()
21.90.2.64fdt_path_offset_namelen()
21.90.2.65fdt_property()
21.90.2.66dd_property_cell()
21.90.2.67/dt_property_placeholder()

21.90.2.68'dt_property_u32()
21.90.2.69'dt_property_u64()
21.90.2.70fdt_resize()
21.90.2.71fdt_set_hdr_() [1/10]
21.90.2.72fdt_set_hdr_() [2/10]
21.90.2.73fdt_set_hdr_() [3/10]
21.90.2.74fdt_set_hdr_() [4/10]
21.90.2.75dt_set_hdr_() [5/10]
21.90.2.76dt_set_hdr_() [6/10]
21.90.2.77dt_set_hdr_() [7/10]
21.90.2.78'dt_set_hdr_() [8/10]
21.90.2.79'dt_set_hdr_() [9/10]
21.90.2.80fdt_set_hdr_() [10/10]
21.90.2.81fdt_set_name()
21.90.2.82fdt_setprop()
21.90.2.83fdt_setprop_cell()
21.90.2.84fdt_setprop_inplace()
21.90.2.85dt_setprop_inplace_cell()
21.90.2.86dt_setprop_inplace_namelen_partial() 611
21.90.2.87fdt_setprop_inplace_u32()
21.90.2.88fdt_setprop_inplace_u64()
21.90.2.89fdt_setprop_placeholder()
21.90.2.90fdt_setprop_u32()
21.90.2.91fdt_setprop_u64()
21.90.2.92fdt_size_cells()
21.90.2.93fdt_strerror()
21.90.2.94fdt_string()
21.90.2.95fdt_stringlist_contains()
21.90.2.96fdt_stringlist_count()
21.90.2.97/dt stringlist get()

lxiv CONTENTS

21.90.2.98dt_stringlist_search()	18
21.90.2.99dt_subnode_offset()	18
21.90.2.10fdt_subnode_offset_namelen()	19
21.90.2.10fdt_supernode_atdepth_offset()	20
21.91lib/utils/libfdt/libfdt_env.h File Reference	20
21.91.1 Macro Definition Documentation	22
21.91.1.1 CPU_TO_FDT16	22
21.91.1.2 CPU_TO_FDT32	22
21.91.1.3 CPU_TO_FDT64	22
21.91.1.4 EXTRACT_BYTE	23
21.91.1.5 FDT_BITWISE	23
21.91.1.6 FDT_FORCE	23
21.91.1.7 INT_MAX	23
21.91.1.8 memchr	23
21.91.1.9 memcmp	23
21.91.1.10memcpy	23
21.91.1.11memmove	24
21.91.1.12memset	24
21.91.1.13strchr	24
21.91.1.14strcmp	24
21.91.1.15strcpy	24
21.91.1.16strlen	24
21.91.1.17strnlen	24
21.91.1.18strrchr	24
21.91.1.19UINT_MAX	25
21.91.2 Typedef Documentation	25
21.91.2.1 fdt16_t	25
21.91.2.2 fdt32_t	25
21.91.2.3 fdt64_t	25
21.91.3 Function Documentation	25

21.91.3.1 cpu_to_fdt16()	625
21.91.3.2 cpu_to_fdt32()	626
21.91.3.3 cpu_to_fdt64()	626
21.91.3.4 fdt16_to_cpu()	627
21.91.3.5 fdt32_to_cpu()	627
21.91.3.6 fdt64_to_cpu()	627
21.92lib/utils/libfdt/libfdt_internal.h File Reference	628
21.92.1 Macro Definition Documentation	628
21.92.1.1 FDT_ALIGN	629
21.92.1.2 FDT_RO_PROBE	629
21.92.1.3 FDT_SW_MAGIC	629
21.92.1.4 FDT_TAGALIGN	629
21.92.2 Function Documentation	629
21.92.2.1 fdt_check_node_offset_()	630
21.92.2.2 fdt_check_prop_offset_()	630
21.92.2.3 fdt_find_string_()	631
21.92.2.4 fdt_mem_rsv_()	632
21.92.2.5 fdt_mem_rsv_w_()	632
21.92.2.6 fdt_node_end_offset_()	633
21.92.2.7 fdt_offset_ptr_()	633
21.92.2.8 fdt_offset_ptr_w_()	634
21.92.2.9 fdt_ro_probe_()	634
21.93lib/utils/serial/sifive-uart.c File Reference	635
21.93.1 Macro Definition Documentation	636
21.93.1.1 UART_REG_DIV	636
21.93.1.2 UART_REG_IE	636
21.93.1.3 UART_REG_IP	636
21.93.1.4 UART_REG_RXCTRL	637
21.93.1.5 UART_REG_RXFIFO	637
21.93.1.6 UART_REG_TXCTRL	637

lxvi CONTENTS

Ixviii CONTENTS

21.95.1.6 clint_time_rd64()	350
21.95.1.7 clint_time_wr32()	351
21.95.1.8 clint_time_wr64()	351
21.95.1.9 clint_timer_event_start()	351
21.95.1.10clint_timer_event_stop()	352
21.95.1.11clint_timer_value()	352
21.95.1.12clint_warm_ipi_init()	352
21.95.1.13clint_warm_timer_init()	353
21.95.2 Variable Documentation	353
21.95.2.1 clint_ipi	353
21.95.2.2 clint_ipi_base	353
21.95.2.3 clint_ipi_hart_count	353
21.95.2.4 clint_time_base	353
21.95.2.5 clint_time_cmp	354
21.95.2.6 clint_time_hart_count	354
21.95.2.7 clint_time_rd	354
21.95.2.8 clint_time_val	354
21.95.2.9 clint_time_wr	354
21.96lib/utils/sys/htif.c File Reference	354
21.96.1 Macro Definition Documentation	355
21.96.1.1 FROMHOST_CMD	355
21.96.1.2 FROMHOST_DATA	356
21.96.1.3 FROMHOST_DEV	356
21.96.1.4 HTIF_CMD_BITS	356
21.96.1.5 HTIF_CMD_MASK	356
21.96.1.6 HTIF_CMD_SHIFT	356
21.96.1.7 HTIF_CONSOLE_CMD_GETC	356
21.96.1.8 HTIF_CONSOLE_CMD_PUTC	356
21.96.1.9 HTIF_DATA_BITS	357
21.96.1.10HTIF_DATA_MASK	357

21.96.1.11HTIF_DATA_SHIFT	657
21.96.1.12HTIF_DEV_BITS	657
21.96.1.13HTIF_DEV_CONSOLE	657
21.96.1.14HTIF_DEV_MASK	657
21.96.1.15HTIF_DEV_SHIFT	657
21.96.1.16HTIF_DEV_SYSTEM	657
21.96.1.17PK_SYS_write	658
21.96.1.18TOHOST_CMD	658
21.96.2 Function Documentation	658
21.96.2.1attribute()	658
21.96.2.2check_fromhost()	658
21.96.2.3set_tohost()	659
21.96.2.4 htif_getc()	659
21.96.2.5 htif_putc()	660
21.96.2.6 htif_system_down()	660
21.96.3 Variable Documentation	660
21.96.3.1 htif_console_buf	660
21.96.3.2 htif_lock	661
21.97README.md File Reference	661
Index	663

README

Copyright (c) 2019 Western Digital Corporation or its affiliates and other contributors.

RISC-V Open Source Supervisor Binary Interface (OpenSBI)

The RISC-V Supervisor Binary Interface (SBI) is the recommended interface between:

- 1. A platform-specific firmware running in M-mode and a bootloader, a hypervisor or a general-purpose OS executing in S-mode or HS-mode.
- 2. A hypervisor running in HS-mode and a bootloader or a general-purpose OS executing in VS-mode.

The RISC-V SBI specification is maintained as an independent project by the RISC-V Foundation on Github.

The goal of the OpenSBI project is to provide an open-source reference implementation of the RISC-V SBI specifications for platform-specific firmwares executing in M-mode (case 1 mentioned above). An OpenSBI implementation can be easily extended by RISC-V platform and system-on-chip vendors to fit a particular hardware configuration.

The main component of OpenSBI is provided in the form of a platform-independent static library **libsbi.a** implementing the SBI interface. A firmware or bootloader implementation can link against this library to ensure conformance with the SBI interface specifications. *libsbi.a* also defines an interface for integrating with platform-specific operations provided by the platform firmware implementation (e.g. console access functions, inter-processor interrupt control, etc).

To illustrate the use of the *libsbi.a* library, OpenSBI also provides a set of platform-specific support examples. For each example, a platform-specific static library *libplatsbi.a* can be compiled. This library implements SBI call processing by integrating *libsbi.a* with the necessary platform-dependent hardware manipulation functions. For all supported platforms, OpenSBI also provides several runtime firmware examples built using the platform *libplatsbi.a*. These example firmwares can be used to replace the legacy *riscv-pk* bootloader (aka BBL) and enable the use of well-known bootloaders such as U-Boot.

Required Toolchain

OpenSBI can be compiled natively or cross-compiled on a x86 host. For cross-compilation, you can build your own toolchain or just download a prebuilt one from the Bootlin toolchain repository.

Please note that only a 64-bit version of the toolchain is available in the Bootlin toolchain repository for now.

2 README

Building and Installing the OpenSBI Platform-Independent Library

The OpenSBI platform-independent static library *libsbi.a* can be compiled natively or it can be cross-compiled on a host with a different base architecture than RISC-V.

For cross-compiling, the environment variable *CROSS_COMPILE* must be defined to specify the name prefix of the RISC-V compiler toolchain executables, e.g. *riscv64-unknown-elf-* if the gcc executable used is *riscv64-unknown-elf-gcc*.

To build *libsbi.a* simply execute:

make

All compiled binaries as well as the resulting *libsbi.a* static library file will be placed in the *build/lib* directory. To specify an alternate build root directory path, run:

```
make O=<build_directory>
```

To generate files to be installed for using libsbi.a in other projects, run:

```
make install
```

This will create the *install*/directory with all necessary include files copied under the *install*/include directory and the library file copied into the *install*/lib directory. To specify an alternate installation root directory path, run:

```
make I=<install_directory> install
```

Building and Installing a Reference Platform Static Library and Firmware

When the *PLATFORM=*<*platform_subdir*> argument is specified on the make command line, the platform-specific static library *libplatsbi.a* and firmware examples are built for the platform *<platform_subdir>* present in the directory *platform* in the OpenSBI top directory. For example, to compile the platform library and the firmware examples for the QEMU RISC-V *virt* machine, *<platform_subdir>* should be *qemu/virt*.

To build *libsbi.a*, *libplatsbi.a* and the firmware for one of the supported platforms, run:

```
make PLATFORM=<platform_subdir>
```

An alternate build directory path can also be specified:

```
make PLATFORM=<platform_subdir> O=<build_directory>
```

The platform-specific library *libplatsbi.a* will be generated in the *build/platform/<platform_subdir>/lib* directory. The platform firmware files will be under the *build/platform/<platform_subdir>/firmware* directory. The compiled firmwares will be available in two different formats: an ELF file and an expanded image file.

To install *libsbi.a*, *libplatsbi.a*, and the compiled firmwares, run:

```
make PLATFORM=<platform_subdir> install
```

This will copy the compiled platform-specific libraries and firmware files under the *install/platform/<platform_\cup subdir>/* directory. An alternate install root directory path can be specified as follows:

```
make PLATFORM=<platform_subdir> I=<install_directory> install
```

In addition, platform-specific configuration options can be specified with the top-level make command line. These options, such as *PLATFORM_<xyz>* or *FW_<abc>*, are platform-specific and described in more details in the *docs/platform/<pplatform_name>.md* files and *docs/firmware/<firmware_name>.md* files.

Building 32-bit / 64-bit OpenSBI Images

By default, building OpenSBI generates 32-bit or 64-bit images based on the supplied RISC-V cross-compile toolchain. For example if *CROSS_COMPILE* is set to *riscv64-unknown-elf-**, *64-bit OpenSBI images will be generated. If building 32-bit OpenSBI images*, **CROSS_COMPILE* should be set to a toolchain that is pre-configured to generate 32-bit RISC-V codes, like *riscv32-unknown-elf-*.

However it's possible to explicitly specify the image bits we want to build with a given RISC-V toolchain. This can be done by setting the environment variable *PLATFORM_RISCV_XLEN* to the desired width, for example:

```
export CROSS_COMPILE=riscv64-unknown-elf-
export PLATFORM_RISCV_XLEN=32
```

will generate 32-bit OpenSBI images. And vice vesa.

License

OpenSBI is distributed under the terms of the BSD 2-clause license ("Simplified BSD License" or "FreeBSD License", SPDX: *BSD-2-Clause*). A copy of this license with OpenSBI copyright can be found in the file COPYIN← G, BSD.

All source files in OpenSBI contain the 2-Clause BSD license SPDX short identifier in place of the full license text.

```
SPDX-License-Identifier: BSD-2-Clause
```

This enables machine processing of license information based on the SPDX License Identifiers that are available on the SPDX web site.

OpenSBI source code also contains code reused from other projects as listed below. The original license text of these projects is included in the source files where the reused code is present.

• The libfdt source code is disjunctively dual licensed (GPL-2.0+ OR BSD-2-Clause). Some of this project code is used in OpenSBI under the terms of the BSD 2-Clause license. Any contributions to this code must be made under the terms of both licenses.

See also the third party notices file for more information.

Contributing to OpenSBI

The OpenSBI project encourages and welcomes contributions. Contributions should follow the rules described in the OpenSBI Contribution Guideline document. In particular, all patches sent should contain a Signed-off-by tag.

The Contributors List document provides a list of individuals and organizations actively contributing to the OpenSBI project.

4 README

Documentation

Detailed documentation of various aspects of OpenSBI can be found under the *docs* directory. The documentation covers the following topics.

- [Contribution Guideline]: Guideline for contributing code to OpenSBI project
- [Library Usage]: API documentation of OpenSBI static library libsbi.a
- [Platform Support Guide]: Guideline for implementing support for new platforms
- [Platform Documentation]: Documentation of the platforms currently supported.
- [Firmware Documentation]: Documentation for the different types of firmware examples build supported by OpenSBI.

OpenSBI source code is also well documented. For source level documentation, doxygen style is used. Please refer to the Doxygen manual for details on this format.

Doxygen can be installed on Linux distributions using *.deb* packages using the following command.

```
sudo apt-get install doxygen doxygen-latex doxygen-doc doxygen-gui graphviz
```

For *.rpm* based Linux distributions, the following commands can be used.

```
sudo yum install doxygen doxygen-latex doxywizard graphviz
```

or

```
sudo yum install doxygen doxygen-latex doxywizard graphviz
```

To build a consolidated *refman.pdf* of all documentation, run:

```
make docs
```

or

```
make O=<build_directory> docs
```

the resulting *refman.pdf* will be available under the directory *<bul>build_directory>/docs/latex*. To install this file, run:

```
make install_docs
```

or

```
{\tt make \ I=<install\_directory>\ install\_docs}
```

refman.pdf will be installed under *<install_directory>/docs*.

OpenSBI Contribution Guideline

All contributions to OpenSBI can be sent in the following ways:

- 1. Email patches to the OpenSBI mailing list at opensbi@lists.infradead.org
- 2. GitHub Pull Requests (PRs) to the OpenSBI main repository

To join the OpenSBI mailing list, please visit the OpenSBI infradead page.

The OpenSBI maintainers prefer patches via the OpenSBI mailing list (option 1 above) so that they are visible to a wider audience. All accepted patches on the OpenSBI mailing list will be taken by any of the OpenSBI maintainers and merged into the OpenSBI main repository using GitHub PRs.

All contributed work must follow the following rules:

- 1. OpenSBI code should be written in accordance to the Linux coding style.
- 2. This project embraces the <u>Developer Certificate</u> of <u>Origin</u> (DCO) for contributions. This means that you must agree to the following prior to submitting patches: if you agree with this developer certificate you acknowledge this by adding a Signed-off-by tag to your patch commit log. Every submitted patch must have this tag.
- 3. A commit message must have a subject line, followed by a blank line, followed by a description of the patch content. A blank line and the author Signed-off-by tag must follow this description.
- 4. A commit subject line must start with a prefix followed by a ":". Common prefixes are for example "lib:", "platform:", "firmware:", "docs:", "utils:" and "top:".
- 5. Maintainers should use "Rebase and Merge" when using GitHub to merge pull requests to avoid creating unnecessary merge commits.
- 6. Maintainers should avoid creating branches directly in the main riscv/opensbi repository. Instead prefer using a fork of the riscv/opensbi main repository and branches within that fork to create pull requests.
- 7. A maintainer cannot merge his own pull requests in the riscv/opensbi main repository.
- 8. A pull request must get at least one review from a maintainer.
- 9. A pull request must spend at least 24 hours in review to allow for other developers to review.

Developer Certificate of Origin Version 1.1

Copyright (C) 2004, 2006 The Linux Foundation and its contributors. 660 York Street, Suite 102, San Francisco, CA 94110 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Developer's Certificate of Origin 1.1

By making a contribution to this project, I certify that:

- (a) The contribution was created in whole or in part by me and I have the right to submit it under the open source license indicated in the file; or
- (b) The contribution is based upon previous work that, to the best of my knowledge, is covered under an appropriate open source license and I have the right under that license to submit that work with modifications, whether created in whole or in part by me, under the same open source license (unless I am permitted to submit under a different license), as indicated in the file; or
- (c) The contribution was provided directly to me by some other person who certified (a), (b) or (c) and I have not modified it.
- (d) I understand and agree that this project and the contribution are public and that a record of the contribution (including all personal information I submit with it, including my sign-off) is maintained indefinitely and may be redistributed consistent with this project or the open source license(s) involved.

OpenSBI Platform Support Guideline

The OpenSBI platform support allows an implementation to define a set of platform-specific hooks (hardware manipulation functions) in the form of a *struct sbi_platform* data structure instance. This instance is required by the platform-independent *libsbi.a* to execute platform-specific operations.

Each of the reference platform supports provided by OpenSBI defines an instance of the *struct sbi_platform* data structure. For each supported platform, *libplatsbi.a* integrates this instance with *libsbi.a* to create a platform-specific OpenSBI static library. This library is installed in *<install_directory>/platform/<platform_subdir>/lib/libplatsbi.a*

OpenSBI also provides implementation examples of bootable runtime firmwares for the supported platforms. These firmwares are linked against *libplatsbi.a*. Firmware binaries are installed in *<install_\(cup \) directory>/platform/<platform_subdir>/bin*. These firmwares can be used as executable runtime firmwares on the supported platforms as a replacement for the legacy *riskv-pk* boot loader (BBL).

A complete doxygen-style documentation of *struct sbi_platform* and related APIs is available in the file *include/sbi/sbi_platform.h*.

Adding support for a new platform

Support for a new platform named *<xyz>* can be added as follows:

- 1. Create a directory named *<xyz>* under the *platform/* directory.
- 2. Create a platform configuration file named *config.mk* under the *platform*/<*xyz*>/ directory. This configuration file will provide compiler flags, and select firmware options.
- 3. Create a platform/<xyz>/objects.mk file for listing the platform-specific object files to be compiled.
- 4. Create a *platform/<xyz>/platform.c* file providing a *struct sbi_platform* instance.

A platform support code template is available under the *platform/template* directory. Copying this directory and its content as a new directory named *<xyz>* under the *platform/* directory will create all the files mentioned above.

OpenSBI Library Usage

OpenSBI provides two types of static libraries:

- 1. *libsbi.a* A platform-independent generic static library implementing the interface defined by the SBI specifications. Platform-specific processing hooks for the execution of this interface must be provided by the firmware or bootloader linking with this library. This library is installed as *<install directory>/lib/libsbi.a*
- 2. *libsbiutils.a* A static library that will contain all common code required by any platform supported in OpenSBI. It will be built by default and included in libplatsbi.a. This library is installed as *<install_\circ} directory>/lib/libsbiutils.a*.
- 3. *libplatsbi.a* An example platform-specific static library integrating *libsbi.a* with platform-specific hooks. This library is available only for the platforms supported by OpenSBI. This library is installed as *<install_\circ} directory>/platform/<platform subdir>/lib/libplatsbi.a*

Implementations may choose either *libsbi.a* or *libplatsbi.a* to link with their firmware or bootloader. In the case of *libsbi.a*, platform-specific hooks in the form of a *struct sbi_platform* instance need to be provided.

The platform-specific example firmwares provided by OpenSBI are not mandatory. An implementation may choose to link the OpenSBI generic static library together with an M-mode firmware or bootloader providing the hardware-specific hooks. Since OpenSBI is a statically linked library, users must ensure that the license of these external components is compatible with the OpenSBI license.

Constraints on OpenSBI usage from external firmware

Users have to ensure that an external firmware or bootloader linking against OpenSBI static libraries (*libsbi.a* or *libplatsbi.a*) is compiled with the same GCC target options *-mabi*, *-march*, and *-mcmodel*.

There are only two constraints on calling any OpenSBI library function from an external M-mode firmware or bootloader:

- 1. The RISC-V MSCRATCH CSR must point to a valid OpenSBI scratch space (i.e. a struct sbi_scratch instance).
- 2. The RISC-V *SP* register (i.e. the stack pointer) must be set per-HART pointing to distinct non-overlapping stacks.

The most important functions from an external firmware or bootloader perspective are *sbi_init()* and *sbi_trap_* ← *handler()*.

In addition to the above constraints, the external firmware or bootloader must ensure that interrupts are disabled in the *MSTATUS* and *MIE* CSRs when calling the functions *sbi_init()* and *sbi_trap_handler()*.

The *sbi_init()* function should be called by the external firmware or bootloader for each HART that is powered-up at boot-time or in response to a CPU hotplug event.

The *sbi_trap_handler()* function should be called by the external firmware or bootloader to service the following interrupts and traps:

- 1. M-mode timer interrupt
- 2. M-mode software interrupt
- 3. Illegal instruction trap
- 4. Misaligned load trap
- 5. Misaligned store trap
- 6. Supervisor ecall trap
- 7. Hypervisor ecall trap

Note: external firmwares or bootloaders can be more conservative by forwarding all traps and interrupts to *sbi_\infty trap handler()*.

Definitions of OpenSBI Data Types for the External Firmware

OpenSBI can be built as library using external firmware build system such as EDK2 code base (The open source of UEFI firmware implementation) and linked with external firmware drivers based on the external firmware architecture.

OPENSBI_EXTERNAL_SBI_TYPES identifier is introduced to *sbi_types.h* for selecting external header file during the build preprocess in order to define OpensSBI data types based on external firmware data type binding. For example, *bool* is declared as *int* in *sbi_types.h*. However in EDK2 build system, *bool* is declared as *BOOLEAN* which is defined as *unsigned char* data type.

External firmware can define **OPENSBI_EXTERNAL_SBI_TYPES** in CFLAGS and specify it to the header file maintained in its code tree. However, the external build system has to address the additional include directory for the external header file based on its own build system. For example, -D***OPENSBI_EXTERNAL_SBI_TYP ES***=OpensbiTypes.h Above tells sbi_types.h to refer to OpensbiTypes.h instead of using original definitions of data types.

OpenSBI Platform Firmwares

OpenSBI provides firmware builds for specific platforms. Different types of firmwares are supported to deal with the differences between different platforms early boot stage. All firmwares will execute the same initialization procedure of the platform hardware according to the platform specific code as well as OpenSBI generic library code. The supported firmwares type will differ in how the arguments passed by the platform early boot stage are handled, as well as how the boot stage following the firmware will be handled and executed.

OpenSBI currently supports three different types of firmwares.

Firmware with Dynamic Information (FW DYNAMIC)

The *FW_DYNAMIC* firmware gets information about the next booting stage entry, e.g. a bootloader or an OS kernel, from previous booting stage at runtime.

A *FW_DYNAMIC* firmware is particularly useful when the booting stage executed prior to OpenSBI firmware is capable of loading both the OpenSBI firmware and the booting stage binary to follow OpenSBI firmware.

Firmware with Jump Address (FW_JUMP)

The FW_JUMP firmware assumes a fixed address of the next booting stage entry, e.g. a bootloader or an OS kernel, without directly including the binary code for this next stage.

A *FW_JUMP* firmware is particularly useful when the booting stage executed prior to OpenSBI firmware is capable of loading both the OpenSBI firmware and the booting stage binary to follow OpenSBI firmware.

Firmware with Payload (FW PAYLOAD)

The *FW_PAYLOAD* firmware directly includes the binary code for the booting stage to follow OpenSBI firmware execution. Typically, this payload will be a bootloader or an OS kernel.

A *FW_PAYLOAD* firmware is particularly useful when the booting stage executed prior to OpenSBI firmware is not capable of loading both OpenSBI firmware and the booting stage to follow OpenSBI firmware.

A FW_PAYLOAD firmware is also useful for cases where the booting stage prior to OpenSBI firmware does not pass a *flattened device tree (FDT file)*. In such case, a FW_PAYLOAD firmware allows embedding a flattened device tree in the .text section of the final firmware.

Firmware Configuration and Compilation

All firmware types mandate the definition of the following compile time configuration parameter.

• FW_TEXT_ADDR - Defines the address at which the previous booting stage loads OpenSBI firmware.

Additionally, each firmware type as a set of type specific configuration parameters. Detailed information for each firmware type can be found in the following documents.

- [FW_DYNAMIC]: The Firmware with Dynamic Information (FW_DYNAMIC) is described in more details in the file fw_dynamic.md.
- [FW_JUMP]: The Firmware with Jump Address (FW_JUMP) is described in more details in the file fw_← jump.md.
- [FW_PAYLOAD]: The Firmware with Payload (FW_PAYLOAD) is described in more details in the file fw_← payload.md.

Providing different payloads to OpenSBI Firmware

OpenSBI firmware can accept various payloads using a compile time option. Typically, these payloads refer to the next stage boot loader (e.g. U-Boot) or operating system kernel images (e.g. Linux). By default, OpenSBI automatically provides a test payload if no specific payload is specified at compile time.

To specify a payload at compile time, the make variable FW PAYLOAD PATH is used.

```
\verb|make PLATFORM=<| platform_subdir> FW_PAYLOAD_PATH=<| payload path>| payload payload path>| payload payload path>| payload pay
```

The instructions to build each payload is different and the details can be found in the *docs/firmware/payload_←* <payload_name>.md files.

Options for OpenSBI Firmware behaviors

An optional compile time flag FW OPTIONS can be used to control the OpenSBI firmware run-time behaviors.

```
make PLATFORM=<platform_subdir> FW_OPTIONS=<options>
```

FW_OPTIONS is a bitwise or'ed value of various options, eg: FW_OPTIONS=0x1 stands for disabling boot prints from the OpenSBI library.

For all supported options, please check "enum sbi_scratch_options" in the include/sbi/sbi_scratch.h header file.

OpenSBI Firmware with Dynamic Information *FW DYNAMIC*

OpenSBI **firmware with dynamic info (FW_DYNAMIC)** is a firmware which gets information about next booting stage (e.g. a bootloader or an OS) and runtime OpenSBI library options from previous booting stage.

The previous booting stage will pass information to *FW_DYNAMIC* by creating *struct fw_dynamic_info* in memory and passing it's address to *FW_DYNAMIC* via *a2* register of RISC-V CPU.

A *FW_DYNAMIC* firmware is particularly useful when the booting stage executed prior to OpenSBI firmware is capable of loading both the OpenSBI firmware and the booting stage binary to follow OpenSBI firmware.

FW_DYNAMIC Compilation

A platform can enable FW_DYNAMIC firmware using any of the following methods.

- 1. Specifying FW_DYNAMIC=y on the top level make command line.
- 2. Specifying FW_DYNAMIC=y in the target platform *config.mk* configuration file.

The compiled $FW_DYNAMIC$ firmware ELF file is named $fw_dynamic.elf$. It's expanded image file is $fw_dynamic.bin$. Both files are created in the platform specific build directory under the $build/platform/< platform_dynamic.bin$. Both files are created in the platform specific build directory under the $build/platform/< platform_dynamic.bin$.

FW_DYNAMIC Firmware Configuration Options

The *FW_DYNAMIC* firmware does not requires any platform specific configuration parameters because all required information is passed by previous booting stage at runtime via *struct fw_dynamic_info*.

	OpenSBI Firmware with D	vnamic Information *FW	DYNAMIC *
--	-------------------------	------------------------	------------------

OpenSBI Firmware with Jump Address *FW JUMP*

OpenSBI firmware with Jump Address (FW_JUMP) is a firmware which only handles the address of the next booting stage entry, e.g. a bootloader or an OS kernel, without directly including the binary code for this next stage.

A *FW_JUMP* firmware is particularly useful when the booting stage executed prior to the OpenSBI firmware is capable of loading both the OpenSBI firmware and the booting stage binary to follow the OpenSBI firmware.

FW_JUMP Compilation

A platform *FW JUMP* firmware can be enabled by any of the following methods:

- 1. Specifying FW_JUMP=y on the top level make command line.
- 2. Specifying FW_JUMP=y in the target platform *config.mk* configuration file.

The compiled *FW_JUMP* firmware ELF file is named *fw_jump.elf*. Its expanded image file is *fw_jump.bin*. Both files are created in the platform-specific build directory under the *build/platform/<pplatform subdir>/firmware* directory.

FW_JUMP Firmware Configuration Options

To operate correctly, a *FW_JUMP* firmware requires some configuration parameters to be defined using either the top level make command line or the target platform *config.mk* configuration file. The possible parameters are as follows:

- FW_JUMP_ADDR Address of the entry point of the booting stage to be executed following OpenSBI firmware. This address generally corresponds exactly to the address where this next booting stage was loaded. This is a mandatory parameter. Compilation errors will result from not defining this address.
- FW_JUMP_FDT_ADDR Address where the *flattened device tree (FDT file)* passed by the prior booting stage will be placed in memory before executing the booting stage following the OpenSBI firmware. If this option is not provided, then the OpenSBI firmware will pass the FDT address passed by the previous booting stage to the next booting stage.

FW JUMP Example

The [qemu/virt] platform illustrates how to configure and use a FW_JUMP firmware. Detailed information regarding these platforms can be found in the platform documentation files.

OpenSBI Firmware with Payload *FW_PAYLOAD*

OpenSBI **firmware with Payload (FW_PAYLOAD)** is a firmware which directly includes the binary for the booting stage to follow the OpenSBI firmware execution. Typically, this payload will be a bootloader or an OS kernel.

A *FW_PAYLOAD* firmware is particularly useful when the booting stage executed prior to the OpenSBI firmware is not capable of loading both the OpenSBI firmware and the booting stage to follow OpenSBI firmware.

A FW_PAYLOAD firmware is also useful for cases where the booting stage prior to the OpenSBI firmware does not pass a *flattened device tree (FDT file)*. In such a case, a FW_PAYLOAD firmware allows embedding a flattened device tree in the .text section of the final firmware.

Enabling FW_PAYLOAD compilation

The FW_PAYLOAD firmware can be enabled by any of the following methods:

- 1. Specifying FW_PAYLOAD=y on the top level make command line.
- 2. Specifying FW_PAYLOAD=y in the target platform *config.mk* configuration file.

The compiled FW_PAYLOAD firmware ELF file is named fw_jump.elf. Its expanded image file is fw_payload.bin. Both files are created in the platform-specific build directory under the build/platform/<platform_subdir>/firmware directory.

Configuration Options

A *FW_PAYLOAD* firmware is built according to configuration parameters and options. These configuration parameters can be defined using either the top level make command line or the target platform *config.mk* configuration file. The parameters currently defined are as follows:

FW_PAYLOAD_OFFSET - Offset from FW_TEXT_BASE where the payload binary will be linked in the final FW_PAYLOAD firmware binary image. This configuration parameter is mandatory if FW_PAYLOAD_ALIGN is not defined. Compilation errors will result from an incorrect definition of FW_PAYLOAD_OFFSET or of FW_PAYLOAD_ALIGN, or if neither of these parameters are defined.

- FW_PAYLOAD_ALIGN Address alignment constraint where the payload binary will be linked after the end of the base firmware binary in the final FW_PAYLOAD firmware binary image. This configuration parameter is mandatory if FW_PAYLOAD_OFFSET is not defined. If both FW_PAYLOAD_OFFSET and FW_PAYL OAD_ALIGN are defined, FW_PAYLOAD_OFFSET is used and FW_PAYLOAD_ALIGN is ignored.
- FW_PAYLOAD_PATH Path to the image file of the next booting stage binary. If this option is not provided then a simple test payload is automatically generated and used as a payload. This test payload executes an infinite while (1) loop after printing a message on the platform console.
- FW_PAYLOAD_FDT_PATH Path to an external flattened device tree binary file to be embedded in the *.text* section of the final firmware. If this option is not provided and no internal device tree file is specified by the platform (c.f. FW_PAYLOAD_FDT), then the firmware will expect the FDT to be passed as an argument by the prior booting stage.
- FW_PAYLOAD_FDT Path to an internal flattened device tree binary file defined by the platform code. The file name must match the DTB file name specified in the platform *objects.mk* file with the *platform-dtb-y* entry. This option results in FW_PAYLOAD_FDT_PATH to be automatically set. Specifying FW_PAYLOAD_FD← T_PATH on the make command line disables FW_PAYLOAD_FDT and the command line specified device tree binary file is used for building the final firmware.
- FW_PAYLOAD_FDT_ADDR Address where the FDT passed by the prior booting stage or specified by the FW_PAYLOAD_FDT_PATH parameter and embedded in the *.text* section will be placed before executing the next booting stage, that is, the payload firmware. If this option is not provided, then the firmware will pass the FDT address passed by the previous booting stage to the next booting stage.

FW_PAYLOAD Example

The [qemu/virt] platforms illustrate how to configure and use a FW_PAYLOAD firmware. Detailed information regarding these platforms can be found in the platform documentation files.

The *kendryte/k210* platform also enables a build of a *FW_PAYLOAD* using an internally defined device tree file (*FW_PAYLOAD_FDT*).

Linux as a direct payload to OpenSBI

OpenSBI has the capability to load a Linux kernel image directly in supervisor mode. The flattened image generated by the Linux kernel build process can be provided as a payload to OpenSBI.

Detailed examples can be found in both the ../platform/qemu_virt.md "QEMU" and the ../platform/sifive_fu540.md "HiFive Unleashed" platform guides.

U-Boot as a payload to OpenSBI

U-Boot is an open-source primary boot loader. It can be used as first and/or second stage boot loader in an embedded environment. In the context of OpenSBI, U-Boot can be specified as a payload to the OpenSBI firmware, becoming the boot stage following the OpenSBI firmware execution.

The current stable upstream code of U-Boot does not yet include all patches necessary to fully support OpenSBI. To use U-Boot as an OpenSBI payload, the following out-of-tree patch series must be applied to the upstream U-Boot source code:

HiFive Unleashed support for U-Boot

```
https://lists.denx.de/pipermail/u-boot/2019-February/358058.html
```

This patch series enables a single CPU to execute U-Boot. As a result, the next stage boot code such as a Linux kernel can also only execute on a single CPU. U-Boot SMP support for RISC-V can be enabled with the following additional patches:

```
https://lists.denx.de/pipermail/u-boot/2019-February/358393.html
```

Building and Generating U-Boot images

Please refer to the U-Boot build documentation for detailed instructions on how to build U-Boot images.

Once U-Boot images are built, the Linux kernel image needs to be converted into a format that U-Boot understands:

Copy the ulmage to your tftpboot server path if network boot is required.

Andes AE350 SoC Platform

The AE350 AXI/AHB-based platform N25(F)/NX25(F)/D25F/A25/AX25 CPU with level-one memories,interrupt controller, debug module, AXI and AHB Bus Matrix Controller, AXI-to-AHB Bridge and a collection of fundamentalAH ← B/APB bus IP components pre-integrated together as a system design. The high-quality and configurable AHB/APB IPs suites a majority embedded systems, and the verified platform serves as a starting point to jump start SoC designs.

To build platform specific library and firmwares, provide the *PLATFORM=andes/ae350* parameter to the top level make command.

Platform Options

The Andes AE350 platform does not have any platform-specific options.

Building Andes AE350 Platform

To use Linux v5.2 should be used to build Andes AE350 OpenSBI binaries by using the compile time option FW_{\leftarrow} PAYLOAD_FDT_PATH.

AE350's dts is included in https://github.com/andestech/linux/tree/ast-v3_2_0-release-public

Linux Kernel Payload

make PLATFORM=andes/ae350 FW_PAYLOAD_PATH=<linux_build_directory>/arch/riscv/boot/Image FW_PAYLOAD_FDT_PATH=<ae350.dtb path>

Ariane FPGA SoC Platform

Ariane is a 6-stage, single issue, in-order CPU which implements the 64-bit RISC-V instruction set. The Ariane $F \leftarrow PGA$ development platform is based on FPGA SoC (which currently supports only Genesys 2 board) and is capable of running Linux.

The FPGA SoC currently contains the following peripherals:

- · DDR3 memory controller
- · SPI controller to conncet to an SDCard
- · Ethernet controller
- JTAG port (see debugging section below)
- Bootrom containing zero stage bootloader and device tree.

To build platform specific library and firmwares, provide the *PLATFORM=ariane-fpga* parameter to the top level make command.

Platform Options

The Ariane FPGA platform does not have any platform-specific options.

Building Ariane FPGA Platform

Linux Kernel Payload

make PLATFORM=ariane-fpga FW_PAYLOAD_PATH=<linux_build_directory>/arch/riscv/boot/Image

Booting Ariane FPGA Platform

Linux Kernel Payload

As Linux kernel image is embedded in the OpenSBI firmware binary, Ariane will directly boot into Linux directly after powered on.

OpenSBI Supported Platforms

OpenSBI currently supports the following virtual and hardware platforms:

- **QEMU RISC-V Virt Machine**: Platform support for the QEMU *virt* virtual RISC-V machine. This virtual machine is intended for RISC-V software development and tests. More details on this platform can be found in the file [qemu_virt.md].
- SiFive FU540 SoC: Platform support for SiFive FU540 SoC used on the HiFive Unleashed board, as well as the *sifive_u* QEMU virtual RISC-V machine. More details on this platform can be found in the file [sifive_← fu540.md].
- Kendryte K210 SoC: Platform support for the Kendryte K210 SoC used on boards such as the Kendryte KD233 or the Sipeed MAIX Dock.
- Ariane FPGA SoC: Platform support for the Ariane FPGA SoC used on Genesys 2 board.
- Andes AE350 SoC: Platform support for the Andes's SoC (AE350).
- T-HEAD C910: Platform support for the T-HEAD C910 Processor.
- Spike: Platform support for the Spike emulator.

The code for these supported platforms can be used as example to implement support for other platforms. The *platform/template* directory also provides template files for implementing support for a new platform. The *object.mk*, *config.mk* and *platform.c* template files provides enough comments to facilitate the implementation.

QEMU RISC-V Virt Machine Platform

The **QEMU RISC-V Virt Machine** is a virtual platform created for RISC-V software development and testing. It is also referred to as *QEMU RISC-V VirtIO machine* because it uses VirtIO devices for network, storage, and other types of IO.

To build the platform-specific library and firmware images, provide the *PLATFORM=qemu/virt* parameter to the top level make command.

Platform Options

The QEMU RISC-V Virt Machine platform does not have any platform-specific options.

Execution on QEMU RISC-V 64-bit

No Payload Case

Build:

make PLATFORM=qemu/virt

Run:

```
qemu-system-riscv64 -M virt -m 256M -nographic \
    -kernel build/platform/qemu/virt/firmware/fw_payload.elf
```

U-Boot Payload

Note: the command line examples here assume that U-Boot was compiled using the qemu-riscv64_smode ← _defconfig configuration.

Build:

 $\verb| make PLATFORM=qemu/virt FW_PAYLOAD_PATH=< \verb| uboot_build_directory > /u-boot.bin | and a continuous conti$

Run:

```
qemu-system-riscv64 -M virt -m 256M -nographic \
    -kernel build/platform/qemu/virt/firmware/fw_payload.elf

Or

qemu-system-riscv64 -M virt -m 256M -nographic \
    -kernel build/platform/qemu/virt/firmware/fw_jump.elf \
```

Linux Kernel Payload

Note: We assume that the Linux kernel is compiled using arch/riscv/configs/defconfig.

-device loader, file=<ubot_build_directory>/u-boot.bin, addr=0x80200000

Build:

make PLATFORM=qemu/virt FW_PAYLOAD_PATH=<linux_build_directory>/arch/riscv/boot/Image

Run:

```
qemu-system-riscv64 -M virt -m 256M -nographic \
    -kernel build/platform/qemu/virt/firmware/fw_payload.elf \
    -drive file=<path_to_linux_rootfs>, format=raw, id=hd0 \
    -device virtio=blk-device, drive=hd0 \
    -append "root=/dev/vda rw console=ttyS0"

Or

qemu-system-riscv64 -M virt -m 256M -nographic \
    -kernel build/platform/qemu/virt/firmware/fw_jump.elf \
    -device loader, file=<linux_build_directory>/arch/riscv/boot/Image, addr=0x80200000 \
    -drive file=<path_to_linux_rootfs>, format=raw, id=hd0 \
```

Execution on QEMU RISC-V 32-bit

-device virtio-blk-device, drive=hd0 \
-append "root=/dev/vda rw console=ttyS0"

No Payload Case

Build:

make PLATFORM=qemu/virt

Run:

```
\label{eq:continuous} $\operatorname{qemu-system-riscv32}$ -M virt -m 256M -nographic \\ -kernel build/platform/qemu/virt/firmware/fw_payload.elf
```

U-Boot Payload

Note: the command line examples here assume that U-Boot was compiled using the qemu-riscv32_smode ← __defconfig configuration.

Build:

make PLATFORM=qemu/virt FW_PAYLOAD_PATH=<uboot_build_directory>/u-boot.bin

Run:

```
qemu-system-riscv32 -M virt -m 256M -nographic \
    -kernel build/platform/qemu/virt/firmware/fw_payload.elf
```

or

```
qemu-system-riscv32 -M virt -m 256M -nographic \
    -kernel build/platform/qemu/virt/firmware/fw_jump.elf \
    -device loader,file=<uboot_build_directory>/u-boot.bin,addr=0x80400000
```

Linux Kernel Payload

Note: We assume that the Linux kernel is compiled using *arch/riscv/configs/rv32_defconfig* (kernel 5.1 and newer) respectively using *arch/riscv/configs/defconfig* plus setting CONFIG_ARCH_RV32I=y (kernel 5.0 and older).

Build:

make PLATFORM=qemu/virt FW_PAYLOAD_PATH=<linux_build_directory>/arch/riscv/boot/Image

Run:

```
qemu-system-riscv32 -M virt -m 256M -nographic \
    -kernel build/platform/qemu/virt/firmware/fw_payload.elf \
    -drive file=<path_to_linux_rootfs>, format=raw,id=hd0 \
    -device virtio-blk-device,drive=hd0 \
    -append "root=/dev/vda rw console=ttyS0"
```

or

```
qemu-system-riscv32 -M virt -m 256M -nographic \
    -kernel build/platform/qemu/virt/firmware/fw_jump.elf \
    -device loader, file=<linux_build_directory>/arch/riscv/boot/Image, addr=0x80400000 \
    -drive file=<path_to_linux_rootfs>, format=raw, id=hd0 \
    -device virtio-blk-device, drive=hd0 \
    -append "root=/dev/vda rw console=ttyS0"
```

SiFive FU540 SoC Platform

The FU540-C000 is the world's first 4+1 64-bit RISC-V SoC from SiFive. The HiFive Unleashed development platform is based on FU540-C000 and capable of running Linux.

With QEMU v4.2 or above release, the 'sifive_u' machine can be used to test OpenSBI image built for the real hardware as well.

To build platform specific library and firmwares, provide the *PLATFORM=sifive/fu540* parameter to the top level make command.

Platform Options

As hart0 in the FU540 doesn't have an MMU, only harts 1-4 boot by default. A hart mask i.e. FU540_ENABLED — _HART_MASK compile time option is provided to select any other hart for booting. Please keep in mind that this is not a generic option and it can only be specified for FU540 platform in the following way:

make PLATFORM=sifive/fu540 FW_PAYLOAD_PATH=Image FU540_ENABLED_HART_MASK=0x02

This will let the board boot only hart1 instead of default 1-4.

Building SiFive Fu540 Platform

In order to boot SMP Linux in U-Boot, Linux v5.1 (or higher) and latest U-Boot v2020.01 (or higher) should be used.

Linux Kernel Payload

The HiFive Unleashed device tree(DT) is merged in Linux v5.2 release. This DT (device tree) is not backward compatible with the DT passed from FSBL.

To use Linux v5.2 (or higher, the pre-built DTB (DT binary) from Linux v5.2 (or higher) should be used to build SiFive FU540 OpenSBI binaries by using the compile time option *FW_PAYLOAD_FDT_PATH*.

U-Boot Payload

The command-line example here assumes that U-Boot was compiled using the sifive_fu540_defconfig configuration and with U-Boot v2020.01 (or higher).

The detailed U-Boot booting guide is available at U-Boot.

```
make PLATFORM=sifive/fu540 FW_PAYLOAD_PATH=<u-boot_build_dir>/u-boot-dtb.bin
```

U-Boot & Linux Kernel as a single payload

A single monolithic image containing both U-Boot & Linux can also be used if network boot setup is not available.

1. Create a temporary image with u-boot-dtb.bin as the first payload. The command-line example here assumes that U-Boot was compiled using sifive fu540 defconfig configuration.

```
dd if=~/workspace/u-boot-riscv/u-boot-dtb.bin of=/tmp/temp.bin bs=1M
```

2. Append the Linux Kernel image.

```
dd if=<linux_build_directory>/arch/riscv/boot/Image of=/tmp/temp.bin bs=1M seek=4
```

3. Compile OpenSBI with temp.bin (generated in step 2) as payload.

```
make PLATFORM=sifive/fu540 FW_PAYLOAD_PATH=/tmp/temp.bin
or
(For U-Boot which follows Linux v5.2 (or higher) DT bindings)
make PLATFORM=sifive/fu540 FW_PAYLOAD_PATH=/tmp/temp.bin
```

Flashing the OpenSBI firmware binary to storage media:

The first stage boot loader (FSBL) expects the storage media to have a GPT partition table. It tries to look for a partition with following GUID to load the next stage boot loader (OpenSBI in this case).

```
2E54B353-1271-4842-806F-E436D6AF6985
```

That's why the generated firmware binary in above steps should be copied to the partition of the sdcard with above GUID.

```
\verb| dd if=build/platform/sifive/fu540/firmware/fw_payload.bin of=/dev/disk2s1 bs=1024| \\
```

In my case, it is the first partition is disk2s1 that has been formatted with the above specified GUID.

In case of a brand new sdcard, it should be formatted with below partition tables as described here.

Booting SiFive Fu540 Platform

Linux Kernel Payload

As Linux kernel image is embedded in the OpenSBI firmware binary, HiFive Unleashed will directly boot into Linux directly after powered on.

U-Boot Payload

As U-Boot image is used as payload, HiFive Unleashed will boot into a U-Boot prompt. U-Boot tftp boot method can be used to load kernel image in U-Boot prompt. Here are the steps do a tftpboot.

1. Set the ip address of the board.

```
setenv ipaddr <ipaddr of the board>
```

2. Set the tftpboot server IP.

```
setenv serverip <ipaddr of the tftp server>
```

3. Set the network gateway address.

```
setenv gatewayip <ipaddress of the network gateway>
```

4. Load the Linux kernel image from the tftp server.

```
tftpboot ${kernel_addr_r} <Image path in tftpboot directory>
```

5. Load the ramdisk image from the tftp server. This is only required if ramdisk is loaded from tftp server. This step is optional, if rootfs is already part of the kernel or loaded from an external storage by kernel.

```
tftpboot ${ramdisk_addr_r} <ramdisk path in tftpboot directory>
```

6. Load the pre-compiled device tree via tftpboot.

```
tftpboot ${fdt_addr_r} <hifive-unleashed-a00.dtb path in tftpboot directory>
```

7. Set the boot command-line arguments.

```
\verb|setenv| bootargs "root=<root partition> rw console=ttySIF0 earlycon=sbi"|
```

(Note: root partition should point to ** /dev/ram ** - If a ramdisk is used ** root=/dev/mmcblk0pX ** - If a rootfs is already on some other partition of sdcard)

8. Now boot into Linux.

```
booti ${kernel_addr_r} ${ramdisk_addr_r} ${fdt_addr_r}
or
(If ramdisk is not loaded from network)
booti ${kernel_addr_r} - ${fdt_addr_r}
```

U-Boot & Linux Kernel as a single payload

At U-Boot prompt execute the following boot command to boot Linux.

```
booti {\left[ \begin{array}{ccc} \left( x_{r} \right) & - \left( x_{r} \right) \\ \end{array} \right]} - \left[ \begin{array}{ccc} \left( x_{r} \right) & - \left( x_{r} \right) \\ \end{array} \right]
```

QEMU Specific Instructions

If you want to test OpenSBI with QEMU 'sifive_u' machine, please follow the same instructions above, with the exception of not passing FW_PAYLOAD_FDT_PATH.

This is because QEMU generates a device tree blob on the fly based on the command line parameters and it's compatible with the one used in the upstream Linux kernel.

When U-Boot v2020.01 (or higher) is used as the payload, as the SiFive FU540 DTB for the real hardware is embedded in U-Boot binary itself, due to the same reason above, we need to switch the U-Boot sifive_fu540_ defconfig configuration from CONFIG_OF_SEPARATE to CONFIG_OF_PRIOR_STAGE so that U-Boot uses the DTB generated by QEMU, and u-boot.bin should be used as the payload image, like:

make PLATFORM=sifive/fu540 FW_PAYLOAD_PATH=<u-boot_build_dir>/u-boot.bin

While the real hardware operates at the 64-bit mode, it's possible for QEMU to test the 32-bit OpenSBI firmware. This can be helpful for testing 32-bit SiFive specific drivers.

Chapter 16

Spike Simulator Platform

The **Spike** is a RISC-V ISA simulator which implements a functional model of one or more RISC-V harts. The **Spike** compatible virtual platform is also available on QEMU. In fact, we can use same OpenSBI firmware binaries on **Spike** simulator and QEMU Spike machine.

For more details, refer Spike on GitHub

To build the platform-specific library and firmware images, provide the *PLATFORM=spike* parameter to the top level make command.

Platform Options

The Spike platform does not have any platform-specific options.

Execution on Spike Simulator

No Payload Case

Build:

make PLATFORM=spike

Run:

spike build/platform/spike/firmware/fw_payload.elf

Linux Kernel Payload

Note: We assume that the Linux kernel is compiled using arch/riscv/configs/defconfig.

Build:

make PLATFORM=spike FW_PAYLOAD_PATH=<linux_build_directory>/arch/riscv/boot/Image

Run:

 $\verb|spike| -- \verb|initrd| < \verb|path_to_cpio_ramdisk>| build/platform/spike/firmware/fw_payload.elf| \\$

Execution on QEMU RISC-V 64-bit

No Payload Case

```
Build:
```

```
make PLATFORM=spike
```

Run:

```
\label{eq:condition} $\operatorname{\mathsf{qemu-system-riscv64}}$ -M spike -m 256M -nographic \\ -kernel build/platform/spike/firmware/fw_payload.elf
```

Linux Kernel Payload

Note: We assume that the Linux kernel is compiled using arch/riscv/configs/defconfig.

Build:

```
\verb| make PLATFORM=spike FW_PAYLOAD_PATH=< linux\_build\_directory>/arch/riscv/boot/Image | linux\_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/linux_build\_directory>/arch/riscv/boot/li
```

Run:

```
qemu-system-riscv64 -M spike -m 256M -nographic \
    -kernel build/platform/spike/firmware/fw_payload.elf \
    -initrd <path_to_cpio_ramdisk> \
    -append "root=/dev/ram rw console=hvc0 earlycon=sbi"
```

or

```
qemu-system-riscv64 -M spike -m 256M -nographic \
   -bios build/platform/spike/firmware/fw_jump.elf \
   -kernel <linux_build_directory>/arch/riscv/boot/Image \
   -initrd <path_to_cpio_ramdisk> \
   -append "root=/dev/ram rw console=hvc0 earlycon=sbi"
```

Chapter 17

T-HEAD C910 Processor

C910 is a 12-stage, 3 issues, 8 executions, out-of-order 64-bit RISC-V CPU which supports 16 cores, runs with 2.5GHz, and is capable of running Linux.

To build platform specific library and firmwares, provide the *PLATFORM=thead/c910* parameter to the top level make command.

Platform Options

The *T-HEAD C910* platform does not have any platform-specific options.

Building T-HEAD C910 Platform

make PLATFORM=thead/c910

Booting T-HEAD C910 Platform

No Payload

As there's no payload, you may download vmlinux or u-boot to FW_JUMP_ADDR which specified in config.mk or compile commands with GDB. And the execution flow will turn to vmlinux or u-boot when opensbi ends.

Linux Kernel Payload

You can also choose to use Linux kernel as payload by enabling FW_PAYLOAD=y along with specifying FW_P \leftarrow AYLOAD_OFFSET. The kernel image will be embedded in the OPENSBI firmware binary, T-head will directly boot into Linux after OpenSBI.

40 T-HEAD C910 Processor

Chapter 18

Data Structure Index

18.1 Data Structures

Here are the data structures with brief descriptions:

atomic_t	. 45
fdt_header	. 45
fdt_node_header	. 47
fdt_property	
fdt_reserve_entry	. 49
fw_dynamic_info	
sbi_dlist	
sbi_ecall_extension	
sbi_fifo	
sbi_ipi_event_ops	
sbi_platform	
sbi_platform_operations	
sbi_scratch	
sbi_tlb_info	
sbi_trap_info	
sbi_trap_regs	
spinlock t	71

42 Data Structure Index

Chapter 19

File Index

19.1 File List

Here is a list of all files with brief descriptions:

include/sbi/fw_dynamic.h
include/sbi/riscv_asm.h
include/sbi/riscv_atomic.h
include/sbi/riscv_barrier.h
include/sbi/riscv_encoding.h
include/sbi/riscv_fp.h
include/sbi/riscv_io.h
include/sbi/riscv_locks.h
include/sbi/sbi_bitops.h
include/sbi/sbi_bits.h
include/sbi/sbi_console.h
include/sbi/sbi_const.h
include/sbi/sbi_ecall.h
include/sbi/sbi_ecall_interface.h
include/sbi/sbi_emulate_csr.h
include/sbi/sbi_error.h
include/sbi/sbi_fifo.h
include/sbi/sbi_hart.h
include/sbi/sbi_hfence.h
include/sbi/sbi_illegal_insn.h
include/sbi/sbi_init.h
include/sbi/sbi_ipi.h
include/sbi/sbi_list.h
include/sbi/sbi_misaligned_ldst.h
include/sbi/sbi_platform.h
include/sbi/sbi_scratch.h
include/sbi/sbi_string.h
include/sbi/sbi_system.h
include/sbi/sbi_timer.h
include/sbi/sbi_tlb.h
include/sbi/sbi_trap.h
include/sbi/sbi_types.h
include/sbi/sbi_unpriv.h
include/sbi/sbi_version.h
include/sbi_utils/irachip/plic.h

44 File Index

include/sbi_utils/serial/sifive-uart.h
include/sbi_utils/serial/uart8250.h
include/sbi_utils/sys/clint.h
include/sbi_utils/sys/htif.h
lib/sbi/riscv_asm.c
lib/sbi/riscv_atomic.c
lib/sbi/riscv_locks.c
lib/sbi/sbi_console.c
lib/sbi/sbi_ecall.c
lib/sbi/sbi_ecall_base.c
lib/sbi/sbi_ecall_legacy.c
lib/sbi/sbi_ecall_replace.c
lib/sbi/sbi_ecall_vendor.c
lib/sbi/sbi_emulate_csr.c
lib/sbi/sbi_fifo.c
lib/sbi/sbi_hart.c
lib/sbi/sbi_illegal_insn.c
lib/sbi/sbi_init.c
lib/sbi/sbi_ipi.c
lib/sbi/sbi_misaligned_ldst.c
lib/sbi/sbi_scratch.c
lib/sbi/sbi_string.c
lib/sbi/sbi_system.c
lib/sbi/sbi_timer.c
lib/sbi/sbi_tlb.c
lib/sbi/sbi_trap.c
lib/sbi/sbi_unpriv.c
lib/utils/irqchip/plic.c
lib/utils/libfdt/fdt.c
$lib/utils/libfdt/fdt.h \qquad . \qquad$
lib/utils/libfdt/fdt_addresses.c
lib/utils/libfdt/fdt_empty_tree.c
lib/utils/libfdt/fdt_overlay.c
$lib/utils/libfdt/fdt_ro.c \qquad . \qquad$
$lib/utils/libfdt/fdt_rw.c \qquad . \qquad$
lib/utils/libfdt/fdt_strerror.c
$lib/utils/libfdt/fdt_sw.c \qquad . \qquad$
lib/utils/libfdt/fdt_wip.c
$lib/utils/libfdt.h \\ \ \dots \\ \ \dots \\ \ \dots \\ \ \dots \\ \ \dots \\ \ \dots \\ \dots \\$
lib/utils/libfdt_env.h
lib/utils/libfdt_internal.h
lib/utils/serial/sifive-uart.c
lib/utils/serial/uart8250.c
lib/utils/sys/clint.c
lib/utils/sys/htif.c

Chapter 20

Data Structure Documentation

20.1 atomic_t Struct Reference

```
#include <riscv_atomic.h>
```

Data Fields

· volatile long counter

20.1.1 Field Documentation

20.1.1.1 counter

```
\verb|volatile| long| atomic_t::counter|\\
```

The documentation for this struct was generated from the following file:

• include/sbi/riscv_atomic.h

20.2 fdt_header Struct Reference

```
#include <fdt.h>
```

Data Fields

- fdt32_t magic
- fdt32_t totalsize
- fdt32_t off_dt_struct
- fdt32_t off_dt_strings
- fdt32_t off_mem_rsvmap
- fdt32_t version
- fdt32_t last_comp_version
- fdt32_t boot_cpuid_phys
- fdt32_t size_dt_strings
- fdt32_t size_dt_struct

20.2.1 Field Documentation

```
20.2.1.1 boot_cpuid_phys
```

```
fdt32_t fdt_header::boot_cpuid_phys
```

20.2.1.2 last_comp_version

```
fdt32_t fdt_header::last_comp_version
```

20.2.1.3 magic

```
fdt32_t fdt_header::magic
```

20.2.1.4 off_dt_strings

```
fdt32_t fdt_header::off_dt_strings
```

20.2.1.5 off_dt_struct

```
fdt32_t fdt_header::off_dt_struct
```

20.2.1.6 off_mem_rsvmap

```
fdt32_t fdt_header::off_mem_rsvmap
```

20.2.1.7 size_dt_strings

```
fdt32_t fdt_header::size_dt_strings
```

20.2.1.8 size_dt_struct

```
fdt32_t fdt_header::size_dt_struct
```

20.2.1.9 totalsize

```
fdt32_t fdt_header::totalsize
```

20.2.1.10 version

```
fdt32_t fdt_header::version
```

The documentation for this struct was generated from the following file:

• lib/utils/libfdt/fdt.h

20.3 fdt_node_header Struct Reference

```
#include <fdt.h>
```

Data Fields

- fdt32_t tag
- char name [0]

20.3.1 Field Documentation

20.3.1.1 name

```
char fdt_node_header::name[0]
```

20.3.1.2 tag

```
fdt32_t fdt_node_header::tag
```

The documentation for this struct was generated from the following file:

• lib/utils/libfdt/fdt.h

20.4 fdt_property Struct Reference

```
#include <fdt.h>
```

Data Fields

- fdt32_t tag
- fdt32_t len
- fdt32_t nameoff
- char data [0]

20.4.1 Field Documentation

20.4.1.1 data

```
char fdt_property::data[0]
```

20.4.1.2 len

fdt32_t fdt_property::len

20.4.1.3 nameoff

```
fdt32_t fdt_property::nameoff
```

20.4.1.4 tag

```
fdt32_t fdt_property::tag
```

The documentation for this struct was generated from the following file:

• lib/utils/libfdt/fdt.h

20.5 fdt_reserve_entry Struct Reference

```
#include <fdt.h>
```

Data Fields

- fdt64_t address
- fdt64_t size

20.5.1 Field Documentation

20.5.1.1 address

```
fdt64_t fdt_reserve_entry::address
```

20.5.1.2 size

```
fdt64_t fdt_reserve_entry::size
```

The documentation for this struct was generated from the following file:

• lib/utils/libfdt/fdt.h

20.6 fw_dynamic_info Struct Reference

```
#include <fw_dynamic.h>
```

Data Fields

- · unsigned long magic
- unsigned long version
- unsigned long next_addr
- · unsigned long next_mode
- unsigned long options
- unsigned long boot_hart

20.6.1 Detailed Description

Representation dynamic info passed by previous booting stage

20.6.2 Field Documentation

20.6.2.1 boot_hart

unsigned long fw_dynamic_info::boot_hart

Preferred boot HART id

It is possible that the previous booting stage uses same link address as the FW_DYNAMIC firmware. In this case, the relocation lottery mechanism can potentially overwrite the previous booting stage while other HARTs are still running in the previous booting stage leading to boot-time crash. To avoid this boot-time crash, the previous booting stage can specify last HART that will jump to the FW_DYNAMIC firmware as the preferred boot HART.

To avoid specifying a preferred boot HART, the previous booting stage can set it to -1UL which will force the FW_ DYNAMIC firmware to use the relocation lottery mechanism.

20.6.2.2 magic

unsigned long fw_dynamic_info::magic

Info magic

20.6.2.3 next_addr

unsigned long fw_dynamic_info::next_addr

Next booting stage address

20.6.2.4 next_mode

unsigned long fw_dynamic_info::next_mode

Next booting stage mode

20.6.2.5 options

```
unsigned long fw_dynamic_info::options
```

Options for OpenSBI library

20.6.2.6 version

```
unsigned long fw_dynamic_info::version
```

Info version

The documentation for this struct was generated from the following file:

• include/sbi/fw_dynamic.h

20.7 sbi_dlist Struct Reference

```
#include <sbi_list.h>
```

Data Fields

- struct sbi_dlist * next
- struct sbi_dlist * prev

20.7.1 Field Documentation

20.7.1.1 next

```
struct sbi_dlist* sbi_dlist::next
```

20.7.1.2 prev

```
struct sbi_dlist * sbi_dlist::prev
```

The documentation for this struct was generated from the following file:

• include/sbi/sbi_list.h

20.8 sbi_ecall_extension Struct Reference

```
#include <sbi_ecall.h>
```

Data Fields

- · struct sbi_dlist head
- unsigned long extid_start
- · unsigned long extid end
- int(* probe)(struct sbi_scratch *scratch, unsigned long extid, unsigned long *out_val)
- int(* handle)(struct sbi_scratch *scratch, unsigned long extid, unsigned long funcid, unsigned long *args, unsigned long *out_val, struct sbi_trap_info *out_trap)

20.8.1 Field Documentation

20.8.1.1 extid_end

unsigned long sbi_ecall_extension::extid_end

20.8.1.2 extid_start

unsigned long sbi_ecall_extension::extid_start

20.8.1.3 handle

int(* sbi_ecall_extension::handle) (struct sbi_scratch *scratch, unsigned long extid, unsigned
long funcid, unsigned long *args, unsigned long *out_val, struct sbi_trap_info *out_trap)

20.8.1.4 head

struct sbi_dlist sbi_ecall_extension::head

20.8.1.5 probe

```
int(* sbi_ecall_extension::probe) (struct sbi_scratch *scratch, unsigned long extid, unsigned
long *out_val)
```

The documentation for this struct was generated from the following file:

• include/sbi/sbi_ecall.h

20.9 sbi_fifo Struct Reference

```
#include <sbi_fifo.h>
```

Data Fields

- void * queue
- spinlock_t qlock
- u16 entry_size
- u16 num_entries
- u16 avail
- u16 tail

20.9.1 Field Documentation

20.9.1.1 avail

u16 sbi_fifo::avail

20.9.1.2 entry_size

u16 sbi_fifo::entry_size

20.9.1.3 num_entries

u16 sbi_fifo::num_entries

20.9.1.4 qlock

```
spinlock_t sbi_fifo::qlock
```

20.9.1.5 queue

```
void* sbi_fifo::queue
```

20.9.1.6 tail

```
u16 sbi_fifo::tail
```

The documentation for this struct was generated from the following file:

· include/sbi/sbi_fifo.h

20.10 sbi_ipi_event_ops Struct Reference

```
#include <sbi_ipi.h>
```

Data Fields

- char name [32]
- int(* update)(struct sbi_scratch *scratch, struct sbi_scratch *remote_scratch, u32 remote_hartid, void *data)
- void(* sync)(struct sbi_scratch *scratch)
- void(* process)(struct sbi_scratch *scratch)

20.10.1 Detailed Description

IPI event operations or callbacks

20.10.2 Field Documentation

20.10.2.1 name

```
char sbi_ipi_event_ops::name[32]
```

Name of the IPI event operations

20.10.2.2 process

```
void(* sbi_ipi_event_ops::process) (struct sbi_scratch *scratch)
```

Process callback to handle IPI event Note: This is a mandatory callback and it is called on the remote HART after IPI is triggered.

20.10.2.3 sync

```
void(* sbi_ipi_event_ops::sync) (struct sbi_scratch *scratch)
```

Sync callback to wait for remote HART Note: This is an optional callback and it is called just after triggering IPI to remote HART.

20.10.2.4 update

```
int(* sbi_ipi_event_ops::update) (struct sbi_scratch *scratch, struct sbi_scratch *remote_←
scratch, u32 remote_hartid, void *data)
```

Update callback to save/enqueue data for remote HART Note: This is an optional callback and it is called just before triggering IPI to remote HART.

The documentation for this struct was generated from the following file:

• include/sbi/sbi ipi.h

20.11 sbi_platform Struct Reference

```
#include <sbi_platform.h>
```

Data Fields

- · u32 opensbi version
- u32 platform_version
- char name [64]
- u64 features
- u32 hart_count
- u32 hart_stack_size
- u64 disabled_hart_mask
- unsigned long platform_ops_addr
- unsigned long firmware_context

20.11.1 Detailed Description

Representation of a platform

20.11.2 Field Documentation

```
20.11.2.1 disabled_hart_mask
u64 sbi_platform::disabled_hart_mask
Mask representing the set of disabled HARTs
20.11.2.2 features
u64 sbi_platform::features
Supported features
20.11.2.3 firmware_context
unsigned long sbi_platform::firmware_context
Pointer to system firmware specific context
20.11.2.4 hart_count
u32 sbi_platform::hart_count
Total number of HARTs
20.11.2.5 hart_stack_size
u32 sbi_platform::hart_stack_size
Per-HART stack size for exception/interrupt handling
20.11.2.6 name
char sbi_platform::name[64]
Name of the platform
20.11.2.7 opensbi_version
```

u32 sbi_platform::opensbi_version

OpenSBI version this sbi_platform is based on. It's a 32-bit value where upper 16-bits are major number and lower 16-bits are minor number

```
20.11.2.8 platform_ops_addr
```

```
unsigned long sbi_platform::platform_ops_addr
```

Pointer to sbi platform operations

20.11.2.9 platform_version

```
u32 sbi_platform::platform_version
```

OpenSBI platform version released by vendor. It's a 32-bit value where upper 16-bits are major number and lower 16-bits are minor number

The documentation for this struct was generated from the following file:

• include/sbi/sbi_platform.h

20.12 sbi_platform_operations Struct Reference

```
#include <sbi_platform.h>
```

Data Fields

- int(* early_init)(bool cold_boot)
- int(* final_init)(bool cold_boot)
- void(* early_exit)(void)
- void(* final_exit)(void)
- int(* misa_check_extension)(char ext)
- int(* misa_get_xlen)(void)
- u32(* pmp region count)(u32 hartid)
- int(* pmp_region_info)(u32 hartid, u32 index, ulong *prot, ulong *addr, ulong *log2size)
- void(* console_putc)(char ch)
- int(* console_getc)(void)
- int(* console init)(void)
- int(* irqchip_init)(bool cold_boot)
- void(* irqchip_exit)(void)
- void(* ipi_send)(u32 target_hart)
- void(* ipi_clear)(u32 target_hart)
- int(* ipi_init)(bool cold_boot)
- void(* ipi_exit)(void)
- u64(* get_tlbr_flush_limit)(void)
- u64(* timer_value)(void)
- void(* timer_event_start)(u64 next_event)
- void(* timer_event_stop)(void)
- int(* timer_init)(bool cold_boot)
- void(* timer_exit)(void)
- int(* system reboot)(u32 type)
- int(* system_shutdown)(u32 type)
- int(* vendor ext check)(long extid)
- int(* vendor_ext_provider)(long extid, long funcid, unsigned long *args, unsigned long *out_value, struct sbi_trap_info *out_trap)

20.12.1 Detailed Description

Platform functions

20.12.2 Field Documentation

```
20.12.2.1 console_getc
int(* sbi_platform_operations::console_getc) (void)
Read a character from the platform console input
20.12.2.2 console_init
int(* sbi_platform_operations::console_init) (void)
Initialize the platform console
20.12.2.3 console_putc
void(* sbi_platform_operations::console_putc) (char ch)
Write a character to the platform console output
20.12.2.4 early_exit
void(* sbi_platform_operations::early_exit) (void)
Platform early exit
20.12.2.5 early_init
int(* sbi_platform_operations::early_init) (bool cold_boot)
Platform early initialization
20.12.2.6 final_exit
```

void(* sbi_platform_operations::final_exit) (void)

Platform final exit

```
20.12.2.7 final_init
int(* sbi_platform_operations::final_init) (bool cold_boot)
Platform final initialization
20.12.2.8 get_tlbr_flush_limit
u64(* sbi_platform_operations::get_tlbr_flush_limit) (void)
Get tlb flush limit value
20.12.2.9 ipi_clear
void(* sbi_platform_operations::ipi_clear) (u32 target_hart)
Clear IPI for a target HART
20.12.2.10 ipi_exit
void(* sbi_platform_operations::ipi_exit) (void)
Exit IPI for current HART
20.12.2.11 ipi_init
int(* sbi_platform_operations::ipi_init) (bool cold_boot)
Initialize IPI for current HART
20.12.2.12 ipi_send
void(* sbi_platform_operations::ipi_send) (u32 target_hart)
Send IPI to a target HART
20.12.2.13 irqchip_exit
void(* sbi_platform_operations::irqchip_exit) (void)
Exit the platform interrupt controller for current HART
20.12.2.14 irqchip_init
int(* sbi_platform_operations::irqchip_init) (bool cold_boot)
Initialize the platform interrupt controller for current HART
```

```
20.12.2.15 misa_check_extension
```

```
int(* sbi_platform_operations::misa_check_extension) (char ext)
```

For platforms that do not implement misa, non-standard methods are needed to determine cpu extension.

```
20.12.2.16 misa_get_xlen
```

```
int(* sbi_platform_operations::misa_get_xlen) (void)
```

For platforms that do not implement misa, non-standard methods are needed to get MXL field of misa.

```
20.12.2.17 pmp_region_count
```

```
u32(* sbi_platform_operations::pmp_region_count) (u32 hartid)
```

Get number of PMP regions for given HART

```
20.12.2.18 pmp_region_info
```

```
int(* sbi_platform_operations::pmp_region_info) (u32 hartid, u32 index, ulong *prot, ulong
*addr, ulong *log2size)
```

Get PMP regions details (namely: protection, base address, and size) for given HART

20.12.2.19 system_reboot

```
int(* sbi_platform_operations::system_reboot) (u32 type)
```

Reboot the platform

20.12.2.20 system_shutdown

```
int(* sbi_platform_operations::system_shutdown) (u32 type)
```

Shutdown or poweroff the platform

20.12.2.21 timer event start

```
void(* sbi_platform_operations::timer_event_start) (u64 next_event)
```

Start platform timer event for current HART

```
20.12.2.22 timer_event_stop
void(* sbi_platform_operations::timer_event_stop) (void)
Stop platform timer event for current HART
20.12.2.23 timer exit
void(* sbi_platform_operations::timer_exit) (void)
Exit platform timer for current HART
20.12.2.24 timer_init
int(* sbi_platform_operations::timer_init) (bool cold_boot)
Initialize platform timer for current HART
20.12.2.25 timer_value
u64(* sbi_platform_operations::timer_value) (void)
Get platform timer value
20.12.2.26 vendor_ext_check
int(* sbi_platform_operations::vendor_ext_check) (long extid)
platform specific SBI extension implementation probe function
20.12.2.27 vendor_ext_provider
int(* sbi_platform_operations::vendor_ext_provider) (long extid, long funcid, unsigned long
*args, unsigned long *out_value, struct sbi_trap_info *out_trap)
```

platform specific SBI extension implementation provider

The documentation for this struct was generated from the following file:

• include/sbi/sbi_platform.h

20.13 sbi scratch Struct Reference

```
#include <sbi_scratch.h>
```

Data Fields

- unsigned long fw_start
- unsigned long fw_size
- unsigned long next_arg1
- unsigned long next_addr
- unsigned long next_mode
- unsigned long warmboot_addr
- · unsigned long platform addr
- unsigned long hartid_to_scratch
- unsigned long tmp0
- unsigned long options

20.13.1 Detailed Description

Representation of per-HART scratch space

20.13.2 Field Documentation

```
20.13.2.1 fw_size
```

unsigned long sbi_scratch::fw_size

Size (in bytes) of firmware linked to OpenSBI library

20.13.2.2 fw_start

unsigned long sbi_scratch::fw_start

Start (or base) address of firmware linked to OpenSBI library

20.13.2.3 hartid_to_scratch

unsigned long sbi_scratch::hartid_to_scratch

Address of HART ID to sbi_scratch conversion function

20.13.2.4 next_addr

unsigned long sbi_scratch::next_addr

Address of next booting stage for this HART

```
20.13.2.5 next_arg1

unsigned long sbi_scratch::next_arg1

Arg1 (or 'a1' register) of next booting stage for this HART

20.13.2.6 next_mode

unsigned long sbi_scratch::next_mode

Priviledge mode of next booting stage for this HART

20.13.2.7 options

unsigned long sbi_scratch::options

Options for OpenSBI library
```

20.13.2.8 platform_addr

unsigned long sbi_scratch::platform_addr

Address of sbi_platform

20.13.2.9 tmp0

unsigned long sbi_scratch::tmp0

Temporary storage

20.13.2.10 warmboot_addr

unsigned long sbi_scratch::warmboot_addr

Warm boot entry point address for this HART

The documentation for this struct was generated from the following file:

• include/sbi/sbi scratch.h

20.14 sbi_tlb_info Struct Reference

#include <sbi_tlb.h>

Data Fields

- · unsigned long start
- unsigned long size
- · unsigned long asid
- · unsigned long type
- unsigned long shart_mask

20.14.1 Field Documentation

20.14.1.1 asid

unsigned long sbi_tlb_info::asid

20.14.1.2 shart_mask

unsigned long $sbi_tlb_info::shart_mask$

20.14.1.3 size

unsigned long sbi_tlb_info::size

20.14.1.4 start

unsigned long sbi_tlb_info::start

20.14.1.5 type

unsigned long sbi_tlb_info::type

The documentation for this struct was generated from the following file:

• include/sbi/sbi_tlb.h

20.15 sbi_trap_info Struct Reference

```
#include <sbi_trap.h>
```

Data Fields

- unsigned long epc
- unsigned long cause
- unsigned long tval
- unsigned long tval2
- unsigned long tinst

20.15.1 Detailed Description

Representation of trap details

20.15.2 Field Documentation

20.15.2.1 cause

unsigned long sbi_trap_info::cause

cause Trap exception cause

20.15.2.2 epc

unsigned long sbi_trap_info::epc

epc Trap program counter

20.15.2.3 tinst

unsigned long sbi_trap_info::tinst

tinst Trap instruction

20.15.2.4 tval

unsigned long sbi_trap_info::tval

tval Trap value

20.15.2.5 tval2

unsigned long sbi_trap_info::tval2

tval2 Trap value 2

The documentation for this struct was generated from the following file:

• include/sbi/sbi_trap.h

20.16 sbi_trap_regs Struct Reference

```
#include <sbi_trap.h>
```

Data Fields

- · unsigned long zero
- unsigned long ra
- unsigned long sp
- · unsigned long gp
- unsigned long tp
- unsigned long t0
- · unsigned long t1
- unsigned long t2
- unsigned long s0
- unsigned long s1
- unsigned long a0
- unsigned long a1
- unsigned long a2
- unsigned long a3unsigned long a4
- unsigned long a5
- a unsigned long as
- unsigned long a6
- unsigned long a7
- unsigned long s2
- unsigned long s3
- unsigned long s4
- unsigned long s5
- unsigned long s6
- unsigned long s7
- unsigned long s8
- unsigned long s9
- unsigned long s10
- unsigned long s11
- unsigned long t3unsigned long t4
- unsigned long t5
- unsigned long t6
- unsigned long mepc
- unsigned long mstatus
- unsigned long mstatusH

20.16.1 Detailed Description

Representation of register state at time of trap/interrupt

20.16.2 Field Documentation

```
20.16.2.1 a0
unsigned long sbi_trap_regs::a0
a0 register state
20.16.2.2 a1
unsigned long sbi_trap_regs::a1
a1 register state
20.16.2.3 a2
unsigned long sbi_trap_regs::a2
a2 register state
20.16.2.4 a3
unsigned long sbi_trap_regs::a3
a3 register state
20.16.2.5 a4
unsigned long sbi_trap_regs::a4
a4 register state
20.16.2.6 a5
```

a5 register state

unsigned long sbi_trap_regs::a5

```
20.16.2.7 a6
unsigned long sbi_trap_regs::a6
a6 register state
20.16.2.8 a7
unsigned long sbi_trap_regs::a7
a7 register state
20.16.2.9 gp
unsigned long sbi_trap_regs::gp
gp register state
20.16.2.10 mepc
unsigned long sbi_trap_regs::mepc
mepc register state
20.16.2.11 mstatus
unsigned long sbi_trap_regs::mstatus
mstatus register state
20.16.2.12 mstatusH
unsigned long sbi_trap_regs::mstatusH
mstatusH register state (only for 32-bit)
20.16.2.13 ra
unsigned long sbi_trap_regs::ra
ra register state
20.16.2.14 s0
unsigned long sbi_trap_regs::s0
s0 register state
```

Generated by Doxygen

```
20.16.2.15 s1
unsigned long sbi_trap_regs::s1
s1 register state
20.16.2.16 s10
unsigned long sbi_trap_regs::s10
s10 register state
20.16.2.17 s11
unsigned long sbi_trap_regs::s11
s11 register state
20.16.2.18 s2
unsigned long sbi_trap_regs::s2
s2 register state
20.16.2.19 s3
unsigned long sbi_trap_regs::s3
s3 register state
20.16.2.20 s4
unsigned long sbi_trap_regs::s4
s4 register state
20.16.2.21 s5
unsigned long sbi_trap_regs::s5
s5 register state
20.16.2.22 s6
unsigned long sbi_trap_regs::s6
s6 register state
```

```
20.16.2.23 s7
unsigned long sbi_trap_regs::s7
s7 register state
20.16.2.24 s8
unsigned long sbi_trap_regs::s8
s8 register state
20.16.2.25 s9
unsigned long sbi_trap_regs::s9
s9 register state
20.16.2.26 sp
unsigned long sbi_trap_regs::sp
sp register state
20.16.2.27 t0
unsigned long sbi_trap_regs::t0
t0 register state
20.16.2.28 t1
unsigned long sbi_trap_regs::t1
t1 register state
20.16.2.29 t2
unsigned long sbi_trap_regs::t2
t2 register state
20.16.2.30 t3
unsigned long sbi_trap_regs::t3
t3 register state
```

20.16.2.31 t4 unsigned long sbi_trap_regs::t4 t4 register state 20.16.2.32 t5 unsigned long sbi_trap_regs::t5 t5 register state 20.16.2.33 t6 unsigned long sbi_trap_regs::t6 t6 register state 20.16.2.34 tp unsigned long sbi_trap_regs::tp tp register state 20.16.2.35 zero unsigned long sbi_trap_regs::zero

.

zero register state

The documentation for this struct was generated from the following file:

• include/sbi/sbi_trap.h

20.17 spinlock_t Struct Reference

```
#include <riscv_locks.h>
```

Data Fields

volatile long lock

20.17.1 Field Documentation

20.17.1.1 lock

```
volatile long spinlock_t::lock
```

The documentation for this struct was generated from the following file:


• include/sbi/riscv_locks.h

Chapter 21

21.1	docs/contributing.md File Reference
21.2	docs/firmware/fw.md File Reference
21.3	docs/firmware/fw_dynamic.md File Reference
21.4	docs/firmware/fw_jump.md File Reference
21.5	docs/firmware/fw_payload.md File Reference
21.6	docs/firmware/payload_linux.md File Reference
21.7	docs/firmware/payload_uboot.md File Reference
21.8	docs/library_usage.md File Reference
21.9	docs/platform/andes-ae350.md File Reference
21.10	docs/platform/ariane-fpga.md File Reference
21.11	docs/platform/platform.md File Reference
21.12	docs/platform/gemu_virt.md File Reference

- 21.13 docs/platform/sifive_fu540.md File Reference
- 21.14 docs/platform/spike.md File Reference
- 21.15 docs/platform/thead-c910.md File Reference
- 21.16 docs/platform_guide.md File Reference
- 21.17 include/sbi/fw_dynamic.h File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/sbi_types.h>
Include dependency graph for fw dynamic.h:
```



Data Structures

• struct fw_dynamic_info

Macros

- #define FW_DYNAMIC_INFO_MAGIC_OFFSET (0 * __SIZEOF_POINTER__)
- #define FW_DYNAMIC_INFO_VERSION_OFFSET (1 * __SIZEOF_POINTER__)
- #define FW_DYNAMIC_INFO_NEXT_ADDR_OFFSET (2 * __SIZEOF_POINTER_
- #define FW DYNAMIC INFO NEXT MODE OFFSET (3 * SIZEOF POINTER)
- #define FW_DYNAMIC_INFO_OPTIONS_OFFSET (4 * __SIZEOF_POINTER__)
- #define FW_DYNAMIC_INFO_BOOT_HART_OFFSET (5 * __SIZEOF_POINTER__)
- #define FW_DYNAMIC_INFO_MAGIC_VALUE 0x4942534f
- #define FW DYNAMIC INFO VERSION MAX 0x2
- #define FW DYNAMIC INFO NEXT MODE U 0x0
- #define FW_DYNAMIC_INFO_NEXT_MODE_S 0x1
- #define FW_DYNAMIC_INFO_NEXT_MODE_M 0x3

Variables

```
• struct fw_dynamic_info __packed
```

21.17.1 Macro Definition Documentation

```
21.17.1.1 FW_DYNAMIC_INFO_BOOT_HART_OFFSET
#define FW_DYNAMIC_INFO_BOOT_HART_OFFSET (5 * __SIZEOF_POINTER__)
Offset of boot_hart member in fw_dynamic_info (version >= 2)
21.17.1.2 FW_DYNAMIC_INFO_MAGIC_OFFSET
#define FW_DYNAMIC_INFO_MAGIC_OFFSET (0 * __SIZEOF_POINTER__)
Offset of magic member in fw_dynamic_info
21.17.1.3 FW_DYNAMIC_INFO_MAGIC_VALUE
#define FW_DYNAMIC_INFO_MAGIC_VALUE 0x4942534f
Expected value of info magic ('OSBI' ascii string in hex)
21.17.1.4 FW_DYNAMIC_INFO_NEXT_ADDR_OFFSET
#define FW_DYNAMIC_INFO_NEXT_ADDR_OFFSET (2 * __SIZEOF_POINTER__)
Offset of next_addr member in fw_dynamic_info (version >= 1)
21.17.1.5 FW_DYNAMIC_INFO_NEXT_MODE_M
#define FW_DYNAMIC_INFO_NEXT_MODE_M 0x3
21.17.1.6 FW_DYNAMIC_INFO_NEXT_MODE_OFFSET
#define FW_DYNAMIC_INFO_NEXT_MODE_OFFSET (3 * __SIZEOF_POINTER__)
```


Offset of next_mode member in fw_dynamic_info (version >= 1)

```
21.17.1.7 FW_DYNAMIC_INFO_NEXT_MODE_S
#define FW_DYNAMIC_INFO_NEXT_MODE_S 0x1
21.17.1.8 FW_DYNAMIC_INFO_NEXT_MODE_U
#define FW_DYNAMIC_INFO_NEXT_MODE_U 0x0
Possible next mode values
21.17.1.9 FW_DYNAMIC_INFO_OPTIONS_OFFSET
#define FW_DYNAMIC_INFO_OPTIONS_OFFSET (4 * __SIZEOF_POINTER__)
Offset of options member in <a href="mailto:fw_dynamic_info">fw_dynamic_info</a> (version >= 1)
21.17.1.10 FW_DYNAMIC_INFO_VERSION_MAX
#define FW_DYNAMIC_INFO_VERSION_MAX 0x2
Maximum supported info version
21.17.1.11 FW_DYNAMIC_INFO_VERSION_OFFSET
#define FW_DYNAMIC_INFO_VERSION_OFFSET (1 * __SIZEOF_POINTER__)
Offset of version member in fw dynamic info
21.17.2 Variable Documentation
21.17.2.1 __packed
```


struct fw_dynamic_info __packed

21.18 include/sbi/riscv_asm.h File Reference

#include <sbi/riscv_encoding.h>
Include dependency graph for riscv_asm.h:



This graph shows which files directly or indirectly include this file:



Macros

- #define __ASM_STR(x) #x
- #define PAGE_SHIFT (12)
- #define PAGE_SIZE (_AC(1, UL) << PAGE_SHIFT)
- #define PAGE_MASK (\sim (PAGE_SIZE 1))
- #define REG_L __REG_SEL(Id, Iw)
- #define REG_S __REG_SEL(sd, sw)
- #define SZREG __REG_SEL(8, 4)
- #define LGREG __REG_SEL(3, 2)
- #define csr_swap(csr, val)
- #define csr_read(csr)
- #define csr_write(csr, val)
- #define csr_read_set(csr, val)
- #define csr_set(csr, val)
- #define csr_read_clear(csr, val)
- #define csr_clear(csr, val)
- #define wfi()
- #define misa_extension(c)

Functions

- unsigned long csr_read_num (int csr_num)
- void csr_write_num (int csr_num, unsigned long val)
- int misa_extension_imp (char ext)
- int misa xlen (void)
- static void misa_string (char *out, unsigned int out_sz)
- int pmp_set (unsigned int n, unsigned long prot, unsigned long addr, unsigned long log2len)
- int pmp_get (unsigned int n, unsigned long *prot_out, unsigned long *addr_out, unsigned long *log2len_out)

21.18.1 Macro Definition Documentation

```
21.18.1.4 csr_read_clear
```

Value:

21.18.1.5 csr_read_set

Value:

21.18.1.6 csr_set

```
({
    unsigned long _v = (unsigned long)(val);
    _asm__volatile_("csrs " _ASM_STR(csr) ", %0" \
    : "rK"(_v)
    : "memory");
})
```

```
21.18.1.7 csr_swap
```

```
#define csr_swap( csr, val )
```

Value:

21.18.1.8 csr_write

Value:

21.18.1.9 LGREG

```
#define LGREG __REG_SEL(3, 2)
```

21.18.1.10 misa_extension

```
#define misa_extension( \it c )
```

```
21.18.1.11 PAGE_MASK
```

```
#define PAGE_MASK (\sim(PAGE_SIZE - 1))
```

21.18.1.12 PAGE_SHIFT

```
#define PAGE_SHIFT (12)
```

21.18.1.13 PAGE_SIZE

```
#define PAGE_SIZE (_AC(1, UL) << PAGE_SHIFT)</pre>
```

21.18.1.14 REG_L

```
#define REG_L ___REG_SEL(ld, lw)
```

21.18.1.15 REG_S

```
#define REG_S ___REG_SEL(sd, sw)
```

21.18.1.16 SZREG

```
#define SZREG ___REG_SEL(8, 4)
```

21.18.1.17 wfi


```
#define wfi( )
```

```
do {
    __asm____volatile__("wfi" ::: "memory"); \
    } while (0)
```

21.18.2 Function Documentation


21.18.2.1 csr_read_num()

Here is the caller graph for this function:



21.18.2.2 csr_write_num()

Here is the caller graph for this function:



21.18.2.3 misa_extension_imp()

Here is the call graph for this function:




Here is the caller graph for this function:



21.18.2.4 misa_string()

Here is the call graph for this function:




Here is the caller graph for this function:



21.18.2.5 misa_xlen()

```
int misa_xlen (
     void )
```

Here is the call graph for this function:




Here is the caller graph for this function:




21.18.2.6 pmp_get()

```
int pmp_get (
          unsigned int n,
          unsigned long * prot_out,
          unsigned long * addr_out,
           unsigned long * log2len_out )
```

Here is the call graph for this function:




Here is the caller graph for this function:




21.18.2.7 pmp_set()

```
int pmp_set (
    unsigned int n,
    unsigned long prot,
    unsigned long addr,
    unsigned long log2len)
```

Here is the call graph for this function:




Here is the caller graph for this function:



21.19 include/sbi/riscv_atomic.h File Reference

This graph shows which files directly or indirectly include this file:



Data Structures

· struct atomic t

Macros

- #define ATOMIC_INIT(_lptr, val) (_lptr)->counter = (val)
- #define ATOMIC INITIALIZER(val)

Functions

- long atomic read (atomic t *atom)
- void atomic write (atomic t *atom, long value)
- long atomic_add_return (atomic_t *atom, long value)
- long atomic_sub_return (atomic_t *atom, long value)
- long arch_atomic_cmpxchg (atomic_t *atom, long oldval, long newval)
- long arch_atomic_xchg (atomic_t *atom, long newval)
- unsigned int atomic raw xchg uint (volatile unsigned int *ptr, unsigned int newval)
- unsigned long atomic_raw_xchg_ulong (volatile unsigned long *ptr, unsigned long newval)
- int atomic_set_bit (int nr, atomic_t *atom)
- int atomic_clear_bit (int nr, atomic_t *atom)
- int atomic_raw_set_bit (int nr, volatile unsigned long *addr)
- int atomic_raw_clear_bit (int nr, volatile unsigned long *addr)

21.19.1 Macro Definition Documentation

21.19.1.1 ATOMIC_INIT

21.19.1.2 ATOMIC_INITIALIZER

21.19.2 Function Documentation

.counter = (val), \

21.19.2.1 arch_atomic_cmpxchg()

21.19.2.2 arch_atomic_xchg()

21.19.2.3 atomic_add_return()

Here is the caller graph for this function:



21.19.2.4 atomic_clear_bit()

```
int atomic_clear_bit (
          int nr,
          atomic_t * atom ) [inline]
```

Clear a bit in an atomic variable and return the new value. : Bit to set. : atomic variable to modify Here is the call graph for this function:



21.19.2.5 atomic_raw_clear_bit()


Clear a bit in any address and return the new value . : Bit to set. : Address to modify Here is the caller graph for this function:



21.19.2.6 atomic_raw_set_bit()

```
int atomic_raw_set_bit (  \mbox{int } nr, \\ \mbox{volatile unsigned long } * \mbox{\it add} r \; ) \quad \mbox{[inline]}
```


Set a bit in any address and return the new value . : Bit to set. : Address to modify Here is the caller graph for this function:



21.19.2.7 atomic_raw_xchg_uint()

21.19.2.8 atomic_raw_xchg_ulong()

Here is the caller graph for this function:



21.19.2.9 atomic_read()

21.19.2.10 atomic_set_bit()

```
int atomic_set_bit (
    int nr,
    atomic_t * atom ) [inline]
```

Set a bit in an atomic variable and return the new value. : Bit to set. : atomic variable to modify Here is the call graph for this function:




21.19.2.11 atomic_sub_return()

21.19.2.12 atomic_write()

21.20 include/sbi/riscv_barrier.h File Reference

This graph shows which files directly or indirectly include this file:



Macros

```
#define RISCV_ACQUIRE_BARRIER "\tfence r , rw\n"
#define RISCV_RELEASE_BARRIER "\tfence rw, w\n"
#define RISCV_FENCE(p, s) __asm____volatile__ ("fence " #p "," #s : : : "memory")
#define mb() RISCV_FENCE(iorw,iorw)
#define rmb() RISCV_FENCE(ir,ir)
#define wmb() RISCV_FENCE(ow,ow)
#define smp_mb() RISCV_FENCE(rw,rw)
#define smp_rmb() RISCV_FENCE(r,r)
#define smp_wmb() RISCV_FENCE(w,w)
#define cpu_relax() asm volatile ("" : : : "memory")
#define smp_store release(p, v)
```

21.20.1 Macro Definition Documentation

• #define __smp_load_acquire(p)

Value:

```
({
          typeof(*p) __p1 = *(p); \
          RISCV_FENCE(r, rw); \
          _p1;
}
```

21.20.1.2 __smp_store_release

```
do {
          RISCV_FENCE(rw, w); \
          *(p) = (v);
          while (0)
```

```
21.20.1.3 cpu_relax
#define cpu_relax( ) asm volatile ("" : : "memory")
21.20.1.4 mb
#define mb() RISCV_FENCE(iorw,iorw)
21.20.1.5 RISCV_ACQUIRE_BARRIER
#define RISCV_ACQUIRE_BARRIER "\tfence r , rw\n"
21.20.1.6 RISCV_FENCE
#define RISCV_FENCE(
             р,
             s ) __asm__ _volatile__ ("fence " \sharp p "," \sharp s : : "memory")
21.20.1.7 RISCV_RELEASE_BARRIER
#define RISCV_RELEASE_BARRIER "\tfence rw, w\n"
21.20.1.8 rmb
#define rmb() RISCV_FENCE(ir,ir)
21.20.1.9 smp_mb
#define smp_mb() RISCV_FENCE(rw,rw)
```

21.20.1.10 smp_rmb

```
#define smp_rmb() RISCV_FENCE(r,r)
```

21.20.1.11 smp_wmb


```
#define smp_wmb() RISCV_FENCE(w,w)
```

21.20.1.12 wmb

```
#define wmb() RISCV_FENCE(ow,ow)
```

21.21 include/sbi/riscv_encoding.h File Reference

```
#include <sbi/sbi_const.h>
Include dependency graph for riscv_encoding.h:
```



This graph shows which files directly or indirectly include this file:



Macros

- #define MSTATUS SIE UL(0x00000002)
- #define MSTATUS MIE UL(0x00000008)
- #define MSTATUS SPIE SHIFT 5
- #define MSTATUS SPIE (UL(1) << MSTATUS SPIE SHIFT)
- #define MSTATUS_UBE _UL(0x00000040)
- #define MSTATUS MPIE UL(0x00000080)
- #define MSTATUS_SPP_SHIFT 8
- #define MSTATUS_SPP (_UL(1) << MSTATUS_SPP_SHIFT)
- #define MSTATUS MPP SHIFT 11
- #define MSTATUS MPP (UL(3) << MSTATUS MPP SHIFT)
- #define MSTATUS FS UL(0x00006000)
- #define MSTATUS_XS _UL(0x00018000)
- #define MSTATUS MPRV UL(0x00020000)
- #define MSTATUS_SUM _UL(0x00040000)
- #define MSTATUS MXR UL(0x00080000)
- #define MSTATUS_TVM _UL(0x00100000)
- #define MSTATUS_TW _UL(0x00200000)
- #define MSTATUS_TSR _UL(0x00400000)
- #define MSTATUS32_SD _UL(0x80000000)
- #define MSTATUSH_SBE _UL(0x00000010)
- #define MSTATUSH MBE UL(0x00000020)
- #define MSTATUSH_MPV _UL(0x00000080)
- #define MSTATUS32 SD UL(0x80000000)
- #define MSTATUS64 SD ULL(0x8000000000000000)
- #define SSTATUS SIE MSTATUS SIE
- · #define SSTATUS SPIE SHIFT MSTATUS SPIE SHIFT
- #define SSTATUS SPIE MSTATUS SPIE
- #define SSTATUS_SPP_SHIFT MSTATUS_SPP_SHIFT
- #define SSTATUS_SPP MSTATUS_SPP
- #define SSTATUS_FS MSTATUS_FS
- #define SSTATUS_XS MSTATUS_XS
- #define SSTATUS_SUM MSTATUS_SUM
- #define SSTATUS_MXR MSTATUS_MXR
- #define SSTATUS32_SD MSTATUS32_SD
- #define SSTATUS64_UXL MSTATUS_UXL
- #define SSTATUS64_SD MSTATUS64_SD
- #define HSTATUS_VTSR _UL(0x00400000)
- #define HSTATUS_VTVM _UL(0x00100000)
- #define HSTATUS_SP2V _UL(0x00000200)
- #define HSTATUS_SP2P _UL(0x00000100)
- #define HSTATUS_SPV _UL(0x00000080)
- #define HSTATUS_SPRV _UL(0x00000001)
- #define IRQ S SOFT 1
- #define IRQ VS SOFT 2
- #define IRQ M SOFT 3
- #define IRQ_S_TIMER 5
- #define IRQ_VS_TIMER 6
- #define IRQ_M_TIMER 7
- #define IRQ_S_EXT 9
- #define IRQ_VS_EXT 10
- #define IRQ_M_EXT 11
- #define IRQ_S_GEXT 12
- #define MIP_SSIP (_UL(1) << IRQ_S_SOFT)

```
    #define MIP_VSSIP (_UL(1) << IRQ_VS_SOFT)</li>

    #define MIP_MSIP (_UL(1) << IRQ_M_SOFT)</li>

    #define MIP_STIP (_UL(1) << IRQ_S_TIMER)</li>

    #define MIP_VSTIP (_UL(1) << IRQ_VS_TIMER)</li>

    #define MIP_MTIP (_UL(1) << IRQ_M_TIMER)</li>

    #define MIP_SEIP (_UL(1) << IRQ_S_EXT)</li>

    #define MIP VSEIP ( UL(1) << IRQ VS EXT)</li>

    #define MIP_MEIP (_UL(1) << IRQ_M_EXT)</li>

    #define MIP_SGEIP (_UL(1) << IRQ_S_GEXT)</li>

• #define SIP SSIP MIP SSIP
• #define SIP STIP MIP STIP

    #define PRV U UL(0)

• #define PRV_S _UL(1)

    #define PRV M UL(3)

    #define SATP32_MODE _UL(0x80000000)

    #define SATP32 ASID UL(0x7FC00000)

    #define SATP32 PPN UL(0x003FFFFF)

    #define SATP64 MODE ULL(0xF0000000000000000)

    #define SATP64_ASID _ULL(0x0FFF00000000000)

    #define SATP64_PPN _ULL(0x00000FFFFFFFFFF)

    #define SATP_MODE_OFF _UL(0)

• #define SATP MODE SV32 UL(1)

    #define SATP MODE SV39 UL(8)

    #define SATP_MODE_SV48 _UL(9)

    #define SATP MODE SV57 UL(10)

    #define SATP_MODE_SV64 _UL(11)

#define PMP_R _UL(0x01)

    #define PMP W UL(0x02)

    #define PMP X UL(0x04)

    #define PMP_A _UL(0x18)

• #define PMP_A_TOR _UL(0x08)

    #define PMP A NA4 UL(0x10)

    #define PMP_A_NAPOT _UL(0x18)

• #define PMP_L _UL(0x80)

    #define PMP SHIFT 2

    #define PMP COUNT 16

    #define PTE_V _UL(0x001) /* Valid */

    #define PTE_R _UL(0x002) /* Read */

    #define PTE_W _UL(0x004) /* Write */

 #define PTE X UL(0x008) /* Execute */

    #define PTE U UL(0x010) /* User */

    #define PTE_G _UL(0x020) /* Global */

    #define PTE A UL(0x040) /* Accessed */

    #define PTE_D _UL(0x080) /* Dirty */

    #define PTE_SOFT_UL(0x300) /* Reserved for Software */

• #define PTE PPN SHIFT 10
#define PTE_TABLE(PTE) (((PTE) & (PTE_V | PTE_R | PTE_W | PTE_X)) == PTE V)

    #define MSTATUS_SD MSTATUS32_SD

    #define SSTATUS_SD SSTATUS32_SD

    #define RISCV_PGLEVEL_BITS 10

• #define SATP MODE SATP32 MODE
• #define RISCV PGSHIFT 12

    #define RISCV PGSIZE (1 << RISCV PGSHIFT)</li>

    #define CSR USTATUS 0x0

    #define CSR FFLAGS 0x1
```

- #define CSR FRM 0x2
- #define CSR_FCSR 0x3
- #define CSR_CYCLE 0xc00
- #define CSR UIE 0x4
- #define CSR UTVEC 0x5
- #define CSR_USCRATCH 0x40
- #define CSR UEPC 0x41
- #define CSR_UCAUSE 0x42
- #define CSR UTVAL 0x43
- #define CSR UIP 0x44
- #define CSR TIME 0xc01
- #define CSR INSTRET 0xc02
- #define CSR_HPMCOUNTER3 0xc03
- #define CSR_HPMCOUNTER4 0xc04
- #define CSR_HPMCOUNTER5 0xc05
- #define CSR HPMCOUNTER6 0xc06
- #define CSR HPMCOUNTER7 0xc07
- #define CSR HPMCOUNTER8 0xc08
- #define CSR_HPMCOUNTER9 0xc09
- #define CSR_HPMCOUNTER10 0xc0a
- #define CSR_HPMCOUNTER11 0xc0b
- #define CSR HPMCOUNTER12 0xc0c
- #define CSR HPMCOUNTER13 0xc0d
- #define CSR_HPMCOUNTER14 0xc0e
- #define CSR HPMCOUNTER15 0xc0f
- #define CSR_HPMCOUNTER16 0xc10
- #define CSR_HPMCOUNTER17 0xc11
- #define CSR HPMCOUNTER18 0xc12
- #define CSR HPMCOUNTER19 0xc13
- #define CSR_HPMCOUNTER20 0xc14
- #define CSR HPMCOUNTER21 0xc15
- #define CSR HPMCOUNTER22 0xc16
- #define CSR_HPMCOUNTER23 0xc17
- #define CSR HPMCOUNTER24 0xc18
- #define CSR HPMCOUNTER25 0xc19
- #define CSR_HPMCOUNTER26 0xc1a
- #define CSR_HPMCOUNTER27 0xc1b
- #define CSR_HPMCOUNTER28 0xc1c
- #define CSR_HPMCOUNTER29 0xc1d
- #define CSR HPMCOUNTER30 0xc1e
- #define CSR HPMCOUNTER31 0xc1f
- #define CSR_SSTATUS 0x100
- #define CSR_SIE 0x104
- #define CSR_STVEC 0x105
- #define CSR_SCOUNTEREN 0x106
- #define CSR_SSCRATCH 0x140
- #define CSR_SEPC 0x141
- #define CSR_SCAUSE 0x142
- #define CSR_STVAL 0x143
- #define CSR_SIP 0x144
- #define CSR SATP 0x180
- #define CSR_HSTATUS 0x600
- #define CSR_HEDELEG 0x602
- #define CSR_HIDELEG 0x603
- #define CSR_HIE 0x604

- #define CSR HTIMEDELTA 0x605
- #define CSR_HTIMEDELTAH 0x615
- #define CSR_HCOUNTERNEN 0x606
- #define CSR HGEIE 0x607
- #define CSR HTVAL 0x643
- #define CSR_HIP 0x644
- #define CSR HTINST 0x64a
- #define CSR_HGATP 0x680
- #define CSR_HGEIP 0xe07
- #define CSR VSSTATUS 0x200
- #define CSR VSIE 0x204
- #define CSR VSTVEC 0x205
- #define CSR_VSSCRATCH 0x240
- #define CSR VSEPC 0x241
- #define CSR_VSCAUSE 0x242
- #define CSR VSTVAL 0x243
- #define CSR VSIP 0x244
- #define CSR VSATP 0x280
- #define CSR_MSTATUS 0x300
- #define CSR_MISA 0x301
- #define CSR_MEDELEG 0x302
- #define CSR MIDELEG 0x303
- #define CSR MIE 0x304
- #define CSR_MTVEC 0x305
- #define CSR MCOUNTEREN 0x306
- #define CSR_MSTATUSH 0x310
- #define CSR MSCRATCH 0x340
- #define CSR_MEPC 0x341
- #define CSR MCAUSE 0x342
- #define CSR_MTVAL 0x343
- #define CSR MIP 0x344
- #define CSR MTINST 0x34a
- #define CSR_MTVAL2 0x34b
- #define CSR_PMPCFG0 0x3a0
- #define CSR_PMPCFG1 0x3a1#define CSR_PMPCFG2 0x3a2
- #define CCD_DMDCEC2.0v2e2
- #define CSR_PMPCFG3 0x3a3#define CSR_PMPADDR0 0x3b0
- #define CSR PMPADDR1 0x3b1
- #define CSR PMPADDR2 0x3b2
- #define CSR PMPADDR3 0x3b3
- #define CSR_PMPADDR4 0x3b4
- #define CSR PMPADDR5 0x3b5
- #define CSR_PMPADDR6 0x3b6
- #define CSR PMPADDR7 0x3b7
- #define CSR PMPADDR8 0x3b8
- #define CSR PMPADDR9 0x3b9
- #define CSR_PMPADDR10 0x3ba
- #define CSR_PMPADDR11 0x3bb
- #define CSR_PMPADDR12 0x3bc
- #define CSR_PMPADDR13 0x3bd
- #define CSR_PMPADDR14 0x3be
- #define CSR_PMPADDR15 0x3bf
- #define CSR_TSELECT 0x7a0
- #define CSR_TDATA1 0x7a1

- #define CSR TDATA2 0x7a2
- #define CSR TDATA3 0x7a3
- #define CSR_DCSR 0x7b0
- #define CSR DPC 0x7b1
- #define CSR DSCRATCH 0x7b2
- #define CSR_MCYCLE 0xb00
- #define CSR MINSTRET 0xb02
- #define CSR_MHPMCOUNTER3 0xb03
- #define CSR_MHPMCOUNTER4 0xb04
- #define CSR_MHPMCOUNTER5 0xb05
- #define CSR_MHPMCOUNTER6 0xb06
- #define CSR MHPMCOUNTER7 0xb07
- #define CSR_MHPMCOUNTER8 0xb08
- #define CSR MHPMCOUNTER9 0xb09
- #define CSR_MHPMCOUNTER10 0xb0a
- #define CSR MHPMCOUNTER11 0xb0b
- #define Oott_With WOOdNTETTT OXDOR
- #define CSR_MHPMCOUNTER12 0xb0c
- #define CSR_MHPMCOUNTER13 0xb0d
- #define CSR_MHPMCOUNTER14 0xb0e
- #define CSR MHPMCOUNTER15 0xb0f
- #define CSR_MHPMCOUNTER16 0xb10
- #define CSR MHPMCOUNTER17 0xb11
- #define CSR MHPMCOUNTER18 0xb12
- #define CSR_MHPMCOUNTER19 0xb13
- #define CSR MHPMCOUNTER20 0xb14
- #define CSR_MHPMCOUNTER21 0xb15
- #define CSR_MHPMCOUNTER22 0xb16
- #define CSR MHPMCOUNTER23 0xb17
- #define CSR MHPMCOUNTER24 0xb18
- #define CSR_MHPMCOUNTER25 0xb19
- #define CSR MHPMCOUNTER26 0xb1a
- #define CSR MHPMCOUNTER27 0xb1b
- #define CSR_MHPMCOUNTER28 0xb1c
- #define CSR_MHPMCOUNTER29 0xb1d
- #define CSR_MHPMCOUNTER30 0xb1e
- #define CSR_MHPMCOUNTER31 0xb1f
- #define CSR_MHPMEVENT3 0x323
- #define CSR_MHPMEVENT4 0x324
- #define CSR MHPMEVENT5 0x325
- #define CSR MHPMEVENT6 0x326
- #define CSR MHPMEVENT7 0x327
- #define CSR_MHPMEVENT8 0x328
- #define CSR_MHPMEVENT9 0x329
- #define CSR_MHPMEVENT10 0x32a
- #define CSR_MHPMEVENT11 0x32b
- #define CSR MHPMEVENT12 0x32c
- #define CSR_MHPMEVENT13 0x32d
- #define CSR_MHPMEVENT14 0x32e
- #define CSR_MHPMEVENT15 0x32f
- #define CSR_MHPMEVENT16 0x330
- #define CSR_MHPMEVENT17 0x331
- #define CSR_MHPMEVENT18 0x332
- #define CSR_MHPMEVENT19 0x333
- #define CSR_MHPMEVENT20 0x334
- #define CSR_MHPMEVENT21 0x335

- #define CSR MHPMEVENT22 0x336
- #define CSR MHPMEVENT23 0x337
- #define CSR_MHPMEVENT24 0x338
- #define CSR MHPMEVENT25 0x339
- #define CSR MHPMEVENT26 0x33a
- #define CSR_MHPMEVENT27 0x33b
- #define CSR_MHPMEVENT28 0x33c
- #define CSR_MHPMEVENT29 0x33d
- #define CSR_MHPMEVENT30 0x33e
- #define CSR MHPMEVENT31 0x33f
- #define CSR_MVENDORID 0xf11
- #define CSR MARCHID 0xf12
- #define CSR_MIMPID 0xf13
- #define CSR MHARTID 0xf14
- #define CSR_CYCLEH 0xc80
- #define CSR TIMEH 0xc81
- #define CSR INSTRETH 0xc82
- #define CSR HPMCOUNTER3H 0xc83
- #define CSR HPMCOUNTER4H 0xc84
- #define CSR HPMCOUNTER5H 0xc85
- #define CSR_HPMCOUNTER6H 0xc86
- #define CSR HPMCOUNTER7H 0xc87
- #define CSR HPMCOUNTER8H 0xc88
- #define CSR_HPMCOUNTER9H 0xc89
- #define CSR HPMCOUNTER10H 0xc8a
- #define CSR_HPMCOUNTER11H 0xc8b
- #define CSR HPMCOUNTER12H 0xc8c
- #define CSR HPMCOUNTER13H 0xc8d
- #define CSR HPMCOUNTER14H 0xc8e
- #define CSR_HPMCOUNTER15H 0xc8f
- #define CSR HPMCOUNTER16H 0xc90
- #define CSR HPMCOUNTER17H 0xc91
- #define CSR_HPMCOUNTER18H 0xc92
- #define CSR_HPMCOUNTER19H 0xc93
- #define CSR_HPMCOUNTER20H 0xc94
 #define CSR_HPMCOUNTER21H 0xc95
- #define CSR HPMCOUNTER22H 0xc96
- #define CSR HPMCOUNTER23H 0xc97
- #define CSR_HPMCOUNTER24H 0xc98
- #define CSR HPMCOUNTER25H 0xc99
- #define CSR HPMCOUNTER26H 0xc9a
- #define CSR_HPMCOUNTER27H 0xc9b
- #define CSR_HPMCOUNTER28H 0xc9c
- #define CSR_HPMCOUNTER29H 0xc9d
- #define CSR_HPMCOUNTER30H 0xc9e
- #define CSR HPMCOUNTER31H 0xc9f
- #define CSR MCYCLEH 0xb80
- #define CSR_MINSTRETH 0xb82
- #define CSR_MHPMCOUNTER3H 0xb83
- #define CSR_MHPMCOUNTER4H 0xb84
- #define CSR MHPMCOUNTER5H 0xb85
- #define CSR MHPMCOUNTER6H 0xb86
- #define CSR MHPMCOUNTER7H 0xb87
- #define CSR MHPMCOUNTER8H 0xb88
- #define CSR MHPMCOUNTER9H 0xb89

- #define CSR MHPMCOUNTER10H 0xb8a
- #define CSR MHPMCOUNTER11H 0xb8b
- #define CSR_MHPMCOUNTER12H 0xb8c
- #define CSR MHPMCOUNTER13H 0xb8d
- #define CSR MHPMCOUNTER14H 0xb8e
- #define CSR_MHPMCOUNTER15H 0xb8f
- #define CSR MHPMCOUNTER16H 0xb90
- #define CSR_MHPMCOUNTER17H 0xb91
- #define CSR_MHPMCOUNTER18H 0xb92
- #define CSR MHPMCOUNTER19H 0xb93
- Washing Gott_Mill MoodstrEfffort oxboo
- #define CSR_MHPMCOUNTER20H 0xb94
- #define CSR_MHPMCOUNTER21H 0xb95
- #define CSR_MHPMCOUNTER22H 0xb96
- #define CSR_MHPMCOUNTER23H 0xb97
- #define CSR_MHPMCOUNTER24H 0xb98
- #define CSR_MHPMCOUNTER25H 0xb99
- #define CSR_MHPMCOUNTER26H 0xb9a
- #define CSR_MHPMCOUNTER27H 0xb9b
- #define CSR_MHPMCOUNTER28H 0xb9c
- #define CSR_MHPMCOUNTER29H 0xb9d
- #define CSR_MHPMCOUNTER30H 0xb9e
- #define CSR MHPMCOUNTER31H 0xb9f
- #define CAUSE MISALIGNED FETCH 0x0
- #define CAUSE_FETCH_ACCESS 0x1
- #define CAUSE ILLEGAL INSTRUCTION 0x2
- #define CAUSE_BREAKPOINT 0x3
- #define CAUSE MISALIGNED LOAD 0x4
- #define CAUSE LOAD ACCESS 0x5
- #define CAUSE MISALIGNED STORE 0x6
- #define CAUSE_STORE_ACCESS 0x7
- #define CAUSE USER ECALL 0x8
- #define CAUSE HYPERVISOR ECALL 0x9
- #define CAUSE_SUPERVISOR_ECALL 0xa
- #define CAUSE_MACHINE_ECALL 0xb
- #define CAUSE_FETCH_PAGE_FAULT 0xc
- #define CAUSE_LOAD_PAGE_FAULT 0xd
- #define CAUSE_STORE_PAGE_FAULT 0xf
- #define CAUSE FETCH GUEST PAGE FAULT 0x14
- #define CAUSE_LOAD_GUEST_PAGE_FAULT 0x15
- #define CAUSE STORE GUEST PAGE FAULT 0x17
- #define INSN MATCH LB 0x3
- #define INSN_MASK_LB 0x707f
- #define INSN_MATCH_LH 0x1003
- #define INSN_MASK_LH 0x707f
- #define INSN MATCH LW 0x2003
- #define INSN MASK LW 0x707f
- #define INSN MATCH LD 0x3003
- #define INSN_MASK_LD 0x707f
- #define INSN_MATCH_LBU 0x4003
- #define INSN_MASK_LBU 0x707f
- #define INSN MATCH LHU 0x5003
- #define INSN_MASK_LHU 0x707f
- #define INSN MATCH LWU 0x6003
- #define INSN_MASK_LWU 0x707f
- #define INSN MATCH SB 0x23

- #define INSN MASK SB 0x707f
- #define INSN_MATCH_SH 0x1023
- #define INSN_MASK_SH 0x707f
- #define INSN MATCH SW 0x2023
- #define INSN MASK SW 0x707f
- #define INSN_MATCH_SD 0x3023
- #define INSN MASK SD 0x707f
- #define INSN_MATCH_FLW 0x2007
- #define INSN_MASK_FLW 0x707f
- #define INSN MATCH FLD 0x3007
- #define INSN MASK FLD 0x707f
- #define INSN MATCH FLQ 0x4007
- #define INSN MASK FLQ 0x707f
- #define INSN MATCH FSW 0x2027
- #define INSN_MASK_FSW 0x707f
- #define INSN MATCH FSD 0x3027
- #define INSN MASK FSD 0x707f
- #define INSN MATCH FSQ 0x4027
- #define INSN_MASK_FSQ 0x707f
- #define INSN_MATCH_C_LD 0x6000
- #define INSN_MASK_C_LD 0xe003
- #define INSN MATCH C SD 0xe000
- #define INSN MASK C SD 0xe003
- #define INSN_MATCH_C_LW 0x4000
- #define INSN MASK C LW 0xe003
- #define INSN_MATCH_C_SW 0xc000
- #define INSN MASK C SW 0xe003
- #define INSN MATCH C LDSP 0x6002
- #define INSN_MASK_C_LDSP 0xe003
- #define INSN_MATCH_C_SDSP 0xe002
- #define INSN_MASK_C_SDSP 0xe003
- #define INSN MATCH C LWSP 0x4002
- #define INSN_MASK_C_LWSP 0xe003
- #define INSN MATCH C SWSP 0xc002
- #define INSN_MASK_C_SWSP 0xe003
- #define INSN MATCH C FLD 0x2000
- #define INSN_MASK_C_FLD 0xe003
- #define INSN_MATCH_C_FLW 0x6000
- #define INSN_MASK_C_FLW 0xe003
- #define INSN_MATCH_C_FSD 0xa000
- #define INSN MASK C FSD 0xe003
- #define INSN_MATCH_C_FSW 0xe000
- #define INSN_MASK_C_FSW 0xe003
- #define INSN_MATCH_C_FLDSP 0x2002
- #define INSN_MASK_C_FLDSP 0xe003
- #define INSN_MATCH_C_FSDSP 0xa002
- #define INSN_MASK_C_FSDSP 0xe003
- #define INSN_MATCH_C_FLWSP 0x6002
- #define INSN_MASK_C_FLWSP 0xe003#define INSN_MATCH_C_FSWSP 0xe002
- #define INSN MASK C FSWSP 0xe003
- #define INSN MASK WFI 0xffffff00
- #define INSN MATCH WFI 0x10500000
- #define INSN 16BIT MASK 0x3
- #define INSN_32BIT_MASK 0x1c

```
#define INSN_IS_16BIT(insn) (((insn) & INSN_16BIT_MASK) != INSN_16BIT_MASK)

    #define INSN_IS_32BIT(insn)

• #define INSN LEN(insn) (INSN IS 16BIT(insn) ? 2:4)
• #define LOG REGBYTES 2

    #define REGBYTES (1 << LOG REGBYTES)</li>

• #define SH RD 7
• #define SH RS1 15
• #define SH RS2 20
• #define SH RS2C 2
• #define RV_X(x, s, n) (((x) >> (s)) & ((1 << (n)) - 1))
• #define RVC LW IMM(x)

    #define RVC_LD_IMM(x)

    #define RVC LWSP IMM(x)

• #define RVC_LDSP_IMM(x)
• #define RVC SWSP IMM(x)
• #define RVC_SDSP_IMM(x)
#define RVC_RS1S(insn) (8 + RV_X(insn, SH_RD, 3))

    #define RVC RS2S(insn) (8 + RV X(insn, SH RS2C, 3))

• #define RVC_RS2(insn) RV_X(insn, SH_RS2C, 5)
• #define SHIFT_RIGHT(x, y) ((y) < 0 ? ((x) << -(y)) : ((x) >> (y)))

    #define REG_MASK ((1 << (5 + LOG_REGBYTES)) - (1 << LOG_REGBYTES))</li>

    #define REG_OFFSET(insn, pos) (SHIFT_RIGHT((insn), (pos) - LOG_REGBYTES) & REG_MASK)

    #define REG_PTR(insn, pos, regs) (ulong *)((ulong)(regs) + REG_OFFSET(insn, pos))

    #define GET_RM(insn) (((insn) >> 12) & 7)

• #define GET_RS1(insn, regs) (*REG_PTR(insn, SH_RS1, regs))
• #define GET_RS2(insn, regs) (*REG_PTR(insn, SH_RS2, regs))
• #define GET_RS1S(insn, regs) (*REG_PTR(RVC_RS1S(insn), 0, regs))

    #define GET_RS2S(insn, regs) (*REG_PTR(RVC_RS2S(insn), 0, regs))

    #define GET_RS2C(insn, regs) (*REG_PTR(insn, SH_RS2C, regs))

    #define GET_SP(regs) (*REG_PTR(2, 0, regs))

#define SET_RD(insn, regs, val) (*REG_PTR(insn, SH_RD, regs) = (val))
• #define IMM I(insn) ((s32)(insn) >> 20)
• #define IMM S(insn)

    #define MASK_FUNCT3 0x7000
```

21.21.1 Macro Definition Documentation

21.21.1.1 CAUSE_BREAKPOINT

#define CAUSE_BREAKPOINT 0x3

21.21.1.2 CAUSE_FETCH_ACCESS

#define CAUSE_FETCH_ACCESS 0x1

21.21.1.3 CAUSE_FETCH_GUEST_PAGE_FAULT

#define CAUSE_FETCH_GUEST_PAGE_FAULT 0x14

21.21.1.4 CAUSE_FETCH_PAGE_FAULT

#define CAUSE_FETCH_PAGE_FAULT 0xc

21.21.1.5 CAUSE_HYPERVISOR_ECALL

#define CAUSE_HYPERVISOR_ECALL 0x9

21.21.1.6 CAUSE_ILLEGAL_INSTRUCTION

#define CAUSE_ILLEGAL_INSTRUCTION 0x2

21.21.1.7 CAUSE_LOAD_ACCESS

#define CAUSE_LOAD_ACCESS 0x5

21.21.1.8 CAUSE_LOAD_GUEST_PAGE_FAULT

#define CAUSE_LOAD_GUEST_PAGE_FAULT 0x15

21.21.1.9 CAUSE_LOAD_PAGE_FAULT

#define CAUSE_LOAD_PAGE_FAULT 0xd

21.21.1.10 CAUSE_MACHINE_ECALL

#define CAUSE_MACHINE_ECALL 0xb

21.21.1.11 CAUSE_MISALIGNED_FETCH

#define CAUSE_MISALIGNED_FETCH 0x0

21.21.1.12 CAUSE_MISALIGNED_LOAD

#define CAUSE_MISALIGNED_LOAD 0x4

21.21.1.13 CAUSE_MISALIGNED_STORE

#define CAUSE_MISALIGNED_STORE 0x6

21.21.1.14 CAUSE_STORE_ACCESS

#define CAUSE_STORE_ACCESS 0x7

21.21.1.15 CAUSE_STORE_GUEST_PAGE_FAULT

#define CAUSE_STORE_GUEST_PAGE_FAULT 0x17

21.21.1.16 CAUSE_STORE_PAGE_FAULT

#define CAUSE_STORE_PAGE_FAULT 0xf

21.21.1.17 CAUSE_SUPERVISOR_ECALL

#define CAUSE_SUPERVISOR_ECALL 0xa

21.21.1.18 CAUSE_USER_ECALL

#define CAUSE_USER_ECALL 0x8

21.21.1.19 CSR_CYCLE

#define CSR_CYCLE 0xc00

21.21.1.20 CSR_CYCLEH

#define CSR_CYCLEH 0xc80

21.21.1.21 CSR_DCSR

#define CSR_DCSR 0x7b0

21.21.1.22 CSR_DPC

#define CSR_DPC 0x7b1

21.21.1.23 CSR_DSCRATCH

#define CSR_DSCRATCH 0x7b2

21.21.1.24 CSR_FCSR

#define CSR_FCSR 0x3

21.21.1.25 CSR_FFLAGS

#define CSR_FFLAGS 0x1

21.21.1.26 CSR_FRM

#define CSR_FRM 0x2

21.21.1.27 CSR_HCOUNTERNEN

#define CSR_HCOUNTERNEN 0x606

21.21.1.28 CSR_HEDELEG

#define CSR_HEDELEG 0x602

21.21.1.29 CSR_HGATP

#define CSR_HGATP 0x680

21.21.1.30 CSR_HGEIE

#define CSR_HGEIE 0x607

21.21.1.31 CSR_HGEIP

#define CSR_HGEIP 0xe07

21.21.1.32 CSR_HIDELEG

#define CSR_HIDELEG 0x603

21.21.1.33 CSR_HIE

#define CSR_HIE 0x604

21.21.1.34 CSR_HIP

#define CSR_HIP 0x644

21.21.1.35 CSR_HPMCOUNTER10

#define CSR_HPMCOUNTER10 0xc0a

21.21.1.36 CSR_HPMCOUNTER10H

#define CSR_HPMCOUNTER10H 0xc8a

21.21.1.37 CSR_HPMCOUNTER11

#define CSR_HPMCOUNTER11 0xc0b

21.21.1.38 CSR_HPMCOUNTER11H

#define CSR_HPMCOUNTER11H 0xc8b

21.21.1.39 CSR_HPMCOUNTER12

#define CSR_HPMCOUNTER12 0xc0c

21.21.1.40 CSR_HPMCOUNTER12H

#define CSR_HPMCOUNTER12H 0xc8c

21.21.1.41 CSR_HPMCOUNTER13

#define CSR_HPMCOUNTER13 0xc0d

21.21.1.42 CSR_HPMCOUNTER13H

#define CSR_HPMCOUNTER13H 0xc8d

21.21.1.43 CSR_HPMCOUNTER14

#define CSR_HPMCOUNTER14 0xc0e

21.21.1.44 CSR_HPMCOUNTER14H

#define CSR_HPMCOUNTER14H 0xc8e

21.21.1.45 CSR_HPMCOUNTER15

#define CSR_HPMCOUNTER15 0xc0f

21.21.1.46 CSR_HPMCOUNTER15H

#define CSR_HPMCOUNTER15H 0xc8f

21.21.1.47 CSR_HPMCOUNTER16

#define CSR_HPMCOUNTER16 0xc10

21.21.1.48 CSR_HPMCOUNTER16H

#define CSR_HPMCOUNTER16H 0xc90

21.21.1.49 CSR_HPMCOUNTER17

#define CSR_HPMCOUNTER17 0xc11

21.21.1.50 CSR_HPMCOUNTER17H

#define CSR_HPMCOUNTER17H 0xc91

21.21.1.51 CSR_HPMCOUNTER18

#define CSR_HPMCOUNTER18 0xc12

21.21.1.52 CSR_HPMCOUNTER18H

#define CSR_HPMCOUNTER18H 0xc92

21.21.1.53 CSR_HPMCOUNTER19

#define CSR_HPMCOUNTER19 0xc13

21.21.1.54 CSR_HPMCOUNTER19H

#define CSR_HPMCOUNTER19H 0xc93

21.21.1.55 CSR_HPMCOUNTER20

#define CSR_HPMCOUNTER20 0xc14

21.21.1.56 CSR_HPMCOUNTER20H

#define CSR_HPMCOUNTER20H 0xc94

21.21.1.57 CSR_HPMCOUNTER21

#define CSR_HPMCOUNTER21 0xc15

21.21.1.58 CSR_HPMCOUNTER21H

#define CSR_HPMCOUNTER21H 0xc95

21.21.1.59 CSR_HPMCOUNTER22

#define CSR_HPMCOUNTER22 0xc16

21.21.1.60 CSR_HPMCOUNTER22H

#define CSR_HPMCOUNTER22H 0xc96

21.21.1.61 CSR_HPMCOUNTER23

#define CSR_HPMCOUNTER23 0xc17

21.21.1.62 CSR_HPMCOUNTER23H

#define CSR_HPMCOUNTER23H 0xc97

21.21.1.63 CSR_HPMCOUNTER24

#define CSR_HPMCOUNTER24 0xc18

21.21.1.64 CSR_HPMCOUNTER24H

#define CSR_HPMCOUNTER24H 0xc98

21.21.1.65 CSR_HPMCOUNTER25

#define CSR_HPMCOUNTER25 0xc19

21.21.1.66 CSR_HPMCOUNTER25H

#define CSR_HPMCOUNTER25H 0xc99

21.21.1.67 CSR_HPMCOUNTER26

#define CSR_HPMCOUNTER26 0xc1a

21.21.1.68 CSR_HPMCOUNTER26H

#define CSR_HPMCOUNTER26H 0xc9a

21.21.1.69 CSR_HPMCOUNTER27

#define CSR_HPMCOUNTER27 0xclb

21.21.1.70 CSR_HPMCOUNTER27H

#define CSR_HPMCOUNTER27H 0xc9b

21.21.1.71 CSR_HPMCOUNTER28

#define CSR_HPMCOUNTER28 0xclc

21.21.1.72 CSR_HPMCOUNTER28H

#define CSR_HPMCOUNTER28H 0xc9c

21.21.1.73 CSR_HPMCOUNTER29

#define CSR_HPMCOUNTER29 0xcld

21.21.1.74 CSR_HPMCOUNTER29H

#define CSR_HPMCOUNTER29H 0xc9d

21.21.1.75 CSR_HPMCOUNTER3

#define CSR_HPMCOUNTER3 0xc03

21.21.1.76 CSR_HPMCOUNTER30

#define CSR_HPMCOUNTER30 0xcle

21.21.1.77 CSR_HPMCOUNTER30H

#define CSR_HPMCOUNTER30H 0xc9e

21.21.1.78 CSR_HPMCOUNTER31

#define CSR_HPMCOUNTER31 0xc1f

21.21.1.79 CSR_HPMCOUNTER31H

#define CSR_HPMCOUNTER31H 0xc9f

21.21.1.80 CSR_HPMCOUNTER3H

#define CSR_HPMCOUNTER3H 0xc83

21.21.1.81 CSR_HPMCOUNTER4

#define CSR_HPMCOUNTER4 0xc04

21.21.1.82 CSR_HPMCOUNTER4H

#define CSR_HPMCOUNTER4H 0xc84

21.21.1.83 CSR_HPMCOUNTER5

#define CSR_HPMCOUNTER5 0xc05

21.21.1.84 CSR_HPMCOUNTER5H

#define CSR_HPMCOUNTER5H 0xc85

21.21.1.85 CSR_HPMCOUNTER6

#define CSR_HPMCOUNTER6 0xc06

21.21.1.86 CSR_HPMCOUNTER6H

#define CSR_HPMCOUNTER6H 0xc86

21.21.1.87 CSR_HPMCOUNTER7

#define CSR_HPMCOUNTER7 0xc07

21.21.1.88 CSR_HPMCOUNTER7H

#define CSR_HPMCOUNTER7H 0xc87

21.21.1.89 CSR_HPMCOUNTER8

#define CSR_HPMCOUNTER8 0xc08

21.21.1.90 CSR_HPMCOUNTER8H

#define CSR_HPMCOUNTER8H 0xc88

21.21.1.91 CSR_HPMCOUNTER9

#define CSR_HPMCOUNTER9 0xc09

21.21.1.92 CSR_HPMCOUNTER9H

#define CSR_HPMCOUNTER9H 0xc89

21.21.1.93 CSR_HSTATUS

#define CSR_HSTATUS 0x600

21.21.1.94 CSR_HTIMEDELTA

#define CSR_HTIMEDELTA 0x605

21.21.1.95 CSR_HTIMEDELTAH

#define CSR_HTIMEDELTAH 0x615

21.21.1.96 CSR_HTINST

#define CSR_HTINST 0x64a

21.21.1.97 CSR_HTVAL

#define CSR_HTVAL 0x643

21.21.1.98 CSR_INSTRET

#define CSR_INSTRET 0xc02

21.21.1.99 CSR_INSTRETH

#define CSR_INSTRETH 0xc82

21.21.1.100 CSR_MARCHID

#define CSR_MARCHID 0xf12

21.21.1.101 CSR_MCAUSE

#define CSR_MCAUSE 0x342

21.21.1.102 CSR_MCOUNTEREN

#define CSR_MCOUNTEREN 0x306

21.21.1.103 CSR_MCYCLE

#define CSR_MCYCLE 0xb00

21.21.1.104 CSR_MCYCLEH

#define CSR_MCYCLEH 0xb80

21.21.1.105 CSR_MEDELEG

#define CSR_MEDELEG 0x302

21.21.1.106 CSR_MEPC

#define CSR_MEPC 0x341

21.21.1.107 CSR_MHARTID

#define CSR_MHARTID 0xf14

21.21.1.108 CSR_MHPMCOUNTER10

#define CSR_MHPMCOUNTER10 0xb0a

21.21.1.109 CSR_MHPMCOUNTER10H

#define CSR_MHPMCOUNTER10H 0xb8a

21.21.1.110 CSR_MHPMCOUNTER11

#define CSR_MHPMCOUNTER11 0xb0b

21.21.1.111 CSR_MHPMCOUNTER11H

#define CSR_MHPMCOUNTER11H 0xb8b

21.21.1.112 CSR_MHPMCOUNTER12

#define CSR_MHPMCOUNTER12 0xb0c

21.21.1.113 CSR_MHPMCOUNTER12H

#define CSR_MHPMCOUNTER12H 0xb8c

21.21.1.114 CSR_MHPMCOUNTER13

#define CSR_MHPMCOUNTER13 0xb0d

21.21.1.115 CSR_MHPMCOUNTER13H

#define CSR_MHPMCOUNTER13H 0xb8d

21.21.1.116 CSR_MHPMCOUNTER14

#define CSR_MHPMCOUNTER14 0xb0e

21.21.1.117 CSR_MHPMCOUNTER14H

#define CSR_MHPMCOUNTER14H 0xb8e

21.21.1.118 CSR_MHPMCOUNTER15

#define CSR_MHPMCOUNTER15 0xb0f

21.21.1.119 CSR_MHPMCOUNTER15H

#define CSR_MHPMCOUNTER15H 0xb8f

21.21.1.120 CSR_MHPMCOUNTER16

#define CSR_MHPMCOUNTER16 0xb10

21.21.1.121 CSR_MHPMCOUNTER16H

#define CSR_MHPMCOUNTER16H 0xb90

21.21.1.122 CSR_MHPMCOUNTER17

#define CSR_MHPMCOUNTER17 0xb11

21.21.1.123 CSR_MHPMCOUNTER17H

#define CSR_MHPMCOUNTER17H 0xb91

21.21.1.124 CSR_MHPMCOUNTER18

#define CSR_MHPMCOUNTER18 0xb12

21.21.1.125 CSR_MHPMCOUNTER18H

#define CSR_MHPMCOUNTER18H 0xb92

21.21.1.126 CSR_MHPMCOUNTER19

#define CSR_MHPMCOUNTER19 0xb13

21.21.1.127 CSR_MHPMCOUNTER19H

#define CSR_MHPMCOUNTER19H 0xb93

21.21.1.128 CSR_MHPMCOUNTER20

#define CSR_MHPMCOUNTER20 0xb14

21.21.1.129 CSR_MHPMCOUNTER20H

#define CSR_MHPMCOUNTER20H 0xb94

21.21.1.130 CSR_MHPMCOUNTER21

#define CSR_MHPMCOUNTER21 0xb15

21.21.1.131 CSR_MHPMCOUNTER21H

#define CSR_MHPMCOUNTER21H 0xb95

21.21.1.132 CSR_MHPMCOUNTER22

#define CSR_MHPMCOUNTER22 0xb16

21.21.1.133 CSR_MHPMCOUNTER22H

#define CSR_MHPMCOUNTER22H 0xb96

21.21.1.134 CSR_MHPMCOUNTER23

#define CSR_MHPMCOUNTER23 0xb17

21.21.1.135 CSR_MHPMCOUNTER23H

#define CSR_MHPMCOUNTER23H 0xb97

21.21.1.136 CSR_MHPMCOUNTER24

#define CSR_MHPMCOUNTER24 0xb18

21.21.1.137 CSR_MHPMCOUNTER24H

#define CSR_MHPMCOUNTER24H 0xb98

21.21.1.138 CSR_MHPMCOUNTER25

#define CSR_MHPMCOUNTER25 0xb19

21.21.1.139 CSR_MHPMCOUNTER25H

#define CSR_MHPMCOUNTER25H 0xb99

21.21.1.140 CSR_MHPMCOUNTER26

#define CSR_MHPMCOUNTER26 0xb1a

21.21.1.141 CSR_MHPMCOUNTER26H

#define CSR_MHPMCOUNTER26H 0xb9a

21.21.1.142 CSR_MHPMCOUNTER27

#define CSR_MHPMCOUNTER27 0xb1b

21.21.1.143 CSR_MHPMCOUNTER27H

#define CSR_MHPMCOUNTER27H 0xb9b

21.21.1.144 CSR_MHPMCOUNTER28

#define CSR_MHPMCOUNTER28 0xb1c

21.21.1.145 CSR_MHPMCOUNTER28H

#define CSR_MHPMCOUNTER28H 0xb9c

21.21.1.146 CSR_MHPMCOUNTER29

#define CSR_MHPMCOUNTER29 0xb1d

21.21.1.147 CSR_MHPMCOUNTER29H

#define CSR_MHPMCOUNTER29H 0xb9d

21.21.1.148 CSR_MHPMCOUNTER3

#define CSR_MHPMCOUNTER3 0xb03

21.21.1.149 CSR_MHPMCOUNTER30

#define CSR_MHPMCOUNTER30 0xb1e

21.21.1.150 CSR_MHPMCOUNTER30H

#define CSR_MHPMCOUNTER30H 0xb9e

21.21.1.151 CSR_MHPMCOUNTER31

#define CSR_MHPMCOUNTER31 0xb1f

21.21.1.152 CSR_MHPMCOUNTER31H

#define CSR_MHPMCOUNTER31H 0xb9f

21.21.1.153 CSR_MHPMCOUNTER3H

#define CSR_MHPMCOUNTER3H 0xb83

21.21.1.154 CSR_MHPMCOUNTER4

#define CSR_MHPMCOUNTER4 0xb04

21.21.1.155 CSR_MHPMCOUNTER4H

#define CSR_MHPMCOUNTER4H 0xb84

21.21.1.156 CSR_MHPMCOUNTER5

#define CSR_MHPMCOUNTER5 0xb05

21.21.1.157 CSR_MHPMCOUNTER5H

#define CSR_MHPMCOUNTER5H 0xb85

21.21.1.158 CSR_MHPMCOUNTER6

#define CSR_MHPMCOUNTER6 0xb06

21.21.1.159 CSR_MHPMCOUNTER6H

#define CSR_MHPMCOUNTER6H 0xb86

21.21.1.160 CSR_MHPMCOUNTER7

#define CSR_MHPMCOUNTER7 0xb07

21.21.1.161 CSR_MHPMCOUNTER7H

#define CSR_MHPMCOUNTER7H 0xb87

21.21.1.162 CSR_MHPMCOUNTER8

#define CSR_MHPMCOUNTER8 0xb08

21.21.1.163 CSR_MHPMCOUNTER8H

#define CSR_MHPMCOUNTER8H 0xb88

21.21.1.164 CSR_MHPMCOUNTER9

#define CSR_MHPMCOUNTER9 0xb09

21.21.1.165 CSR_MHPMCOUNTER9H

#define CSR_MHPMCOUNTER9H 0xb89

21.21.1.166 CSR_MHPMEVENT10

#define CSR_MHPMEVENT10 0x32a

21.21.1.167 CSR_MHPMEVENT11

#define CSR_MHPMEVENT11 0x32b

21.21.1.168 CSR_MHPMEVENT12

#define CSR_MHPMEVENT12 0x32c

21.21.1.169 CSR_MHPMEVENT13

#define CSR_MHPMEVENT13 0x32d

21.21.1.170 CSR_MHPMEVENT14

#define CSR_MHPMEVENT14 0x32e

21.21.1.171 CSR_MHPMEVENT15

#define CSR_MHPMEVENT15 0x32f

21.21.1.172 CSR_MHPMEVENT16

#define CSR_MHPMEVENT16 0x330

21.21.1.173 CSR_MHPMEVENT17

#define CSR_MHPMEVENT17 0x331

21.21.1.174 CSR_MHPMEVENT18

#define CSR_MHPMEVENT18 0x332

21.21.1.175 CSR_MHPMEVENT19

#define CSR_MHPMEVENT19 0x333

21.21.1.176 CSR_MHPMEVENT20

#define CSR_MHPMEVENT20 0x334

21.21.1.177 CSR_MHPMEVENT21

#define CSR_MHPMEVENT21 0x335

21.21.1.178 CSR_MHPMEVENT22

#define CSR_MHPMEVENT22 0x336

21.21.1.179 CSR_MHPMEVENT23

#define CSR_MHPMEVENT23 0x337

21.21.1.180 CSR_MHPMEVENT24

#define CSR_MHPMEVENT24 0x338

21.21.1.181 CSR_MHPMEVENT25

#define CSR_MHPMEVENT25 0x339

21.21.1.182 CSR_MHPMEVENT26

#define CSR_MHPMEVENT26 0x33a

21.21.1.183 CSR_MHPMEVENT27

#define CSR_MHPMEVENT27 0x33b

21.21.1.184 CSR_MHPMEVENT28

#define CSR_MHPMEVENT28 0x33c

21.21.1.185 CSR_MHPMEVENT29

#define CSR_MHPMEVENT29 0x33d

21.21.1.186 CSR_MHPMEVENT3

#define CSR_MHPMEVENT3 0x323

21.21.1.187 CSR_MHPMEVENT30

#define CSR_MHPMEVENT30 0x33e

21.21.1.188 CSR_MHPMEVENT31

#define CSR_MHPMEVENT31 0x33f

21.21.1.189 CSR_MHPMEVENT4

#define CSR_MHPMEVENT4 0x324

21.21.1.190 CSR_MHPMEVENT5

#define CSR_MHPMEVENT5 0x325

21.21.1.191 CSR_MHPMEVENT6

#define CSR_MHPMEVENT6 0x326

21.21.1.192 CSR_MHPMEVENT7

#define CSR_MHPMEVENT7 0x327

21.21.1.193 CSR_MHPMEVENT8

#define CSR_MHPMEVENT8 0x328

21.21.1.194 CSR_MHPMEVENT9

#define CSR_MHPMEVENT9 0x329

21.21.1.195 CSR_MIDELEG

#define CSR_MIDELEG 0x303

21.21.1.196 CSR_MIE

#define CSR_MIE 0x304

21.21.1.197 CSR_MIMPID

#define CSR_MIMPID 0xf13

21.21.1.198 CSR_MINSTRET

#define CSR_MINSTRET 0xb02

21.21.1.199 CSR_MINSTRETH

#define CSR_MINSTRETH 0xb82

21.21.1.200 CSR_MIP

#define CSR_MIP 0x344

21.21.1.201 CSR_MISA

#define CSR_MISA 0x301

21.21.1.202 CSR_MSCRATCH

#define CSR_MSCRATCH 0x340

21.21.1.203 CSR_MSTATUS

#define CSR_MSTATUS 0x300

21.21.1.204 CSR_MSTATUSH

#define CSR_MSTATUSH 0x310

21.21.1.205 CSR_MTINST

#define CSR_MTINST 0x34a

21.21.1.206 CSR_MTVAL

#define CSR_MTVAL 0x343

21.21.1.207 CSR_MTVAL2

#define CSR_MTVAL2 0x34b

21.21.1.208 CSR_MTVEC

#define CSR_MTVEC 0x305

21.21.1.209 CSR_MVENDORID

#define CSR_MVENDORID 0xf11

21.21.1.210 CSR_PMPADDR0

#define CSR_PMPADDR0 0x3b0

21.21.1.211 CSR_PMPADDR1

#define CSR_PMPADDR1 0x3b1

21.21.1.212 CSR_PMPADDR10

#define CSR_PMPADDR10 0x3ba

21.21.1.213 CSR_PMPADDR11

#define CSR_PMPADDR11 0x3bb

21.21.1.214 CSR_PMPADDR12

#define CSR_PMPADDR12 0x3bc

21.21.1.215 CSR_PMPADDR13

#define CSR_PMPADDR13 0x3bd

21.21.1.216 CSR_PMPADDR14

#define CSR_PMPADDR14 0x3be

21.21.1.217 CSR_PMPADDR15

#define CSR_PMPADDR15 0x3bf

21.21.1.218 CSR_PMPADDR2

#define CSR_PMPADDR2 0x3b2

21.21.1.219 CSR_PMPADDR3

#define CSR_PMPADDR3 0x3b3

21.21.1.220 CSR_PMPADDR4

#define CSR_PMPADDR4 0x3b4

21.21.1.221 CSR_PMPADDR5

#define CSR_PMPADDR5 0x3b5

21.21.1.222 CSR_PMPADDR6

#define CSR_PMPADDR6 0x3b6

21.21.1.223 CSR_PMPADDR7

#define CSR_PMPADDR7 0x3b7

21.21.1.224 CSR_PMPADDR8

#define CSR_PMPADDR8 0x3b8

21.21.1.225 CSR_PMPADDR9

#define CSR_PMPADDR9 0x3b9

21.21.1.226 CSR_PMPCFG0

#define CSR_PMPCFG0 0x3a0

21.21.1.227 CSR_PMPCFG1

#define CSR_PMPCFG1 0x3a1

21.21.1.228 CSR_PMPCFG2

#define CSR_PMPCFG2 0x3a2

21.21.1.229 CSR_PMPCFG3

#define CSR_PMPCFG3 0x3a3

21.21.1.230 CSR_SATP

#define CSR_SATP 0x180

21.21.1.231 CSR_SCAUSE

#define CSR_SCAUSE 0x142

21.21.1.232 CSR_SCOUNTEREN

#define CSR_SCOUNTEREN 0x106

21.21.1.233 CSR_SEPC

#define CSR_SEPC 0x141

21.21.1.234 CSR_SIE

#define CSR_SIE 0x104

21.21.1.235 CSR_SIP

#define CSR_SIP 0x144

21.21.1.236 CSR_SSCRATCH

#define CSR_SSCRATCH 0x140

21.21.1.237 CSR_SSTATUS

#define CSR_SSTATUS 0x100

21.21.1.238 CSR_STVAL

#define CSR_STVAL 0x143

21.21.1.239 CSR_STVEC

#define CSR_STVEC 0x105

21.21.1.240 CSR_TDATA1

#define CSR_TDATA1 0x7a1

21.21.1.241 CSR_TDATA2

#define CSR_TDATA2 0x7a2

21.21.1.242 CSR_TDATA3

#define CSR_TDATA3 0x7a3

21.21.1.243 CSR_TIME

#define CSR_TIME 0xc01

21.21.1.244 CSR_TIMEH

#define CSR_TIMEH 0xc81

21.21.1.245 CSR_TSELECT

#define CSR_TSELECT 0x7a0

21.21.1.246 CSR_UCAUSE

#define CSR_UCAUSE 0x42

21.21.1.247 CSR_UEPC

#define CSR_UEPC 0x41

21.21.1.248 CSR_UIE

#define CSR_UIE 0x4

21.21.1.249 CSR_UIP

#define CSR_UIP 0x44

21.21.1.250 CSR_USCRATCH

#define CSR_USCRATCH 0x40

21.21.1.251 CSR_USTATUS

#define CSR_USTATUS 0x0

21.21.1.252 CSR_UTVAL

#define CSR_UTVAL 0x43

21.21.1.253 CSR_UTVEC

#define CSR_UTVEC 0x5

21.21.1.254 CSR_VSATP

#define CSR_VSATP 0x280

21.21.1.255 CSR_VSCAUSE

#define CSR_VSCAUSE 0x242

21.21.1.256 CSR_VSEPC

#define CSR_VSEPC 0x241

21.21.1.257 CSR_VSIE

#define CSR_VSIE 0x204

21.21.1.258 CSR_VSIP

#define CSR_VSIP 0x244

21.21.1.259 CSR_VSSCRATCH

```
#define CSR_VSSCRATCH 0x240
```

21.21.1.260 CSR_VSSTATUS

```
#define CSR_VSSTATUS 0x200
```

21.21.1.261 CSR_VSTVAL

```
#define CSR_VSTVAL 0x243
```

21.21.1.262 CSR_VSTVEC

```
#define CSR_VSTVEC 0x205
```

21.21.1.263 GET_RM

```
#define GET_RM( insn \ ) \ (((insn) \ >> \ 12) \ \& \ 7)
```

21.21.1.264 GET_RS1

21.21.1.265 GET_RS1S

```
21.21.1.266 GET_RS2
```

```
#define GET_RS2(
             insn,
             regs ) (*REG_PTR(insn, SH_RS2, regs))
21.21.1.267 GET_RS2C
#define GET_RS2C(
             insn,
             regs ) (*REG_PTR(insn, SH_RS2C, regs))
21.21.1.268 GET_RS2S
#define GET_RS2S(
              regs ) (*REG_PTR(RVC_RS2S(insn), 0, regs))
21.21.1.269 GET_SP
#define GET_SP(
             regs ) (*REG_PTR(2, 0, regs))
21.21.1.270 HSTATUS_SP2P
#define HSTATUS_SP2P _UL(0x00000100)
21.21.1.271 HSTATUS_SP2V
#define HSTATUS_SP2V _UL(0x00000200)
```

21.21.1.272 HSTATUS_SPRV

#define $HSTATUS_SPRV_UL(0x00000001)$

```
21.21.1.273 HSTATUS_SPV
```

```
#define HSTATUS_SPV _UL(0x00000080)
```

21.21.1.274 HSTATUS_VTSR

```
#define HSTATUS_VTSR _UL(0x00400000)
```

21.21.1.275 HSTATUS_VTVM

```
#define HSTATUS_VTVM _UL(0x00100000)
```

21.21.1.276 IMM_I

21.21.1.277 IMM_S

```
\begin{tabular}{ll} \# define & IMM\_S ( & \\ & insn \end{tabular} ) \\
```

Value:

21.21.1.278 INSN_16BIT_MASK

```
#define INSN_16BIT_MASK 0x3
```

21.21.1.279 INSN_32BIT_MASK

```
#define INSN_32BIT_MASK 0x1c
```

21.21.1.280 INSN_IS_16BIT

21.21.1.281 INSN_IS_32BIT

Value:

21.21.1.282 INSN_LEN

21.21.1.283 INSN_MASK_C_FLD

#define INSN_MASK_C_FLD 0xe003

21.21.1.284 INSN_MASK_C_FLDSP

#define INSN_MASK_C_FLDSP 0xe003

21.21.1.285 INSN_MASK_C_FLW

#define INSN_MASK_C_FLW 0xe003

21.21.1.286 INSN_MASK_C_FLWSP

#define INSN_MASK_C_FLWSP 0xe003

21.21.1.287 INSN_MASK_C_FSD

#define INSN_MASK_C_FSD 0xe003

21.21.1.288 INSN_MASK_C_FSDSP

#define INSN_MASK_C_FSDSP 0xe003

21.21.1.289 INSN_MASK_C_FSW

#define INSN_MASK_C_FSW 0xe003

21.21.1.290 INSN_MASK_C_FSWSP

#define INSN_MASK_C_FSWSP 0xe003

21.21.1.291 INSN_MASK_C_LD

#define INSN_MASK_C_LD 0xe003

21.21.1.292 INSN_MASK_C_LDSP

#define INSN_MASK_C_LDSP 0xe003

21.21.1.293 INSN_MASK_C_LW

#define INSN_MASK_C_LW 0xe003

21.21.1.294 INSN_MASK_C_LWSP

#define INSN_MASK_C_LWSP 0xe003

21.21.1.295 INSN_MASK_C_SD

#define INSN_MASK_C_SD 0xe003

21.21.1.296 INSN_MASK_C_SDSP

#define INSN_MASK_C_SDSP 0xe003

21.21.1.297 INSN_MASK_C_SW

#define INSN_MASK_C_SW 0xe003

21.21.1.298 INSN_MASK_C_SWSP

#define INSN_MASK_C_SWSP 0xe003

21.21.1.299 INSN_MASK_FLD

#define INSN_MASK_FLD 0x707f

21.21.1.300 INSN_MASK_FLQ

#define INSN_MASK_FLQ 0x707f

21.21.1.301 INSN_MASK_FLW

#define INSN_MASK_FLW 0x707f

21.21.1.302 INSN_MASK_FSD

#define INSN_MASK_FSD 0x707f

21.21.1.303 INSN_MASK_FSQ

#define INSN_MASK_FSQ 0x707f

21.21.1.304 INSN_MASK_FSW

#define INSN_MASK_FSW 0x707f

21.21.1.305 INSN_MASK_LB

#define INSN_MASK_LB 0x707f

21.21.1.306 INSN_MASK_LBU

#define INSN_MASK_LBU 0x707f

21.21.1.307 INSN_MASK_LD

#define INSN_MASK_LD 0x707f

21.21.1.308 INSN_MASK_LH

#define INSN_MASK_LH 0x707f

21.21.1.309 INSN_MASK_LHU

#define INSN_MASK_LHU 0x707f

21.21.1.310 INSN_MASK_LW

#define INSN_MASK_LW 0x707f

21.21.1.311 INSN_MASK_LWU

#define INSN_MASK_LWU 0x707f

21.21.1.312 INSN_MASK_SB

#define INSN_MASK_SB 0x707f

21.21.1.313 INSN_MASK_SD

#define INSN_MASK_SD 0x707f

21.21.1.314 INSN_MASK_SH

#define INSN_MASK_SH 0x707f

21.21.1.315 INSN_MASK_SW

#define INSN_MASK_SW 0x707f

21.21.1.316 INSN_MASK_WFI

#define INSN_MASK_WFI 0xffffff00

21.21.1.317 INSN_MATCH_C_FLD

#define INSN_MATCH_C_FLD 0x2000

21.21.1.318 INSN_MATCH_C_FLDSP

#define INSN_MATCH_C_FLDSP 0x2002

21.21.1.319 INSN_MATCH_C_FLW

#define INSN_MATCH_C_FLW 0x6000

21.21.1.320 INSN_MATCH_C_FLWSP

#define INSN_MATCH_C_FLWSP 0x6002

21.21.1.321 INSN_MATCH_C_FSD

#define INSN_MATCH_C_FSD 0xa000

21.21.1.322 INSN_MATCH_C_FSDSP

#define INSN_MATCH_C_FSDSP 0xa002

21.21.1.323 INSN_MATCH_C_FSW

#define INSN_MATCH_C_FSW 0xe000

21.21.1.324 INSN_MATCH_C_FSWSP

#define INSN_MATCH_C_FSWSP 0xe002

21.21.1.325 INSN_MATCH_C_LD

#define INSN_MATCH_C_LD 0x6000

21.21.1.326 INSN_MATCH_C_LDSP

#define INSN_MATCH_C_LDSP 0x6002

21.21.1.327 INSN_MATCH_C_LW

#define INSN_MATCH_C_LW 0x4000

21.21.1.328 INSN_MATCH_C_LWSP

#define INSN_MATCH_C_LWSP 0x4002

21.21.1.329 INSN_MATCH_C_SD

#define INSN_MATCH_C_SD 0xe000

21.21.1.330 INSN_MATCH_C_SDSP

#define INSN_MATCH_C_SDSP 0xe002

21.21.1.331 INSN_MATCH_C_SW

#define INSN_MATCH_C_SW 0xc000

21.21.1.332 INSN_MATCH_C_SWSP

#define INSN_MATCH_C_SWSP 0xc002

21.21.1.333 INSN_MATCH_FLD

#define INSN_MATCH_FLD 0x3007

21.21.1.334 INSN_MATCH_FLQ

#define INSN_MATCH_FLQ 0x4007

21.21.1.335 INSN_MATCH_FLW

#define INSN_MATCH_FLW 0x2007

21.21.1.336 INSN_MATCH_FSD

#define INSN_MATCH_FSD 0x3027

21.21.1.337 INSN_MATCH_FSQ

#define INSN_MATCH_FSQ 0x4027

21.21.1.338 INSN_MATCH_FSW

#define INSN_MATCH_FSW 0x2027

21.21.1.339 INSN_MATCH_LB

#define INSN_MATCH_LB 0x3

21.21.1.340 INSN_MATCH_LBU

#define INSN_MATCH_LBU 0x4003

21.21.1.341 INSN_MATCH_LD

#define INSN_MATCH_LD 0x3003

21.21.1.342 INSN_MATCH_LH

#define INSN_MATCH_LH 0x1003

21.21.1.343 INSN_MATCH_LHU

#define INSN_MATCH_LHU 0x5003

21.21.1.344 INSN_MATCH_LW

#define INSN_MATCH_LW 0x2003

21.21.1.345 INSN_MATCH_LWU

#define INSN_MATCH_LWU 0x6003

21.21.1.346 INSN_MATCH_SB

#define INSN_MATCH_SB 0x23

21.21.1.347 INSN_MATCH_SD

#define INSN_MATCH_SD 0x3023

21.21.1.348 INSN_MATCH_SH

#define INSN_MATCH_SH 0x1023

21.21.1.349 INSN_MATCH_SW

#define INSN_MATCH_SW 0x2023

21.21.1.350 INSN_MATCH_WFI

#define INSN_MATCH_WFI 0x10500000

21.21.1.351 IRQ_M_EXT

#define IRQ_M_EXT 11

21.21.1.352 IRQ_M_SOFT

#define IRQ_M_SOFT 3

21.21.1.353 IRQ_M_TIMER

#define IRQ_M_TIMER 7

21.21.1.354 IRQ_S_EXT

#define IRQ_S_EXT 9

21.21.1.355 IRQ_S_GEXT

#define IRQ_S_GEXT 12

21.21.1.356 IRQ_S_SOFT

#define IRQ_S_SOFT 1

21.21.1.357 IRQ_S_TIMER

#define IRQ_S_TIMER 5

21.21.1.358 IRQ_VS_EXT #define IRQ_VS_EXT 10 21.21.1.359 IRQ_VS_SOFT #define IRQ_VS_SOFT 2 21.21.1.360 IRQ_VS_TIMER #define IRQ_VS_TIMER 6 21.21.1.361 LOG_REGBYTES #define LOG_REGBYTES 2 21.21.1.362 MASK_FUNCT3 #define MASK_FUNCT3 0x7000 21.21.1.363 MIP_MEIP #define MIP_MEIP (_UL(1) << IRQ_M_EXT)</pre> 21.21.1.364 MIP_MSIP #define MIP_MSIP (_UL(1) << IRQ_M_SOFT)</pre>

21.21.1.365 MIP_MTIP

#define MIP_MTIP (_UL(1) << IRQ_M_TIMER)</pre>

```
21.21.1.366 MIP_SEIP
#define MIP_SEIP (_UL(1) << IRQ_S_EXT)</pre>
21.21.1.367 MIP_SGEIP
\label{eq:continuous} \mbox{\#define MIP\_SGEIP (\_UL(1) << IRQ\_S\_GEXT)}
21.21.1.368 MIP_SSIP
#define MIP_SSIP (_UL(1) << IRQ_S_SOFT)</pre>
21.21.1.369 MIP_STIP
#define MIP_STIP (_UL(1) << IRQ_S_TIMER)</pre>
21.21.1.370 MIP_VSEIP
\label{eq:continuous} \mbox{\#define MIP\_VSEIP (\_UL\,(1) << IRQ\_VS\_EXT)}
21.21.1.371 MIP_VSSIP
#define MIP_VSSIP (_UL(1) << IRQ_VS_SOFT)</pre>
21.21.1.372 MIP_VSTIP
#define MIP_VSTIP (_UL(1) << IRQ_VS_TIMER)</pre>
21.21.1.373 MSTATUS32_SD [1/2]
#define MSTATUS32_SD _UL(0x80000000)
```

```
21.21.1.374 MSTATUS32_SD [2/2]
#define MSTATUS32_SD _UL(0x80000000)
21.21.1.375 MSTATUS64_SD
#define MSTATUS64_SD _ULL(0x8000000000000000)
21.21.1.376 MSTATUS_FS
#define MSTATUS_FS _UL(0x00006000)
21.21.1.377 MSTATUS_MIE
#define MSTATUS_MIE _UL(0x00000008)
21.21.1.378 MSTATUS_MPIE
#define MSTATUS_MPIE _UL(0x00000080)
21.21.1.379 MSTATUS_MPP
#define MSTATUS_MPP (_UL(3) << MSTATUS_MPP_SHIFT)</pre>
21.21.1.380 MSTATUS_MPP_SHIFT
#define MSTATUS_MPP_SHIFT 11
21.21.1.381 MSTATUS_MPRV
```

#define MSTATUS_MPRV _UL(0x00020000)

21.21.1.382 MSTATUS_MXR

#define MSTATUS_MXR _UL(0x00080000)

21.21.1.383 MSTATUS_SD

#define MSTATUS_SD MSTATUS32_SD

21.21.1.384 MSTATUS_SIE

#define MSTATUS_SIE _UL(0x00000002)

21.21.1.385 MSTATUS_SPIE

#define MSTATUS_SPIE (_UL(1) << MSTATUS_SPIE_SHIFT)</pre>

21.21.1.386 MSTATUS_SPIE_SHIFT

#define MSTATUS_SPIE_SHIFT 5

21.21.1.387 MSTATUS_SPP

#define MSTATUS_SPP (_UL(1) << MSTATUS_SPP_SHIFT)</pre>

21.21.1.388 MSTATUS_SPP_SHIFT

#define MSTATUS_SPP_SHIFT 8

21.21.1.389 MSTATUS_SUM

#define MSTATUS_SUM _UL(0x00040000)

21.21.1.390 MSTATUS_TSR

```
#define MSTATUS_TSR _UL(0x00400000)
```

21.21.1.391 MSTATUS_TVM

```
#define MSTATUS_TVM _UL(0x00100000)
```

21.21.1.392 MSTATUS_TW

```
#define MSTATUS_TW _UL(0x00200000)
```

21.21.1.393 MSTATUS_UBE

```
#define MSTATUS_UBE _UL(0x00000040)
```

21.21.1.394 MSTATUS_XS

#define MSTATUS_XS _UL(0x00018000)

21.21.1.395 MSTATUSH_MBE

#define MSTATUSH_MBE _UL(0x00000020)

21.21.1.396 MSTATUSH_MPV

#define MSTATUSH_MPV _UL(0x00000080)

21.21.1.397 MSTATUSH_SBE

#define MSTATUSH_SBE _UL(0x00000010)

21.21.1.398 PMP_A

```
#define PMP_A _UL(0x18)
```

21.21.1.399 PMP_A_NA4

```
#define PMP_A_NA4 _UL(0x10)
```

21.21.1.400 PMP_A_NAPOT

```
#define PMP_A_NAPOT _UL(0x18)
```

21.21.1.401 PMP_A_TOR

```
#define PMP_A_TOR _UL(0x08)
```

21.21.1.402 PMP_COUNT

#define PMP_COUNT 16

21.21.1.403 PMP_L

#define PMP_L _UL(0x80)

21.21.1.404 PMP_R

#define PMP_R _UL(0x01)

21.21.1.405 PMP_SHIFT

#define PMP_SHIFT 2

```
21.21.1.406 PMP_W
#define PMP_W _UL(0x02)
21.21.1.407 PMP_X
#define PMP_X _UL(0x04)
21.21.1.408 PRV_M
#define PRV_M _UL(3)
21.21.1.409 PRV_S
#define PRV_S _UL(1)
21.21.1.410 PRV_U
#define PRV_U _UL(0)
21.21.1.411 PTE_A
#define PTE_A _UL(0x040) /* Accessed */
21.21.1.412 PTE_D
\#define PTE_D \_UL(0x080) /* Dirty */
21.21.1.413 PTE_G
#define PTE_G \_UL(0x020) /* Global */
```

21.21.1.414 PTE_PPN_SHIFT

```
#define PTE_PPN_SHIFT 10
```

21.21.1.415 PTE_R

```
\#define PTE_R \_UL(0x002) /* Read */
```

21.21.1.416 PTE_SOFT

```
#define PTE_SOFT \_UL(0x300) /* Reserved for Software */
```

21.21.1.417 PTE_TABLE

```
#define PTE_TABLE(  PTE \ ) \ (((PTE) \ \& \ (PTE_V \ | \ PTE_R \ | \ PTE_W \ | \ PTE_X)) \ == \ PTE_V)
```

21.21.1.418 PTE_U

```
#define PTE_U _UL(0x010) /* User */
```

21.21.1.419 PTE_V

```
\#define PTE_V \_UL(0x001) /* Valid */
```

21.21.1.420 PTE_W

```
#define PTE_W _UL(0x004) /* Write */
```

```
21.21.1.421 PTE_X
```

```
#define PTE_X \_UL(0x008) /* Execute */
```

21.21.1.422 REG_MASK

```
\#define\ REG\_MASK\ ((1 << (5 + LOG\_REGBYTES)) - (1 << LOG\_REGBYTES))
```

21.21.1.423 REG_OFFSET

21.21.1.424 REG_PTR

21.21.1.425 REGBYTES

```
#define REGBYTES (1 << LOG_REGBYTES)</pre>
```

21.21.1.426 RISCV_PGLEVEL_BITS

```
#define RISCV_PGLEVEL_BITS 10
```

21.21.1.427 RISCV_PGSHIFT

```
#define RISCV_PGSHIFT 12
```

```
21.21.1.428 RISCV_PGSIZE
```

```
#define RISCV_PGSIZE (1 << RISCV_PGSHIFT)</pre>
```

21.21.1.429 RV_X

21.21.1.430 RVC_LD_IMM

Value:

```
((RV_X(x, 10, 3) << 3) | \
(RV_X(x, 5, 2) << 6))
```

21.21.1.431 RVC_LDSP_IMM

```
#define RVC_LDSP_IMM( x )
```

Value:

21.21.1.432 RVC_LW_IMM

```
#define RVC_LW_IMM( x )
```

Value:

21.21.1.433 RVC_LWSP_IMM

```
#define RVC_LWSP_IMM( x )
```

Value:

21.21.1.434 RVC_RS1S

21.21.1.435 RVC_RS2

21.21.1.436 RVC_RS2S

21.21.1.437 RVC_SDSP_IMM

```
#define RVC_SDSP_IMM( x )
```

Value:

```
((RV_X(x, 10, 3) << 3) | \
(RV_X(x, 7, 3) << 6))
```

21.21.1.438 RVC_SWSP_IMM

```
\begin{tabular}{ll} \# define & RVC\_SWSP\_IMM ( & & & \\ & & x & ) \end{tabular}
```

Value:

```
((RV_X(x, 9, 4) << 2) | \
(RV_X(x, 7, 2) << 6))
```

21.21.1.439 SATP32_ASID

```
#define SATP32_ASID _UL(0x7FC00000)
```

21.21.1.440 SATP32_MODE

```
#define SATP32_MODE _UL(0x80000000)
```

21.21.1.441 SATP32_PPN

```
#define SATP32_PPN _UL(0x003FFFFF)
```

21.21.1.442 SATP64_ASID

```
#define SATP64_ASID _ULL(0x0FFFF00000000000)
```

21.21.1.443 SATP64_MODE

```
#define SATP64_MODE _ULL(0xF000000000000000)
```

21.21.1.444 SATP64_PPN

```
#define SATP64_PPN _ULL(0x00000FFFFFFFFFF)
```

21.21.1.445 SATP_MODE

```
#define SATP_MODE SATP32_MODE
```

21.21.1.446 SATP_MODE_OFF

```
#define SATP_MODE_OFF _UL(0)
```

21.21.1.447 SATP_MODE_SV32

```
#define SATP_MODE_SV32 _UL(1)
```

21.21.1.448 SATP_MODE_SV39

```
#define SATP_MODE_SV39 _UL(8)
```

21.21.1.449 SATP_MODE_SV48

```
#define SATP_MODE_SV48 _UL(9)
```

21.21.1.450 SATP_MODE_SV57

#define SATP_MODE_SV57 _UL(10)

21.21.1.451 SATP_MODE_SV64

#define SATP_MODE_SV64 _UL(11)

21.21.1.452 SET_RD

21.21.1.453 SH_RD

#define SH_RD 7

21.21.1.454 SH_RS1

#define SH_RS1 15

21.21.1.455 SH_RS2

#define SH_RS2 20

21.21.1.456 SH_RS2C

#define SH_RS2C 2

21.21.1.457 SHIFT_RIGHT

21.21.1.458 SIP_SSIP

#define SIP_SSIP MIP_SSIP

21.21.1.459 SIP_STIP

#define SIP_STIP MIP_STIP

21.21.1.460 SSTATUS32_SD

#define SSTATUS32_SD MSTATUS32_SD

21.21.1.461 SSTATUS64_SD

#define SSTATUS64_SD MSTATUS64_SD

21.21.1.462 SSTATUS64_UXL

#define SSTATUS64_UXL MSTATUS_UXL

21.21.1.463 SSTATUS_FS

#define SSTATUS_FS MSTATUS_FS

21.21.1.464 SSTATUS_MXR

#define SSTATUS_MXR MSTATUS_MXR

21.21.1.465 SSTATUS_SD

#define SSTATUS_SD SSTATUS32_SD

21.21.1.466 SSTATUS_SIE

#define SSTATUS_SIE MSTATUS_SIE

21.21.1.467 SSTATUS_SPIE

#define SSTATUS_SPIE MSTATUS_SPIE

21.21.1.468 SSTATUS_SPIE_SHIFT

#define SSTATUS_SPIE_SHIFT MSTATUS_SPIE_SHIFT

21.21.1.469 SSTATUS_SPP

#define SSTATUS_SPP MSTATUS_SPP

21.21.1.470 SSTATUS_SPP_SHIFT

#define SSTATUS_SPP_SHIFT MSTATUS_SPP_SHIFT

21.21.1.471 SSTATUS_SUM


#define SSTATUS_SUM MSTATUS_SUM

21.21.1.472 SSTATUS_XS


#define SSTATUS_XS MSTATUS_XS

21.22 include/sbi/riscv_fp.h File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_encoding.h>
#include <sbi/sbi_types.h>
Include dependency graph for riscv_fp.h:
```



This graph shows which files directly or indirectly include this file:



Macros

- #define GET_PRECISION(insn) (((insn) >> 25) & 3)
- #define GET_RM(insn) (((insn) >> 12) & 7)
- #define PRECISION_S 0
- #define PRECISION_D 1

21.22.1 Macro Definition Documentation

21.22.1.1 GET_PRECISION

```
#define GET_PRECISION( insn \ ) \ (((insn) \ >> \ 25) \ \& \ 3)
```

21.22.1.2 GET_RM

```
#define GET_RM( insn \ ) \ (((insn) \ >> \ 12) \ \& \ 7)
```

21.22.1.3 PRECISION_D


#define PRECISION_D 1

21.22.1.4 PRECISION_S


#define PRECISION_S 0

21.23 include/sbi/riscv_io.h File Reference

```
#include <sbi/riscv_barrier.h>
#include <sbi/sbi_types.h>
Include dependency graph for riscv_io.h:
```



This graph shows which files directly or indirectly include this file:



Macros

```
#define io rbr() do {} while (0)
#define __io_rar() do {} while (0)

    #define __io_rbw() do {} while (0)

#define __io_raw() do {} while (0)

    #define readb_relaxed(c) ({ u8 __v; __io_rbr(); __v = __raw_readb(c); __io_rar(); __v; })

    #define readw_relaxed(c) ({ u16 __v; __io_rbr(); __v = __raw_readw(c); __io_rar(); __v; })

    #define readl_relaxed(c) ({ u32 __v; __io_rbr(); __v = __raw_readl(c); __io_rar(); __v; })

    #define writeb relaxed(v, c) ({ io rbw(); raw writeb((v),(c)); io raw(); })

    #define writew relaxed(v, c) ({ io rbw(); raw writew((v),(c)); io raw(); })

#define writel_relaxed(v, c) ({ __io_rbw(); __raw_writel((v),(c)); __io_raw(); })

    #define readq_relaxed(c) ({ u64 __v; __io_rbr(); __v = __raw_readq(c); __io_rar(); __v; })

#define writeq_relaxed(v, c) ({ __io_rbw(); __raw_writeq((v),(c)); __io_raw(); })
• #define io br() do {} while (0)
#define __io_ar() __asm__ _volatile__ ("fence i,r" : : : "memory");
#define __io_bw() __asm__ _volatile__ ("fence w,o" : : : "memory");
#define io aw() do {} while (0)

    #define readb(c) ({ u8 __v; __io_br(); __v = __raw_readb(c); __io_ar(); __v; })

    #define readw(c) ({ u16 __v; __io_br(); __v = __raw_readw(c); __io_ar(); __v; })

    #define readl(c) ({ u32 __v; __io_br(); __v = __raw_readl(c); __io_ar(); __v; })

    #define writeb(v, c) ({ __io_bw(); __raw_writeb((v),(c)); __io_aw(); })

    #define writew(v, c) ({ __io_bw(); __raw_writew((v),(c)); __io_aw(); })

    #define writel(v, c) ({ __io_bw(); __raw_writel((v),(c)); __io_aw(); })

    #define readq(c) ({ u64 __v; __io_br(); __v = __raw_readq(c); __io_ar(); __v; })

#define writeg(v, c) ({ io bw(); raw writeg((v),(c)); io aw(); })
```

Functions

```
static void __raw_writeb (u8 val, volatile void *addr)
static void __raw_writew (u16 val, volatile void *addr)
static void __raw_writel (u32 val, volatile void *addr)
static void __raw_writeq (u64 val, volatile void *addr)
static u8 __raw_readb (const volatile void *addr)
static u16 __raw_readw (const volatile void *addr)
static u32 __raw_readl (const volatile void *addr)
static u64 __raw_readq (const volatile void *addr)
```

21.23.1 Macro Definition Documentation

```
21.23.1.1 __io_ar
#define __io_ar() __asm__ _volatile__ ("fence i,r" : : "memory");
21.23.1.2 __io_aw
#define __io_aw( ) do {} while (0)
21.23.1.3 __io_br
#define ___io_br() do {} while (0)
21.23.1.4 __io_bw
#define __io_bw() __asm__ _volatile__ ("fence w,o" : : : "memory");
21.23.1.5 __io_rar
#define __io_rar( ) do {} while (0)
21.23.1.6 __io_raw
#define __io_raw() do {} while (0)
21.23.1.7 __io_rbr
#define __io_rbr() do {} while (0)
```

```
21.23.1.8 __io_rbw
#define __io_rbw() do {} while (0)
21.23.1.9 readb
#define readb(
            c) ({ u8 __v; __io_br(); __v = __raw_readb(c); __io_ar(); __v; })
21.23.1.10 readb_relaxed
#define readb_relaxed(
             c ) ({ u8 __v; __io_rbr(); __v = __raw_readb(c); __io_rar(); __v; })
21.23.1.11 readl
#define readl(
             c ) ({ u32 __v; __io_br(); __v = __raw_readl(c); __io_ar(); __v; })
21.23.1.12 readl_relaxed
#define readl_relaxed(
              c ) ({ u32 __v; __io_rbr(); __v = __raw_readl(c); __io_rar(); __v; })
21.23.1.13 readq
#define readq(
             c ) ({ u64 __v; __io_br(); __v = __raw_readq(c); __io_ar(); __v; })
21.23.1.14 readq_relaxed
#define readq_relaxed(
             c ) ({ u64 __v; __io_rbr(); __v = __raw_readq(c); __io_rar(); __v; })
```

```
21.23.1.15 readw
```

21.23.1.18 writeb_relaxed

21.23.1.19 writel

21.23.1.20 writel_relaxed

```
21.23.1.21 writeq
```

```
#define writeq(
              c ) ({ __io_bw(); __raw_writeq((v),(c)); __io_aw(); })
21.23.1.22 writeq_relaxed
#define writeq_relaxed(
              c ) ({ __io_rbw(); __raw_writeq((v),(c)); __io_raw(); })
21.23.1.23 writew
#define writew(
              c ) ({ __io_bw(); __raw_writew((v),(c)); __io_aw(); })
21.23.1.24 writew_relaxed
#define writew_relaxed(
              c ) ({ __io_rbw(); __raw_writew((v),(c)); __io_raw(); })
21.23.2 Function Documentation
21.23.2.1 __raw_readb()
```

```
static u32 \_raw\_readl ( const volatile void * addr ) [inline], [static]
```

const volatile void * addr) [inline], [static]


static u8 __raw_readb (

21.23.2.2 __raw_readl()

```
21.23.2.3 __raw_readq()
static u64 ___raw_readq (
             const volatile void * addr ) [inline], [static]
21.23.2.4 __raw_readw()
static u16 ___raw_readw (
              const volatile void * addr ) [inline], [static]
21.23.2.5 __raw_writeb()
static void ___raw_writeb (
              u8 val,
              volatile void * addr ) [inline], [static]
21.23.2.6 __raw_writel()
static void ___raw_writel (
              u32 val,
              volatile void * addr ) [inline], [static]
21.23.2.7 __raw_writeq()
static void __raw_writeq (
               volatile void * addr ) [inline], [static]
21.23.2.8 __raw_writew()
static void ___raw_writew (
               \  \  \, \text{volatile void} \, * \, \textit{addr} \, \, ) \quad [\text{inline}] \, , \, \, [\text{static}] \, \,
```

21.24 include/sbi/riscv_locks.h File Reference

This graph shows which files directly or indirectly include this file:



Data Structures

struct spinlock_t

Macros

- #define __RISCV_SPIN_UNLOCKED 0
- #define SPIN_LOCK_INIT(_lptr) (_lptr)->lock = __RISCV_SPIN_UNLOCKED
- #define SPIN_LOCK_INITIALIZER

Functions

- int spin_lock_check (spinlock_t *lock)
- int spin_trylock (spinlock_t *lock)
- void spin_lock (spinlock_t *lock)
- void spin_unlock (spinlock_t *lock)

21.24.1 Macro Definition Documentation

21.24.1.1 __RISCV_SPIN_UNLOCKED

```
#define ___RISCV_SPIN_UNLOCKED 0
```

21.24.1.2 SPIN_LOCK_INIT

21.24.1.3 SPIN_LOCK_INITIALIZER

```
#define SPIN_LOCK_INITIALIZER
```


Value:

```
.lock = __RISCV_SPIN_UNLOCKED, \
```


21.24.2 Function Documentation

21.24.2.1 spin_lock()

Here is the call graph for this function:




Here is the caller graph for this function:




21.24.2.2 spin_lock_check()

Here is the caller graph for this function:




21.24.2.3 spin_trylock()

Here is the caller graph for this function:



21.24.2.4 spin_unlock()


Here is the caller graph for this function:




21.25 include/sbi/sbi_bitops.h File Reference

#include <sbi/sbi_bits.h>
#include <sbi/riscv_asm.h>

Include dependency graph for sbi_bitops.h:



This graph shows which files directly or indirectly include this file:



Macros

• #define ffz(x) $__{ffs}(\sim(x))$

Functions

- static int ffs (int x)
- static int __ffs (unsigned long word)
- static int fls (int x)
- static unsigned long __fls (unsigned long word)

21.25.1 Macro Definition Documentation

21.25.1.1 ffz

```
#define ffz( x ) __ffs(\sim(x))
```

21.25.2 Function Documentation

```
21.25.2.1 __ffs()
```

```
static int __ffs (
          unsigned long word ) [inline], [static]
```

__ffs - find first bit in word. : The word to search


Undefined if no bit exists, so code should check against 0 first.

```
21.25.2.2 __fls()
```

```
static unsigned long __fls (
          unsigned long word ) [inline], [static]
```

__fls - find last (most-significant) set bit in a long word : the word to search

Undefined if no set bit exists, so code should check against 0 first. Here is the caller graph for this function:



21.25.2.3 ffs()

```
static int ffs (
                int x ) [inline], [static]
```

ffs - Find first bit set : the word to search

This is defined the same way as the libc and compiler builtin ffs routines, therefore differs in spirit from the above ffz (man ffs).


21.25.2.4 fls()

fls - find last (most-significant) bit set : the word to search

This is defined the same way as ffs. Note f(s(0)) = 0, f(s(1)) = 1, f(s(0)) = 32.

21.26 include/sbi/sbi_bits.h File Reference

This graph shows which files directly or indirectly include this file:



Macros

- #define EXTRACT_FIELD(val, which) (((val) & (which)) / ((which) & ~((which)-1)))
- #define INSERT_FIELD(val, which, fieldval) (((val) & \sim (which)) | ((fieldval) * ((which) & \sim ((which)-1))))
- #define BIT MASK(nr) (1UL << ((nr) % BITS PER LONG))
- #define BIT_WORD(nr) ((nr) / BITS_PER_LONG)

21.26.1 Macro Definition Documentation

21.26.1.1 BIT_MASK

```
#define BIT_MASK(  nr \ ) \ (1UL << ((nr) \ % BITS_PER_LONG))
```

21.26.1.2 BIT_WORD

```
#define BIT_WORD(  nr \ ) \ \ \mbox{((nr) / BITS_PER_LONG)}
```

21.26.1.3 EXTRACT_FIELD


```
#define EXTRACT_FIELD( val, \\ which ) \ (((val) \& (which)) \ / \ ((which) \& \sim ((which)-1)))
```

21.26.1.4 INSERT_FIELD


```
#define INSERT_FIELD( val, \\ which, \\ fieldval ) (((val) & \sim (which)) | ((fieldval) * ((which) & \sim ((which)-1))))
```

21.27 include/sbi/sbi_console.h File Reference

```
#include <sbi/sbi_types.h>
Include dependency graph for sbi_console.h:
```



This graph shows which files directly or indirectly include this file:



Macros

• #define __printf(a, b) __attribute__((format(printf, a, b)))

Functions

- bool sbi_isprintable (char ch)
- int sbi_getc (void)
- void sbi_putc (char ch)
- void sbi_puts (const char *str)
- void sbi_gets (char *s, int maxwidth, char endchar)
- int __printf (2, 3) sbi_sprintf(char *out
- int const char int __printf (3, 4) sbi_snprintf(char *out
- int const char int u32 const char int __printf (1, 2) sbi_printf(const char *format
- int const char int sbi_console_init (struct sbi_scratch *scratch)

Variables

- int const char * format
- int const char int u32 out_sz

21.27.1 Macro Definition Documentation

21.27.2 Function Documentation

21.27.2.4 sbi_console_init()

Here is the call graph for this function:




Here is the caller graph for this function:




21.27.2.5 sbi_getc()

```
int sbi_getc (
     void )
```

Here is the call graph for this function:



Here is the caller graph for this function:



21.27.2.6 sbi_gets()

Here is the call graph for this function:




21.27.2.7 sbi_isprintable()


```
bool sbi_isprintable ( char \ ch \ )
```

21.27.2.8 sbi_putc()

Here is the call graph for this function:




Here is the caller graph for this function:



21.27.2.9 sbi_puts()

Here is the call graph for this function:



21.27.3 Variable Documentation

21.27.3.1 format


int const char * format

21.27.3.2 out_sz

int const char int u32 out_sz

21.28 include/sbi/sbi_const.h File Reference

This graph shows which files directly or indirectly include this file:



Macros

21.28.1.1 __AC

```
#define __AC(X, Y) (X##Y)
#define _AC(X, Y) __AC(X,Y)
#define _AT(T, X) ((T)(X))
#define _UL(x) (_AC(x, UL))
#define _ULL(x) (_UL(1) << (x))</li>
#define _BITUL(x) (_UL(1) << (x))</li>
#define UL(x) (_UL(x))
#define UL(x) (_UL(x))
#define UL(x) (_ULL(x))
#define _STR(s) #s
#define STRINGIFY(s) __STR(s)
```

21.28.1 Macro Definition Documentation


21.28.1.5 _BITUL #define _BITUL(x) (_UL(1) << (x)) 21.28.1.6 _BITULL #define _BITULL(x) (_ULL(1) << (x)) 21.28.1.7 _UL #define _UL(x) (_AC(x, UL)) 21.28.1.8 _ULL #define _ULL(x) (_AC(x, ULL)) 21.28.1.9 STRINGIFY #define STRINGIFY(s) ___STR(s) 21.28.1.10 UL #define UL(x) (_UL(x)) 21.28.1.11 ULL

#define ULL(


x) (_ULL(x))

21.29 include/sbi/sbi_ecall.h File Reference

```
#include <sbi/sbi_types.h>
#include <sbi/sbi_list.h>
Include dependency graph for sbi_ecall.h:
```



This graph shows which files directly or indirectly include this file:



Data Structures

· struct sbi ecall extension

Macros

- #define SBI_ECALL_VERSION_MAJOR 0
- #define SBI ECALL VERSION MINOR 2
- #define SBI_OPENSBI_IMPID 1

Functions

- u16 sbi_ecall_version_major (void)
- u16 sbi_ecall_version_minor (void)
- struct sbi ecall extension * sbi ecall find extension (unsigned long extid)
- int sbi_ecall_register_extension (struct sbi_ecall_extension *ext)
- void sbi_ecall_unregister_extension (struct sbi_ecall_extension *ext)
- int sbi_ecall_handler (u32 hartid, ulong mcause, struct sbi_trap_regs *regs, struct sbi_scratch *scratch)
- int sbi_ecall_init (void)

Variables

- struct sbi_ecall_extension ecall_base
- struct sbi_ecall_extension ecall_legacy
- struct sbi_ecall_extension ecall_time
- struct sbi_ecall_extension ecall_rfence
- struct sbi_ecall_extension ecall_ipi
- struct sbi_ecall_extension ecall_vendor

21.29.1 Macro Definition Documentation

21.29.1.1 SBI_ECALL_VERSION_MAJOR

#define SBI_ECALL_VERSION_MAJOR 0

21.29.1.2 SBI_ECALL_VERSION_MINOR

#define SBI_ECALL_VERSION_MINOR 2


21.29.1.3 SBI_OPENSBI_IMPID

#define SBI_OPENSBI_IMPID 1

21.29.2 Function Documentation


21.29.2.1 sbi_ecall_find_extension()

Here is the caller graph for this function:



21.29.2.2 sbi_ecall_handler()

Here is the call graph for this function:




Here is the caller graph for this function:




21.29.2.3 sbi_ecall_init()

```
int sbi_ecall_init (
     void )
```

Here is the call graph for this function:




Here is the caller graph for this function:




21.29.2.4 sbi_ecall_register_extension()

```
int sbi_ecall_register_extension ( {\tt struct \; sbi\_ecall\_extension \; * \; ext \; )}
```

Here is the call graph for this function:



Here is the caller graph for this function:




21.29.2.5 sbi_ecall_unregister_extension()

Here is the call graph for this function:



21.29.2.6 sbi_ecall_version_major()

Here is the caller graph for this function:



21.29.2.7 sbi_ecall_version_minor()

Here is the call graph for this function:



Here is the caller graph for this function:




21.29.3 Variable Documentation

```
21.29.3.1 ecall_base
struct sbi_ecall_extension ecall_base
21.29.3.2 ecall_ipi
struct sbi_ecall_extension ecall_ipi
21.29.3.3 ecall_legacy
struct sbi_ecall_extension ecall_legacy
21.29.3.4 ecall_rfence
struct sbi_ecall_extension ecall_rfence
21.29.3.5 ecall_time
struct sbi_ecall_extension ecall_time
21.29.3.6 ecall_vendor
```

struct sbi_ecall_extension ecall_vendor

21.30 include/sbi/sbi_ecall_interface.h File Reference

This graph shows which files directly or indirectly include this file:



Macros

- #define SBI_EXT_0_1_SET_TIMER 0x0
- #define SBI_EXT_0_1_CONSOLE_PUTCHAR 0x1
- #define SBI_EXT_0_1_CONSOLE_GETCHAR 0x2
- #define SBI_EXT_0_1_CLEAR_IPI 0x3
- #define SBI EXT 0 1 SEND IPI 0x4
- #define SBI_EXT_0_1_REMOTE_FENCE_I 0x5
- #define SBI EXT 0 1 REMOTE SFENCE VMA 0x6
- #define SBI_EXT_0_1_REMOTE_SFENCE_VMA_ASID 0x7
- #define SBI EXT 0 1 SHUTDOWN 0x8
- #define SBI EXT BASE 0x10
- #define SBI EXT TIME 0x54494D45
- #define SBI_EXT_IPI 0x735049
- #define SBI_EXT_RFENCE 0x52464E43
- #define SBI_EXT_BASE_GET_SPEC_VERSION 0x0
- #define SBI EXT BASE GET IMP ID 0x1
- #define SBI EXT BASE GET IMP VERSION 0x2
- #define SBI_EXT_BASE_PROBE_EXT 0x3
- #define SBI_EXT_BASE_GET_MVENDORID 0x4
- #define SBI EXT BASE GET MARCHID 0x5
- #define SBI_EXT_BASE_GET_MIMPID 0x6
- #define SBI_EXT_TIME_SET_TIMER 0x0
- #define SBI_EXT_IPI_SEND_IPI 0x0
- #define SBI EXT RFENCE REMOTE FENCE I 0x0
- #define SBI_EXT_RFENCE_REMOTE_SFENCE_VMA 0x1
- #define SBI_EXT_RFENCE_REMOTE_SFENCE_VMA_ASID 0x2
- #define SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA 0x3
- #define SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA_VMID 0x4
- #define SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA 0x5
- #define SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA_ASID 0x6
- #define SBI SPEC VERSION MAJOR OFFSET 24
- #define SBI_SPEC_VERSION_MAJOR_MASK 0x7f
- #define SBI SPEC VERSION MINOR MASK 0xffffff
- #define SBI_EXT_VENDOR_START 0x09000000
- #define SBI EXT VENDOR END 0x09FFFFFF

21.30.1 Macro Definition Documentation

21.30.1.1 SBI_EXT_0_1_CLEAR_IPI

#define SBI_EXT_0_1_CLEAR_IPI 0x3

21.30.1.2 SBI_EXT_0_1_CONSOLE_GETCHAR

#define SBI_EXT_0_1_CONSOLE_GETCHAR 0x2

21.30.1.3 SBI_EXT_0_1_CONSOLE_PUTCHAR

#define SBI_EXT_0_1_CONSOLE_PUTCHAR 0x1

21.30.1.4 SBI_EXT_0_1_REMOTE_FENCE_I

#define SBI_EXT_0_1_REMOTE_FENCE_I 0x5

21.30.1.5 SBI_EXT_0_1_REMOTE_SFENCE_VMA

#define SBI_EXT_0_1_REMOTE_SFENCE_VMA 0x6

21.30.1.6 SBI_EXT_0_1_REMOTE_SFENCE_VMA_ASID

#define SBI_EXT_0_1_REMOTE_SFENCE_VMA_ASID 0x7

21.30.1.7 SBI_EXT_0_1_SEND_IPI

#define SBI_EXT_0_1_SEND_IPI 0x4

21.30.1.8 SBI_EXT_0_1_SET_TIMER

#define SBI_EXT_0_1_SET_TIMER 0x0

21.30.1.9 SBI_EXT_0_1_SHUTDOWN

#define SBI_EXT_0_1_SHUTDOWN 0x8

21.30.1.10 SBI_EXT_BASE

#define SBI_EXT_BASE 0x10

21.30.1.11 SBI_EXT_BASE_GET_IMP_ID

#define SBI_EXT_BASE_GET_IMP_ID 0x1

21.30.1.12 SBI_EXT_BASE_GET_IMP_VERSION

#define SBI_EXT_BASE_GET_IMP_VERSION 0x2

21.30.1.13 SBI_EXT_BASE_GET_MARCHID

#define SBI_EXT_BASE_GET_MARCHID 0x5

21.30.1.14 SBI_EXT_BASE_GET_MIMPID

#define SBI_EXT_BASE_GET_MIMPID 0x6

21.30.1.15 SBI_EXT_BASE_GET_MVENDORID

 $\verb|#define SBI_EXT_BASE_GET_MVENDORID 0x4|\\$

21.30.1.16 SBI_EXT_BASE_GET_SPEC_VERSION

#define SBI_EXT_BASE_GET_SPEC_VERSION 0x0

21.30.1.17 SBI_EXT_BASE_PROBE_EXT

#define SBI_EXT_BASE_PROBE_EXT 0x3

21.30.1.18 SBI_EXT_IPI

#define SBI_EXT_IPI 0x735049

21.30.1.19 SBI_EXT_IPI_SEND_IPI

#define SBI_EXT_IPI_SEND_IPI 0x0

21.30.1.20 SBI_EXT_RFENCE

#define SBI_EXT_RFENCE 0x52464E43

21.30.1.21 SBI_EXT_RFENCE_REMOTE_FENCE_I

#define SBI_EXT_RFENCE_REMOTE_FENCE_I 0x0

21.30.1.22 SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA

#define SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA 0x3

21.30.1.23 SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA_VMID

#define SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA_VMID 0x4

21.30.1.24 SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA

#define SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA 0x5

21.30.1.25 SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA_ASID

#define SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA_ASID 0x6

21.30.1.26 SBI_EXT_RFENCE_REMOTE_SFENCE_VMA

#define SBI_EXT_RFENCE_REMOTE_SFENCE_VMA 0x1

21.30.1.27 SBI_EXT_RFENCE_REMOTE_SFENCE_VMA_ASID

#define SBI_EXT_RFENCE_REMOTE_SFENCE_VMA_ASID 0x2

21.30.1.28 SBI_EXT_TIME

#define SBI_EXT_TIME 0x54494D45

21.30.1.29 SBI_EXT_TIME_SET_TIMER

#define SBI_EXT_TIME_SET_TIMER 0x0

21.30.1.30 SBI_EXT_VENDOR_END

#define SBI_EXT_VENDOR_END 0x09FFFFFF

21.30.1.31 SBI_EXT_VENDOR_START

#define SBI_EXT_VENDOR_START 0x09000000

21.30.1.32 SBI_SPEC_VERSION_MAJOR_MASK

#define SBI_SPEC_VERSION_MAJOR_MASK 0x7f

21.30.1.33 SBI_SPEC_VERSION_MAJOR_OFFSET


#define SBI_SPEC_VERSION_MAJOR_OFFSET 24

21.30.1.34 SBI_SPEC_VERSION_MINOR_MASK


#define SBI_SPEC_VERSION_MINOR_MASK 0xffffff

21.31 include/sbi/sbi_emulate_csr.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_emulate_csr.h:



This graph shows which files directly or indirectly include this file:



Functions


- int sbi_emulate_csr_read (int csr_num, u32 hartid, struct sbi_trap_regs *regs, struct sbi_scratch *scratch, ulong *csr_val)
- int sbi_emulate_csr_write (int csr_num, u32 hartid, struct sbi_trap_regs *regs, struct sbi_scratch *scratch, ulong csr_val)

21.31.1 Function Documentation

21.31.1.1 sbi_emulate_csr_read()

```
int sbi_emulate_csr_read (
    int csr_num,
    u32 hartid,
    struct sbi_trap_regs * regs,
    struct sbi_scratch * scratch,
    ulong * csr_val )
```

Here is the call graph for this function:




Here is the caller graph for this function:



21.31.1.2 sbi_emulate_csr_write()

Here is the call graph for this function:



Here is the caller graph for this function:



21.32 include/sbi/sbi_error.h File Reference

This graph shows which files directly or indirectly include this file:



Macros

- #define SBI OK 0
- #define SBI_EFAIL -1
- #define SBI_ENOTSUPP -2
- #define SBI_EINVAL -3
- #define SBI_DENIED -4
- #define SBI_INVALID_ADDR -5
- #define SBI ENODEV -6
- #define SBI_ENOSYS -7
- #define SBI ETIMEDOUT -8
- #define SBI_EIO -9
- #define SBI_EILL -10
- #define SBI_ENOSPC -11
- #define SBI_ENOMEM -12
- #define SBI_ETRAP -13
- #define SBI_EUNKNOWN -14
- #define SBI_ENOENT -15

21.32.1 Macro Definition Documentation

21.32.1.1 SBI_DENIED

#define SBI_DENIED -4

21.32.1.2 SBI_EFAIL

#define SBI_EFAIL -1

21.32.1.3 SBI_EILL

#define SBI_EILL -10

21.32.1.4 SBI_EINVAL

#define SBI_EINVAL -3

21.32.1.5 SBI_EIO

#define SBI_EIO -9

21.32.1.6 SBI_ENODEV

#define SBI_ENODEV -6

21.32.1.7 SBI_ENOENT

#define SBI_ENOENT -15

21.32.1.8 SBI_ENOMEM

#define SBI_ENOMEM -12

21.32.1.9 SBI_ENOSPC

#define SBI_ENOSPC -11

21.32.1.10 SBI_ENOSYS

#define SBI_ENOSYS -7

21.32.1.11 SBI_ENOTSUPP

#define SBI_ENOTSUPP -2

21.32.1.12 SBI_ETIMEDOUT

#define SBI_ETIMEDOUT -8

21.32.1.13 SBI_ETRAP

#define SBI_ETRAP -13

21.32.1.14 SBI_EUNKNOWN

#define SBI_EUNKNOWN -14

21.32.1.15 SBI_INVALID_ADDR


#define SBI_INVALID_ADDR -5

21.32.1.16 SBI_OK


#define SBI_OK 0

21.33 include/sbi/sbi_fifo.h File Reference

#include <sbi/riscv_locks.h>
#include <sbi/sbi_types.h>
Include dependency graph for sbi_fifo.h:



This graph shows which files directly or indirectly include this file:



Data Structures

· struct sbi_fifo

Enumerations

• enum sbi_fifo_inplace_update_types { SBI_FIFO_SKIP, SBI_FIFO_UPDATED, SBI_FIFO_UNCHANGED }

Functions

- int sbi_fifo_dequeue (struct sbi_fifo *fifo, void *data)
- int sbi_fifo_enqueue (struct sbi_fifo *fifo, void *data)
- void sbi_fifo_init (struct sbi_fifo *fifo, void *queue_mem, u16 entries, u16 entry_size)
- bool sbi_fifo_is_empty (struct sbi_fifo *fifo)
- bool sbi fifo is full (struct sbi fifo *fifo)
- int sbi_fifo_inplace_update (struct sbi_fifo *fifo, void *in, int(*fptr)(void *in, void *data))
- u16 sbi_fifo_avail (struct sbi_fifo *fifo)

21.33.1 Enumeration Type Documentation

21.33.1.1 sbi_fifo_inplace_update_types

```
enum sbi_fifo_inplace_update_types
```


Enumerator

SBI_FIFO_SKIP	
SBI_FIFO_UPDATED	
SBI_FIFO_UNCHANGED	

21.33.2 Function Documentation


```
21.33.2.1 sbi_fifo_avail()
```

Here is the call graph for this function:




21.33.2.2 sbi_fifo_dequeue()

Here is the call graph for this function:




Here is the caller graph for this function:



21.33.2.3 sbi_fifo_enqueue()

Here is the call graph for this function:



Here is the caller graph for this function:




21.33.2.4 sbi_fifo_init()

Here is the call graph for this function:




Here is the caller graph for this function:



21.33.2.5 sbi_fifo_inplace_update()

Provide a helper function to do inplace update to the fifo. Note: The callback function is called with lock being held.

Do not invoke any other fifo function from callback. Otherwise, it will lead to deadlock. Here is the call graph for this function:




Here is the caller graph for this function:




21.33.2.6 sbi_fifo_is_empty()

Here is the call graph for this function:




21.33.2.7 sbi_fifo_is_full()

Here is the call graph for this function:




21.34 include/sbi/sbi hart.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_hart.h:



This graph shows which files directly or indirectly include this file:



Functions

- int sbi_hart_init (struct sbi_scratch *scratch, u32 hartid, bool cold_boot)
- void * sbi_hart_get_trap_info (struct sbi_scratch *scratch)
- void sbi_hart_set_trap_info (struct sbi_scratch *scratch, void *data)
- void sbi_hart_delegation_dump (struct sbi_scratch *scratch)
- void sbi_hart_pmp_dump (struct sbi_scratch *scratch)
- void attribute ((noreturn)) sbi hart hang(void)
- void sbi_hart_mark_available (u32 hartid)
- ulong sbi_hart_available_mask (void)
- void sbi_hart_unmark_available (u32 hartid)
- struct sbi_scratch * sbi_hart_id_to_scratch (struct sbi_scratch *scratch, u32 hartid)
- void sbi_hart_wait_for_coldboot (struct sbi_scratch *scratch, u32 hartid)
- void sbi_hart_wake_coldboot_harts (struct sbi_scratch *scratch, u32 hartid)
- u32 sbi current hartid (void)


Variables

- void unsigned long arg1
- · void unsigned long unsigned long next addr
- void unsigned long unsigned long next mode
- void unsigned long unsigned long bool next_virt

21.34.1 Function Documentation


void)

Return HART ID of the caller. Here is the caller graph for this function:




21.34.1.3 sbi_hart_available_mask()

Here is the call graph for this function:




Here is the caller graph for this function:



21.34.1.4 sbi_hart_delegation_dump()

Here is the call graph for this function:



Here is the caller graph for this function:




21.34.1.5 sbi_hart_get_trap_info()

Here is the caller graph for this function:




21.34.1.6 sbi_hart_id_to_scratch()

Here is the caller graph for this function:




21.34.1.7 sbi_hart_init()

Here is the call graph for this function:




Here is the caller graph for this function:




21.34.1.8 sbi_hart_mark_available()

Here is the call graph for this function:




Here is the caller graph for this function:



21.34.1.9 sbi_hart_pmp_dump()

Here is the call graph for this function:




Here is the caller graph for this function:




21.34.1.10 sbi_hart_set_trap_info()


Here is the caller graph for this function:



21.34.1.11 sbi_hart_unmark_available()


Here is the call graph for this function:





21.34.1.12 sbi_hart_wait_for_coldboot()


Here is the call graph for this function:



Here is the caller graph for this function:



21.34.1.13 sbi_hart_wake_coldboot_harts()



Here is the caller graph for this function:



21.34.2 Variable Documentation

21.34.2.1 arg1

void unsigned long arg1

21.34.2.2 next_addr

void unsigned long unsigned long next_addr

21.34.2.3 next_mode


void unsigned long unsigned long unsigned long next_mode

21.34.2.4 next_virt

 $\verb|void unsigned long unsigned long unsigned long bool next_virt|\\$

21.35 include/sbi/sbi_hfence.h File Reference

This graph shows which files directly or indirectly include this file:




Functions

- void <u>__sbi_hfence_gvma_vmid_gpa</u> (unsigned long vmid, unsigned long gpa)
- void <u>__sbi_hfence_gvma_vmid</u> (unsigned long vmid)
- void <u>__sbi_hfence_gvma_gpa</u> (unsigned long gpa)
- void sbi hfence gyma all (void)
- void __sbi_hfence_vvma_asid_va (unsigned long asid, unsigned long va)
- void <u>__sbi_hfence_vvma_asid</u> (unsigned long asid)
- void <u>__sbi_hfence_vvma_va</u> (unsigned long va)
- void __sbi_hfence_vvma_all (void)

21.35.1 Function Documentation

21.35.1.1 __sbi_hfence_gvma_all()


Invalidate all possible Stage2 TLBs Here is the caller graph for this function:



21.35.1.2 __sbi_hfence_gvma_gpa()

```
void __sbi_hfence_gvma_gpa (
          unsigned long gpa )
```

Invalidate Stage2 TLBs for given guest physical address Here is the caller graph for this function:



21.35.1.3 __sbi_hfence_gvma_vmid()

```
void __sbi_hfence_gvma_vmid (
          unsigned long vmid )
```

Invalidate Stage2 TLBs for given VMID Here is the caller graph for this function:




21.35.1.4 __sbi_hfence_gvma_vmid_gpa()

Invalidate Stage2 TLBs for given VMID and guest physical address Here is the caller graph for this function:



21.35.1.5 __sbi_hfence_vvma_all()


Invalidate all possible Stage2 TLBs Here is the caller graph for this function:



21.35.1.6 __sbi_hfence_vvma_asid()

```
void __sbi_hfence_vvma_asid (
          unsigned long asid )
```

Invalidate unified TLB entries for given ASID for a guest Here is the caller graph for this function:




21.35.1.7 __sbi_hfence_vvma_asid_va()

Invalidate unified TLB entries for given asid and guest virtual address Here is the caller graph for this function: $\frac{1}{2} \left(\frac{1}{2} \right) = \frac{1}{2} \left(\frac{1}{2} \right) \left(\frac{$




21.35.1.8 __sbi_hfence_vvma_va()

Invalidate unified TLB entries for a given guest virtual address Here is the caller graph for this function:




21.36 include/sbi/sbi_illegal_insn.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_illegal_insn.h:



This graph shows which files directly or indirectly include this file:




Functions


• int sbi_illegal_insn_handler (u32 hartid, ulong mcause, ulong insn, struct sbi_trap_regs *regs, struct sbi_ coratch *scratch)

21.36.1 Function Documentation

21.36.1.1 sbi_illegal_insn_handler()


Here is the call graph for this function:






21.37 include/sbi/sbi_init.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_init.h:



This graph shows which files directly or indirectly include this file:



Functions

- void __noreturn sbi_init (struct sbi_scratch *scratch)
- unsigned long sbi_init_count (u32 hartid)
- void __noreturn sbi_exit (struct sbi_scratch *scratch)

21.37.1 Function Documentation

21.37.1.1 sbi_exit()

Exit OpenSBI library for current HART and stop HART


The function expects following:


- 1. The 'mscratch' CSR is pointing to sbi_scratch of current HART
- 2. Stack pointer (SP) is setup for current HART

Parameters

```
scratch pointer to sbi_scratch of current HART
```

Here is the call graph for this function:





21.37.1.2 sbi_init()

Initialize OpenSBI library for current HART and jump to next booting stage.


The function expects following:

- 1. The 'mscratch' CSR is pointing to sbi_scratch of current HART
- 2. Stack pointer (SP) is setup for current HART
- 3. Interrupts are disabled in MSTATUS CSR
- 4. All interrupts are disabled in MIE CSR

Parameters


scratch pointer to sbi_scratch of current HART

Here is the call graph for this function:




21.37.1.3 sbi_init_count()

Here is the call graph for this function:



21.38 include/sbi/sbi_ipi.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_ipi.h:



This graph shows which files directly or indirectly include this file:



Data Structures

• struct sbi_ipi_event_ops

Macros

#define SBI_IPI_EVENT_MAX __riscv_xlen

Functions

- int sbi_ipi_send_many (struct sbi_scratch *scratch, ulong hmask, ulong hbase, u32 event, void *data)
- int sbi_ipi_event_create (const struct sbi_ipi_event_ops *ops)
- void sbi_ipi_event_destroy (u32 event)
- int sbi_ipi_send_smode (struct sbi_scratch *scratch, ulong hmask, ulong hbase)
- void sbi_ipi_clear_smode (struct sbi_scratch *scratch)
- int sbi_ipi_send_halt (struct sbi_scratch *scratch, ulong hmask, ulong hbase)
- void sbi_ipi_process (struct sbi_scratch *scratch)
- int sbi_ipi_init (struct sbi_scratch *scratch, bool cold_boot)
- void sbi_ipi_exit (struct sbi_scratch *scratch)

21.38.1 Macro Definition Documentation

```
21.38.1.1 SBI_IPI_EVENT_MAX
```

```
#define SBI_IPI_EVENT_MAX ___riscv_xlen
```


21.38.2 Function Documentation

21.38.2.1 sbi_ipi_clear_smode()

```
sbi_ipi_clear_smode sbi_ecall_legacy_handler
```


21.38.2.2 sbi_ipi_event_create()

Here is the caller graph for this function:




21.38.2.3 sbi_ipi_event_destroy()

21.38.2.4 sbi_ipi_exit()





Here is the caller graph for this function:



21.38.2.5 sbi_ipi_init()


Here is the call graph for this function:






21.38.2.6 sbi_ipi_process()


Here is the call graph for this function:




Here is the caller graph for this function:



21.38.2.7 sbi_ipi_send_halt()




Here is the caller graph for this function:




21.38.2.8 sbi_ipi_send_many()

As this function only handlers scalar values of hart mask, it must be set to all online harts if the intention is to send IPIs to all the harts. If hmask is zero, no IPIs will be sent. FIXME: This check is valid only ULONG size. This is okay for now as available hart mask can support upto ULONG size only. Here is the call graph for this function:





Here is the caller graph for this function:



21.38.2.9 sbi_ipi_send_smode()


Here is the call graph for this function:






21.39 include/sbi/sbi_list.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_list.h:



This graph shows which files directly or indirectly include this file:



Data Structures

· struct sbi dlist

Macros

- #define SBI LIST POISON PREV 0xDEADBEEF
- #define SBI LIST POISON NEXT 0xFADEBABE
- #define SBI_LIST_HEAD_INIT(__Iname) { &(__Iname), &(__Iname) }
- #define SBI_LIST_HEAD(_Iname) struct sbi_dlist _Iname = SBI_LIST_HEAD_INIT(_Iname)
- #define SBI INIT LIST HEAD(ptr)
- #define sbi_list_entry(ptr, type, member) container_of(ptr, type, member)
- #define sbi_list_first_entry(ptr, type, member) sbi_list_entry((ptr)->next, type, member)
- #define sbi_list_last_entry(ptr, type, member) sbi_list_entry((ptr)->prev, type, member)
- #define sbi_list_for_each(pos, head) for (pos = (head)->next; pos != (head); pos = pos->next)
- #define sbi_list_for_each_entry(pos, head, member)

Functions

- static void <u>sbi_list_add</u> (struct sbi_dlist *new, struct sbi_dlist *prev, struct sbi_dlist *next)
- static void sbi_list_add (struct sbi_dlist *new, struct sbi_dlist *head)
- static void sbi_list_add_tail (struct sbi_dlist *new, struct sbi_dlist *tnode)
- static void __sbi_list_del (struct sbi_dlist *prev, struct sbi_dlist *next)
- static void sbi list del entry (struct sbi dlist *entry)
- static void sbi_list_del (struct sbi_dlist *entry)
- static void sbi_list_del_init (struct sbi_dlist *entry)

21.39.1 Macro Definition Documentation

21.39.1.1 SBI_INIT_LIST_HEAD

Value:

```
do {
     (ptr)->next = ptr; (ptr)->prev = ptr; \
} while (0);
```

21.39.1.2 sbi_list_entry

Get the struct for this entry

Parameters

ptr	the &struct list_head pointer.	
type	the type of the struct this is embedded in.	
member	the name of the list_struct within the struct.	

21.39.1.3 sbi_list_first_entry

Get the first element from a list

Parameters

ptr	the list head to take the element from.
type	the type of the struct this is embedded in.
member	the name of the list struct within the struct.

Note: that list is expected to be not empty.

21.39.1.4 sbi_list_for_each

Iterate over a list

Parameters

pos	the &struct list_head to use as a loop cursor.
head	the head for your list.

21.39.1.5 sbi_list_for_each_entry

Value:

Iterate over list of given type

Parameters

pos	the type * to use as a loop cursor. the head for your list.	
head		
member	the name of the list_struct within the struct.	

21.39.1.6 SBI_LIST_HEAD

21.39.1.7 SBI_LIST_HEAD_INIT

21.39.1.8 sbi_list_last_entry

Get the last element from a list

Parameters

ptr	the list head to take the element from.
type	the type of the struct this is embedded in.
member	the name of the list_head within the struct.

Note: that list is expected to be not empty.

21.39.1.9 SBI_LIST_POISON_NEXT

```
#define SBI_LIST_POISON_NEXT 0xFADEBABE
```

21.39.1.10 SBI_LIST_POISON_PREV

```
#define SBI_LIST_POISON_PREV 0xDEADBEEF
```

21.39.2 Function Documentation


21.39.2.1 __sbi_list_add()

Here is the caller graph for this function:



21.39.2.2 __sbi_list_del()

Here is the caller graph for this function:



21.39.2.3 __sbi_list_del_entry()



Here is the caller graph for this function:



21.39.2.4 sbi_list_add()

Adds the new node after the given head.

Parameters

new	New node that needs to be added to list.	
head	List head after which the "new" node should be added. Note: the new node is added after the head.	

Here is the call graph for this function:



21.39.2.5 sbi_list_add_tail()

Adds a node at the tail where tnode points to tail node.

Parameters

new I	The new node to be added before tail.
tnode 1	The current tail node. Note: the new node is added before tail node.
Generated by Doxygen	

Here is the call graph for this function:



Here is the caller graph for this function:



21.39.2.6 sbi_list_del()

Deletes a given entry from list.

Parameters

```
node Node to be deleted.
```

Here is the call graph for this function:



21.39.2.7 sbi_list_del_init()

Deletes entry from list and reinitialize it.


Parameters

entry the element to delete from the list.

Here is the call graph for this function:




Here is the caller graph for this function:




21.40 include/sbi/sbi_misaligned_ldst.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi misaligned ldst.h:



This graph shows which files directly or indirectly include this file:




Functions

- int sbi_misaligned_load_handler (u32 hartid, ulong mcause, ulong addr, ulong tval2, ulong tinst, struct sbi
 _trap_regs *regs, struct sbi_scratch *scratch)
- int sbi_misaligned_store_handler (u32 hartid, ulong mcause, ulong addr, ulong tval2, ulong tinst, struct sbi
 _trap_regs *regs, struct sbi_scratch *scratch)

21.40.1 Function Documentation

21.40.1.1 sbi_misaligned_load_handler()




Here is the caller graph for this function:

```
sbi_misaligned_load ____ sbi_trap_handler
```

21.40.1.2 sbi_misaligned_store_handler()

```
int sbi_misaligned_store_handler (
          u32 hartid,
          ulong mcause,
          ulong addr,
          ulong tval2,
          ulong tinst,
          struct sbi_trap_regs * regs,
          struct sbi_scratch * scratch )
```


Here is the call graph for this function:





21.41 include/sbi/sbi_platform.h File Reference

```
#include <sbi/sbi_ecall.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_scratch.h>
#include <sbi/sbi_trap.h>
#include <sbi/sbi_version.h>
Include dependency graph for sbi_platform.h:
```



This graph shows which files directly or indirectly include this file:



Data Structures

- struct sbi_platform_operations
- struct sbi_platform

Macros

- #define SBI_PLATFORM_VERSION(Major, Minor) ((Major << 16) | Minor)
- #define SBI_PLATFORM_OPENSBI_VERSION_OFFSET (0x00)
- #define SBI_PLATFORM_VERSION_OFFSET (0x04)
- #define SBI_PLATFORM_NAME_OFFSET (0x08)
- #define SBI_PLATFORM_FEATURES_OFFSET (0x48)
- #define SBI_PLATFORM_HART_COUNT_OFFSET (0x50)
- #define SBI_PLATFORM_HART_STACK_SIZE_OFFSET (0x54)
- #define SBI_PLATFORM_DISABLED_HART_OFFSET (0x58)
- #define SBI_PLATFORM_OPS_OFFSET (0x60)

- #define SBI PLATFORM FIRMWARE CONTEXT OFFSET (0x60 + SIZEOF POINTER)
- #define SBI PLATFORM TLB RANGE FLUSH LIMIT DEFAULT (1UL << 12)
- #define SBI_PLATFORM_DEFAULT_FEATURES
- #define sbi_platform_ptr(__s) ((const struct sbi_platform *)((__s)->platform_addr))
- #define sbi platform thishart ptr()
- #define sbi_platform_ops(_p) ((const struct sbi_platform_operations *)(_p)->platform_ops_addr)
- #define sbi platform has timer value(p) ((p)->features & SBI PLATFORM HAS TIMER VALUE)
- #define sbi_platform_has_hart_hotplug(__p) ((__p)->features & SBI_PLATFORM_HAS_HART_HOTPLUG)
- #define sbi_platform_has_pmp(__p) ((__p)->features & SBI_PLATFORM_HAS_PMP)
- #define sbi platform has scounteren(p) ((p)->features & SBI PLATFORM HAS SCOUNTEREN)
- #define sbi_platform_has_mcounteren(__p) ((__p)->features & SBI_PLATFORM_HAS_MCOUNTEREN)

Enumerations

enum sbi_platform_features {
 SBI_PLATFORM_HAS_TIMER_VALUE = (1 << 0), SBI_PLATFORM_HAS_HART_HOTPLUG = (1 << 1),
 SBI_PLATFORM_HAS_PMP = (1 << 2), SBI_PLATFORM_HAS_SCOUNTEREN = (1 << 3),
 SBI_PLATFORM_HAS_MCOUNTEREN = (1 << 4), SBI_PLATFORM_HAS_MFAULTS_DELEGATION = (1 << 5) }

Functions

- static const char * sbi_platform_name (const struct sbi_platform *plat)
- static bool sbi platform hart disabled (const struct sbi platform *plat, u32 hartid)
- static u64 sbi_platform_tlbr_flush_limit (const struct sbi_platform *plat)
- static u32 sbi platform hart count (const struct sbi platform *plat)
- static u32 sbi_platform_hart_stack_size (const struct sbi_platform *plat)
- static int sbi_platform_early_init (const struct sbi_platform *plat, bool cold_boot)
- static int sbi_platform_final_init (const struct sbi_platform *plat, bool cold_boot)
- static void sbi_platform_early_exit (const struct sbi_platform *plat)
- static void sbi_platform_final_exit (const struct sbi_platform *plat)
- static int sbi platform misa extension (const struct sbi platform *plat, char ext)
- static int sbi platform misa xlen (const struct sbi platform *plat)
- static u32 sbi_platform_pmp_region_count (const struct sbi_platform *plat, u32 hartid)
- static int sbi_platform_pmp_region_info (const struct sbi_platform *plat, u32 hartid, u32 index, ulong *prot, ulong *addr, ulong *log2size)
- static void sbi_platform_console_putc (const struct sbi_platform *plat, char ch)
- static int sbi_platform_console_getc (const struct sbi_platform *plat)
- static int sbi platform console init (const struct sbi platform *plat)
- static int sbi_platform_irqchip_init (const struct sbi_platform *plat, bool cold_boot)
- static void sbi_platform_irqchip_exit (const struct sbi_platform *plat)
- static void sbi platform ipi send (const struct sbi platform *plat, u32 target hart)
- static void sbi platform ipi clear (const struct sbi platform *plat, u32 target hart)
- static int sbi_platform_ipi_init (const struct sbi_platform *plat, bool cold_boot)
- static void sbi_platform_ipi_exit (const struct sbi_platform *plat)
- static u64 sbi platform timer value (const struct sbi platform *plat)
- static void sbi_platform_timer_event_start (const struct sbi_platform *plat, u64 next_event)
- static void sbi_platform_timer_event_stop (const struct sbi_platform *plat)
- static int sbi_platform_timer_init (const struct sbi_platform *plat, bool cold_boot)
- static void sbi platform timer exit (const struct sbi platform *plat)
- static int sbi_platform_system_reboot (const struct sbi_platform *plat, u32 type)
- static int sbi_platform_system_shutdown (const struct sbi_platform *plat, u32 type)
- static int sbi platform vendor ext check (const struct sbi platform *plat, long extid)
- static int sbi_platform_vendor_ext_provider (const struct sbi_platform *plat, long extid, long funcid, unsigned long *args, unsigned long *out_value, struct sbi_trap_info *out_trap)

Variables

• struct sbi_platform_operations __packed

21.41.1 Macro Definition Documentation

```
21.41.1.1 SBI_PLATFORM_DEFAULT_FEATURES
```

```
#define SBI_PLATFORM_DEFAULT_FEATURES
```

Value:

```
(SBI_PLATFORM_HAS_TIMER_VALUE | SBI_PLATFORM_HAS_PMP | \
SBI_PLATFORM_HAS_SCOUNTEREN | SBI_PLATFORM_HAS_MCOUNTEREN | \
SBI_PLATFORM_HAS_MFAULTS_DELEGATION)
```

Default feature set for a platform

```
21.41.1.2 SBI_PLATFORM_DISABLED_HART_OFFSET
```

```
#define SBI_PLATFORM_DISABLED_HART_OFFSET (0x58)
```

Offset of disabled_hart_mask in struct sbi_platform

```
21.41.1.3 SBI PLATFORM FEATURES OFFSET
```

```
\#define SBI_PLATFORM_FEATURES_OFFSET (0x48)
```

Offset of features in struct sbi_platform

```
21.41.1.4 SBI_PLATFORM_FIRMWARE_CONTEXT_OFFSET
```

```
#define SBI_PLATFORM_FIRMWARE_CONTEXT_OFFSET (0x60 + __SIZEOF_POINTER__)
```

Offset of firmware_context in struct sbi_platform

```
21.41.1.5 SBI_PLATFORM_HART_COUNT_OFFSET
```

```
#define SBI_PLATFORM_HART_COUNT_OFFSET (0x50)
```

Offset of hart_count in struct sbi_platform

```
21.41.1.6 SBI_PLATFORM_HART_STACK_SIZE_OFFSET
```

```
#define SBI_PLATFORM_HART_STACK_SIZE_OFFSET (0x54)
```

Offset of hart_stack_size in struct sbi_platform

21.41.1.7 sbi_platform_has_hart_hotplug

Check whether the platform supports HART hotplug

21.41.1.8 sbi_platform_has_mcounteren

Check whether the platform supports mcounteren CSR

21.41.1.9 sbi_platform_has_mfaults_delegation

Check whether the platform supports fault delegation

21.41.1.10 sbi_platform_has_pmp

Check whether the platform has PMP support

21.41.1.11 sbi_platform_has_scounteren

Check whether the platform supports scounteren CSR

21.41.1.12 sbi_platform_has_timer_value

Check whether the platform supports timer value

```
21.41.1.13 SBI_PLATFORM_NAME_OFFSET
#define SBI_PLATFORM_NAME_OFFSET (0x08)
Offset of name in struct sbi_platform
21.41.1.14 SBI_PLATFORM_OPENSBI_VERSION_OFFSET
#define SBI_PLATFORM_OPENSBI_VERSION_OFFSET (0x00)
Offset of opensbi_version in struct sbi_platform
21.41.1.15 sbi_platform_ops
#define sbi_platform_ops(
               \_p ) ((const struct sbi_platform_operations *)(\_p)->platform_ops_addr)
Get pointer to platform_ops_addr from platform pointer
21.41.1.16 SBI_PLATFORM_OPS_OFFSET
#define SBI_PLATFORM_OPS_OFFSET (0x60)
Offset of platform_ops_addr in struct sbi_platform
21.41.1.17 sbi_platform_ptr
#define sbi_platform_ptr(
               __s ) ((const struct sbi_platform *)((__s)->platform_addr))
Get pointer to sbi_platform for sbi_scratch pointer
21.41.1.18 sbi_platform_thishart_ptr
#define sbi_platform_thishart_ptr()
Value:
((const struct sbi_platform *) \
    (sbi_scratch_thishart_ptr()->platform_addr))
Get pointer to sbi_platform for current HART
21.41.1.19 SBI_PLATFORM_TLB_RANGE_FLUSH_LIMIT_DEFAULT
\#define SBI_PLATFORM_TLB_RANGE_FLUSH_LIMIT_DEFAULT (1UL << 12)
```

21.41.1.20 SBI_PLATFORM_VERSION

OpenSBI 32-bit platform version with:

- 1. upper 16-bits as major number
- 2. lower 16-bits as minor number

21.41.1.21 SBI_PLATFORM_VERSION_OFFSET

```
#define SBI_PLATFORM_VERSION_OFFSET (0x04)
```

Offset of platform_version in struct sbi_platform

21.41.2 Enumeration Type Documentation

21.41.2.1 sbi_platform_features

```
enum sbi_platform_features
```

Possible feature flags of a platform

Enumerator

SBI_PLATFORM_HAS_TIMER_VALUE	Platform has timer value
SBI_PLATFORM_HAS_HART_HOTPLUG	Platform has HART hotplug support
SBI_PLATFORM_HAS_PMP	Platform has PMP support
SBI_PLATFORM_HAS_SCOUNTEREN	Platform has S-mode counter enable
SBI_PLATFORM_HAS_MCOUNTEREN	Platform has M-mode counter enable
SBI_PLATFORM_HAS_MFAULTS_DELEGATION	Platform has fault delegation support

21.41.3 Function Documentation

21.41.3.1 sbi_platform_console_getc()

Read a character from the platform console input


Parameters

```
plat pointer to struct sbi_platform
```

Returns

character read from console input

Here is the caller graph for this function:



21.41.3.2 sbi_platform_console_init()

Initialize the platform console

Parameters

```
plat pointer to struct sbi_platform
```

Returns

0 on success and negative error code on failure




21.41.3.3 sbi_platform_console_putc()

Write a character to the platform console output

Parameters

plat	pointer to struct sbi_platform
ch	character to write


Here is the caller graph for this function:




21.41.3.4 sbi_platform_early_exit()

Early exit for current HART

Parameters





21.41.3.5 sbi_platform_early_init()

Early initialization for current HART


Parameters

plat	pointer to struct sbi_platform
cold_boot	whether cold boot (TRUE) or warm_boot (FALSE)

Returns

0 on success and negative error code on failure

Here is the caller graph for this function:




21.41.3.6 sbi_platform_final_exit()

Final exit for current HART

Parameters

plat pointer to struct sbi_platform

Here is the caller graph for this function:



21.41.3.7 sbi_platform_final_init()

Final initialization for current HART


Parameters

plat	pointer to struct sbi_platform
cold_boot	whether cold boot (TRUE) or warm_boot (FALSE)

Returns

0 on success and negative error code on failure

Here is the caller graph for this function:



21.41.3.8 sbi_platform_hart_count()

Get total number of HARTs supported by the platform


Parameters

plat	pointer to struct sbi_platform
------	--------------------------------

Returns

total number of HARTs

Here is the caller graph for this function:



21.41.3.9 sbi_platform_hart_disabled()


Check whether the given HART is disabled

plat	pointer to struct sbi_platform
hartid	HART ID

Returns

TRUE if HART is disabled and FALSE otherwise

Here is the caller graph for this function:



21.41.3.10 sbi_platform_hart_stack_size()

Get per-HART stack size for exception/interrupt handling

Parameters

```
plat pointer to struct sbi_platform
```

Returns

stack size in bytes

21.41.3.11 sbi_platform_ipi_clear()

Clear IPI for a target HART

plat	pointer to struct sbi_platform
target_hart	HART ID of IPI target

Here is the caller graph for this function:




21.41.3.12 sbi_platform_ipi_exit()

Exit the platform IPI support for current HART

Parameters

```
plat pointer to struct sbi_platform
```

Here is the caller graph for this function:



21.41.3.13 sbi_platform_ipi_init()


Initialize the platform IPI support for current HART

plat	pointer to struct sbi_platform
cold_boot	whether cold boot (TRUE) or warm_boot (FALSE)

Returns

0 on success and negative error code on failure

Here is the caller graph for this function:



21.41.3.14 sbi_platform_ipi_send()

Send IPI to a target HART

Parameters

plat	pointer to struct sbi_platform
target_hart	HART ID of IPI target

Here is the caller graph for this function:




21.41.3.15 sbi_platform_irqchip_exit()

Exit the platform interrupt controller for current HART

Parameters

```
plat pointer to struct sbi_platform
```

Here is the caller graph for this function:



21.41.3.16 sbi_platform_irqchip_init()


Initialize the platform interrupt controller for current HART

Parameters

plat	pointer to struct sbi_platform
cold_boot	whether cold boot (TRUE) or warm_boot (FALSE)

Returns

0 on success and negative error code on failure



21.41.3.17 sbi_platform_misa_extension()

Check CPU extension in MISA

Parameters

plat	pointer to struct sbi_platform
ext	shorthand letter for CPU extensions

Returns

zero for not-supported and non-zero for supported

Here is the caller graph for this function:



21.41.3.18 sbi_platform_misa_xlen()

Get MXL field of MISA

Parameters

```
plat pointer to struct sbi_platform
```

Returns

1/2/3 on success and error code on failure



21.41.3.19 sbi_platform_name()

Get name of the platform

Parameters

```
plat pointer to struct sbi_platform
```

Returns

pointer to platform name on success and "Unknown" on failure

Here is the caller graph for this function:



21.41.3.20 sbi_platform_pmp_region_count()

Get the number of PMP regions of a HART

plat	pointer to struct sbi_platform
hartid	HART ID

Returns

number of PMP regions

Here is the caller graph for this function:



21.41.3.21 sbi_platform_pmp_region_info()


Get PMP regions details (namely: protection, base address, and size) of a HART

Parameters

plat	pointer to struct sbi_platform
hartid	HART ID
index	index of PMP region for which we want details
prot	output pointer for PMP region protection
addr	output pointer for PMP region base address
log2size	output pointer for log-of-2 PMP region size

Returns

0 on success and negative error code on failure



21.41.3.22 sbi_platform_system_reboot()

Reboot the platform


Parameters

plat	pointer to struct sbi_platform
type	type of reboot

Returns

0 on success and negative error code on failure

Here is the caller graph for this function:



21.41.3.23 sbi_platform_system_shutdown()

Shutdown or poweroff the platform

plat	pointer to struct sbi_platform
type	type of shutdown or poweroff

Returns

0 on success and negative error code on failure

Here is the caller graph for this function:

```
sbi_platform_system sbi_system_shutdown sbi_ecall_legacy_handler
```

21.41.3.24 sbi_platform_timer_event_start()

Start platform timer event for current HART

Parameters

plat	pointer to struct struct sbi_platform
next_event	timer value when timer event will happen

Here is the caller graph for this function:




21.41.3.25 sbi_platform_timer_event_stop()

Stop platform timer event for current HART

Parameters

```
plat pointer to struct sbi_platform
```

Here is the caller graph for this function:




21.41.3.26 sbi_platform_timer_exit()

Exit the platform timer for current HART

Parameters

```
plat pointer to struct sbi_platform
```

Here is the caller graph for this function:



21.41.3.27 sbi_platform_timer_init()

Initialize the platform timer for current HART


Parameters

plat	pointer to struct sbi_platform
cold_boot	whether cold boot (TRUE) or warm_boot (FALSE)

Returns

0 on success and negative error code on failure


Here is the caller graph for this function:



21.41.3.28 sbi_platform_timer_value()

Get platform timer value

Parameters



Returns

64-bit timer value



21.41.3.29 sbi_platform_tlbr_flush_limit()

Get platform specific tlb range flush maximum value. Any request with size higher than this is upgraded to a full flush.


Parameters

```
plat pointer to struct sbi_platform
```

Returns

tlb range flush limit value. Returns a default (page size) if not defined by platform.

Here is the caller graph for this function:



21.41.3.30 sbi_platform_vendor_ext_check()

Check if a vendor extension is implemented or not.

plat	pointer to struct sbi_platform
extid vendor SBI extension id	

Returns

0 if extid is not implemented and 1 if implemented

Here is the caller graph for this function:



21.41.3.31 sbi_platform_vendor_ext_provider()

Invoke platform specific vendor SBI extension implementation.

plat	pointer to struct sbi_platform	
extid	vendor SBI extension id	
funcid	SBI function id within the extension id	
args	pointer to arguments passed by the caller	
out_value	output value that can be filled by the callee	
out_trap	trap info that can be filled by the callee	

Returns

0 on success and negative error code on failure

Here is the caller graph for this function:




21.41.4 Variable Documentation


```
21.41.4.1 __packed
struct sbi_platform __packed
```

21.42 include/sbi/sbi_scratch.h File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/sbi_types.h>
Include dependency graph for sbi scratch.h:
```



This graph shows which files directly or indirectly include this file:



Data Structures

· struct sbi_scratch

Macros

- #define SBI_SCRATCH_FW_START_OFFSET (0 * __SIZEOF_POINTER__)
- #define SBI_SCRATCH_FW_SIZE_OFFSET (1 * __SIZEOF_POINTER__)
- #define SBI_SCRATCH_NEXT_ARG1_OFFSET (2 * __SIZEOF_POINTER__)
- #define SBI_SCRATCH_NEXT_ADDR_OFFSET (3 * __SIZEOF_POINTER__)
- #define SBI_SCRATCH_NEXT_MODE_OFFSET (4 * __SIZEOF_POINTER__)
- #define SBI_SCRATCH_WARMBOOT_ADDR_OFFSET (5 * __SIZEOF_POINTER__)
- #define SBI_SCRATCH_PLATFORM_ADDR_OFFSET (6 * __SIZEOF_POINTER__)
- #define SBI SCRATCH HARTID TO SCRATCH OFFSET (7 * SIZEOF POINTER)
- #define SBI_SCRATCH_TMP0_OFFSET (8 * __SIZEOF_POINTER__)
- #define SBI_SCRATCH_OPTIONS_OFFSET (9 * __SIZEOF_POINTER__)
- #define SBI SCRATCH EXTRA SPACE OFFSET (10 * SIZEOF POINTER)
- #define SBI_SCRATCH_SIZE (64 * __SIZEOF_POINTER__)
- #define sbi_scratch_thishart_ptr() ((struct sbi_scratch *)csr_read(CSR_MSCRATCH))
- #define sbi_scratch_thishart_arg1_ptr() ((void *)(sbi_scratch_thishart_ptr()->next_arg1))
- #define sbi_scratch_offset_ptr(scratch, offset) ((void *)scratch + (offset))
- #define sbi_scratch_thishart_offset_ptr(offset) ((void *)sbi_scratch_thishart_ptr() + (offset))

Enumerations

• enum sbi_scratch_options { SBI_SCRATCH_NO_BOOT_PRINTS = (1 << 0), SBI_SCRATCH_DEBUG_ \leftarrow PRINTS = (1 << 1) }

Functions

- unsigned long sbi_scratch_alloc_offset (unsigned long size, const char *owner)
- void sbi_scratch_free_offset (unsigned long offset)

Variables

struct sbi_scratch __packed

21.42.1 Macro Definition Documentation

```
21.42.1.1 SBI_SCRATCH_EXTRA_SPACE_OFFSET
#define SBI_SCRATCH_EXTRA_SPACE_OFFSET (10 * __SIZEOF_POINTER__)
Offset of extra space in <a href="mailto:sbi_scratch">sbi_scratch</a>
21.42.1.2 SBI_SCRATCH_FW_SIZE_OFFSET
#define SBI_SCRATCH_FW_SIZE_OFFSET (1 * __SIZEOF_POINTER__)
Offset of fw_size member in sbi_scratch
21.42.1.3 SBI_SCRATCH_FW_START_OFFSET
#define SBI_SCRATCH_FW_START_OFFSET (0 * __SIZEOF_POINTER__)
Offset of fw_start member in sbi_scratch
21.42.1.4 SBI_SCRATCH_HARTID_TO_SCRATCH_OFFSET
#define SBI_SCRATCH_HARTID_TO_SCRATCH_OFFSET (7 * __SIZEOF_POINTER__)
Offset of hartid_to_scratch member in sbi_scratch
21.42.1.5 SBI_SCRATCH_NEXT_ADDR_OFFSET
#define SBI_SCRATCH_NEXT_ADDR_OFFSET (3 * __SIZEOF_POINTER__)
Offset of next_addr member in sbi_scratch
21.42.1.6 SBI_SCRATCH_NEXT_ARG1_OFFSET
#define SBI_SCRATCH_NEXT_ARG1_OFFSET (2 * __SIZEOF_POINTER__)
Offset of next_arg1 member in sbi_scratch
21.42.1.7 SBI_SCRATCH_NEXT_MODE_OFFSET
#define SBI_SCRATCH_NEXT_MODE_OFFSET (4 * __SIZEOF_POINTER__)
```

Offset of next_mode member in sbi_scratch

```
21.42.1.8 sbi_scratch_offset_ptr
#define sbi_scratch_offset_ptr(
               scratch,
               offset ) ((void *)scratch + (offset))
Get pointer from offset in sbi scratch
21.42.1.9 SBI_SCRATCH_OPTIONS_OFFSET
#define SBI_SCRATCH_OPTIONS_OFFSET (9 * __SIZEOF_POINTER__)
Offset of options member in sbi_scratch
21.42.1.10 SBI_SCRATCH_PLATFORM_ADDR_OFFSET
#define SBI_SCRATCH_PLATFORM_ADDR_OFFSET (6 * __SIZEOF_POINTER__)
Offset of platform addr member in sbi scratch
21.42.1.11 SBI_SCRATCH_SIZE
#define SBI_SCRATCH_SIZE (64 * __SIZEOF_POINTER__)
Maximum size of sbi scratch
21.42.1.12 sbi_scratch_thishart_arg1_ptr
#define sbi_scratch_thishart_arg1_ptr() ((void *)(sbi_scratch_thishart_ptr()->next_arg1))
Get Arg1 of next booting stage for current HART
21.42.1.13 sbi_scratch_thishart_offset_ptr
#define sbi_scratch_thishart_offset_ptr(
               offset ) ((void *)sbi_scratch_thishart_ptr() + (offset))
Get pointer from offset in <a href="mailto:sbi_scratch">sbi_scratch</a> for current HART
21.42.1.14 sbi_scratch_thishart_ptr
#define sbi_scratch_thishart_ptr() ((struct sbi_scratch *)csr_read(CSR_MSCRATCH))
```

Get pointer to sbi_scratch for current HART

21.42.1.15 SBI_SCRATCH_TMP0_OFFSET

```
#define SBI_SCRATCH_TMP0_OFFSET (8 * __SIZEOF_POINTER__)
```

Offset of tmp0 member in sbi_scratch

21.42.1.16 SBI_SCRATCH_WARMBOOT_ADDR_OFFSET

```
#define SBI_SCRATCH_WARMBOOT_ADDR_OFFSET (5 * __SIZEOF_POINTER__)
```

Offset of warmboot_addr member in sbi_scratch

21.42.2 Enumeration Type Documentation

21.42.2.1 sbi_scratch_options

```
enum sbi_scratch_options
```

Possible options for OpenSBI library

Enumerator

SBI_SCRATCH_NO_BOOT_PRINTS	Disable prints during boot
SBI_SCRATCH_DEBUG_PRINTS	Enable runtime debug prints

21.42.3 Function Documentation

21.42.3.1 sbi_scratch_alloc_offset()


```
unsigned long sbi_scratch_alloc_offset (
          unsigned long size,
          const char * owner )
```

Allocate from extra space in sbi_scratch


Returns

zero on failure and non-zero (>= SBI_SCRATCH_EXTRA_SPACE_OFFSET) on success

Here is the call graph for this function:




Here is the caller graph for this function:



21.42.3.2 sbi_scratch_free_offset()

```
void sbi_scratch_free_offset (
          unsigned long offset )
```

Free-up extra space in sbi_scratch Here is the caller graph for this function:




21.42.4 Variable Documentation


```
21.42.4.1 __packed struct sbi_scratch __packed
```

21.43 include/sbi/sbi_string.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_string.h:



This graph shows which files directly or indirectly include this file:



Functions

- int sbi_strcmp (const char *a, const char *b)
- size_t sbi_strlen (const char *str)
- size_t sbi_strnlen (const char *str, size_t count)
- char * sbi_strcpy (char *dest, const char *src)
- char * sbi_strncpy (char *dest, const char *src, size_t count)
- char * sbi_strchr (const char *s, int c)
- char * sbi_strrchr (const char *s, int c)
- void * sbi_memset (void *s, int c, size_t count)
- void * sbi_memcpy (void *dest, const void *src, size_t count)
- void * sbi_memmove (void *dest, const void *src, size_t count)
- int sbi_memcmp (const void *s1, const void *s2, size_t count)
- void * sbi_memchr (const void *s, int c, size_t count)


21.43.1 Function Documentation

21.43.1.1 sbi_memchr()

21.43.1.2 sbi_memcmp()

21.43.1.3 sbi_memcpy()


Here is the caller graph for this function:



21.43.1.4 sbi_memmove()

21.43.1.5 sbi_memset()

Here is the caller graph for this function:



21.43.1.6 sbi_strchr()

```
char* sbi_strchr (  {\rm const~char} \ * \ s, \\ {\rm int} \ c \ )
```

21.43.1.7 sbi_strcmp()

21.43.1.8 sbi_strcpy()

21.43.1.9 sbi_strlen()

Here is the caller graph for this function:



21.43.1.10 sbi_strncpy()

21.43.1.11 sbi_strnlen()


21.43.1.12 sbi_strrchr()

```
char* sbi_strrchr (  {\rm const~char} \ * \ s, \\ {\rm int} \ c \ )
```




21.44 include/sbi/sbi_system.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_system.h:



This graph shows which files directly or indirectly include this file:



Functions

- int sbi_system_early_init (struct sbi_scratch *scratch, bool cold_boot)
- int sbi_system_final_init (struct sbi_scratch *scratch, bool cold_boot)
- void sbi_system_early_exit (struct sbi_scratch *scratch)
- void sbi_system_final_exit (struct sbi_scratch *scratch)
- void __noreturn sbi_system_reboot (struct sbi_scratch *scratch, u32 type)
- void __noreturn sbi_system_shutdown (struct sbi_scratch *scratch, u32 type)

21.44.1 Function Documentation

21.44.1.1 sbi_system_early_exit()


Here is the call graph for this function:



21.44.1.2 sbi_system_early_init()

Here is the call graph for this function:





21.44.1.3 sbi_system_final_exit()


Here is the call graph for this function:



21.44.1.4 sbi_system_final_init()


Here is the call graph for this function:






21.44.1.5 sbi_system_reboot()


Here is the call graph for this function:



21.44.1.6 sbi_system_shutdown()




Here is the caller graph for this function:




21.45 include/sbi/sbi_timer.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_timer.h:



This graph shows which files directly or indirectly include this file:




Functions

- u64 sbi_timer_value (struct sbi_scratch *scratch)
- u64 sbi_timer_virt_value (struct sbi_scratch *scratch)
- u64 sbi_timer_get_delta (struct sbi_scratch *scratch)
- void sbi_timer_set_delta (struct sbi_scratch *scratch, ulong delta)
- void sbi_timer_set_delta_upper (struct sbi_scratch *scratch, ulong delta_upper)
- void sbi_timer_event_start (struct sbi_scratch *scratch, u64 next_event)
- void sbi_timer_process (struct sbi_scratch *scratch)
- int sbi_timer_init (struct sbi_scratch *scratch, bool cold_boot)
- void sbi_timer_exit (struct sbi_scratch *scratch)


21.45.1 Function Documentation

21.45.1.1 sbi_timer_event_start()

Here is the call graph for this function:




Here is the caller graph for this function:




21.45.1.2 sbi_timer_exit()

Here is the call graph for this function:



Here is the caller graph for this function:




21.45.1.3 sbi_timer_get_delta()




21.45.1.4 sbi_timer_init()

Here is the call graph for this function:



Here is the caller graph for this function:



21.45.1.5 sbi_timer_process()



21.45.1.6 sbi_timer_set_delta()

Here is the caller graph for this function:


```
sbi_timer_set_delta sbi_emulate_csr_write system_opcode_insn
```

21.45.1.7 sbi_timer_set_delta_upper()


Here is the caller graph for this function:

```
sbi_timer_set_delta _____sbi_emulate_csr_write ____ system_opcode_insn
```

21.45.1.8 sbi_timer_value()




Here is the caller graph for this function:




21.45.1.9 sbi_timer_virt_value()

Here is the call graph for this function:




Here is the caller graph for this function:




21.46 include/sbi/sbi_tlb.h File Reference

#include <sbi/sbi_types.h>

Include dependency graph for sbi_tlb.h:



This graph shows which files directly or indirectly include this file:



Data Structures

· struct sbi tlb info

Macros

- #define SBI_TLB_FLUSH_ALL ((unsigned long)-1)
- #define SBI_TLB_FIFO_NUM_ENTRIES 8
- #define SBI_TLB_INFO_SIZE sizeof(struct sbi_tlb_info)

Enumerations

enum sbi_tlb_info_types {
 SBI_TLB_FLUSH_VMA, SBI_TLB_FLUSH_VMA_ASID, SBI_TLB_FLUSH_GVMA, SBI_TLB_FLUSH_GV
 MA_VMID,
 SBI_TLB_FLUSH_VVMA, SBI_TLB_FLUSH_VVMA_ASID, SBI_ITLB_FLUSH }

Functions

- int sbi_tlb_request (struct sbi_scratch *scratch, ulong hmask, ulong hbase, struct sbi_tlb_info *tinfo)
- int sbi_tlb_init (struct sbi_scratch *scratch, bool cold_boot)

21.46.1 Macro Definition Documentation

21.46.1.1 SBI_TLB_FIFO_NUM_ENTRIES

#define SBI_TLB_FIFO_NUM_ENTRIES 8

21.46.1.2 SBI_TLB_FLUSH_ALL

#define SBI_TLB_FLUSH_ALL ((unsigned long)-1)

21.46.1.3 SBI_TLB_INFO_SIZE

#define SBI_TLB_INFO_SIZE sizeof(struct sbi_tlb_info)

21.46.2 Enumeration Type Documentation

21.46.2.1 sbi_tlb_info_types


enum sbi_tlb_info_types

Enumerator


21.46.3 Function Documentation

21.46.3.1 sbi_tlb_init()

Here is the call graph for this function:




Here is the caller graph for this function:




21.46.3.2 sbi_tlb_request()

Here is the call graph for this function:




Here is the caller graph for this function:



21.47 include/sbi/sbi_trap.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_trap.h:



This graph shows which files directly or indirectly include this file:



Data Structures

- · struct sbi_trap_regs
- · struct sbi trap info

Macros

- #define SBI_TRAP_REGS_zero 0
- #define SBI_TRAP_REGS_ra 1
- #define SBI TRAP REGS sp 2
- #define SBI_TRAP_REGS_gp 3
- #define SBI TRAP REGS tp 4
- #define SBI TRAP REGS to 5
- #define SBI_TRAP_REGS_t1 6
- #define SBI_TRAP_REGS_t2 7
- #define SBI_TRAP_REGS_s0 8
- #define SBI_TRAP_REGS_s1 9
- #define SBI_TRAP_REGS_a0 10
- #define SBI TRAP REGS at 11
- #define SBI TRAP REGS a2 12
- #define SBI_TRAP_REGS_a3 13
- #define SBI_TRAP_REGS_a4 14
- #define SBI_TRAP_REGS_a5 15
- #define SBI TRAP REGS a6 16
- #define SBI_TRAP_REGS_a7 17
- #define SBI_TRAP_REGS_s2 18
- #define SBI_TRAP_REGS_s3 19
- #define SBI_TRAP_REGS_s5 21
- #define SBI_TRAP_REGS_s6 22
- #define SBI_TRAP_REGS_s7 23
- #define SBI_TRAP_REGS_s8 24
- #define SBI_TRAP_REGS_s9 25
- #define SBI_TRAP_REGS_s10 26
- #define SBI_TRAP_REGS_s11 27
- #define SBI TRAP REGS t3 28
- #define SBI_TRAP_REGS_t4 29
- #define SBI_TRAP_REGS_t5 30
- #define SBI_TRAP_REGS_t6 31
- #define SBI_TRAP_REGS_mepc 32
- #define SBI_TRAP_REGS_mstatus 33
- #define SBI_TRAP_REGS_mstatusH 34
- #define SBI TRAP REGS last 35
- #define SBI_TRAP_REGS_OFFSET(x) ((SBI_TRAP_REGS_##x) * __SIZEOF_POINTER__)
- #define SBI_TRAP_REGS_SIZE SBI_TRAP_REGS_OFFSET(last)

Functions

- int sbi_trap_redirect (struct sbi_trap_regs *regs, struct sbi_trap_info *trap, struct sbi_scratch *scratch)
- void sbi_trap_handler (struct sbi_trap_regs *regs, struct sbi_scratch *scratch)

Variables

• struct sbi_trap_regs __packed

21.47.1 Macro Definition Documentation

```
21.47.1.1 SBI_TRAP_REGS_a0

#define SBI_TRAP_REGS_a0 10

Index of a0 member in sbi_trap_regs

21.47.1.2 SBI_TRAP_REGS_a1

#define SBI_TRAP_REGS_a1 11

Index of a1 member in sbi_trap_regs

21.47.1.3 SBI_TRAP_REGS_a2

#define SBI_TRAP_REGS_a2 12

Index of a2 member in sbi_trap_regs
```

21.47.1.4 SBI_TRAP_REGS_a3

#define SBI_TRAP_REGS_a3 13

Index of a3 member in sbi_trap_regs

21.47.1.5 SBI_TRAP_REGS_a4

#define SBI_TRAP_REGS_a4 14

Index of a4 member in sbi_trap_regs

```
21.47.1.6 SBI_TRAP_REGS_a5
#define SBI_TRAP_REGS_a5 15
Index of a5 member in sbi_trap_regs
21.47.1.7 SBI_TRAP_REGS_a6
#define SBI_TRAP_REGS_a6 16
Index of a6 member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
21.47.1.8 SBI_TRAP_REGS_a7
#define SBI_TRAP_REGS_a7 17
Index of a7 member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
21.47.1.9 SBI_TRAP_REGS_gp
#define SBI_TRAP_REGS_gp 3
Index of gp member in sbi_trap_regs
21.47.1.10 SBI_TRAP_REGS_last
#define SBI_TRAP_REGS_last 35
Last member index in sbi_trap_regs
21.47.1.11 SBI_TRAP_REGS_mepc
#define SBI_TRAP_REGS_mepc 32
Index of mepc member in sbi trap regs
21.47.1.12 SBI_TRAP_REGS_mstatus
#define SBI_TRAP_REGS_mstatus 33
Index of mstatus member in sbi_trap_regs
21.47.1.13 SBI_TRAP_REGS_mstatusH
#define SBI_TRAP_REGS_mstatusH 34
```

Index of mstatusH member in sbi_trap_regs

```
21.47.1.14 SBI_TRAP_REGS_OFFSET
#define SBI_TRAP_REGS_OFFSET(
                x ) ((SBI_TRAP_REGS_##x) * __SIZEOF_POINTER__)
Get offset of member with name 'x' in sbi_trap_regs
21.47.1.15 SBI_TRAP_REGS_ra
#define SBI_TRAP_REGS_ra 1
Index of ra member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
21.47.1.16 SBI_TRAP_REGS_s0
#define SBI_TRAP_REGS_s0 8
Index of s0 member in sbi_trap_regs
21.47.1.17 SBI_TRAP_REGS_s1
#define SBI_TRAP_REGS_s1 9
Index of s1 member in sbi_trap_regs
21.47.1.18 SBI_TRAP_REGS_s10
#define SBI_TRAP_REGS_s10 26
Index of s10 member in sbi_trap_regs
21.47.1.19 SBI_TRAP_REGS_s11
#define SBI_TRAP_REGS_s11 27
Index of s11 member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
```

```
21.47.1.20 SBI_TRAP_REGS_s2

#define SBI_TRAP_REGS_s2 18

Index of s2 member in sbi_trap_regs

Generated by Doxygen
```

```
21.47.1.21 SBI_TRAP_REGS_s3
#define SBI_TRAP_REGS_s3 19
Index of s3 member in sbi_trap_regs
21.47.1.22 SBI_TRAP_REGS_s4
#define SBI_TRAP_REGS_s4 20
Index of s4 member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
21.47.1.23 SBI_TRAP_REGS_s5
#define SBI_TRAP_REGS_s5 21
Index of s5 member in sbi_trap_regs
21.47.1.24 SBI_TRAP_REGS_s6
#define SBI_TRAP_REGS_s6 22
Index of s6 member in sbi_trap_regs
21.47.1.25 SBI_TRAP_REGS_s7
#define SBI_TRAP_REGS_s7 23
Index of s7 member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
21.47.1.26 SBI_TRAP_REGS_s8
#define SBI_TRAP_REGS_s8 24
Index of s8 member in sbi trap regs
21.47.1.27 SBI_TRAP_REGS_s9
#define SBI_TRAP_REGS_s9 25
Index of s9 member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
21.47.1.28 SBI_TRAP_REGS_SIZE
#define SBI_TRAP_REGS_SIZE SBI_TRAP_REGS_OFFSET(last)
Size (in bytes) of sbi_trap_regs
```

Generated by Doxygen

```
21.47.1.29 SBI_TRAP_REGS_sp
#define SBI_TRAP_REGS_sp 2
Index of sp member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
21.47.1.30 SBI_TRAP_REGS_t0
#define SBI_TRAP_REGS_t0 5
Index of t0 member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
21.47.1.31 SBI_TRAP_REGS_t1
#define SBI_TRAP_REGS_t1 6
Index of t1 member in sbi_trap_regs
21.47.1.32 SBI_TRAP_REGS_t2
#define SBI_TRAP_REGS_t2 7
Index of t2 member in sbi_trap_regs
21.47.1.33 SBI_TRAP_REGS_t3
#define SBI_TRAP_REGS_t3 28
Index of t3 member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
21.47.1.34 SBI_TRAP_REGS_t4
#define SBI_TRAP_REGS_t4 29
Index of t4 member in sbi trap regs
21.47.1.35 SBI_TRAP_REGS_t5
#define SBI_TRAP_REGS_t5 30
Index of t5 member in sbi_trap_regs
21.47.1.36 SBI_TRAP_REGS_t6
#define SBI_TRAP_REGS_t6 31
Index of t6 member in <a href="mailto:sbi_trap_regs">sbi_trap_regs</a>
```

21.47.1.37 SBI_TRAP_REGS_tp

```
#define SBI_TRAP_REGS_tp 4
```

Index of tp member in sbi_trap_regs

21.47.1.38 SBI_TRAP_REGS_zero

```
#define SBI_TRAP_REGS_zero 0
```

Index of zero member in sbi_trap_regs

21.47.2 Function Documentation

21.47.2.1 sbi_trap_handler()

Handle trap/interrupt


This function is called by firmware linked to OpenSBI library for handling trap/interrupt. It expects the following:

- 1. The 'mscratch' CSR is pointing to sbi_scratch of current HART
- 2. The 'mcause' CSR is having exception/interrupt cause
- 3. The 'mtval' CSR is having additional trap information
- 4. The 'mtval2' CSR is having additional trap information
- 5. The 'mtinst' CSR is having decoded trap instruction
- 6. Stack pointer (SP) is setup for current HART
- 7. Interrupts are disabled in MSTATUS CSR

Parameters

regs	pointer to register state
scratch	pointer to sbi_scratch of current HART

Here is the call graph for this function:



21.47.2.2 sbi_trap_redirect()

Redirect trap to lower privledge mode (S-mode or U-mode)


Parameters

regs	pointer to register state
trap	pointer to trap details
scratch	pointer to sbi_scratch of current HART

Returns

0 on success and negative error code on failure

Here is the caller graph for this function:



21.47.3 Variable Documentation

```
21.47.3.1 __packed
```

struct sbi_trap_regs __packed

21.48 include/sbi/sbi_types.h File Reference

This graph shows which files directly or indirectly include this file:



Macros

- #define TRUE 1
- #define FALSE 0
- #define NULL ((void *)0)
- #define __packed __attribute__((packed))
- #define __noreturn __attribute__((noreturn))
- #define likely(x) __builtin_expect((x), 1)
- #define unlikely(x) __builtin_expect((x), 0)
- #define offsetof(TYPE, MEMBER) ((size_t) &((TYPE *)0)->MEMBER)

- #define container_of(ptr, type, member)
- #define MAX(a, b) ((a) > (b) ? (a) : (b))
- #define MIN(a, b) ((a) < (b) ? (a) : (b))
- #define CLAMP(a, lo, hi) MIN(MAX(a, lo), hi)
- #define STR(x) XSTR(x)
- #define XSTR(x) #x
- #define ROUNDUP(a, b) ((((a)-1) / (b) + 1) * (b))
- #define ROUNDDOWN(a, b) ((a) / (b) * (b))

Typedefs

- typedef char s8
- typedef unsigned char u8
- · typedef unsigned char uint8_t
- typedef short s16
- typedef unsigned short u16
- typedef short int16 t
- typedef unsigned short uint16_t
- typedef int s32
- typedef unsigned int u32
- · typedef int int32_t
- typedef unsigned int uint32_t
- typedef int bool
- · typedef unsigned long ulong
- typedef unsigned long uintptr t
- typedef unsigned long size_t
- typedef long ssize t
- typedef unsigned long virtual_addr_t
- typedef unsigned long virtual_size_t
- typedef unsigned long physical addr t
- typedef unsigned long physical_size_t

21.48.1 Macro Definition Documentation

```
21.48.1.1 __noreturn
#define __noreturn __attribute__((noreturn))

21.48.1.2 __packed
struct sbi_platform __packed __attribute__((packed))
```

```
21.48.1.3 CLAMP
```

```
#define CLAMP(
                a,
                10,
                hi ) MIN(MAX(a, lo), hi)
21.48.1.4 container_of
#define container_of(
               ptr,
                type,
               member )
Value:
    const typeof(((type *)0)->member) * __mptr = (ptr); \
(type *)((char *)__mptr - offsetof(type, member)); })
21.48.1.5 FALSE
#define FALSE 0
21.48.1.6 likely
#define likely(
           x ) __builtin_expect((x), 1)
21.48.1.7 MAX
#define MAX(
                b ) ((a) > (b) ? (a) : (b))
21.48.1.8 MIN
#define MIN(
                b ) ((a) < (b) ? (a) : (b))
```

21.48.1.9 NULL

```
#define NULL ((void *)0)
```

21.48.1.10 offsetof

21.48.1.11 ROUNDDOWN

21.48.1.12 ROUNDUP

21.48.1.13 STR

```
#define STR( x ) XSTR(x)
```

21.48.1.14 TRUE

#define TRUE 1

21.48.1.15 unlikely

21.48.1.16 XSTR

```
#define XSTR( x ) \#x
```

21.48.2 Typedef Documentation

```
21.48.2.1 bool
```

```
typedef int bool
```

21.48.2.2 int16_t

```
typedef short int16_t
```

21.48.2.3 int32_t

typedef int int32_t

21.48.2.4 physical_addr_t

 ${\tt typedef\ unsigned\ long\ physical_addr_t}$

21.48.2.5 physical_size_t

 ${\tt typedef \ unsigned \ long \ physical_size_t}$

21.48.2.6 s16


typedef short s16

```
21.48.2.7 s32
typedef int s32
21.48.2.8 s8
typedef char s8
21.48.2.9 size_t
typedef unsigned long size_t
21.48.2.10 ssize_t
typedef long ssize_t
21.48.2.11 u16
typedef unsigned short {\tt u16}
21.48.2.12 u32
typedef unsigned int u32
21.48.2.13 u8
typedef unsigned char u8
21.48.2.14 uint16_t
typedef unsigned short uint16_t
```


21.48.2.15 uint32_t typedef unsigned int $uint32_t$ 21.48.2.16 uint8_t typedef unsigned char uint8_t 21.48.2.17 uintptr_t typedef unsigned long uintptr_t 21.48.2.18 ulong typedef unsigned long ulong 21.48.2.19 virtual_addr_t typedef unsigned long virtual_addr_t 21.48.2.20 virtual_size_t ${\tt typedef \ unsigned \ long \ virtual_size_t}$

21.49 include/sbi/sbi_unpriv.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sbi_unpriv.h:



This graph shows which files directly or indirectly include this file:



Macros

- #define DECLARE_UNPRIVILEGED_LOAD_FUNCTION(type)
- #define DECLARE_UNPRIVILEGED_STORE_FUNCTION(type)

Functions

• ulong sbi_get_insn (ulong mepc, struct sbi_scratch *scratch, struct sbi_trap_info *trap)

21.49.1 Macro Definition Documentation

21.49.1.1 DECLARE_UNPRIVILEGED_LOAD_FUNCTION

```
\begin{tabular}{ll} \# define \ \ DECLARE\_UNPRIVILEGED\_LOAD\_FUNCTION ( \\ type \ ) \end{tabular}
```

Value:

21.49.1.2 DECLARE_UNPRIVILEGED_STORE_FUNCTION

```
\label{eq:define_declare_unprivileged_store_function} \texttt{type} \ )
```

Value:


21.49.2 Function Documentation

21.49.2.1 sbi_get_insn()

Here is the call graph for this function:


```
sbi_get_insn sbi_hart_set_trap_info
```

Here is the caller graph for this function:



21.50 include/sbi/sbi_version.h File Reference

This graph shows which files directly or indirectly include this file:



Macros

- #define OPENSBI_VERSION_MAJOR 0
- #define OPENSBI_VERSION_MINOR 6
- #define OPENSBI_VERSION

21.50.1 Macro Definition Documentation

21.50.1.1 OPENSBI_VERSION

#define OPENSBI_VERSION

Value:

```
((OPENSBI_VERSION_MAJOR << 16) | \
(OPENSBI_VERSION_MINOR))
```

OpenSBI 32-bit version with:

- 1. upper 16-bits as major number
- 2. lower 16-bits as minor number

21.50.1.2 OPENSBI_VERSION_MAJOR


#define OPENSBI_VERSION_MAJOR 0

21.50.1.3 OPENSBI_VERSION_MINOR


#define OPENSBI_VERSION_MINOR 6

21.51 include/sbi_utils/irqchip/plic.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for plic.h:



This graph shows which files directly or indirectly include this file:



Functions

- void plic_fdt_fixup (void *fdt, const char *compat)
- int plic_warm_irqchip_init (u32 target_hart, int m_cntx_id, int s_cntx_id)
- int plic_cold_irqchip_init (unsigned long base, u32 num_sources, u32 hart_count)
- void plic_set_thresh (u32 cntxid, u32 val)
- void plic_set_ie (u32 cntxid, u32 word_index, u32 val)

21.51.1 Function Documentation

21.51.1.1 plic_cold_irqchip_init()


```
int plic_cold_irqchip_init (
          unsigned long base,
          u32 num_sources,
          u32 hart_count )
```

Here is the call graph for this function:

```
plic_cold_irqchip_init plic_set_priority
```

21.51.1.2 plic_fdt_fixup()

Here is the call graph for this function:



21.51.1.3 plic_set_ie()

Here is the caller graph for this function:




21.51.1.4 plic_set_thresh()

Here is the caller graph for this function:




21.51.1.5 plic_warm_irqchip_init()

Here is the call graph for this function:




21.52 include/sbi_utils/serial/sifive-uart.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for sifive-uart.h:



This graph shows which files directly or indirectly include this file:




Functions

- void sifive_uart_putc (char ch)
- int sifive_uart_getc (void)
- int sifive_uart_init (unsigned long base, u32 in_freq, u32 baudrate)

21.52.1 Function Documentation

21.52.1.1 sifive_uart_getc()


Here is the call graph for this function:



21.52.1.2 sifive_uart_init()

```
int sifive_uart_init (
          unsigned long base,
          u32 in_freq,
          u32 baudrate )
```


Here is the call graph for this function:



21.52.1.3 sifive_uart_putc()


```
void sifive_uart_putc ( char \ ch )
```

Here is the call graph for this function:




21.53 include/sbi_utils/serial/uart8250.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for uart8250.h:



This graph shows which files directly or indirectly include this file:



Functions

- void uart8250_putc (char ch)
- int uart8250_getc (void)
- int uart8250_init (unsigned long base, u32 in_freq, u32 baudrate, u32 reg_shift, u32 reg_width)

21.53.1 Function Documentation

21.53.1.1 uart8250_getc()


```
int uart8250_getc ( void )
```

Here is the call graph for this function:



21.53.1.2 uart8250_init()


Here is the call graph for this function:



21.53.1.3 uart8250_putc()


```
void uart8250_putc ( char\ ch )
```

Here is the call graph for this function:




21.54 include/sbi_utils/sys/clint.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for clint.h:



This graph shows which files directly or indirectly include this file:



Functions

- void clint_ipi_send (u32 target_hart)
- void clint_ipi_sync (u32 target_hart)
- void clint_ipi_clear (u32 target_hart)
- int clint_warm_ipi_init (void)
- int clint_cold_ipi_init (unsigned long base, u32 hart_count)
- u64 clint timer value (void)
- void clint_timer_event_stop (void)
- void clint_timer_event_start (u64 next_event)
- int clint_warm_timer_init (void)
- int clint_cold_timer_init (unsigned long base, u32 hart_count, bool has_64bit_mmio)


21.54.1 Function Documentation

21.54.1.1 clint_cold_ipi_init()

21.54.1.2 clint_cold_timer_init()

```
int clint_cold_timer_init (
          unsigned long base,
          u32 hart_count,
          bool has_64bit_mmio )
```

Here is the call graph for this function:



21.54.1.3 clint_ipi_clear()

Here is the caller graph for this function:




21.54.1.4 clint_ipi_send()

21.54.1.5 clint_ipi_sync()

21.54.1.6 clint_timer_event_start()

Here is the call graph for this function:



21.54.1.7 clint_timer_event_stop()


Here is the call graph for this function:



21.54.1.8 clint_timer_value()

21.54.1.9 clint_warm_ipi_init()

Here is the call graph for this function:




21.54.1.10 clint_warm_timer_init()

Here is the call graph for this function:




21.55 include/sbi_utils/sys/htif.h File Reference

#include <sbi/sbi_types.h>
Include dependency graph for htif.h:



This graph shows which files directly or indirectly include this file:



Functions


- void httf_putc">httf_putc (char ch)
- int htif_getc (void)
- int htif_system_down (u32 type)

21.55.1 Function Documentation

21.55.1.1 htif_getc()

```
int htif_getc (
     void )
```


Here is the call graph for this function:




21.55.1.2 htif_putc()

```
void htif_putc ( {\tt char}\ {\it ch}\ )
```

Here is the call graph for this function:






21.55.1.3 htif_system_down()

21.56 lib/sbi/riscv asm.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_encoding.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_platform.h>
Include dependency graph for riscv_asm.c:
```




Functions

- int misa_extension_imp (char ext)
- int misa_xlen (void)
- unsigned long csr_read_num (int csr_num)
- void csr_write_num (int csr_num, unsigned long val)
- static unsigned long ctz (unsigned long x)
- int pmp set (unsigned int n, unsigned long prot, unsigned long addr, unsigned long log2len)
- int pmp_get (unsigned int n, unsigned long *prot_out, unsigned long *addr_out, unsigned long *log2len_out)

21.56.1 Function Documentation


21.56.1.1 csr_read_num()

Here is the caller graph for this function:




21.56.1.2 csr_write_num()

Here is the caller graph for this function:



21.56.1.3 ctz()

```
static unsigned long ctz ( \label{eq:ctz} \text{unsigned long } x \text{ ) } \text{ [static]}
```



21.56.1.4 misa_extension_imp()

Here is the call graph for this function:




Here is the caller graph for this function:



21.56.1.5 misa_xlen()

```
int misa_xlen (
     void )
```

Here is the call graph for this function:







21.56.1.6 pmp_get()

```
int pmp_get (
          unsigned int n,
          unsigned long * prot_out,
          unsigned long * addr_out,
           unsigned long * log2len_out )
```

Here is the call graph for this function:




Here is the caller graph for this function:



21.56.1.7 pmp_set()

```
int pmp_set (
          unsigned int n,
          unsigned long prot,
          unsigned long addr,
          unsigned long log2len)
```




Here is the caller graph for this function:



21.57 lib/sbi/riscv atomic.c File Reference

```
#include <sbi/sbi_types.h>
#include <sbi/riscv_asm.h>
#include <sbi/riscv_atomic.h>
#include <sbi/riscv_barrier.h>
#include <sbi/sbi_bits.h>
```

Include dependency graph for riscv_atomic.c:



Macros

- #define __axchg(ptr, new, size)
- #define axchg(ptr, x)
- #define __xchg(ptr, new, size)
- #define xchg(ptr, n)
- #define __cmpxchg(ptr, old, new, size)
- #define cmpxchg(ptr, o, n)
- #define __atomic_op_bit_ord(op, mod, nr, addr, ord)
- #define __atomic_op_bit(op, mod, nr, addr) __atomic_op_bit_ord(op, mod, nr, addr, .aqrl)
- #define ___NOP(x) (x)
- #define ___NOT(x) (~(x))

Functions

- long atomic read (atomic t *atom)
- void atomic_write (atomic_t *atom, long value)
- long atomic_add_return (atomic_t *atom, long value)
- long atomic_sub_return (atomic_t *atom, long value)
- long arch_atomic_cmpxchg (atomic_t *atom, long oldval, long newval)
- long arch_atomic_xchg (atomic_t *atom, long newval)
- unsigned int atomic_raw_xchg_uint (volatile unsigned int *ptr, unsigned int newval)
- unsigned long atomic_raw_xchg_ulong (volatile unsigned long *ptr, unsigned long newval)
- int atomic_raw_set_bit (int nr, volatile unsigned long *addr)
- int atomic_raw_clear_bit (int nr, volatile unsigned long *addr)
- int atomic set bit (int nr, atomic t *atom)
- int atomic clear bit (int nr, atomic t *atom)

21.57.1 Macro Definition Documentation

21.57.1.1 atomic op bit

21.57.1.2 __atomic_op_bit_ord

Value:

21.57.1.3 __axchg

Value:

21.57.1.4 __cmpxchg

21.57.1.5 __NOP

```
#define \_NOP( _{x} ) (x)
```

21.57.1.6 __NOT

```
#define __NOT(  x \ ) \ (\sim (\texttt{x}))
```

```
21.57.1.7 __xchg
```

21.57.1.8 axchg

```
#define axchg( ptr, x )
```

Value:

21.57.1.9 cmpxchg

```
#define cmpxchg(
    ptr
    o,
    n )
```

Value:

```
({
    __typeof__(*(ptr)) _o_ = (o);
    __typeof__(*(ptr)) _n_ = (n);
    (__typeof__(*(ptr)))
    __cmpxchg((ptr), _o_, _n_, sizeof(*(ptr))); \
})
```

21.57.1.10 xchg

```
#define xchg( ptr, \\ n \ )
```

Value:

```
({
    __typeof__(*(ptr)) _n_ = (n);
    (__typeof__(*(ptr))) _xchg((ptr), _n_, sizeof(*(ptr))); \
})
```

21.57.2 Function Documentation

21.57.2.1 arch_atomic_cmpxchg()

21.57.2.2 arch_atomic_xchg()


21.57.2.3 atomic_add_return()



21.57.2.4 atomic_clear_bit()

```
int atomic_clear_bit (
          int nr,
          atomic_t * atom ) [inline]
```

Clear a bit in an atomic variable and return the new value. : Bit to set. : atomic variable to modify Here is the call graph for this function:



21.57.2.5 atomic_raw_clear_bit()


Clear a bit in any address and return the new value . : Bit to set. : Address to modify Here is the caller graph for this function:



21.57.2.6 atomic_raw_set_bit()

```
int atomic_raw_set_bit (
          int nr,
          volatile unsigned long * addr ) [inline]
```


Set a bit in any address and return the new value . : Bit to set. : Address to modify Here is the caller graph for this function:



21.57.2.7 atomic_raw_xchg_uint()

21.57.2.8 atomic_raw_xchg_ulong()

Here is the caller graph for this function:



21.57.2.9 atomic_read()

21.57.2.10 atomic_set_bit()

```
int atomic_set_bit (
          int nr,
          atomic_t * atom ) [inline]
```

Set a bit in an atomic variable and return the new value. : Bit to set. : atomic variable to modify Here is the call graph for this function:




21.57.2.11 atomic_sub_return()

21.57.2.12 atomic_write()

21.58 lib/sbi/riscv_locks.c File Reference

```
#include <sbi/riscv_barrier.h>
#include <sbi/riscv_locks.h>
Include dependency graph for riscv_locks.c:
```



Functions


```
• int spin_lock_check (spinlock_t *lock)
```

```
• int spin_trylock (spinlock_t *lock)
```


- void spin_lock (spinlock_t *lock)
- void spin_unlock (spinlock_t *lock)

21.58.1 Function Documentation

```
21.58.1.1 spin_lock()
```




Here is the caller graph for this function:




21.58.1.2 spin_lock_check()

Here is the caller graph for this function:




21.58.1.3 spin_trylock()

Here is the caller graph for this function:



21.58.1.4 spin_unlock()


Here is the caller graph for this function:



21.59 lib/sbi/sbi_console.c File Reference

```
#include <sbi/sbi_platform.h>
#include <sbi/sbi_console.h>
#include <sbi/riscv_locks.h>
```

Include dependency graph for sbi_console.c:



Macros

- #define PAD_RIGHT 1
- #define PAD ZERO 2
- #define PAD ALTERNATE 4
- #define PRINT_BUF_LEN 64
- #define va_start(v, I) __builtin_va_start((v), I)
- #define va_end __builtin_va_end
- #define va_arg __builtin_va_arg

Typedefs

• typedef __builtin_va_list va_list

Functions

- bool sbi_isprintable (char c)
- int sbi_getc (void)
- void sbi_putc (char ch)
- void sbi_puts (const char *str)
- void sbi_gets (char *s, int maxwidth, char endchar)
- static void printc (char **out, u32 *out len, char ch)
- static int prints (char **out, u32 *out_len, const char *string, int width, int flags)
- static int printi (char **out, u32 *out_len, long long i, int b, int sg, int width, int flags, int letbase)
- static int print (char **out, u32 *out_len, const char *format, va_list args)
- int sbi_sprintf (char *out, const char *format,...)
- int sbi_snprintf (char *out, u32 out_sz, const char *format,...)
- int sbi_printf (const char *format,...)
- int sbi_dprintf (struct sbi_scratch *scratch, const char *format,...)
- int sbi_console_init (struct sbi_scratch *scratch)

Variables

- static const struct sbi_platform * console_plat = NULL
- static spinlock_t console_out_lock = SPIN_LOCK_INITIALIZER

21.59.1 Macro Definition Documentation

```
21.59.1.1 PAD_ALTERNATE
```

```
#define PAD_ALTERNATE 4
```

21.59.1.2 PAD_RIGHT

```
#define PAD_RIGHT 1
```

21.59.1.3 PAD ZERO

#define PAD_ZERO 2

21.59.1.4 PRINT_BUF_LEN

```
#define PRINT_BUF_LEN 64
```

21.59.1.5 va_arg

```
#define va_arg __builtin_va_arg
```

21.59.1.6 va_end

#define va_end __builtin_va_end

21.59.1.7 va_start


21.59.2 Typedef Documentation


```
21.59.2.1 va_list
typedef __builtin_va_list va_list
```

21.59.3 Function Documentation

21.59.3.1 print()

Here is the call graph for this function:






21.59.3.2 printc()


Here is the call graph for this function:




Here is the caller graph for this function:



21.59.3.3 printi()





Here is the caller graph for this function:



21.59.3.4 prints()

Here is the call graph for this function:






21.59.3.5 sbi_console_init()


Here is the call graph for this function:




Here is the caller graph for this function:



21.59.3.6 sbi_dprintf()




Here is the caller graph for this function:




21.59.3.7 sbi_getc()

```
int sbi_getc (
     void )
```

Here is the call graph for this function:





21.59.3.8 sbi_gets()


Here is the call graph for this function:




21.59.3.9 sbi_isprintable()

```
bool sbi_isprintable ( {\tt char}\ c\ )
```

21.59.3.10 sbi_printf()




Here is the caller graph for this function:



21.59.3.11 sbi_putc()

```
void sbi_putc ( {\tt char} \ {\it ch} \ )
```


Here is the call graph for this function:






21.59.3.12 sbi_puts()

Here is the call graph for this function:




21.59.3.13 sbi_snprintf()



21.59.3.14 sbi_sprintf()

Here is the call graph for this function:



21.59.4 Variable Documentation

21.59.4.1 console_out_lock

```
spinlock_t console_out_lock = SPIN_LOCK_INITIALIZER [static]
```


21.59.4.2 console_plat

```
const struct sbi_platform* console_plat = NULL [static]
```

21.60 lib/sbi/sbi_ecall.c File Reference

```
#include <sbi/sbi_ecall.h>
#include <sbi/sbi_ecall_interface.h>
#include <sbi/sbi_error.h>
```

#include <sbi/sbi_trap.h>
Include dependency graph for sbi_ecall.c:




Functions

- u16 sbi_ecall_version_major (void)
- u16 sbi_ecall_version_minor (void)
- static SBI_LIST_HEAD (ecall_exts_list)
- struct sbi_ecall_extension * sbi_ecall_find_extension (unsigned long extid)
- int sbi_ecall_register_extension (struct sbi_ecall_extension *ext)
- void sbi_ecall_unregister_extension (struct sbi_ecall_extension *ext)
- int sbi_ecall_handler (u32 hartid, ulong mcause, struct sbi_trap_regs *regs, struct sbi_scratch *scratch)
- int sbi ecall init (void)


21.60.1 Function Documentation

21.60.1.1 sbi_ecall_find_extension()



21.60.1.2 sbi_ecall_handler()

Here is the call graph for this function:




Here is the caller graph for this function:



21.60.1.3 sbi_ecall_init()

```
int sbi_ecall_init (
     void )
```




Here is the caller graph for this function:



21.60.1.4 sbi_ecall_register_extension()

```
int sbi_ecall_register_extension ( {\tt struct \; sbi\_ecall\_extension \; * \; ext \; )}
```

Here is the call graph for this function:



Here is the caller graph for this function:



21.60.1.5 sbi_ecall_unregister_extension()

Here is the call graph for this function:



21.60.1.6 sbi_ecall_version_major()

Here is the caller graph for this function:



21.60.1.7 sbi_ecall_version_minor()

Here is the call graph for this function:





21.60.1.8 SBI_LIST_HEAD()


Here is the caller graph for this function:



21.61 lib/sbi/sbi ecall base.c File Reference

```
#include <sbi/sbi_ecall.h>
#include <sbi/sbi_ecall_interface.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_version.h>
#include <sbi/riscv_asm.h>
```

Include dependency graph for sbi_ecall_base.c:



Functions

- static int sbi_ecall_base_probe (struct sbi_scratch *scratch, unsigned long extid, unsigned long *out_val)
- static int sbi_ecall_base_handler (struct sbi_scratch *scratch, unsigned long extid, unsigned long funcid, unsigned long *args, unsigned long *out_val, struct sbi_trap_info *out_trap)


Variables

· struct sbi ecall extension ecall base

21.61.1 Function Documentation

21.61.1.1 sbi_ecall_base_handler()

Here is the call graph for this function:



21.61.1.2 sbi_ecall_base_probe()

Here is the call graph for this function:





21.61.2 Variable Documentation

```
21.61.2.1 ecall_base

struct sbi_ecall_extension ecall_base

Initial value:

= {
    .extid_start = SBI_EXT_BASE,
    .extid_end = SBI_EXT_BASE,
    .handle = sbi_ecall_base_handler,
```

21.62 lib/sbi/sbi_ecall_legacy.c File Reference

```
#include <sbi/sbi_console.h>
#include <sbi/sbi_ecall.h>
#include <sbi/sbi_ecall_interface.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_ipi.h>
#include <sbi/sbi_system.h>
#include <sbi/sbi_timer.h>
#include <sbi/sbi_tlb.h>
#include <sbi/sbi_trap.h>
#include <sbi/sbi_unpriv.h>
#include <sbi/sbi_hart.h>
```

Include dependency graph for sbi_ecall_legacy.c:

Functions

- static int sbi_load_hart_mask_unpriv (struct sbi_scratch *scratch, ulong *pmask, ulong *hmask, struct sbi
 _trap_info *uptrap)
- static int sbi_ecall_legacy_handler (struct sbi_scratch *scratch, unsigned long extid, unsigned long funcid, unsigned long *args, unsigned long *out_val, struct sbi_trap_info *out_trap)


Variables

struct sbi_ecall_extension ecall_legacy


21.62.1 Function Documentation

21.62.1.1 sbi_ecall_legacy_handler()


Here is the call graph for this function:



21.62.1.2 sbi_load_hart_mask_unpriv()



Here is the caller graph for this function:



21.62.2 Variable Documentation

```
21.62.2.1 ecall_legacy
```

```
struct sbi_ecall_extension ecall_legacy
```


Initial value:

```
= {
    .extid_start = SBI_EXT_0_1_SET_TIMER,
    .extid_end = SBI_EXT_0_1_SHUTDOWN,
    .handle = sbi_ecall_legacy_handler,
}
```

21.63 lib/sbi/sbi_ecall_replace.c File Reference

```
#include <sbi/sbi_ecall.h>
#include <sbi/sbi_ecall_interface.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_hart.h>
#include <sbi/sbi_ipi.h>
#include <sbi/sbi_timer.h>
#include <sbi/sbi_tlb.h>
#include <sbi/riscv_asm.h>
```

Include dependency graph for sbi_ecall_replace.c:



Functions

- static int sbi_ecall_time_handler (struct sbi_scratch *scratch, unsigned long extid, unsigned long funcid, unsigned long *args, unsigned long *out_val, struct sbi_trap_info *out_trap)
- static int sbi_ecall_rfence_handler (struct sbi_scratch *scratch, unsigned long extid, unsigned long funcid, unsigned long *args, unsigned long *out_val, struct sbi_trap_info *out_trap)
- static int sbi_ecall_ipi_handler (struct sbi_scratch *scratch, unsigned long extid, unsigned long funcid, unsigned long *args, unsigned long *out_val, struct sbi_trap_info *out_trap)


Variables

- · struct sbi ecall extension ecall time
- struct sbi_ecall_extension ecall_rfence
- struct sbi_ecall_extension ecall_ipi

21.63.1 Function Documentation


21.63.1.1 sbi_ecall_ipi_handler()

```
static int sbi_ecall_ipi_handler (
    struct sbi_scratch * scratch,
    unsigned long extid,
    unsigned long funcid,
    unsigned long * args,
    unsigned long * out_val,
    struct sbi_trap_info * out_trap ) [static]
```




21.63.1.2 sbi_ecall_rfence_handler()

Here is the call graph for this function:



21.63.1.3 sbi_ecall_time_handler()

Here is the call graph for this function:



21.63.2 Variable Documentation

```
21.63.2.1 ecall_ipi
```

```
struct sbi_ecall_extension ecall_ipi
```

Initial value:

```
= {
    .extid_start = SBI_EXT_IPI,
    .extid_end = SBI_EXT_IPI,
    .handle = sbi_ecall_ipi_handler,
```

21.63.2.2 ecall_rfence

```
\verb|struct sbi_ecall_extension ecall_rfence|\\
```

Initial value:

```
= {
    .extid_start = SBI_EXT_RFENCE,
    .extid_end = SBI_EXT_RFENCE,
    .handle = sbi_ecall_rfence_handler,
```

21.63.2.3 ecall_time


```
struct sbi_ecall_extension ecall_time
```

Initial value:

```
= {
    .extid_start = SBI_EXT_TIME,
    .extid_end = SBI_EXT_TIME,
    .handle = sbi_ecall_time_handler,
```

21.64 lib/sbi/sbi_ecall_vendor.c File Reference

```
#include <sbi/sbi_ecall.h>
#include <sbi/sbi_ecall_interface.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_platform.h>
Include dependency graph for sbi_ecall_vendor.c:
```



Functions

- static int sbi_ecall_vendor_probe (struct sbi_scratch *scratch, unsigned long extid, unsigned long *out_val)
- static int sbi_ecall_vendor_handler (struct sbi_scratch *scratch, unsigned long extid, unsigned long funcid, unsigned long *args, unsigned long *out_val, struct sbi_trap_info *out_trap)


Variables

· struct sbi_ecall_extension ecall_vendor

21.64.1 Function Documentation


21.64.1.1 sbi_ecall_vendor_handler()

Here is the call graph for this function:



21.64.1.2 sbi_ecall_vendor_probe()

Here is the call graph for this function:



21.64.2 Variable Documentation

21.64.2.1 ecall_vendor

```
struct sbi_ecall_extension ecall_vendor
```


Initial value:

```
= {
    .extid_start = SBI_EXT_VENDOR_START,
    .extid_end = SBI_EXT_VENDOR_END,
    .probe = sbi_ecall_vendor_probe,
    .handle = sbi_ecall_vendor_handler,
}
```

21.65 lib/sbi/sbi_emulate_csr.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_encoding.h>
#include <sbi/sbi_bits.h>
#include <sbi/sbi_console.h>
#include <sbi/sbi_emulate_csr.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_timer.h>
#include <sbi/sbi_trap.h>
```

Include dependency graph for sbi_emulate_csr.c:



Functions


- int sbi_emulate_csr_read (int csr_num, u32 hartid, struct sbi_trap_regs *regs, struct sbi_scratch *scratch, ulong *csr_val)
- int sbi_emulate_csr_write (int csr_num, u32 hartid, struct sbi_trap_regs *regs, struct sbi_scratch *scratch, ulong csr_val)

21.65.1 Function Documentation

21.65.1.1 sbi_emulate_csr_read()

```
int sbi_emulate_csr_read (
    int csr_num,
    u32 hartid,
    struct sbi_trap_regs * regs,
    struct sbi_scratch * scratch,
    ulong * csr_val )
```


Here is the call graph for this function:



Here is the caller graph for this function:



21.65.1.2 sbi_emulate_csr_write()




Here is the caller graph for this function:



21.66 lib/sbi/sbi fifo.c File Reference

```
#include <sbi/riscv_locks.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_fifo.h>
#include <sbi/sbi_string.h>
Include dependency graph for sbi_fifo.c:
```




Functions

- void sbi_fifo_init (struct sbi_fifo *fifo, void *queue_mem, u16 entries, u16 entry_size)
- static bool __sbi_fifo_is_full (struct sbi_fifo *fifo)
- u16 sbi_fifo_avail (struct sbi_fifo *fifo)
- bool sbi fifo is full (struct sbi fifo *fifo)
- static void __sbi_fifo_enqueue (struct sbi_fifo *fifo, void *data)
- static bool __sbi_fifo_is_empty (struct sbi_fifo *fifo)
- bool sbi_fifo_is_empty (struct sbi_fifo *fifo)
- static void <u>__sbi_fifo_reset</u> (struct sbi_fifo *fifo)
- bool sbi_fifo_reset (struct sbi_fifo *fifo)
- int sbi_fifo_inplace_update (struct sbi_fifo *fifo, void *in, int(*fptr)(void *in, void *data))
- int sbi fifo enqueue (struct sbi fifo *fifo, void *data)
- int sbi_fifo_dequeue (struct sbi_fifo *fifo, void *data)

21.66.1 Function Documentation

21.66.1.1 __sbi_fifo_enqueue()


Here is the call graph for this function:



Here is the caller graph for this function:


```
__sbi_fifo_enqueue sbi_tlb_update
```

21.66.1.2 __sbi_fifo_is_empty()



21.66.1.3 __sbi_fifo_is_full()

Here is the caller graph for this function:



21.66.1.4 __sbi_fifo_reset()


Here is the call graph for this function:






21.66.1.5 sbi_fifo_avail()


Here is the call graph for this function:



21.66.1.6 sbi_fifo_dequeue()




Here is the caller graph for this function:



21.66.1.7 sbi_fifo_enqueue()

Here is the call graph for this function:






21.66.1.8 sbi_fifo_init()

Here is the call graph for this function:




Here is the caller graph for this function:



21.66.1.9 sbi_fifo_inplace_update()

Provide a helper function to do inplace update to the fifo. Note: The callback function is called with lock being held.


Do not invoke any other fifo function from callback. Otherwise, it will lead to deadlock. Here is the call graph for this function:



Here is the caller graph for this function:


```
sbi_fifo_inplace_update sbi_tlb_update
```

21.66.1.10 sbi_fifo_is_empty()




21.66.1.11 sbi_fifo_is_full()

Here is the call graph for this function:




21.66.1.12 sbi_fifo_reset()



21.67 lib/sbi/sbi hart.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_barrier.h>
#include <sbi/riscv_encoding.h>
#include <sbi/riscv_fp.h>
#include <sbi/riscv_locks.h>
#include <sbi/sbi_bits.h>
#include <sbi/sbi_console.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_hart.h>
#include <sbi/sbi_platform.h>
Include dependency graph for sbi_hart.c:
```



Macros

#define COLDBOOT_WAIT_BITMAP_SIZE __riscv_xlen

Typedefs

typedef struct sbi_scratch *(* h2s) (ulong hartid)

Functions

- unsigned int sbi_current_hartid ()
- static void mstatus_init (struct sbi_scratch *scratch, u32 hartid)
- static int fp_init (u32 hartid)
- static int delegate_traps (struct sbi_scratch *scratch, u32 hartid)
- void sbi_hart_delegation_dump (struct sbi_scratch *scratch)
- unsigned long log2roundup (unsigned long x)
- void sbi_hart_pmp_dump (struct sbi_scratch *scratch)
- static int pmp init (struct sbi scratch *scratch, u32 hartid)
- int sbi_hart_init (struct sbi_scratch *scratch, u32 hartid, bool cold_boot)
- void * sbi_hart_get_trap_info (struct sbi_scratch *scratch)
- void sbi_hart_set_trap_info (struct sbi_scratch *scratch, void *data)
- void <u>attribute</u> ((noreturn))
- void sbi_hart_mark_available (u32 hartid)
- · void sbi hart unmark available (u32 hartid)
- ulong sbi hart available mask (void)
- struct sbi_scratch * sbi_hart_id_to_scratch (struct sbi_scratch *scratch, u32 hartid)
- void sbi_hart_wait_for_coldboot (struct sbi_scratch *scratch, u32 hartid)
- void sbi_hart_wake_coldboot_harts (struct sbi_scratch *scratch, u32 hartid)

Variables

- static unsigned long trap_info_offset
- static spinlock_t avail_hart_mask_lock = SPIN_LOCK_INITIALIZER
- static volatile unsigned long avail_hart_mask = 0
- static spinlock_t coldboot_lock = SPIN_LOCK_INITIALIZER
- static unsigned long coldboot_done = 0
- static unsigned long coldboot_wait_bitmap = 0

21.67.1 Macro Definition Documentation

```
21.67.1.1 COLDBOOT_WAIT_BITMAP_SIZE
```

```
#define COLDBOOT_WAIT_BITMAP_SIZE ___riscv_xlen
```

21.67.2 Typedef Documentation

21.67.2.1 h2s


```
typedef struct sbi_scratch*(* h2s) (ulong hartid)
```

21.67.3 Function Documentation

```
21.67.3.1 __attribute__()
```


21.67.3.2 delegate_traps()

Here is the caller graph for this function:




21.67.3.3 fp_init()

Here is the caller graph for this function:




21.67.3.4 log2roundup()




21.67.3.5 mstatus_init()


Here is the caller graph for this function:



21.67.3.6 pmp_init()


Here is the call graph for this function:






21.67.3.7 sbi_current_hartid()


Return HART ID of the caller. Here is the caller graph for this function:



21.67.3.8 sbi_hart_available_mask()




Here is the caller graph for this function:



21.67.3.9 sbi_hart_delegation_dump()

Here is the call graph for this function:



Here is the caller graph for this function:

```
sbi_hart_delegation_dump sbi_boot_prints init_coldboot sbi_init
```


21.67.3.10 sbi_hart_get_trap_info()

Here is the caller graph for this function:




21.67.3.11 sbi_hart_id_to_scratch()

Here is the caller graph for this function:




21.67.3.12 sbi_hart_init()

Here is the call graph for this function:




Here is the caller graph for this function:




21.67.3.13 sbi_hart_mark_available()

Here is the call graph for this function:




Here is the caller graph for this function:



21.67.3.14 sbi_hart_pmp_dump()


Here is the call graph for this function:






21.67.3.15 sbi_hart_set_trap_info()


Here is the caller graph for this function:



21.67.3.16 sbi_hart_unmark_available()


Here is the call graph for this function:






21.67.3.17 sbi_hart_wait_for_coldboot()


Here is the call graph for this function:



Here is the caller graph for this function:



21.67.3.18 sbi_hart_wake_coldboot_harts()



Here is the caller graph for this function:



21.67.4 Variable Documentation

21.67.4.1 avail_hart_mask

volatile unsigned long avail_hart_mask = 0 [static]

21.67.4.2 avail_hart_mask_lock

```
spinlock_t avail_hart_mask_lock = SPIN_LOCK_INITIALIZER [static]
```

21.67.4.3 coldboot_done

unsigned long coldboot_done = 0 [static]

21.67.4.4 coldboot_lock

spinlock_t coldboot_lock = SPIN_LOCK_INITIALIZER [static]

21.67.4.5 coldboot_wait_bitmap


unsigned long coldboot_wait_bitmap = 0 [static]

21.67.4.6 trap_info_offset

```
unsigned long trap_info_offset [static]
```

21.68 lib/sbi/sbi_illegal_insn.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_encoding.h>
#include <sbi/sbi_bits.h>
#include <sbi/sbi_emulate_csr.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_illegal_insn.h>
#include <sbi/sbi_trap.h>
#include <sbi/sbi_unpriv.h>
Include dependency graph for sbi illegal insn.c:
```



Typedefs

typedef int(* illegal_insn_func) (ulong insn, u32 hartid, ulong mcause, struct sbi_trap_regs *regs, struct sbi
 _scratch *scratch)

Functions

- static int truly_illegal_insn (ulong insn, u32 hartid, ulong mcause, struct sbi_trap_regs *regs, struct sbi_
 scratch *scratch)
- static int system_opcode_insn (ulong insn, u32 hartid, ulong mcause, struct sbi_trap_regs *regs, struct sbi
 _scratch *scratch)
- int sbi_illegal_insn_handler (u32 hartid, ulong mcause, ulong insn, struct sbi_trap_regs *regs, struct sbi_
 scratch *scratch)

Variables

• static illegal insn func illegal insn table [32]

21.68.1 Typedef Documentation

21.68.1.1 illegal_insn_func


```
typedef int(* illegal_insn_func) (ulong insn, u32 hartid, ulong mcause, struct sbi_trap_regs
*regs, struct sbi_scratch *scratch)
```

21.68.2 Function Documentation

21.68.2.1 sbi_illegal_insn_handler()

```
int sbi_illegal_insn_handler (
          u32 hartid,
          ulong mcause,
          ulong insn,
          struct sbi_trap_regs * regs,
          struct sbi_scratch * scratch )
```

Here is the call graph for this function:






21.68.2.2 system_opcode_insn()

```
static int system_opcode_insn (
          ulong insn,
          u32 hartid,
          ulong mcause,
          struct sbi_trap_regs * regs,
          struct sbi_scratch * scratch ) [static]
```

Here is the call graph for this function:




21.68.2.3 truly_illegal_insn()

```
static int truly_illegal_insn (
          ulong insn,
          u32 hartid,
          ulong mcause,
          struct sbi_trap_regs * regs,
          struct sbi_scratch * scratch ) [static]
```

Here is the call graph for this function:






21.68.3 Variable Documentation

21.68.3.1 illegal_insn_table

```
illegal_insn_func illegal_insn_table[32] [static]
```

21.69 lib/sbi/sbi_init.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_atomic.h>
#include <sbi/sbi_console.h>
#include <sbi/sbi_ecall.h>
#include <sbi/sbi_hart.h>
#include <sbi/sbi_ipi.h>
#include <sbi/sbi_platform.h>
#include <sbi/sbi_system.h>
#include <sbi/sbi_timer.h>
#include <sbi/sbi_ttimer.h>
#include <sbi/sbi_ttlb.h>
#include <sbi/sbi_version.h>
Include dependency graph for sbi_init.c:
```



Macros

• #define BANNER

Functions

- static void sbi_boot_prints (struct sbi_scratch *scratch, u32 hartid)
- static void __noreturn init_coldboot (struct sbi_scratch *scratch, u32 hartid)
- static void __noreturn init_warmboot (struct sbi_scratch *scratch, u32 hartid)
- void noreturn sbi init (struct sbi scratch *scratch)
- unsigned long sbi init count (u32 hartid)
- void __noreturn sbi_exit (struct sbi_scratch *scratch)

Variables

- static unsigned long init_count_offset
- static atomic_t coldboot_lottery = ATOMIC_INITIALIZER(0)

21.69.1 Macro Definition Documentation

21.69.1.1 BANNER


#define BANNER

Value:

21.69.2 Function Documentation

21.69.2.1 init_coldboot()


Here is the call graph for this function:





21.69.2.2 init_warmboot()

Here is the call graph for this function:




Here is the caller graph for this function:



21.69.2.3 sbi_boot_prints()

Here is the call graph for this function:



Here is the caller graph for this function:



21.69.2.4 sbi_exit()

Exit OpenSBI library for current HART and stop HART


The function expects following:

- 1. The 'mscratch' CSR is pointing to sbi_scratch of current HART
- 2. Stack pointer (SP) is setup for current HART


Parameters

scratch pointer to sbi_scratch of current HART

Here is the call graph for this function:



Here is the caller graph for this function:



```
21.69.2.5 sbi_init()
```

Initialize OpenSBI library for current HART and jump to next booting stage.


The function expects following:

- 1. The 'mscratch' CSR is pointing to sbi_scratch of current HART
- 2. Stack pointer (SP) is setup for current HART
- 3. Interrupts are disabled in MSTATUS CSR
- 4. All interrupts are disabled in MIE CSR

Parameters


scratch pointer to sbi_scratch of current HART

Here is the call graph for this function:



21.69.2.6 sbi_init_count()

Here is the call graph for this function:



21.69.3 Variable Documentation

21.69.3.1 coldboot_lottery


```
atomic_t coldboot_lottery = ATOMIC_INITIALIZER(0) [static]
```

21.69.3.2 init_count_offset

unsigned long init_count_offset [static]

21.70 lib/sbi/sbi_ipi.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_atomic.h>
#include <sbi/riscv_barrier.h>
#include <sbi/sbi_bitops.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_hart.h>
#include <sbi/sbi_init.h>
#include <sbi/sbi_ipi.h>
#include <sbi/sbi_platform.h>
Include dependency graph for sbi_ipi.c:
```



Functions

- static int sbi_ipi_send (struct sbi_scratch *scratch, u32 remote_hartid, u32 event, void *data)
- int sbi_ipi_send_many (struct sbi_scratch *scratch, ulong hmask, ulong hbase, u32 event, void *data)
- int sbi_ipi_event_create (const struct sbi_ipi_event_ops *ops)
- void sbi_ipi_event_destroy (u32 event)
- static void sbi_ipi_process_smode (struct sbi_scratch *scratch)
- int sbi ipi send smode (struct sbi scratch *scratch, ulong hmask, ulong hbase)
- void sbi ipi clear smode (struct sbi scratch *scratch)
- static void sbi_ipi_process_halt (struct sbi_scratch *scratch)
- int sbi_ipi_send_halt (struct sbi_scratch *scratch, ulong hmask, ulong hbase)
- void sbi ipi process (struct sbi scratch *scratch)
- int sbi_ipi_init (struct sbi_scratch *scratch, bool cold_boot)
- void sbi_ipi_exit (struct sbi_scratch *scratch)

Variables

- · static unsigned long ipi_data_off
- static const struct sbi_ipi_event_ops * ipi_ops_array [SBI_IPI_EVENT_MAX]
- · static struct sbi ipi event ops ipi smode ops
- static u32 ipi_smode_event = SBI_IPI_EVENT_MAX
- static struct sbi_ipi_event_ops ipi_halt_ops
- static u32 ipi_halt_event = SBI_IPI_EVENT_MAX

21.70.1 Function Documentation


```
21.70.1.1 sbi_ipi_clear_smode()
```

```
sbi_ipi_clear_smode sbi_ecall_legacy_handler
```

21.70.1.2 sbi_ipi_event_create()


```
int sbi_ipi_event_create ( {\tt const\ struct\ sbi\_ipi\_event\_ops\ *\ ops\ )}
```

Here is the caller graph for this function:




21.70.1.3 sbi_ipi_event_destroy()

21.70.1.4 sbi_ipi_exit()





Here is the caller graph for this function:



21.70.1.5 sbi_ipi_init()


Here is the call graph for this function:






21.70.1.6 sbi_ipi_process()

Here is the call graph for this function:




Here is the caller graph for this function:




21.70.1.7 sbi_ipi_process_halt()

Here is the call graph for this function:




21.70.1.8 sbi_ipi_process_smode()

21.70.1.9 sbi_ipi_send()





Here is the caller graph for this function:



21.70.1.10 sbi_ipi_send_halt()


Here is the call graph for this function:






21.70.1.11 sbi_ipi_send_many()

As this function only handlers scalar values of hart mask, it must be set to all online harts if the intention is to send IPIs to all the harts. If hmask is zero, no IPIs will be sent. FIXME: This check is valid only ULONG size. This is okay for now as available hart mask can support upto ULONG size only. Here is the call graph for this function:




Here is the caller graph for this function:




21.70.1.12 sbi_ipi_send_smode()

Here is the call graph for this function:



Here is the caller graph for this function:



21.70.2 Variable Documentation

21.70.2.1 ipi_data_off

unsigned long ipi_data_off [static]

21.70.2.2 ipi_halt_event

u32 ipi_halt_event = SBI_IPI_EVENT_MAX [static]

```
21.70.2.3 ipi_halt_ops
```

```
struct sbi_ipi_event_ops ipi_halt_ops [static]
```

Initial value:

```
= {
    .name = "IPI_HALT",
    .process = sbi_ipi_process_halt,
}
```

21.70.2.4 ipi_ops_array

```
const struct sbi_ipi_event_ops* ipi_ops_array[SBI_IPI_EVENT_MAX] [static]
```

21.70.2.5 ipi_smode_event

```
u32 ipi_smode_event = SBI_IPI_EVENT_MAX [static]
```

21.70.2.6 ipi_smode_ops

```
struct sbi_ipi_event_ops ipi_smode_ops [static]
```


Initial value:

```
= {
    .name = "IPI_SMODE",
    .process = sbi_ipi_process_smode,
}
```

21.71 lib/sbi/sbi_misaligned_ldst.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_encoding.h>
#include <sbi/riscv_fp.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_misaligned_ldst.h>
#include <sbi/sbi_trap.h>
#include <sbi/sbi_unpriv.h>
```

Include dependency graph for sbi_misaligned_ldst.c:



Functions


- int sbi_misaligned_load_handler (u32 hartid, ulong mcause, ulong addr, ulong tval2, ulong tinst, struct sbi ← _trap_regs *regs, struct sbi_scratch *scratch)
- int sbi_misaligned_store_handler (u32 hartid, ulong mcause, ulong addr, ulong tval2, ulong tinst, struct sbi ← _trap_regs *regs, struct sbi_scratch *scratch)

21.71.1 Function Documentation


21.71.1.1 sbi_misaligned_load_handler()

```
int sbi_misaligned_load_handler (
             u32 hartid.
             ulong mcause,
             ulong addr,
             ulong tval2,
             ulong tinst,
             struct sbi_trap_regs * regs,
             struct sbi_scratch * scratch )
```

Here is the call graph for this function:



Here is the caller graph for this function:




21.71.1.2 sbi_misaligned_store_handler()

```
int sbi_misaligned_store_handler (
          u32 hartid,
          ulong mcause,
          ulong addr,
          ulong tval2,
          ulong tinst,
          struct sbi_trap_regs * regs,
          struct sbi_scratch * scratch )
```




Here is the caller graph for this function:



21.72 lib/sbi/sbi_scratch.c File Reference

```
#include <sbi/riscv_locks.h>
#include <sbi/sbi_hart.h>
#include <sbi/sbi_platform.h>
#include <sbi/sbi_scratch.h>
#include <sbi/sbi_string.h>
Include dependency graph for sbi_scratch.c:
```



Functions

- unsigned long sbi_scratch_alloc_offset (unsigned long size, const char *owner)
- void sbi_scratch_free_offset (unsigned long offset)

Variables

- static spinlock_t extra_lock = SPIN_LOCK_INITIALIZER
- static unsigned long extra_offset = SBI_SCRATCH_EXTRA_SPACE_OFFSET

21.72.1 Function Documentation

21.72.1.1 sbi_scratch_alloc_offset()


```
unsigned long sbi_scratch_alloc_offset (
          unsigned long size,
          const char * owner )
```


Allocate from extra space in sbi_scratch

Returns

zero on failure and non-zero (>= SBI_SCRATCH_EXTRA_SPACE_OFFSET) on success

Here is the call graph for this function:






21.72.1.2 sbi_scratch_free_offset()

```
void sbi_scratch_free_offset (
          unsigned long offset )
```

Free-up extra space in sbi_scratch Here is the caller graph for this function:



21.72.2 Variable Documentation

```
21.72.2.1 extra_lock
```


```
spinlock_t extra_lock = SPIN_LOCK_INITIALIZER [static]
```

21.72.2.2 extra_offset

```
unsigned long extra_offset = SBI_SCRATCH_EXTRA_SPACE_OFFSET [static]
```

21.73 lib/sbi/sbi_string.c File Reference

#include <sbi/sbi_string.h>
Include dependency graph for sbi_string.c:



Functions


```
int sbi_strcmp (const char *a, const char *b)
size_t sbi_strlen (const char *str)
size_t sbi_strnlen (const char *str, size_t count)
char *sbi_strcpy (char *dest, const char *src)
char * sbi_strcpy (char *dest, const char *src, size_t count)
char * sbi_strchr (const char *s, int c)
char * sbi_strchr (const char *s, int c)
void * sbi_memset (void *s, int c, size_t count)
void * sbi_memcpy (void *dest, const void *src, size_t count)
void * sbi_memcpy (void *dest, const void *src, size_t count)
int sbi_memcpp (const void *s1, const void *s2, size_t count)
void * sbi_memchr (const void *s, int c, size_t count)
```

21.73.1 Function Documentation

21.73.1.1 sbi_memchr()

21.73.1.2 sbi_memcmp()

21.73.1.3 sbi_memcpy()




21.73.1.4 sbi_memmove()

21.73.1.5 sbi_memset()

```
\begin{tabular}{ll} void* sbi\_memset ( & void* s, & \\ & int c, & \\ & size\_t count ) \end{tabular}
```

Here is the caller graph for this function:



21.73.1.6 sbi_strchr()

```
\label{eq:char} \begin{array}{c} \text{char* sbi\_strchr (} \\ & \text{const char * $s$,} \\ & \text{int $c$ )} \end{array}
```

21.73.1.7 sbi_strcmp()

21.73.1.8 sbi_strcpy()

21.73.1.9 sbi_strlen()

Here is the caller graph for this function:



21.73.1.10 sbi_strncpy()

21.73.1.11 sbi_strnlen()

21.73.1.12 sbi_strrchr()

```
char* sbi_strrchr (  {\rm const\ char}\ *\ s, \\ {\rm int\ } c\ )
```


Here is the call graph for this function:



21.74 lib/sbi/sbi_system.c File Reference

```
#include <sbi/sbi_hart.h>
#include <sbi/sbi_platform.h>
#include <sbi/sbi_system.h>
#include <sbi/sbi_ipi.h>
#include <sbi/sbi_init.h>
```

Include dependency graph for sbi_system.c:



Functions

- int sbi_system_early_init (struct sbi_scratch *scratch, bool cold_boot)
- int sbi_system_final_init (struct sbi_scratch *scratch, bool cold_boot)
- void sbi_system_early_exit (struct sbi_scratch *scratch)
- void sbi_system_final_exit (struct sbi_scratch *scratch)
- void __noreturn sbi_system_reboot (struct sbi_scratch *scratch, u32 type)
- void __noreturn sbi_system_shutdown (struct sbi_scratch *scratch, u32 type)

21.74.1 Function Documentation

21.74.1.1 sbi_system_early_exit()


Here is the call graph for this function:

```
sbi_system_early_exit _____ sbi_platform_early_exit
```

21.74.1.2 sbi_system_early_init()

Here is the call graph for this function:





21.74.1.3 sbi_system_final_exit()


Here is the call graph for this function:



21.74.1.4 sbi_system_final_init()


Here is the call graph for this function:






21.74.1.5 sbi_system_reboot()

Here is the call graph for this function:



21.74.1.6 sbi_system_shutdown()




Here is the caller graph for this function:



21.75 lib/sbi/sbi_timer.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_encoding.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_platform.h>
#include <sbi/sbi_timer.h>
Include dependency graph for sbi_timer.c:
```



Functions

- u64 get ticks (void)
- u64 sbi timer value (struct sbi scratch *scratch)
- u64 sbi_timer_virt_value (struct sbi_scratch *scratch)
- u64 sbi_timer_get_delta (struct sbi_scratch *scratch)
- void sbi_timer_set_delta (struct sbi_scratch *scratch, ulong delta)
- void sbi_timer_set_delta_upper (struct sbi_scratch *scratch, ulong delta_upper)
- void sbi_timer_event_start (struct sbi_scratch *scratch, u64 next_event)
- void sbi_timer_process (struct sbi_scratch *scratch)
- int sbi timer init (struct sbi scratch *scratch, bool cold boot)
- void sbi_timer_exit (struct sbi_scratch *scratch)

Variables

• static unsigned long time_delta_off

21.75.1 Function Documentation


```
21.75.1.1 get_ticks()
u64 get_ticks (
void )
```


Here is the caller graph for this function:



21.75.1.2 sbi_timer_event_start()


Here is the call graph for this function:






21.75.1.3 sbi_timer_exit()


Here is the call graph for this function:



Here is the caller graph for this function:




21.75.1.4 sbi_timer_get_delta()




21.75.1.5 sbi_timer_init()

Here is the call graph for this function:



Here is the caller graph for this function:



21.75.1.6 sbi_timer_process()



21.75.1.7 sbi_timer_set_delta()

Here is the caller graph for this function:


```
sbi_timer_set_delta sbi_emulate_csr_write system_opcode_insn
```

21.75.1.8 sbi_timer_set_delta_upper()


Here is the caller graph for this function:

```
sbi_timer_set_delta _____sbi_emulate_csr_write _____system_opcode_insn
```

21.75.1.9 sbi_timer_value()




Here is the caller graph for this function:



21.75.1.10 sbi_timer_virt_value()

Here is the call graph for this function:



Here is the caller graph for this function:




21.75.2 Variable Documentation

21.75.2.1 time_delta_off

unsigned long time_delta_off [static]

21.76 lib/sbi/sbi tlb.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_atomic.h>
#include <sbi/riscv_barrier.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_fifo.h>
#include <sbi/sbi_hart.h>
#include <sbi/sbi_ipi.h>
#include <sbi/sbi_scratch.h>
#include <sbi/sbi_tlb.h>
#include <sbi/sbi_tlb.h>
#include <sbi/sbi_string.h>
#include <sbi/sbi_string.h>
#include <sbi/sbi_platform.h>
Include dependency graph for sbi tlb.c:
```



Functions

- static void sbi_tlb_flush_all (void)
- static void sbi_tlb_hfence_vvma (struct sbi_tlb_info *tinfo)
- static void sbi_tlb_hfence_gvma (struct sbi_tlb_info *tinfo)
- static void sbi_tlb_sfence_vma (struct sbi_tlb_info *tinfo)
- static void sbi tlb hfence vvma asid (struct sbi tlb info *tinfo)
- static void sbi_tlb_hfence_gvma_vmid (struct sbi_tlb_info *tinfo)
- static void sbi_tlb_sfence_vma_asid (struct sbi_tlb_info *tinfo)
- static void sbi tlb local flush (struct sbi tlb info *tinfo)
- static void sbi_tlb_entry_process (struct sbi_scratch *scratch, struct sbi_tlb_info *tinfo)
- static void sbi_tlb_process_count (struct sbi_scratch *scratch, int count)
- static void sbi tlb process (struct sbi scratch *scratch)
- static void sbi tlb sync (struct sbi scratch *scratch)
- static int sbi tlb range check (struct sbi tlb info *curr, struct sbi tlb info *next)
- static int sbi_tlb_update_cb (void *in, void *data)
- static int sbi_tlb_update (struct sbi_scratch *scratch, struct sbi_scratch *remote_scratch, u32 remote_hartid, void *data)
- int sbi_tlb_request (struct sbi_scratch *scratch, ulong hmask, ulong hbase, struct sbi_tlb_info *tinfo)
- int sbi_tlb_init (struct sbi_scratch *scratch, bool cold_boot)


Variables

- static unsigned long tlb sync off
- · static unsigned long tlb fifo off
- · static unsigned long tlb_fifo_mem_off
- · static unsigned long tlb range flush limit
- static struct sbi_ipi_event_ops tlb_ops
- static u32 tlb_event = SBI_IPI_EVENT_MAX

21.76.1 Function Documentation


21.76.1.1 __sbi_tlb_range_check()


Here is the caller graph for this function:



21.76.1.2 sbi_tlb_entry_process()


Here is the call graph for this function:






21.76.1.3 sbi_tlb_flush_all()

Here is the caller graph for this function:



21.76.1.4 sbi_tlb_hfence_gvma()


Here is the call graph for this function:





21.76.1.5 sbi_tlb_hfence_gvma_vmid()


Here is the call graph for this function:



Here is the caller graph for this function:



21.76.1.6 sbi_tlb_hfence_vvma()




Here is the caller graph for this function:



21.76.1.7 sbi_tlb_hfence_vvma_asid()


Here is the call graph for this function:






21.76.1.8 sbi_tlb_init()

Here is the call graph for this function:




Here is the caller graph for this function:




21.76.1.9 sbi_tlb_local_flush()


Here is the call graph for this function:



Here is the caller graph for this function:




21.76.1.10 sbi_tlb_process()




21.76.1.11 sbi_tlb_process_count()

Here is the call graph for this function:




Here is the caller graph for this function:




21.76.1.12 sbi_tlb_request()

Here is the call graph for this function:



Here is the caller graph for this function:



21.76.1.13 sbi_tlb_sfence_vma()




Here is the caller graph for this function:



21.76.1.14 sbi_tlb_sfence_vma_asid()

Here is the call graph for this function:




Here is the caller graph for this function:




21.76.1.15 sbi_tlb_sync()

Here is the call graph for this function:



21.76.1.16 sbi_tlb_update()

For now, Busy loop until there is space in the fifo. There may be case where target hart is also enqueue in source hart's fifo. Both hart may busy loop leading to a deadlock. TODO: Introduce a wait/wakeup event mechanism to handle this properly. Here is the call graph for this function:



21.76.1.17 sbi_tlb_update_cb()

Call back to decide if an inplace fifo update is required or next entry can can be skipped. Here are the different cases that are being handled.

Case1: if next flush request range lies within one of the existing entry, skip the next entry. Case2: if flush request range in current fifo entry lies within next flush request, update the current entry.

Note: We can not issue a fifo reset anymore if a complete vma flush is requested. This is because we are queueing FENCE. I requests as well now. To ease up the pressure in enqueue/fifo sync path, try to dequeue 1 element before continuing the while loop. This method is preferred over wfi/ipi because of MMIO cost involved in later method. Here is the call graph for this function:



Here is the caller graph for this function:



21.76.2 Variable Documentation

21.76.2.1 tlb_event

```
u32 tlb_event = SBI_IPI_EVENT_MAX [static]
```

21.76.2.2 tlb_fifo_mem_off

unsigned long tlb_fifo_mem_off [static]

21.76.2.3 tlb_fifo_off

```
unsigned long tlb_fifo_off [static]
```

21.76.2.4 tlb_ops

struct sbi_ipi_event_ops tlb_ops [static]

Initial value:

```
= {
    .name = "IPI_TLB",
    .update = sbi_tlb_update,
    .sync = sbi_tlb_sync,
    .process = sbi_tlb_process,
```

21.76.2.5 tlb_range_flush_limit


```
unsigned long tlb_range_flush_limit [static]
```

21.76.2.6 tlb_sync_off

unsigned long tlb_sync_off [static]

21.77 lib/sbi/sbi_trap.c File Reference

```
#include <sbi/riscv_asm.h>
#include <sbi/riscv_encoding.h>
#include <sbi/sbi_console.h>
#include <sbi/sbi_ecall.h>
#include <sbi/sbi_error.h>
#include <sbi/sbi_hart.h>
#include <sbi/sbi_illegal_insn.h>
#include <sbi/sbi_ipi.h>
#include <sbi/sbi_misaligned_ldst.h>
#include <sbi/sbi_timer.h>
#include <sbi/sbi_trap.h>
Include dependency graph for sbi_trap.c:
```




Functions

- static void __noreturn sbi_trap_error (const char *msg, int rc, u32 hartid, ulong mcause, ulong mtval, ulong mtval2, ulong mtinst, struct sbi_trap_regs *regs)
- int sbi_trap_redirect (struct sbi_trap_regs *regs, struct sbi_trap_info *trap, struct sbi_scratch *scratch)
- void sbi_trap_handler (struct sbi_trap_regs *regs, struct sbi_scratch *scratch)

21.77.1 Function Documentation

21.77.1.1 sbi_trap_error()

Here is the call graph for this function:





21.77.1.2 sbi_trap_handler()

Handle trap/interrupt


This function is called by firmware linked to OpenSBI library for handling trap/interrupt. It expects the following:

- 1. The 'mscratch' CSR is pointing to sbi_scratch of current HART
- 2. The 'mcause' CSR is having exception/interrupt cause
- 3. The 'mtval' CSR is having additional trap information
- 4. The 'mtval2' CSR is having additional trap information
- 5. The 'mtinst' CSR is having decoded trap instruction
- 6. Stack pointer (SP) is setup for current HART
- 7. Interrupts are disabled in MSTATUS CSR

Parameters

regs	pointer to register state
scratch	pointer to sbi_scratch of current HART

Here is the call graph for this function:



21.77.1.3 sbi_trap_redirect()

```
struct sbi_trap_info * trap,
struct sbi_scratch * scratch )
```

Redirect trap to lower privledge mode (S-mode or U-mode)


Parameters

regs	pointer to register state
trap	pointer to trap details
scratch	pointer to sbi_scratch of current HART

Returns

0 on success and negative error code on failure


Here is the caller graph for this function:



21.78 lib/sbi/sbi_unpriv.c File Reference

```
#include <sbi/riscv_encoding.h>
#include <sbi/sbi_bits.h>
#include <sbi/sbi_hart.h>
#include <sbi/sbi_scratch.h>
#include <sbi/sbi_trap.h>
#include <sbi/sbi_unpriv.h>
```

Include dependency graph for sbi_unpriv.c:



Macros

- #define DEFINE_UNPRIVILEGED_LOAD_FUNCTION(type, insn)
- #define DEFINE_UNPRIVILEGED_STORE_FUNCTION(type, insn)

Functions

- u64 sbi_load_u64 (const u64 *addr, struct sbi_scratch *scratch, struct sbi_trap_info *trap)
- void sbi_store_u64 (u64 *addr, u64 val, struct sbi_scratch *scratch, struct sbi_trap_info *trap)
- ulong sbi_get_insn (ulong mepc, struct sbi_scratch *scratch, struct sbi_trap_info *trap)

21.78.1 Macro Definition Documentation

21.78.1.1 DEFINE_UNPRIVILEGED_LOAD_FUNCTION

Value:

```
sbi_hart_set_trap_info(scratch, trap);
asm volatile(
   "csrrs %0, " STR(CSR_MSTATUS) ", %3\n"
   ".option push\n"
   ".option norvc\n"
   #insn " %1, %2\n"
   ".option pop\n"
   "csrw " STR(CSR_MSTATUS) ", %0"
   : "+&r"(_mstatus), "=&r"(val)
   : "m"(*addr), "r"(MSTATUS_MPRV));
sbi_hart_set_trap_info(scratch, NULL);
return val;
}
```

21.78.1.2 DEFINE_UNPRIVILEGED_STORE_FUNCTION

```
#define DEFINE_UNPRIVILEGED_STORE_FUNCTION( type, \\ insn \ )
```

Value:


21.78.2 Function Documentation

21.78.2.1 sbi_get_insn()

Here is the call graph for this function:



Here is the caller graph for this function:



21.78.2.2 sbi_load_u64()


21.78.2.3 sbi_store_u64()

```
void sbi_store_u64 (
          u64 * addr,
          u64 val,
          struct sbi_scratch * scratch,
          struct sbi_trap_info * trap )
```

21.79 lib/utils/irqchip/plic.c File Reference

```
#include <sbi/riscv_io.h>
#include <sbi/riscv_encoding.h>
#include <sbi/sbi_console.h>
#include <sbi/sbi_string.h>
#include <sbi_utils/irqchip/plic.h>
#include <libfdt.h>
#include <fdt.h>
```

Include dependency graph for plic.c:



Macros

- #define PLIC_PRIORITY_BASE 0x0
- #define PLIC PENDING BASE 0x1000
- #define PLIC ENABLE BASE 0x2000
- #define PLIC_ENABLE_STRIDE 0x80
- #define PLIC_CONTEXT_BASE 0x200000
- #define PLIC_CONTEXT_STRIDE 0x1000

Functions

- static void plic_set_priority (u32 source, u32 val)
- void plic_set_thresh (u32 cntxid, u32 val)
- void plic_set_ie (u32 cntxid, u32 word_index, u32 val)
- void plic_fdt_fixup (void *fdt, const char *compat)
- int plic_warm_irqchip_init (u32 target_hart, int m_cntx_id, int s_cntx_id)
- int plic_cold_irqchip_init (unsigned long base, u32 num_sources, u32 hart_count)

Variables

- static u32 plic_hart_count
- static u32 plic_num_sources
- static volatile void * plic_base

21.79.1 Macro Definition Documentation

21.79.1.1 PLIC_CONTEXT_BASE

#define PLIC_CONTEXT_BASE 0x200000

21.79.1.2 PLIC_CONTEXT_STRIDE

#define PLIC_CONTEXT_STRIDE 0x1000

21.79.1.3 PLIC_ENABLE_BASE

#define PLIC_ENABLE_BASE 0x2000

21.79.1.4 PLIC_ENABLE_STRIDE

#define PLIC_ENABLE_STRIDE 0x80

21.79.1.5 PLIC_PENDING_BASE

#define PLIC_PENDING_BASE 0x1000

21.79.1.6 PLIC_PRIORITY_BASE

#define PLIC_PRIORITY_BASE 0x0

21.79.2 Function Documentation

21.79.2.1 plic_cold_irqchip_init()


```
int plic_cold_irqchip_init (
          unsigned long base,
          u32 num_sources,
          u32 hart_count )
```

Here is the call graph for this function:



21.79.2.2 plic_fdt_fixup()

Here is the call graph for this function:




21.79.2.3 plic_set_ie()

Here is the caller graph for this function:



21.79.2.4 plic_set_priority()

Here is the caller graph for this function:




21.79.2.5 plic_set_thresh()



21.79.2.6 plic_warm_irqchip_init()

Here is the call graph for this function:



21.79.3 Variable Documentation

21.79.3.1 plic_base

```
volatile void* plic_base [static]
```

21.79.3.2 plic_hart_count


```
u32 plic_hart_count [static]
```

21.79.3.3 plic_num_sources

```
u32 plic_num_sources [static]
```

21.80 lib/utils/libfdt/fdt.c File Reference

```
#include "libfdt_env.h"
#include <fdt.h>
#include <libfdt.h>
#include "libfdt_internal.h"
Include dependency graph for fdt.c:
```



Functions

- int fdt_ro_probe_ (const void *fdt)
- static int check_off_ (uint32_t hdrsize, uint32_t totalsize, uint32_t off)
- static int check_block_ (uint32_t hdrsize, uint32_t totalsize, uint32_t base, uint32_t size)
- size_t fdt_header_size_ (uint32_t version)
- int fdt_check_header (const void *fdt)
- const void * fdt_offset_ptr (const void *fdt, int offset, unsigned int len)
- uint32_t fdt_next_tag (const void *fdt, int startoffset, int *nextoffset)
- int fdt check node offset (const void *fdt, int offset)
- int fdt_check_prop_offset_ (const void *fdt, int offset)
- int fdt_next_node (const void *fdt, int offset, int *depth)
- int fdt_first_subnode (const void *fdt, int offset)
- int fdt next subnode (const void *fdt, int offset)
- const char * fdt_find_string_ (const char *strtab, int tabsize, const char *s)
- int fdt_move (const void *fdt, void *buf, int bufsize)


21.80.1 Function Documentation

21.80.1.1 check_block_()


Here is the call graph for this function:



Here is the caller graph for this function:



21.80.1.2 check_off_()




21.80.1.3 fdt_check_header()

fdt_check_header - sanity check a device tree header


: pointer to data which might be a flattened device tree

fdt_check_header() checks that the given buffer contains what appears to be a flattened device tree, and that the header contains valid information (to the extent that can be determined from the header alone).

returns: 0, if the buffer appears to contain a valid device tree -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_TRUNCATED, standard meanings, as above Here is the call graph for this function:




Here is the caller graph for this function:




21.80.1.4 fdt_check_node_offset_()


Here is the call graph for this function:




Here is the caller graph for this function:



21.80.1.5 fdt_check_prop_offset_()




Here is the caller graph for this function:



21.80.1.6 fdt_find_string_()

Here is the caller graph for this function:



21.80.1.7 fdt_first_subnode()

fdt_first_subnode() - get offset of first direct subnode

: FDT blob : Offset of node to check


Returns

offset of first subnode, or -FDT_ERR_NOTFOUND if there is none

Here is the call graph for this function:




Here is the caller graph for this function:



21.80.1.8 fdt_header_size_()

fdt_header_size - return the size of the tree's header : pointer to a flattened device tree Here is the caller graph for this function:




21.80.1.9 fdt_move()


fdt_move - move a device tree around in memory : pointer to the device tree to move : pointer to memory where the device is to be moved : size of the memory space at buf

fdt_move() relocates, if possible, the device tree blob located at fdt to the buffer at buf of size bufsize. The buffer may overlap with the existing device tree blob at fdt. Therefore, fdt_move(fdt, fdt, fdt_totalsize(fdt)) should always succeed.


returns: 0, on success -FDT_ERR_NOSPACE, bufsize is insufficient to contain the device tree -FDT_ERR_BAD ← MAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, standard meanings Here is the caller graph for this function:



21.80.1.10 fdt_next_node()



Here is the caller graph for this function:



21.80.1.11 fdt_next_subnode()

fdt_next_subnode() - get offset of next direct subnode

After first calling fdt_first_subnode(), call this function repeatedly to get direct subnodes of a parent node.


: FDT blob : Offset of previous subnode

Returns

offset of next subnode, or -FDT_ERR_NOTFOUND if there are no more subnodes




Here is the caller graph for this function:



21.80.1.12 fdt_next_tag()




Here is the caller graph for this function:




21.80.1.13 fdt_offset_ptr()



Here is the caller graph for this function:



21.80.1.14 fdt_ro_probe_()



21.81 lib/utils/libfdt/fdt.h File Reference

This graph shows which files directly or indirectly include this file:



Data Structures

- struct fdt header
- · struct fdt_reserve_entry
- · struct fdt node header
- struct fdt_property

Macros

- #define FDT_MAGIC 0xd00dfeed /* 4: version, 4: total size */
- #define FDT_TAGSIZE sizeof(fdt32_t)
- #define FDT_BEGIN_NODE 0x1 /* Start node: full name */
- #define FDT_END_NODE 0x2 /* End node */
- #define FDT_PROP
- #define FDT NOP 0x4 /* nop */
- #define FDT_END 0x9
- #define FDT_V1_SIZE (7*sizeof(fdt32_t))
- #define FDT_V2_SIZE (FDT_V1_SIZE + sizeof(fdt32_t))
- #define FDT_V3_SIZE (FDT_V2_SIZE + sizeof(fdt32_t))
- #define FDT_V16_SIZE FDT_V3_SIZE
- #define FDT_V17_SIZE (FDT_V16_SIZE + sizeof(fdt32_t))

21.81.1 Macro Definition Documentation

21.81.1.1 FDT_BEGIN_NODE

```
#define FDT_BEGIN_NODE 0x1 /* Start node: full name */
```

21.81.1.2 FDT_END

#define FDT_END 0x9

```
21.81.1.3 FDT_END_NODE
#define FDT_END_NODE 0x2 /* End node */
21.81.1.4 FDT_MAGIC
\#define FDT_MAGIC 0xd00dfeed /* 4: version, 4: total size */
21.81.1.5 FDT_NOP
#define FDT_NOP 0x4 /* nop */
21.81.1.6 FDT_PROP
#define FDT_PROP
Value:
0x3 /* Property: name off, size, content */
21.81.1.7 FDT_TAGSIZE
#define FDT_TAGSIZE sizeof(fdt32_t)
21.81.1.8 FDT_V16_SIZE
#define FDT_V16_SIZE FDT_V3_SIZE
21.81.1.9 FDT_V17_SIZE
#define FDT_V17_SIZE (FDT_V16_SIZE + sizeof(fdt32_t))
```

```
21.81.1.10 FDT_V1_SIZE
```

```
#define FDT_V1_SIZE (7*sizeof(fdt32_t))
```

21.81.1.11 FDT_V2_SIZE


```
#define FDT_V2_SIZE (FDT_V1_SIZE + sizeof(fdt32_t))
```

21.81.1.12 FDT_V3_SIZE

```
#define FDT_V3_SIZE (FDT_V2_SIZE + sizeof(fdt32_t))
```

21.82 lib/utils/libfdt/fdt_addresses.c File Reference

```
#include "libfdt_env.h"
#include <fdt.h>
#include <libfdt.h>
#include "libfdt_internal.h"
Include dependency graph for fdt_addresses.c:
```



Functions

- static int fdt_cells (const void *fdt, int nodeoffset, const char *name)
- int fdt_address_cells (const void *fdt, int nodeoffset)
- int fdt_size_cells (const void *fdt, int nodeoffset)

21.82.1 Function Documentation

21.82.1.1 fdt_address_cells()

fdt_address_cells - retrieve address size for a bus represented in the tree : pointer to the device tree blob : offset of the node to find the address size for

When the node has a valid #address-cells property, returns its value.


returns: $0 \le n < \text{FDT_MAX_NCELLS}$, on success 2, if the node has no #address-cells property -FDT_ERR_BA \leftarrow DNCELLS, if the node has a badly formatted or invalid #address-cells property -FDT_ERR_BADMAGIC, -FDT_E \leftarrow RR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:



21.82.1.2 fdt_cells()



Here is the caller graph for this function:



21.82.1.3 fdt_size_cells()

fdt_size_cells - retrieve address range size for a bus represented in the tree : pointer to the device tree blob : offset of the node to find the address range size for

When the node has a valid #size-cells property, returns its value.


returns: 0 <= n < FDT_MAX_NCELLS, on success 1, if the node has no #size-cells property -FDT_ERR_B↔ ADNCELLS, if the node has a badly formatted or invalid #size-cells property -FDT_ERR_BADMAGIC, -FDT_E↔ RR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:



21.83 lib/utils/libfdt/fdt_empty_tree.c File Reference

```
#include "libfdt_env.h"
#include <fdt.h>
#include <libfdt.h>
```

```
#include "libfdt_internal.h"
Include dependency graph for fdt_empty_tree.c:
```




Functions

• int fdt_create_empty_tree (void *buf, int bufsize)

21.83.1 Function Documentation


21.83.1.1 fdt_create_empty_tree()

Here is the call graph for this function:



21.84 lib/utils/libfdt/fdt_overlay.c File Reference

```
#include "libfdt_env.h"
#include <fdt.h>
#include <libfdt.h>
#include "libfdt_internal.h"
Include dependency graph for fdt_overlay.c:
```



Functions

• static uint32_t overlay_get_target_phandle (const void *fdto, int fragment)

static int overlay_get_target (const void *fdt, const void *fdto, int fragment, char const **pathp)

: Name of the property to modify (phandle or linux,phandle)

overlay_phandle_add_offset - Increases a phandle by an offset : Base device tree blob : Device tree overlay blob

: offset to apply

overlay_phandle_add_offset() increments a node phandle by a given offset.

returns: 0 on success. Negative error code on error

- static int overlay_phandle_add_offset (void *fdt, int node, const char *name, uint32_t delta)
- static int overlay adjust node phandles (void *fdto, int node, uint32 t delta)
- static int overlay adjust local phandles (void *fdto, uint32 t delta)
- static int overlay update local node references (void *fdto, int tree node, int fixup node, uint32 t delta)
- static int overlay update local references (void *fdto, uint32 t delta)

: Name of the property holding the phandle reference in the overlay

overlay_fixup_one_phandle - Set an overlay phandle to the base one : Base Device Tree blob : Device tree overlay blob : Node offset of the symbols node in the base device tree : Path to a node holding a phandle in the overlay : number of path characters to consider

: number of name characters to consider : Offset within the overlay property where the phandle is stored : Label of the node referenced by the phandle

overlay_fixup_one_phandle() resolves an overlay phandle pointing to a node in the base device tree.

This is part of the device tree overlay application process, when you want all the phandles in the overlay to point to the actual base dt nodes.

returns: 0 on success Negative error code on failure

- static int overlay_fixup_one_phandle (void *fdt, void *fdto, int symbols_off, const char *path, uint32_t path_len, const char *name, uint32_t name_len, int poffset, const char *label)
- static int overlay_fixup_phandle (void *fdt, void *fdto, int symbols_off, int property)
- static int overlay_fixup_phandles (void *fdt, void *fdto)
- static int overlay_apply_node (void *fdt, int target, void *fdto, int node)
- static int overlay_merge (void *fdt, void *fdto)
- static int get_path_len (const void *fdt, int nodeoffset)
- static int overlay_symbol_update (void *fdt, void *fdto)
- int fdt_overlay_apply (void *fdt, void *fdto)

21.84.1 Function Documentation

21.84.1.1 fdt_overlay_apply()


```
int fdt_overlay_apply (
     void * fdt,
     void * fdto )
```

fdt_overlay_apply - Applies a DT overlay on a base DT : pointer to the base device tree blob : pointer to the device tree overlay blob

fdt overlay apply() will apply the given device tree overlay on the given base device tree.

Expect the base device tree to be modified, even if the function returns an error.

returns: 0, on success -FDT_ERR_NOSPACE, there's not enough space in the base device tree -FDT_ERR_← NOTFOUND, the overlay points to some inexistant nodes or properties in the base DT -FDT_ERR_BADPHAN← DLE, -FDT_ERR_BADOVERLAY, -FDT_ERR_NOPHANDLES, -FDT_ERR_INTERNAL, -FDT_ERR_BADLAYOUT, -FDT_ERR_BADMAGIC, -FDT_ERR_BADOFFSET, -FDT_ERR_BADPATH, -FDT_ERR_BADVERSION, -FDT_← ERR_BADSTRUCTURE, -FDT_ERR_BADSTATE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:



21.84.1.2 get_path_len()

Here is the call graph for this function:






21.84.1.3 overlay_adjust_local_phandles()


overlay_adjust_local_phandles - Adjust the phandles of a whole overlay : Device tree overlay blob : Offset to shift the phandles of

overlay_adjust_local_phandles() adds a constant to all the phandles of an overlay. This is mainly use as part of the overlay application process, when we want to update all the overlay phandles to not conflict with the overlays of the base device tree.

returns: 0 on success Negative error code on failure Here is the call graph for this function:



Here is the caller graph for this function:




21.84.1.4 overlay_adjust_node_phandles()


overlay_adjust_node_phandles - Offsets the phandles of a node : Device tree overlay blob : Offset of the node we want to adjust : Offset to shift the phandles of

overlay_adjust_node_phandles() adds a constant to all the phandles of a given node. This is mainly use as part of the overlay application process, when we want to update all the overlay phandles to not conflict with the overlays of the base device tree.

returns: 0 on success Negative error code on failure Here is the call graph for this function:



Here is the caller graph for this function:




21.84.1.5 overlay_apply_node()

overlay_apply_node - Merges a node into the base device tree : Base Device Tree blob : Node offset in the base device tree to apply the fragment to : Device tree overlay blob : Node offset in the overlay holding the changes to merge

overlay_apply_node() merges a node into a target base device tree node pointed.

This is part of the final step in the device tree overlay application process, when all the phandles have been adjusted and resolved and you just have to merge overlay into the base device tree.

returns: 0 on success Negative error code on failure Here is the call graph for this function:




Here is the caller graph for this function:



21.84.1.6 overlay_fixup_one_phandle()


Here is the call graph for this function:





21.84.1.7 overlay_fixup_phandle()

Here is the call graph for this function:



Here is the caller graph for this function:



21.84.1.8 overlay_fixup_phandles()


```
static int overlay_fixup_phandles ( \mbox{void} \ * \ fdt, \\ \mbox{void} \ * \ fdto \ ) \ \mbox{[static]}
```

overlay_fixup_phandles - Resolve the overlay phandles to the base device tree : Base Device Tree blob : Device tree overlay blob

overlay_fixup_phandles() resolves all the overlay phandles pointing to nodes in the base device tree.

This is one of the steps of the device tree overlay application process, when you want all the phandles in the overlay to point to the actual base dt nodes.

returns: 0 on success Negative error code on failure Here is the call graph for this function:



Here is the caller graph for this function:





21.84.1.9 overlay_get_target()

overlay_get_target - retrieves the offset of a fragment's target : Base device tree blob : Device tree overlay blob : node offset of the fragment in the overlay : pointer which receives the path of the target (or NULL)

overlay_get_target() retrieves the target offset in the base device tree of a fragment, no matter how the actual targetting is done (through a phandle or a path)

returns: the targetted node offset in the base device tree Negative error code on error Here is the call graph for this function:





21.84.1.10 overlay_get_target_phandle()


overlay_get_target_phandle - retrieves the target phandle of a fragment : pointer to the device tree overlay blob : node offset of the fragment in the overlay

overlay_get_target_phandle() retrieves the target phandle of an overlay fragment when that fragment uses a phandle (target property) instead of a path (target-path property).

returns: the phandle pointed by the target property 0, if the phandle was not found -1, if the phandle was malformed Here is the call graph for this function:



Here is the caller graph for this function:




21.84.1.11 overlay_merge()

overlay_merge - Merge an overlay into its base device tree : Base Device Tree blob : Device tree overlay blob

overlay_merge() merges an overlay into its base device tree.

This is the next to last step in the device tree overlay application process, when all the phandles have been adjusted and resolved and you just have to merge overlay into the base device tree.

returns: 0 on success Negative error code on failure Here is the call graph for this function:





Here is the caller graph for this function:



21.84.1.12 overlay_phandle_add_offset()

Here is the call graph for this function:






21.84.1.13 overlay_symbol_update()

overlay_symbol_update - Update the symbols of base tree after a merge : Base Device Tree blob : Device tree overlay blob

overlay_symbol_update() updates the symbols of the base tree with the symbols of the applied overlay

This is the last step in the device tree overlay application process, allowing the reference of overlay symbols by subsequent overlay operations.

returns: 0 on success Negative error code on failure Here is the call graph for this function:






21.84.1.14 overlay_update_local_node_references()

overlay_update_local_node_references - Adjust the overlay references : Device tree overlay blob : Node offset of the node to operate on : Node offset of the matching local fixups node : Offset to shift the phandles of


overlay_update_local_nodes_references() update the phandles pointing to a node within the device tree overlay by adding a constant delta.

This is mainly used as part of a device tree application process, where you want the device tree overlays phandles to not conflict with the ones from the base device tree before merging them.

returns: 0 on success Negative error code on failure Here is the call graph for this function:



Here is the caller graph for this function:




21.84.1.15 overlay_update_local_references()

overlay_update_local_references - Adjust the overlay references : Device tree overlay blob : Offset to shift the phandles of


overlay_update_local_references() update all the phandles pointing to a node within the device tree overlay by adding a constant delta to not conflict with the base overlay.

This is mainly used as part of a device tree application process, where you want the device tree overlays phandles to not conflict with the ones from the base device tree before merging them.

returns: 0 on success Negative error code on failure Here is the call graph for this function:




Here is the caller graph for this function:



21.85 lib/utils/libfdt/fdt_ro.c File Reference

```
#include "libfdt_env.h"
#include <fdt.h>
#include <libfdt.h>
#include "libfdt_internal.h"
```

Include dependency graph for fdt_ro.c:




Functions

- static int fdt_nodename_eq_ (const void *fdt, int offset, const char *s, int len)
- const char * fdt_get_string (const void *fdt, int stroffset, int *lenp)
- const char * fdt_string (const void *fdt, int stroffset)
- static int fdt_string_eq_ (const void *fdt, int stroffset, const char *s, int len)
- uint32_t fdt_get_max_phandle (const void *fdt)
- static const struct fdt_reserve_entry * fdt_mem_rsv (const void *fdt, int n)
- int fdt get mem rsv (const void *fdt, int n, uint64 t *address, uint64 t *size)
- int fdt num mem rsv (const void *fdt)
- static int nextprop_ (const void *fdt, int offset)
- int fdt_subnode_offset_namelen (const void *fdt, int offset, const char *name, int namelen)
- int fdt_subnode_offset (const void *fdt, int parentoffset, const char *name)
- int fdt_path_offset_namelen (const void *fdt, const char *path, int namelen)
- int fdt path offset (const void *fdt, const char *path)
- const char * fdt_get_name (const void *fdt, int nodeoffset, int *len)
- int fdt_first_property_offset (const void *fdt, int nodeoffset)
- int fdt_next_property_offset (const void *fdt, int offset)
- static const struct fdt_property * fdt_get_property_by_offset_ (const void *fdt, int offset, int *lenp)
- const struct fdt_property * fdt_get_property_by_offset (const void *fdt, int offset, int *lenp)
- static const struct fdt_property * fdt_get_property_namelen_ (const void *fdt, int offset, const char *name, int namelen, int *lenp, int *poffset)
- const struct fdt_property * fdt_get_property_namelen (const void *fdt, int offset, const char *name, int namelen, int *lenp)
- const struct fdt_property * fdt_get_property (const void *fdt, int nodeoffset, const char *name, int *lenp)


- const void * fdt_getprop_namelen (const void *fdt, int nodeoffset, const char *name, int namelen, int *lenp)
- const void * fdt_getprop_by_offset (const void *fdt, int offset, const char **namep, int *lenp)
- const void * fdt getprop (const void *fdt, int nodeoffset, const char *name, int *lenp)
- uint32_t fdt_get_phandle (const void *fdt, int nodeoffset)
- const char * fdt_get_alias_namelen (const void *fdt, const char *name, int namelen)
- const char * fdt_get_alias (const void *fdt, const char *name)
- int fdt get path (const void *fdt, int nodeoffset, char *buf, int buflen)
- int fdt supernode atdepth offset (const void *fdt, int nodeoffset, int supernodedepth, int *nodedepth)
- int fdt_node_depth (const void *fdt, int nodeoffset)
- int fdt_parent_offset (const void *fdt, int nodeoffset)
- int fdt_node_offset_by_prop_value (const void *fdt, int startoffset, const char *propname, const void *propval, int proplen)
- int fdt node offset by phandle (const void *fdt, uint32 t phandle)
- int fdt_stringlist_contains (const char *strlist, int listlen, const char *str)
- int fdt_stringlist_count (const void *fdt, int nodeoffset, const char *property)
- int fdt stringlist search (const void *fdt, int nodeoffset, const char *property, const char *string)
- const char * fdt stringlist get (const void *fdt, int nodeoffset, const char *property, int idx, int *lenp)
- int fdt_node_check_compatible (const void *fdt, int nodeoffset, const char *compatible)
- int fdt node offset by compatible (const void *fdt, int startoffset, const char *compatible)
- int fdt check full (const void *fdt, size t bufsize)

21.85.1 Function Documentation

21.85.1.1 fdt_check_full()



Here is the caller graph for this function:




21.85.1.2 fdt_first_property_offset()


fdt_first_property_offset - find the offset of a node's first property : pointer to the device tree blob : structure block offset of a node

fdt_first_property_offset() finds the first property of the node at the given structure block offset.

returns: structure block offset of the property (>=0), on success -FDT_ERR_NOTFOUND, if the requested node has no properties -FDT_ERR_BADOFFSET, if nodeoffset did not point to an FDT_BEGIN_NODE tag -FDT_ERC_R_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERC_R_BADMAGIC, standard meanings. Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.3 fdt_get_alias()

Here is the call graph for this function:






21.85.1.4 fdt_get_alias_namelen()

Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.5 fdt_get_max_phandle()


fdt_get_max_phandle - retrieves the highest phandle in a tree : pointer to the device tree blob

fdt_get_max_phandle retrieves the highest phandle in the given device tree. This will ignore badly formatted phandles, or phandles with a value of 0 or -1.

returns: the highest phandle on success 0, if no phandle was found in the device tree -1, if an error occurred Here is the call graph for this function:



Here is the caller graph for this function:




21.85.1.6 fdt_get_mem_rsv()


 $fdt_get_mem_rsv$ - retrieve one memory reserve map entry : pointer to the device tree blob , : pointers to 64-bit variables

On success, *address and *size will contain the address and size of the n-th reserve map entry from the device tree blob, in native-endian format.

returns: 0, on success -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:





21.85.1.7 fdt_get_name()

fdt_get_name - retrieve the name of a given node : pointer to the device tree blob : structure block offset of the starting node : pointer to an integer variable (will be overwritten) or NULL

fdt_get_name() retrieves the name (including unit address) of the device tree node at structure block offset nodeoffset. If lenp is non-NULL, the length of this name is also returned, in the integer pointed to by lenp.

returns: pointer to the node's name, on success If lenp is non-NULL, *lenp contains the length of that name (>=0) NULL, on error if lenp is non-NULL *lenp contains an error code (<0): -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTA TE, standard meanings Here is the call graph for this function:






21.85.1.8 fdt_get_path()

fdt_get_path - determine the full path of a node : pointer to the device tree blob : offset of the node whose path to find : character buffer to contain the returned path (will be overwritten) : size of the character buffer at buf


fdt_get_path() computes the full path of the node at offset nodeoffset, and records that path in the buffer at buf.

NOTE: This function is expensive, as it must scan the device tree structure from the start to nodeoffset.

returns: 0, on success buf contains the absolute path of the node at nodeoffset, as a NUL-terminated string. -F ← DT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_NOSPACE, the path of the given node is longer than (bufsize-1) characters and will not fit in the given buffer. -FDT_ERR_BADMAGIC, -FD ← T_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.9 fdt_get_phandle()


fdt_get_phandle - retrieve the phandle of a given node : pointer to the device tree blob : structure block offset of the node

fdt_get_phandle() retrieves the phandle of the device tree node at structure block offset nodeoffset.

returns: the phandle of the node at nodeoffset, on success (!=0, !=-1) 0, if the node has no phandle, or another error occurs Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.10 fdt_get_property()



Here is the caller graph for this function:




21.85.1.11 fdt_get_property_by_offset()

fdt_get_property_by_offset - retrieve the property at a given offset : pointer to the device tree blob : offset of the property to retrieve : pointer to an integer variable (will be overwritten) or NULL

fdt_get_property_by_offset() retrieves a pointer to the fdt_property structure within the device tree blob at the given offset. If lenp is non-NULL, the length of the property value is also returned, in the integer pointed to by lenp.


Note that this code only works on device tree versions >= 16. fdt_getprop() works on all versions.

returns: pointer to the structure representing the property if lenp is non-NULL, *lenp contains the length of the property value (>=0) NULL, on error if lenp is non-NULL, *lenp contains an error code (<0): -FDT_ERR_BADO \leftarrow FFSET, nodeoffset did not point to FDT_PROP tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ \leftarrow ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:




21.85.1.12 fdt_get_property_by_offset_()

Here is the call graph for this function:




Here is the caller graph for this function:



21.85.1.13 fdt_get_property_namelen()


Here is the call graph for this function:




Here is the caller graph for this function:



21.85.1.14 fdt_get_property_namelen_()



Here is the caller graph for this function:



21.85.1.15 fdt_get_string()


fdt_get_string - retrieve a string from the strings block of a device tree : pointer to the device tree blob : offset of the string within the strings block (native endian) : optional pointer to return the string's length

fdt_get_string() retrieves a pointer to a single string from the strings block of the device tree blob at fdt, and optionally also returns the string's length in *lenp.

returns: a pointer to the string, on success NULL, if stroffset is out of bounds, or doesn't point to a valid string Here is the call graph for this function:




Here is the caller graph for this function:



21.85.1.16 fdt_getprop()



Here is the caller graph for this function:




21.85.1.17 fdt_getprop_by_offset()


fdt_getprop_by_offset - retrieve the value of a property at a given offset : pointer to the device tree blob : offset of the property to read : pointer to a string variable (will be overwritten) or NULL : pointer to an integer variable (will be overwritten) or NULL

fdt_getprop_by_offset() retrieves a pointer to the value of the property at structure block offset 'offset' (this will be a pointer to within the device blob itself, not a copy of the value). If lenp is non-NULL, the length of the property value is also returned, in the integer pointed to by lenp. If namep is non-NULL, the property's namne will also be returned in the char * pointed to by namep (this will be a pointer to within the device tree's string block, not a new copy of the name).


returns: pointer to the property's value if lenp is non-NULL, *lenp contains the length of the property value (>=0) if namep is non-NULL *namep contains a pointer to the property name. NULL, on error if lenp is non-NULL, *lenp contains an error code (<0): -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_PROP tag -FDT_ERR_\top BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_\top TRUNCATED, standard meanings Here is the call graph for this function:




Here is the caller graph for this function:



21.85.1.18 fdt_getprop_namelen()




Here is the caller graph for this function:



21.85.1.19 fdt_mem_rsv()



Here is the caller graph for this function:




21.85.1.20 fdt_next_property_offset()


fdt_next_property_offset - step through a node's properties : pointer to the device tree blob : structure block offset of a property

fdt_next_property_offset() finds the property immediately after the one at the given structure block offset. This will be a property of the same node as the given property.

returns: structure block offset of the next property (>=0), on success -FDT_ERR_NOTFOUND, if the given property is the last in its node -FDT_ERR_BADOFFSET, if nodeoffset did not point to an FDT_PROP tag -FDT_ERR_BACDMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRCUNCATED, standard meanings. Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.21 fdt_node_check_compatible()


fdt_node_check_compatible: check a node's compatible property : pointer to the device tree blob : offset of a tree node : string to match against

fdt_node_check_compatible() returns 0 if the given node contains a 'compatible' property with the given string as one of its elements, it returns non-zero otherwise, or on error.

returns: 0, if the node has a 'compatible' property listing the given string 1, if the node has a 'compatible' property, but it does not list the given string -FDT_ERR_NOTFOUND, if the given node has no 'compatible' property -FDT ← _ERR_BADOFFSET, if nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_B ← ADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.22 fdt_node_depth()

fdt_node_depth - find the depth of a given node : pointer to the device tree blob : offset of the node whose parent to find

fdt_node_depth() finds the depth of a given node. The root node has depth 0, its immediate subnodes depth 1 and so forth.

NOTE: This function is expensive, as it must scan the device tree structure from the start to nodeoffset.

returns: depth of the node at nodeoffset (>=0), on success -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR← _BADSTRUCTURE, standard meanings Here is the call graph for this function:





21.85.1.23 fdt_node_offset_by_compatible()

fdt_node_offset_by_compatible - find nodes with a given 'compatible' value : pointer to the device tree blob : only find nodes after this offset : 'compatible' string to match against


fdt_node_offset_by_compatible() returns the offset of the first node after startoffset, which has a 'compatible' property which lists the given compatible string; or if startoffset is -1, the very first such node in the tree.

To iterate through all nodes matching the criterion, the following idiom can be used: offset = fdt_node_offset_by_ \leftarrow compatible(fdt, -1, compatible); while (offset != -FDT_ERR_NOTFOUND) { // other code here offset = fdt_node_ \leftarrow offset_by_compatible(fdt, offset, compatible); }

Note the -1 in the first call to the function, if 0 is used here instead, the function will never locate the root node, even if it matches the criterion.

returns: structure block offset of the located node (>= 0, >startoffset), on success -FDT_ERR_NOTFOUND, no node matching the criterion exists in the tree after startoffset -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_E RR_BADSTRUCTURE, standard meanings Here is the call graph for this function:






21.85.1.24 fdt_node_offset_by_phandle()


fdt_node_offset_by_phandle - find the node with a given phandle : pointer to the device tree blob : phandle value

fdt_node_offset_by_phandle() returns the offset of the node which has the given phandle value. If there is more than one node in the tree with the given phandle (an invalid tree), results are undefined.

returns: structure block offset of the located node (>= 0), on success -FDT_ERR_NOTFOUND, no node with that phandle exists -FDT_ERR_BADPHANDLE, given phandle value was invalid (0 or -1) -FDT_ERR_BADMAGIC, -F \leftarrow DT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.25 fdt_node_offset_by_prop_value()

fdt_node_offset_by_prop_value - find nodes with a given property value : pointer to the device tree blob : only find nodes after this offset : property name to check : property value to search for : length of the value in propval

fdt_node_offset_by_prop_value() returns the offset of the first node after startoffset, which has a property named propname whose value is of length proplen and has value equal to propval; or if startoffset is -1, the very first such node in the tree.


To iterate through all nodes matching the criterion, the following idiom can be used: offset = fdt_node_offset_← by_prop_value(fdt, -1, propname, propval, proplen); while (offset != -FDT_ERR_NOTFOUND) { // other code here offset = fdt_node_offset_by_prop_value(fdt, offset, propname, propval, proplen); }

Note the -1 in the first call to the function, if 0 is used here instead, the function will never locate the root node, even if it matches the criterion.


returns: structure block offset of the located node (>= 0, >startoffset), on success -FDT_ERR_NOTFOUND, no node matching the criterion exists in the tree after startoffset -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_E RR_BADSTRUCTURE, standard meanings Here is the call graph for this function:




Here is the caller graph for this function:



21.85.1.26 fdt_nodename_eq_()



Here is the caller graph for this function:





21.85.1.27 fdt_num_mem_rsv()

fdt_num_mem_rsv - retrieve the number of memory reserve map entries : pointer to the device tree blob

Returns the number of entries in the device tree blob's memory reservation map. This does not include the terminating 0.0 entry or any other (0.0) entries reserved for expansion.

returns: the number of entries Here is the call graph for this function:





21.85.1.28 fdt_parent_offset()

fdt_parent_offset - find the parent of a given node : pointer to the device tree blob : offset of the node whose parent to find

fdt_parent_offset() locates the parent node of a given node (that is, it finds the offset of the node which contains the node at nodeoffset as a subnode).

NOTE: This function is expensive, as it must scan the device tree structure from the start to nodeoffset, twice.

returns: structure block offset of the parent of the node at nodeoffset (>=0), on success -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_E← RR_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.29 fdt_path_offset()


fdt_path_offset - find a tree node by its full path : pointer to the device tree blob : full path of the node to locate

fdt_path_offset() finds a node of a given path in the device tree. Each path component may omit the unit address portion, but the results of this are undefined if any such path component is ambiguous (that is if there are multiple nodes at the relevant level matching the given component, differentiated only by unit address).

returns: structure block offset of the node with the requested path (>=0), on success -FDT_ERR_BADPATH, given path does not begin with '/' or is invalid -FDT_ERR_NOTFOUND, if the requested node does not exist -FDT_ER← R_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ER← R_TRUNCATED, standard meanings. Here is the call graph for this function:



Here is the caller graph for this function:




21.85.1.30 fdt_path_offset_namelen()

fdt_path_offset_namelen - find a tree node by its full path : pointer to the device tree blob : full path of the node to locate : number of characters of path to consider

Identical to fdt_path_offset(), but only consider the first namelen characters of path as the path name. Here is the call graph for this function:



Here is the caller graph for this function:





21.85.1.31 fdt_string()

fdt_string - retrieve a string from the strings block of a device tree : pointer to the device tree blob : offset of the string within the strings block (native endian)

fdt_string() retrieves a pointer to a single string from the strings block of the device tree blob at fdt.


returns: a pointer to the string, on success NULL, if stroffset is out of bounds, or doesn't point to a valid string Here is the call graph for this function:






21.85.1.32 fdt_string_eq_()

Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.33 fdt_stringlist_contains()


fdt_stringlist_contains - check a string list property for a string : Property containing a list of strings to check : Length of property : String to search for

This is a utility function provided for convenience. The list contains one or more strings, each terminated by \0, as is found in a device tree "compatible" property.

Returns

: 1 if the string is found in the list, 0 not found, or invalid list

Here is the caller graph for this function:



21.85.1.34 fdt_stringlist_count()

Here is the call graph for this function:





21.85.1.35 fdt_stringlist_get()

Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.36 fdt_stringlist_search()





Here is the caller graph for this function:



21.85.1.37 fdt_subnode_offset()


Here is the call graph for this function:






21.85.1.38 fdt_subnode_offset_namelen()

Here is the call graph for this function:



Here is the caller graph for this function:



21.85.1.39 fdt_supernode_atdepth_offset()

fdt_supernode_atdepth_offset - find a specific ancestor of a node : pointer to the device tree blob : offset of the node whose parent to find : depth of the ancestor to find : pointer to an integer variable (will be overwritten) or NULL

fdt_supernode_atdepth_offset() finds an ancestor of the given node at a specific depth from the root (where the root
itself has depth 0, its immediate subnodes depth 1 and so forth). So fdt_supernode_atdepth_offset(fdt, nodeoffset,


0, NULL); will always return 0, the offset of the root node. If the node at nodeoffset has depth D, then: fdt_\(-\text{supernode_atdepth_offset}\) (fdt, nodeoffset, D, NULL); will return nodeoffset itself.

NOTE: This function is expensive, as it must scan the device tree structure from the start to nodeoffset.


returns: structure block offset of the node at node offset's ancestor of depth supernodedepth (>=0), on success -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_NOTFOUND, supernodedepth was greater than the depth of nodeoffset -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ER R_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:




Here is the caller graph for this function:



21.85.1.40 nextprop_()




Here is the caller graph for this function:



21.86 lib/utils/libfdt/fdt_rw.c File Reference

```
#include "libfdt_env.h"
#include <fdt.h>
#include <libfdt.h>
#include "libfdt_internal.h"
```

Include dependency graph for fdt_rw.c:



Macros

• #define FDT_RW_PROBE(fdt)

Functions

- static int fdt_blocks_misordered_ (const void *fdt, int mem_rsv_size, int struct_size)
- static int fdt_rw_probe_ (void *fdt)
- static int fdt_data_size_ (void *fdt)
- static int fdt_splice_ (void *fdt, void *splicepoint, int oldlen, int newlen)
- static int fdt_splice_mem_rsv_ (void *fdt, struct fdt_reserve_entry *p, int oldn, int newn)
- static int fdt_splice_struct_ (void *fdt, void *p, int oldlen, int newlen)
- static int fdt_splice_string_ (void *fdt, int newlen)
- static int fdt find add string (void *fdt, const char *s)
- int fdt add mem rsv (void *fdt, uint64 t address, uint64 t size)
- int fdt del mem rsv (void *fdt, int n)
- static int fdt_resize_property_ (void *fdt, int nodeoffset, const char *name, int len, struct fdt_property **prop)
- static int fdt_add_property_ (void *fdt, int nodeoffset, const char *name, int len, struct fdt_property **prop)
- int fdt_set_name (void *fdt, int nodeoffset, const char *name)
- int fdt_setprop_placeholder (void *fdt, int nodeoffset, const char *name, int len, void **prop_data)
- int fdt setprop (void *fdt, int nodeoffset, const char *name, const void *val, int len)
- int fdt_appendprop (void *fdt, int nodeoffset, const char *name, const void *val, int len)
- int fdt delprop (void *fdt, int nodeoffset, const char *name)
- int fdt_add_subnode_namelen (void *fdt, int parentoffset, const char *name, int namelen)

- int fdt_add_subnode (void *fdt, int parentoffset, const char *name)
- int fdt del node (void *fdt, int nodeoffset)
- static void fdt_packblocks_ (const char *old, char *new, int mem_rsv_size, int struct_size)
- int fdt open into (const void *fdt, void *buf, int bufsize)
- int fdt_pack (void *fdt)

21.86.1 Macro Definition Documentation

21.86.1.1 FDT_RW_PROBE

```
#define FDT_RW_PROBE( fdt )
```

Value:

```
int err_; \
    if ((err_ = fdt_rw_probe_(fdt)) != 0) \
        return err_; \
```

21.86.2 Function Documentation


21.86.2.1 fdt_add_mem_rsv()

fdt_add_mem_rsv - add one memory reserve map entry : pointer to the device tree blob , : 64-bit values (native endian)

Adds a reserve map entry to the given blob reserving a region at address address of length size.


This function will insert data into the reserve map and will therefore change the indexes of some entries in the table.

returns: 0, on success -FDT_ERR_NOSPACE, there is insufficient free space in the blob to contain the new reservation entry -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADST← RUCTURE, -FDT_ERR_BADLAYOUT, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:




21.86.2.2 fdt_add_property_()

Here is the call graph for this function:




Here is the caller graph for this function:



21.86.2.3 fdt_add_subnode()




Here is the caller graph for this function:




21.86.2.4 fdt_add_subnode_namelen()

Here is the call graph for this function:




Here is the caller graph for this function:




21.86.2.5 fdt_appendprop()

```
const void * val,
int len )
```


Here is the call graph for this function:



Here is the caller graph for this function:



21.86.2.6 fdt_blocks_misordered_()



21.86.2.7 fdt_data_size_()

Here is the caller graph for this function:




21.86.2.8 fdt_del_mem_rsv()

fdt_del_mem_rsv - remove a memory reserve map entry : pointer to the device tree blob : entry to remove

fdt del mem rsv() removes the n-th memory reserve map entry from the blob.

This function will delete data from the reservation table and will therefore change the indexes of some entries in the table.

returns: 0, on success -FDT_ERR_NOTFOUND, there is no entry of the given index (i.e. there are less than n+1 reserve map entries) -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ER R_BADSTRUCTURE, -FDT_ERR_BADLAYOUT, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:




21.86.2.9 fdt_del_node()

fdt_del_node - delete a node (subtree) : pointer to the device tree blob : offset of the node to nop

fdt del node() will remove the given node, including all its subnodes if any, from the blob.

This function will delete data from the blob, and will therefore change the offsets of some existing nodes.

returns: 0, on success -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ER R_BADLAYOUT, -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_B ADSTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:



21.86.2.10 fdt_delprop()

```
int fdt_delprop (
     void * fdt,
     int nodeoffset,
     const char * name )
```



21.86.2.11 fdt_find_add_string_()


Here is the call graph for this function:




Here is the caller graph for this function:



21.86.2.12 fdt_open_into()




Here is the caller graph for this function:



21.86.2.13 fdt_pack()

```
int fdt_pack ( \mbox{void} \ * \ fdt \ )
```

Here is the call graph for this function:



21.86.2.14 fdt_packblocks_()




21.86.2.15 fdt_resize_property_()

Here is the call graph for this function:



Here is the caller graph for this function:




21.86.2.16 fdt_rw_probe_()




21.86.2.17 fdt_set_name()


Here is the call graph for this function:



21.86.2.18 fdt_setprop()

Here is the call graph for this function:







21.86.2.19 fdt_setprop_placeholder()

```
int fdt_setprop_placeholder (
    void * fdt,
    int nodeoffset,
    const char * name,
    int len,
    void ** prop_data )
```

Here is the call graph for this function:



Here is the caller graph for this function:



21.86.2.20 fdt_splice_()





Here is the caller graph for this function:



21.86.2.21 fdt_splice_mem_rsv_()

Here is the call graph for this function:






21.86.2.22 fdt_splice_string_()


Here is the call graph for this function:




Here is the caller graph for this function:



21.86.2.23 fdt_splice_struct_()




Here is the caller graph for this function:



21.87 lib/utils/libfdt/fdt_strerror.c File Reference

```
#include "libfdt_env.h"
#include <fdt.h>
#include <libfdt.h>
#include "libfdt_internal.h"
Include dependency graph for fdt_strerror.c:
```



Macros

- #define FDT_ERRTABENT(val) [(val)] = { .str = #val, }
- #define FDT_ERRTABSIZE (sizeof(fdt_errtable) / sizeof(fdt_errtable[0]))

Functions

• const char * fdt_strerror (int errval)

Variables

• static struct fdt_errtabent fdt_errtable []

21.87.1 Macro Definition Documentation

21.87.1.1 FDT_ERRTABENT

21.87.1.2 FDT_ERRTABSIZE

```
#define FDT_ERRTABSIZE (sizeof(fdt_errtable) / sizeof(fdt_errtable[0]))
```

21.87.2 Function Documentation

21.87.2.1 fdt_strerror()

21.87.3 Variable Documentation

21.87.3.1 fdt_errtable

```
struct fdt_errtabent fdt_errtable[] [static]
```

Initial value:

```
FDT_ERRTABENT (FDT_ERR_NOTFOUND),
FDT_ERRTABENT (FDT_ERR_EXISTS),
FDT_ERRTABENT (FDT_ERR_NOSPACE),


FDT_ERRTABENT (FDT_ERR_BADOFFSET),
FDT_ERRTABENT (FDT_ERR_BADPATH),
FDT_ERRTABENT (FDT_ERR_BADPHANDLE),
FDT_ERRTABENT (FDT_ERR_BADSTATE),

FDT_ERRTABENT (FDT_ERR_TRUNCATED),
FDT_ERRTABENT (FDT_ERR_BADSTATE),

FDT_ERRTABENT (FDT_ERR_BADVERSION),
FDT_ERRTABENT (FDT_ERR_BADSTRUCTURE),
FDT_ERRTABENT (FDT_ERR_BADSTRUCTURE),
FDT_ERRTABENT (FDT_ERR_BADLAYOUT),
FDT_ERRTABENT (FDT_ERR_INTERNAL),
FDT_ERRTABENT (FDT_ERR_BADNCELLS),
FDT_ERRTABENT (FDT_ERR_BADVALUE),
FDT_ERRTABENT (FDT_ERR_BADVALUE),
FDT_ERRTABENT (FDT_ERR_BADVERLAY),
FDT_ERRTABENT (FDT_ERR_BADVERLAY),
FDT_ERRTABENT (FDT_ERR_NOPHANDLES),
```

21.88 lib/utils/libfdt/fdt_sw.c File Reference

```
#include "libfdt_env.h"
#include <fdt.h>
#include <libfdt.h>
#include "libfdt_internal.h"
Include dependency graph for fdt_sw.c:
```



Macros

- #define FDT SW PROBE(fdt)
- #define FDT_SW_PROBE_MEMRSV(fdt)
- #define FDT_SW_PROBE_STRUCT(fdt)

Functions

- static int fdt_sw_probe_ (void *fdt)
- static int fdt sw probe memrsv (void *fdt)
- static int fdt_sw_probe_struct_ (void *fdt)
- static void * fdt_grab_space_ (void *fdt, size_t len)
- int fdt_create (void *buf, int bufsize)
- int fdt_resize (void *fdt, void *buf, int bufsize)
- int fdt_add_reservemap_entry (void *fdt, uint64_t addr, uint64_t size)
- int fdt finish reservemap (void *fdt)
- int fdt_begin_node (void *fdt, const char *name)
- int fdt_end_node (void *fdt)
- static int fdt_find_add_string_ (void *fdt, const char *s)
- int fdt_property_placeholder (void *fdt, const char *name, int len, void **valp)
- int fdt_property (void *fdt, const char *name, const void *val, int len)
- int fdt_finish (void *fdt)

21.88.1 Macro Definition Documentation

```
21.88.1.1 FDT_SW_PROBE
```

Value:

```
{ \
    int err; \
    if ((err = fdt_sw_probe_(fdt)) != 0) \
        return err; \
}
```

21.88.1.2 FDT_SW_PROBE_MEMRSV

Value:

```
int err; \
   if ((err = fdt_sw_probe_memrsv_(fdt)) != 0) \
        return err; \
}
```

21.88.1.3 FDT_SW_PROBE_STRUCT

```
#define FDT_SW_PROBE_STRUCT( fdt \ )
```

Value:


```
{
    int err; \
    if ((err = fdt_sw_probe_struct_(fdt)) != 0) \
        return err; \
}
```

21.88.2 Function Documentation

21.88.2.1 fdt_add_reservemap_entry()


Here is the call graph for this function:






21.88.2.2 fdt_begin_node()


Here is the call graph for this function:



Here is the caller graph for this function:




21.88.2.3 fdt_create()




21.88.2.4 fdt_end_node()

Here is the call graph for this function:




Here is the caller graph for this function:




21.88.2.5 fdt_find_add_string_()

```
static int fdt_find_add_string_ (  \mbox{void} \ * \ fdt, \\ \mbox{const char} \ * \ s \ ) \ \ [static]
```




Here is the caller graph for this function:




21.88.2.6 fdt_finish()

```
int fdt_finish ( \label{eq:condition} \mbox{void} \ * \ \mbox{\it fdt} \ )
```


Here is the call graph for this function:






21.88.2.7 fdt_finish_reservemap()

Here is the call graph for this function:




Here is the caller graph for this function:



21.88.2.8 fdt_grab_space_()




Here is the caller graph for this function:



21.88.2.9 fdt_property()


Here is the call graph for this function:






21.88.2.10 fdt_property_placeholder()

Here is the call graph for this function:



Here is the caller graph for this function:




21.88.2.11 fdt_resize()

```
int fdt_resize (
     void * fdt,
     void * buf,
     int bufsize )
```



```
21.88.2.12 fdt_sw_probe_()
```

Here is the caller graph for this function:



21.88.2.13 fdt_sw_probe_memrsv_()

Here is the call graph for this function:




21.88.2.14 fdt_sw_probe_struct_()



21.89 lib/utils/libfdt/fdt_wip.c File Reference

```
#include "libfdt_env.h"
#include <fdt.h>
#include <libfdt.h>
#include "libfdt_internal.h"
Include dependency graph for fdt_wip.c:
```



Functions

- int fdt_setprop_inplace_namelen_partial (void *fdt, int nodeoffset, const char *name, int namelen, uint32_t idx, const void *val, int len)
- int fdt_setprop_inplace (void *fdt, int nodeoffset, const char *name, const void *val, int len)
- static void fdt_nop_region_ (void *start, int len)
- int fdt_nop_property (void *fdt, int nodeoffset, const char *name)
- int fdt_node_end_offset_ (void *fdt, int offset)
- int fdt_nop_node (void *fdt, int nodeoffset)


21.89.1 Function Documentation

21.89.1.1 fdt_node_end_offset_()

Here is the call graph for this function:



Here is the caller graph for this function:




21.89.1.2 fdt_nop_node()

fdt nop node - replace a node (subtree) with nop tags : pointer to the device tree blob : offset of the node to nop

fdt_nop_node() will replace a given node's representation in the blob, including all its subnodes, if any, with FDT← NOP tags, effectively removing it from the tree.

This function will alter only the bytes in the blob which contain the node and its properties and subnodes, and will not alter or move any other part of the tree.

returns: 0, on success -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ER⇔ R_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ER⇔ R_TRUNCATED, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:



21.89.1.3 fdt_nop_property()

Here is the call graph for this function:






21.89.1.4 fdt_nop_region_()

Here is the call graph for this function:




Here is the caller graph for this function:



21.89.1.5 fdt_setprop_inplace()

```
int fdt_setprop_inplace (
    void * fdt,
    int nodeoffset,
    const char * name,
    const void * val,
    int len )
```




Here is the caller graph for this function:




21.89.1.6 fdt_setprop_inplace_namelen_partial()

```
int fdt_setprop_inplace_namelen_partial (
    void * fdt,
    int nodeoffset,
    const char * name,
    int namelen,
    uint32_t idx,
    const void * val,
    int len )
```

Here is the call graph for this function:




Here is the caller graph for this function:




21.90 lib/utils/libfdt/libfdt.h File Reference

```
#include <libfdt_env.h>
#include <fdt.h>
```

Include dependency graph for libfdt.h:



This graph shows which files directly or indirectly include this file:



Macros

- #define FDT_FIRST_SUPPORTED_VERSION 0x02
- #define FDT_LAST_SUPPORTED_VERSION 0x11
- #define FDT_ERR_NOTFOUND 1
- #define FDT ERR EXISTS 2
- #define FDT_ERR_NOSPACE 3
- #define FDT_ERR_BADOFFSET 4
- #define FDT_ERR_BADPATH 5
- #define FDT_ERR_BADPHANDLE 6
- #define FDT_ERR_BADSTATE 7
- #define FDT_ERR_TRUNCATED 8
- #define FDT_ERR_BADMAGIC 9
- #define FDT_ERR_BADVERSION 10
- #define FDT_ERR_BADSTRUCTURE 11
- #define FDT_ERR_BADLAYOUT 12
- #define FDT_ERR_INTERNAL 13
- #define FDT_ERR_BADNCELLS 14
- #define FDT_ERR_BADVALUE 15
- #define FDT_ERR_BADOVERLAY 16

- #define FDT ERR NOPHANDLES 17
- #define FDT_ERR_MAX 17
- #define fdt_for_each_subnode(node, fdt, parent)
- #define fdt get header(fdt, field) (fdt32 ld(&((const struct fdt header *)(fdt))->field))
- #define fdt_magic(fdt) (fdt_get_header(fdt, magic))
- #define fdt_totalsize(fdt) (fdt_get_header(fdt, totalsize))
- #define fdt_off_dt_struct(fdt) (fdt_get_header(fdt, off_dt_struct))
- #define fdt_off_dt_strings(fdt) (fdt_get_header(fdt, off_dt_strings))
- #define fdt_off_mem_rsvmap(fdt) (fdt_get_header(fdt, off_mem_rsvmap))
- #define fdt_version(fdt) (fdt_get_header(fdt, version))
- #define fdt_last_comp_version(fdt) (fdt_get_header(fdt, last_comp_version))
- #define fdt_boot_cpuid_phys(fdt) (fdt_get_header(fdt, boot_cpuid_phys))
- #define fdt_size dt_strings(fdt) (fdt_get_header(fdt, size dt_strings))
- #define fdt_size dt_struct(fdt) (fdt_get_header(fdt, size dt_struct))
- #define fdt_set_hdr_(name)

Functions

- const void * fdt_offset_ptr (const void *fdt, int offset, unsigned int checklen)
- static void * fdt_offset_ptr_w (void *fdt, int offset, int checklen)
- uint32 t fdt next tag (const void *fdt, int offset, int *nextoffset)
- static uint32 t fdt32 ld (const fdt32 t *p)
- static uint64 t fdt64 ld (const fdt64 t *p)
- int fdt_next_node (const void *fdt, int offset, int *depth)
- int fdt_first_subnode (const void *fdt, int offset)
- int fdt_next_subnode (const void *fdt, int offset)
- fdt_set_hdr_ (magic)
- fdt_set_hdr_ (totalsize)
- fdt_set_hdr_ (off_dt_struct)
- fdt_set_hdr_ (off_dt_strings)
- fdt_set_hdr_ (off_mem_rsvmap)
- fdt_set_hdr_ (version)
- fdt_set_hdr_ (last_comp_version)
- fdt_set_hdr_ (boot_cpuid_phys)
- fdt_set_hdr_ (size_dt_strings)
- fdt set hdr (size dt struct)
- size_t fdt_header_size_ (uint32_t version)
- static size_t fdt_header_size (const void *fdt)
- int fdt_check_header (const void *fdt)
- int fdt_move (const void *fdt, void *buf, int bufsize)
- int fdt check full (const void *fdt, size t bufsize)
- const char * fdt_get_string (const void *fdt, int stroffset, int *lenp)
- const char * fdt string (const void *fdt, int stroffset)
- uint32_t fdt_get_max_phandle (const void *fdt)
- int fdt num mem rsv (const void *fdt)
- int fdt get mem rsv (const void *fdt, int n, uint64 t *address, uint64 t *size)

: name of the property to find

fdt_getprop - retrieve the value of a given property : pointer to the device tree blob : offset of the node whose property to find

: pointer to an integer variable (will be overwritten) or NULL

fdt_getprop() retrieves a pointer to the value of the property named 'name' of the node at offset nodeoffset (this will be a pointer to within the device blob itself, not a copy of the value). If lenp is non-NULL, the length of the property value is also returned, in the integer pointed to by lenp.

returns: pointer to the property's value if lenp is non-NULL, *lenp contains the length of the property value (>=0) NULL, on error if lenp is non-NULL, *lenp contains an error code (<0): -FDT_ERR_NOTFOUND, node does not have named property -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings

- const struct fdt_property * fdt_get_property_namelen (const void *fdt, int nodeoffset, const char *name, int namelen, int *lenp)
- const struct fdt_property * fdt_get_property (const void *fdt, int nodeoffset, const char *name, int *lenp)
- static struct fdt_property * fdt_get_property_w (void *fdt, int nodeoffset, const char *name, int *lenp)
- const void * fdt_getprop_by_offset (const void *fdt, int offset, const char **namep, int *lenp)
- const void * fdt_getprop_namelen (const void *fdt, int nodeoffset, const char *name, int namelen, int *lenp)
- static void * fdt_getprop_namelen_w (void *fdt, int nodeoffset, const char *name, int namelen, int *lenp)
- const void * fdt_getprop (const void *fdt, int nodeoffset, const char *name, int *lenp)
- static void * fdt_getprop_w (void *fdt, int nodeoffset, const char *name, int *lenp)
- uint32_t fdt_get_phandle (const void *fdt, int nodeoffset)

: name of the property to nop

fdt_delprop - delete a property : pointer to the device tree blob : offset of the node whose property to nop fdt_del_property() will delete the given property.

This function will delete data from the blob, and will therefore change the offsets of some existing nodes.

returns: 0, on success -FDT_ERR_NOTFOUND, node does not have the named property -FDT_ERR_BADO↔ FFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ERR_BADLAYOUT, -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRUNCA↔ TED, standard meanings

- int fdt_nop_property (void *fdt, int nodeoffset, const char *name)
- int fdt_nop_node (void *fdt, int nodeoffset)
- int fdt_create (void *buf, int bufsize)
- int fdt_resize (void *fdt, void *buf, int bufsize)
- int fdt_add_reservemap_entry (void *fdt, uint64_t addr, uint64_t size)
- int fdt finish reservemap (void *fdt)
- int fdt begin node (void *fdt, const char *name)
- int fdt property (void *fdt, const char *name, const void *val, int len)
- static int fdt_property_u32 (void *fdt, const char *name, uint32_t val)
- static int fdt property u64 (void *fdt, const char *name, uint64 t val)
- static int fdt property cell (void *fdt, const char *name, uint32 t val)
- int fdt delprop (void *fdt, int nodeoffset, const char *name)

: name to give the node

fdt_set_name - change the name of a given node : pointer to the device tree blob : structure block offset of a

fdt_set_name() replaces the name (including unit address, if any) of the given node with the given string. NO← TE: this function can't efficiently check if the new name is unique amongst the given node's siblings; results are undefined if this function is invoked with a name equal to one of the given node's siblings.

This function may insert or delete data from the blob, and will therefore change the offsets of some existing nodes.

returns: 0, on success -FDT_ERR_NOSPACE, there is insufficient free space in the blob to contain the new name -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, standard meanings

int fdt_set_name (void *fdt, int nodeoffset, const char *name)

: name of the property to append to

fdt_appendprop - append to or create a property : pointer to the device tree blob : offset of the node whose property to change

: pointer to data to append to the property value : length of the data to append to the property value

fdt_appendprop() appends the value to the named property in the given node, creating the property if it does not already exist.

This function may insert data into the blob, and will therefore change the offsets of some existing nodes.

returns: 0, on success -FDT_ERR_NOSPACE, there is insufficient free space in the blob to contain the new property value -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ERR_BAD → DLAYOUT, -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BAD → STRUCTURE, -FDT_ERR_BADLAYOUT, -FDT_ERR_TRUNCATED, standard meanings

• int fdt_appendprop (void *fdt, int nodeoffset, const char *name, const void *val, int len)

: name of the subnode to locate

fdt_add_subnode - creates a new node : pointer to the device tree blob : structure block offset of a node

fdt_add_subnode() creates a new node as a subnode of the node at structure block offset parentoffset, with the given name (which should include the unit address, if any).

This function will insert data into the blob, and will therefore change the offsets of some existing nodes.

returns: structure block offset of the created nodeequested subnode (>=0), on success -FDT_ERR_NOTFO ← UND, if the requested subnode does not exist -FDT_ERR_BADOFFSET, if parentoffset did not point to an FD ← T_BEGIN_NODE tag -FDT_ERR_EXISTS, if the node at parentoffset already has a subnode of the given name -FDT_ERR_NOSPACE, if there is insufficient free space in the blob to contain the new node -FDT_ERR_NO ← SPACE -FDT_ERR_BADLAYOUT -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings.

- #define fdt_for_each_property_offset(property, fdt, node)
- int fdt_subnode_offset_namelen (const void *fdt, int parentoffset, const char *name, int namelen)
- int fdt_subnode_offset (const void *fdt, int parentoffset, const char *name)
- int fdt_path_offset_namelen (const void *fdt, const char *path, int namelen)
- int fdt path offset (const void *fdt, const char *path)
- const char * fdt_get_name (const void *fdt, int nodeoffset, int *lenp)
- int fdt_first_property_offset (const void *fdt, int nodeoffset)
- int fdt_next_property_offset (const void *fdt, int offset)
- const struct fdt_property * fdt_get_property_by_offset (const void *fdt, int offset, int *lenp)
- int fdt add subnode namelen (void *fdt, int parentoffset, const char *name, int namelen)
- int fdt_add_subnode (void *fdt, int parentoffset, const char *name)
- int fdt_del_node (void *fdt, int nodeoffset)
- int fdt_overlay_apply (void *fdt, void *fdto)
- const char * fdt strerror (int errval)

: name of the alias th look up

fdt_get_alias - retrieve the path referenced by a given alias : pointer to the device tree blob

fdt_get_alias() retrieves the value of a given alias. That is, the value of the property named 'name' in the node /aliases.

returns: a pointer to the expansion of the alias named 'name', if it exists NULL, if the given alias or the /aliases node does not exist

- #define FDT MAX NCELLS 4
- const char * fdt_get_alias_namelen (const void *fdt, const char *name, int namelen)
- const char * fdt_get_alias (const void *fdt, const char *name)
- int fdt get path (const void *fdt, int nodeoffset, char *buf, int buflen)
- int fdt_supernode_atdepth_offset (const void *fdt, int nodeoffset, int supernodedepth, int *nodedepth)
- int fdt_node_depth (const void *fdt, int nodeoffset)
- int fdt parent offset (const void *fdt, int nodeoffset)
- int fdt_node_offset_by_prop_value (const void *fdt, int startoffset, const char *propname, const void *propval, int proplen)
- int fdt_node_offset_by_phandle (const void *fdt, uint32_t phandle)
- int fdt node check compatible (const void *fdt, int nodeoffset, const char *compatible)
- int fdt_node_offset_by_compatible (const void *fdt, int startoffset, const char *compatible)
- int fdt stringlist contains (const char *strlist, int listlen, const char *str)
- int fdt_stringlist_count (const void *fdt, int nodeoffset, const char *property)
- int fdt_stringlist_search (const void *fdt, int nodeoffset, const char *property, const char *string)
- const char * fdt stringlist get (const void *fdt, int nodeoffset, const char *property, int index, int *lenp)
- int fdt address cells (const void *fdt, int nodeoffset)
- int fdt_size_cells (const void *fdt, int nodeoffset)

: name of the property to change

fdt_appendprop_string - append a string to a property : pointer to the device tree blob : offset of the node whose property to change

: string value to append to the property

fdt_appendprop_string() appends the given string to the value of the named property in the given node, or creates a new property with that value if it does not already exist.

This function may insert data into the blob, and will therefore change the offsets of some existing nodes.

returns: 0, on success -FDT_ERR_NOSPACE, there is insufficient free space in the blob to contain the new property value -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ERR_BADLAYOUT, - \leftarrow FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, - \leftarrow FDT_ERR_BADLAYOUT, -FDT_ERR_TRUNCATED, standard meanings

- #define fdt_setprop_string(fdt, nodeoffset, name, str) fdt_setprop((fdt), (nodeoffset), (name), (str), strlen(str)+1)
- #define fdt_setprop_empty(fdt, nodeoffset, name) fdt_setprop((fdt), (nodeoffset), (name), NULL, 0)
- #define fdt_appendprop_string(fdt, nodeoffset, name, str) fdt_appendprop((fdt), (nodeoffset), (name), (str), strlen(str)+1)
- int fdt_setprop_inplace_namelen_partial (void *fdt, int nodeoffset, const char *name, int namelen, uint32_t idx, const void *val, int len)
- int fdt setprop inplace (void *fdt, int nodeoffset, const char *name, const void *val, int len)

```
• static int fdt_setprop_inplace_u32 (void *fdt, int nodeoffset, const char *name, uint32_t val)
```

- static int fdt_setprop_inplace_u64 (void *fdt, int nodeoffset, const char *name, uint64_t val)
- static int fdt_setprop_inplace_cell (void *fdt, int nodeoffset, const char *name, uint32_t val)
- int fdt_setprop (void *fdt, int nodeoffset, const char *name, const void *val, int len)
- int fdt setprop placeholder (void *fdt, int nodeoffset, const char *name, int len, void **prop data)
- static int fdt setprop u32 (void *fdt, int nodeoffset, const char *name, uint32 t val)
- static int fdt_setprop_u64 (void *fdt, int nodeoffset, const char *name, uint64_t val)
- static int fdt setprop cell (void *fdt, int nodeoffset, const char *name, uint32 t val)
- static int fdt appendprop u32 (void *fdt, int nodeoffset, const char *name, uint32 t val)
- static int fdt_appendprop_u64 (void *fdt, int nodeoffset, const char *name, uint64_t val)
- static int fdt_appendprop_cell (void *fdt, int nodeoffset, const char *name, uint32_t val)

: name of property to add

fdt_property_placeholder - add a new property and return a ptr to its value

: pointer to the device tree blob

: length of property value in bytes : returns a pointer to where where the value should be placed

returns: 0, on success -FDT ERR BADMAGIC, -FDT ERR NOSPACE, standard meanings

- #define fdt_property_string(fdt, name, str) fdt_property(fdt, name, str, strlen(str)+1)
- int fdt_property_placeholder (void *fdt, const char *name, int len, void **valp)
- int fdt end node (void *fdt)
- int fdt finish (void *fdt)
- int fdt_create_empty_tree (void *buf, int bufsize)
- int fdt_open_into (const void *fdt, void *buf, int bufsize)
- int fdt pack (void *fdt)
- int fdt_add_mem_rsv (void *fdt, uint64_t address, uint64_t size)
- int fdt_del_mem_rsv (void *fdt, int n)

21.90.1 Macro Definition Documentation

21.90.1.1 fdt_appendprop_string

21.90.1.2 fdt_boot_cpuid_phys

21.90.1.3 FDT_ERR_BADLAYOUT

#define FDT_ERR_BADLAYOUT 12

21.90.1.4 FDT_ERR_BADMAGIC

#define FDT_ERR_BADMAGIC 9

21.90.1.5 FDT_ERR_BADNCELLS

#define FDT_ERR_BADNCELLS 14

21.90.1.6 FDT_ERR_BADOFFSET

#define FDT_ERR_BADOFFSET 4

21.90.1.7 FDT_ERR_BADOVERLAY

#define FDT_ERR_BADOVERLAY 16

21.90.1.8 FDT_ERR_BADPATH

#define FDT_ERR_BADPATH 5

21.90.1.9 FDT_ERR_BADPHANDLE

#define FDT_ERR_BADPHANDLE 6

21.90.1.10 FDT_ERR_BADSTATE

#define FDT_ERR_BADSTATE 7

21.90.1.11 FDT_ERR_BADSTRUCTURE

#define FDT_ERR_BADSTRUCTURE 11

21.90.1.12 FDT_ERR_BADVALUE

#define FDT_ERR_BADVALUE 15

21.90.1.13 FDT_ERR_BADVERSION

#define FDT_ERR_BADVERSION 10

21.90.1.14 FDT_ERR_EXISTS

#define FDT_ERR_EXISTS 2

21.90.1.15 FDT_ERR_INTERNAL

#define FDT_ERR_INTERNAL 13

21.90.1.16 FDT_ERR_MAX

#define FDT_ERR_MAX 17

21.90.1.17 FDT_ERR_NOPHANDLES

#define FDT_ERR_NOPHANDLES 17

21.90.1.18 FDT_ERR_NOSPACE

#define FDT_ERR_NOSPACE 3

21.90.1.19 FDT_ERR_NOTFOUND

```
#define FDT_ERR_NOTFOUND 1
```

21.90.1.20 FDT_ERR_TRUNCATED

```
#define FDT_ERR_TRUNCATED 8
```

21.90.1.21 FDT_FIRST_SUPPORTED_VERSION

```
#define FDT_FIRST_SUPPORTED_VERSION 0x02
```

21.90.1.22 fdt_for_each_property_offset

Value:

fdt_for_each_property_offset - iterate over all properties of a node

```
: property offset (int, Ivalue) : FDT blob (const void *) : node offset (int)
```

This is actually a wrapper around a for loop and would be used like so:

```
fdt_for_each_property_offset(property, fdt, node) { Use property ... }
```

```
if ((property < 0) && (property != -FDT_ERR_NOTFOUND)) { Error handling }
```

Note that this is implemented as a macro and property is used as iterator in the loop. The node variable can be constant or even a literal.

```
21.90.1.23 fdt_for_each_subnode
```

Value:

```
for (node = fdt_first_subnode(fdt, parent);
    node >= 0;
    node = fdt_next_subnode(fdt, node))
```

fdt_for_each_subnode - iterate over all subnodes of a parent

```
: child node (int, Ivalue) : FDT blob (const void *) : parent node (int)
```

This is actually a wrapper around a for loop and would be used like so:

```
fdt\_for\_each\_subnode(node,\,fdt,\,parent)\;\{\;Use\;node\;...\;\}
```

```
if ((node < 0) && (node != -FDT_ERR_NOTFOUND)) { Error handling }
```

Note that this is implemented as a macro and is used as iterator in the loop. The parent variable be constant or even a literal.

21.90.1.24 fdt_get_header

21.90.1.25 fdt_last_comp_version

21.90.1.26 FDT_LAST_SUPPORTED_VERSION

```
#define FDT_LAST_SUPPORTED_VERSION 0x11
```

21.90.1.27 fdt_magic

```
21.90.1.28 FDT_MAX_NCELLS
```

```
#define FDT_MAX_NCELLS 4
```

FDT_MAX_NCELLS - maximum value for #address-cells and #size-cells

This is the maximum value for #address-cells, #size-cells and similar properties that will be processed by libfdt. IEE1275 requires that OF implementations handle values up to 4. Implementations may support larger values, but in practice higher values aren't used.

```
21.90.1.29 fdt_off_dt_strings
#define fdt_off_dt_strings(
               fdt ) (fdt_get_header(fdt, off_dt_strings))
21.90.1.30 fdt_off_dt_struct
#define fdt_off_dt_struct(
               fdt ) (fdt_get_header(fdt, off_dt_struct))
21.90.1.31 fdt_off_mem_rsvmap
#define fdt_off_mem_rsvmap(
                fdt ) (fdt_get_header(fdt, off_mem_rsvmap))
21.90.1.32 fdt_property_string
#define fdt_property_string(
               fdt,
               str ) fdt_property(fdt, name, str, strlen(str)+1)
21.90.1.33 fdt_set_hdr_
#define fdt_set_hdr_(
               name )
Value:
static inline void fdt_set_##name(void *fdt, uint32_t val) \
        struct fdt_header *fdth = (struct fdt_header *)fdt; \
fdth->name = cpu_to_fdt32(val); \
    }
```

21.90.1.34 fdt_setprop_empty

21.90.1.35 fdt_setprop_string

21.90.1.36 fdt_size_dt_strings

21.90.1.37 fdt_size_dt_struct


21.90.1.38 fdt_totalsize

21.90.1.39 fdt_version

21.90.2 Function Documentation

21.90.2.1 fdt32_ld()


Here is the caller graph for this function:



21.90.2.2 fdt64_ld()



Here is the caller graph for this function:




21.90.2.3 fdt_add_mem_rsv()

fdt_add_mem_rsv - add one memory reserve map entry : pointer to the device tree blob , : 64-bit values (native endian)

Adds a reserve map entry to the given blob reserving a region at address address of length size.

This function will insert data into the reserve map and will therefore change the indexes of some entries in the table.

returns: 0, on success -FDT_ERR_NOSPACE, there is insufficient free space in the blob to contain the new reservation entry -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADST← RUCTURE, -FDT_ERR_BADLAYOUT, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:



21.90.2.4 fdt_add_reservemap_entry()

Here is the call graph for this function:




Here is the caller graph for this function:




21.90.2.5 fdt_add_subnode()

```
int fdt_add_subnode (
     void * fdt,
     int parentoffset,
     const char * name )
```




Here is the caller graph for this function:



21.90.2.6 fdt_add_subnode_namelen()

Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.7 fdt_address_cells()

fdt_address_cells - retrieve address size for a bus represented in the tree : pointer to the device tree blob : offset of the node to find the address size for


When the node has a valid #address-cells property, returns its value.


returns: $0 \le n < \text{FDT_MAX_NCELLS}$, on success 2, if the node has no #address-cells property -FDT_ERR_BA \leftarrow DNCELLS, if the node has a badly formatted or invalid #address-cells property -FDT_ERR_BADMAGIC, -FDT_E \leftarrow RR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:



21.90.2.8 fdt_appendprop()

Here is the call graph for this function:






21.90.2.9 fdt_appendprop_cell()


fdt_appendprop_cell - append a single cell value to a property

This is an alternative name for fdt appendprop u32() Here is the call graph for this function:



21.90.2.10 fdt_appendprop_u32()


Here is the call graph for this function:






21.90.2.11 fdt_appendprop_u64()


Here is the call graph for this function:



21.90.2.12 fdt_begin_node()


Here is the call graph for this function:






21.90.2.13 fdt_check_full()

Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.14 fdt_check_header()


```
int fdt_check_header ( {\tt const\ void\ *\ fdt\ )}
```

fdt_check_header - sanity check a device tree header


: pointer to data which might be a flattened device tree

fdt_check_header() checks that the given buffer contains what appears to be a flattened device tree, and that the header contains valid information (to the extent that can be determined from the header alone).


returns: 0, if the buffer appears to contain a valid device tree -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_TRUNCATED, standard meanings, as above Here is the call graph for this function:



Here is the caller graph for this function:




21.90.2.15 fdt_create()



21.90.2.16 fdt_create_empty_tree()

Here is the call graph for this function:



21.90.2.17 fdt_del_mem_rsv()


```
int fdt_del_mem_rsv ( \mbox{void} \ * \ fdt, \\ \mbox{int} \ n \ )
```

fdt_del_mem_rsv - remove a memory reserve map entry : pointer to the device tree blob : entry to remove

fdt_del_mem_rsv() removes the n-th memory reserve map entry from the blob.

This function will delete data from the reservation table and will therefore change the indexes of some entries in the table.

returns: 0, on success -FDT_ERR_NOTFOUND, there is no entry of the given index (i.e. there are less than n+1 reserve map entries) -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ER R_BADSTRUCTURE, -FDT_ERR_BADLAYOUT, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:




21.90.2.18 fdt_del_node()

fdt_del_node - delete a node (subtree) : pointer to the device tree blob : offset of the node to nop

fdt del node() will remove the given node, including all its subnodes if any, from the blob.

This function will delete data from the blob, and will therefore change the offsets of some existing nodes.

returns: 0, on success -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ER¢ R_BADLAYOUT, -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BCTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:



21.90.2.19 fdt_delprop()


```
int fdt_delprop (
     void * fdt,
     int nodeoffset,
     const char * name )
```



21.90.2.20 fdt_end_node()

```
int fdt_end_node ( \mbox{void} \ * \ fdt \ )
```

Here is the call graph for this function:




Here is the caller graph for this function:




21.90.2.21 fdt_finish()

```
int fdt_finish ( void * fdt )
```




Here is the caller graph for this function:




21.90.2.22 fdt_finish_reservemap()

```
int fdt_finish_reservemap (  {\tt void} \, * \, {\it fdt} \, \, )
```

Here is the call graph for this function:







21.90.2.23 fdt_first_property_offset()

fdt_first_property_offset - find the offset of a node's first property : pointer to the device tree blob : structure block offset of a node

fdt_first_property_offset() finds the first property of the node at the given structure block offset.

returns: structure block offset of the property (>=0), on success -FDT_ERR_NOTFOUND, if the requested node has no properties -FDT_ERR_BADOFFSET, if nodeoffset did not point to an FDT_BEGIN_NODE tag -FDT_ER← R_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ER← R_TRUNCATED, standard meanings. Here is the call graph for this function:





21.90.2.24 fdt_first_subnode()

fdt first subnode() - get offset of first direct subnode

: FDT blob : Offset of node to check


Returns

offset of first subnode, or -FDT_ERR_NOTFOUND if there is none

Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.25 fdt_get_alias()



Here is the caller graph for this function:




21.90.2.26 fdt_get_alias_namelen()

```
const char* fdt_get_alias_namelen (
                const void * fdt,
                 const char * name,
                 int namelen )
```

Here is the call graph for this function:





21.90.2.27 fdt_get_max_phandle()


fdt_get_max_phandle - retrieves the highest phandle in a tree : pointer to the device tree blob

fdt_get_max_phandle retrieves the highest phandle in the given device tree. This will ignore badly formatted phandles, or phandles with a value of 0 or -1.

returns: the highest phandle on success 0, if no phandle was found in the device tree -1, if an error occurred Here is the call graph for this function:



Here is the caller graph for this function:




21.90.2.28 fdt_get_mem_rsv()


 $fdt_get_mem_rsv$ - retrieve one memory reserve map entry : pointer to the device tree blob , : pointers to 64-bit variables

On success, *address and *size will contain the address and size of the n-th reserve map entry from the device tree blob, in native-endian format.

returns: 0, on success -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:





21.90.2.29 fdt_get_name()

fdt_get_name - retrieve the name of a given node : pointer to the device tree blob : structure block offset of the starting node : pointer to an integer variable (will be overwritten) or NULL

fdt_get_name() retrieves the name (including unit address) of the device tree node at structure block offset nodeoffset. If lenp is non-NULL, the length of this name is also returned, in the integer pointed to by lenp.

returns: pointer to the node's name, on success If lenp is non-NULL, *lenp contains the length of that name (>=0) NULL, on error if lenp is non-NULL *lenp contains an error code (<0): -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTA TE, standard meanings Here is the call graph for this function:






21.90.2.30 fdt_get_path()

fdt_get_path - determine the full path of a node : pointer to the device tree blob : offset of the node whose path to find : character buffer to contain the returned path (will be overwritten) : size of the character buffer at buf


fdt get path() computes the full path of the node at offset nodeoffset, and records that path in the buffer at buf.

NOTE: This function is expensive, as it must scan the device tree structure from the start to nodeoffset.

returns: 0, on success buf contains the absolute path of the node at nodeoffset, as a NUL-terminated string. -F ← DT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_NOSPACE, the path of the given node is longer than (bufsize-1) characters and will not fit in the given buffer. -FDT_ERR_BADMAGIC, -FD ← T_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:




21.90.2.31 fdt_get_phandle()

fdt_get_phandle - retrieve the phandle of a given node : pointer to the device tree blob : structure block offset of the node

fdt_get_phandle() retrieves the phandle of the device tree node at structure block offset nodeoffset.


returns: the phandle of the node at nodeoffset, on success (!= 0, != -1) 0, if the node has no phandle, or another error occurs Here is the call graph for this function:





21.90.2.32 fdt_get_property()

Here is the call graph for this function:



Here is the caller graph for this function:




21.90.2.33 fdt_get_property_by_offset()

fdt_get_property_by_offset - retrieve the property at a given offset : pointer to the device tree blob : offset of the property to retrieve : pointer to an integer variable (will be overwritten) or NULL

fdt_get_property_by_offset() retrieves a pointer to the fdt_property structure within the device tree blob at the given offset. If lenp is non-NULL, the length of the property value is also returned, in the integer pointed to by lenp.


Note that this code only works on device tree versions >= 16. fdt_getprop() works on all versions.

returns: pointer to the structure representing the property if lenp is non-NULL, *lenp contains the length of the property value (>=0) NULL, on error if lenp is non-NULL, *lenp contains an error code (<0): -FDT_ERR_BADO FFSET, nodeoffset did not point to FDT_PROP tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_FRR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:



21.90.2.34 fdt_get_property_namelen()

Here is the call graph for this function:





21.90.2.35 fdt_get_property_w()

Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.36 fdt_get_string()


fdt_get_string - retrieve a string from the strings block of a device tree : pointer to the device tree blob : offset of the string within the strings block (native endian) : optional pointer to return the string's length

fdt_get_string() retrieves a pointer to a single string from the strings block of the device tree blob at fdt, and optionally also returns the string's length in *lenp.

returns: a pointer to the string, on success NULL, if stroffset is out of bounds, or doesn't point to a valid string Here is the call graph for this function:




Here is the caller graph for this function:



21.90.2.37 fdt_getprop()






21.90.2.38 fdt_getprop_by_offset()

```
const void* fdt_getprop_by_offset (
    const void * fdt,
    int offset,
    const char ** namep,
    int * lenp )
```


fdt_getprop_by_offset - retrieve the value of a property at a given offset : pointer to the device tree blob : offset of the property to read : pointer to a string variable (will be overwritten) or NULL : pointer to an integer variable (will be overwritten) or NULL

fdt_getprop_by_offset() retrieves a pointer to the value of the property at structure block offset 'offset' (this will be a pointer to within the device blob itself, not a copy of the value). If lenp is non-NULL, the length of the property value is also returned, in the integer pointed to by lenp. If namep is non-NULL, the property's namne will also be returned in the char * pointed to by namep (this will be a pointer to within the device tree's string block, not a new copy of the name).


returns: pointer to the property's value if lenp is non-NULL, *lenp contains the length of the property value (>=0) if namep is non-NULL *namep contains a pointer to the property name. NULL, on error if lenp is non-NULL, *lenp contains an error code (<0): -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_PROP tag -FDT_ERR_\top BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_\top TRUNCATED, standard meanings Here is the call graph for this function:




Here is the caller graph for this function:



21.90.2.39 fdt_getprop_namelen()





21.90.2.40 fdt_getprop_namelen_w()


Here is the call graph for this function:







21.90.2.41 fdt_getprop_w()

Here is the call graph for this function:




21.90.2.42 fdt_header_size()





21.90.2.43 fdt_header_size_()

fdt_header_size - return the size of the tree's header : pointer to a flattened device tree Here is the caller graph for this function:




21.90.2.44 fdt_move()

fdt_move - move a device tree around in memory : pointer to the device tree to move : pointer to memory where the device is to be moved : size of the memory space at buf


fdt_move() relocates, if possible, the device tree blob located at fdt to the buffer at buf of size bufsize. The buffer may overlap with the existing device tree blob at fdt. Therefore, fdt_move(fdt, fdt, fdt_totalsize(fdt)) should always succeed.

returns: 0, on success -FDT_ERR_NOSPACE, bufsize is insufficient to contain the device tree -FDT_ERR_BAD ← MAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, standard meanings Here is the caller graph for this function:



21.90.2.45 fdt_next_node()






21.90.2.46 fdt_next_property_offset()


fdt_next_property_offset - step through a node's properties : pointer to the device tree blob : structure block offset of a property

fdt_next_property_offset() finds the property immediately after the one at the given structure block offset. This will be a property of the same node as the given property.

returns: structure block offset of the next property (>=0), on success -FDT_ERR_NOTFOUND, if the given property is the last in its node -FDT_ERR_BADOFFSET, if nodeoffset did not point to an FDT_PROP tag -FDT_ERR_BA⇔ DMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TR⇔ UNCATED, standard meanings. Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.47 fdt_next_subnode()

fdt_next_subnode() - get offset of next direct subnode


After first calling fdt_first_subnode(), call this function repeatedly to get direct subnodes of a parent node.

: FDT blob : Offset of previous subnode


Returns

offset of next subnode, or -FDT_ERR_NOTFOUND if there are no more subnodes $% \left(1\right) =\left(1\right) \left(1\right)$






21.90.2.48 fdt_next_tag()



Here is the caller graph for this function:




21.90.2.49 fdt_node_check_compatible()

fdt_node_check_compatible: check a node's compatible property : pointer to the device tree blob : offset of a tree node : string to match against

fdt_node_check_compatible() returns 0 if the given node contains a 'compatible' property with the given string as one of its elements, it returns non-zero otherwise, or on error.

returns: 0, if the node has a 'compatible' property listing the given string 1, if the node has a 'compatible' property, but it does not list the given string -FDT_ERR_NOTFOUND, if the given node has no 'compatible' property -FDT ← _ERR_BADOFFSET, if nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_B ← ADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:





21.90.2.50 fdt_node_depth()

fdt_node_depth - find the depth of a given node : pointer to the device tree blob : offset of the node whose parent to find

fdt_node_depth() finds the depth of a given node. The root node has depth 0, its immediate subnodes depth 1 and so forth.

NOTE: This function is expensive, as it must scan the device tree structure from the start to nodeoffset.

returns: depth of the node at nodeoffset (>=0), on success -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR← _BADSTRUCTURE, standard meanings Here is the call graph for this function:





21.90.2.51 fdt_node_offset_by_compatible()

fdt_node_offset_by_compatible - find nodes with a given 'compatible' value : pointer to the device tree blob : only find nodes after this offset : 'compatible' string to match against


fdt_node_offset_by_compatible() returns the offset of the first node after startoffset, which has a 'compatible' property which lists the given compatible string; or if startoffset is -1, the very first such node in the tree.

To iterate through all nodes matching the criterion, the following idiom can be used: offset = fdt_node_offset_by_ \hookleftarrow compatible(fdt, -1, compatible); while (offset != -FDT_ERR_NOTFOUND) { // other code here offset = fdt_node_ \hookleftarrow offset_by_compatible(fdt, offset, compatible); }

Note the -1 in the first call to the function, if 0 is used here instead, the function will never locate the root node, even if it matches the criterion.

returns: structure block offset of the located node (>= 0, >startoffset), on success -FDT_ERR_NOTFOUND, no node matching the criterion exists in the tree after startoffset -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_E RR_BADSTRUCTURE, standard meanings Here is the call graph for this function:






21.90.2.52 fdt_node_offset_by_phandle()


fdt_node_offset_by_phandle - find the node with a given phandle : pointer to the device tree blob : phandle value

fdt_node_offset_by_phandle() returns the offset of the node which has the given phandle value. If there is more than one node in the tree with the given phandle (an invalid tree), results are undefined.

returns: structure block offset of the located node (>= 0), on success -FDT_ERR_NOTFOUND, no node with that phandle exists -FDT_ERR_BADPHANDLE, given phandle value was invalid (0 or -1) -FDT_ERR_BADMAGIC, -F \leftarrow DT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.53 fdt_node_offset_by_prop_value()


fdt_node_offset_by_prop_value - find nodes with a given property value : pointer to the device tree blob : only find nodes after this offset : property name to check : property value to search for : length of the value in propval

fdt_node_offset_by_prop_value() returns the offset of the first node after startoffset, which has a property named propname whose value is of length proplen and has value equal to propval; or if startoffset is -1, the very first such node in the tree.

To iterate through all nodes matching the criterion, the following idiom can be used: offset = fdt_node_offset_← by_prop_value(fdt, -1, propname, propval, proplen); while (offset != -FDT_ERR_NOTFOUND) { // other code here offset = fdt_node_offset_by_prop_value(fdt, offset, propname, propval, proplen); }

Note the -1 in the first call to the function, if 0 is used here instead, the function will never locate the root node, even if it matches the criterion.

returns: structure block offset of the located node (>= 0, >startoffset), on success -FDT_ERR_NOTFOUND, no node matching the criterion exists in the tree after startoffset -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_E RR_BADSTRUCTURE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:

```
fdt_node_offset_by _____fdt_getprop_w
```


21.90.2.54 fdt_nop_node()

fdt nop node - replace a node (subtree) with nop tags : pointer to the device tree blob : offset of the node to nop

fdt_nop_node() will replace a given node's representation in the blob, including all its subnodes, if any, with FDT \(\to \) NOP tags, effectively removing it from the tree.

This function will alter only the bytes in the blob which contain the node and its properties and subnodes, and will not alter or move any other part of the tree.

returns: 0, on success -FDT_ERR_BADOFFSET, nodeoffset did not point to FDT_BEGIN_NODE tag -FDT_ER⇔ R_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ER⇔ R_TRUNCATED, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.55 fdt_nop_property()

Here is the call graph for this function:






21.90.2.56 fdt_num_mem_rsv()

```
int fdt_num_mem_rsv ( {\tt const\ void\ *\ fdt\ )}
```


fdt_num_mem_rsv - retrieve the number of memory reserve map entries : pointer to the device tree blob

Returns the number of entries in the device tree blob's memory reservation map. This does not include the terminating 0,0 entry or any other (0,0) entries reserved for expansion.

returns: the number of entries Here is the call graph for this function:




Here is the caller graph for this function:



21.90.2.57 fdt_offset_ptr()




Here is the caller graph for this function:




21.90.2.58 fdt_offset_ptr_w()

Here is the call graph for this function:




Here is the caller graph for this function:



21.90.2.59 fdt_open_into()

Here is the call graph for this function:






21.90.2.60 fdt_overlay_apply()

fdt_overlay_apply - Applies a DT overlay on a base DT : pointer to the base device tree blob : pointer to the device tree overlay blob

fdt_overlay_apply() will apply the given device tree overlay on the given base device tree.


Expect the base device tree to be modified, even if the function returns an error.

returns: 0, on success -FDT_ERR_NOSPACE, there's not enough space in the base device tree -FDT_ERR_ ← NOTFOUND, the overlay points to some inexistant nodes or properties in the base DT -FDT_ERR_BADPHAN ← DLE, -FDT_ERR_BADOVERLAY, -FDT_ERR_NOPHANDLES, -FDT_ERR_INTERNAL, -FDT_ERR_BADLAYOUT, -FDT_ERR_BADMAGIC, -FDT_ERR_BADOFFSET, -FDT_ERR_BADPATH, -FDT_ERR_BADVERSION, -FDT_ ← ERR_BADSTRUCTURE, -FDT_ERR_BADSTATE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:



21.90.2.61 fdt_pack()

```
int fdt_pack ( \mbox{void} \ * \ fdt \ )
```



21.90.2.62 fdt_parent_offset()

fdt_parent_offset - find the parent of a given node : pointer to the device tree blob : offset of the node whose parent to find

fdt_parent_offset() locates the parent node of a given node (that is, it finds the offset of the node which contains the node at nodeoffset as a subnode).

NOTE: This function is expensive, as it must scan the device tree structure from the start to nodeoffset, twice.

returns: structure block offset of the parent of the node at nodeoffset (>=0), on success -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_E← RR_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.63 fdt_path_offset()


fdt_path_offset - find a tree node by its full path : pointer to the device tree blob : full path of the node to locate

fdt_path_offset() finds a node of a given path in the device tree. Each path component may omit the unit address portion, but the results of this are undefined if any such path component is ambiguous (that is if there are multiple nodes at the relevant level matching the given component, differentiated only by unit address).

returns: structure block offset of the node with the requested path (>=0), on success -FDT_ERR_BADPATH, given path does not begin with '/' or is invalid -FDT_ERR_NOTFOUND, if the requested node does not exist -FDT_ER← R_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ER← R_TRUNCATED, standard meanings. Here is the call graph for this function:



Here is the caller graph for this function:




21.90.2.64 fdt_path_offset_namelen()

fdt_path_offset_namelen - find a tree node by its full path : pointer to the device tree blob : full path of the node to locate : number of characters of path to consider

Identical to fdt_path_offset(), but only consider the first namelen characters of path as the path name. Here is the call graph for this function:





Here is the caller graph for this function:



21.90.2.65 fdt_property()


Here is the call graph for this function:






21.90.2.66 fdt_property_cell()


Here is the call graph for this function:



21.90.2.67 fdt_property_placeholder()


Here is the call graph for this function:





21.90.2.68 fdt_property_u32()


Here is the call graph for this function:




Here is the caller graph for this function:



21.90.2.69 fdt_property_u64()




```
21.90.2.70 fdt_resize()
```



```
21.90.2.75 fdt_set_hdr_() [5/10]
fdt_set_hdr_ (
         off_mem_rsvmap )
21.90.2.76 fdt_set_hdr_() [6/10]
fdt_set_hdr_ (
           version )
21.90.2.77 fdt_set_hdr_() [7/10]
fdt_set_hdr_ (
           last_comp_version )
21.90.2.78 fdt_set_hdr_() [8/10]
fdt_set_hdr_ (
            boot_cpuid_phys )
21.90.2.79 fdt_set_hdr_() [9/10]
fdt_set_hdr_ (
            size_dt_strings )
21.90.2.80 fdt_set_hdr_() [10/10]
fdt_set_hdr_ (
           size_dt_struct )
```


21.90.2.81 fdt_set_name()


Here is the call graph for this function:



21.90.2.82 fdt_setprop()

Here is the call graph for this function:






21.90.2.83 fdt_setprop_cell()

fdt_setprop_cell - set a property to a single cell value

This is an alternative name for fdt_setprop_u32() Here is the call graph for this function:



21.90.2.84 fdt_setprop_inplace()

```
int fdt_setprop_inplace (
    void * fdt,
    int nodeoffset,
    const char * name,
    const void * val,
    int len )
```

Here is the call graph for this function:






21.90.2.85 fdt_setprop_inplace_cell()

fdt_setprop_inplace_cell - change the value of a single-cell property


This is an alternative name for fdt_setprop_inplace_u32() Here is the call graph for this function:



21.90.2.86 fdt_setprop_inplace_namelen_partial()


Here is the call graph for this function:





21.90.2.87 fdt_setprop_inplace_u32()


Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.88 fdt_setprop_inplace_u64()




21.90.2.89 fdt_setprop_placeholder()

```
int fdt_setprop_placeholder (
    void * fdt,
    int nodeoffset,
    const char * name,
    int len,
    void ** prop_data )
```


Here is the call graph for this function:



Here is the caller graph for this function:



21.90.2.90 fdt_setprop_u32()



Here is the caller graph for this function:



21.90.2.91 fdt_setprop_u64()

Here is the call graph for this function:



21.90.2.92 fdt_size_cells()

fdt_size_cells - retrieve address range size for a bus represented in the tree : pointer to the device tree blob : offset of the node to find the address range size for

When the node has a valid #size-cells property, returns its value.

returns: $0 \le n \le PDT_MAX_NCELLS$, on success 1, if the node has no #size-cells property -FDT_ERR_B \leftrightarrow ADNCELLS, if the node has a badly formatted or invalid #size-cells property -FDT_ERR_BADMAGIC, -FDT_E \leftrightarrow RR_BADVERSION, -FDT_ERR_BADSTATE, -FDT_ERR_BADSTRUCTURE, -FDT_ERR_TRUNCATED, standard meanings Here is the call graph for this function:




21.90.2.93 fdt_strerror()


21.90.2.94 fdt_string()

fdt_string - retrieve a string from the strings block of a device tree : pointer to the device tree blob : offset of the string within the strings block (native endian)

fdt_string() retrieves a pointer to a single string from the strings block of the device tree blob at fdt.

returns: a pointer to the string, on success NULL, if stroffset is out of bounds, or doesn't point to a valid string Here is the call graph for this function:





21.90.2.95 fdt_stringlist_contains()


fdt_stringlist_contains - check a string list property for a string : Property containing a list of strings to check : Length of property : String to search for

This is a utility function provided for convenience. The list contains one or more strings, each terminated by \0, as is found in a device tree "compatible" property.

Returns

: 1 if the string is found in the list, 0 not found, or invalid list


Here is the caller graph for this function:



21.90.2.96 fdt_stringlist_count()



Here is the caller graph for this function:



21.90.2.97 fdt_stringlist_get()

Here is the call graph for this function:





21.90.2.98 fdt_stringlist_search()


Here is the call graph for this function:




Here is the caller graph for this function:



21.90.2.99 fdt_subnode_offset()





Here is the caller graph for this function:



21.90.2.100 fdt_subnode_offset_namelen()

Here is the call graph for this function:





21.90.2.101 fdt_supernode_atdepth_offset()

fdt_supernode_atdepth_offset - find a specific ancestor of a node : pointer to the device tree blob : offset of the node whose parent to find : depth of the ancestor to find : pointer to an integer variable (will be overwritten) or NULL

fdt_supernode_atdepth_offset() finds an ancestor of the given node at a specific depth from the root (where the root itself has depth 0, its immediate subnodes depth 1 and so forth). So fdt_supernode_atdepth_offset(fdt, nodeoffset, 0, NULL); will always return 0, the offset of the root node. If the node at nodeoffset has depth D, then: fdt_\circ
supernode_atdepth_offset(fdt, nodeoffset, D, NULL); will return nodeoffset itself.

NOTE: This function is expensive, as it must scan the device tree structure from the start to nodeoffset.

returns: structure block offset of the node at node offset's ancestor of depth supernodedepth (>=0), on success -FDT_ERR_BADOFFSET, nodeoffset does not refer to a BEGIN_NODE tag -FDT_ERR_NOTFOUND, supernodedepth was greater than the depth of nodeoffset -FDT_ERR_BADMAGIC, -FDT_ERR_BADVERSION, -FDT_ER← R_BADSTATE, -FDT_ERR_BADSTRUCTURE, standard meanings Here is the call graph for this function:




Here is the caller graph for this function:



21.91 lib/utils/libfdt/libfdt_env.h File Reference

```
#include <sbi/sbi_string.h>
#include <sbi/sbi_types.h>
```

Include dependency graph for libfdt_env.h:



This graph shows which files directly or indirectly include this file:



Macros

- #define INT_MAX ((int)(\sim 0U >> 1))
- #define UINT_MAX ((unsigned int)~0U)
- #define FDT_FORCE
- #define FDT_BITWISE
- #define memmove sbi_memmove
- #define memcpy sbi_memcpy
- #define memcmp sbi_memcmp
- #define memchr sbi_memchr
- · #define memset sbi_memset
- #define strchr sbi_strchr
- #define strrchr sbi_strrchr
- #define strcpy sbi_strcpy
- #define strcmp sbi_strcmp
- #define strlen sbi_strlen
- #define strnlen sbi_strnlen
- #define EXTRACT_BYTE(x, n) ((unsigned long long)((uint8_t *)&x)[n])
- #define CPU_TO_FDT16(x) ((EXTRACT_BYTE(x, 0) << 8) | EXTRACT_BYTE(x, 1))
- #define CPU TO FDT32(x)
- #define CPU_TO_FDT64(x)

Typedefs

```
• typedef uint16_t FDT_BITWISE fdt16_t
```

- typedef uint32_t FDT_BITWISE fdt32_t
- typedef uint64_t FDT_BITWISE fdt64_t

Functions

```
    static uint16_t fdt16_to_cpu (fdt16_t x)
```

- static fdt16_t cpu_to_fdt16 (uint16_t x)
- static uint32_t fdt32_to_cpu (fdt32_t x)
- static fdt32_t cpu_to_fdt32 (uint32_t x)
- static uint64_t fdt64_to_cpu (fdt64_t x)
- static fdt64_t cpu_to_fdt64 (uint64_t x)

21.91.1 Macro Definition Documentation

```
21.91.1.1 CPU_TO_FDT16
```

21.91.1.2 CPU_TO_FDT32

```
#define CPU_TO_FDT32(
     x )
```

Value:

21.91.1.3 CPU_TO_FDT64

```
#define CPU_TO_FDT64(
     x )
```

Value:

21.91.1.4 EXTRACT_BYTE

21.91.1.5 FDT_BITWISE

#define FDT_BITWISE

21.91.1.6 FDT_FORCE

#define FDT_FORCE

21.91.1.7 INT_MAX

#define INT_MAX ((int)(\sim 0U >> 1))

21.91.1.8 memchr

#define memchr sbi_memchr

21.91.1.9 memcmp

#define memcmp sbi_memcmp

21.91.1.10 memcpy

#define memcpy sbi_memcpy

21.91.1.11 memmove #define memmove sbi_memmove 21.91.1.12 memset #define memset sbi_memset 21.91.1.13 strchr #define strchr sbi_strchr 21.91.1.14 strcmp #define strcmp sbi_strcmp 21.91.1.15 strcpy #define strcpy sbi_strcpy 21.91.1.16 strlen #define strlen sbi_strlen 21.91.1.17 strnlen #define strnlen sbi_strnlen 21.91.1.18 strrchr

#define strrchr sbi_strrchr

```
21.91.1.19 UINT_MAX
```

```
#define UINT_MAX ((unsigned int)\sim0U)
```

21.91.2 Typedef Documentation

21.91.2.1 fdt16_t

```
typedef uint16_t FDT_BITWISE fdt16_t
```

21.91.2.2 fdt32_t

```
typedef uint32_t FDT_BITWISE fdt32_t
```

21.91.2.3 fdt64_t


```
typedef uint64_t FDT_BITWISE fdt64_t
```

21.91.3 Function Documentation


21.91.3.1 cpu_to_fdt16()

21.91.3.2 cpu_to_fdt32()

Here is the caller graph for this function:




21.91.3.3 cpu_to_fdt64()



21.91.3.4 fdt16_to_cpu()

21.91.3.5 fdt32_to_cpu()

Here is the caller graph for this function:




21.91.3.6 fdt64_to_cpu()


21.92 lib/utils/libfdt/libfdt_internal.h File Reference

#include <fdt.h>

Include dependency graph for libfdt_internal.h:



This graph shows which files directly or indirectly include this file:



Macros

- #define FDT_ALIGN(x, a) (((x) + (a) 1) & \sim ((a) 1))
- #define FDT_TAGALIGN(x) (FDT_ALIGN((x), FDT_TAGSIZE))
- #define FDT_RO_PROBE(fdt)
- #define FDT_SW_MAGIC (~FDT_MAGIC)

Functions

- int fdt_ro_probe_ (const void *fdt)
- int fdt check node offset (const void *fdt, int offset)
- int fdt_check_prop_offset_ (const void *fdt, int offset)
- const char * fdt_find_string_ (const char *strtab, int tabsize, const char *s)
- int fdt_node_end_offset_ (void *fdt, int nodeoffset)
- static const void * fdt_offset_ptr_ (const void *fdt, int offset)
- static void * fdt_offset_ptr_w_ (void *fdt, int offset)
- static const struct fdt_reserve_entry * fdt_mem_rsv_ (const void *fdt, int n)
- static struct fdt_reserve_entry * fdt_mem_rsv_w_ (void *fdt, int n)

21.92.1 Macro Definition Documentation

21.92.1.1 FDT_ALIGN

```
#define FDT_ALIGN(  x, \\ a ) \ (((x) + (a) - 1) \& \sim ((a) - 1))
```

21.92.1.2 FDT_RO_PROBE

Value:

```
f \
    int err_; \
    if ((err_ = fdt_ro_probe_(fdt)) != 0) \
        return err_; \
```

21.92.1.3 FDT_SW_MAGIC


```
#define FDT_SW_MAGIC (\simFDT_MAGIC)
```

21.92.1.4 FDT_TAGALIGN


21.92.2 Function Documentation

21.92.2.1 fdt_check_node_offset_()

Here is the call graph for this function:



Here is the caller graph for this function:




21.92.2.2 fdt_check_prop_offset_()


Here is the call graph for this function:



Here is the caller graph for this function:




21.92.2.3 fdt_find_string_()



21.92.2.4 fdt_mem_rsv_()


Here is the caller graph for this function:



21.92.2.5 fdt_mem_rsv_w_()

Here is the call graph for this function:






21.92.2.6 fdt_node_end_offset_()


Here is the call graph for this function:



Here is the caller graph for this function:



21.92.2.7 fdt_offset_ptr_()




21.92.2.8 fdt_offset_ptr_w_()

Here is the call graph for this function:




Here is the caller graph for this function:



21.92.2.9 fdt_ro_probe_()


Here is the caller graph for this function:



21.93 lib/utils/serial/sifive-uart.c File Reference

```
#include <sbi/riscv_io.h>
#include <sbi/sbi_console.h>
#include <sbi_utils/serial/sifive-uart.h>
```

Include dependency graph for sifive-uart.c:



Macros

• #define UART_REG_TXFIFO 0

- #define UART_REG_RXFIFO 1
- #define UART_REG_TXCTRL 2
- #define UART_REG_RXCTRL 3
- #define UART_REG_IE 4
- #define UART REG IP 5
- #define UART_REG_DIV 6
- #define UART TXFIFO FULL 0x80000000
- #define UART_RXFIFO_EMPTY 0x80000000
- #define UART_RXFIFO_DATA 0x000000ff
- #define UART_TXCTRL_TXEN 0x1
- #define UART_RXCTRL_RXEN 0x1

Functions

- static unsigned int uart min clk divisor (uint64 t in freq, uint64 t max target hz)
- static u32 get_reg (u32 num)
- static void set_reg (u32 num, u32 val)
- void sifive_uart_putc (char ch)
- int sifive_uart_getc (void)
- int sifive_uart_init (unsigned long base, u32 in_freq, u32 baudrate)

Variables

- static volatile void * uart_base
- static u32 uart_in_freq
- static u32 uart_baudrate

21.93.1 Macro Definition Documentation

```
21.93.1.1 UART_REG_DIV
```

#define UART_REG_DIV 6

21.93.1.2 UART_REG_IE

#define UART_REG_IE 4

21.93.1.3 UART_REG_IP

#define UART_REG_IP 5

21.93.1.4 UART_REG_RXCTRL

#define UART_REG_RXCTRL 3

21.93.1.5 UART_REG_RXFIFO

#define UART_REG_RXFIFO 1

21.93.1.6 UART_REG_TXCTRL

#define UART_REG_TXCTRL 2

21.93.1.7 UART_REG_TXFIFO

#define UART_REG_TXFIFO 0

21.93.1.8 UART_RXCTRL_RXEN

#define UART_RXCTRL_RXEN 0x1

21.93.1.9 UART_RXFIFO_DATA

#define UART_RXFIFO_DATA 0x000000ff

21.93.1.10 UART_RXFIFO_EMPTY

#define UART_RXFIFO_EMPTY 0x80000000

21.93.1.11 UART_TXCTRL_TXEN

#define UART_TXCTRL_TXEN 0x1


21.93.1.12 UART_TXFIFO_FULL

```
#define UART_TXFIFO_FULL 0x80000000
```


21.93.2 Function Documentation

```
21.93.2.1 get_reg()
```

Here is the caller graph for this function:



21.93.2.2 set_reg()




21.93.2.3 sifive_uart_getc()

Here is the call graph for this function:




21.93.2.4 sifive_uart_init()

Here is the call graph for this function:



21.93.2.5 sifive_uart_putc()

Here is the call graph for this function:



21.93.2.6 uart_min_clk_divisor()

Find minimum divisor divides in_freq to max_target_hz; Based on uart driver n SiFive FSBL.

 $f_baud = f_in / (div + 1) => div = (f_in / f_baud) - 1$ The nearest integer solution requires rounding up as to not exceed max_target_hz. div = ceil(f_in / f_baud) - 1 = floor((f_in - 1 + f_baud) / f_baud) - 1 This should not overflow as long as (f_in - 1 + f_baud) does not exceed $2^32 - 1$, which is unlikely since we represent frequencies in kHz. Here is the caller graph for this function:



21.93.3 Variable Documentation

21.93.3.1 uart_base

```
volatile void* uart_base [static]
```

21.93.3.2 uart_baudrate


```
u32 uart_baudrate [static]
```

21.93.3.3 uart_in_freq

```
u32 uart_in_freq [static]
```

21.94 lib/utils/serial/uart8250.c File Reference

```
#include <sbi/riscv_io.h>
#include <sbi_utils/serial/uart8250.h>
Include dependency graph for uart8250.c:
```



Macros

- #define UART_RBR_OFFSET 0 /* In: Recieve Buffer Register */
- #define UART_THR_OFFSET 0 /* Out: Transmitter Holding Register */
- #define UART_DLL_OFFSET 0 /* Out: Divisor Latch Low */
- #define UART_IER_OFFSET 1 /* I/O: Interrupt Enable Register */
- #define UART DLM OFFSET 1 /* Out: Divisor Latch High */
- #define UART_FCR_OFFSET 2 /* Out: FIFO Control Register */
- #define UART_IIR_OFFSET 2 /* I/O: Interrupt Identification Register */
- #define UART_LCR_OFFSET 3 /* Out: Line Control Register */
- #define UART_MCR_OFFSET 4 /* Out: Modem Control Register */
- #define UART LSR OFFSET 5 /* In: Line Status Register */
- #define UART_MSR_OFFSET 6 /* In: Modem Status Register */
- #define UART SCR OFFSET 7 /* I/O: Scratch Register */
- #define UART_MDR1_OFFSET 8 /* I/O: Mode Register */

- #define UART_LSR_FIFOE 0x80 /* Fifo error */
- #define UART_LSR_TEMT 0x40 /* Transmitter empty */
- #define UART_LSR_THRE 0x20 /* Transmit-hold-register empty */
- #define UART LSR BI 0x10 /* Break interrupt indicator */
- #define UART LSR FE 0x08 /* Frame error indicator */
- #define UART_LSR_PE 0x04 /* Parity error indicator */
- #define UART_LSR_OE 0x02 /* Overrun error indicator */
- #define UART_LSR_DR 0x01 /* Receiver data ready */
- #define UART_LSR_BRK_ERROR_BITS 0x1E /* BI, FE, PE, OE bits */

Functions

- static u32 get_reg (u32 num)
- static void set reg (u32 num, u32 val)
- void uart8250_putc (char ch)
- int uart8250_getc (void)
- int uart8250_init (unsigned long base, u32 in_freq, u32 baudrate, u32 reg_shift, u32 reg_width)

Variables

- static volatile void * uart8250 base
- static u32 uart8250_in_freq
- static u32 uart8250_baudrate
- static u32 uart8250 reg width
- static u32 uart8250_reg_shift

21.94.1 Macro Definition Documentation

```
21.94.1.1 UART_DLL_OFFSET
```

```
#define UART_DLL_OFFSET 0 /* Out: Divisor Latch Low */
```

21.94.1.2 UART_DLM_OFFSET

#define UART_DLM_OFFSET 1 /* Out: Divisor Latch High */

21.94.1.3 UART_FCR_OFFSET

#define UART_FCR_OFFSET 2 /* Out: FIFO Control Register */

21.94.1.4 UART_IER_OFFSET

#define UART_IER_OFFSET 1 /* I/O: Interrupt Enable Register */

21.94.1.5 UART_IIR_OFFSET

#define UART_IIR_OFFSET 2 /* I/O: Interrupt Identification Register */

21.94.1.6 UART_LCR_OFFSET

#define UART_LCR_OFFSET 3 /* Out: Line Control Register */

21.94.1.7 UART_LSR_BI

#define UART_LSR_BI 0x10 /* Break interrupt indicator */

21.94.1.8 UART_LSR_BRK_ERROR_BITS

 $\#define\ UART_LSR_BRK_ERROR_BITS\ Ox1E\ /*\ BI,\ FE,\ PE,\ OE\ bits\ */$

21.94.1.9 UART_LSR_DR

#define UART_LSR_DR 0x01 /* Receiver data ready */

21.94.1.10 UART_LSR_FE

#define UART_LSR_FE 0x08 /* Frame error indicator */

#define UART_LSR_FIFOE 0x80 /* Fifo error */

21.94.1.12 UART_LSR_OE

```
\#define UART_LSR_OE 0x02 /* Overrun error indicator */
```



```
#define UART_LSR_OFFSET 5 /* In: Line Status Register */
```

21.94.1.14 UART_LSR_PE

```
#define UART_LSR_PE 0x04 /* Parity error indicator */
```



```
#define UART_LSR_TEMT 0x40 /* Transmitter empty */
```



```
\texttt{\#define UART\_LSR\_THRE 0x20 /* Transmit-hold-register empty */}
```

21.94.1.17 UART_MCR_OFFSET

```
#define UART_MCR_OFFSET 4 /* Out: Modem Control Register */
```

21.94.1.18 UART_MDR1_OFFSET

```
#define UART_MDR1_OFFSET 8 /* I/O: Mode Register */
```



```
\#define UART_MSR_OFFSET 6 /* In: Modem Status Register */
```

21.94.1.20 UART_RBR_OFFSET

```
\#define\ UART\_RBR\_OFFSET\ 0\ /*\ In:\ Recieve\ Buffer\ Register\ */
```




```
#define UART_SCR_OFFSET 7 /* I/O: Scratch Register */
```

21.94.1.22 UART_THR_OFFSET

```
#define UART_THR_OFFSET 0 /* Out: Transmitter Holding Register */
```


21.94.2 Function Documentation

21.94.2.1 get_reg()



21.94.2.2 set_reg()

Here is the caller graph for this function:



21.94.2.3 uart8250_getc()

```
int uart8250_getc (
     void )
```


Here is the call graph for this function:



21.94.2.4 uart8250_init()

```
int uart8250_init (
          unsigned long base,
          u32 in_freq,
          u32 baudrate,
          u32 reg_shift,
          u32 reg_width )
```


Here is the call graph for this function:



21.94.2.5 uart8250_putc()

```
void uart8250_putc ( char\ ch )
```

Here is the call graph for this function:



21.94.3 Variable Documentation

21.94.3.1 uart8250_base

```
volatile void* uart8250_base [static]
```

21.94.3.2 uart8250_baudrate

```
u32 uart8250_baudrate [static]
```

21.94.3.3 uart8250_in_freq

```
u32 uart8250_in_freq [static]
```

21.94.3.4 uart8250_reg_shift

```
u32 uart8250_reg_shift [static]
```


21.94.3.5 uart8250_reg_width

```
u32 uart8250_reg_width [static]
```

21.95 lib/utils/sys/clint.c File Reference

```
#include <sbi/riscv_io.h>
#include <sbi/riscv_atomic.h>
#include <sbi/sbi_hart.h>
#include <sbi_utils/sys/clint.h>
```

Include dependency graph for clint.c:



Functions

- void clint_ipi_send (u32 target_hart)
- void clint_ipi_clear (u32 target_hart)
- int clint_warm_ipi_init (void)
- int clint_cold_ipi_init (unsigned long base, u32 hart_count)
- static u64 clint_time_rd64 (volatile u64 *addr)
- static void clint_time_wr64 (u64 value, volatile u64 *addr)
- static u64 clint_time_rd32 (volatile u64 *addr)
- static void clint_time_wr32 (u64 value, volatile u64 *addr)
- u64 clint timer value (void)
- void clint_timer_event_stop (void)
- void clint timer event start (u64 next event)
- int clint_warm_timer_init (void)
- int clint_cold_timer_init (unsigned long base, u32 hart_count, bool has_64bit_mmio)

Variables

```
static u32 clint_ipi_hart_count
static volatile void * clint_ipi_base
static volatile u32 * clint_ipi
static u32 clint_time_hart_count
static volatile void * clint_time_base
static volatile u64 * clint_time_val
static volatile u64 * clint_time_cmp
static u64(* clint_time_rd )(volatile u64 *addr) = clint_time_rd32
static void(* clint_time_wr )(u64 value, volatile u64 *addr) = clint_time_wr32
```

21.95.1 Function Documentation


21.95.1.1 clint_cold_ipi_init()

```
int clint_cold_ipi_init (
          unsigned long base,
          u32 hart_count )
```

21.95.1.2 clint_cold_timer_init()

```
int clint_cold_timer_init (
          unsigned long base,
          u32 hart_count,
          bool has_64bit_mmio )
```

Here is the call graph for this function:



650 File Documentation

21.95.1.3 clint_ipi_clear()

Here is the caller graph for this function:




21.95.1.4 clint_ipi_send()

21.95.1.5 clint_time_rd32()

21.95.1.6 clint_time_rd64()

Here is the caller graph for this function:



21.95.1.7 clint_time_wr32()

```
static void clint_time_wr32 (
          u64 value,
          volatile u64 * addr ) [static]
```

21.95.1.8 clint_time_wr64()


```
static void clint_time_wr64 (  \mbox{u64 } value, \\ \mbox{volatile u64 * } addr \;) \mbox{ [static]}
```

Here is the caller graph for this function:



21.95.1.9 clint_timer_event_start()

Here is the call graph for this function:



File Documentation

21.95.1.10 clint_timer_event_stop()


Here is the call graph for this function:



21.95.1.11 clint_timer_value()

21.95.1.12 clint_warm_ipi_init()

Here is the call graph for this function:



21.95.1.13 clint_warm_timer_init()

Here is the call graph for this function:



21.95.2 Variable Documentation

21.95.2.1 clint_ipi

```
volatile u32* clint_ipi [static]
```

21.95.2.2 clint_ipi_base

volatile void* clint_ipi_base [static]

21.95.2.3 clint_ipi_hart_count

u32 clint_ipi_hart_count [static]

21.95.2.4 clint_time_base

volatile void* clint_time_base [static]

654 File Documentation

21.95.2.5 clint_time_cmp

```
volatile u64* clint_time_cmp [static]
```

21.95.2.6 clint_time_hart_count

```
u32 clint_time_hart_count [static]
```

21.95.2.7 clint_time_rd

```
u64(* clint_time_rd) (volatile u64 *addr) = clint_time_rd32 [static]
```

21.95.2.8 clint_time_val


```
volatile u64* clint_time_val [static]
```

21.95.2.9 clint_time_wr

```
void(* clint_time_wr) (u64 value, volatile u64 *addr) = clint_time_wr32 [static]
```

21.96 lib/utils/sys/htif.c File Reference

```
#include <sbi/riscv_locks.h>
#include <sbi_utils/sys/htif.h>
Include dependency graph for htif.c:
```



Macros

- #define HTIF_DATA_BITS 48
- #define HTIF_DATA_MASK ((1ULL << HTIF_DATA_BITS) 1)
- #define HTIF DATA SHIFT 0
- #define HTIF_CMD_BITS 8
- #define HTIF_CMD_MASK ((1ULL << HTIF_CMD_BITS) 1)
- #define HTIF_CMD_SHIFT 48
- #define HTIF_DEV_BITS 8
- #define HTIF DEV MASK ((1ULL << HTIF DEV BITS) 1)
- #define HTIF_DEV_SHIFT 56
- #define HTIF_DEV_SYSTEM 0
- #define HTIF DEV CONSOLE 1
- #define HTIF_CONSOLE_CMD_GETC 0
- #define HTIF_CONSOLE_CMD_PUTC 1
- #define TOHOST CMD(dev, cmd, payload)
- #define FROMHOST_DEV(fromhost_value) ((uint64_t)((fromhost_value) >> HTIF_DEV_SHIFT) & HTIF_←
 DEV_MASK)
- #define FROMHOST_DATA(fromhost_value) ((uint64_t)((fromhost_value) >> HTIF_DATA_SHIFT) & HTI←
 F DATA MASK)
- #define PK SYS write 64

Functions

- volatile uint64_t tohost __attribute__ ((section(".htif")))
- static void <u>__check_fromhost</u> ()
- static void <u>set_tohost</u> (uint64_t dev, uint64_t cmd, uint64_t data)
- void httf_putc">httf_putc (char ch)
- int htif_getc (void)
- int htif_system_down (u32 type)

Variables

- static int htif_console_buf
- static spinlock_t htif_lock = SPIN_LOCK_INITIALIZER

21.96.1 Macro Definition Documentation

21.96.1.1 FROMHOST_CMD

```
\label{thm:combost_cmd} $$\#define FROMHOST\_CMD($$fromhost\_value) >> HTIF\_CMD\_SHIFT) \& HTIF\_CMD\_MA \hookleftarrow SK)$
```

656 File Documentation

21.96.1.2 FROMHOST_DATA

21.96.1.3 FROMHOST_DEV

```
\label{thm:continuous} $$ $from host\_value \ ) \ ((uint 64\_t) ((from host\_value) >> $$ $ HTIF\_DEV\_SHIFT) \& $$ $ HTIF\_DEV\_MA $\longleftrightarrow $$ SK) $$
```

21.96.1.4 HTIF_CMD_BITS

#define HTIF_CMD_BITS 8

21.96.1.5 HTIF_CMD_MASK

```
\verb|#define HTIF_CMD_MASK ((1ULL << HTIF_CMD_BITS) - 1)|\\
```

21.96.1.6 HTIF_CMD_SHIFT

#define HTIF_CMD_SHIFT 48

21.96.1.7 HTIF_CONSOLE_CMD_GETC

#define HTIF_CONSOLE_CMD_GETC 0

21.96.1.8 HTIF_CONSOLE_CMD_PUTC

#define HTIF_CONSOLE_CMD_PUTC 1

21.96.1.9 HTIF_DATA_BITS

#define HTIF_DATA_BITS 48

21.96.1.10 HTIF_DATA_MASK

 $\verb|#define HTIF_DATA_MASK ((1ULL << HTIF_DATA_BITS) - 1)|\\$

21.96.1.11 HTIF_DATA_SHIFT

#define HTIF_DATA_SHIFT 0

21.96.1.12 HTIF_DEV_BITS

#define HTIF_DEV_BITS 8

21.96.1.13 HTIF_DEV_CONSOLE

#define HTIF_DEV_CONSOLE 1

21.96.1.14 HTIF_DEV_MASK

#define HTIF_DEV_MASK ((1ULL << HTIF_DEV_BITS) - 1)</pre>

21.96.1.15 HTIF_DEV_SHIFT

#define HTIF_DEV_SHIFT 56

21.96.1.16 HTIF_DEV_SYSTEM

#define HTIF_DEV_SYSTEM 0

658 File Documentation

21.96.1.17 PK_SYS_write

```
#define PK_SYS_write 64
```

21.96.1.18 TOHOST_CMD

Value:

```
({ \
   if ((dev) || (cmd)) __builtin_trap(); \
   (payload); })
```


21.96.2 Function Documentation

```
21.96.2.1 __attribute__()
```

21.96.2.2 __check_fromhost()


```
static void __check_fromhost ( ) [static]
```

Here is the caller graph for this function:




21.96.2.3 __set_tohost()

Here is the call graph for this function:




Here is the caller graph for this function:



21.96.2.4 htif_getc()

```
int htif_getc (
     void )
```

Here is the call graph for this function:




File Documentation


21.96.2.5 htif_putc()

```
void htif_putc ( {\tt char}\ {\it ch}\ )
```

Here is the call graph for this function:



Here is the caller graph for this function:



21.96.2.6 htif_system_down()

```
int htif_system_down ( u32 \ type )
```

21.96.3 Variable Documentation

21.96.3.1 htif_console_buf

int htif_console_buf [static]

21.96.3.2 htif_lock

spinlock_t htif_lock = SPIN_LOCK_INITIALIZER [static]

21.97 README.md File Reference

File Documentation

Index

AC	riscv_io.h, 167
sbi_const.h, 187	io_rar
AT	riscv_io.h, 167
sbi_const.h, 187	io_raw
BITUL	 riscv_io.h, 167
sbi_const.h, 187	io_rbr
BITULL	riscv_io.h, 167
sbi_const.h, 188	io_rbw
_UL	riscv_io.h, 167
sbi_const.h, 188	noreturn
ULL	sbi_types.h, 303
sbi_const.h, 188	packed
AC	fw_dynamic.h, 76
sbi_const.h, 187	sbi_platform.h, 270
ASM STR	sbi_scratch.h, 276
riscv asm.h, 78	sbi_trap.h, 302
NOP	sbi_types.h, 303
riscv_atomic.c, 332	printf
NOT	piiitti sbi_console.h, 182, 183
riscv_atomic.c, 332	raw_readb
RISCV_SPIN_UNLOCKED	riscv_io.h, 170
riscv_locks.h, 172	
STR	raw_readl
	riscv_io.h, 170
sbi_const.h, 187	raw_readq
atomic_op_bit	riscv_io.h, 170
riscv_atomic.c, 331	raw_readw
atomic_op_bit_ord	riscv_io.h, 171
riscv_atomic.c, 331	raw_writeb
attribute	riscv_io.h, 171
htif.c, 658	raw_writel
sbi_hart.c, 379	riscv_io.h, 171
sbi_hart.h, 212	raw_writeq
_axchg	riscv_io.h, 171
riscv_atomic.c, 331	raw_writew
check_fromhost	riscv_io.h, 171
htif.c, 658	sbi_fifo_enqueue
cmpxchg	sbi_fifo.c, 371
riscv_atomic.c, 332	sbi_fifo_is_empty
ffs	sbi_fifo.c, 371
sbi_bitops.h, 179	sbi_fifo_is_full
fls	sbi_fifo.c, 371
sbi_bitops.h, 179	sbi_fifo_reset
io_ar	sbi_fifo.c, 372
riscv_io.h, 167	sbi_hfence_gvma_all
io_aw	sbi_hfence.h, 220
riscv_io.h, 167	sbi_hfence_gvma_gpa
io_br	sbi_hfence.h, 220
riscv_io.h, 167	sbi_hfence_gvma_vmid
io_bw	sbi_hfence.h, 221

sbi_hfence_gvma_vmid_gpa	atomic_add_return
sbi_hfence.h, 221	riscv_atomic.c, 334
sbi_hfence_vvma_all	riscv_atomic.h, 87
sbi_hfence.h, 221	atomic_clear_bit
_sbi_hfence_vvma_asid	riscv_atomic.c, 334
sbi hfence.h, 222	riscv_atomic.h, 87
sbi_hfence_vvma_asid_va	atomic_raw_clear_bit
sbi hfence.h, 222	riscv_atomic.c, 335
sbi_hfence_vvma_va	riscv_atomic.h, 88
sbi hfence.h, 222	atomic_raw_set_bit
sbi_list_add	riscv_atomic.c, 335
sbi_list.h, 239	riscv_atomic.h, 88
sbi_list_del	atomic_raw_xchg_uint
sbi list.h, 240	riscv atomic.c, 336
— · · · · · · · · · · · · · · · · · · ·	
sbi_list_del_entry	riscv_atomic.h, 89
sbi_list.h, 240	atomic_raw_xchg_ulong
sbi_tlb_range_check	riscv_atomic.c, 336
sbi_tlb.c, 429	riscv_atomic.h, 89
set_tohost	atomic_read
htif.c, 658	riscv_atomic.c, 336
smp_load_acquire	riscv_atomic.h, 89
riscv_barrier.h, 91	atomic_set_bit
smp_store_release	riscv_atomic.c, 336
riscv_barrier.h, 91	riscv_atomic.h, 89
xchg	atomic_sub_return
riscv_atomic.c, 332	riscv_atomic.c, 337
	riscv_atomic.h, 90
a0	atomic_t, 45
sbi_trap_regs, 67	counter, 45
a1	atomic write
sbi_trap_regs, 67	riscv atomic.c, 337
a2	riscv_atomic.h, 90
sbi_trap_regs, 67	avail
a3	sbi fifo, 53
sbi_trap_regs, 67	avail_hart_mask
a4	sbi_hart.c, 389
sbi_trap_regs, 67	
a5	avail_hart_mask_lock
sbi trap regs, 67	sbi_hart.c, 389
a6	axchg
sbi_trap_regs, 67	riscv_atomic.c, 333
a7	BANNER
sbi_trap_regs, 68	
ATOMIC INITIALIZER	sbi_init.c, 394
riscv_atomic.h, 86	BIT_MASK
	sbi_bits.h, 180
ATOMIC_INIT	BIT_WORD
riscv_atomic.h, 86	sbi_bits.h, 180
address	bool
fdt_reserve_entry, 49	sbi_types.h, 306
arch_atomic_cmpxchg	boot_cpuid_phys
riscv_atomic.c, 334	fdt_header, 46
riscv_atomic.h, 87	boot_hart
arch_atomic_xchg	fw_dynamic_info, 50
riscv_atomic.c, 334	
riscv_atomic.h, 87	CAUSE_BREAKPOINT
arg1	riscv_encoding.h, 102
sbi_hart.h, 219	CAUSE_FETCH_ACCESS
asid	riscv_encoding.h, 102
sbi_tlb_info, 64	CAUSE_FETCH_GUEST_PAGE_FAULT

riscv_encoding.h, 102 CAUSE_FETCH_PAGE_FAULT	riscv_encoding.h, 105 CSR HEDELEG
riscv_encoding.h, 103	riscv_encoding.h, 106
CAUSE_HYPERVISOR_ECALL	CSR_HGATP
riscv_encoding.h, 103 CAUSE_ILLEGAL_INSTRUCTION	riscv_encoding.h, 106 CSR HGEIE
riscv_encoding.h, 103	riscv_encoding.h, 106
CAUSE_LOAD_ACCESS	CSR_HGEIP
riscv_encoding.h, 103 CAUSE LOAD GUEST PAGE FAULT	riscv_encoding.h, 106 CSR HIDELEG
riscv_encoding.h, 103	riscv_encoding.h, 106
CAUSE_LOAD_PAGE_FAULT	CSR_HIE
riscv_encoding.h, 103	riscv_encoding.h, 106
CAUSE_MACHINE_ECALL riscv_encoding.h, 103	CSR_HIP riscv_encoding.h, 106
CAUSE_MISALIGNED_FETCH	CSR_HPMCOUNTER10
riscv_encoding.h, 103	riscv_encoding.h, 106
CAUSE_MISALIGNED_LOAD	CSR_HPMCOUNTER10H
riscv_encoding.h, 104 CAUSE_MISALIGNED_STORE	riscv_encoding.h, 107 CSR HPMCOUNTER11
riscv_encoding.h, 104	riscv_encoding.h, 107
CAUSE_STORE_ACCESS	CSR_HPMCOUNTER11H
riscv_encoding.h, 104	riscv_encoding.h, 107
CAUSE_STORE_GUEST_PAGE_FAULT riscv_encoding.h, 104	CSR_HPMCOUNTER12
CAUSE_STORE_PAGE_FAULT	riscv_encoding.h, 107 CSR HPMCOUNTER12H
riscv_encoding.h, 104	riscv_encoding.h, 107
CAUSE_SUPERVISOR_ECALL	CSR_HPMCOUNTER13
riscv_encoding.h, 104	riscv_encoding.h, 107
CAUSE_USER_ECALL riscv_encoding.h, 104	CSR_HPMCOUNTER13H riscv_encoding.h, 107
CLAMP	CSR_HPMCOUNTER14
sbi_types.h, 303	riscv_encoding.h, 107
COLDBOOT_WAIT_BITMAP_SIZE	CSR_HPMCOUNTER14H
sbi_hart.c, 379 CPU TO FDT16	riscv_encoding.h, 108 CSR HPMCOUNTER15
libfdt env.h, 622	riscv_encoding.h, 108
CPU_TO_FDT32	CSR_HPMCOUNTER15H
libfdt_env.h, 622	riscv_encoding.h, 108
CPU_TO_FDT64 libfdt_env.h, 622	CSR_HPMCOUNTER16 riscv_encoding.h, 108
CSR CYCLEH	CSR HPMCOUNTER16H
riscv_encoding.h, 105	riscv_encoding.h, 108
CSR_CYCLE	CSR_HPMCOUNTER17
riscv_encoding.h, 104 CSR DCSR	riscv_encoding.h, 108 CSR HPMCOUNTER17H
riscv encoding.h, 105	riscv_encoding.h, 108
CSR_DPC	CSR_HPMCOUNTER18
riscv_encoding.h, 105	riscv_encoding.h, 108
CSR_DSCRATCH	CSR_HPMCOUNTER18H
riscv_encoding.h, 105 CSR FCSR	riscv_encoding.h, 109 CSR HPMCOUNTER19
riscv_encoding.h, 105	riscv_encoding.h, 109
CSR_FFLAGS	CSR_HPMCOUNTER19H
riscv_encoding.h, 105	riscv_encoding.h, 109
CSR_FRM riscv_encoding.h, 105	CSR_HPMCOUNTER20 riscv_encoding.h, 109
CSR_HCOUNTERNEN	CSR HPMCOUNTER20H
- -	_

riscv_encoding.h, 109	riscv_encoding.h, 113
CSR_HPMCOUNTER21	CSR_HPMCOUNTER6H
riscv_encoding.h, 109	riscv_encoding.h, 113
CSR_HPMCOUNTER21H	CSR_HPMCOUNTER7
riscv_encoding.h, 109	riscv_encoding.h, 113
CSR_HPMCOUNTER22	CSR_HPMCOUNTER7H
riscv_encoding.h, 109	riscv_encoding.h, 113
CSR_HPMCOUNTER22H	CSR_HPMCOUNTER8
riscv_encoding.h, 110	riscv_encoding.h, 113
CSR_HPMCOUNTER23	CSR_HPMCOUNTER8H
riscv_encoding.h, 110	riscv_encoding.h, 113
CSR_HPMCOUNTER23H	CSR_HPMCOUNTER9
riscv_encoding.h, 110	riscv_encoding.h, 113
CSR_HPMCOUNTER24	CSR_HPMCOUNTER9H
riscv_encoding.h, 110	riscv_encoding.h, 114
CSR_HPMCOUNTER24H	CSR_HSTATUS
riscv_encoding.h, 110	riscv_encoding.h, 114
CSR_HPMCOUNTER25	CSR_HTIMEDELTAH
riscv_encoding.h, 110	riscv_encoding.h, 114
CSR_HPMCOUNTER25H	CSR_HTIMEDELTA
riscv_encoding.h, 110	riscv_encoding.h, 114
CSR_HPMCOUNTER26	CSR_HTINST
riscv_encoding.h, 110	riscv_encoding.h, 114
CSR_HPMCOUNTER26H	CSR_HTVAL
riscv_encoding.h, 111	riscv_encoding.h, 114
CSR_HPMCOUNTER27	CSR_INSTRETH
riscv_encoding.h, 111	riscv_encoding.h, 114
CSR_HPMCOUNTER27H	CSR_INSTRET
riscv_encoding.h, 111 CSR_HPMCOUNTER28	riscv_encoding.h, 114 CSR MARCHID
	-
riscv_encoding.h, 111 CSR_HPMCOUNTER28H	riscv_encoding.h, 115 CSR MCAUSE
riscv_encoding.h, 111	riscv_encoding.h, 115
CSR HPMCOUNTER29	CSR MCOUNTEREN
riscv_encoding.h, 111	riscv_encoding.h, 115
CSR HPMCOUNTER29H	CSR MCYCLEH
riscv_encoding.h, 111	riscv_encoding.h, 115
CSR_HPMCOUNTER3	CSR MCYCLE
riscv_encoding.h, 111	riscv_encoding.h, 115
CSR HPMCOUNTER30	CSR MEDELEG
riscv encoding.h, 112	riscv_encoding.h, 115
CSR HPMCOUNTER30H	CSR MEPC
riscv_encoding.h, 112	riscv encoding.h, 115
CSR HPMCOUNTER31	CSR MHARTID
riscv_encoding.h, 112	riscv encoding.h, 115
CSR HPMCOUNTER31H	CSR_MHPMCOUNTER10
riscv_encoding.h, 112	riscv encoding.h, 116
CSR HPMCOUNTER3H	CSR MHPMCOUNTER10H
riscv_encoding.h, 112	riscv_encoding.h, 116
CSR HPMCOUNTER4	CSR MHPMCOUNTER11
riscv_encoding.h, 112	riscv_encoding.h, 116
CSR HPMCOUNTER4H	CSR MHPMCOUNTER11H
riscv_encoding.h, 112	riscv_encoding.h, 116
CSR HPMCOUNTER5	CSR MHPMCOUNTER12
riscv_encoding.h, 112	riscv_encoding.h, 116
CSR_HPMCOUNTER5H	CSR_MHPMCOUNTER12H
riscv_encoding.h, 113	riscv_encoding.h, 116
CSR_HPMCOUNTER6	CSR_MHPMCOUNTER13
-	_

riscv_encoding.h, 116	riscv_encoding.h, 120
CSR_MHPMCOUNTER13H	CSR_MHPMCOUNTER28
riscv_encoding.h, 116	riscv_encoding.h, 120
CSR_MHPMCOUNTER14	CSR_MHPMCOUNTER28H
riscv_encoding.h, 117	riscv_encoding.h, 120
CSR_MHPMCOUNTER14H	CSR_MHPMCOUNTER29
riscv_encoding.h, 117	riscv_encoding.h, 120
CSR_MHPMCOUNTER15	CSR_MHPMCOUNTER29H
riscv_encoding.h, 117	riscv_encoding.h, 120
CSR_MHPMCOUNTER15H	CSR_MHPMCOUNTER3
riscv_encoding.h, 117	riscv_encoding.h, 121
CSR_MHPMCOUNTER16	CSR_MHPMCOUNTER30
riscv_encoding.h, 117	riscv_encoding.h, 121
CSR_MHPMCOUNTER16H	CSR_MHPMCOUNTER30H
riscv_encoding.h, 117	riscv_encoding.h, 121
CSR_MHPMCOUNTER17	CSR_MHPMCOUNTER31
riscv_encoding.h, 117	riscv_encoding.h, 121
CSR_MHPMCOUNTER17H	CSR_MHPMCOUNTER31H
riscv_encoding.h, 117	riscv_encoding.h, 121
CSR_MHPMCOUNTER18	CSR_MHPMCOUNTER3H
riscv_encoding.h, 118	riscv_encoding.h, 121
CSR_MHPMCOUNTER18H	CSR_MHPMCOUNTER4
riscv_encoding.h, 118	riscv_encoding.h, 121
CSR_MHPMCOUNTER19	CSR_MHPMCOUNTER4H
riscv_encoding.h, 118	riscv_encoding.h, 121
CSR_MHPMCOUNTER19H	CSR_MHPMCOUNTER5
riscv_encoding.h, 118	riscv_encoding.h, 122
CSR_MHPMCOUNTER20	CSR_MHPMCOUNTER5H
riscv_encoding.h, 118	riscv_encoding.h, 122
CSR_MHPMCOUNTER20H	CSR_MHPMCOUNTER6
riscv_encoding.h, 118	riscv_encoding.h, 122
CSR_MHPMCOUNTER21	CSR_MHPMCOUNTER6H
riscv_encoding.h, 118	riscv_encoding.h, 122
CSR_MHPMCOUNTER21H	CSR_MHPMCOUNTER7
riscv_encoding.h, 118	riscv_encoding.h, 122
CSR_MHPMCOUNTER22	CSR_MHPMCOUNTER7H
riscv_encoding.h, 119	riscv_encoding.h, 122
CSR_MHPMCOUNTER22H	CSR_MHPMCOUNTER8
riscv_encoding.h, 119	riscv_encoding.h, 122
CSR_MHPMCOUNTER23	CSR_MHPMCOUNTER8H
riscv_encoding.h, 119	riscv_encoding.h, 122
CSR_MHPMCOUNTER23H riscv_encoding.h, 119	CSR_MHPMCOUNTER9
CSR MHPMCOUNTER24	riscv_encoding.h, 123 CSR MHPMCOUNTER9H
-	-
riscv_encoding.h, 119 CSR MHPMCOUNTER24H	riscv_encoding.h, 123 CSR MHPMEVENT10
-	_
riscv_encoding.h, 119	riscv_encoding.h, 123
CSR_MHPMCOUNTER25	CSR_MHPMEVENT11
riscv_encoding.h, 119	riscv_encoding.h, 123
CSR_MHPMCOUNTER25H	CSR_MHPMEVENT12
riscv_encoding.h, 119	riscv_encoding.h, 123
CSR_MHPMCOUNTER26	CSR_MHPMEVENT13
riscv_encoding.h, 120	riscv_encoding.h, 123 CSR MHPMEVENT14
CSR_MHPMCOUNTER26H	_
riscv_encoding.h, 120 CSR MHPMCOUNTER27	riscv_encoding.h, 123 CSR MHPMEVENT15
-	-
riscv_encoding.h, 120 CSR MHPMCOUNTER27H	riscv_encoding.h, 123 CSR MHPMEVENT16
OOK_IVITE IVIOODINTED2/TI	OOLI_IVII II-IVIEVEIVI IO

riscv_encoding.h, 124 CSR_MHPMEVENT17	riscv_encoding.h, 127 CSR_MSCRATCH
riscv_encoding.h, 124 CSR MHPMEVENT18	riscv_encoding.h, 127 CSR MSTATUSH
riscv_encoding.h, 124	riscv_encoding.h, 128
CSR_MHPMEVENT19 riscv_encoding.h, 124	CSR_MSTATUS riscv_encoding.h, 127
CSR_MHPMEVENT20	CSR_MTINST
riscv_encoding.h, 124 CSR_MHPMEVENT21	riscv_encoding.h, 128 CSR_MTVAL2
riscv_encoding.h, 124 CSR MHPMEVENT22	riscv_encoding.h, 128 CSR MTVAL
riscv_encoding.h, 124	riscv_encoding.h, 128
CSR_MHPMEVENT23	CSR_MTVEC
riscv_encoding.h, 124 CSR_MHPMEVENT24	riscv_encoding.h, 128 CSR_MVENDORID
riscv_encoding.h, 125	riscv_encoding.h, 128
CSR_MHPMEVENT25 riscv_encoding.h, 125	CSR_PMPADDR0 riscv_encoding.h, 128
CSR_MHPMEVENT26	CSR_PMPADDR1
riscv_encoding.h, 125 CSR_MHPMEVENT27	riscv_encoding.h, 128 CSR_PMPADDR10
riscv_encoding.h, 125 CSR MHPMEVENT28	riscv_encoding.h, 129 CSR PMPADDR11
riscv_encoding.h, 125	riscv_encoding.h, 129
CSR_MHPMEVENT29	CSR_PMPADDR12
riscv_encoding.h, 125 CSR_MHPMEVENT3	riscv_encoding.h, 129 CSR_PMPADDR13
riscv_encoding.h, 125 CSR MHPMEVENT30	riscv_encoding.h, 129 CSR PMPADDR14
riscv_encoding.h, 125	riscv_encoding.h, 129
CSR_MHPMEVENT31	CSR_PMPADDR15
riscv_encoding.h, 126 CSR MHPMEVENT4	riscv_encoding.h, 129 CSR PMPADDR2
riscv_encoding.h, 126	riscv_encoding.h, 129
CSR_MHPMEVENT5	CSR_PMPADDR3
riscv_encoding.h, 126 CSR_MHPMEVENT6	riscv_encoding.h, 129 CSR_PMPADDR4
riscv_encoding.h, 126 CSR MHPMEVENT7	riscv_encoding.h, 130 CSR PMPADDR5
riscv_encoding.h, 126	riscv_encoding.h, 130
CSR_MHPMEVENT8	CSR_PMPADDR6
riscv_encoding.h, 126 CSR MHPMEVENT9	riscv_encoding.h, 130 CSR PMPADDR7
riscv_encoding.h, 126	riscv_encoding.h, 130
CSR_MIDELEG	CSR_PMPADDR8
riscv_encoding.h, 126 CSR_MIMPID	riscv_encoding.h, 130 CSR_PMPADDR9
riscv_encoding.h, 127	riscv_encoding.h, 130
CSR_MINSTRETH riscv_encoding.h, 127	CSR_PMPCFG0 riscv_encoding.h, 130
CSR_MINSTRET	CSR_PMPCFG1
riscv_encoding.h, 127	riscv_encoding.h, 130
CSR_MISA riscv_encoding.h, 127	CSR_PMPCFG2 riscv_encoding.h, 131
CSR_MIE	CSR_PMPCFG3
riscv_encoding.h, 127 CSR MIP	riscv_encoding.h, 131 CSR SATP

riscv_encoding.h, 131 CSR_SCAUSE	riscv_encoding.h, 134 CSR_VSSTATUS
riscv_encoding.h, 131 CSR_SCOUNTEREN	riscv_encoding.h, 135 CSR_VSTVAL
riscv_encoding.h, 131 CSR_SEPC	riscv_encoding.h, 135 CSR_VSTVEC
riscv_encoding.h, 131 CSR SIE	riscv_encoding.h, 135 cause
riscv_encoding.h, 131	sbi_trap_info, 65
CSR_SIP riscv_encoding.h, 131	check_block_ fdt.c, 453
CSR SSCRATCH	check_off_
riscv_encoding.h, 132	fdt.c, 453
CSR_SSTATUS	clint.c
riscv_encoding.h, 132	clint_cold_ipi_init, 649
CSR_STVAL riscv_encoding.h, 132	clint_cold_timer_init, 649 clint ipi, 653
CSR_STVEC	clint_ipi_base, 653
riscv_encoding.h, 132	clint_ipi_clear, 649
CSR_TDATA1	clint_ipi_hart_count, 653
riscv_encoding.h, 132	clint_ipi_send, 650
CSR_TDATA2 riscv_encoding.h, 132	clint_time_base, 653 clint_time_cmp, 653
CSR TDATA3	clint_time_hart_count, 654
riscv_encoding.h, 132	clint_time_rd, 654
CSR_TIMEH	clint_time_rd32, 650
riscv_encoding.h, 133	clint_time_rd64, 650
CSR_TIME riscv_encoding.h, 132	clint_time_val, 654 clint_time_wr, 654
CSR_TSELECT	clint_time_wr32, 650
riscv_encoding.h, 133	clint_time_wr64, 651
CSR_UCAUSE	clint_timer_event_start, 651
riscv_encoding.h, 133	clint_timer_event_stop, 651
CSR_UEPC riscv_encoding.h, 133	clint_timer_value, 652 clint_warm_ipi_init, 652
CSR_UIE	clint_warm_timer_init, 652
riscv_encoding.h, 133	clint.h
CSR_UIP	clint_cold_ipi_init, 320
riscv_encoding.h, 133	clint_cold_timer_init, 321
CSR_USCRATCH riscv_encoding.h, 133	clint_ipi_clear, 321 clint_ipi_send, 321
CSR_USTATUS	clint_ipi_sync, 322
riscv_encoding.h, 133	clint_timer_event_start, 322
CSR_UTVAL	clint_timer_event_stop, 322
riscv_encoding.h, 134	clint_timer_value, 322
CSR_UTVEC riscv_encoding.h, 134	clint_warm_ipi_init, 323 clint warm timer init, 323
CSR_VSATP	clint_cold_ipi_init
riscv_encoding.h, 134	clint.c, 649
CSR_VSCAUSE	clint.h, 320
riscv_encoding.h, 134	clint_cold_timer_init
CSR_VSEPC riscv_encoding.h, 134	clint.c, 649 clint.h, 321
CSR VSIE	clint_ipi
riscv_encoding.h, 134	clint.c, 653
CSR_VSIP	clint_ipi_base
riscv_encoding.h, 134	clint.c, 653
CSR_VSSCRATCH	clint_ipi_clear

clint.c, 649	console_out_lock
clint.h, 321	sbi_console.c, 353
clint_ipi_hart_count	console_plat
clint.c, 653	sbi_console.c, 353
clint_ipi_send	console_putc
clint.c, 650	sbi_platform_operations, 58
clint.h, 321	container_of
clint_ipi_sync	sbi_types.h, 304
clint.h, 322	counter
clint_time_base	atomic_t, 45
clint.c, 653	cpu_relax
clint_time_cmp	riscv_barrier.h, 91
clint.c, 653	cpu_to_fdt16 libfdt_env.h, 625
clint_time_hart_count	
clint.c, 654	cpu_to_fdt32 libfdt_env.h, 625
clint_time_rd	cpu_to_fdt64
clint.c, 654	libfdt env.h, 626
clint_time_rd32	csr_clear
clint.c, 650	riscv_asm.h, 78
clint_time_rd64	csr read
clint.c, 650	riscv_asm.h, 78
clint_time_val	csr_read_clear
clint.c, 654	riscv_asm.h, 78
clint_time_wr	csr_read_num
clint.c, 654	riscv_asm.c, 326
clint_time_wr32 clint.c, 650	riscv_asm.h, 82
clint_time_wr64	csr_read_set
clint.c, 651	riscv_asm.h, 79
clint_timer_event_start	csr_set
clint.c, 651	riscv_asm.h, 79
clint.h, 322	csr_swap
clint timer event stop	riscv_asm.h, 79
clint.c, 651	csr_write
clint.h, 322	riscv_asm.h, 80
clint_timer_value	csr_write_num
clint.c, 652	riscv_asm.c, 327
clint.h, 322	riscv_asm.h, 82
clint_warm_ipi_init	ctz
clint.c, 652	riscv_asm.c, 327
clint.h, 323	DECLARE UNPRIVILEGED LOAD FUNCTION
clint_warm_timer_init	sbi_unpriv.h, 309
clint.c, 652	DECLARE_UNPRIVILEGED_STORE_FUNCTION
clint.h, 323	sbi_unpriv.h, 310
cmpxchg	DEFINE UNPRIVILEGED LOAD FUNCTION
riscv_atomic.c, 333	sbi_unpriv.c, 444
coldboot done	DEFINE_UNPRIVILEGED_STORE_FUNCTION
sbi_hart.c, 389	sbi_unpriv.c, 445
coldboot_lock	data
sbi_hart.c, 389	fdt_property, 48
coldboot_lottery	delegate_traps
sbi_init.c, 400	sbi_hart.c, 379
coldboot_wait_bitmap	disabled_hart_mask
sbi_hart.c, 389	sbi_platform, 56
console_getc	docs/contributing.md, 73
sbi_platform_operations, 58	docs/firmware/fw.md, 73
console_init	docs/firmware/fw_dynamic.md, 73
sbi_platform_operations, 58	docs/firmware/fw_jump.md, 73

docs/firmware/fw_payload.md, 73	libfdt_env.h, 623
docs/firmware/payload_linux.md, 73	FDT_END_NODE
docs/firmware/payload_uboot.md, 73	fdt.h, 463
docs/library_usage.md, 73	FDT END
docs/platform/andes-ae350.md, 73	fdt.h, 463
docs/platform/ariane-fpga.md, 73	FDT_ERR_BADLAYOUT
docs/platform/platform.md, 73	libfdt.h, 552
docs/platform/gemu_virt.md, 73	
–	FDT_ERR_BADMAGIC
docs/platform/sifive_fu540.md, 74	libfdt.h, 553
docs/platform/spike.md, 74	FDT_ERR_BADNCELLS
docs/platform/thead-c910.md, 74	libfdt.h, 553
docs/platform_guide.md, 74	FDT_ERR_BADOFFSET
EVED A OT DIVITE	libfdt.h, 553
EXTRACT_BYTE	FDT_ERR_BADOVERLAY
libfdt_env.h, 622	libfdt.h, 553
EXTRACT_FIELD	FDT_ERR_BADPATH
sbi_bits.h, 181	libfdt.h, 553
early_exit	FDT_ERR_BADPHANDLE
sbi_platform_operations, 58	libfdt.h, 553
early_init	FDT_ERR_BADSTATE
sbi_platform_operations, 58	
ecall_base	libfdt.h, 553
sbi_ecall.h, 194	FDT_ERR_BADSTRUCTURE
sbi_ecall_base.c, 360	libfdt.h, 553
ecall_ipi	FDT_ERR_BADVALUE
sbi_ecall.h, 194	libfdt.h, 554
sbi_ecall_replace.c, 364	FDT_ERR_BADVERSION
ecall_legacy	libfdt.h, 554
	FDT_ERR_EXISTS
sbi_ecall.h, 194	libfdt.h, 554
sbi_ecall_legacy.c, 362	FDT_ERR_INTERNAL
ecall_rfence	libfdt.h, 554
sbi_ecall.h, 194	FDT ERR MAX
sbi_ecall_replace.c, 365	libfdt.h, 554
ecall_time	FDT ERR NOPHANDLES
sbi_ecall.h, 194	libfdt.h, 554
sbi_ecall_replace.c, 365	
ecall_vendor	FDT_ERR_NOSPACE
sbi_ecall.h, 194	libfdt.h, 554
sbi_ecall_vendor.c, 367	FDT_ERR_NOTFOUND
entry_size	libfdt.h, 554
sbi_fifo, 53	FDT_ERR_TRUNCATED
epc	libfdt.h, 555
sbi_trap_info, 65	FDT_ERRTABENT
extid end	fdt_strerror.c, 531
sbi_ecall_extension, 52	FDT_ERRTABSIZE
extid_start	fdt strerror.c, 531
	FDT_FIRST_SUPPORTED_VERSION
sbi_ecall_extension, 52	 libfdt.h, <u>555</u>
extra_lock	FDT_FORCE
sbi_scratch.c, 414	libfdt_env.h, 623
extra_offset	FDT_LAST_SUPPORTED_VERSION
sbi_scratch.c, 414	
FALOE	libfdt.h, 556
FALSE	FDT_MAGIC
sbi_types.h, 304	fdt.h, 464
FDT_ALIGN	FDT_MAX_NCELLS
libfdt_internal.h, 628	libfdt.h, 556
FDT_BEGIN_NODE	FDT_NOP
fdt.h, 463	fdt.h, 464
FDT_BITWISE	FDT_PROP

fdt.h, 464	fdt_check_header, 453
FDT_RO_PROBE	fdt_check_node_offset_, 454
libfdt_internal.h, 629	fdt_check_prop_offset_, 455
FDT_RW_PROBE	fdt_find_string_, 456
fdt_rw.c, 517	fdt_first_subnode, 456
FDT_SW_MAGIC	fdt_header_size_, 457
libfdt_internal.h, 629	fdt_move, 457
FDT_SW_PROBE_MEMRSV	fdt_next_node, 458
fdt_sw.c, 533	fdt_next_subnode, 459
FDT SW PROBE STRUCT	fdt_next_tag, 460
fdt_sw.c, 533	fdt_offset_ptr, 461
FDT SW PROBE	fdt ro probe , 462
	fdt.h
fdt_sw.c, 533	
FDT_TAGALIGN	FDT_BEGIN_NODE, 463
libfdt_internal.h, 629	FDT_END_NODE, 463
FDT_TAGSIZE	FDT_END, 463
fdt.h, 464	FDT_MAGIC, 464
FDT_V16_SIZE	FDT_NOP, 464
fdt.h, 464	FDT_PROP, 464
FDT_V17_SIZE	FDT_TAGSIZE, 464
fdt.h, 464	FDT_V16_SIZE, 464
FDT_V1_SIZE	FDT_V17_SIZE, 464
fdt.h, 464	FDT_V1_SIZE, 464
FDT_V2_SIZE	FDT_V2_SIZE, 465
 fdt.h, 465	FDT_V3_SIZE, 465
FDT_V3_SIZE	fdt16_t
fdt.h, 465	libfdt_env.h, 625
FROMHOST_CMD	fdt16_to_cpu
htif.c, 655	libfdt_env.h, 626
FROMHOST_DATA	fdt32_ld
htif.c, 655	libfdt.h, 558
FROMHOST_DEV	fdt32_t
htif.c, 656	libfdt_env.h, 625
FW_DYNAMIC_INFO_BOOT_HART_OFFSET	fdt32_to_cpu
fw_dynamic.h, 75	libfdt_env.h, 627
FW_DYNAMIC_INFO_MAGIC_OFFSET	fdt64_ld
fw_dynamic.h, 75	libfdt.h, 559
FW_DYNAMIC_INFO_MAGIC_VALUE	fdt64_t
fw_dynamic.h, 75	libfdt_env.h, 625
FW_DYNAMIC_INFO_NEXT_ADDR_OFFSET	fdt64_to_cpu
fw_dynamic.h, 75	libfdt_env.h, 627
FW_DYNAMIC_INFO_NEXT_MODE_OFFSET	fdt_add_mem_rsv
fw_dynamic.h, 75	fdt_rw.c, 517
FW_DYNAMIC_INFO_NEXT_MODE_M	libfdt.h, 560
fw_dynamic.h, 75	fdt_add_property_
FW_DYNAMIC_INFO_NEXT_MODE_S	fdt_rw.c, 517
fw_dynamic.h, 75	fdt_add_reservemap_entry
FW_DYNAMIC_INFO_NEXT_MODE_U	fdt_sw.c, 534
fw_dynamic.h, 76	libfdt.h, 560
FW_DYNAMIC_INFO_OPTIONS_OFFSET	fdt_add_subnode
fw_dynamic.h, 76	fdt_rw.c, 518
_ ·	
FW_DYNAMIC_INFO_VERSION_MAX	libfdt.h, 561
fw_dynamic.h, 76	fdt_add_subnode_namelen
FW_DYNAMIC_INFO_VERSION_OFFSET	fdt_rw.c, 519
fw_dynamic.h, 76	libfdt.h, 562
fdt.c	fdt_address_cells
check_block_, 453	fdt_addresses.c, 466
check off . 453	libfdt.h. 562

fdt_addresses.c	fdt_errtable
fdt_address_cells, 466	fdt_strerror.c, 531
fdt_cells, 466	fdt_find_add_string_
fdt_size_cells, 467	fdt_rw.c, 522
fdt_appendprop	fdt_sw.c, 536
fdt_rw.c, 519	fdt_find_string_
libfdt.h, 563	fdt.c, 456
fdt_appendprop_cell	libfdt_internal.h, 631
libfdt.h, 563	fdt_finish
fdt_appendprop_string	fdt_sw.c, 537
libfdt.h, 552	libfdt.h, 570
fdt_appendprop_u32	fdt_finish_reservemap
libfdt.h, 564	fdt_sw.c, 537
fdt_appendprop_u64	libfdt.h, 571
libfdt.h, 564	fdt_first_property_offset
fdt_begin_node	fdt_ro.c, 484
fdt sw.c, 534	libfdt.h, 571
libfdt.h, 565	fdt first subnode
fdt blocks misordered	fdt.c, 456
fdt_rw.c, 520	libfdt.h, 572
fdt_boot_cpuid_phys	fdt_for_each_property_offset
libfdt.h, 552	libfdt.h, 555
fdt_cells	fdt_for_each_subnode
fdt_addresses.c, 466	libfdt.h, 555
fdt_check_full	fdt_get_alias
fdt_ro.c, 483	fdt_ro.c, 485
libfdt.h, 565	libfdt.h, 573
fdt_check_header	fdt_get_alias_namelen
fdt.c, 453	fdt_ro.c, 486
libfdt.h, 566	libfdt.h, 574
fdt_check_node_offset_	fdt_get_header
fdt.c, 454	libfdt.h, 556
libfdt_internal.h, 629	fdt_get_max_phandle
fdt_check_prop_offset_	fdt_ro.c, 486
fdt.c, 455	libfdt.h, 574
libfdt_internal.h, 630	fdt_get_mem_rsv
fdt_create	fdt_ro.c, 487
fdt_sw.c, 535	libfdt.h, 575
libfdt.h, 567	fdt_get_name
fdt_create_empty_tree	fdt_ro.c, 488
fdt_empty_tree.c, 468	libfdt.h, 576
libfdt.h, 568	fdt_get_path
fdt_data_size_	fdt_ro.c, 488
fdt_rw.c, 520	libfdt.h, 577
fdt_del_mem_rsv	fdt_get_phandle
fdt_rw.c, 521	fdt_ro.c, 489
libfdt.h, 568	libfdt.h, 578
fdt_del_node	fdt_get_property
fdt_rw.c, 521	fdt_ro.c, 490
libfdt.h, 568	libfdt.h, 578
fdt_delprop	fdt_get_property_by_offset
fdt_rw.c, 522	fdt_ro.c, 491
libfdt.h, 569	libfdt.h, 579
fdt_empty_tree.c	fdt_get_property_by_offset_
fdt_create_empty_tree, 468	fdt_ro.c, 491
fdt_end_node	fdt_get_property_namelen
fdt_sw.c, 535	fdt_ro.c, 492
libfdt.h, 569	libfdt.h, 580

fdt_get_property_namelen_	fdt.c, 459
fdt_ro.c, 493	libfdt.h, 590
fdt_get_property_w	fdt_next_tag
libfdt.h, 580	fdt.c, 460
fdt_get_string	libfdt.h, 591
fdt_ro.c, 494	fdt_node_check_compatible
libfdt.h, 581	fdt_ro.c, 500
fdt_getprop	libfdt.h, 592
fdt_ro.c, 495	fdt_node_depth
libfdt.h, 582	fdt_ro.c, 501
fdt_getprop_by_offset	libfdt.h, 593
fdt_ro.c, 496	fdt_node_end_offset_
libfdt.h, 583	fdt_wip.c, 542
fdt_getprop_namelen	libfdt_internal.h, 632
fdt_ro.c, 497	fdt_node_header, 47
libfdt.h, 584	name, 47
fdt_getprop_namelen_w	tag, 48
libfdt.h, 585	fdt_node_offset_by_compatible
fdt_getprop_w	fdt_ro.c, 501
libfdt.h, 586	libfdt.h, 593
fdt_grab_space_	fdt_node_offset_by_phandle
fdt_sw.c, 538	fdt_ro.c, 502
fdt_header, 45	libfdt.h, 594
boot_cpuid_phys, 46	fdt_node_offset_by_prop_value
last_comp_version, 46	fdt_ro.c, 503
magic, 46	libfdt.h, 595
off_dt_strings, 46	fdt_nodename_eq_
off_dt_struct, 46	fdt_ro.c, 504
off_mem_rsvmap, 46	fdt_nop_node
size_dt_strings, 47	fdt_wip.c, 543
size_dt_struct, 47	libfdt.h, 596
totalsize, 47	fdt_nop_property
version, 47	fdt_wip.c, 544
fdt_header_size	libfdt.h, 597
libfdt.h, 586	fdt_nop_region_
fdt_header_size_	fdt_wip.c, 544
fdt.c, 457	fdt_num_mem_rsv
libfdt.h, 587	fdt_ro.c, 505
fdt_last_comp_version	libfdt.h, 598
libfdt.h, 556	fdt_off_dt_strings
fdt_magic	libfdt.h, 557
libfdt.h, 556	fdt_off_dt_struct
fdt_mem_rsv	libfdt.h, 557
fdt_ro.c, 498	fdt_off_mem_rsvmap
fdt_mem_rsv_	libfdt.h, 557
libfdt_internal.h, 631	fdt_offset_ptr
fdt_mem_rsv_w_	fdt.c, 461
libfdt_internal.h, 632	libfdt.h, 598
fdt_move	fdt_offset_ptr_
fdt.c, 457	libfdt_internal.h, 633
libfdt.h, 587	fdt_offset_ptr_w
fdt_next_node	libfdt.h, 599
fdt.c, 458	fdt_offset_ptr_w_
libfdt.h, 588	libfdt_internal.h, 633
fdt_next_property_offset	fdt_open_into
fdt_ro.c, 499	fdt_rw.c, 523
libfdt.h, 589	libfdt.h, 600
fdt_next_subnode	fdt_overlay.c

fdt_overlay_apply, 470	fdt_ro.c
get_path_len, 471	fdt_check_full, 483
overlay_adjust_local_phandles, 471	fdt_first_property_offset, 484
overlay_adjust_node_phandles, 472	fdt_get_alias, 485
overlay_apply_node, 473	fdt_get_alias_namelen, 486
overlay_fixup_one_phandle, 474	fdt_get_max_phandle, 486
overlay_fixup_phandle, 474	fdt_get_mem_rsv, 487
overlay_fixup_phandles, 475	fdt_get_name, 488
overlay_get_target, 476	fdt_get_path, 488
overlay_get_target_phandle, 476	fdt_get_phandle, 489
overlay_merge, 477	fdt_get_property, 490
overlay_phandle_add_offset, 478	fdt_get_property_by_offset, 491
overlay_symbol_update, 479	fdt_get_property_by_offset_, 491
overlay_update_local_node_references, 479	fdt_get_property_namelen, 492
overlay_update_local_references, 480	fdt_get_property_namelen_, 493
fdt_overlay_apply	fdt_get_string, 494
fdt overlay.c, 470	fdt_getprop, 495
_ • •	
libfdt.h, 601	fdt_getprop_by_offset, 496
fdt_pack	fdt_getprop_namelen, 497
fdt_rw.c, 524	fdt_mem_rsv, 498
libfdt.h, 601	fdt_next_property_offset, 499
fdt_packblocks_	fdt_node_check_compatible, 500
fdt_rw.c, 524	fdt_node_depth, 501
fdt_parent_offset	fdt_node_offset_by_compatible, 501
fdt_ro.c, 505	fdt_node_offset_by_phandle, 502
libfdt.h, 601	fdt_node_offset_by_prop_value, 503
fdt_path_offset	fdt_nodename_eq_, 504
fdt_ro.c, 506	fdt_num_mem_rsv, 505
libfdt.h, 602	fdt_parent_offset, 505
fdt_path_offset_namelen	fdt_path_offset, 506
fdt_ro.c, 507	fdt_path_offset_namelen, 507
libfdt.h, 603	fdt_string, 508
fdt_property, 48	fdt_string_eq_, 508
data, 48	fdt_stringlist_contains, 509
fdt_sw.c, 539	fdt_stringlist_count, 510
len, 48	fdt_stringlist_get, 510
libfdt.h, 604	fdt_stringlist_search, 511
nameoff, 48	fdt_subnode_offset, 512
tag, 49	fdt_subnode_offset_namelen, 512
fdt_property_cell	fdt supernode atdepth offset, 513
libfdt.h, 604	nextprop_, 514
fdt_property_placeholder	fdt_ro_probe_
fdt_sw.c, 539	fdt.c, 462
libfdt.h, 605	libfdt_internal.h, 634
fdt_property_string	fdt_rw.c
libfdt.h, 557	FDT_RW_PROBE, 517
fdt_property_u32	fdt_add_mem_rsv, 517
libfdt.h, 605	fdt_add_property_, 517
fdt_property_u64	fdt_add_subnode, 518
libfdt.h, 606	fdt_add_subnode_namelen, 519
fdt_reserve_entry, 49	fdt_appendprop, 519
address, 49	fdt_blocks_misordered_, 520
size, 49	fdt_data_size_, 520
fdt_resize	fdt_del_mem_rsv, 521
fdt_sw.c, 540	fdt_del_node, 521
libfdt.h, 606	fdt_delprop, 522
fdt_resize_property_	fdt_find_add_string_, 522
fdt_rw.c, 524	fdt_open_into, 523

fdt_pack, 524	fdt_rw.c, 528
fdt_packblocks_, 524	fdt_splice_struct_
fdt_resize_property_, 524	fdt_rw.c, 529
fdt_rw_probe_, 525	fdt_strerror
fdt_set_name, 525	fdt_strerror.c, 531
fdt_setprop, 526	libfdt.h, 615
fdt_setprop_placeholder, 526	fdt_strerror.c
fdt_splice_, 527	FDT_ERRTABENT, 531
fdt_splice_mem_rsv_, 528	FDT_ERRTABSIZE, 531
fdt_splice_string_, 528	fdt_errtable, 531
fdt_splice_struct_, 529	fdt_strerror, 531
fdt_rw_probe_	fdt_string
fdt_rw.c, 525	fdt_ro.c, 508
fdt_set_hdr_	libfdt.h, 615
libfdt.h, 557, 607, 608	fdt_string_eq_
fdt_set_name	fdt_ro.c, 508
fdt_rw.c, 525	fdt_stringlist_contains
libfdt.h, 608	fdt_ro.c, 509
fdt_setprop	libfdt.h, 615
fdt_rw.c, 526	fdt_stringlist_count
libfdt.h, 609	fdt_ro.c, 510
fdt_setprop_cell	libfdt.h, 616
libfdt.h, 609	fdt stringlist get
fdt_setprop_empty	fdt_ro.c, 510
libfdt.h, 557	libfdt.h, 617
fdt_setprop_inplace	fdt_stringlist_search
fdt_wip.c, 545	fdt_ro.c, 511
libfdt.h, 610	libfdt.h, 617
fdt_setprop_inplace_cell	fdt_subnode_offset
libfdt.h, 610	fdt_ro.c, 512
fdt_setprop_inplace_namelen_partial	libfdt.h, 618
fdt_wip.c, 546	fdt_subnode_offset_namelen
libfdt.h, 611	fdt_ro.c, 512
fdt_setprop_inplace_u32	libfdt.h, 619
libfdt.h, 611	fdt_supernode_atdepth_offset
fdt_setprop_inplace_u64	fdt_ro.c, 513
libfdt.h, 612	libfdt.h, 619
fdt_setprop_placeholder	fdt_sw.c
fdt_rw.c, 526	FDT_SW_PROBE_MEMRSV, 533
libfdt.h, 612	FDT_SW_PROBE_STRUCT, 533
fdt_setprop_string	FDT_SW_PROBE, 533
libfdt.h, 558	fdt_add_reservemap_entry, 534
fdt_setprop_u32	fdt_begin_node, 534
libfdt.h, 613	fdt_create, 535
fdt_setprop_u64	fdt_end_node, 535
libfdt.h, 614	fdt_find_add_string_, 536
fdt_size_cells	fdt_finish, 537
fdt_addresses.c, 467	fdt_finish_reservemap, 537
libfdt.h, 614	fdt_grab_space_, 538
fdt_size_dt_strings	fdt_property, 539
libfdt.h, 558	fdt_property_placeholder, 539
fdt_size_dt_struct	fdt_resize, 540
libfdt.h, 558	fdt_sw_probe_, 540
fdt_splice_	fdt_sw_probe_memrsv_, 541
fdt_rw.c, 527	fdt_sw_probe_struct_, 541
fdt_splice_mem_rsv_	fdt_sw_probe_
fdt_rw.c, 528	fdt_sw.c, 540
fdt_splice_string_	fdt_sw_probe_memrsv_

fdt_sw.c, 541	riscv_fp.h, 165
fdt_sw_probe_struct_	GET_RS1
fdt_sw.c, 541	riscv_encoding.h, 135
fdt_totalsize	GET_RS1S
libfdt.h, 558	riscv_encoding.h, 135
fdt_version	GET_RS2
libfdt.h, 558	riscv_encoding.h, 135
fdt_wip.c	GET_RS2C
fdt_node_end_offset_, 542	riscv_encoding.h, 136
fdt_nop_node, 543	GET_RS2S
fdt_nop_property, 544	riscv_encoding.h, 136
fdt_nop_region_, 544	GET_RM
fdt_setprop_inplace, 545	riscv_encoding.h, 135
fdt_setprop_inplace_namelen_partial, 546	riscv_fp.h, 165
features	GET_SP
sbi_platform, 56	riscv_encoding.h, 136
ffs	get_path_len
sbi_bitops.h, 179	fdt_overlay.c, 471
ffz	get_reg
sbi_bitops.h, 179	sifive-uart.c, 638
final_exit	uart8250.c, 645
sbi_platform_operations, 58	get_ticks
final_init	sbi_timer.c, 423
sbi_platform_operations, 58	get_tlbr_flush_limit
firmware_context	sbi_platform_operations, 59
sbi_platform, 56	gp
fls	sbi_trap_regs, 68
sbi_bitops.h, 180	h2s
format	sbi_hart.c, 379
sbi_console.h, 186	HSTATUS_SP2P
fp_init	riscv_encoding.h, 136
sbi_hart.c, 380 fw dynamic.h	HSTATUS SP2V
packed, 76	riscv encoding.h, 136
FW_DYNAMIC_INFO_BOOT_HART_OFFSET, 75	HSTATUS SPRV
FW DYNAMIC INFO MAGIC OFFSET, 75	riscv_encoding.h, 136
FW DYNAMIC INFO MAGIC VALUE, 75	HSTATUS_SPV
FW DYNAMIC INFO NEXT ADDR OFFSET, 75	riscv encoding.h, 136
FW DYNAMIC INFO NEXT MODE OFFSET,	HSTATUS_VTSR
75	riscv_encoding.h, 137
EW DYNAMIC INFO NEXT MODE M /5	HSTATUS_VTVM
FW_DYNAMIC_INFO_NEXT_MODE_M, 75 FW_DYNAMIC_INFO_NEXT_MODE_S_75	HSTATUS_VTVM riscv_encoding.h, 137
FW_DYNAMIC_INFO_NEXT_MODE_S, 75	_
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76	riscv_encoding.h, 137
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76	riscv_encoding.h, 137 HTIF_CMD_BITS
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50 next_addr, 50	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656 HTIF_CONSOLE_CMD_GETC
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50 next_addr, 50 next_mode, 50	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656 HTIF_CONSOLE_CMD_GETC htif.c, 656
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50 next_addr, 50 next_mode, 50 options, 50	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656 HTIF_CONSOLE_CMD_GETC htif.c, 656 HTIF_CONSOLE_CMD_PUTC
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50 next_addr, 50 next_mode, 50 options, 50 version, 51	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656 HTIF_CONSOLE_CMD_GETC htif.c, 656 HTIF_CONSOLE_CMD_PUTC htif.c, 656 HTIF_DATA_BITS htif.c, 656
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50 next_addr, 50 next_mode, 50 options, 50 version, 51 fw_size	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656 HTIF_CONSOLE_CMD_GETC htif.c, 656 HTIF_CONSOLE_CMD_PUTC htif.c, 656 HTIF_DATA_BITS
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50 next_addr, 50 next_mode, 50 options, 50 version, 51 fw_size sbi_scratch, 62	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656 HTIF_CONSOLE_CMD_GETC htif.c, 656 HTIF_CONSOLE_CMD_PUTC htif.c, 656 HTIF_DATA_BITS htif.c, 656 HTIF_DATA_MASK htif.c, 657
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50 next_addr, 50 next_mode, 50 options, 50 version, 51 fw_size sbi_scratch, 62 fw_start	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656 HTIF_CONSOLE_CMD_GETC htif.c, 656 HTIF_CONSOLE_CMD_PUTC htif.c, 656 HTIF_DATA_BITS htif.c, 656 HTIF_DATA_MASK htif.c, 657 HTIF_DATA_SHIFT
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50 next_addr, 50 next_mode, 50 options, 50 version, 51 fw_size sbi_scratch, 62 fw_start sbi_scratch, 62	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656 HTIF_CONSOLE_CMD_GETC htif.c, 656 HTIF_CONSOLE_CMD_PUTC htif.c, 656 HTIF_DATA_BITS htif.c, 656 HTIF_DATA_MASK htif.c, 657 HTIF_DATA_SHIFT htif.c, 657
FW_DYNAMIC_INFO_NEXT_MODE_S, 75 FW_DYNAMIC_INFO_NEXT_MODE_U, 76 FW_DYNAMIC_INFO_OPTIONS_OFFSET, 76 FW_DYNAMIC_INFO_VERSION_MAX, 76 FW_DYNAMIC_INFO_VERSION_OFFSET, 76 fw_dynamic_info, 49 boot_hart, 50 magic, 50 next_addr, 50 next_mode, 50 options, 50 version, 51 fw_size sbi_scratch, 62 fw_start	riscv_encoding.h, 137 HTIF_CMD_BITS htif.c, 656 HTIF_CMD_MASK htif.c, 656 HTIF_CMD_SHIFT htif.c, 656 HTIF_CONSOLE_CMD_GETC htif.c, 656 HTIF_CONSOLE_CMD_PUTC htif.c, 656 HTIF_DATA_BITS htif.c, 656 HTIF_DATA_MASK htif.c, 657 HTIF_DATA_SHIFT

htif.c, 657	htif.c, 660
HTIF_DEV_CONSOLE	htif.h, 325
htif.c, 657	htif_system_down
HTIF_DEV_MASK	htif.c, 660
htif.c, 657	htif.h, 325
HTIF_DEV_SHIFT	
htif.c, 657	IMM_I
HTIF_DEV_SYSTEM	riscv_encoding.h, 137
htif.c, 657	IMM_S
handle	riscv_encoding.h, 137
sbi ecall extension, 52	INSERT_FIELD
hart count	sbi_bits.h, 181
sbi_platform, 56	INSN_16BIT_MASK
hart_stack_size	riscv_encoding.h, 137
sbi_platform, 56	INSN_32BIT_MASK
hartid_to_scratch	riscv_encoding.h, 137
sbi_scratch, 62	INSN_IS_16BIT
head	riscv_encoding.h, 137
sbi ecall extension, 52	INSN_IS_32BIT
htif.c	riscv_encoding.h, 138
	INSN_LEN
attribute, 658 check fromhost, 658	riscv_encoding.h, 138
 -	INSN_MASK_C_FLDSP
set_tohost, 658	riscv_encoding.h, 138
FROMHOST_CMD, 655	INSN_MASK_C_FLWSP
FROMHOST_DATA, 655	riscv_encoding.h, 138
FROMHOST_DEV, 656	INSN_MASK_C_FLD
HTIF_CMD_BITS, 656	riscv_encoding.h, 138
HTIF_CMD_MASK, 656	INSN_MASK_C_FLW
HTIF_CMD_SHIFT, 656	riscv_encoding.h, 138
HTIF_CONSOLE_CMD_GETC, 656	INSN MASK C FSDSP
HTIF_CONSOLE_CMD_PUTC, 656	riscv_encoding.h, 139
HTIF_DATA_BITS, 656	INSN MASK C FSWSP
HTIF_DATA_MASK, 657	riscv_encoding.h, 139
HTIF_DATA_SHIFT, 657	INSN_MASK_C_FSD
HTIF_DEV_BITS, 657	riscv encoding.h, 139
HTIF_DEV_CONSOLE, 657	INSN MASK C FSW
HTIF_DEV_MASK, 657	riscv_encoding.h, 139
HTIF_DEV_SHIFT, 657	INSN_MASK_C_LDSP
HTIF_DEV_SYSTEM, 657	riscv encoding.h, 139
htif_console_buf, 660	INSN MASK C LWSP
htif_getc, 659	riscv_encoding.h, 139
htif_lock, 660	INSN MASK C LD
htif_putc, 660	riscv_encoding.h, 139
htif_system_down, 660	INSN_MASK_C_LW
PK SYS write, 657	riscv_encoding.h, 139
TOHOST_CMD, 658	INSN_MASK_C_SDSP
htif.h	riscv_encoding.h, 140
htif_getc, 324	INSN MASK C SWSP
htif_putc, 325	riscv_encoding.h, 140
htif_system_down, 325	INSN MASK C SD
htif console buf	riscv_encoding.h, 140
htif.c, 660	INSN MASK C SW
htif_getc	riscv_encoding.h, 140
htif.c, 659	INSN MASK FLD
htif.h, 324	riscv_encoding.h, 140
htif lock	INSN MASK FLQ
htif.c, 660	riscv_encoding.h, 140
htif_putc	INSN MASK FLW
niii_puit	HAOIN_INIAOIN_I EVV

riscv_encoding.h, 140	riscv_encoding.h, 144
INSN_MASK_FSD	INSN_MATCH_C_SD
riscv_encoding.h, 140	riscv_encoding.h, 144
INSN_MASK_FSQ	INSN_MATCH_C_SW
riscv_encoding.h, 141	riscv_encoding.h, 144
INSN_MASK_FSW	INSN_MATCH_FLD
riscv_encoding.h, 141	riscv_encoding.h, 144
INSN_MASK_LBU riscv_encoding.h, 141	INSN_MATCH_FLQ
INSN MASK LHU	riscv_encoding.h, 144 INSN MATCH FLW
riscv_encoding.h, 141	riscv_encoding.h, 145
INSN MASK LWU	INSN MATCH FSD
riscv_encoding.h, 142	riscv_encoding.h, 145
INSN MASK LB	INSN MATCH FSQ
riscv_encoding.h, 141	riscv_encoding.h, 145
INSN MASK LD	INSN MATCH FSW
riscv_encoding.h, 141	riscv_encoding.h, 145
INSN MASK LH	INSN MATCH LBU
riscv_encoding.h, 141	riscv_encoding.h, 145
INSN MASK LW	INSN MATCH LHU
riscv_encoding.h, 141	riscv_encoding.h, 146
INSN MASK SB	INSN MATCH LWU
riscv_encoding.h, 142	riscv_encoding.h, 146
INSN MASK SD	INSN MATCH LB
riscv_encoding.h, 142	riscv_encoding.h, 145
INSN_MASK_SH	INSN_MATCH_LD
riscv_encoding.h, 142	riscv_encoding.h, 145
INSN_MASK_SW	INSN_MATCH_LH
riscv_encoding.h, 142	riscv_encoding.h, 145
INSN_MASK_WFI	INSN_MATCH_LW
riscv_encoding.h, 142	riscv_encoding.h, 146
INSN_MATCH_C_FLDSP	INSN_MATCH_SB
riscv_encoding.h, 142	riscv_encoding.h, 146
INSN_MATCH_C_FLWSP	INSN_MATCH_SD
riscv_encoding.h, 143	riscv_encoding.h, 146
INSN_MATCH_C_FLD	INSN_MATCH_SH
riscv_encoding.h, 142	riscv_encoding.h, 146
INSN_MATCH_C_FLW	INSN_MATCH_SW
riscv_encoding.h, 143	riscv_encoding.h, 146
INSN_MATCH_C_FSDSP	INSN_MATCH_WFI
riscv_encoding.h, 143	riscv_encoding.h, 146
INSN_MATCH_C_FSWSP	INT_MAX
riscv_encoding.h, 143	libfdt_env.h, 623
INSN_MATCH_C_FSD	IRQ_M_EXT
riscv_encoding.h, 143	riscv_encoding.h, 147
INSN_MATCH_C_FSW	IRQ_M_SOFT
riscv_encoding.h, 143	riscv_encoding.h, 147
INSN_MATCH_C_LDSP	IRQ_M_TIMER
riscv_encoding.h, 143	riscv_encoding.h, 147
INSN_MATCH_C_LWSP riscv_encoding.h, 144	IRQ_S_EXT riscv_encoding.h, 147
INSN_MATCH_C_LD	IRQ_S_GEXT
riscv_encoding.h, 143	riscv_encoding.h, 147
INSN MATCH C LW	IRQ S SOFT
riscv_encoding.h, 144	riscv_encoding.h, 147
INSN_MATCH_C_SDSP	IRQ S TIMER
riscv_encoding.h, 144	riscv_encoding.h, 147
INSN MATCH C SWSP	IRQ VS EXT

riscv_encoding.h, 147	ipi_clear
IRQ_VS_SOFT	sbi_platform_operations, 59
riscv_encoding.h, 148	ipi_data_off
IRQ_VS_TIMER	sbi_ipi.c, 408
riscv_encoding.h, 148	ipi_exit
illegal_insn_func	sbi_platform_operations, 59
sbi_illegal_insn.c, 390	ipi_halt_event
illegal_insn_table	sbi_ipi.c, 408 ipi_halt_ops
sbi_illegal_insn.c, 393	sbi ipi.c, 408
include/sbi/fw_dynamic.h, 74	ipi_init
include/sbi/riscv_asm.h, 77	sbi_platform_operations, 59
include/sbi/riscv_atomic.h, 86 include/sbi/riscv_barrier.h, 90	ipi_ops_array
include/sbi/riscv_encoding.h, 93	sbi_ipi.c, 409
include/sbi/riscv_fp.h, 164	ipi_send
include/sbi/riscv_io.h, 165	sbi platform operations, 59
include/sbi/riscv_locks.h, 172	ipi_smode_event
include/sbi/sbi_bitops.h, 177	sbi_ipi.c, 409
include/sbi/sbi_bits.h, 180	ipi smode ops
include/sbi/sbi_console.h, 181	sbi_ipi.c, 409
include/sbi/sbi const.h, 186	irqchip_exit
include/sbi/sbi ecall.h, 189	sbi_platform_operations, 59
include/sbi/sbi_ecall_interface.h, 194	irqchip_init
include/sbi/sbi_emulate_csr.h, 200	sbi_platform_operations, 59
include/sbi/sbi_error.h, 202	1.0050
include/sbi/sbi_fifo.h, 205	LGREG
include/sbi/sbi hart.h, 211	riscv_asm.h, 80
include/sbi/sbi hfence.h, 220	LOG_REGBYTES
include/sbi/sbi_illegal_insn.h, 223	riscv_encoding.h, 148
include/sbi/sbi_init.h, 225	last_comp_version
include/sbi/sbi ipi.h, 229	fdt_header, 46 len
include/sbi/sbi_list.h, 236	fdt_property, 48
include/sbi/sbi_misaligned_ldst.h, 243	lib/sbi/riscv_asm.c, 326
include/sbi/sbi_platform.h, 246	lib/sbi/riscv_asmic.c, 330
include/sbi/sbi_scratch.h, 270	lib/sbi/riscv_locks.c, 337
include/sbi/sbi_string.h, 276	lib/sbi/sbi_console.c, 342
include/sbi/sbi_system.h, 280	lib/sbi/sbi_ecall.c, 353
include/sbi/sbi_timer.h, 284	lib/sbi/sbi_ecall_base.c, 358
include/sbi/sbi_tlb.h, 289	lib/sbi/sbi_ecall_legacy.c, 360
include/sbi/sbi_trap.h, 293	lib/sbi/sbi_ecall_replace.c, 362
include/sbi/sbi_types.h, 302	lib/sbi/sbi_ecall_vendor.c, 366
include/sbi/sbi_unpriv.h, 309	lib/sbi/sbi_emulate_csr.c, 368
include/sbi/sbi_version.h, 311	lib/sbi/sbi_fifo.c, 370
include/sbi_utils/irqchip/plic.h, 312	lib/sbi/sbi_hart.c, 378
include/sbi_utils/serial/sifive-uart.h, 315	lib/sbi/sbi_illegal_insn.c, 390
include/sbi_utils/serial/uart8250.h, 317	lib/sbi/sbi_init.c, 393
include/sbi_utils/sys/clint.h, 320	lib/sbi/sbi_ipi.c, 400
include/sbi_utils/sys/htif.h, 324	lib/sbi/sbi_misaligned_ldst.c, 410
init_coldboot	lib/sbi/sbi_scratch.c, 412
sbi_init.c, 394	lib/sbi/sbi_string.c, 414
init_count_offset	lib/sbi/sbi_system.c, 418
sbi_init.c, 400	lib/sbi/sbi_timer.c, 422
init_warmboot	lib/sbi/sbi_tlb.c, 428
sbi_init.c, 395	lib/sbi/sbi_trap.c, 440
int16_t	lib/sbi/sbi_unpriv.c, 443
sbi_types.h, 306	lib/utils/irqchip/plic.c, 447
int32_t	lib/utils/libfdt/fdt.c, 452
sbi_types.h, 306	lib/utils/libfdt/fdt.h, 463

111 / 211 / 111 / 111 / 111 / 111	(1) 1 500
lib/utils/libfdt/fdt_addresses.c, 465	fdt_end_node, 569
lib/utils/libfdt/fdt_empty_tree.c, 467	fdt_finish, 570
lib/utils/libfdt/fdt_overlay.c, 469	fdt_finish_reservemap, 571
lib/utils/libfdt/fdt_ro.c, 481	fdt_first_property_offset, 571
lib/utils/libfdt/fdt_rw.c, 515	fdt_first_subnode, 572
lib/utils/libfdt/fdt_strerror.c, 530	fdt_for_each_property_offset, 555
lib/utils/libfdt/fdt_sw.c, 532	fdt_for_each_subnode, 555
lib/utils/libfdt/fdt_wip.c, 542	fdt_get_alias, 573
lib/utils/libfdt/libfdt.h, 546	fdt_get_alias_namelen, 574
lib/utils/libfdt/libfdt_env.h, 620	fdt_get_header, 556
lib/utils/libfdt/libfdt_internal.h, 628	fdt_get_max_phandle, 574
lib/utils/serial/sifive-uart.c, 635	fdt_get_mem_rsv, 575
lib/utils/serial/uart8250.c, 641	fdt_get_name, 576
lib/utils/sys/clint.c, 648	fdt_get_path, 577
lib/utils/sys/htif.c, 654	fdt_get_phandle, 578
libfdt.h	fdt_get_property, 578
FDT_ERR_BADLAYOUT, 552	fdt_get_property_by_offset, 579
FDT_ERR_BADMAGIC, 553	fdt_get_property_namelen, 580
FDT_ERR_BADNCELLS, 553	fdt_get_property_w, 580
FDT_ERR_BADOFFSET, 553	fdt_get_string, 581
FDT_ERR_BADOVERLAY, 553	fdt_getprop, 582
FDT_ERR_BADPATH, 553	fdt_getprop_by_offset, 583
FDT_ERR_BADPHANDLE, 553	fdt_getprop_namelen, 584
FDT_ERR_BADSTATE, 553	fdt_getprop_namelen_w, 585
FDT_ERR_BADSTRUCTURE, 553	fdt_getprop_w, 586
FDT_ERR_BADVALUE, 554	fdt_header_size, 586
FDT_ERR_BADVERSION, 554	fdt_header_size_, 587
FDT_ERR_EXISTS, 554	fdt_last_comp_version, 556
FDT_ERR_INTERNAL, 554	fdt_magic, 556
FDT_ERR_MAX, 554	fdt_move, 587
FDT_ERR_NOPHANDLES, 554	fdt_next_node, 588
FDT_ERR_NOSPACE, 554	fdt_next_property_offset, 589
FDT_ERR_NOTFOUND, 554	fdt_next_subnode, 590
FDT_ERR_TRUNCATED, 555	fdt_next_tag, 591
FDT_FIRST_SUPPORTED_VERSION, 555	fdt_node_check_compatible, 592
FDT_LAST_SUPPORTED_VERSION, 556	fdt_node_depth, 593
FDT_MAX_NCELLS, 556	fdt_node_offset_by_compatible, 593
fdt32_ld, 558	fdt_node_offset_by_phandle, 594
fdt64_ld, 559	fdt_node_offset_by_prop_value, 595
fdt_add_mem_rsv, 560	fdt_nop_node, 596
fdt_add_reservemap_entry, 560	fdt_nop_property, 597
fdt_add_subnode, 561	fdt_num_mem_rsv, 598
fdt_add_subnode_namelen, 562	fdt_off_dt_strings, 557
fdt_address_cells, 562	fdt_off_dt_struct, 557
fdt_appendprop, 563	fdt_off_mem_rsvmap, 557
fdt_appendprop_cell, 563	fdt_offset_ptr, 598
fdt_appendprop_string, 552	fdt_offset_ptr_w, 599
fdt_appendprop_u32, 564	fdt_open_into, 600
fdt_appendprop_u64, 564	fdt_overlay_apply, 601
fdt_begin_node, 565	fdt_pack, 601
fdt_boot_cpuid_phys, 552	fdt_parent_offset, 601
fdt_check_full, 565	fdt_path_offset, 602
fdt_check_header, 566	fdt_path_offset_namelen, 603
fdt_create, 567	fdt_property, 604
fdt_create_empty_tree, 568	fdt_property_cell, 604
fdt_del_mem_rsv, 568	fdt_property_placeholder, 605
fdt_del_node, 568	fdt_property_string, 557
fdt_delprop, 569	fdt_property_u32, 605

fdt_property_u64, 606	UINT_MAX, 624
fdt_resize, 606	libfdt_internal.h
fdt_set_hdr_, 557, 607, 608	FDT_ALIGN, 628
fdt_set_name, 608	FDT_RO_PROBE, 629
fdt_setprop, 609	FDT_SW_MAGIC, 629
fdt_setprop_cell, 609	FDT_TAGALIGN, 629
fdt_setprop_empty, 557	fdt_check_node_offset_, 629
fdt_setprop_inplace, 610	fdt_check_prop_offset_, 630
fdt_setprop_inplace_cell, 610	fdt_find_string_, 631
fdt_setprop_inplace_namelen_partial, 611	fdt_mem_rsv_, 631
fdt_setprop_inplace_u32, 611	fdt_mem_rsv_w_, 632
fdt_setprop_inplace_u64, 612	fdt_node_end_offset_, 632
fdt_setprop_placeholder, 612	fdt_offset_ptr_, 633
fdt_setprop_string, 558	fdt_offset_ptr_w_, 633
fdt_setprop_u32, 613	fdt_ro_probe_, 634
fdt_setprop_u64, 614	likely
fdt_size_cells, 614	sbi_types.h, 304
fdt_size_dt_strings, 558	lock
fdt size dt struct, 558	spinlock_t, 71
fdt_strerror, 615	log2roundup
fdt string, 615	sbi_hart.c, 380
fdt_stringlist_contains, 615	
fdt_stringlist_count, 616	MASK_FUNCT3
fdt_stringlist_get, 617	riscv_encoding.h, 148
fdt_stringlist_search, 617	MAX
fdt_subnode_offset, 618	sbi_types.h, 304
fdt_subnode_offset_namelen, 619	MIP_MEIP
fdt_supernode_atdepth_offset, 619	riscv_encoding.h, 148
fdt_totalsize, 558	MIP_MSIP
fdt_version, 558	riscv_encoding.h, 148
	MIP_MTIP
libfdt_env.h	riscv_encoding.h, 148
CPU_TO_FDT16, 622	MIP_SEIP
CPU_TO_FDT32, 622	riscv_encoding.h, 148
CPU_TO_FDT64, 622	MIP_SGEIP
cpu_to_fdt16, 625	riscv_encoding.h, 149
cpu_to_fdt32, 625	MIP_SSIP
cpu_to_fdt64, 626	riscv_encoding.h, 149
EXTRACT_BYTE, 622	MIP_STIP
FDT_BITWISE, 623	riscv_encoding.h, 149
FDT_FORCE, 623	MIP_VSEIP
fdt16_t, 625	riscv_encoding.h, 149
fdt16_to_cpu, 626	MIP_VSSIP
fdt32_t, 625	riscv_encoding.h, 149
fdt32_to_cpu, 627	MIP_VSTIP
fdt64_t, 625	riscv_encoding.h, 149
fdt64_to_cpu, 627	MIN
INT_MAX, 623	sbi_types.h, 304
memchr, 623	MSTATUS32_SD
memcmp, 623	riscv_encoding.h, 149
memcpy, 623	MSTATUS64_SD
memmove, 623	riscv_encoding.h, 150
memset, 624	MSTATUS_FS
strchr, 624	riscv_encoding.h, 150
strcmp, 624	MSTATUS_MIE
strcpy, 624	riscv_encoding.h, 150
strlen, 624	MSTATUS_MPIE
strnlen, 624	riscv_encoding.h, 150
strrchr, 624	MSTATUS_MPP_SHIFT

riscv_encoding.h, 150	misa_extension_imp
MSTATUS_MPRV	riscv_asm.c, 327
riscv_encoding.h, 150	riscv_asm.h, 82
MSTATUS_MPP	misa_get_xlen
riscv_encoding.h, 150	sbi_platform_operations, 60
MSTATUS_MXR	misa_string
riscv_encoding.h, 150	riscv_asm.h, 83
MSTATUS_SIE	misa_xlen
riscv_encoding.h, 151	riscv_asm.c, 328
MSTATUS SPIE SHIFT	riscv_asm.h, 83
riscv encoding.h, 151	mstatus
MSTATUS SPIE	sbi_trap_regs, 68
riscv_encoding.h, 151	mstatus_init
MSTATUS SPP SHIFT	sbi_hart.c, 380
riscv_encoding.h, 151	mstatusH
MSTATUS SPP	sbi_trap_regs, 68
riscv_encoding.h, 151	_ 1_ 0 ,
MSTATUS SUM	NULL
riscv encoding.h, 151	sbi_types.h, 304
MSTATUS SD	name
riscv_encoding.h, 151	fdt_node_header, 47
MSTATUS TSR	sbi_ipi_event_ops, 54
-	sbi platform, 56
riscv_encoding.h, 151	nameoff
MSTATUS_TVM	fdt_property, 48
riscv_encoding.h, 152	next
MSTATUS_TW	sbi_dlist, 51
riscv_encoding.h, 152	next_addr
MSTATUS_UBE	fw_dynamic_info, 50
riscv_encoding.h, 152	sbi_hart.h, 219
MSTATUS_XS	sbi_scratch, 62
riscv_encoding.h, 152	next_arg1
MSTATUSH_MBE	sbi scratch, 62
riscv_encoding.h, 152	next_mode
MSTATUSH_MPV	fw_dynamic_info, 50
riscv_encoding.h, 152	sbi_hart.h, 219
MSTATUSH_SBE	sbi_scratch, 63
riscv_encoding.h, 152	next virt
magic	sbi hart.h, 219
fdt_header, 46	nextprop_
fw_dynamic_info, 50	fdt_ro.c, 514
mb	num entries
riscv_barrier.h, 92	sbi fifo, 53
memchr	3510, 00
libfdt_env.h, 623	OPENSBI_VERSION_MAJOR
memcmp	sbi version.h, 311
libfdt_env.h, 623	OPENSBI_VERSION_MINOR
memcpy	sbi version.h, 312
libfdt env.h, 623	OPENSBI_VERSION
memmove	sbi_version.h, 311
libfdt env.h, 623	off_dt_strings
memset	fdt_header, 46
libfdt env.h, 624	off_dt_struct
mepc	fdt header, 46
sbi_trap_regs, 68	off_mem_rsvmap
misa_check_extension	fdt_header, 46
sbi_platform_operations, 59	offsetof
misa extension	sbi_types.h, 305
riscv_asm.h, 80	opensbi_version
11307_43111.11, 00	opensol_version

ali alattana FO	DMD A NA4
sbi_platform, 56	PMP_A_NA4
options	riscv_encoding.h, 153
fw_dynamic_info, 50	PMP_A_NAPOT
sbi_scratch, 63	riscv_encoding.h, 153
out_sz sbi_console.h, 186	PMP_A_TOR
overlay_adjust_local_phandles	riscv_encoding.h, 153 PMP COUNT
fdt_overlay.c, 471	-
overlay_adjust_node_phandles	riscv_encoding.h, 153 PMP_SHIFT
fdt_overlay.c, 472	
overlay_apply_node	riscv_encoding.h, 153 PMP A
fdt_overlay.c, 473	riscv_encoding.h, 152
overlay_fixup_one_phandle	PMP L
fdt_overlay.c, 474	riscv_encoding.h, 153
overlay_fixup_phandle	PMP R
fdt_overlay.c, 474	riscv_encoding.h, 153
overlay_fixup_phandles	PMP W
fdt_overlay.c, 475	riscv_encoding.h, 153
overlay_get_target	PMP X
fdt_overlay.c, 476	riscv_encoding.h, 154
overlay_get_target_phandle	PRECISION D
fdt_overlay.c, 476	riscv_fp.h, 165
overlay_merge	PRECISION S
fdt_overlay.c, 477	riscv_fp.h, 165
overlay_phandle_add_offset	PRINT_BUF_LEN
fdt_overlay.c, 478	sbi_console.c, 344
overlay_symbol_update	PRV M
fdt_overlay.c, 479	riscv_encoding.h, 154
overlay_update_local_node_references	PRV S
fdt_overlay.c, 479	riscv_encoding.h, 154
overlay_update_local_references	PRV U
fdt_overlay.c, 480	riscv_encoding.h, 154
PAD ALTERNATE	PTE_PPN_SHIFT
sbi console.c, 344	riscv_encoding.h, 154
PAD RIGHT	PTE_SOFT
sbi_console.c, 344	riscv_encoding.h, 155
PAD ZERO	PTE_TABLE
sbi_console.c, 344	riscv_encoding.h, 155
PAGE MASK	PTE_A
riscv_asm.h, 80	riscv_encoding.h, 154
PAGE_SHIFT	PTE_D
riscv_asm.h, 81	riscv_encoding.h, 154
PAGE_SIZE	PTE_G
riscv_asm.h, 81	riscv_encoding.h, 154
PK_SYS_write	PTE_R
htif.c, 657	riscv_encoding.h, 155
PLIC_CONTEXT_BASE	PTE_U
plic.c, 448	riscv_encoding.h, 155
PLIC_CONTEXT_STRIDE	PTE_V
plic.c, 448	riscv_encoding.h, 155
PLIC_ENABLE_BASE	PTE_W
plic.c, 448	riscv_encoding.h, 155
PLIC_ENABLE_STRIDE	PTE_X
plic.c, 448	riscv_encoding.h, 155
PLIC_PENDING_BASE	physical_addr_t
plic.c, 448	sbi_types.h, 306
PLIC_PRIORITY_BASE plic.c, 448	physical_size_t sbi_types.h, 306

platform addr sbi_scratch, 63 platform, ops_addr sbi_platform, 56 platform version sbi_platform, 57 plic.oc PLIC_CONTEXT_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_PRIORITY_BASE, 448 plic_base, 451 plic_old_irachip_init, 448 plic_set_ie, 449 plic_set_ie, 449 plic_set_ie, 449 plic_set_thresh, 450 plic set thresh, 314 plic_sold_irachip_init, 313 plic_set_thresh, 314 plic_old_irachip_init, 314 plic_base plic.c, 451 plic_cold_irachip_init, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_set_priority plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 451 plic_set_ie plic.c, 451 plic_set_priority plic.c, 450 plic_set_thresh plic.c, 450 plic_swarm_irachip_init plic_c, 450 plic_swarm_irachip_init plic_warm_irachip_init plic_warm_irachip_init plic_c, 450 plic_h, 314 plic_warm_irachip_init plic_warm_irachip_in		
platform_ops_addr sbi_platform, 56 platform_version sbi_platform, 57 plic.c PLIC_CONTEXT_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_PENDING_BASE, 448 PLIC_PENDING_BASE, 448 PLIC_PENDING_BASE, 448 PLIC_PENDING_BASE, 448 plic_base, 451 plic_base, 451 plic_num_sources, 451 plic_set_iresh, 450 plic_set_thresh, 450 plic_warm_irqchip_init, 314 plic_base plic.c, 450 plic_set_iresh plic.c, 450 plic_set_thresh plic.c, 450 plic_set_mean, 450 plic_set_thresh plic_c, 450 plic_set_iresh plic_c, 450 plic_set_mean, 450 plic_set_thresh plic_c, 450 plic_set_thresh plic_c, 450 plic_set_mean plic_icd_fixip plic_det_fixip plic_det_fixip plic_det_fixip plic_det_fixip plic_det_fixip plic_set_iresh plic_det_fixip plic_det_f	platform_addr	pmp_region_info
sbi_platform, 56 platform_version sbi_platform, 57 plic.c PLIC_CONTEXT_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENABLE_STRIDE, 448 PLIC_PENDING_BASE, 448 PILC_PENDING_BASE, 448 PILC_PIC_PENDING_BASE, 448 PI	sbi_scratch, 63	sbi_platform_operations, 60
platform_version sbi_platform, 57 ppic.c PLIC_CONTEXT_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENDING_BASE, 448 PLIC_PENDING_BASE, 448 PLIC_PENDING_BASE, 448 plic_base, 451 plic_base, 451 plic_nart_count, 451 plic_set_priority, 450 plic_set_thresh, 314 plic_set_ei, 313 plic_set_thresh, 314 plic_base plic_c, 451 plic_code_irqchip_init, 314 plic_base plic_c, 448 plic_hart_count plic_c, 448 plic_hart_count plic_c, 449 plic_base plic_set_bridgh_priority plic_c, 450 plic_set_ei_e glic_c, 451 plic_c_set_ei_e glic_c, 451 plic_c_set_ei_e glic_c, 451 plic_c_set_ei_e glic_c, 451 plic_c_set_ei_e glic_c, 455 plic_set_ei_e glic_c, 450 plic_h, 313 plic_set_thresh plic_c, 450 plic_h, 314 plic_set_ei_ei_ei_ei_ei_ei_ei_ei_ei_ei_ei_ei_ei_	platform_ops_addr	pmp_set
sbi_platform, 57 plic.c PLIC_CONTEXT_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENABLE_BASE, 448 PLIC_PRIDING_BASE, 448 PIDL_PRIDING_BASE, 48	sbi_platform, 56	riscv_asm.c, 329
plic.c PLIC_CONTEXT_BASE, 448 PLIC_CNABLE_BASE, 448 PLIC_PRIDING BASE, 448 PLIC_PENDING BASE, 448 PLIC_PENDING BASE, 448 PLIC_PRICITY_BASE, 448 PIC_CONSOLIC_, 345 Pricity_Bic_A, 450 Plic_AT_COUNT, 451 Plic_BASE, 448 PIC_ATABLE Pricity_Bic_A, 450 Plic_AT_COUNT, 451 Plic_BASE, 448 PIC_BASE, 448 Pricity_Bic_A, 450 Plic_AT_COUNT, 451 Plic_BASE, 448 PIC_BASE, 448 Pricity_Bic_A, 450 Plic_AT_COUNT, 451 Plic_BASE, 448 PIC_BASE, 448 P	platform_version	riscv_asm.h, 85
plic.c PLIC_CONTEXT_BASE, 448 PLIC_CNABLE_BASE, 448 PLIC_PRIDING BASE, 448 PLIC_PENDING BASE, 448 PLIC_PENDING BASE, 448 PLIC_PRICITY_BASE, 448 PIC_CONSOLIC_, 345 Pricity_Bic_A, 450 Plic_AT_COUNT, 451 Plic_BASE, 448 PIC_ATABLE Pricity_Bic_A, 450 Plic_AT_COUNT, 451 Plic_BASE, 448 PIC_BASE, 448 Pricity_Bic_A, 450 Plic_AT_COUNT, 451 Plic_BASE, 448 PIC_BASE, 448 Pricity_Bic_A, 450 Plic_AT_COUNT, 451 Plic_BASE, 448 PIC_BASE, 448 P	•	prev
PLIC_CONTEXT_BASE, 448 PLIC_CONTEXT_STRIDE, 448 PLIC_ENABLE BASE, 448 PLIC_PENDING_BASE, 448 PIDIC_PENDING_BASE, 448 PLIC_PENDING_BASE, 448 PLIC_PENDING_BASE, 448 PLIC_PENDING_BASE, 448 PIDIC_PENDING_BASE, 48 PIDIC	-	sbi dlist, 51
PLIC_CONTEXT_STRIDE, 448 PLIC_ENABLE_BASE, 448 PLIC_ENDING_BASE, 448 PLIC_PRIDING_BASE, 448 PLIC_DRIDING_BASE, 448 PLIC_PRIDING_BASE, 448 PLIC_PRIDING_BASE, 448 PLIC_PRIDING_BASE, 448 PLIC_PRIDING_BASE, 448 PIC_DASE, 449 PLIC_DRIDING_BASE, 448 PIC_DASE, 449 PLIC_DRIDING_BASE, 448 PIC_DASE, 449 PLIC_PRIDING_BASE, 448 PIC_DASE, 449 PLIC_PRIDING_BASE, 448 PLIC_PRIDING_BASE, 448 PIC_DASE, 449 PLIC_DRIDING_BASE, 448 PIC_DASE, 449 PLIC_PRIDING_BASE, 448 PIC_DASE, 449 PIC_DASE, 448 PIC_DASE, 449 PIC_DASE, 448 PIC_DASE, 448 PIC_DASE, 448 PIC_DASE, 448 PIC_DASE, 449 PIC_DASE, 448	•	
PLIC_ENABLE_BASE, 448 PLIC_PENDING BASE, 448 plic_base, 451 plic_cold_irqchip_init, 448 plic_that_count, 451 plic_set_ie, 449 plic_set_priority, 450 plic_set_thresh, 450 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 313 plic_cold_irqchip_init, 314 plic_warm_irqchip_init plic_c, 451 plic_cold_irqchip_init plic, 449 plic, 449 plic, 449 plic, 449 plic, 451 plic_pending plic, 449 plic, 451 plic_num_sources plic, 451 plic_num_sources plic, 451 plic_set_ie plic, 450 plic, 314 ppp_get riscv_asm.h, 84 ppp_init splic_varm_irqchip_init plic, 450 plic, 314 ppp_get riscv_asm.h, 84 ppp_init splic_varm_irqchip_init plic, 450 plic, 314 ppp_get riscv_asm.h, 84 ppp_init splic_varm_irqchip_init plic, 450 plic, 314 ppp_get riscv_asm.h, 84 ppp_init splic_varm_irqchip_init plic_varm_irqchip_init plic_varm_irqchip_init plic, 450 plic, 314 ppp_get riscv_asm.h, 84 ppp_init splic_varm_irqchip_init plic_varm_irqchip_init plic_varm_irqchip_i		sbi console.c, 345
PLIC_ENABLE_STRIDE_448 PLIC_PENDING_BASE_448 PLIC_PENDINT_BASE_448 plic_base_451 plic_cold_irqchip_init, 448 plic_num_sources, 451 plic_set_lie_int, 450 plic_set_lie_int, 313 plic_fdt_fixup, 313 plic_tdt_fixup plic_c, 448 plic_, 448 plic_, 448 plic_, 451 plic_cold_irqchip_init, 314 plic_base plic_c, 449 plic_set_lie_int plic_c, 449 plic_set_lie_int plic_c, 449 plic_set_lie_int plic_c, 451 plic_num_sources plic_t, 451 plic_set_lie plic_c, 451 plic_num_sources plic_t, 451 plic_pelic_int plic_c, 449 plic_tf_fixup plic_c, 449 plic_tf_fixup plic_c, 451 plic_pelic_int plic_c, 449 plic_h, 313 plic_tf_fixup plic_c, 451 plic_pelic_int plic_c, 451 plic_pelic_int plic_c, 451 plic_pelic_int plic_th_fixup		
PLIC_PENDING_BASE, 448 PLIC PRIORITY_BASE, 448 Plic_base, 451 plic_cold_irqchip_init, 448 plic_fat_fixup, 449 plic_hart_count, 451 plic_set_ie, 449 plic_set_priority, 450 plic_warm_irqchip_init, 450 plic_warm_irqchip_init, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 451 plic_cold_irqchip_init plic_c, 451 plic_cold_irqchip_init plic_c, 448 plic_hart_count plic_ft_fixup plic_ft_fixup plic_hart_count plic_c, 451 plic_num_sources plic_c, 451 plic_plic_nim_sources plic_c, 451 plic_plic_set_ie plic_set_ie plic_set_priority plic_set_priority plic_c, 450 plic_set_thresh plic_c, 450 plic_h 314 ppp_get riscv_asm.b, 84 ppp_init ppp_region_count ppp_region_count riscv_encoding,h, 157 priory		sbi console.c, 345
PLIC_PRIORITY_BASE, 448 plic_base, 451 plic_cold_irqchip_init, 448 plic_fdt_fixup, 449 plic_hart_count, 451 plic_set_ie, 449 plic_set_priority, 450 plic_set_priority, 450 plic_set_ie, 449 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 314 plic_base plic.c, 451 plic_cold_irqchip_init plic.c, 448 plic.h, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 314 plic_set_ie, 313 plic_cold_irqchip_init plic.c, 451 plic_cold_irqchip_init plic.c, 449 plic.h, 313 plic_set_ie, 314 plic_set_ie, 313 plic_set_ie, 314 plic_set_ie, 313 plic_set_ie, 314 plic_set_ie, 313 plic_set_ie, 315 plic_set_ie, 316 plic_set_ie, 316 plic_set_ie, 316 plic_set_ie, 316 plic_set_ie, 317 plic_set_ie, 318 pl		
plic_base, 451 plic_cold_irqchip_init, 448 plic_ftf_fxup, 449 plic_hart_count, 451 plic_set_priority, 450 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 313 plic_cold_irqchip_init, 314 plic_cold_irqchip_init, 314 plic_cold_irqchip_init plic_c, 451 plic_c, 451 plic_num_sources plic.c, 451 plic_icd_ft_fxup plic_set_ie, 313 plic_c, 451 plic_cold_irqchip_init plic.c, 451 plic_num_sources plic.c, 451 plic_num_sources plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 450 plic.set_ie plic.c, 450 plic, 314 plic_warm_irqchip_init plic.c, 450 plich, 314 ppg_get riscv_asm.b, 84 pp_init pp_get riscv_asm.b, 84 pp_rejoin_count pp_rejoin_count pricsc_ies plic, 314 ppp_get riscv_asm.b, 84 ppp_rejoin_count pricsc_ies plic_t, 314 ppp_get riscv_asm.b, 84 ppp_rejoin_count pricsc_ies plic_t, 314 ppp_get riscv_asm.b, 84 ppp_rejoin_count pricsc_ies plic_that.c, 381 ppp_rejoin_count pricsc_ies priceses pricsc_ies pricsc_ies prices prics		•
pilic_cold_irqchip_init, 448 pilic_fldt_fixup, 449 pilic_num_sources, 451 pilic_set_ie, 449 pilic_set_ie, 449 pilic_set_ie, 449 pilic_set_ie, 449 pilic_set_ie, 449 pilic_set_ie, 449 pilic_set_thresh, 450 pilic_warm_irqchip_init, 450 pilic_warm_irqchip_init, 313 pilic_set_ie, 313 pilic_set_ie, 313 pilic_set_ie, 313 pilic_set_ie, 314 pilic_warm_irqchip_init, 314 pilic_base pilic_c, 451 pilic_cold_irqchip_init pilic_c, 448 pilic_h, 313 pilic_ft_fixup pilic_c, 448 pilic_h, 313 pilic_ft_fixup pilic_c, 449 pilic_h, 313 pilic_part_count pilic_c, 451 pilic_num_sources pilic_, 451 pilic_part_fount pilic_c, 450 pilic_h, 313 pilic_set_priority pilic_c, 450 pilic_h, 314 pilic_warm_irqchip_init pilic_n, 450 pilic_h, 314 pilic_warm_irqchip_init pilic_n, 450 pilic_h, 314 pilic_part_in, 328 pilic_part_in, 328 pilic_part_in, 328 pilic_part_in, 328 pilic_part_in, 328 pilic_part_in, 325 pilic_part_in, 326 pilic_part_in, 327 pilic_part_in, 327 pilic_part_in, 327 pilic_part_in, 328 pilic_part_in, 328 pilic_part_in, 327 probes process pilic_part_in, 320 pilic_part_in, 320 pilic_part_in, 321 process pilic_part_in, 322 pilic_part_in, 322 pilic_part_in, 322 pilic_part_in, 322 pili		
pilic_fdt_fixup, 449 pilic_hart_count, 451 pilic_num_sources, 450 pilic_set_ie, 449 pilic_set_ie, 449 pilic_set_ie, 449 pilic_set_priority, 450 pilic_set_ie, 450 pilic_set_ie, 450 pilic_set_ie, 450 pilic_set_ie, 313 pilic_set_thresh, 314 pilic_set_ie, 313 pilic_set_thresh, 314 pilic_set_ie, 313 pilic_set_thresh, 314 pilic_oase pilic_c, 451 pilic_cold_irqchip_init pilic_c, 448 pilic_h, 313 pilic_fdt_fixup pilic_h, 313 pilic_fdt_fixup pilic_c, 449 pilic_num_sources pilic_c, 451 pilic_num_sources pilic_c, 451 pilic_set_ie pilic_c, 451 pilic_set_ie pilic_c, 451 pilic_set_ie pilic_c, 451 pilic_set_ie pilic_c, 450 pilic_set_tresh pilic_c, 450 pilic_h, 314 pilic_warm_irqchip_init pilic_n, 350 pilic_h, 314 pilic_warm_irqchip_init pilic_n, 450 pilic_h, 315 pilic_h, 316 pilic_h, 450 pilic_h,	• —	•
piic_hart_count, 451 piic_num_sources, 451 piic_set_ie, 449 piic_set_briority, 450 piic_set_thresh, 450 piic_set_thresh, 450 piic_set_ie, 313 piic_set_ie, 313 piic_set_ie, 313 piic_set_thresh, 314 piic_warm_irqchip_init, 314 piic_old_irqchip_init piic_c, 451 piic_c, 448 piic_td_fixup piic_c, 448 piic_hart_count piic_c, 449 piic_num_sources piic_c, 451 piic_num_sources piic_c, 451 piic_num_sources piic_c, 451 piic_set_ie piic_c, 450 piic_k, 314 piic_warm_irqchip_init piic_k, 450 piic_h, 314 piic_warm_irqchip_init piic_k, 450 piic_h, 314 pp_get riscv_asm.h, 84 pp_get riscv_asm.h, 84 pp_get riscv_asm.h, 84 pp_pet riscv_asm.h, 84 ppp_init sbi_hart.c, 381 pp_get_encoding.h, 157 process sbi_ipie_vent_ops, 54 plock sbi_iffo, 53 queue sbi_iffo, 54 README.md, 661 REG_MSK riscv_encoding.h, 156 REG_PTR riscv_encoding.h, 156 REG_PTR riscv_encoding.h, 156 REG_PTR riscv_encoding.h, 156 REG_L riscv_asm.h, 81 REG_S riscv_asm.h, 81 REG_S riscv_asm.h, 81 REG_S RISCV_FENCE riscv_encoding.h, 156 RISCV_PGSI/IE riscv_encoding.h, 156 RISCV_PGI/IE riscv_encoding.h, 156 RIS		
piic_num_sources, 451 piic_set_ie, 449 piic_set_priority, 450 piic_set_priority piic_cold_irqchip_init, 313 piic_set_ie, 313 piic_set_ie, 313 piic_set_ie, 313 piic_set_priority piic_c, 451 piic_cold_irqchip_init piic_tot_fixup p		•
piic_set_ie, 449 piic_set_priority, 450 piic_set_priority, 450 piic_set_mram_irqchip_init, 450 piic_n piic_set_ie, 313 piic_set_thresh, 314 piic_set_thresh, 314 piic_set_thresh, 314 piic_set_thresh, 314 piic_dase piic.c, 451 piic_dase piic.c, 448 piic.h, 313 piic_fdt_fixup piic.c, 449 piic.h, 313 piic_set_ie, 313 piic_set_ie, 313 piic_set_ie, 314 piic_set_ie, 314 piic_set_ie, 315 piic_dase piic.c, 451 piic_oold_irqchip_init piic.c, 448 piic.h, 313 piic_fdt_fixup piic.c, 449 piic.h, 313 piic_thart_count piic.c, 451 piic_num_sources piic.c, 451 piic_num_sources piic.c, 451 piic_set_ie piic.c, 449 piic.h, 313 piic_set_ie piic.c, 450 piic.h, 314 piic_set_thresh piic.c, 450 piic.h, 314 piic_warm_irqchip_init piic.c, 450 piic.h, 314 piic_pet riscv_asm.c, 328 riscv_asm.h, 84 prp_init sbi_hart.c, 381 procest_init, 450 procest_ie piic_land piic_set_proceding.h, 157 piic_land piic_pet piic_land piic_land piic_pet piic_pat piic_pet piic_pat piic	• – –	
pilic_set_priority, 450 plic_set_thresh, 450 plic_set_thresh, 450 plic_nch plic_cold_irqchip_init, 450 plic_dt_fixup, 313 plic_set_thresh, 314 plic_warm_irqchip_init, 314 plic_warm_irqchip_init, 314 plic_warm_irqchip_init, 314 plic_warm_irqchip_init plic_c, 4451 plic_cold_irqchip_init plic_c, 448 plic.h, 313 plic_fdt_fixup plic_c, 449 plic_h, 313 plic_nart_count plic_c, 451 plic_num_sources plic_c, 451 plic_set_ie plic_c, 449 plic_h, 313 plic_set_ie plic_set_ie plic_set_ie plic_set_ie plic_set_priority plic_set_set_priority plic_set_set_priority plic_set_foo plic_h, 314 plic_set_priority plic_set_thresh plic_c, 450 plic_h, 314 plic_warm_irqchip_init plic_warm_irqchip_init plic_warm_irqchip_init plic_set_set_set_priority plic_h, 314 plic_marm_oset plic_h, 314 plic_marm_irqchip_init plic_set_set_set_priority plic_h, 314 plic_marm_irqchip_init plic_warm_irqchip_init plic_warm_irqchip_init plic_warm_irqchip_init plic_set_set_set_priority plic_h, 314 plic_marm_irqchip_init plic_warm_irqchip_init plic_set_set_set_priority plic_h, 314 plic_marm_irqchip_init plic_warm_irqchip_init plic_set_set_set_priority plic_h, 314 plic_marm_irqchip_init plic_warm_irqchip_init plic_warm_irqchip_init plic_warm_irqchip_init plic_yarm_irqchip_init plic_yarm_irqchip_in		•
plic_set_thresh, 450 plic_warm_irqchip_init, 450 plic_h plic_cold_irqchip_init, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 314 plic_warm_irqchip_init, 314 plic_warm_irqchip_init, 314 plic_base plic.c, 451 plic_cold_irqchip_init plic_c, 448 plic_h, 313 plic_ft_fixup plic_h, 313 plic_ft_fixup plic_h, 313 plic_hart_count plic_c, 451 plic_num_sources plic_c, 451 plic_set_ie plic_c, 451 plic_set_ie plic_c, 450 plic_h, 314 plic_warm_irqchip_init plic_warm_irqchip_init plic_warm_irqchip_init plic_c, 450 plic_h, 314 pmp_get riscv_asm.h, 84 pmp_init sb_hart_c, 381 pm_jeegin_count plic_set_encoding,h, 156 plic_marm_irqchip_init plic_t, 450 plic_h, 314 pmp_region_count plic_t, 381 pmp_region_count plic_t, 381 pm_resion_count plic_t, 381 pm_region_count plic_t, 351 plic_pat_ie plic_th, 314 pmp_region_count plic_th, 315 plic_pat_ie plic_th, 316 plic_pat_ie plic_th, 317 plic_pat_ie plic_th, 318 pmp_region_count plic_th, 319 pmp_region_count plic_th, 319 pmp_region_count plic_th, 314 pmp_region_count plic_th, 315 plic_pat_ie plic_th, 316 plic_pat_ie plic_th, 317 plic_pat_ie plic_th, 318 pmp_region_count plic_th, 319 pmp_region_count plic_th, 313 plic_pat_pat_pat_pat_pat_pat_pat_pat_pat_pat		cspereepe, e :
plic_set_mesh, 450 plic_n plic_warm_irqchip_init, 450 plic.h plic_cold_irqchip_init, 313 plic_set_tie, 313 plic_set_thresh, 314 plic_base plic.c, 451 plic_cold_irqchip_init plic.c, 449 plic.h, 313 plic_hart_count plic_c, 451 plic_num_sources plic.c, 451 plic_set_ie plic_c, 450 plic_h, 314 plic_set_thresh plic_c, 450 plic_h, 314 plic_warm_irqchip_init plic.c, 450 plic_h, 314 plic_warm_irqchip_init plic.c, 450 plic_h, 314 pmp_get riscv_asm.h, 84 pmp_nint sb_hart.c, 381 pmp_region_count sb_fifo, 53 queue sb_fifo, 54 sb_fifo, 53 queue sb_fifo, 53 queue sb_fifo, 53 queue sb_fifo, 54 README.md, 661 REG_MASK riscv_encoding.h, 156 REG_PTR riscv_encoding.h, 156 REG_PTR riscv_encoding.h, 156 REG_L riscv_asm.h, 81 REG_S riscv_asm.h, 81 REG_S riscv_asm.h, 81 REG_STTES riscv_encoding.h, 156 RISCV_PGLEVEL_BITS riscv_encoding.h, 156 RISCV_PGSHIFT riscv_encoding.h, 156 RISCV_PGSHIFT riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 REG_DFSIZE RISCV_PGSHIFT riscv_encoding.h, 156 REG_LT REG_MXK riscv_encoding.h, 156 REG_LT REG_DMASK riscv_encoding.h, 156 REG_LT REG_DTAR riscv_encoding.h, 156 REG_LT riscv_enco		glock
pilic_warm_injenip_init, 450 pilic_cold_irqchip_init, 313 pilic_fdt_fixup, 313 pilic_set_ie, 313 pilic_set_ie, 313 pilic_warm_irqchip_init, 314 pilic_warm_irqchip_init, 314 pilic_base pilic.c, 451 pilic_cold_irqchip_init pilic.c, 448 pilic.h, 313 pilic_fdt_fixup pilic_fdt_fixup pilic_c, 449 pilic_n, 313 pilic_nart_count pilic_n, 451 pilic_num_sources pilic_n, 451 pilic_set_ie pilic_c, 449 pilic_n, 451 pilic_set_ie pilic_c, 450 pilic_h, 314 pilic_warm_irqchip_init pilic_n, 450 pilic_h, 314 pilic_pet pilic_n, 450 pilic_h, 314 pilic_pet pilic_n, 450 pilic_h, 314 pilic_pet pilic_n, 305 pilic_pet pil		•
plic_cold_irqchip_init, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 314 plic_base plic.c, 451 plic_cold_irqchip_init plic.c, 449 plic_hart_count plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic_base plic.c, 451 plic_inum_sources plic.c, 451 plic_set_ie plic.c, 451 plic_set_ie plic.c, 451 plic_inum_sources plic.c, 451 plic_set_ie plic.c, 450 plic_set_ie plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.h, 34 pmp_get riscv_asm.h, 34 pmp_init sbi_hart.c, 381 pmp_region_count README.md, 661 REG_MASK riscv_encoding.h, 156 REG_OFFSET riscv_encoding.h, 156 REG_DFTR riscv_encoding.h, 156 REG_L riscv_encoding.h, 156 REG_L riscv_asm.h, 81 REG_BYTES riscv_encoding.h, 156 RISCV_ACQUIRE_BARRIER riscv_barrier.h, 92 RISCV_PGLEVEL_BITS riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 ROUNDUP riscv_encoding.h, 157 RVC_LD_IMM riscv_encoding.h, 157		
plic_dt_fixup, 313 plic_set_ie, 313 plic_set_ie, 313 plic_set_ie, 314 plic_warm_irqchip_init, 314 plic_base plic.c, 451 plic_hart_count plic_num_sources plic.c, 451 plic_num_sources plic.c, 449 plic_base plic.c, 451 plic_set_ie plic.c, 451 plic_out_fixup plic.c, 451 plic_out_sources plic.c, 451 plic_set_ie plic.c, 450 plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.h, 84 pmp_nint sbi_hart.c, 381 pmp_region_count plicsc, 381 pmp_region_count plicsc, 481 plic_hart_count plic.c, 450 pmp_region_count plic.c, 450 pmp_region_count plic.c, 381 pmp_region_count plic.c, 381 pmp_region_count plic.c, 381 pmp_region_count plic.d, 381 pmp_region_count plic.d, 314 prop_region_count plic.d, 381 pmp_region_count plic.d, 381 pmp_region_count plic.d, 450 procedure, 156 procedure, 157 procedure, 156 procedure, 157 procedure, 156 procedure, 15	•	
plic_set_ie, 313 plic_set_thresh, 314 plic_warm_irqchip_init, 314 plic_base plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic_set_ie plic.c, 451 plic_set_ie plic.c, 450 plic.set_thresh plic.c, 450 plic.c, 450 plic.d, 314 plic.c, 450 plic.d, 314 plic.c, 450 plic.d, 314 ppp_get riscv_asm.h, 84 ppp_pinit plic.c, 450 plic.h, 314 ppp_get riscv_asm.h, 84 ppp_init sbi_hart.c, 381 ppp_region_count REG_PTR riscv_encoding.h, 156 REG_L riscv_encoding.h, 156 REG_PTR riscv_encoding.h, 156 REG_PTER riscv_encoding.h, 156 REG_PTER riscv_encoding.h, 156 REG_PTER riscv_encoding.h, 156 REG_PTER		
plic_set_thresh, 314 plic_warm_irqchip_init, 314 plic_base plic.c, 451 plic_cold_irqchip_init plic.c, 449 plic.n, 313 plic_hart_count plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_ntart_ount plic.c, 451 plic_set_ie plic.c, 451 plic_set_ie plic.c, 450 plic.set_thresh plic.c, 450 plic.h, 314 pmp_get riscv_asm.h, 84 plic.h, 314 pmp_region_count plic.c, 450 pmp_get riscv_asm.h, 84 pmp_init plic.c, 381 pmp_region_count plic.c, 381 priscv_encoding,h, 156 priscv_encoding,h, 157		README.md, 661
plic_warm_irqchip_init, 314 plic_base plic.c, 451 plic_cold_irqchip_init plic_cold_irqchip_init plic.c, 448 plic.h, 313 plic_ftd_fixup plic.c, 449 plic.h, 313 plic_hart_count plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_je plic.c, 450 plic.set_thresh plic.c, 450 plic.h, 314 ppp_get risev_asm.c, 328 risev_asm.c, 328 risev_asm.c, 328 risev_asm.c, 381 pmp_get risev_asm.c, 381 pmp_region_count PREG_PTR risev_encoding.h, 156 REG_L risev_asm.h, 81 REG_S risev_asm.h, 81 REG_S risev_asm.h, 81 REG_S risev_asm.h, 81 REG_S REG_OFFSET risev_encoding.h, 156 REG_L risev_asm.h, 81 REG_S REG_CFT risev_encoding.h, 156 REG_L risev_asm.h, 81 REG_S REG_UL risev_asm.h, 81 REG_S REG_L risev_asm.h, 81 REG_S REG_L risev_asm.h, 81 REG_S REG_L RISev_PC_LD_IMM risev_encoding.h, 156 REG_L risev_asm.h, 81 REG_S RISev_asm.h Reg_S RISev_asm.h Reg_S RISev_asm.h Re		REG MASK
plic_warm_irqchip_init, 314 plic_base plic.c, 451 plic_cold_irqchip_init plic.c, 448 plic.h, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_hart_count plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_je plic.c, 450 plic.c, 450 plic.c, 450 plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic_warm_irtqchip_init plic_warm_irtqchip_init plic_warm_irtqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.h, 84 prication	· — —	riscv encoding.h, 156
plic.c, 451 plic_cold_irqchip_init plic.c, 448 plic.h, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_h, 313 plic_h, 313 plic_hart_count plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_periority plic.c, 450 plic.c, 450 plic.h, 314 pmp_get resev_asm.c, 328 risev_asm.h, 81 REG_S risev_asm.h, 81 REG_S risev_asm.h, 81 REG_S risev_asm.h, 81 REG_S risev_asm.h, 81 REG_STES RISCV_acquire_h, 81 REG_STES RISCV_ACQUIRE_BARRIER risev_barrier.h, 92 RISCV_FENCE risev_barrier.h, 92 RISCV_FENCE risev_encoding.h, 156 RISCV_PGLEVEL_BITS risev_encoding.h, 156 RISCV_PGSHIFT risev_encoding.h, 156 RISCV_PGSIZE risev_encoding.h, 156 RISCV_RELEASE_BARRIER RISCV_RELEASE_BARRIER RISCV_RELEASE_BARRIER RISCV_RELEASE_BARRIER RISCV_RELEASE_BARRIER RISCV_BELEASE_BARRIER		
plic.c, 451 plic_cold_irqchip_init plic.c, 448 plic.h, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_hart_count plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_priority plic.c, 450 plic_set_for plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 plic_nder_irich, 317 plic_red_init plic_cold_irichip_init plic_c, 450 plic_num_irichip_init plic_c, 450 plic_num_irichip_init plic_c, 450 plic_num_irichip_init plic_		_
plic_cold_irqchip_init plic.c, 448 plic.h, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_h, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_h, 313 plic_hart_count plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_je plic.c, 450 plic_set_thresh plic_set_thresh plic_set_je plic_c, 450 plic_set_je plic_set_je	plic.c, 451	
plic.c, 448 plic.h, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_hart_count plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_priority plic.c, 450 plic_set_thresh plic_set_thresh plic_warm_irqchip_init plic_warm_irqchip_init prop_get riscv_asm.h, 81 REG_S RIscv_acquinelle riscv_asm.h, 81 REG_S RIscv_acquinelle r		_
plic.h, 313 plic_fdt_fixup plic.c, 449 plic.h, 313 plic_hart_count plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_je plic.c, 450 plic.set_thresh plic.c, 450 pl	plic.c, 448	
plic_fdt_fixup plic.c, 449 plic.h, 313 plic_hart_count plic_c, 451 plic_num_sources plic_c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_je plic.c, 450 plic_set_thresh plic_c, 450 plic_h, 314 plic_warm_irqchip_init plic_c, 450 plic, h, 314 ppp_get riscv_asm.c, 328 riscv_asm.c, 328 riscv_asm.h, 84 ppp_region_count REG_S riscv_asm.h, 81 REG_S riscv_encoding.h, 156 RISCV_ACQUIRE_BARRIER riscv_barrier.h, 92 RISCV_FENCE riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 157	plic.h, 313	-
plic.c, 449 plic.h, 313 plic.h, 313 plic.hart_count plic.c, 451 plic.num_sources plic.c, 451 plic.set_ie plic.c, 449 plic.h, 313 plic.h, 313 plic.set_je plic.c, 449 plic.h, 313 plic.h, 313 plic.c, 449 plic.c, 450 plic.set_thresh plic.c, 450 plic.h, 314 plic.warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.h, 84 pmp_init pmp_region_count riscv_encoding.h, 157 priscv_encoding.h, 157 priscv_encoding.h, 305 priscv_encoding.h, 305 priscv_encoding.h, 157 priscv_encoding.h, 157 priscv_encoding.h, 305 priscv_encoding.h, 157 priscv_encoding.h, 157 priscv_encoding.h, 157 priscv_encoding.h, 157 priscv_encoding.h, 157 priscv_encoding.h, 157	plic_fdt_fixup	
plic.h, 313 plic_hart_count plic.c, 451 plic_num_sources plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_priority plic.c, 450 plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 ppp_get plic.c, 450 ppp_get plic.c, 450 plic.h, 314 pmp_init ppp_region_count plic.h, 314 pmp_region_count plic.h, 315 priscv_encoding.h, 156 priscv_encoding.h, 157 priscv_encoding.h, 157 priscv_encoding.h, 157	plic.c, 449	_
plic_hart_count plic.c, 451 plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic.set_priority plic.c, 450 plic.set_thresh plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 ppp_get riscv_asm.c, 328 riscv_asm.h, 84 ppp_init ppic.c, 381 ppic.c, 450 plic.hart.c, 381 ppr_get priority ppic.c, 450 plic.hart.c, 381 ppr_get ppic.c, 381 ppic.e, 451 ppic.e, 452 ppic.e, 453 ppic.e, 454 ppic.e, 455 ppic.e, 450	plic.h, 313	
plic.c, 451 plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic.set_priority plic.c, 450 plic.set_thresh plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.c, 328 riscv_asm.h, 84 pmp_init plic.c, 450 plic.num_sources riscv_barrier.h, 92 RISCV_PGLEVEL_BITS riscv_encoding.h, 156 RISCV_PGSHIFT riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 ROUNDUP sbi_types.h, 305 RV_X riscv_encoding.h, 157 RVC_LD_IMM pmp_region_count	plic_hart_count	
plic_num_sources plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_priority plic.c, 450 plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.h, 84 pmp_region_count riscv_barrier.h, 92 RISCV_PGSLIE riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 RV_X riscv_encoding.h, 157 RVC_LD_IMM riscv_encoding.h, 157	plic.c, 451	_
plic.c, 451 plic_set_ie plic.c, 449 plic.h, 313 plic_set_priority plic.c, 450 plic_set_thresh plic.h, 314 plic_warm_irqchip_init plic_c, 450 plic_sat_mirqchip_init plic_warm_irqchip_init plic.c, 450 plic_set_set_othersh plic_warm_irqchip_init plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.c, 328 riscv_asm.h, 84 pmp_init pmp_region_count RISCV_PGLEVEL_BITS riscv_encoding.h, 156 RISCV_PGSHIFT riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 ROUNDUP riscv_asm.c, 328 riscv_asm.h, 84 RV_X riscv_encoding.h, 157 RVC_LD_IMM riscv_encoding.h, 157	plic_num_sources	
plic_set_ie plic.c, 449 plic.h, 313 riscv_encoding.h, 156 plic_set_priority plic.c, 450 plic_set_thresh plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.h, 84 pmp_init pmp_region_count riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 RV_X riscv_encoding.h, 157	plic.c, 451	-
plic.c, 449 plic.h, 313 plic_set_priority plic.c, 450 plic_set_thresh plic.c, 450 plic_set_priority plic.c, 450 plic_set_thresh plic.c, 450 plic_set_thresh plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.c, 328 riscv_asm.h, 84 pmp_init pmp_region_count RISCV_PGSIZE riscv_encoding.h, 156 RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 ROUNDUP riscv_asm.c, 328 riscv_asm.c, 328 RV_X RV_X RV_C_LD_IMM riscv_encoding.h, 157	plic_set_ie	
plic.h, 313 plic_set_priority plic.c, 450 plic_set_thresh plic.c, 450 plic_set_thresh plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.h, 314 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.c, 328 riscv_asm.h, 84 pmp_init riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 ROUNDUP riscv_asm.c, 328 riscv_asm.h, 84 RV_X pmp_init riscv_encoding.h, 157 RVC_LD_IMM pmp_region_count	plic.c, 449	
plic_set_priority plic.c, 450 riscv_encoding.h, 156 plic_set_thresh plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.c, 328 riscv_asm.h, 84 pmp_init riscv_encoding.h, 156 RISCV_PGSIZE riscv_encoding.h, 156 RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 ROUNDUP riscv_asm.c, 328 riscv_asm.h, 84 RV_X riscv_encoding.h, 157 RVC_LD_IMM pmp_region_count	plic.h, 313	
plic.c, 450 plic_set_thresh plic.c, 450 plic_set_thresh plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.c, 328 riscv_asm.h, 84 pmp_init pmp_region_count riscv_encoding.h, 157 riscv_encoding.h, 157 riscv_encoding.h, 157 riscv_encoding.h, 157	plic set priority	
plic_set_thresh plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.c, 328 riscv_asm.h, 84 pmp_init pmp_region_count RISCV_PGSIZE riscv_encoding.h, 156 RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 ROUNDUP riscv_encoding.h, 305 RV_X riscv_encoding.h, 157	, .	-
plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.c, 450 plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.h, 84 pmp_init sbi_hart.c, 381 pmp_region_count riscv_encoding.h, 157 riscv_encoding.h, 157 riscv_encoding.h, 157	•	
plic.h, 314 plic_warm_irqchip_init plic.c, 450 plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.h, 84 pmp_init pmp_region_count RISCV_RELEASE_BARRIER riscv_barrier.h, 92 ROUNDDOWN sbi_types.h, 305 ROUNDUP sbi_types.h, 305 RV_X riscv_encoding.h, 157	• — —	
plic_warm_irqchip_init	•	
plic.c, 450 plic.h, 314 sbi_types.h, 305 pmp_get riscv_asm.c, 328 riscv_asm.h, 84 pmp_init sbi_hart.c, 381 pmp_region_count ROUNDDOWN sbi_types.h, 305 ROUNDUP sbi_types.h, 305 RV_X riscv_encoding.h, 157	•	
plic.h, 314 pmp_get riscv_asm.c, 328 riscv_asm.h, 84 pmp_init sbi_hart.c, 381 pmp_region_count sbi_types.h, 305 RV_X riscv_encoding.h, 157 RVC_LD_IMM riscv_encoding.h, 157		
pmp_get ROUNDUP riscv_asm.c, 328 sbi_types.h, 305 riscv_asm.h, 84 RV_X pmp_init riscv_encoding.h, 157 sbi_hart.c, 381 RVC_LD_IMM pmp_region_count riscv_encoding.h, 157	•	
riscv_asm.c, 328 sbi_types.h, 305 riscv_asm.h, 84 RV_X pmp_init riscv_encoding.h, 157 sbi_hart.c, 381 RVC_LD_IMM pmp_region_count riscv_encoding.h, 157	•	
riscv_asm.h, 84 pmp_init riscv_encoding.h, 157 sbi_hart.c, 381 pmp_region_count RVC_LD_IMM riscv_encoding.h, 157		
pmp_init riscv_encoding.h, 157 sbi_hart.c, 381 RVC_LD_IMM pmp_region_count riscv_encoding.h, 157		
sbi_hart.c, 381 RVC_LD_IMM pmp_region_count riscv_encoding.h, 157		_
pmp_region_count riscv_encoding.h, 157		
ou_piationii_operations, oo nvo_LDor_liviivi		
	301_piatio1111_operatio113, 00	TTVO_LD3F_IIVIIVI

riscv_encoding.h, 157	PAGE_SHIFT, 81
RVC_LW_IMM	PAGE_SIZE, 81
riscv_encoding.h, 157	pmp_get, 84
RVC_LWSP_IMM	pmp_set, 85
riscv_encoding.h, 157	REG_L, 81
RVC_RS1S	REG_S, 81
riscv_encoding.h, 158	SZREG, 81
RVC_RS2	wfi, 81
riscv_encoding.h, 158	riscv_atomic.c
RVC_RS2S	NOP, 332
riscv_encoding.h, 158	NOT, 332
RVC_SDSP_IMM	atomic_op_bit, 331
riscv_encoding.h, 158	atomic_op_bit_ord, 331
RVC_SWSP_IMM	axchg, 331
riscv_encoding.h, 158	cmpxchg, 332
ra	xchg, 332
sbi_trap_regs, 68	arch_atomic_cmpxchg, 334
readb	arch_atomic_xchg, 334 atomic_add_return, 334
riscv_io.h, 168 readb relaxed	atomic clear bit, 334
riscv_io.h, 168	atomic_raw_clear_bit, 335
readl	atomic_raw_clear_bit, 335
riscv_io.h, 168	atomic_raw_set_bit, 336
readl relaxed	atomic_raw_xchg_ulong, 336
riscv_io.h, 168	atomic_read, 336
readq	atomic_set_bit, 336
riscv_io.h, 168	atomic_sub_return, 337
readq_relaxed	atomic_write, 337
riscv_io.h, 168	axchg, 333
readw	_
	cmpxchg, 333 xchg, 333
readw	cmpxchg, 333
readw riscv_io.h, 168	cmpxchg, 333 xchg, 333
readw riscv_io.h, 168 readw_relaxed	cmpxchg, 333 xchg, 333 riscv_atomic.h
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_set, 329	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_lear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88 atomic_raw_xchg_uint, 89
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_set, 329 riscv_asm.h	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_get, 329 riscv_asm.hASM_STR, 78	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_klen, 328 pmp_get, 328 pmp_get, 328 pmp_set, 329 riscv_asm.hASM_STR, 78 csr_clear, 78	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_set_bit, 89
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_set, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read, 78	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_lear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_uint, 89 atomic_read, 89 atomic_set_bit, 89 atomic_sub_return, 90
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_get, 328 pmp_set, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read_78 csr_read_clear, 78	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_lear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_uint, 89 atomic_read, 89 atomic_read, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_get, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read_clear, 78 csr_read_num, 82	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90 riscv_barrier.h
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_get, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read_78 csr_read_clear, 78 csr_read_clear, 78 csr_read_set, 79	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_set_bit, 89 atomic_set_bit, 89 atomic_sub_return, 90 riscv_barrier.hsmp_load_acquire, 91
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_klen, 328 pmp_get, 328 pmp_get, 328 pmp_set, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read, 78 csr_read_clear, 78 csr_read_loum, 82 csr_read_set, 79 csr_set, 79	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_set_bit, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90 riscv_barrier.hsmp_load_acquire, 91smp_store_release, 91
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_klen, 328 pmp_get, 328 pmp_get, 328 pmp_set, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read, 78 csr_read_clear, 78 csr_read_loum, 82 csr_read_set, 79 csr_set, 79 csr_swap, 79	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_lear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90 riscv_barrier.hsmp_load_acquire, 91smp_store_release, 91 cpu_relax, 91
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_get, 328 pmp_set, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read, 78 csr_read_clear, 78 csr_read_loum, 82 csr_read_set, 79 csr_swap, 79 csr_swap, 79 csr_write, 80	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_lear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_uint, 89 atomic_read, 89 atomic_read, 89 atomic_sub_return, 90 atomic_sub_return, 90 riscv_barrier.hsmp_load_acquire, 91smp_store_release, 91 cpu_relax, 91 mb, 92
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_set, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read_roum, 82 csr_read_set, 79 csr_set, 79 csr_swap, 79 csr_write_num, 82	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_lear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_read, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90 riscv_barrier.hsmp_load_acquire, 91smp_store_release, 91 cpu_relax, 91 mb, 92 RISCV_ACQUIRE_BARRIER, 92
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_get, 328 pmp_set, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read_, 78 csr_read_clear, 78 csr_read_loum, 82 csr_read_set, 79 csr_set, 79 csr_swap, 79 csr_write, 80 csr_write_num, 82 LGREG, 80	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_lear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_set_bit, 89 atomic_set_bit, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90 riscv_barrier.hsmp_load_acquire, 91smp_store_release, 91 cpu_relax, 91 mb, 92 RISCV_ACQUIRE_BARRIER, 92 RISCV_FENCE, 92
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_xlen, 328 pmp_get, 328 pmp_get, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read_r8 csr_read_clear, 78 csr_read_num, 82 csr_read_set, 79 csr_set, 79 csr_swap, 79 csr_write_num, 82 LGREG, 80 misa_extension, 80	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_set_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_set_bit, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90 riscv_barrier.hsmp_load_acquire, 91smp_store_release, 91 cpu_relax, 91 mb, 92 RISCV_ACQUIRE_BARRIER, 92 RISCV_RELEASE_BARRIER, 92
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_klen, 328 pmp_get, 328 pmp_get, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read, 78 csr_read_clear, 78 csr_read_loar, 78 csr_read_set, 79 csr_set, 79 csr_swap, 79 csr_write, 80 csr_write_num, 82 LGREG, 80 misa_extension, 80 misa_extension_imp, 82	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_set_bit, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90 riscv_barrier.h smp_load_acquire, 91smp_store_release, 91 cpu_relax, 91 mb, 92 RISCV_ACQUIRE_BARRIER, 92 RISCV_RELEASE_BARRIER, 92 rmb, 92
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_klen, 328 pmp_get, 328 pmp_get, 328 pmp_set, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read, 78 csr_read_clear, 78 csr_read_loum, 82 csr_read_set, 79 csr_set, 79 csr_swap, 79 csr_write, 80 csr_write_num, 82 LGREG, 80 misa_extension, 80 misa_extension_imp, 82 misa_string, 83	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_lear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_uint, 89 atomic_read, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90 riscv_barrier.hsmp_load_acquire, 91smp_store_release, 91 cpu_relax, 91 mb, 92 RISCV_ACQUIRE_BARRIER, 92 RISCV_RELEASE_BARRIER, 92 rmb, 92 smp_mb, 92
readw riscv_io.h, 168 readw_relaxed riscv_io.h, 169 riscv_asm.c csr_read_num, 326 csr_write_num, 327 ctz, 327 misa_extension_imp, 327 misa_klen, 328 pmp_get, 328 pmp_get, 329 riscv_asm.hASM_STR, 78 csr_clear, 78 csr_read, 78 csr_read_clear, 78 csr_read_loar, 78 csr_read_set, 79 csr_set, 79 csr_swap, 79 csr_write, 80 csr_write_num, 82 LGREG, 80 misa_extension, 80 misa_extension_imp, 82	cmpxchg, 333 xchg, 333 riscv_atomic.h ATOMIC_INITIALIZER, 86 ATOMIC_INIT, 86 arch_atomic_cmpxchg, 87 arch_atomic_xchg, 87 atomic_add_return, 87 atomic_clear_bit, 87 atomic_raw_clear_bit, 88 atomic_raw_xchg_uint, 89 atomic_raw_xchg_uint, 89 atomic_raw_xchg_ulong, 89 atomic_read, 89 atomic_set_bit, 89 atomic_set_bit, 89 atomic_sub_return, 90 atomic_write, 90 riscv_barrier.h smp_load_acquire, 91smp_store_release, 91 cpu_relax, 91 mb, 92 RISCV_ACQUIRE_BARRIER, 92 RISCV_RELEASE_BARRIER, 92 rmb, 92

winb, 93 risov_encoding.h risov_encoding		
CAUSE_BECAMPOINT_102 CAUSE_FETCH_ACCESS, 102 CAUSE_FETCH_GUEST_PAGE_FAULT, 103 CAUSE_MPERVISOR_ECALL, 103 CAUSE_LILEGAL_INSTRUCTION, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_MSALIGNED_FAULT, 103 CAUSE_MSALIGNED_FETCH, 103 CAUSE_MSALIGNED_FETCH, 103 CAUSE_MSALIGNED_FETCH, 103 CAUSE_MSALIGNED_STORE, 104 CAUSE_MISALIGNED_STORE, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_SUPERVISOR_ECALL, 104 CSR_CYCLE, 105 CSR_DPC, 105 CSR_DPC, 105 CSR_DPC, 105 CSR_DPC, 106 CSR_DPC, 1	wmb, 93	CSR_HPMCOUNTER21, 109
CAUSE_FETCH_ACCESS, 102 CAUSE_FETCH_PAGE_FAULT, 103 CAUSE_FETCH_PAGE_FAULT, 103 CAUSE_MYPERVISOR_ECALL, 103 CAUSE_LLEGAL_INSTRUCTION, 103 CAUSE_LLOAD_ACCESS, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_PAGE_FAULT, 103 CAUSE_LOAD_PAGE_FAULT, 103 CAUSE_MSALIGNED_FAGE_FAULT, 103 CAUSE_MSALIGNED_FETCH, 103 CAUSE_MISALIGNED_LOAD, 104 CAUSE_MISALIGNED_STORE, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_FAULT_104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_COLL_, 104 CAUSE_STORE_FAGE_FAULT, 104 CAUSE_USER_ECALL, 104 CSR_PEMCOUNTER29, 111 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER31, 112 CSR_PEMCOUNTER31, 112 CSR_PEMCOUNTER31, 112 CSR_PEMCOUNTER31, 112 CSR_PEMCOUNTER31, 112 CSR_HPMCOUNTER31, 113 CS	riscv_encoding.h	CSR_HPMCOUNTER21H, 109
CAUSE_FETCH_PAGE_FAULT, 102 CAUSE_HYPERVISOR_ECALL, 103 CAUSE_LILEGAL_INSTRUCTION, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_PAGE_FAULT, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_MACHINE_ECALL, 103 CAUSE_MACHINE_ECALL, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_LOAD, 104 CAUSE_MISALIGNED_LOAD, 104 CAUSE_MISALIGNED_LOAD, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_USER_ECALL, 104 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLE, 104 CSR_DSCRATCH, 105 CSR_FENGS, 105 CSR_HPMCOUNTER3H, 112 CSR_HPMCOUNTER3H, 112 CSR_HPMCOUNTER9H, 110 CSR_HDELEG, 106 CSR_HEDELEG, 106 CSR_HEDELEG, 106 CSR_HEDELEG, 106 CSR_HEMCOUNTER1H, 107 CSR_HPMCOUNTER1H, 108 CSR_HPMCOUNTER1H, 109 CSR_HPMCOUNTER1	CAUSE_BREAKPOINT, 102	CSR_HPMCOUNTER22, 109
CAUSE_FETCH_PAGE_FAULT, 103 CAUSE_ILLEGAL_INSTRUCTION, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_MOAD_PAGE_FAULT, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_PAGE_FAULT, 104 CAUSE_USER_ECALL, 104 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER31, 112 CSR_DCSR_105 CSR_DCSR_105 CSR_DCSR_105 CSR_DCSR_105 CSR_DCSR_105 CSR_DCSR_105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_HPMCOUNTER31, 112 CSR_HPMCOUNTER31, 113 CSR_HPMCOUNTER81, 114 CSR_HPMCOUNTER81, 116 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER115, 108 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 108 CSR_HPMCOUNTER114, 108 CSR_HPMCOUNTER114, 109 CSR_HP	CAUSE_FETCH_ACCESS, 102	CSR_HPMCOUNTER22H, 110
CAUSE_FETCH_PAGE_FAULT, 103 CAUSE_ILLEGAL_INSTRUCTION, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_MOAD_PAGE_FAULT, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_PAGE_FAULT, 104 CAUSE_USER_ECALL, 104 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER29, 111 CSR_HPMCOUNTER31, 112 CSR_DCSR_105 CSR_DCSR_105 CSR_DCSR_105 CSR_DCSR_105 CSR_DCSR_105 CSR_DCSR_105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_HPMCOUNTER31, 112 CSR_HPMCOUNTER31, 113 CSR_HPMCOUNTER81, 114 CSR_HPMCOUNTER81, 116 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER115, 108 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 107 CSR_HPMCOUNTER114, 108 CSR_HPMCOUNTER114, 108 CSR_HPMCOUNTER114, 109 CSR_HP	CAUSE FETCH GUEST PAGE FAULT, 102	CSR HPMCOUNTER23, 110
CAUSE_HYPERVISOR_ECALL, 103 CAUSE_LICAD_ACCESS, 103 CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_PAGE_FAULT, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 104 CAUSE_MISALIGNED_STORE, 104 CAUSE_STORE_CUEST_PAGE_FAULT, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_CUEST_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_USER_FCALL, 104 CAUSE_USER_FCALL, 104 CSR_HPMCOUNTER29, 111 CAUSE_USER_FCALL, 104 CSR_HPMCOUNTER30, 112 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLE, 106 CSR_DSCR, 105 CSR_HPMCOUNTER31H, 112 CSR_FCSR, 105 CSR_HPMCOUNTER3H, 112 CSR_FCSR, 105 CSR_HPMCOUNTER3H, 112 CSR_FCSR, 105 CSR_HPMCOUNTER3H, 113 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERSH, 113 CSR_HCOUNTERSH, 113 CSR_HEDELEG, 106 CSR_HGEIP, 106 CSR_HGEIP, 106 CSR_HGEIP, 106 CSR_HGEIP, 106 CSR_HCOUNTER1H, 107 CSR_HPMCOUNTER1H, 107 CSR_HPMCOUNTER11, 107 CSR_HPMC		-
CAUSE_LICAD_ACCESS, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_LOAD_BAGE_FAULT, 103 CAUSE_MISALICANED_FETCH, 103 CAUSE_MISALICANED_FETCH, 103 CAUSE_MISALICANED_FETCH, 103 CAUSE_MISALICANED_FETCH, 103 CAUSE_MISALICANED_FETCH, 103 CAUSE_MISALICANED_FETCH, 103 CAUSE_MISALICANED_LOAD, 104 CAUSE_MISALICANED_LOAD, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_ECALL, 104 CSR_HPMCOUNTER29, 111 CAUSE_USER_ECALL, 104 CSR_HPMCOUNTER30, 112 CSR_CYCLE, 105 CSR_CYCLE, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_PECALL, 105 CSR_PECALL, 106 CSR_FCASR, 105 CSR_HPMCOUNTER3H, 112 CSR_PECALR, 105 CSR_PECALR, 105 CSR_HPMCOUNTER3H, 112 CSR_PECALR, 106 CSR_HCOUNTERNEN, 105 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HCOUNTERSH, 114 CSR_HPMCOUNTERSH, 116 CSR_HGEIP, 106 CSR_HGEIP, 106 CSR_HGEIP, 106 CSR_HEIP, 106 CSR_HEIP, 106 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTERSH, 116 CSR_HPMCOUNTERSH, 116 CSR_HPMCOUNTERSH, 108 CSR_HPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_MHPMCOUNTERS	:	
CAUSE_LOAD_ACCESS, 103 CAUSE_LOAD_QUEST_PAGE_FAULT, 103 CAUSE_MACHINE_ECALL, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_STORE, 104 CAUSE_MISALIGNED_STORE, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_ECALL, 104 CSR_HPMCOUNTER29H, 111 CSR_DCSR, 105 CSR_CYCLEH, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_HPMCOUNTER9H, 112 CSR_HCOUNTER9H, 112 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 106 CSR_HGATP, 106 CSR_HGEIE, 106 CSR_HGEIE, 106 CSR_HGEIE, 106 CSR_HEIE, 106 CSR_HIDELEG, 106 CSR_HPMCOUNTER1H, 107 CSR_HPMCOUNTER1H, 108 CSR_HPMCOUNTER1H, 109 CSR_HPMCOUNTER1H, 109 CSR_HPMCOUNTER1H, 109 CSR_HPMCOUNTER1H, 109 CSR_HPMCOUNTER1H, 109 CSR_HPMCOUNTER1H, 109 CSR_HPMCOUNTER11, 1109 CSR_HPMCOUNTER1H, 109 CSR_HPMCOUNTER11, 1109 CSR_		
CAUSE_LOAD_GUEST_PAGE_FAULT, 103 CAUSE_LOAD_PAGE_FAULT, 103 CAUSE_MACHINE_FCALL, 103 CAUSE_MACHINE_FCALL, 103 CAUSE_MACHINE_FCALL, 103 CAUSE_MISALIGNED_FTCH, 103 CAUSE_MISALIGNED_FTCH, 103 CAUSE_MISALIGNED_TOAD, 104 CAUSE_MISALIGNED_STORE, 104 CAUSE_MISALIGNED_STORE, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_SUPERVISOR_ECALL, 104 CSR_CYCLE, 105 CSR_CYCLE, 106 CSR_CYCLE, 106 CSR_DPC, 105 CSR_DSCRATCH, 105 CSR_DSCRATCH, 105 CSR_DSCRATCH, 105 CSR_FCASR, 105 CSR_FCASR, 105 CSR_FCASR, 105 CSR_HPMCOUNTERSH, 112 CSR_FCASR, 105 CSR_HPMCOUNTERSH, 112 CSR_HPMCOUNTERSH, 112 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 114 CSR_HPMCOUNTERSH, 116 CSR_HPMCOUNTERSH, 117 CSR_HPMCOUNTERSH, 118 CSR_HPMCOUNTERSH, 119 CSR_HPMCOUNTERSH, 119 CSR_MPMCOUNTERSH, 119 CSR_MPMC		-
CAUSE_LOAD_PAGE_FAULT, 103 CAUSE_MCACHINE_ECALL, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_STORE, 104 CAUSE_MISALIGNED_STORE, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_ECALL, 104 CSR_HPMCOUNTER30, 112 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CSR_CYCLEH, 105 CSR_CSR_CYCLEH, 105 CSR_CSR_CYCLEH, 105 CSR_CSR_CYCLEH, 105 CSR_CSR_CSR_CYCLEH, 105 CSR_CSR_CYCLEH, 105 CSR_CSR_CYCLEH, 105 CSR_CSR_CSR_CSR_CSR_CSR_CSR_CSR_CSR_CSR_		-
CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_LOAD, 104 CAUSE_MISALIGNED_LOAD, 104 CAUSE_MISALIGNED_STORE, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_ECALL, 104 CAUSE_USER_ECALL, 104 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLE, 104 CSR_DOSR, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_HPMCOUNTER3H, 112 CSR_DOUNTERNEN, 105 CSR_HPMCOUNTERNEN, 105 CSR_HEDELEG, 106 CSR_HED		
CAUSE_MISALIGNED_FETCH, 103 CAUSE_MISALIGNED_LOAD, 104 CAUSE_MISALIGNED_STORE, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CSR_HPMCOUNTER28, 111 CAUSE_USER_ECALL, 104 CSR_CYCLE, 105 CSR_CYCLE, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DSCRATCH, 105 CSR_FCSR, 105 CSR_FCSR, 105 CSR_FRM, 105 CSR_FCSR, 105 CSR_FRM, 105 CSR_FCSR, 105 CSR_HPMCOUNTER3H, 112 CSR_HPMCOUNTER3H, 112 CSR_FCSR, 105 CSR_FRM, 105 CSR_HPMCOUNTERH, 113 CSR_HPMCOUNTERH, 113 CSR_HEDELEG, 106 CSR_HGAIP, 106 CSR_HGEIP, 106 CSR_HDELEG, 106 CSR_HPMCOUNTERT, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 114 CSR_HPMCOUNTERSH, 117 CSR_HPMCOUNTERSH, 107 CSR_HPMCOUNTERSH, 107 CSR_HPMCOUNTERSH, 108 CSR_HPMCOUNTERSH, 109 CSR_MPMCOUNTERSH, 119 CSR_MPMC		-
CAUSE_MISALIGNED_LOAD, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_ECALL, 105 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_DCSR, 106 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_FFLAGS, 105 CSR_FRM, 105 CSR_HPMCOUNTERNEN, 105 CSR_HPMCOUNTERNEN, 105 CSR_HPMCOUNTERNEN, 105 CSR_HCOUNTERNEN, 106 CSR_HCOUNTERNEN, 107 CSR_HCOUNTERNEN, 106 CSR_HCOUNTERNEN, 107 CSR_HCOUNTERNEN, 117 CSR_HCOUNTERNEN, 117 CSR_HCOUNTERNE	-	-
CAUSE_MISALIGNED_STORE, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_ACCESS, 104 CAUSE_STORE_GEST_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CSR_HPMCOUNTER29H, 111 CAUSE_USER_ECALL, 104 CSR_DECN_TOSS CSR_CYCLE, 105 CSR_CYCLE, 104 CSR_DECN_TOSS CSR_DECN_TOSS CSR_DECN_TOSS CSR_DECN_TOSS CSR_DECN_TOSS CSR_DECN_TOSS CSR_DECN_TOSS CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_HPMCOUNTER3H, 112 CSR_DECN_TOSS CSR_HPMCOUNTER3H, 112 CSR_DECN_TOSS CSR_HPMCOUNTERSH, 113 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 106 CSR_HCOUNTERNEN, 106 CSR_HCOUNTERSH, 113 CSR_HCOUNTERSH, 113 CSR_HCOUNTERSH, 113 CSR_HCOUNTERSH, 113 CSR_HCOUNTERSH, 113 CSR_HCOUNTERSH, 114 CSR_HPMCOUNTERSH, 117 CSR_HCOUNTERSH, 107 CSR_HCOUNTERSH, 108 CSR_HCOUNTERSH, 108 CSR_HCOUNTERSH, 108 CSR_HCOUNTERSH, 108 CSR_HCOUNTERSH, 108 CSR_HCOUNTERSH, 109 CSR_HCOUNTERS		
CAUSE_STORE_ACCESS, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CSR_HPMCOUNTER3, 111 CSR_HPMCOUNTER3, 111 CSR_HPMCOUNTER3, 111 CSR_HPMCOUNTER3, 111 CSR_HPMCOUNTER3, 111 CSR_HPMCOUNTER3, 112 CSR_CYCLE, 104 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR_TOS CSR_DSCRATCH, 105 CSR_FCSR_S, 105 CSR_FCSR_S, 105 CSR_FFLAGS, 105 CSR_FFLAGS, 105 CSR_HPMCOUNTER4H, 112 CSR_HPMCOUNTER8H, 112 CSR_HPMCOUNTER8H, 112 CSR_HPMCOUNTER8H, 113 CSR_HEBLEG, 106 CSR_HEBLEG, 106 CSR_HEBLEG, 106 CSR_HEBLEG, 106 CSR_HEBLEG, 106 CSR_HPMCOUNTER7H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER7H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER10H, 107 CSR_HPMCOUNTER10H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 108 CSR_HPMCOUNTER11H, 109 CSR_HPMCOUNTER11H, 109 CSR_HPMCOUNTER11H, 109 CSR_HPMCOUNTER11H, 109 CSR_HPMCOUNTER11H, 109 CSR_HPMCOUNTER11H, 119 CSR_HPMCOUNTER11H, 109 CSR_HPMCOUNTER11H, 109 CSR_HPMCOUNTER11H, 109 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER11H, 119 CSR_HPMCOUNTER11H, 119 CSR_HPMCOUNTER12H, 1116 CSR_HPMCOUNTER12H, 1116 CSR_HPMCOUNTER12H, 116		-
CAUSE_STORE_GUEST_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_ECALL, 104 CAUSE_USER_ECALL, 105 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DSCRATCH, 105 CSR_DSCRATCH, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FELAGS, 105 CSR_FRM, 105 CSR_FELAGS, 105 CSR_HPMCOUNTERSH, 112 CSR_HPMCOUNTERSH, 112 CSR_HPMCOUNTERSH, 112 CSR_HPMCOUNTERSH, 113 CSR_HCOUNTERNEN, 105 CSR_HPMCOUNTERSH, 113 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERSH, 113 CSR_HCOUNTERSH, 114 CSR_HPMCOUNTERSH, 117 CSR_HCOUNTERSH, 117 CSR_HCOUNTERSH, 117 CSR_HCOUNTERSH, 117 CSR_HCOUNTERSH, 107 CSR_HCOUNTERSH, 108 CSR_HCOUNTERSH, 109 CSR_MHCOUNTERSH, 109 CSR_MHCOUNTERSH, 116		-
CAUSE_STORE_PAGE_FAULT, 104 CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_ECALL, 104 CAUSE_USER_ECALL, 105 CSR_CYCLEH, 105 CSR_CYCLE, 104 CSR_CYCLE, 104 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DC, 115		CSR_HPMCOUNTER28H, 111
CAUSE_SUPERVISOR_ECALL, 104 CAUSE_USER_ECALL, 104 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_CYCLE, 104 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR, 105 CSR_DCSR_CYCLE, 112 CSR_CYCLE, 105 CSR_DCSR_CYCLE, 112 CSR_CYCLE, 105 CSR_DCSR_CYCLE, 112 CSR_DCSR_CYCLE, 115 CSR_DCSR_CYCLE, 115 CSR_DCSR_CYCLE, 115 CSR_DCSR_CYCLE, 116 CSR_DCSR_CYCLE, 115 CSR_DCSR_DCSR_CYCLE, 116 CSR_DCSR_DCSR_DCSR_CYCLE, 116 CSR_DCSR_DCSR_DCSR_CYCLE, 116 CSR_DCSR_DCSR_DCSR_CYCLE, 116 CSR_DCSR_DCSR_DCSR_DCSR_CYCLE, 115 CSR_DCSR_DCSR_DCSR_DCSR_DCSR_DCSR_DCSR_D	CAUSE_STORE_GUEST_PAGE_FAULT, 104	CSR_HPMCOUNTER29, 111
CAUSE_USER_ECALL, 104 CSR_CYCLEH, 105 CSR_CYCLEH, 105 CSR_DCSR, 112 CSR_DCSR, 105 CSR_DCSR_DCSR, 112 CSR_DCSR, 115 CSR_DCSR, 115 CSR_DCSR_DCSR, 115 CSR_DCSR_DCSR_DCSR, 115 CSR_DCSR_DCSR_DCSR_DCSNCTER10, 116 CSR_DCSR_DCSR_DCSNCTER11, 116 CSR_DCSR_DCSR_DCSNCTER11, 116 CSR_DCSR_DCSR_DCSNCTER11, 116 CSR_DCSR_DCSR_DCSNCTER11, 116 CSR_DCSR_DCSNCTTER11, 116 CSR_DCSR_DCSNCTTER12, 116 CSR_DCSR_DCSNCTTER12, 116 CSR_DCSR_DCSNCTTER12, 116 CSR_DCSR_DCSNCTTER12, 116 CSR_DCSR_DCSNCTTER12, 116 CSR_DCSR_DCSNCTTER12, 116 CSR_DCSNCTTER12, 116 CSR_DCSNCTTER12, 116 CSR_DCSNCTTER12, 116 CSR_DCSNCTTER12, 116 CSR_DCSNCTTER12, 116 CSR_DCSNCTTER12, 116 CSR_DCSNCTTER30, 112 CSR_DCSNCTTER30, 112 CSR_DCSNCTTER30, 112 CSR_DCSNCTTE	CAUSE_STORE_PAGE_FAULT, 104	CSR_HPMCOUNTER29H, 111
CSR_CYCLEH, 105 CSR_CYCLE, 104 CSR_CYCLE, 105 CSR_DCSR, 105 CSR_DPC, 105 CSR_DPC, 105 CSR_DPC, 105 CSR_DSCRATCH, 105 CSR_DSCRATCH, 105 CSR_DSCRATCH, 105 CSR_FCSR, 105 CSR_FCSR, 105 CSR_FRM, 105 CSR_FRM, 105 CSR_FRM, 105 CSR_FRM, 105 CSR_HPMCOUNTER5H, 112 CSR_FRM, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERFSH, 113 CSR_HCOUNTERNEN, 106 CSR_HGEIE, 106 CSR_HGEIE, 106 CSR_HGEIE, 106 CSR_HGEIE, 106 CSR_HBCOUNTER7H, 113 CSR_HGEIE, 106 CSR_HBCOUNTER7H, 113 CSR_HBCOUNTER8H, 113 CSR_HBCOUNTER9H, 114 CSR_HIP, 106 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12, 107 CSR_HPMCOUNTER12, 107 CSR_HPMCOUNTER13, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER15H, 107 CSR_HPMCOUNTER15H, 107 CSR_HPMCOUNTER11H, 108 CSR_HPMCOUNTER12H, 109 CSR_HPMCOUNTER12H, 116	CAUSE_SUPERVISOR_ECALL, 104	CSR_HPMCOUNTER3, 111
CSR_CYCLE, 104 CSR_DCSR, 105 CSR_DCSR, 112 CSR_DCSR, 112 CSR_DCSR, 112 CSR_DCSR, 112 CSR_DCSR, 113 CSR_DCSR, 106 CSR_DCSR_DCSR, 113 CSR_DCSR, 106 CSR_DCSR_DCSR, 113 CSR_DCSR, 106 CSR_DCSR_DCSR, 113 CSR_DCSR, 116 CSR_DCSR_DCSR, 113 CSR_DCSR, 116 CSR_DCSR, 116 CSR_DCSR, 116 CSR_DCSR, 117 CSR_DCSR, 115 CSR_DCSR_DCSR, 115 CSR_DCSR_DCSR_DCSR, 115 CSR_DCSR_DCSR, 115 CSR_DCSR_DCSR, 115 CSR_DCSR_DCSR_DCSR, 115 CSR_DCSR_DCSR_DCSR, 115 CSR_DCSR_DCSR_DCSR, 115 CSR_DCSR_DCSR_DCSR, 115 CSR_DCSR_DCSR_DCSR_DCSR, 115 CSR_DCSR_DCSR_DCSR_DCSR_DCSR_DCSR_DCSR_D	CAUSE_USER_ECALL, 104	CSR_HPMCOUNTER30, 112
CSR_DCSR, 105 CSR_DPC, 105 CSR_DSCRATCH, 105 CSR_DSCRATCH, 105 CSR_FCSR, 105 CSR_FCSR, 105 CSR_FFLAGS, 105 CSR_FFLAGS, 105 CSR_FRM, 105 CSR_FRM, 105 CSR_HPMCOUNTER4H, 112 CSR_FRM, 105 CSR_HPMCOUNTER5, 112 CSR_HPMCOUNTER5H, 113 CSR_HCOUNTERNEN, 105 CSR_HPMCOUNTER6H, 113 CSR_HGELEG, 106 CSR_HGELE, 106 CSR_HGELE, 106 CSR_HGELE, 106 CSR_HGELEG, 106 CSR_HBMCOUNTER7H, 113 CSR_HGELE, 106 CSR_HBCOUNTER8H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER8H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10H, 107 CSR_HCOUNTER10H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER11H, 108 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER12H, 109 CSR_MHPMCOUNTER12H, 116	CSR_CYCLEH, 105	CSR_HPMCOUNTER30H, 112
CSR_DCSR, 105 CSR_DPC, 105 CSR_DSCRATCH, 105 CSR_DSCRATCH, 105 CSR_FCSR, 105 CSR_FCSR, 105 CSR_FFLAGS, 105 CSR_FFLAGS, 105 CSR_FRM, 105 CSR_FRM, 105 CSR_HPMCOUNTER4H, 112 CSR_FRM, 105 CSR_HPMCOUNTER5, 112 CSR_HPMCOUNTER5H, 113 CSR_HCOUNTERNEN, 105 CSR_HPMCOUNTER6H, 113 CSR_HGELEG, 106 CSR_HGELE, 106 CSR_HGELE, 106 CSR_HGELE, 106 CSR_HGELEG, 106 CSR_HBMCOUNTER7H, 113 CSR_HGELE, 106 CSR_HBCOUNTER8H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER8H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10H, 107 CSR_HCOUNTER10H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER11H, 108 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER12H, 109 CSR_MHPMCOUNTER12H, 116	CSR CYCLE, 104	CSR HPMCOUNTER31, 112
CSR_DPC, 105 CSR_DSCRATCH, 105 CSR_DSCRATCH, 105 CSR_PCSR, 105 CSR_FFLAGS, 105 CSR_FFLAGS, 105 CSR_FFLAGS, 105 CSR_FRM, 105 CSR_FRM, 105 CSR_HPMCOUNTERSH, 112 CSR_FRM, 105 CSR_HPMCOUNTERSH, 113 CSR_HCOUNTERNEN, 105 CSR_HPMCOUNTERSH, 113 CSR_HCOUNTERNEN, 105 CSR_HPMCOUNTERSH, 113 CSR_HGATP, 106 CSR_HPMCOUNTER7H, 113 CSR_HGEIE, 106 CSR_HPMCOUNTER7H, 113 CSR_HGEIE, 106 CSR_HPMCOUNTER7H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER8H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER8H, 113 CSR_HIP, 106 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER11, 116 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER11, 116 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER11, 116 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER11, 116 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER12H, 119 CSR_MPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER12H, 116 CSR_MPMCOUNTER111H, 116 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER12H, 116		
CSR_DSCRATCH, 105 CSR_FCSR, 105 CSR_FCSR, 105 CSR_FFLAGS, 105 CSR_FMM_005 CSR_HPMCOUNTERSH, 112 CSR_HCOUNTERSH, 105 CSR_HCOUNTERSH, 105 CSR_HCOUNTERSH, 105 CSR_HCOUNTERSH, 113 CSR_HCOUNTERSH, 106 CSR_HCOUNTERSH, 113 CSR_HGATP, 106 CSR_HCOUNTERSH, 113 CSR_HGEIE, 106 CSR_HPMCOUNTERSH, 113 CSR_HGEIP, 106 CSR_HPMCOUNTERSH, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTERSH, 113 CSR_HIP, 106 CSR_HPMCOUNTERSH, 113 CSR_HIP, 106 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 114 CSR_HPMCOUNTERSH, 117 CSR_HPMCOUNTERSH, 107 CSR_HCOUNTERSH, 108 CSR_HCOUNTERSH, 109 CSR_MCOUNTERSH, 116 CSR_HCOUNTERSH, 109 CSR_MCOUNTERSH, 116 CSR_HCOUNTERSH, 109 CSR_MCOUNTERSH, 116 CSR_MCOUNTERSH, 119 CSR_MCO		-
CSR_FCSR, 105 CSR_FFLAGS, 105 CSR_FRM, 105 CSR_FRM, 105 CSR_FRM, 105 CSR_HPMCOUNTERS, 112 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 105 CSR_HPMCOUNTERSH, 113 CSR_HCOUNTERSH, 113 CSR_HGELEG, 106 CSR_HBMCOUNTERSH, 113 CSR_HGELE, 106 CSR_HPMCOUNTERSH, 113 CSR_HBELEG, 106 CSR_HPMCOUNTERSH, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTERSH, 113 CSR_HIP, 106 CSR_HPMCOUNTERSH, 113 CSR_HIP, 106 CSR_HPMCOUNTERSH, 114 CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTERSH, 114 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTERSH, 114 CSR_HPMCOUNTERSH, 117 CSR_HPMCOUNTERSH, 117 CSR_HPMCOUNTERSH, 107 CSR_HTIMEDELTAH, 114 CSR_HPMCOUNTERSH, 107 CSR_HPMCOUNTERSH, 108 CSR_HPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_HPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_HPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_HPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_MPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_MPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_MPMCOUNTERSH, 119 CSR_MHPMCOUNTERSH, 116 CSR_MHPMCOUNT	-	-
CSR_FFLAGS, 105 CSR_FRM, 105 CSR_FRM, 105 CSR_HPMCOUNTERSH, 113 CSR_HCOUNTERNEN, 105 CSR_HPMCOUNTERSH, 113 CSR_HEDELEG, 106 CSR_HPMCOUNTERSH, 113 CSR_HGEIE, 106 CSR_HPMCOUNTERSH, 113 CSR_HGEIE, 106 CSR_HPMCOUNTERSH, 113 CSR_HGEIE, 106 CSR_HPMCOUNTERSH, 113 CSR_HIBELEG, 106 CSR_HPMCOUNTERSH, 113 CSR_HIBELEG, 106 CSR_HPMCOUNTERSH, 113 CSR_HIP, 106 CSR_HPMCOUNTERSH, 113 CSR_HPMCOUNTERSH, 114 CSR_HPMCOUNTERSH, 117 CSR_HPMCOUNTERSH, 117 CSR_HPMCOUNTERSH, 117 CSR_HPMCOUNTERSH, 107 CSR_HPMCOUNTERSH, 114 CSR_HPMCOUNTERSH, 107 CSR_HPMCOUNTERSH, 108 CSR_HPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_HPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_HPMCOUNTERSH, 109 CSR_MHPMCOUNTERSH, 116 CSR_HPMCOUNTERSH, 119 CSR_HPMCOUNTERSH, 119 CSR_MPMCOUNTERSH, 119 CSR_MPMCOUNTERSH, 119 CSR_MPMCOUNTERSH, 119 CSR_MPMCOUNTERSH, 119 CSR_MPMCOUNTERSH, 119 CSR_MHPMCOUNTERSH, 116 CSR_MHPMCOUNTERS	— · · · · · · · · · · · · · · · · · · ·	
CSR_FRM, 105 CSR_HCOUNTERNEN, 105 CSR_HCOUNTERNEN, 106 CSR_HEDELEG, 106 CSR_HPMCOUNTER6H, 113 CSR_HGATP, 106 CSR_HPMCOUNTER7, 113 CSR_HGEIE, 106 CSR_HPMCOUNTER7, 113 CSR_HGEIE, 106 CSR_HPMCOUNTER8H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER8H, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER8H, 113 CSR_HIP, 106 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER12, 107 CSR_HPMCOUNTER12, 107 CSR_HPMCOUNTER13, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16, 108 CSR_HPMCOUNTER17, 108 CSR_HPMCOUNTER17, 108 CSR_HPMCOUNTER18, 108 CSR_HPMCOUNTER11, 109 CSR_MPMCOUNTER11, 109 CSR_MPMCOUNTER11, 116 CSR_HPMCOUNTER11, 109 CSR_MPMCOUNTER11, 116 CSR_MPMCOUNTER11, 109 CSR_MPMCOUNTER11, 116 CSR_MPMCOUNTER11, 109 CSR_MPMCOUNTER12, 116 CSR_MPMCOUNTER11, 116 CSR_MPMCOUNTER12, 119 CSR_MPMCOUNTER11, 1108 CSR_MPMCOUNTER111, 1108 CSR_MPMCOUNTER111, 1108 CSR_MPMCOUNTER111, 1108 CSR_MPMCOUNTER111, 116 CSR_MPMCOUNTER111, 116 CSR_MPMCOUNTER111, 116 CSR_MPMCOUNTER111, 116 CSR_MPMCOUNTER111, 116 CSR_MPMCOUNTER12, 116 CSR_MPMCOUNTER12, 116 CSR_MPMCOUNTER12, 116		
CSR_HCOUNTERNEN, 105 CSR_HEDELEG, 106 CSR_HEDELEG, 106 CSR_HGATP, 106 CSR_HGATP, 106 CSR_HGEIE, 106 CSR_HGEIE, 106 CSR_HGEIE, 106 CSR_HPMCOUNTER7H, 113 CSR_HGEIP, 106 CSR_HPMCOUNTER8, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER8H, 113 CSR_HIE, 106 CSR_HPMCOUNTER8H, 113 CSR_HIP, 106 CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTER10H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER18H, 109 CSR_MPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER11H, 108 CSR_MPMCOUNTER11H, 108 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER12H, 116	-	-
CSR_HEDELEG, 106 CSR_HGATP, 106 CSR_HGEIE, 106 CSR_HGEIE, 106 CSR_HGEIP, 106 CSR_HGEIP, 106 CSR_HDMCOUNTER7, 113 CSR_HGEIP, 106 CSR_HDMCOUNTER8, 113 CSR_HDMCOUNTER8, 113 CSR_HIDELEG, 106 CSR_HPMCOUNTER9, 113 CSR_HIP, 106 CSR_HPMCOUNTER9, 114 CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTER10, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER12, 107 CSR_HDMCOUNTER12, 107 CSR_HDMCOUNTER13, 107 CSR_HDMCOUNTER13, 107 CSR_HPMCOUNTER13, 107 CSR_HPMCOUNTER14, 107 CSR_HPMCOUNTER14, 107 CSR_HPMCOUNTER15, 108 CSR_HPMCOUNTER15, 108 CSR_HPMCOUNTER15, 108 CSR_HPMCOUNTER16, 108 CSR_HPMCOUNTER16, 108 CSR_HPMCOUNTER16, 108 CSR_HPMCOUNTER17, 108 CSR_HPMCOUNTER17, 108 CSR_HPMCOUNTER18, 109 CSR_MPMCOUNTER18, 109 CSR_MPMCOUNTER11, 116 CSR_MPMCOUNTER19, 109 CSR_MPMCOUNTER11, 116 CSR_MPMCOUNTER11, 116 CSR_MPMCOUNTER11, 119 CSR_MPMCOUNTER11, 119 CSR_MPMCOUNTER11, 119 CSR_MPMCOUNTER11, 116 CSR_MPMCOUNTER12, 116 CSR_MPMCOUNTER12, 116 CSR_MPMCOUNTER12, 116	-	-
CSR_HGATP, 106 CSR_HGEIE, 106 CSR_HGEIE, 106 CSR_HGEIP, 106 CSR_HOCUNTER7H, 113 CSR_HIDELEG, 106 CSR_HIDELEG, 106 CSR_HIPMCOUNTER8H, 113 CSR_HIP, 106 CSR_HIPMCOUNTER8H, 113 CSR_HIP, 106 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER15H, 107 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_MPMCOUNTER19H, 109 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER19H, 109 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER19H, 109 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER12H, 119 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER11H, 116 CSR_MPMCOUNTER12H, 116 CSR_MPMCOUNTER12H, 116		
CSR_HGEIE, 106 CSR_HGEIP, 106 CSR_HGEIP, 106 CSR_HDELEG, 106 CSR_HDELEG, 106 CSR_HDCOUNTER8H, 113 CSR_HIE, 106 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER15H, 107 CSR_HPMCOUNTER15H, 107 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER12H, 116 CSR_MPMCOUNTER12H, 116 CSR_MPMCOUNTER12H, 116		
CSR_HGEIP, 106 CSR_HIDELEG, 106 CSR_HIDELEG, 106 CSR_HIPMCOUNTER8H, 113 CSR_HIP, 106 CSR_HPMCOUNTER9, 113 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER12H, 116	-	-
CSR_HIDELEG, 106 CSR_HIE, 106 CSR_HIP, 106 CSR_HPMCOUNTER9, 113 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTER10H, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12, 107 CSR_HPMCOUNTER13, 107 CSR_HPMCOUNTER13, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER12H, 116	-	<u> </u>
CSR_HIE, 106 CSR_HPMCOUNTER9, 113 CSR_HPMCOUNTER9H, 114 CSR_HPMCOUNTER10, 106 CSR_HSTATUS, 114 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12H, 116 CSR_MHPMCOUNTER11H, 116		-
CSR_HIP, 106 CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTER10H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER15H, 107 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12H, 116		
CSR_HPMCOUNTER10, 106 CSR_HPMCOUNTER10H, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11, 107 CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13, 107 CSR_HPMCOUNTER13, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER15, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER12, 116 CSR_HPMCOUNTER12, 116 CSR_HPMCOUNTER12H, 116	- :	
CSR_HPMCOUNTER10H, 107 CSR_HTIMEDELTAH, 114 CSR_HPMCOUNTER11, 107 CSR_HTIMEDELTA, 114 CSR_HPMCOUNTER11H, 107 CSR_HTINST, 114 CSR_HPMCOUNTER12, 107 CSR_HTVAL, 114 CSR_HPMCOUNTER13H, 107 CSR_INSTRETH, 114 CSR_HPMCOUNTER13H, 107 CSR_MARCHID, 115 CSR_HPMCOUNTER14H, 107 CSR_MCAUSE, 115 CSR_HPMCOUNTER14H, 108 CSR_MCOUNTEREN, 115 CSR_HPMCOUNTER15H, 108 CSR_MCYCLEH, 115 CSR_HPMCOUNTER16H, 108 CSR_MEDELEG, 115 CSR_HPMCOUNTER16H, 108 CSR_MEDELEG, 115 CSR_HPMCOUNTER17H, 108 CSR_MEPC, 115 CSR_HPMCOUNTER18H, 108 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER18H, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12H, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116		
CSR_HPMCOUNTER11, 107 CSR_HTIMEDELTA, 114 CSR_HPMCOUNTER11H, 107 CSR_HTINST, 114 CSR_HPMCOUNTER12, 107 CSR_HTVAL, 114 CSR_HPMCOUNTER13H, 107 CSR_INSTRETH, 114 CSR_HPMCOUNTER13H, 107 CSR_MARCHID, 115 CSR_HPMCOUNTER14H, 107 CSR_MCAUSE, 115 CSR_HPMCOUNTER14H, 108 CSR_MCOUNTEREN, 115 CSR_HPMCOUNTER15, 108 CSR_MCYCLEH, 115 CSR_HPMCOUNTER16H, 108 CSR_MCYCLE, 115 CSR_HPMCOUNTER16H, 108 CSR_MEPC, 115 CSR_HPMCOUNTER17H, 108 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER18H, 109 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_MHPMCOUNTER12H, 116	CSR_HPMCOUNTER10, 106	CSR_HSTATUS, 114
CSR_HPMCOUNTER11H, 107 CSR_HPMCOUNTER12, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER12H, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116	CSR_HPMCOUNTER10H, 107	CSR_HTIMEDELTAH, 114
CSR_HPMCOUNTER12, 107 CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER19H, 109 CSR_MPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116	CSR_HPMCOUNTER11, 107	CSR_HTIMEDELTA, 114
CSR_HPMCOUNTER12H, 107 CSR_HPMCOUNTER13, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14H, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116 CSR_HPMCOUNTER12H, 116	CSR_HPMCOUNTER11H, 107	CSR_HTINST, 114
CSR_HPMCOUNTER13, 107 CSR_HPMCOUNTER13H, 107 CSR_HPMCOUNTER14, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12H, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116	CSR_HPMCOUNTER12, 107	CSR_HTVAL, 114
CSR_HPMCOUNTER13H, 107 CSR_MARCHID, 115 CSR_HPMCOUNTER14, 107 CSR_MCAUSE, 115 CSR_HPMCOUNTER14H, 108 CSR_MCOUNTEREN, 115 CSR_HPMCOUNTER15, 108 CSR_MCYCLEH, 115 CSR_HPMCOUNTER16H, 108 CSR_MEDELEG, 115 CSR_HPMCOUNTER16H, 108 CSR_MEPC, 115 CSR_HPMCOUNTER17, 108 CSR_MHPMCOUNTER10, 116 CSR_HPMCOUNTER18H, 108 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER18H, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116	CSR_HPMCOUNTER12H, 107	CSR_INSTRETH, 114
CSR_HPMCOUNTER14, 107 CSR_HPMCOUNTER14H, 108 CSR_HPMCOUNTER15, 108 CSR_HPMCOUNTER15, 108 CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17, 108 CSR_HPMCOUNTER17, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12H, 116 CSR_HPMCOUNTER2O, 109 CSR_MHPMCOUNTER12H, 116	CSR_HPMCOUNTER13, 107	CSR_INSTRET, 114
CSR_HPMCOUNTER14, 107 CSR_MCAUSE, 115 CSR_HPMCOUNTER14H, 108 CSR_MCOUNTEREN, 115 CSR_HPMCOUNTER15, 108 CSR_MCYCLEH, 115 CSR_HPMCOUNTER15H, 108 CSR_MCYCLE, 115 CSR_HPMCOUNTER16H, 108 CSR_MEDELEG, 115 CSR_HPMCOUNTER17H, 108 CSR_MEPC, 115 CSR_HPMCOUNTER17H, 108 CSR_MHARTID, 115 CSR_HPMCOUNTER18H, 108 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER18H, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116	CSR HPMCOUNTER13H, 107	CSR MARCHID, 115
CSR_HPMCOUNTER14H, 108 CSR_MCOUNTEREN, 115 CSR_HPMCOUNTER15, 108 CSR_MCYCLEH, 115 CSR_HPMCOUNTER15H, 108 CSR_MCYCLE, 115 CSR_HPMCOUNTER16, 108 CSR_MEDELEG, 115 CSR_HPMCOUNTER16H, 108 CSR_MEPC, 115 CSR_HPMCOUNTER17, 108 CSR_MEPC, 115 CSR_MHPMCOUNTER10, 116 CSR_HPMCOUNTER17H, 108 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER18H, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116		CSR MCAUSE, 115
CSR_HPMCOUNTER15, 108 CSR_MCYCLEH, 115 CSR_HPMCOUNTER15H, 108 CSR_MCYCLE, 115 CSR_HPMCOUNTER16, 108 CSR_MEDELEG, 115 CSR_HPMCOUNTER16H, 108 CSR_MEPC, 115 CSR_HPMCOUNTER17, 108 CSR_MHARTID, 115 CSR_HPMCOUNTER17H, 108 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER18H, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116	-	
CSR_HPMCOUNTER15H, 108 CSR_HPMCOUNTER16, 108 CSR_HPMCOUNTER16, 108 CSR_HPMCOUNTER16H, 108 CSR_HPMCOUNTER17, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18H, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12H, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116		
CSR_HPMCOUNTER16, 108 CSR_MEDELEG, 115 CSR_HPMCOUNTER16H, 108 CSR_MEPC, 115 CSR_HPMCOUNTER17, 108 CSR_MHARTID, 115 CSR_HPMCOUNTER17H, 108 CSR_MHPMCOUNTER10, 116 CSR_HPMCOUNTER18, 108 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER19, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116	_ ,	-
CSR_HPMCOUNTER16H, 108 CSR_MEPC, 115 CSR_HPMCOUNTER17, 108 CSR_MHARTID, 115 CSR_HPMCOUNTER17H, 108 CSR_MHPMCOUNTER10, 116 CSR_HPMCOUNTER18, 108 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER18H, 109 CSR_MHPMCOUNTER11, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116	-	-
CSR_HPMCOUNTER17, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18, 108 CSR_MHPMCOUNTER10H, 116 CSR_HPMCOUNTER18H, 109 CSR_MHPMCOUNTER11, 116 CSR_HPMCOUNTER19, 109 CSR_MHPMCOUNTER11H, 116 CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116		
CSR_HPMCOUNTER17H, 108 CSR_HPMCOUNTER18, 108 CSR_HPMCOUNTER18, 109 CSR_HPMCOUNTER19H, 116		
CSR_HPMCOUNTER18, 108 CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116		-
CSR_HPMCOUNTER18H, 109 CSR_HPMCOUNTER11, 116 CSR_HPMCOUNTER19, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116		-
CSR_HPMCOUNTER19, 109 CSR_HPMCOUNTER19H, 109 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116		
CSR_HPMCOUNTER19H, 109 CSR_MHPMCOUNTER12, 116 CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116		-
CSR_HPMCOUNTER20, 109 CSR_MHPMCOUNTER12H, 116		-
CSR_HPMCOUNTER20H, 109 CSR_MHPMCOUNTER13, 116	-	-
	CSR_HPMCOUNTER20H, 109	CSR_MHPMCOUNTER13, 116

CSR_MHPMCOUNTER13H, 116	CSR_MHPMEVENT17, 124
CSR_MHPMCOUNTER14, 117	CSR_MHPMEVENT18, 124
CSR_MHPMCOUNTER14H, 117	CSR_MHPMEVENT19, 124
CSR MHPMCOUNTER15, 117	CSR MHPMEVENT20, 124
CSR MHPMCOUNTER15H, 117	CSR MHPMEVENT21, 124
CSR MHPMCOUNTER16, 117	CSR MHPMEVENT22, 124
CSR_MHPMCOUNTER16H, 117	CSR_MHPMEVENT23, 124
CSR MHPMCOUNTER17, 117	CSR MHPMEVENT24, 125
CSR MHPMCOUNTER17H, 117	CSR MHPMEVENT25, 125
CSR_MHPMCOUNTER18, 118	CSR_MHPMEVENT26, 125
CSR MHPMCOUNTER18H, 118	CSR MHPMEVENT27, 125
CSR MHPMCOUNTER19, 118	CSR_MHPMEVENT28, 125
_	-
CSR_MHPMCOUNTER19H, 118	CSR_MHPMEVENT29, 125
CSR_MHPMCOUNTER20, 118	CSR_MHPMEVENT3, 125
CSR_MHPMCOUNTER20H, 118	CSR_MHPMEVENT30, 125
CSR_MHPMCOUNTER21, 118	CSR_MHPMEVENT31, 126
CSR_MHPMCOUNTER21H, 118	CSR_MHPMEVENT4, 126
CSR_MHPMCOUNTER22, 119	CSR_MHPMEVENT5, 126
CSR_MHPMCOUNTER22H, 119	CSR_MHPMEVENT6, 126
CSR_MHPMCOUNTER23, 119	CSR_MHPMEVENT7, 126
CSR_MHPMCOUNTER23H, 119	CSR_MHPMEVENT8, 126
CSR_MHPMCOUNTER24, 119	CSR_MHPMEVENT9, 126
CSR_MHPMCOUNTER24H, 119	CSR_MIDELEG, 126
CSR_MHPMCOUNTER25, 119	CSR_MIMPID, 127
CSR_MHPMCOUNTER25H, 119	CSR_MINSTRETH, 127
CSR_MHPMCOUNTER26, 120	CSR_MINSTRET, 127
CSR MHPMCOUNTER26H, 120	CSR MISA, 127
CSR MHPMCOUNTER27, 120	CSR_MIE, 127
CSR_MHPMCOUNTER27H, 120	CSR_MIP, 127
CSR_MHPMCOUNTER28, 120	CSR_MSCRATCH, 127
CSR MHPMCOUNTER28H, 120	CSR MSTATUSH, 128
CSR MHPMCOUNTER29, 120	CSR MSTATUS, 127
CSR MHPMCOUNTER29H, 120	CSR_MTINST, 128
CSR MHPMCOUNTER3, 121	CSR MTVAL2, 128
CSR MHPMCOUNTER30, 121	CSR MTVAL, 128
CSR MHPMCOUNTER30H, 121	CSR MTVEC, 128
CSR_MHPMCOUNTER31, 121	CSR_MVENDORID, 128
	CSR_PMPADDR0, 128
CSR_MHPMCOUNTER31H, 121	
CSR_MHPMCOUNTER3H, 121	CSR_PMPADDR1, 128
CSR_MHPMCOUNTER4, 121	CSR_PMPADDR10, 129
CSR_MHPMCOUNTER4H, 121	CSR_PMPADDR11, 129
CSR_MHPMCOUNTER5, 122	CSR_PMPADDR12, 129
CSR_MHPMCOUNTER5H, 122	CSR_PMPADDR13, 129
CSR_MHPMCOUNTER6, 122	CSR_PMPADDR14, 129
CSR_MHPMCOUNTER6H, 122	CSR_PMPADDR15, 129
CSR_MHPMCOUNTER7, 122	CSR_PMPADDR2, 129
CSR_MHPMCOUNTER7H, 122	CSR_PMPADDR3, 129
CSR_MHPMCOUNTER8, 122	CSR_PMPADDR4, 130
CSR_MHPMCOUNTER8H, 122	CSR_PMPADDR5, 130
CSR_MHPMCOUNTER9, 123	CSR_PMPADDR6, 130
CSR_MHPMCOUNTER9H, 123	CSR_PMPADDR7, 130
CSR_MHPMEVENT10, 123	CSR_PMPADDR8, 130
CSR_MHPMEVENT11, 123	CSR_PMPADDR9, 130
CSR_MHPMEVENT12, 123	CSR_PMPCFG0, 130
CSR_MHPMEVENT13, 123	CSR_PMPCFG1, 130
CSR_MHPMEVENT14, 123	CSR_PMPCFG2, 131
CSR_MHPMEVENT15, 123	CSR_PMPCFG3, 131
CSR_MHPMEVENT16, 124	CSR_SATP, 131
	_ ,

CSR_SCAUSE, 131	INSN_MASK_C_FSD, 139
CSR_SCOUNTEREN, 131	INSN_MASK_C_FSW, 139
CSR_SEPC, 131	INSN_MASK_C_LDSP, 139
CSR_SIE, 131	INSN_MASK_C_LWSP, 139
CSR_SIP, 131	INSN_MASK_C_LD, 139
CSR_SSCRATCH, 132	INSN_MASK_C_LW, 139
CSR_SSTATUS, 132	INSN_MASK_C_SDSP, 140
CSR_STVAL, 132	INSN_MASK_C_SWSP, 140
CSR_STVEC, 132	INSN_MASK_C_SD, 140
CSR_TDATA1, 132	INSN_MASK_C_SW, 140
CSR_TDATA2, 132	INSN_MASK_FLD, 140
CSR_TDATA3, 132	INSN_MASK_FLQ, 140
CSR_TIMEH, 133	INSN_MASK_FLW, 140
CSR TIME, 132	INSN MASK FSD, 140
CSR TSELECT, 133	INSN MASK FSQ, 141
CSR UCAUSE, 133	INSN MASK FSW, 141
<u> </u>	′
CSR_UEPC, 133	INSN_MASK_LBU, 141
CSR_UIE, 133	INSN_MASK_LHU, 141
CSR_UIP, 133	INSN_MASK_LWU, 142
CSR_USCRATCH, 133	INSN_MASK_LB, 141
CSR_USTATUS, 133	INSN_MASK_LD, 141
CSR_UTVAL, 134	INSN_MASK_LH, 141
CSR UTVEC, 134	INSN MASK LW, 141
CSR VSATP, 134	INSN MASK SB, 142
CSR VSCAUSE, 134	INSN MASK SD, 142
CSR VSEPC, 134	INSN MASK SH, 142
-	
CSR_VSIE, 134	INSN_MASK_SW, 142
CSR_VSIP, 134	INSN_MASK_WFI, 142
CSR_VSSCRATCH, 134	INSN_MATCH_C_FLDSP, 142
CSR_VSSTATUS, 135	INSN_MATCH_C_FLWSP, 143
CSR_VSTVAL, 135	INSN_MATCH_C_FLD, 142
CSR_VSTVEC, 135	INSN_MATCH_C_FLW, 143
GET_RS1, 135	INSN_MATCH_C_FSDSP, 143
GET RS1S, 135	INSN MATCH C FSWSP, 143
GET RS2, 135	INSN MATCH C FSD, 143
GET_RS2C, 136	INSN_MATCH_C_FSW, 143
GET_RS2S, 136	INSN_MATCH_C_LDSP, 143
GET_RM, 135	INSN_MATCH_C_LWSP, 144
GET_SP, 136	INSN_MATCH_C_LD, 143
HSTATUS_SP2P, 136	INSN_MATCH_C_LW, 144
HSTATUS_SP2V, 136	INSN_MATCH_C_SDSP, 144
HSTATUS_SPRV, 136	INSN_MATCH_C_SWSP, 144
HSTATUS_SPV, 136	INSN_MATCH_C_SD, 144
HSTATUS_VTSR, 137	INSN_MATCH_C_SW, 144
HSTATUS_VTVM, 137	INSN_MATCH_FLD, 144
IMM I, 137	INSN MATCH FLQ, 144
IMM S, 137	INSN MATCH FLW, 145
INSN_16BIT_MASK, 137	INSN MATCH FSD, 145
INSN_32BIT_MASK, 137	INSN_MATCH_FSQ, 145
INSN IS 16BIT, 137	INSN MATCH FSW, 145
INSN_IS_32BIT, 138	INSN_MATCH_LBU, 145
INSN_LEN, 138	INSN_MATCH_LHU, 146
INSN_MASK_C_FLDSP, 138	INSN_MATCH_LWU, 146
INSN_MASK_C_FLWSP, 138	INSN_MATCH_LB, 145
INSN_MASK_C_FLD, 138	INSN_MATCH_LD, 145
INSN_MASK_C_FLW, 138	INSN_MATCH_LH, 145
INSN_MASK_C_FSDSP, 139	INSN_MATCH_LW, 146
INSN_MASK_C_FSWSP, 139	INSN MATCH SB, 146

INSN_MATCH_SD, 146	PMP_W, 153
INSN_MATCH_SH, 146	PMP_X, 154
INSN_MATCH_SW, 146	PRV_M, 154
INSN MATCH WFI, 146	PRV_S, 154
IRQ_M_EXT, 147	PRV U, 154
IRQ_M_SOFT, 147	PTE_PPN_SHIFT, 154
IRQ_M_TIMER, 147	PTE_SOFT, 155
IRQ S EXT, 147	PTE TABLE, 155
IRQ_S_GEXT, 147	PTE_A, 154
IRQ S SOFT, 147	PTE_D, 154
IRQ S TIMER, 147	PTE G, 154
IRQ_VS_EXT, 147	PTE_R, 155
IRQ_VS_SOFT, 148	PTE_U, 155
IRQ_VS_TIMER, 148	PTE_V, 155
LOG_REGBYTES, 148	PTE_W, 155
MASK_FUNCT3, 148	PTE_X, 155
MIP_MEIP, 148	REG_MASK, 156
MIP_MSIP, 148	REG_OFFSET, 156
MIP_MTIP, 148	REG_PTR, 156
MIP_SEIP, 148	REGBYTES, 156
MIP_SGEIP, 149	RISCV_PGLEVEL_BITS, 156
MIP_SSIP, 149	RISCV_PGSHIFT, 156
MIP_STIP, 149	RISCV_PGSIZE, 156
MIP_VSEIP, 149	RV_X, 157
MIP_VSSIP, 149	RVC_LD_IMM, 157
MIP_VSTIP, 149	RVC_LDSP_IMM, 157
MSTATUS32 SD, 149	RVC_LW_IMM, 157
MSTATUS64_SD, 150	RVC_LWSP_IMM, 157
MSTATUS_FS, 150	RVC_RS1S, 158
MSTATUS_MIE, 150	RVC_RS2, 158
MSTATUS MPIE, 150	RVC RS2S, 158
MSTATUS_MPP_SHIFT, 150	RVC_SDSP_IMM, 158
MSTATUS MPRV, 150	RVC_SWSP_IMM, 158
MSTATUS MPP, 150	SATP32 ASID, 159
MSTATUS_MXR, 150	SATP32_MODE, 159
MSTATUS_SIE, 151	SATP32 PPN, 159
MSTATUS SPIE SHIFT, 151	- '
	SATP64_ASID, 159
MSTATUS_SPIE, 151	SATP64_MODE, 159
MSTATUS_SPP_SHIFT, 151	SATP64_PPN, 159
MSTATUS_SPP, 151	SATP_MODE_OFF, 160
MSTATUS_SUM, 151	SATP_MODE_SV32, 160
MSTATUS_SD, 151	SATP_MODE_SV39, 160
MSTATUS_TSR, 151	SATP_MODE_SV48, 160
MSTATUS_TVM, 152	SATP_MODE_SV57, 160
MSTATUS_TW, 152	SATP_MODE_SV64, 160
MSTATUS_UBE, 152	SATP_MODE, 159
MSTATUS_XS, 152	SET_RD, 160
MSTATUSH_MBE, 152	SH_RS1, 161
MSTATUSH_MPV, 152	SH_RS2, 161
MSTATUSH_SBE, 152	SH_RS2C, 161
PMP_A_NA4, 153	SH_RD, 161
PMP_A_NAPOT, 153	SHIFT_RIGHT, 161
PMP_A_TOR, 153	SIP_SSIP, 161
PMP_COUNT, 153	SIP_STIP, 161
PMP_SHIFT, 153	SSTATUS32_SD, 162
PMP_A, 152	
-	SSTATUS64_SD, 162
PMP L, 153	
PMP_L, 153 PMP_R, 153	SSTATUS64_SD, 162 SSTATUS64_UXL, 162 SSTATUS FS, 162

SSTATUS_MXR, 162	spin_trylock, 175
SSTATUS_SIE, 162	spin_unlock, 176
SSTATUS_SPIE_SHIFT, 163	rmb
SSTATUS_SPIE, 162	riscv_barrier.h, 92
SSTATUS SPP SHIFT, 163	
SSTATUS SPP, 163	s0
SSTATUS SUM, 163	sbi_trap_regs, 68
SSTATUS SD, 162	s1
SSTATUS XS, 163	sbi_trap_regs, 68
riscv_fp.h	s10
GET PRECISION, 165	sbi_trap_regs, 69
GET_RM, 165	s11
	sbi_trap_regs, 69
PRECISION_D, 165	s16
PRECISION_S, 165	sbi_types.h, 306
riscv_io.h	s2
io_ar, 167	sbi_trap_regs, 69
io_aw, 167	s3
io_br, 167	sbi trap regs, 69
io_bw, 167	s32
io_rar, 167	sbi types.h, 306
io_raw, 167	s4
io_rbr, 167	sbi trap regs, 69
io_rbw, 167	s5_trap_regs, 09
raw_readb, 170	
raw_readl, 170	sbi_trap_regs, 69
raw_readq, 170	s6
raw readw, 171	sbi_trap_regs, 69
raw_writeb, 171	s7
raw_writel, 171	sbi_trap_regs, 69
raw_writeq, 171	s8
raw writew, 171	sbi_trap_regs, 70
readb, 168	sbi_types.h, 307
readb_relaxed, 168	s9
readl, 168	sbi_trap_regs, 70
readl_relaxed, 168	SATP32_ASID
readq, 168	riscv_encoding.h, 159
•	SATP32_MODE
readq_relaxed, 168	riscv_encoding.h, 159
readw, 168	SATP32_PPN
readw_relaxed, 169	riscv_encoding.h, 159
writeb, 169	SATP64_ASID
writeb_relaxed, 169	riscv_encoding.h, 159
writel, 169	SATP64_MODE
writel_relaxed, 169	riscv_encoding.h, 159
writeq, 169	SATP64_PPN
writeq_relaxed, 170	riscv_encoding.h, 159
writew, 170	SATP_MODE_OFF
writew_relaxed, 170	riscv_encoding.h, 160
riscv_locks.c	SATP_MODE_SV32
spin_lock, 338	riscv_encoding.h, 160
spin_lock_check, 339	SATP MODE SV39
spin_trylock, 340	riscv_encoding.h, 160
spin_unlock, 341	SATP MODE SV48
riscv_locks.h	riscv_encoding.h, 160
RISCV_SPIN_UNLOCKED, 172	SATP_MODE_SV57
SPIN_LOCK_INITIALIZER, 172	riscv_encoding.h, 160
SPIN_LOCK_INIT, 172	SATP MODE SV64
spin_lock, 173	riscv_encoding.h, 160
spin_lock_check, 174	SATP MODE
Spin_100K_01100K, 17 1	555L

ricay anading h 150	ahi agall interface h 107
riscv_encoding.h, 159	sbi_ecall_interface.h, 197
SBI_DENIED	SBI_EXT_BASE_GET_MVENDORID
sbi_error.h, 202	sbi_ecall_interface.h, 197
SBI_ECALL_VERSION_MAJOR	SBI_EXT_BASE_GET_SPEC_VERSION
sbi_ecall.h, 190	sbi_ecall_interface.h, 197
SBI_ECALL_VERSION_MINOR	SBI_EXT_BASE_PROBE_EXT
sbi_ecall.h, 190	sbi_ecall_interface.h, 197
SBI_EFAIL	SBI_EXT_BASE
sbi_error.h, 202	sbi_ecall_interface.h, 196
SBI_EILL	SBI_EXT_IPI_SEND_IPI
sbi_error.h, 203	sbi_ecall_interface.h, 197
SBI_EINVAL	SBI_EXT_IPI
sbi_error.h, 203	sbi_ecall_interface.h, 197
SBI_EIO	SBI_EXT_RFENCE_REMOTE_FENCE_I
sbi_error.h, 203	sbi_ecall_interface.h, 198
SBI_ENODEV	SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA_V
sbi_error.h, 203	MID
SBI_ENOENT	sbi_ecall_interface.h, 198
sbi_error.h, 203	SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA
SBI_ENOMEM	sbi_ecall_interface.h, 198
sbi_error.h, 203	SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA_ASID
SBI ENOSPC	sbi_ecall_interface.h, 198
sbi error.h, 203	SBI EXT RFENCE REMOTE HFENCE VVMA
SBI ENOSYS	sbi_ecall_interface.h, 198
sbi_error.h, 203	SBI_EXT_RFENCE_REMOTE_SFENCE_VMA_ASID
SBI_ENOTSUPP	sbi_ecall_interface.h, 198
sbi_error.h, 204	SBI_EXT_RFENCE_REMOTE_SFENCE_VMA
SBI_ETIMEDOUT	sbi_ecall_interface.h, 198
sbi_error.h, 204	SBI_EXT_RFENCE
SBI_ETRAP	sbi_ecall_interface.h, 198
sbi_error.h, 204	SBI_EXT_TIME_SET_TIMER
SBI_EUNKNOWN	sbi_ecall_interface.h, 199
sbi error.h, 204	SBI_EXT_TIME
SBI_EXT_0_1_CLEAR_IPI	sbi_ecall_interface.h, 199
sbi_ecall_interface.h, 195	SBI EXT VENDOR END
SBI_EXT_0_1_CONSOLE_GETCHAR	sbi_ecall_interface.h, 199
sbi_ecall_interface.h, 195	SBI_EXT_VENDOR_START
SBI_EXT_0_1_CONSOLE_PUTCHAR	sbi_ecall_interface.h, 199
sbi_ecall_interface.h, 195	SBI_INIT_LIST_HEAD
SBI_EXT_0_1_REMOTE_FENCE_I	sbi_list.h, 237
sbi_ecall_interface.h, 196	SBI_INVALID_ADDR
SBI_EXT_0_1_REMOTE_SFENCE_VMA_ASID	sbi_error.h, 204
sbi_ecall_interface.h, 196	SBI_IPI_EVENT_MAX
SBI_EXT_0_1_REMOTE_SFENCE_VMA	sbi_ipi.h, 230
sbi_ecall_interface.h, 196	SBI_LIST_HEAD_INIT
SBI_EXT_0_1_SEND_IPI	sbi_list.h, 238
sbi_ecall_interface.h, 196	SBI_LIST_HEAD
SBI_EXT_0_1_SET_TIMER	sbi ecall.c, 357
sbi_ecall_interface.h, 196	sbi_list.h, 238
SBI_EXT_0_1_SHUTDOWN	SBI_LIST_POISON_NEXT
sbi_ecall_interface.h, 196	sbi_list.h, 239
SBI_EXT_BASE_GET_IMP_ID	SBI_LIST_POISON_PREV
sbi_ecall_interface.h, 196	sbi_list.h, 239
SBI_EXT_BASE_GET_IMP_VERSION	SBI_OPENSBI_IMPID
sbi_ecall_interface.h, 197	sbi_ecall.h, 190
SBI_EXT_BASE_GET_MARCHID	SBI_OK
sbi_ecall_interface.h, 197	sbi_error.h, 204
SBI_EXT_BASE_GET_MIMPID	SBI_PLATFORM_DEFAULT_FEATURES

11 11 11 11 11	001 TID INFO 0175
sbi_platform.h, 248	SBI_TLB_INFO_SIZE
SBI_PLATFORM_DISABLED_HART_OFFSET sbi_platform.h, 248	sbi_tlb.h, 291 SBI TRAP REGS OFFSET
SBI_PLATFORM_FEATURES_OFFSET	sbi trap.h, 296
sbi_platform.h, 248	SBI_TRAP_REGS_SIZE
SBI_PLATFORM_FIRMWARE_CONTEXT_OFFSET	sbi_trap.h, 298
sbi_platform.h, 248	SBI_TRAP_REGS_a0
SBI_PLATFORM_HART_COUNT_OFFSET	 sbi_trap.h, 295
sbi_platform.h, 248	SBI_TRAP_REGS_a1
SBI_PLATFORM_HART_STACK_SIZE_OFFSET	sbi_trap.h, 295
sbi_platform.h, 248	SBI_TRAP_REGS_a2
SBI_PLATFORM_NAME_OFFSET	sbi_trap.h, 295
sbi_platform.h, 249	SBI_TRAP_REGS_a3
SBI_PLATFORM_OPENSBI_VERSION_OFFSET	sbi_trap.h, 295
sbi_platform.h, 250	SBI_TRAP_REGS_a4
SBI_PLATFORM_OPS_OFFSET	sbi_trap.h, 295
sbi_platform.h, 250 SBI_PLATFORM_TLB_RANGE_FLUSH_LIMIT_DEF↔	SBI_TRAP_REGS_a5 sbi_trap.h, 295
AULT	SBI_TRAP_REGS_a6
sbi_platform.h, 250	sbi_trap.h, 296
SBI_PLATFORM_VERSION_OFFSET	SBI_TRAP_REGS_a7
sbi_platform.h, 251	sbi_trap.h, 296
SBI_PLATFORM_VERSION	SBI_TRAP_REGS_gp
sbi_platform.h, 250	sbi_trap.h, 296
SBI_SCRATCH_EXTRA_SPACE_OFFSET	SBI_TRAP_REGS_last
sbi_scratch.h, 271	sbi_trap.h, 296
SBI_SCRATCH_FW_SIZE_OFFSET	SBI_TRAP_REGS_mepc
sbi_scratch.h, 272	sbi_trap.h, 296
SBI_SCRATCH_FW_START_OFFSET	SBI_TRAP_REGS_mstatus
sbi_scratch.h, 272	sbi_trap.h, 296
SBI_SCRATCH_HARTID_TO_SCRATCH_OFFSET	SBI_TRAP_REGS_mstatusH
sbi_scratch.h, 272 SBI_SCRATCH_NEXT_ADDR_OFFSET	sbi_trap.h, 296 SBI_TRAP_REGS_ra
sbi_scratch.h, 272	sbi_trap.h, 297
SBI_SCRATCH_NEXT_ARG1_OFFSET	SBI_TRAP_REGS_s0
sbi_scratch.h, 272	sbi trap.h, 297
SBI_SCRATCH_NEXT_MODE_OFFSET	SBI_TRAP_REGS_s1
sbi_scratch.h, 272	 sbi_trap.h, 297
SBI_SCRATCH_OPTIONS_OFFSET	SBI_TRAP_REGS_s10
sbi_scratch.h, 273	sbi_trap.h, 297
SBI_SCRATCH_PLATFORM_ADDR_OFFSET	SBI_TRAP_REGS_s11
sbi_scratch.h, 273	sbi_trap.h, 297
SBI_SCRATCH_SIZE	SBI_TRAP_REGS_s2
sbi_scratch.h, 273	sbi_trap.h, 297
SBI_SCRATCH_TMP0_OFFSET	SBI_TRAP_REGS_s3
sbi_scratch.h, 273 SBI SCRATCH WARMBOOT ADDR OFFSET	sbi_trap.h, 297 SBI TRAP REGS s4
sbi scratch.h, 274	sbi_trap.h, 298
SBI_SPEC_VERSION_MAJOR_MASK	SBI_TRAP_REGS_s5
sbi_ecall_interface.h, 199	sbi_trap.h, 298
SBI_SPEC_VERSION_MAJOR_OFFSET	SBI TRAP REGS s6
sbi_ecall_interface.h, 199	sbi_trap.h, 298
SBI_SPEC_VERSION_MINOR_MASK	SBI_TRAP_REGS_s7
sbi_ecall_interface.h, 199	sbi_trap.h, 298
SBI_TLB_FIFO_NUM_ENTRIES	SBI_TRAP_REGS_s8
sbi_tlb.h, 291	sbi_trap.h, 298
SBI_TLB_FLUSH_ALL	SBI_TRAP_REGS_s9
sbi_tlb.h, 291	sbi_trap.h, 298

SBI_TRAP_REGS_sp	SSTATUS_SPP
sbi_trap.h, 298	riscv_encoding.h, 163
SBI_TRAP_REGS_t0	SSTATUS_SUM
sbi_trap.h, 299	riscv_encoding.h, 163
SBI_TRAP_REGS_t1	SSTATUS_SD
sbi_trap.h, 299	riscv_encoding.h, 162
SBI_TRAP_REGS_t2	SSTATUS_XS
sbi_trap.h, 299	riscv_encoding.h, 163
SBI_TRAP_REGS_t3	STRINGIFY
sbi_trap.h, 299	sbi_const.h, 188
SBI_TRAP_REGS_t4	STR
sbi_trap.h, 299	sbi_types.h, 305
SBI_TRAP_REGS_t5	SZREG
sbi_trap.h, 299	riscv_asm.h, 81
SBI_TRAP_REGS_t6	sbi_bitops.h
sbi_trap.h, 299 SBI_TRAP_REGS_tp	ffs, 179 fls, 179
sbi_trap.h, 299	ns, 179 ffs, 179
SBI_TRAP_REGS_zero	ffz, 179
sbi_trap.h, 300	fls, 180
SET_RD	sbi_bits.h
riscv_encoding.h, 160	BIT_MASK, 180
SH_RS1	BIT WORD, 180
riscv_encoding.h, 161	EXTRACT_FIELD, 181
SH RS2	INSERT_FIELD, 181
riscv_encoding.h, 161	sbi_boot_prints
SH RS2C	sbi_init.c, 396
riscv_encoding.h, 161	sbi_console.c
SH RD	console_out_lock, 353
riscv_encoding.h, 161	console_plat, 353
SHIFT RIGHT	PAD_ALTERNATE, 344
riscv_encoding.h, 161	PAD RIGHT, 344
SIP SSIP	PAD_ZERO, 344
riscv_encoding.h, 161	PRINT_BUF_LEN, 344
SIP_STIP	print, 345
riscv_encoding.h, 161	printc, 345
SPIN_LOCK_INITIALIZER	printi, 346
riscv_locks.h, 172	prints, 347
SPIN_LOCK_INIT	sbi_console_init, 347
riscv_locks.h, 172	sbi_dprintf, 348
SSTATUS32_SD	sbi_getc, 349
riscv_encoding.h, 162	sbi_gets, 349
SSTATUS64_SD	sbi_isprintable, 350
riscv_encoding.h, 162	sbi_printf, 350
SSTATUS64_UXL	sbi_putc, 351
riscv_encoding.h, 162	sbi_puts, 351
SSTATUS_FS	sbi_snprintf, 352
riscv_encoding.h, 162	sbi_sprintf, 352
SSTATUS_MXR	va_arg, 344
riscv_encoding.h, 162	va_end, 344
SSTATUS_SIE	va_list, 345
riscv_encoding.h, 162	va_start, 344
SSTATUS_SPIE_SHIFT	sbi_console.h
riscv_encoding.h, 163	printf, 182, 183
SSTATUS_SPIE	format, 186
riscv_encoding.h, 162	out_sz, 186
SSTATUS_SPP_SHIFT	sbi_console_init, 183
riscv_encoding.h, 163	sbi_getc, 183

sbi_gets, 184	sbi_ecall_base.c, 358
sbi_isprintable, 184	sbi_ecall_base_probe
sbi_putc, 185	sbi_ecall_base.c, 359
sbi_puts, 185	sbi_ecall_extension, 52
sbi_console_init	extid_end, 52
sbi_console.c, 347	extid_start, 52
sbi_console.h, 183	handle, 52
sbi_const.h	head, 52
_AC, 187	probe, 52
_AT, 187	sbi_ecall_find_extension
_BITUL, 187	sbi ecall.c, 354
_BITULL, 188	sbi_ecall.h, 190
	sbi_ecall_handler
	sbi_ecall.c, 354
AC, 187	sbi_ecall.h, 190
STR, 187	sbi_ecall_init
STRINGIFY, 188	sbi_ecall.c, 355
ULL, 188	sbi_ecall.h, 191
UL, 188	sbi_ecall_interface.h
sbi_current_hartid	SBI_EXT_0_1_CLEAR_IPI, 195
sbi_hart.c, 382	SBI_EXT_0_1_CONSOLE_GETCHAR, 195
sbi_hart.h, 212	SBI EXT 0 1 CONSOLE PUTCHAR, 195
sbi_dlist, 51	SBI_EXT_0_1_REMOTE_FENCE_I, 196
next, 51	SBI EXT 0 1 REMOTE SFENCE VMA ASID,
prev, 51	196
sbi_dprintf	SBI_EXT_0_1_REMOTE_SFENCE_VMA, 196
sbi_console.c, 348	
sbi_ecall.c	SBI_EXT_0_1_SEND_IPI, 196 SBI_EXT_0_1_SET_TIMER, 196
SBI_LIST_HEAD, 357	SBI_EXT_0_1_SET_TIMER, 190 SBI_EXT_0_1_SHUTDOWN, 196
sbi_ecall_find_extension, 354	
	SBI_EXT_BASE_GET_IMP_ID, 196
sbi_ecall_handler, 354	SBI_EXT_BASE_GET_IMP_VERSION, 197
sbi_ecall_init, 355	SBI_EXT_BASE_GET_MARCHID, 197
sbi_ecall_register_extension, 356	SBI_EXT_BASE_GET_MIMPID, 197
sbi_ecall_unregister_extension, 356	SBI_EXT_BASE_GET_MVENDORID, 197
sbi_ecall_version_major, 357	SBI_EXT_BASE_GET_SPEC_VERSION, 197
sbi_ecall_version_minor, 357	SBI_EXT_BASE_PROBE_EXT, 197
sbi_ecall.h	SBI_EXT_BASE, 196
ecall_base, 194	SBI_EXT_IPI_SEND_IPI, 197
ecall_ipi, 194	SBI_EXT_IPI, 197
ecall_legacy, 194	SBI_EXT_RFENCE_REMOTE_FENCE_I, 198
ecall_rfence, 194	SBI_EXT_RFENCE_REMOTE_HFENCE_GVM↔
ecall_time, 194	A_VMID, 198
ecall_vendor, 194 SBI ECALL VERSION MAJOR, 190	SBI_EXT_RFENCE_REMOTE_HFENCE_GVMA,
	198
SBI_ECALL_VERSION_MINOR, 190	SBI_EXT_RFENCE_REMOTE_HFENCE_VVM↔
SBI_OPENSBI_IMPID, 190	A_ASID, 198
sbi_ecall_find_extension, 190	SBI_EXT_RFENCE_REMOTE_HFENCE_VVMA,
sbi_ecall_handler, 190	198
sbi_ecall_init, 191	SBI_EXT_RFENCE_REMOTE_SFENCE_VMA_
sbi_ecall_register_extension, 192	ASID, 198
sbi_ecall_unregister_extension, 192	SBI_EXT_RFENCE_REMOTE_SFENCE_VMA,
sbi_ecall_version_major, 193	198
sbi_ecall_version_minor, 193	SBI_EXT_RFENCE, 198
sbi_ecall_base.c	SBI_EXT_TIME_SET_TIMER, 199
ecall_base, 360	SBI_EXT_TIME, 199
sbi_ecall_base_handler, 358	SBI_EXT_VENDOR_END, 199
sbi_ecall_base_probe, 359	SBI_EXT_VENDOR_START, 199
sbi_ecall_base_handler	SBI_SPEC_VERSION_MAJOR_MASK, 199

SBI_SPEC_VERSION_MAJOR_OFFSET, 199 SBI_SPEC_VERSION_MINOR_MASK, 199	SBI_EIO, 203 SBI_ENODEV, 203
sbi ecall ipi handler	SBI_ENOENT, 203
sbi_ecall_replace.c, 363	SBI ENOMEM, 203
sbi_ecall_legacy.c	SBI ENOSPC, 203
ecall_legacy, 362	SBI ENOSYS, 203
sbi_ecall_legacy_handler, 361	SBI_ENOTSUPP, 204
sbi_load_hart_mask_unpriv, 361	SBI ETIMEDOUT, 204
sbi_ecall_legacy_handler	SBI ETRAP, 204
sbi_ecall_legacy.c, 361	SBI EUNKNOWN, 204
sbi_ecall_register_extension	SBI_INVALID_ADDR, 204
sbi_ecall.c, 356	SBI_OK, 204
sbi_ecall.h, 192	sbi_exit
sbi_ecall_replace.c	sbi_init.c, 397
ecall_ipi, 364	sbi_init.h, 225
ecall_rfence, 365	sbi_fifo, 53
ecall_time, 365	avail, 53
sbi_ecall_ipi_handler, 363	entry_size, 53
sbi_ecall_rfence_handler, 363	num_entries, 53
sbi_ecall_time_handler, 364	qlock, 53
sbi_ecall_rfence_handler	queue, 54
sbi_ecall_replace.c, 363	tail, 54
sbi_ecall_time_handler	sbi_fifo.c
sbi ecall replace.c, 364	sbi_fifo_enqueue, 371
sbi_ecall_unregister_extension	sbi_fifo_is_empty, 371
sbi_ecall.c, 356	sbi_fifo_is_full, 371
sbi_ecall.h, 192	sbi_fifo_reset, 372
sbi_ecall_vendor.c	sbi_fifo_avail, 372
ecall_vendor, 367	sbi_fifo_dequeue, 373
sbi_ecall_vendor_handler, 366	sbi_fifo_enqueue, 374
sbi_ecall_vendor_probe, 367	sbi_fifo_init, 374
sbi_ecall_vendor_handler	sbi_fifo_inplace_update, 375
sbi_ecall_vendor.c, 366	sbi_fifo_is_empty, 376
sbi_ecall_vendor_probe	sbi_fifo_is_full, 376
sbi_ecall_vendor.c, 367	sbi_fifo_reset, 377
sbi_ecall_version_major	sbi fifo.h
sbi_ecall.c, 357	sbi_fifo_avail, 206
sbi_ecall.h, 193	sbi_fifo_dequeue, 206
sbi_ecall_version_minor	sbi_fifo_enqueue, 207
sbi_ecall.c, 357	sbi_fifo_init, 208
sbi_ecall.h, 193	sbi_fifo_inplace_update, 209
sbi emulate csr.c	sbi_fifo_inplace_update_types, 206
sbi_emulate_csr_read, 368	sbi_fifo_is_empty, 209
sbi_emulate_csr_write, 369	sbi_fifo_is_full, 210
sbi emulate csr.h	sbi_fifo_avail
sbi_emulate_csr_read, 200	sbi_fifo.c, 372
sbi_emulate_csr_write, 201	sbi_fifo.h, 206
sbi_emulate_csr_read	sbi_fifo_dequeue
sbi_emulate_csr.c, 368	sbi_fifo.c, 373
sbi_emulate_csr.h, 200	sbi_fifo.h, 206
sbi_emulate_csr_write	sbi_fifo_enqueue
sbi_emulate_csr.c, 369	sbi_fifo.c, 374
sbi_emulate_csr.h, 201	sbi_fifo.h, 207
sbi error.h	sbi fifo init
SBI_DENIED, 202	sbi_fifo.c, 374
SBI_EFAIL, 202	sbi_fifo.h, 208
SBI_EILL, 203	sbi_fifo_inplace_update
SBI_EINVAL, 203	sbi_fifo.c, 375

sbi_fifo.h, 209	sbi_hart_init, 214
sbi_fifo_inplace_update_types	sbi_hart_mark_available, 215
sbi_fifo.h, 206	sbi_hart_pmp_dump, 216
sbi_fifo_is_empty	sbi_hart_set_trap_info, 217
sbi_fifo.c, 376	sbi_hart_unmark_available, 217
sbi_fifo.h, 209	sbi_hart_wait_for_coldboot, 217
sbi_fifo_is_full	sbi_hart_wake_coldboot_harts, 218
sbi_fifo.c, 376	sbi_hart_available_mask
sbi_fifo.h, 210	sbi_hart.c, 382 sbi_hart.h, 212
sbi_fifo_reset	
sbi_fifo.c, 377	sbi_hart_delegation_dump
sbi_get_insn sbi_unpriv.c, 445	sbi_hart.c, 383 sbi_hart.h, 213
sbi_unpriv.h, 310	sbi_hart_get_trap_info
_ ·	sbi_hart.c, 383
sbi_getc sbi_console.c, 349	sbi_nart.h, 213
sbi_console.t, 349	sbi_hart_id_to_scratch
sbi gets	sbi_hart.c, 384
sbi_console.c, 349	sbi_hart.b, 214
sbi_console.t, 349	sbi_hart_init
sbi hart.c	sbi_hart.c, 384
attribute, 379	sbi_hart.h, 214
avail_hart_mask, 389	sbi_hart_mark_available
avail_hart_mask_lock, 389	sbi_hart.c, 385
COLDBOOT_WAIT_BITMAP_SIZE, 379	sbi_hart.h, 215
coldboot_done, 389	sbi_hart_pmp_dump
coldboot lock, 389	sbi hart.c, 386
coldboot_wait_bitmap, 389	sbi_hart.h, 216
delegate_traps, 379	sbi_hart_set_trap_info
fp_init, 380	sbi_hart.c, 387
h2s, 379	sbi_hart.h, 217
log2roundup, 380	sbi_hart_unmark_available
mstatus init, 380	sbi hart.c, 387
pmp_init, 381	sbi hart.h, 217
sbi_current_hartid, 382	sbi_hart_wait_for_coldboot
sbi_hart_available_mask, 382	sbi hart.c, 387
sbi_hart_delegation_dump, 383	sbi_hart.h, 217
sbi_hart_get_trap_info, 383	sbi hart wake coldboot harts
sbi_hart_id_to_scratch, 384	sbi_hart.c, 388
sbi_hart_init, 384	sbi_hart.h, 218
sbi_hart_mark_available, 385	sbi_hfence.h
sbi_hart_pmp_dump, 386	sbi_hfence_gvma_all, 220
sbi_hart_set_trap_info, 387	sbi_hfence_gvma_gpa, 220
sbi_hart_unmark_available, 387	sbi_hfence_gvma_vmid, 221
sbi_hart_wait_for_coldboot, 387	sbi_hfence_gvma_vmid_gpa, 221
sbi_hart_wake_coldboot_harts, 388	sbi_hfence_vvma_all, 221
trap_info_offset, 389	sbi_hfence_vvma_asid, 222
sbi_hart.h	sbi_hfence_vvma_asid_va, 222
attribute, 212	sbi_hfence_vvma_va, 222
arg1, 219	sbi_illegal_insn.c
next_addr, 219	illegal_insn_func, 390
next_mode, 219	illegal_insn_table, 393
next_virt, 219	sbi_illegal_insn_handler, 391
sbi_current_hartid, 212	system_opcode_insn, 391
sbi_hart_available_mask, 212	truly_illegal_insn, 392
sbi_hart_delegation_dump, 213	sbi_illegal_insn.h
sbi_hart_get_trap_info, 213	sbi_illegal_insn_handler, 224
sbi_hart_id_to_scratch, 214	sbi_illegal_insn_handler

sbi_illegal_insn.c, 391	sbi_ipi_event_destroy
sbi_illegal_insn.h, 224	sbi_ipi.c, 402
sbi_init	sbi_ipi.h, 231
sbi_init.c, 398	sbi_ipi_event_ops, 54
sbi_init.h, 227	name, 54
sbi_init.c	process, 54
BANNER, 394	sync, 55
coldboot_lottery, 400	update, 55
init_coldboot, 394	sbi_ipi_exit
init_count_offset, 400	sbi_ipi.c, 402
init warmboot, 395	sbi_ipi.h, 231
sbi_boot_prints, 396	sbi_ipi_init
sbi_exit, 397	sbi_ipi.c, 403
sbi init, 398	sbi_ipi.h, 232
- :	— ·
sbi_init_count, 399	sbi_ipi_process
sbi_init.h	sbi_ipi.c, 403
sbi_exit, 225	sbi_ipi.h, 232
sbi_init, 227	sbi_ipi_process_halt
sbi_init_count, 228	sbi_ipi.c, 404
sbi_init_count	sbi_ipi_process_smode
sbi_init.c, 399	sbi_ipi.c, 405
sbi_init.h, 228	sbi_ipi_send
sbi_ipi.c	sbi_ipi.c, 405
ipi_data_off, 408	sbi_ipi_send_halt
ipi_halt_event, 408	sbi_ipi.c, 406
ipi_halt_ops, 408	sbi_ipi.h, <mark>233</mark>
ipi_ops_array, 409	sbi_ipi_send_many
ipi_smode_event, 409	sbi_ipi.c, 406
ipi_smode_ops, 409	sbi_ipi.h, 234
sbi_ipi_clear_smode, 401	sbi_ipi_send_smode
sbi_ipi_event_create, 401	sbi_ipi.c, 407
sbi_ipi_event_destroy, 402	sbi_ipi.h, 235
sbi_ipi_exit, 402	sbi_isprintable
sbi_ipi_init, 403	sbi_console.c, 350
sbi_ipi_process, 403	sbi_console.h, 184
sbi_ipi_process_halt, 404	sbi_list.h
sbi ipi process smode, 405	sbi list add, 239
sbi_ipi_send, 405	sbi_list_del, 240
sbi_ipi_send_halt, 406	sbi_list_del_entry, 240
sbi_ipi_send_many, 406	SBI_INIT_LIST_HEAD, 237
sbi_ipi_send_smode, 407	SBI LIST HEAD INIT, 238
sbi_ipi.h	SBI LIST HEAD, 238
SBI_IPI_EVENT_MAX, 230	SBI LIST POISON NEXT, 239
sbi_ipi_clear_smode, 230	SBI LIST POISON PREV, 239
sbi_ipi_event_create, 230	sbi_list_add, 241
sbi ipi event destroy, 231	sbi_list_add_tail, 241
sbi_ipi_exit, 231	sbi list del, 242
sbi_ipi_init, 232	sbi_list_del_init, 242
sbi_ipi_process, 232	sbi_list_entry, 237
sbi_ipi_send_halt, 233	sbi_list_first_entry, 237
-·	'
sbi_ipi_send_many, 234	sbi_list_for_each, 238 sbi_list_for_each_entry, 238
sbi_ipi_send_smode, 235	·
sbi_ipi_clear_smode	sbi_list_last_entry, 239
sbi_ipi.c, 401	sbi_list_add
sbi_ipi.h, 230	sbi_list.h, 241
sbi_ipi_event_create	sbi_list_add_tail
sbi_ipi.c, 401	sbi_list.h, 241
sbi_ipi.h, 230	sbi_list_del

sbi_list.h, 242	SBI_PLATFORM_DISABLED_HART_OFFSET,
sbi_list_del_init	248
sbi_list.h, 242	SBI_PLATFORM_FEATURES_OFFSET, 248
sbi_list_entry	SBI_PLATFORM_FIRMWARE_CONTEXT_OFF←
sbi_list.h, 237	SET, 248
sbi_list_first_entry	SBI_PLATFORM_HART_COUNT_OFFSET, 248
sbi_list.h, 237	SBI_PLATFORM_HART_STACK_SIZE_OFFSET, 248
sbi_list_for_each	SBI_PLATFORM_NAME_OFFSET, 249
sbi_list.h, 238	SBI_PLATFORM_OPENSBI_VERSION_OFFSET,
sbi_list_for_each_entry	250
sbi_list.h, 238	SBI PLATFORM OPS OFFSET, 250
sbi_list_last_entry	SBI_PLATFORM_TLB_RANGE_FLUSH_LIMIT
sbi_list.h, 239	DEFAULT, 250
sbi_load_hart_mask_unpriv	SBI_PLATFORM_VERSION_OFFSET, 251
sbi_ecall_legacy.c, 361	SBI_PLATFORM_VERSION, 250
sbi_load_u64	sbi_platform_console_getc, 251
sbi_unpriv.c, 446	sbi_platform_console_init, 252
sbi_memchr	sbi_platform_console_putc, 252
sbi_string.c, 415	sbi_platform_early_exit, 253
sbi_string.h, 277	sbi_platform_early_init, 253
sbi_memcmp	sbi_platform_features, 251
sbi_string.c, 415	sbi_platform_final_exit, 254
sbi_string.h, 277	sbi_platform_final_init, 255
sbi_memcpy	sbi_platform_hart_count, 255
sbi_string.c, 415	sbi_platform_hart_disabled, 256
sbi_string.h, 277	sbi_platform_hart_stack_size, 257
sbi_memmove	sbi_platform_has_hart_hotplug, 249
sbi_string.c, 415	sbi_platform_has_mcounteren, 249
sbi_string.h, 277	sbi_platform_has_mfaults_delegation, 249
sbi_memset	sbi_platform_has_pmp, 249
sbi_string.c, 416	sbi_platform_has_scounteren, 249
sbi_string.h, 277	sbi_platform_has_timer_value, 249
sbi_misaligned_ldst.c	sbi_platform_ipi_clear, 257
sbi_misaligned_load_handler, 410	sbi_platform_ipi_exit, 258
sbi_misaligned_store_handler, 411	sbi_platform_ipi_init, 258
sbi_misaligned_ldst.h	sbi_platform_ipi_send, 259
sbi_misaligned_load_handler, 244	sbi_platform_irqchip_exit, 259
sbi_misaligned_store_handler, 245	sbi platform irqchip init, 260
sbi_misaligned_load_handler	sbi_platform_misa_extension, 260
sbi_misaligned_ldst.c, 410	sbi_platform_misa_xlen, 261
sbi_misaligned_ldst.h, 244	sbi_platform_name, 261
sbi_misaligned_store_handler	sbi_platform_ops, 250
sbi_misaligned_ldst.c, 411	sbi_platform_pmp_region_count, 262
sbi_misaligned_ldst.h, 245	sbi_platform_pmp_region_info, 263
sbi_platform, 55	sbi platform ptr, 250
disabled_hart_mask, 56	sbi_platform_system_reboot, 263
features, 56	sbi_platform_system_shutdown, 264
firmware_context, 56	sbi_platform_thishart_ptr, 250
hart_count, 56	sbi_platform_timer_event_start, 265
hart_stack_size, 56	sbi_platform_timer_event_stop, 265
name, 56	sbi_platform_timer_exit, 266
opensbi_version, 56	sbi_platform_timer_init, 266
platform_ops_addr, 56	sbi_platform_timer_value, 267
platform_version, 57	sbi_platform_tlbr_flush_limit, 267
sbi_platform.h	sbi_platform_vendor_ext_check, 268
packed, 270	sbi_platform_vendor_ext_provider, 269
SBI_PLATFORM_DEFAULT_FEATURES, 248	sbi_platform_console_getc
	_, _ _

sbi_platform.h, 251	final_init, 58
sbi_platform_console_init	get_tlbr_flush_limit, 59
sbi_platform.h, 252	ipi_clear, 59
sbi_platform_console_putc	ipi_exit, 59
sbi_platform.h, 252	ipi_init, 59
sbi_platform_early_exit	ipi_send, 59
sbi_platform.h, 253	irqchip_exit, 59
sbi_platform_early_init	irqchip_init, 59
sbi_platform.h, 253	misa_check_extension, 59
sbi_platform_features	misa_get_xlen, 60
sbi_platform.h, 251	pmp_region_count, 60
sbi_platform_final_exit	pmp_region_info, 60
sbi_platform.h, 254	system_reboot, 60
sbi_platform_final_init	system_shutdown, 60
sbi_platform.h, 255	timer_event_start, 60
sbi_platform_hart_count	timer_event_stop, 60
sbi_platform.h, 255	timer_exit, 61
sbi_platform_hart_disabled	timer_init, 61
sbi_platform.h, 256	timer_value, 61
sbi_platform_hart_stack_size	vendor_ext_check, 61
sbi_platform.h, 257	vendor_ext_provider, 61
sbi_platform_has_hart_hotplug	sbi_platform_ops
sbi_platform.h, 249	sbi_platform.h, 250
sbi_platform_has_mcounteren	sbi_platform_pmp_region_count
sbi_platform.h, 249	sbi_platform.h, 262
sbi_platform_has_mfaults_delegation	sbi_platform_pmp_region_info
sbi_platform.h, 249 sbi_platform_has_pmp	sbi_platform.h, 263
sbi_platform.h, 249	sbi_platform_ptr sbi_platform.h, 250
sbi_platform_has_scounteren	sbi_platform_system_reboot
sbi platform.h, 249	sbi_platform.h, 263
sbi_platform_has_timer_value	sbi_platform_system_shutdown
sbi_platform.h, 249	sbi_platform.h, 264
sbi_platform_ipi_clear	sbi_platform_thishart_ptr
sbi_platform.h, 257	sbi_platform.h, 250
sbi_platform_ipi_exit	sbi_platform_timer_event_start
sbi platform.h, 258	sbi_platform.h, 265
sbi_platform_ipi_init	sbi_platform_timer_event_stop
sbi platform.h, 258	sbi_platform.h, 265
sbi_platform_ipi_send	sbi_platform_timer_exit
sbi platform.h, 259	sbi_platform.h, 266
sbi_platform_irqchip_exit	sbi_platform_timer_init
sbi_platform.h, 259	sbi_platform.h, 266
sbi platform irqchip init	sbi_platform_timer_value
sbi_platform.h, 260	sbi_platform.h, 267
sbi_platform_misa_extension	sbi_platform_tlbr_flush_limit
sbi_platform.h, 260	sbi_platform.h, 267
sbi_platform_misa_xlen	sbi_platform_vendor_ext_check
sbi_platform.h, 261	sbi_platform.h, 268
sbi_platform_name	sbi_platform_vendor_ext_provider
sbi_platform.h, 261	sbi_platform.h, 269
sbi_platform_operations, 57	sbi_printf
console_getc, 58	sbi_console.c, 350
console_init, 58	sbi_putc
console_putc, 58	sbi_console.c, 351
early_exit, 58	sbi_console.h, 185
early_init, 58	sbi_puts
final_exit, 58	sbi_console.c, 351

sbi_console.h, 185	sbi_console.c, 352
sbi_scratch, 61	sbi_sprintf
fw_size, 62	sbi_console.c, 352
fw_start, 62	sbi_store_u64
hartid_to_scratch, 62	sbi_unpriv.c, 446
next_addr, 62	sbi_strchr
next_arg1, 62	sbi_string.c, 416
next_mode, 63	sbi_string.h, 278
options, 63	sbi_strcmp
platform_addr, 63	sbi_string.c, 416
tmp0, 63	sbi_string.h, 278
warmboot_addr, 63	sbi_strcpy
sbi scratch.c	sbi_string.c, 416
extra_lock, 414	sbi_string.h, 278
extra_offset, 414	sbi_string.c
sbi_scratch_alloc_offset, 413	sbi_memchr, 415
sbi_scratch_free_offset, 413	sbi_memcmp, 415
sbi scratch.h	sbi memcpy, 415
packed, 276	sbi_memmove, 415
SBI_SCRATCH_EXTRA_SPACE_OFFSET, 271	sbi_memset, 416
SBI_SCRATCH_FW_SIZE_OFFSET, 272	sbi_strchr, 416
SBI_SCRATCH_FW_START_OFFSET, 272	
	sbi_strcmp, 416
SBI_SCRATCH_HARTID_TO_SCRATCH_OFF SET_070	sbi_strcpy, 416
SET, 272	sbi_strlen, 417
SBI_SCRATCH_NEXT_ADDR_OFFSET, 272	sbi_strncpy, 417
SBI_SCRATCH_NEXT_ARG1_OFFSET, 272	sbi_strnlen, 417
SBI_SCRATCH_NEXT_MODE_OFFSET, 272	sbi_strrchr, 417
SBI_SCRATCH_OPTIONS_OFFSET, 273	sbi_string.h
SBI_SCRATCH_PLATFORM_ADDR_OFFSET,	sbi_memchr, 277
273	sbi_memcmp, 277
SBI_SCRATCH_SIZE, 273	sbi_memcpy, 277
SBI_SCRATCH_TMP0_OFFSET, 273	sbi_memmove, 277
SBI_SCRATCH_WARMBOOT_ADDR_OFFSET,	sbi_memset, 277
274	sbi_strchr, 278
sbi_scratch_alloc_offset, 274	sbi_strcmp, 278
sbi_scratch_free_offset, 275	sbi_strcpy, 278
sbi_scratch_offset_ptr, 272	sbi_strlen, 278
sbi_scratch_options, 274	sbi_strncpy, 279
sbi_scratch_thishart_arg1_ptr, 273	sbi_strnlen, 279
sbi_scratch_thishart_offset_ptr, 273	sbi_strrchr, 279
sbi_scratch_thishart_ptr, 273	sbi_strlen
sbi_scratch_alloc_offset	sbi_string.c, 417
sbi_scratch.c, 413	sbi_string.h, 278
sbi_scratch.h, 274	sbi strncpy
sbi scratch free offset	sbi_string.c, 417
sbi scratch.c, 413	sbi string.h, 279
sbi_scratch.h, 275	sbi strnlen
sbi_scratch_offset_ptr	sbi_string.c, 417
sbi_scratch.h, 272	sbi_string.h, 279
sbi_scratch_options	sbi strrchr
sbi_scratch.h, 274	sbi_string.c, 417
sbi_scratch_thishart_arg1_ptr	sbi_string.h, 279
sbi_scratch.h, 273	sbi_string.n, 270
sbi_scratch_thishart_offset_ptr	sbi_system_early_exit, 419
sbi_scratch.h, 273	sbi_system_early_init, 419
sbi_scratch_thishart_ptr	sbi_system_final_exit, 419
	_ ·
sbi_scratch.h, 273	sbi_system_final_init, 420
sbi_snprintf	sbi_system_reboot, 420

sbi_system_shutdown, 421	sbi_timer.c, 424
sbi_system.h	sbi_timer.h, 286
sbi_system_early_exit, 280	sbi_timer_process
sbi_system_early_init, 281	sbi_timer.c, 425
sbi_system_final_exit, 281	sbi_timer.h, 287
sbi_system_final_init, 282	sbi_timer_set_delta
sbi_system_reboot, 282	sbi_timer.c, 425
sbi_system_shutdown, 283	sbi_timer.h, 287
sbi_system_early_exit	sbi_timer_set_delta_upper
sbi_system.c, 419	sbi_timer.c, 426
sbi_system.h, 280	sbi_timer.h, 288
sbi_system_early_init	sbi_timer_value
sbi_system.c, 419	sbi_timer.c, 426
sbi_system.h, 281	sbi_timer.h, 288
sbi_system_final_exit	sbi_timer_virt_value
sbi_system.c, 419	sbi_timer.c, 427
sbi_system.h, 281	sbi_timer.h, 289
sbi_system_final_init	sbi_tlb.c
sbi_system.c, 420	sbi_tlb_range_check, 429
sbi_system.h, 282	sbi_tlb_entry_process, 429
sbi_system_reboot	sbi_tlb_flush_all, 430
sbi_system.c, 420	sbi_tlb_hfence_gvma, 430
sbi_system.h, 282	sbi_tlb_hfence_gvma_vmid, 430
sbi_system_shutdown	sbi_tlb_hfence_vvma, 431
sbi_system.c, 421	sbi_tlb_hfence_vvma_asid, 432
sbi_system.h, 283	sbi_tlb_init, 432
sbi_timer.c	sbi_tlb_local_flush, 433
get_ticks, 423	sbi_tlb_process, 434
sbi_timer_event_start, 423	sbi_tlb_process_count, 434
sbi_timer_exit, 424	sbi_tlb_request, 435
sbi_timer_get_delta, 424	sbi_tlb_sfence_vma, 436
sbi_timer_init, 424	sbi_tlb_sfence_vma_asid, 437
sbi_timer_process, 425	sbi_tlb_sync, 437
sbi_timer_set_delta, 425	sbi_tlb_update, 438
sbi_timer_set_delta_upper, 426 sbi_timer_value, 426	sbi_tlb_update_cb, 438
	tlb_event, 439 tlb_fifo_mem_off, 439
sbi_timer_virt_value, 427 time_delta_off, 427	tlb_fifo_off, 439
sbi timer.h	tlb_ops, 440
sbi_timer_event_start, 285	tlb_range_flush_limit, 440
sbi timer exit, 285	tlb_sync_off, 440
sbi_timer_get_delta, 286	sbi_tlb.h
sbi timer init, 286	SBI_TLB_FIFO_NUM_ENTRIES, 291
sbi timer process, 287	SBI TLB FLUSH ALL, 291
sbi_timer_set_delta, 287	SBI_TLB_INFO_SIZE, 291
sbi_timer_set_delta_upper, 288	sbi tlb info types, 291
sbi_timer_value, 288	sbi_tlb_init, 291
sbi_timer_virt_value, 289	sbi_tlb_request, 292
sbi_timer_event_start	sbi_tlb_entry_process
sbi timer.c, 423	sbi tlb.c, 429
sbi timer.h, 285	sbi_tlb_flush_all
sbi_timer_exit	sbi_tlb.c, 430
sbi_timer.c, 424	sbi_tlb_hfence_gvma
sbi timer.h, 285	sbi_tlb.c, 430
sbi_timer_get_delta	sbi_tlb_hfence_gvma_vmid
sbi_timer.c, 424	sbi_tlb.c, 430
sbi_timer.h, 286	sbi_tlb_hfence_vvma
sbi_timer_init	sbi_tlb.c, 431
_ '- '	

sbi_tlb_hfence_vvma_asid	SBI_TRAP_REGS_s2, 297
sbi_tlb.c, 432	SBI_TRAP_REGS_s3, 297
sbi_tlb_info, 63	SBI_TRAP_REGS_s4, 298
asid, 64	SBI_TRAP_REGS_s5, 298
shart_mask, 64	SBI_TRAP_REGS_s6, 298
size, 64	SBI_TRAP_REGS_s7, 298
start, 64	SBI_TRAP_REGS_s8, 298
type, 64	SBI_TRAP_REGS_s9, 298
sbi_tlb_info_types	SBI_TRAP_REGS_sp, 298
sbi_tlb.h, 291	SBI_TRAP_REGS_t0, 299
sbi_tlb_init	SBI_TRAP_REGS_t1, 299
sbi_tlb.c, 432	SBI_TRAP_REGS_t2, 299
sbi_tlb.h, 291	SBI_TRAP_REGS_t3, 299
sbi_tlb_local_flush	SBI_TRAP_REGS_t4, 299
sbi_tlb.c, 433	SBI_TRAP_REGS_t5, 299
sbi_tlb_process	SBI_TRAP_REGS_t6, 299
sbi_tlb.c, 434	SBI_TRAP_REGS_tp, 299
sbi_tlb_process_count	SBI_TRAP_REGS_zero, 300
sbi_tlb.c, 434	sbi_trap_handler, 300
sbi_tlb_request	sbi_trap_redirect, 301
sbi_tlb.c, 435	sbi_trap_error
sbi_tlb.h, 292	sbi_trap.c, 441
sbi_tlb_sfence_vma	sbi_trap_handler
sbi_tlb.c, 436	sbi_trap.c, 441
sbi_tlb_sfence_vma_asid	sbi_trap.h, 300
sbi_tlb.c, 437	sbi_trap_info, 65
sbi_tlb_sync	cause, 65
sbi_tlb.c, 437	epc, 65
sbi_tlb_update	tinst, 65
sbi_tlb.c, 438	tval, 65
sbi_tlb_update_cb	tval2, 65
sbi_tlb.c, 438	sbi_trap_redirect
sbi_trap.c	sbi_trap.c, 442
sbi_trap_error, 441	sbi_trap.h, 301
sbi_trap_handler, 441	sbi_trap_regs, 66
sbi_trap_redirect, 442	a0, <mark>67</mark>
sbi_trap.h	a1, <mark>67</mark>
packed, 302	a2, <mark>67</mark>
SBI_TRAP_REGS_OFFSET, 296	a3, <mark>67</mark>
SBI_TRAP_REGS_SIZE, 298	a4, 67
SBI_TRAP_REGS_a0, 295	a5, <mark>67</mark>
SBI_TRAP_REGS_a1, 295	a6, <mark>67</mark>
SBI_TRAP_REGS_a2, 295	a7, 68
SBI_TRAP_REGS_a3, 295	gp, <mark>68</mark>
SBI_TRAP_REGS_a4, 295	mepc, 68
SBI_TRAP_REGS_a5, 295	mstatus, 68
SBI_TRAP_REGS_a6, 296	mstatusH, 68
SBI_TRAP_REGS_a7, 296	ra, 68
SBI_TRAP_REGS_gp, 296	s0, 68
SBI_TRAP_REGS_last, 296	s1, 68
SBI_TRAP_REGS_mepc, 296	s10, 69
SBI_TRAP_REGS_mstatus, 296	s11, 69
SBI_TRAP_REGS_mstatusH, 296	s2, 69
SBI_TRAP_REGS_ra, 297	s3, 69
SBI_TRAP_REGS_s0, 297	s4, 69
SBI_TRAP_REGS_s1, 297	s5, 69
SBI_TRAP_REGS_s10, 297	s6, 69
SBI_TRAP_REGS_s11, 297	s7, 69

s8, 7 0	DECLARE_UNPRIVILEGED_LOAD_FUNCTION,
s9, 70	309
sp, 70	DECLARE_UNPRIVILEGED_STORE_FUNCTI←
t0, 70	ON, 310
t1, 70	sbi_get_insn, 310
t2, 70	sbi_version.h
t3, 70	OPENSBI_VERSION_MAJOR, 311
t4, 70	OPENSBI_VERSION_MINOR, 312
t5, 71	OPENSBI_VERSION, 311
t6, 71	set_reg
tp, 71	sifive-uart.c, 638
zero, 71	uart8250.c, 645
sbi_types.h	shart_mask
noreturn, 303	sbi_tlb_info, 64
packed, 303	sifive-uart.c
bool, 306	get_reg, 638
CLAMP, 303	set_reg, 638
container_of, 304	sifive_uart_getc, 638
FALSE, 304	sifive_uart_init, 639
int16 t, 306	sifive uart putc, 639
int32_t, 306	UART_REG_DIV, 636
likely, 304	UART REG IE, 636
MAX, 304	UART REG IP, 636
MIN, 304	UART_REG_RXCTRL, 636
NULL, 304	UART_REG_RXFIFO, 637
offsetof, 305	UART REG TXCTRL, 637
physical_addr_t, 306	UART_REG_TXFIFO, 637
physical_size_t, 306	UART_RXCTRL_RXEN, 637
ROUNDDOWN, 305	UART_RXFIFO_DATA, 637
ROUNDUP, 305	UART_RXFIFO_EMPTY, 637
	UART_TXCTRL_TXEN, 637
s16, 306	UART_TXFIFO_FULL, 637
s32, 306	uart_base, 640
\$8,307	
STR, 305	uart_baudrate, 640
size_t, 307	uart_in_freq, 641
ssize_t, 307	uart_min_clk_divisor, 640
TRUE, 305	sifive-uart.h
u16, 307	sifive_uart_getc, 316
u32, 307	sifive_uart_init, 316
u8, 307	sifive_uart_putc, 316
uint16_t, 307	sifive_uart_getc
uint32_t, 307	sifive-uart.c, 638
uint8_t, 308	sifive-uart.h, 316
uintptr_t, 308	sifive_uart_init
ulong, 308	sifive-uart.c, 639
unlikely, 305	sifive-uart.h, 316
virtual_addr_t, 308	sifive_uart_putc
virtual_size_t, 308	sifive-uart.c, 639
XSTR, 305	sifive-uart.h, 316
sbi_unpriv.c	size
DEFINE_UNPRIVILEGED_LOAD_FUNCTION,	fdt_reserve_entry, 49
444	sbi_tlb_info, 64
DEFINE_UNPRIVILEGED_STORE_FUNCTION,	size_dt_strings
445	fdt_header, 47
sbi_get_insn, 445	size_dt_struct
sbi_load_u64, 446	fdt_header, 47
sbi_store_u64, 446	size_t
sbi_unpriv.h	sbi_types.h, 307
_ ·	

smp_mb	t6
riscv_barrier.h, 92	sbi_trap_regs, 71
smp_rmb	TOHOST_CMD
riscv_barrier.h, 92	htif.c, 658
smp_wmb	TRUE
riscv_barrier.h, 93	sbi types.h, 305
sp	tag
sbi_trap_regs, 70	fdt node header, 48
spin_lock	fdt property, 49
riscv_locks.c, 338	tail
riscv_locks.h, 173	sbi fifo, 54
spin_lock_check	time_delta_off
riscv_locks.c, 339	sbi_timer.c, 427
riscv_locks.h, 174	timer_event_start
spin_trylock	sbi_platform_operations, 60
riscy_locks.c, 340	timer_event_stop
riscv_locks.h, 175	sbi_platform_operations, 60
spin_unlock	timer_exit
riscv_locks.c, 341	sbi_platform_operations, 61
riscv_locks.h, 176	timer_init
spinlock_t, 71	sbi_platform_operations, 61
lock, 71	timer_value
ssize_t	sbi_platform_operations, 61
sbi_types.h, 307	tinst
start	sbi_trap_info, 65
sbi_tlb_info, 64	tlb_event
strchr	sbi_tlb.c, 439
libfdt_env.h, 624	tlb_fifo_mem_off
strcmp	sbi_tlb.c, 439
libfdt_env.h, 624	tlb_fifo_off
strcpy	sbi_tlb.c, 439
libfdt env.h, 624	tlb_ops
strlen	sbi_tlb.c, 440
libfdt env.h, 624	tlb_range_flush_limit
strnlen	sbi tlb.c, 440
libfdt_env.h, 624	tlb_sync_off
strrchr	sbi_tlb.c, 440
libfdt_env.h, 624	tmp0
sync	sbi_scratch, 63
sbi_ipi_event_ops, 55	totalsize
system_opcode_insn	fdt_header, 47
sbi_illegal_insn.c, 391	tp
system_reboot	sbi_trap_regs, 71
sbi_platform_operations, 60	trap_info_offset
system_shutdown	sbi_hart.c, 389
sbi_platform_operations, 60	truly_illegal_insn
	sbi_illegal_insn.c, 392
t0	tval
sbi_trap_regs, 70	sbi_trap_info, 65
t1	tval2
sbi_trap_regs, 70	sbi_trap_info, 65
t2	type
sbi_trap_regs, 70	sbi_tlb_info, 64
t3	351_115_1116, 64
sbi_trap_regs, 70	u16
t4	sbi_types.h, 307
sbi_trap_regs, 70	u32
_ · - ·	
15	SDL TVDAS N 307
t5 sbi_trap_regs, 71	sbi_types.h, 307 u8

sbi_types.h, 307	sifive-uart.c, 637
UART_DLL_OFFSET	UART_RXFIFO_EMPTY
uart8250.c, 642	sifive-uart.c, 637
UART_DLM_OFFSET	UART_SCR_OFFSET
uart8250.c, 642	uart8250.c, 645
UART_FCR_OFFSET	UART_THR_OFFSET
uart8250.c, 642	uart8250.c, 645
UART_IER_OFFSET	UART_TXCTRL_TXEN
uart8250.c, 642	sifive-uart.c, 637
UART_IIR_OFFSET	UART_TXFIFO_FULL
uart8250.c, 643	sifive-uart.c, 637
UART_LCR_OFFSET	UINT_MAX
uart8250.c, 643	libfdt_env.h, 624
UART LSR BRK ERROR BITS	ULL
uart8250.c, 643	sbi_const.h, 188
UART_LSR_BI	uart8250.c
uart8250.c, 643	get reg, 645
UART LSR DR	set_reg, 645
uart8250.c, 643	UART DLL OFFSET, 642
UART_LSR_FIFOE	UART_DLM_OFFSET, 642
uart8250.c, 643	UART FCR OFFSET, 642
UART_LSR_FE	UART IER OFFSET, 642
uart8250.c, 643	UART_IIR_OFFSET, 643
UART LSR OFFSET	UART LCR OFFSET, 643
uart8250.c, 644	UART_LSR_BRK_ERROR_BITS, 643
UART_LSR_OE	UART_LSR_BI, 643
	UART LSR DR, 643
uart8250.c, 643	:
UART_LSR_PE	UART_LSR_FIFOE, 643
uart8250.c, 644	UART_LSR_FE, 643
UART_LSR_TEMT	UART_LSR_OFFSET, 644
uart8250.c, 644	UART_LSR_OE, 643
UART_LSR_THRE	UART_LSR_PE, 644
uart8250.c, 644	UART_LSR_TEMT, 644
UART_MCR_OFFSET	UART_LSR_THRE, 644
uart8250.c, 644	UART_MCR_OFFSET, 644
UART_MDR1_OFFSET	UART_MDR1_OFFSET, 644
uart8250.c, 644	UART_MSR_OFFSET, 644
UART_MSR_OFFSET	UART_RBR_OFFSET, 644
uart8250.c, 644	UART_SCR_OFFSET, 645
UART_RBR_OFFSET	UART_THR_OFFSET, 645
uart8250.c, 644	uart8250_base, 647
UART_REG_DIV	uart8250_baudrate, 647
sifive-uart.c, 636	uart8250_getc, 646
UART_REG_IE	uart8250_in_freq, 647
sifive-uart.c, 636	uart8250_init, 646
UART_REG_IP	uart8250_putc, 647
sifive-uart.c, 636	uart8250_reg_shift, 648
UART_REG_RXCTRL	uart8250_reg_width, 648
sifive-uart.c, 636	uart8250.h
UART_REG_RXFIFO	uart8250_getc, 318
sifive-uart.c, 637	uart8250_init, 318
UART_REG_TXCTRL	uart8250_putc, 319
sifive-uart.c, 637	uart8250_base
UART_REG_TXFIFO	uart8250.c, 647
sifive-uart.c, 637	uart8250_baudrate
UART_RXCTRL_RXEN	uart8250.c, 647
sifive-uart.c, 637	uart8250_getc
UART_RXFIFO_DATA	uart8250.c, 646
	,

uart8250.h, 318	sbi_scratch, 63
uart8250_in_freq	wfi
uart8250.c, 647	riscv_asm.h, 81
uart8250_init	wmb
uart8250.c, 646	riscv_barrier.h, 93
uart8250.h, 318	writeb
uart8250_putc	riscv_io.h, 169
uart8250.c, 647	writeb_relaxed
uart8250.h, 319	riscv_io.h, 169
uart8250_reg_shift	writel
uart8250.c, 648	riscv_io.h, 169
uart8250_reg_width	writel_relaxed
uart8250.c, 648	riscv_io.h, 169
uart base	writeq
sifive-uart.c, 640	riscv_io.h, 169
uart baudrate	writeg relaxed
sifive-uart.c, 640	riscv_io.h, 170
uart_in_freq	writew
sifive-uart.c, 641	riscv_io.h, 170
uart_min_clk_divisor	writew relaxed
sifive-uart.c, 640	riscv io.h, 170
uint16 t	,
sbi_types.h, 307	XSTR
uint32 t	sbi_types.h, 305
sbi_types.h, 307	xchg
uint8 t	riscv_atomic.c, 333
sbi_types.h, 308	_ ,
uintptr_t	zero
sbi_types.h, 308	sbi_trap_regs, 71
UL	
sbi_const.h, 188	
ulong	
sbi_types.h, 308	
unlikely	
sbi_types.h, 305	
update	
sbi_ipi_event_ops, 55	
SDI_IpI_everit_ops, 33	
va arg	
sbi_console.c, 344	
va_end	
sbi console.c, 344	
va_list	
sbi_console.c, 345	
va start	
va_start	
sbi_console.c, 344	
sbi_console.c, 344 vendor_ext_check	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61 vendor_ext_provider	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61 vendor_ext_provider sbi_platform_operations, 61 version	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61 vendor_ext_provider sbi_platform_operations, 61 version fdt_header, 47	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61 vendor_ext_provider sbi_platform_operations, 61 version fdt_header, 47 fw_dynamic_info, 51	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61 vendor_ext_provider sbi_platform_operations, 61 version fdt_header, 47 fw_dynamic_info, 51 virtual_addr_t	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61 vendor_ext_provider sbi_platform_operations, 61 version fdt_header, 47 fw_dynamic_info, 51 virtual_addr_t sbi_types.h, 308	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61 vendor_ext_provider sbi_platform_operations, 61 version fdt_header, 47 fw_dynamic_info, 51 virtual_addr_t sbi_types.h, 308 virtual_size_t	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61 vendor_ext_provider sbi_platform_operations, 61 version fdt_header, 47 fw_dynamic_info, 51 virtual_addr_t sbi_types.h, 308	
sbi_console.c, 344 vendor_ext_check sbi_platform_operations, 61 vendor_ext_provider sbi_platform_operations, 61 version fdt_header, 47 fw_dynamic_info, 51 virtual_addr_t sbi_types.h, 308 virtual_size_t	