

Cypress[®] Low Level Driver User Guide

Release 15.2.1

Doc. # 002-00329 Rev. *E

Cypress Semiconductor 198 Champion Court San Jose, CA 95134-1709

Phone (USA): 800.858.1810 Phone (Intnl): +1.408.943.2600

www.cypress.com



Copyrights

© Cypress Semiconductor Corporation, 2010-2015. The information contained herein is subject to change without notice. Cypress Semiconductor Corporation assumes no responsibility for the use of any circuitry other than circuitry embodied in a Cypress product. Nor does it convey or imply any license under patent or other rights. Cypress products are not warranted nor intended to be used for medical, life support, life saving, critical control or safety applications, unless pursuant to an express written agreement with Cypress. Furthermore, Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress products in life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

Any Source Code (software and/or firmware) is owned by Cypress Semiconductor Corporation (Cypress) and is protected by and subject to worldwide patent protection (United States and foreign), United States copyright laws and international treaty provisions. Cypress hereby grants to licensee a personal, non-exclusive, non-transferable license to copy, use, modify, create derivative works of, and compile the Cypress Source Code and derivative works for the sole purpose of creating custom software and or firmware in support of licensee product to be used only in conjunction with a Cypress integrated circuit as specified in the applicable agreement. Any reproduction, modification, translation, compilation, or representation of this Source Code except as specified above is prohibited without the express written permission of Cypress.

Disclaimer: CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Cypress reserves the right to make changes without further notice to the materials described herein. Cypress does not assume any liability arising out of the application or use of any product or circuit described herein. Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress' product in a life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

Use may be limited by and subject to the applicable Cypress software license agreement.

Cypress®, Spansion®, the Spansion logo, MirrorBit®, MirrorBit® Eclipse™, ORNAND™, HyperBus™, HyperFlash™ and combinations thereof, are trademarks and registered trademarks of Cypress Semiconductor Corporation. All other products and company names mentioned in this document may be the trademarks of their respective holders.

Purchase of I^2C components from Cypress or one of its sublicensed Associated Companies conveys a license under the Philips I^2C Patent Rights to use these components in an I^2C system, provided that the system conforms to the I^2C Standard Specification as defined by Philips. As from October 1st, 2006 Philips Semiconductors has a new trade name - NXP Semiconductors.

Flash Code Protection

Cypress products meet the specifications contained in their particular Cypress Datasheets. Cypress believes that its family of products is one of the most secure families of its kind on the market today, regardless of how they are used. There may be methods, unknown to Cypress, that can breach the code protection features. Any of these methods, to our knowledge, would be dishonest and possibly illegal. Neither Cypress nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Cypress is willing to work with the customer who is concerned about the integrity of their code. Code protection is constantly evolving. We at Cypress are committed to continuously improving the code protection features of our products.

Contents



1.	Introduction	4
1.1 1.2	Files	
2.	API Specification	6
2.1	Nomenclature, Arguments, and Typedefs6	
2.2	Arguments7	
2.3	Typdefs	
2.4	Common APIs8	
2.5	CFI Query APIs24	
2.6	Autoselect APIs	
2.7	Unlock Bypass APIs27	
2.8		
2.9	Miscellaneous APIs47	
2.10		
2.1		
2.12		
2.13	3 Interrupt APIs52	
2.14	3	
2.15	5 Evaluate Erase Status APIs55	
2.16		
2.17	7 Continuity Check APIs59	

1. Introduction



The Low Level Driver (LLD) software from Cypress is an API that provides the most basic set of functions required to communicate with a Cypress flash memory device. In most cases, there is a one to one correspondence between commands listed in the data sheet and the LLD Commands. Very little customization is necessary to make the LLD work in your system. The integration of the LLD into your system will greatly reduce your flash driver development time.

This document describes the general Cypress flash device functionalities. Not all functions are applicable to your device. Please refer to the device data sheet for applicable functions.

1.1 Files

The LLD consists of several folders for each flash device family, e.g., \S29GLxxxS\S29ALxxxj\S29ALxxxD. Each folder includes three files as follows:

- Ild_xxx.c The 'xxx' is the flash device family name, e.g., Ild_S29GLxxxS.c. This file contains the Common Commands. You should not need to change this file.
- xxx.h The 'xxx' is the flash device family name, e.g., S29GLxxxs.h. This file contains the external prototypes and the command macros. Include this file wherever you use LLD functions. You should not need to change this file.
- Ild_target_specific.h This file requires changes to work in your system.

We provide the trace.c / trace.h modules that allow you to enable the software traces, which helps a lot during debug phases.

1.2 Making the LLD Work in Your Environment

The LLD was written to support various architectures.

The file Ild_target_specific.h does require modification in order to work in your environment.

In Ild_target_specific.h:

- 1. Select the include header file for the device that you are using. For example, if the device that you are using is S29GL512S, then select S29GLxxxS.h header file.
- Define the LLD flash chip configuration by setting the LLD_CONFIGURATION to a value that matches your system. For example, if you are using two WS256Ns (interleaved), then set the LLD_CONFIGURATION to X16_AS_X32.

```
#define LLD_CONFIGURATION_X16_AS_X16  /* no-interleaving, a single x16 device in x16 mode */
#define LLD_CONFIGURATION_X8X16_AS_X16  /* no-interleaving, a single x8/x16 device in x16 mode */
#define LLD_CONFIGURATION_X8X16_AS_X8  /* no-interleaving, a single x8/x16 device in x8 mode */
#define LLD_CONFIGURATION_X16_AS_X32  /* two x16 devices interleaved to form x32 */
#define LLD_CONFIGURATION_X8X16_AS_X32  /* two x8/x16 devices interleaved to form x32 */
#define LLD_CONFIGURATION_X8_AS_X8  /* no-interleaving, a single x8 device in x8 mode
#define LLD_CONFIGURATION_X8_AS_X32  /* special case when four X8X16 devices in X8 mode interleaving to form X32 */
#define LLD_CONFIGURATION_X8_AS_X16  /* special case when two X8X16 devices in X8 mode interleaving to form X16 */
```



#define LLD CONFIGURATION X32 AS X32 /* no-interleaving, a single x32 device in x32 mode */

- 3. Define how the LLD will do memory reads and writes in your system. Define the macros FLASH_RD and FLASH_WR. The default macro should work for most systems.
- 4. The DelayMicroseconds() functions in Ild_xxx.c and are based on the macro DELAY_1μs. If you choose to use the default Ild_xxx.c delay functions, put a value in DELAY_1μs that will give a one-microsecond delay.
- 5. Define the macro PAUSE_BETWEEN_ERASE_SUSPENDS if you are using the erase suspends in your system and the time between suspends is less that 10 milliseconds and the total number of erase suspends can exceed 5000.

2. API Specification



2.1 Nomenclature, Arguments, and Typedefs

Bank

A bank (flash bank) is like a separate device. Some Cypress devices have multiple banks, thus allowing for simultaneous read (in one bank), while programming (in another bank).

Cascade

Cascade is a term used to describe a multiple flash configuration where the additional flash devices are used to increase the number of addressable locations.

Command (Cmd)

Command refers to the software implementation of a specific data sheet command.

DYB

Dynamic protection Bit. Volatile protection bit for a sector.

Interleaved

Flash is said to be interleaved when identical multiple devices are used to match the data bus size of a processor. For example, two 16-bit devices are combined to match a 32-bit system bus. On interleaved flash, some API will be executed on all multiple devices, e.g. API lld ChipEraseOp() will erase all multiple devices.

LLD

Low Level Driver. The low level driver is the most basic set of flash functions.

Operation (Op)

An operation is defined as one or more commands combined to provide a more complete capability.

OTP

One Time Programmable. A memory area that can be programmed once and cannot be erased.

Page

The largest programmable unit for Write Buffered Programming. Pages are located on boundaries determined by the size of the page. For devices with 32 word write buffers, the page size is 32 words. In this case, pages start at addresses in which the lower five address bits are zero. Write Buffered Programming can only write to locations within a page.

PPB

Persistent Protection Bit. A non-volatile bit used to protect a sector or a sector group.

Word

Word is used to describe the smallest accessible unit of flash in your system. In a system with a single 16-bit flash, a word would be 16 bits (two bytes). In a system with four interleaved 8 bit flash devices, a word would be 32 bits (four bytes).



2.2 Arguments

base addr

The base_addr is the starting address of the bank/device being manipulated.

offset

Offset is a measure of distance in words from the beginning of the device. For command cycles defined in the data sheet, it correlates to the "Addr" field.

2.3 Typdefs

ADDRESS

A variable type used in the code to hold addresses and offsets. Defined in xxx.h.

DEVSTATUS

A variable type used in the code to describe the flash status after an API executed. It is defined in xxx.h. For example, if the return value of API 'lld_ProgramOp()' is 'DEV_NOT_BUSY', it means flash device return status is 'not busy' and program completed without error.

typedef enum {

```
DEV_STATUS_UNKNOWN = 0,
```

DEV_NOT_BUSY,

DEV_BUSY,

DEV_EXCEEDED_TIME_LIMITS,

DEV SUSPEND.

DEV_WRITE_BUFFER_ABORT,

DEV_STATUS_GET_PROBLEM,

DEV_VERIFY_ERROR,

DEV_BYTES_PER_OP_WRONG,

DEV_SECTOR_LOCK,

DEV_PROGRAM_SUSPEND,

DEV_PROGRAM_SUSPEND_ERROR,

DEV_ERASE_SUSPEND,

DEV_ERASE_SUSPEND_ERROR,

DEV_BUSY_IN_OTHER_BANK,

DEV_CONTINUITY_CHECK_PATTERN_ERROR,

 ${\tt DEV_CONTINUITY_CHECK_NO_PATTERN_ERROR, DEV_CONTINUITY_CHECK_PATTERN_DETECTED}$

} DEVSTATUS;

FLASHDATA

A variable type used in the code to hold the smallest unit of data in your system. Its size is determined by the macro LLD_CONFIGURATION (in Ild_target_specific.h. FLASHDATA is defined in xxx.h).

POLLING TYPE

POLLING_TYPE is a type of variable used to identify the operation to the polling routine.

typedef enum

{



LLD_P_POLL_PGM = 1,
LLD_P_POLL_WRT_BUF_PGM,
LLD_P_POLL_SEC_ERS,
LLD_P_POLL_CHIP_ERS,
LLD_P_POLL_RESUME
LLD_P_POLL_BLANK
}POLLING_TYPE;

2.4 Common APIs

Notice some of the APIs listed below share the same names, but with different parameters. For instance, Ild_GetDeviceID() has two forms of parameter list. The first one requires a base address while the second one needs to pass both a base address and offset address. To decide which form of APIs to use, the users need to refer to the data sheet of the specific device or related documents for more details.

2.4.1 Basic Operations

The Command API is a set of functions common to all Cypress flash devices. As we mentioned earlier, there is basically a one to one correlation between Common API functions and the commands listed in the flash data sheet. This API consists of a set of basic functions (Basic Operations) and a set of building blocks (Basic Commands).

The Basic Operations are a set of functions that provide a level of operation one step above the Basic Commands. The operation performs the desired function and poll for completion. The return value is used to determine the status of the operation.

Most of the function names of the Basic Operations end with "Op".

Note: In systems that cannot wait for programming or erasing to finish, you will need to either implement another solution or develop non-blocking code based on our Basic Commands. In LLD, two support functions, DelayMilliseconds() and DelayMicroseconds(), have been implemented as examples. Users need to re-examine or re-implement the functions based on their own particular platforms so more accurate time delay can be achieved.

2.4.1.1 IId_GetVersion

Description:

This command is used to return LLD version number.

Returns: Version number returned in given array.

Parameters:

Name	Туре	Description
versionStr[]	LLD_CHAR *	Empty char array for receiving LLD version number.

Behavior:

Note: The size of the given char array has to be at least 9 in order to avoid buffer overflow.

Related Commands: n/a

Example Code:

```
LLD_ChAR versionStr[9];
lld_GetVersion(versionStr);
printf(" LLD Release Version: %s", versionStr);
```

2.4.1.2 IId Poll – Using DQ Toggling



This function is used to poll the status of the flash after program and erase operations. In the event of a device error, this function will record the error, reset the flash (software reset) and return the status to the caller.

Returns: DEVSTATUS

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
Offset	ADDRESS	Offset to the location being manipulated.
exp_data_ptr	FLASHDATA *	A pointer to a variable containing the expected data.
act_data_ptr	FLASHDATA *	A pointer to a variable to store the actual data.
polling_type	POLLING_TYPE	An indication of the type of operation being performed.

Behavior:

This function will continue to poll until the operation completes or an error is detected.

Related Commands: Ild_StatusGet

Example Code:

2.4.1.3 IId_Poll – Using Status Register

Description:

This function is used to poll the status of the flash after program and erase operations. It will return the value of the status register. The caller routine need to check the status register bit to determine the operation result is succeed or failed.

Returns: FLASHDATA

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
Offset	ADDRESS	Offset to the location being manipulated.

Behavior:

This function will continue to poll until the operation completes or an error is detected.

Related Commands:

Example Code:

```
lld_ProgramBufferToFlashCmd(base_addr, offset);
status_reg = lld_Poll(base_addr, offset);
return(status_reg);
```

2.4.1.4 IId_StatusGetReg

Description:

This function writes the status register read command sequence to flash and reads the current value of the status register.

Returns: value of status register



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	Offset to the location being manipulated.

Behavior:

n/a

Related Commands: Ild_StatusGetReg

Example Code:

```
status_reg = lld_StatusGetReg (base_addr, offset);
```

2.4.1.5 IId_StatusGet

Description:

Unlike Ild_Poll, Ild_StatusGet tests the status and returns immediately. This function would be a good choice in situations where non-blocking functions were required.

Returns: DEVSTATUS

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	Offset to the location being manipulated.

Behavior:

n/a

Related Commands: IId_Poll

Example Code:

```
do
{
    dev_status = lld_StatusGet(base_addr, offset);
}
while(dev_status == DEV_BUSY);
```

2.4.1.6 Ild_StatusClear (CMD1)

Description:

This function clears the status register of the flash.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_StatusGetReg

Example Code:

```
11d_StatusClear (base_addr);
```



2.4.1.7 IId_StatusClear (CMD2)

Description:

This function clears the status register of the flash.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	Offset to the location being manipulated.

Behavior:

n/a

Related Commands: Ild_StatusGetReg

Example Code:

lld_StatusClear (base_addr, offset);

2.4.1.8 IId_ProgramOp

Description:

This function programs a single word in flash and poll the status for completion. This API is implemented by Ild_WriteBufferProgramOp() and with less arguments. If user want to program multiple words in one program sequence, please use Ild_WriteBufferProgramOp() for better performance.

Returns: DEVSTATUS

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index into the flash of the location to program.
write_data	FLASHDATA	The value to program into flash.

Behavior:

If return status of this function is not 'DEV_NOT_BUSY', it means program process failed. Under this condition, device must be reset to return to read array mode. Program suspend will not work with this function, since this function will not return until the process is finished. Returns the device to read array mode.

Related Commands: Ild_ProgramCmd, Ild_Poll

Example Code:

```
status = lld_ProgramOp(addr, offset, write_data);
printf("status = %s\n", get status str(status));
```

2.4.1.9 IId_WriteBufferProgramOp

Description:

This function programs words in the specified flash page and polls status for completion.

Returns: DEVSTATUS

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being programmed.
offset	ADDRESS	An index into the flash page.



Name	Туре	Description
word_count	WORDCOUNT	Number of words (FLASHDATA elements) to program.
data_buf	FLASHDATA *	Pointer to the data to program to flash.

Behavior:

You must be familiar enough with your platform to know what the page boundaries and page sizes are for this function. Page sizes are based on the maximum number of words that can be written in Write Buffered Programming (check the data sheet) and based on your architecture's flash interleaving (check with the designer/schematics).

User can check the return status of this function to get program result.

DEV NOT BUSY — program process is completed and no error

DEV_SECTOR_LOCK — the sector which program address located is locked and cannot be programmed

DEV_PROGRAM_ERROR — program process is failed

Restrictions: Each Write Buffered Programming operation can only write data within a single page and can only write a maximum of LLD_BUFFER_SIZE words.

Program suspend will not work with this function, since this function will not return until the process is finished.

Related Commands: Ild WriteToBufferCmd, Ild ProgramBufferToFlashCmd

Example Code:

2.4.1.10 IId_ChipEraseOp

Description:

This function erases the entire chip and polls for completion. In the case of interleaved devices, all are erased.

Returns: DEVSTATUS

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be erased.

Behavior:

Returns the device to read array mode.

Note: This command takes a long time (minutes) to complete!

Related Commands: Ild_ChipEraseCmd, Ild_Poll

Example Code:

```
status = lld_ChipEraseOp(addr);
printf("status = %s\n", get_status_str(status));
```

2.4.1.11 IId_SectorEraseOp

Description:

This command erases the specified sector and waits for the process to end.

Returns: DEVSTATUS



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being erased.
Offset	ADDRESS	An index into the flash sector to be erased.

Behavior:

This command takes some time to complete (seconds).

Related Commands: Ild_SectorEraseCmd, Ild_Poll

Example Code:

```
status = lld_SectorEraseOp(addr, offset);
printf("status = %s\n", get_status_str(status));
```

2.4.1.12 **IId_ReadOp**

Description:

This function reads the specified word.

Since the flash is usually memory mapped, you can read it without any special commands (its just memory). However, by funneling all the reads through this function a more consistent code base is developed. Also, some higher-level Cypress layers may require it.

Returns: FLASHDATA (Word read)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the bank/device being read.
offset	ADDRESS	An index to the location to be read.

Behavior:

No special behavior.

Related Commands: n/a

Example Code:

```
data_read = lld_ReadOp(addr, offset);
printf("%8.8X\n", data read);
```

2.4.1.13 IId_PageReadOp

Description:

This function reads multiple words within one operation.

The read count is defined by flash device page size. Please refer to device spec for more detail.

Returns: NA Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the bank/device being read.
offset	ADDRESS	An index to the location to be read.
read_buf	FLASHDATA *	The read data buffer
cnt	FLASHDATA	The read byte/word count

Behavior:



No special behavior.

Related Commands: n/a

Example Code:

```
lld_PageReadOp(base_addr, offset, read_buf, cnt);
for (i=0;i<cnt;i++)
  printf("%8.8X\n", data_buf[i]);</pre>
```

2.4.1.14 IId_EraseSuspendOp (CMD1)

Description:

This function suspends the erase operation. The erase resume command will resume the erase operation.

Returns: DEVSTATUS

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be erased.

Behavior:

The device will be in erase suspend mode.

Related Commands: Ild_EraseSuspendCmd, Ild_EraseResumeCmd, Ild_Poll

Example Code:

```
status = lld_EraseSuspendOp(base_addr);
printf("status = %s\n", get status str(status));
```

2.4.1.15 IId EraseSuspendOp (CMD2)

Description:

This function suspends the erase operation. The erase resume command will resume the erase operation.

Returns: DEVSTATUS

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be erased.
offset	ADDRESS	An index to the flash sector to be suspended.

Behavior:

The device will be in erase suspend mode.

Related Commands: Ild_EraseSuspendCmd, Ild_EraseResumeCmd, Ild_Poll

Example Code:

```
status = lld_EraseSuspendOp( base_addr, offset);
printf ( "status = %s\n", get_status_str(status) );
```

2.4.1.16 IId_ProgramSuspendOp (CMD1)

Description:

This function suspends the program operation. The program resume command will resume the program operation.

Returns: DEVSTATUS



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be suspended.

Behavior:

The device will be in program suspend mode.

Related Commands: Ild_ProgramSuspendCmd, Ild_ProgramResumeCmd, Ild_Poll

Example Code:

```
status = lld_ProgramSuspendOp(base_addr);
printf("status = %s\n", get_status_str(status));
```

2.4.1.17 IId_ProgramSuspendOp (CMD2)

Description:

This function suspends the program operation. The program resume command will resume the program operation.

Returns: DEVSTATUS

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be checked.
offset	ADDRESS	An index to the flash sector to be suspended.

Behavior:

The device will be in program suspend mode.

Related Commands: Ild_ProgramSuspendCmd, Ild_ProgramResumeCmd, Ild_Poll

Example Code:

```
status = lld_ProgramSuspendOp( base_addr, offset);
printf ( "status = %s\n", get status str(status) );
```

2.4.1.18 IId_BlankCheckOp

Description:

This function checks the if specified sector is blank. This function is not supported on all flash devices. Please refer flash device data sheet before using this function.

Returns: DEVSTATUS (DEV_ERASE_ERROR = no blank; DEV_NOT_BUSY = blank)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being erased.
offset	ADDRESS	An index to the flash sector to be checked.

Behavior:

This command takes some time to complete.

Related Commands: Ild_SectorEraseCmd, Ild_Poll

Example Code:

```
status = lld_BlankCheckOp(base_addr, offset);
printf("status = %s\n", qet status str(status));
```



2.4.1.19 IId_memcpy

Description:

The Ild_memcpy function was added to simplify Write Buffer Programming. It is used to program memory like the Ild_WriteBufferProgramOp, but the caller does not have to understand flash page sizes, boundaries, etc.

Returns: DEVSTATUS

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being programmed.
Offset	ADDRESS	An index into the flash of the first location to be programmed.
word_cnt	WORDCOUNT	Number of words to program.
data_buf	FLASHDATA *	The location of the source data.

Behavior:

The device is put into read array mode when finished. This can take a long time when there is a great deal of data. This command cannot span banks/devices.

Related Commands: Ild_WriteBufferProgramOp

Example Code:

```
status = lld_memcpy(addr, offset, word_count, source);
printf("status = %s\n", get_status_str(status));
```

2.4.1.20 IId_GetDeviceId

Description:

This function reads the device ID from CFI region.

Returns: unsigned int deviceID

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being read.

Behavior:

No special behavior.

Related Commands: n/a

Example Code:

```
data_read = lld_GetDeviceId(base_addr );
  printf("%8.8X\n", data read);
```

2.4.1.21 IId GetDeviceId (Device with Address Space Overlay Mode)

Description:

This function reads the device ID from CFI region.

Returns: unsigned int deviceID

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being read.
offset	ADDRESS	Specify sector offset for ASO (Address Space Overlay).

Behavior:



No special behavior.

Related Commands: n/a

Example Code:

```
data_read = lld_GetDeviceId(base_addr, offset);
  printf("%8.8X\n", data_read);
```

2.4.2 Basic Commands

2.4.2.1 IId ResetCmd

Description:

This command is used to return the flash to the read array mode. It is normally not necessary after programming or erase, since the flash returns to read array mode automatically when there are no problems. However, if a program or erase operation encounters an error, it will be necessary to issue an Ild_ResetCmd to return the device to read array mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being reset.

Behavior:

Note: The flash Reset command, implemented by Ild_ResetCmd, does not invoke a hardware reset of the flash.

Related Commands: n/a

Example Code:

```
FLASH_WR(base_addr, LLD_UNLOCK_ADDR1, NOR_CFI_QUERY_CMD); /*CFI mode*/
data = FLASH_RD(base_addr, offset); /* Read CFI data */
lld_ResetCmd(base_addr); /* return flash to read array mode */
return(data);
```

2.4.2.2 IId ProgramCmd

Description:

This command is used to program a single word.

Note: On devices that support Write Buffer Programming, you are expected to use Write Buffer Programming. It is possible that future Cypress flash devices will not support the Program command. If you are developing code to run on future parts AND the current part supports Write Buffer Programming, you should program the flash with the Write Buffer Program commands.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being programmed.
offset	ADDRESS	An index into the flash that correlates to the flash array element to be programmed.
pgm_data_ptr	FLASHDATA *	A pointer to the data to be used for programming.

Behavior:

When issued, this command will begin the programming process. The flash will no longer be in read array mode during programming. Typically, this command is followed by a status polling routine to determine the state of the flash.

Related Commands: Ild Poll, Ild StatusGet

Example Code:



lld ProgramCmd(base addr, offset, &write data);

2.4.2.3 IId_WriteToBufferCmd

Description:

This command is used to start the Write Buffer Program sequence. It must be followed by other commands to perform Write Buffer Programming.

Note: Write Buffer Programming is faster than the legacy Ild_ProgramCmd programming method, and it is the recommended way to program flash in devices that support this feature.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being programmed.
offset	ADDRESS	An index into the flash that correlates to the Addr. field in the Command Table of the data sheet.

Behavior:

Write Buffer Programming is more complicated to use than the older Ild_ProgramCmd. Make sure you read the data sheet section on Write Buffer Programming before coding. The Ild_WriteBufferProgramOp or the Ild_memcpy might be easier, since they are complete implementations of Write Buffer Programming.

Restrictions: Each Write Buffer Programming operation can only write data within a single page and can only write a maximum of LLD_BUFFER_SIZE words.

 $\textbf{Related Commands:} \ \textbf{Ild_ProgramBufferToFlashCmd}, \ \textbf{Ild_WriteBufferProgramOp}, \ \textbf{Ild_memcpy}, \ \textbf{Ild_Poll}, \ \textbf{Ild_StatusGet}$

Example Code:

```
/* Issue Load Write Buffer Command Sequence */
    lld_WriteToBufferCmd(base_addr, offset);

/* Write # of locations to program */
    wcount *= LLD_DEV_MULTIPLIER;

FLASH WR(base addr, offset, wcount);
```

2.4.2.4 IId ProgramBufferToFlashCmd

Description:

This command is used in conjunction with the Ild_WriteToBufferCmd. It is the last command issued in the Write Buffer Programming sequence.

Returns: n/a

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being programmed.
offset	ADDRESS	An index into the flash that correlates to the Addr. field in the Command Table of the data sheet.

Behavior:

The device will no longer be in read array mode during the execution of Write Buffered Programming.

Related Commands: Ild WriteToBufferCmd, Ild WriteBufferProgramOp, Ild memcpy, Ild Poll, Ild StatusGet

Example Code:



```
/* Issue Program Buffer to Flash command */
lld ProgramBufferToFlashCmd(base addr, last loaded addr);
```

2.4.2.5 IId_WriteBufferAbortResetCmd

Description:

This command is used to reset the device to read array mode after an error causes a write buffer abort condition. See your device data sheet for a description of what conditions will cause the write buffer abort condition.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being reset.

Behavior:

n/a

 $\textbf{Related Commands:} \ \textbf{Ild_ProgramBufferToFlashCmd}, \ \textbf{Ild_WriteBufferProgramOp}, \ \textbf{Ild_memcpy}, \ \textbf{Ild_Poll}, \ \textbf{Ild_StatusGet}$

Example Code:

```
if(dev_status != DEV_NOT_BUSY)
{
    if(dev_status == DEV_WRITE_BUFFER_ABORT)
    {
        lld_WriteBufferAbortResetCmd(base_addr);
    }
}
```

2.4.2.6 IId_ChipEraseCmd

Description:

The command begins the Chip Erase process. This can take quite a while. During this process the device is not in read array mode.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being erased.

Behavior:

The device is not in read array mode while the erase is in progress.

Related Commands: Ild_SectorEraseCmd, Ild_Poll, IldStatusGet

Example Code:

```
11d_ChipEraseCmd(base_addr);
```

2.4.2.7 IId_SectorEraseCmd

Description:

This command begins a sector erase process. In terms of CPU cycles, this command will take a little time. During that time, the device will not be in read array mode.



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being erased.
offset	ADDRESS	An index into the sector to be erased.

Behavior:

The flash will not be in read array mode during this process. This process can be suspended.

Related Commands: Ild_EraseSuspendCmd, Ild_EraseResumeCmd, Ild_Poll, Ild_StatusGet, Ild_SectorEraseOp

Example Code:

1ld_SectorEraseCmd(base_addr, offset);

2.4.2.8 IId_EraseSuspendCmd (CMD1)

Description:

This command is used to suspend the erase process. It is useful when reading/programming other sectors is necessary.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being suspended.
offset	ADDRESS	An index into the sector being erased.

Behavior:

A DQ polling is inserted before issue suspend command for GL-P device.

Related Commands: Ild_EraseResumeCmd, Ild_SectorEraseCmd

Example Code:

1ld_EraseSuspendCmd(base_addr, offset);

2.4.2.9 IId_EraseSuspendCmd (CMD2)

Description:

This command is used to suspend the erase process. It is useful when reading/programming other sectors is necessary.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being suspended.

Behavior:

n/a

Related Commands: Ild_EraseResumeCmd, Ild_SectorEraseCmd

Example Code:

11d_EraseSuspendCmd(base_addr);

2.4.2.10 IId_EraseResumeCmd (CMD1)

Description:

This command resumes the erase process on a suspended sector.



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index into the sector where the erase needs to be restarted.

Behavior:

The device will not be in read array mode any longer.

Related Commands: Ild_EraseSuspendCmd, Ild_SectorEraseCmd

Example Code:

1ld_EraseSuspendCmd(base_addr, offset);

2.4.2.11 IId_EraseResumeCmd (CMD2)

Description:

This command resumes the erase process on a suspended sector.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

The device will not be in read array mode any longer.

Related Commands: Ild_EraseSuspendCmd, Ild_SectorEraseCmd

Example Code:

lld_EraseSuspendCmd(base_addr);

2.4.2.12 Ild_ProgramSuspendCmd (CMD1)

Description:

This command is used to suspend the programming process. It is useful when reading other sectors is necessary.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being suspended.
offset	ADDRESS	An index to the location being programmed.

Behavior:

n/a

Related Commands: Ild_ProgramResumeCmd, Ild_ProgramBufferToFlashCmd

Example Code:

11d ProgramSuspendCmd(base addr, offset);

2.4.2.13 IId_ProgramSuspendCmd (CMD2)



This command is used to suspend the programming process. It is useful when reading/programming other sectors is necessary.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being suspended.

Behavior:

n/a

Related Commands: Ild_ProgramResumeCmd, Ild_ProgramBufferToFlashCmd

Example Code:

11d ProgramSuspendCmd(base addr);

2.4.2.14 IId ProgramResumeCmd (CMD1)

Description:

This command resumes the programming process on the suspended location.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index into the location where the programming was occurring.

Behavior:

The device will not be in read array mode any longer.

 $\textbf{Related Commands:} \ \mathsf{IId}_\mathsf{ProgramSuspendCmd}, \ \mathsf{IId}_\mathsf{ProgramBufferToFlashCmd}$

Example Code:

11d ProgramSuspendCmd(base addr, offset);

2.4.2.15 IId_ProgramResumeCmd (CMD2)

Description:

This command resumes the program process on the suspended location.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

The device will not be in read array mode any longer.

Related Commands: Ild_ProgramSuspendCmd, Ild_ProgramBufferToFlashCmd

Example Code:

11d_ProgramSuspendCmd(base_addr);

2.4.2.16 IId_StatusRegReadCmd (CMD1)



This command reads the current value of the status register.

Returns: value of status register

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a.

Related Commands: Ild_StatusRegClearCmd

Example Code:

status_reg = lld_StatusRegReadCmd(base_addr);

2.4.2.17 IId_StatusRegReadCmd (CMD2)

Description:

This command reads the current value of the status register.

Returns: value of status register

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	The status read corresponds to the location specified by the offset.

Behavior:

n/a.

Related Commands: Ild_StatusRegClearCmd

Example Code:

status reg = 11d StatusRegReadCmd(base addr, offset);

2.4.2.18 IId_StatusRegClearCmd (CMD1)

Description:

This command clears the current value of the status register.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a.

Related Commands: Ild_StatusRegReadCmd

Example Code:

status = lld_ProgramSuspendOp(base_addr, offset);
lld_StatusRegClearCmd(base_addr);

2.4.2.19 IId_StatusRegClearCmd (CMD2)



This command clears the current value of the status register.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	The status register is cleared for the offset specified.

Behavior:

n/a.

Related Commands: Ild_StatusRegReadCmd

Example Code:

11d_StatusRegClearCmd(base_addr, offset);

2.4.2.20 IId_BlankCheckCmd

Description:

This command checks if a sector is blank or not.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index into the location where to do blank check.

Behavior:

Blank check can only be issued while in array mode not in program or erase suspend mode. Reads to the array while in blank check mode is not allowed and will return unknown data.

Related Commands: Ild_SectorEraseCmd

Example Code:

1ld_BlankCheckCmd(base_addr, offset);

2.5 CFI Query APIs

2.5.1 CFI Query Operation

2.5.1.1 IId_ReadCfiWord

Description:

This function reads the CFI data register **Returns:** FLASHDATA (Word CFI Register)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index into the flash sector to be read.

Behavior:

n/a



Related Commands: Ild_CfiEntryCmd, Ild_CfiExitCmd

Example Code:

```
data = lld_ReadCfiWord(base_addr, offset);
  printf("%8.8X\n", data);
```

2.5.2 CFI Query Commands

2.5.2.1 IId_CfiEntryCmd

Description:

This command causes the CFI data to be available in the first sector of the specified bank.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

The first sector of the device specified in the base_addr parameter will be replaced with the CFI data. Use the Ild_CfiExitCmd to return to read array mode.

Related Commands: Ild CfiExitCmd

Example Code:

11d_CfiEntryCmd(base_addr);

2.5.2.2 IId_CfiEntryCmd

Description:

This command causes the CFI data to be available in the specified sector of the specified bank.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	Sector offset for ASO (Address Space Overlay).

Behavior:

The first sector of the device specified in the base_addr parameter will be replaced with the CFI data. Use the Ild_CfiExitCmd to return to read array mode.

Related Commands: Ild_CfiExitCmd

Example Code:

1ld_CfiEntryCmd(base_addr, offset);

2.5.2.3 Ild_CfiExitCmd

Description:

This command exits CFI mode.



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

Returns the device to read array mode.

Related Commands: Ild_CfiEntryCmd

Example Code:

11d_CfiExitCmd(base_addr);

2.6 Autoselect APIs

2.6.1 Autoselect Commands

2.6.1.1 IId_AutoselectEntryCmd

Description:

This command replaces the first sector with the Autoselect information.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

The device will no longer be in read array mode.

Related Commands: Ild_AutoselectExitCmd

Example Code:

1ld_AutoselectEntryCmd(base_addr);

2.6.1.2 IId_AutoselectEntryCmd (Device with Address Space Overlay Mode)

Description:

This command replaces the specified sector with the Autoselect information.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	Sector offset for ASO (Address Space Overlay).

Behavior:

The device will no longer be in read array mode. **Related Commands:** Ild_AutoselectExitCmd

Example Code:

11d_AutoselectEntryCmd(base_addr, offset);



2.6.1.3 IId_AutoselectExitCmd

Description:

This command returns the device/bank to read array mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

Returns the device to read array mode.

Related Commands: Ild_AutoselectEntryCmd

Example Code:

1ld_AutoselectExitCmd(base_addr);

2.7 Unlock Bypass APIs

2.7.1 Unlock Bypass Commands

2.7.1.1 IId_UnlockBypassEntryCmd

Description:

This command puts the flash state machine in a mode where it will accept minimum cycle commands.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

Use only Unlock Bypass Commands while in this mode.

Related Commands: Ild_UnlockBypassExitCmd, Ild_UnlockBypassProgramCmd

Example Code:

11d UnlockBypassEntryCmd(addr);

2.7.1.2 IId UnlockBypassProgramCmd

Description:

This command is a faster version of the Ild_ProgramCmd.

Note: Like Ild_ProgramCmd, Ild_UnlockBypassProgramCmd should not be used in systems that provide Write Buffer Programming.

Returns: n/a

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be programmed.
offset	ADDRESS	An index to the location to be programmed.
pgm_data_ptr	FLASHDATA *	Pointer to the data to program.



Behavior:

This command can only be used in Unlock Bypass mode.

Related Commands: Ild_UnlockBypassEntryCmd, Ild_UnlockBypassExitCmd

Example Code:

11d_UnlockBypassProgramCmd(addr, offset, &data);

2.7.1.3 IId_UnlockBypassResetCmd

Description:

This command returns the flash state machine to the standard (non-Unlock Bypass) mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Related Commands: Ild_UnlockBypassEntryCmd, Ild_UnlockBypassProgramCmd

Example Code:

11d UnlockBypassResetCmd(base addr);

2.7.1.4 IId_UnlockBypassWriteToBufferCmd

Description:

This command is a fast version of Write To Buffer

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	An index to the location to be programmed.
word_count	WORDCOUNT	Number of words (not bytes) to program.
data_buf	FLASHDATA*	Pointer to the data to program.

Behavior:

This command can only be used in Unlock Bypass mode.

Related Commands: Ild_UnlockBypassEntryCmd, Ild_UnlockBypassResetCmd

Example Code:

11d UnlockBypassWriteToBufferCmd(base addr, offset, word count, &data buf);

2.7.1.5 IId_UnlockBypassProgramBufferToFlashCmd

Description:

This command is a fast version of Program Buffer to Flash



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	An index to the location to be programmed.

Behavior:

This command can only be used in Unlock Bypass mode.

Related Commands: Ild_UnlockBypassEntryCmd, Ild_UnlockBypassResetCmd

Example Code:

lld_UnlockBypassProgramBufferToFlashCmd (base_addr, offset);

2.7.1.6 IId_UnlockBypassWriteToBufferAbortResetCmd

Description:

This command is a fast version of Write To Buffer Abort Reset

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

This command can only be used in Unlock Bypass mode.

Related Commands: Ild_UnlockBypassEntryCmd, Ild_UnlockBypassResetCmd

Example Code:

lld_UnlockBypassWriteToBufferAbortResetCmd (base_addr);

2.7.1.7 IId_UnlockBypassSectorEraseCmd

Description:

This command is a fast version of Sector Erase

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	An index to the location to be programmed.

Behavior:

This command can only be used in Unlock Bypass mode.

 $\textbf{Related Commands}: Ild_UnlockBypassEntryCmd, Ild_UnlockBypassResetCmd$

Example Code:

11d_UnlockBypassSectorEraseCmd (base_addr, offset);

2.7.1.8 Ild_UnlockBypassChipEraseCmd

Description:

This command is a fast version of Chip Erase



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

This command can only be used in Unlock Bypass mode.

Related Commands: Ild_UnlockBypassEntryCmd, Ild_UnlockBypassResetCmd

Example Code:

lld_UnlockBypassChipEraseCmd (base_addr);

2.7.2 Unlock Bypass Operations

2.7.2.1 Ild_UnlockBypassProgramOp

Description:

This command is a fast version of Program Op

Returns: DEVSTATUS (Program Complete, Program Error)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	An index to the location to be programmed.
write_data	FLASHDATA	The data to program.

Behavior:

This command can only be used in Unlock Bypass mode.

Related Commands: Ild_UnlockBypassEntryCmd, Ild_UnlockBypassResetCmd

Example Code:

```
lld_UnlockBypassEntryCmd(base_addr);
status = lld_ UnlockBypassProgramOp (base_addr, offset, write_data);
printf("status = %s\n", get_status_str(status));
lld UnlockBypassResetCmd(base addr);
```

2.7.2.2 IId_UnlockBypassBufferWriteProgramOp

Description:

This command is a fast version of Buffer Write Program Op

Returns: DEVSTATUS (Program Complete, Program Error)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	An index to the location to be programmed.
word_count	WORDCOUNT	Number of words (not bytes) to program.
data_buf	FLASHDATA*	Pointer to the data to program.

Behavior:

This command can only be used in Unlock Bypass mode.

Related Commands: Ild_UnlockBypassEntryCmd, Ild_UnlockBypassResetCmd



Example Code:

```
lld_UnlockBypassEntryCmd(base_addr);
status = lld UnlockBypassBufferWriteProgramOp (base addr, offset, word count, &data buf);
```

2.8 Sector Protection APIs

2.8.1 SecSi Sector Commands

Upon SecSiSectorEntryCmd, the first sector is replaced by the SecSi sector. Once in this mode, use the standard programming and reading commands.

2.8.1.1 IId_SecSiSectorEntryCmd

Description:

This command grants access to the SecSi sector.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

You should read and understand the data sheet section on the SecSi sector before writing to this OTP area.

Related Commands: Ild_SecSiSectorExitCmd

Example Code:

11d_SecSiSectorEntryCmd(addr);

2.8.1.2 IId_SecSiSectorEntryCmd (Device with Address Space Overlay Mode)

Description:

This command grants access to the SecSi sector.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	sector offset for ASO (Address Space Overlay).

Behavior:

You should read and understand the data sheet section on the SecSi sector before writing to this OTP area.

Related Commands: Ild_SecSiSectorExitCmd

Example Code:

1ld_SecSiSectorEntryCmd(base_addr, offset);

2.8.1.3 IId_SecSiSectorExitCmd

Description:

This command restores the first sector with read array data (from SecSi sector data)



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Related Commands: Ild_SecSiSectorEntryCmd

Example Code:

1ld_SecSiSectorExitCmd(base_addr);

2.8.2 Lock Register Operations

2.8.2.1 IId_LockRegBitsReadOp

Description:

This function returns the value of Lock Register. **Returns:** FLASHDATA (Lock Register Word)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Related Commands: Ild_LockRegBitsProgramCmd, Ild_LockRegEntryCmd, Ild_LockRegExitCmd

Example Code:

```
data = lld_LockRegBitsReadOp(addr);
printf("%8.8X\n", data);
```

2.8.2.2 IId_SSRLockRegBitsReadOp

Description:

This function reads the Secure Silicon Region (SSR) lock register.

Returns: FLASHDATA (Word Lock Register)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being read.
offset	ADDRESS	An index into the flash sector to be read.

Behavior:

n/a

 $\textbf{Related Commands:} \ \textbf{Ild_SSRLockRegEntryCmd}, \ \textbf{Ild_SSRLockRegExitCmd}, \ \textbf{Ild_SSRLockRegBitsProgramCmd} \\$

```
Example Code:
```

```
data = lld_SSRLockRegBitsReadOp(base_addr, offset);
printf("%8.8X\n", data);
```



2.8.2.3 IId_LockRegBitsProgramOp

Description:

This function programs the Lock Register with a value. Refer to the data sheet for bit definitions.

Returns: 0 = Operation successful: 1 = Operation failed

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
value	FLASHDATA	The Lock Register value to be programmed.

Behavior:

n/a

Related Commands: Ild_LockRegEntryCmd, Ild_LockRegBitsReadCmd, Ild_LockRegExitCmd

Example Code:

11d LockRegBitsProgramOp(addr, value);

2.8.2.4 IId_SSRLockRegBitsProgramOp

Description:

This function programs the Secure Silicon Region (SSR) lock register.

Returns: DEVSTATUS (0 = Program Completed; DEV_PROGRAM_ERROR = Program Error)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being programmed.
offset	ADDRESS	An index into the flash sector to be programmed.
write_data	FLASHDATA	The value to program into flash.

Behavior:

n/a

 $\textbf{Related Commands:} \ IId_SSRLockRegEntryCmd, \ IId_SSRLockRegExitCmd, \ IId_LockRegBitsReadCmd, \ IId_LockReadCmd, \ IId_LockReadCmd,$

Example Code:

```
status = lld_SSRLockRegBitsProgramOp(addr, offset, write_data);
printf("status = %s\n", get_status_str(status));
```

2.8.2.5 IId_PpbAllEraseOp

Description:

This function un-protects all the PPB bits for sectors/sector groups.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

All the PPB bits are erased at once.

Related Commands: Ild_PpbEntryCmd, Ild_PpbExitCmd, Ild_Poll

Example Code:



11d PpbAllEraseOp(addr);

2.8.2.6 IId_PpbProgramOp

Description:

This function sets the PPB protection for a sector/sector group. When set, the PPB Status Read will return 0 (protected), otherwise it will return 1 (unprotected).

Returns: DEVSTATUS (0 = Program Completed; -1 = Program Error)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index to the flash sector to be protected.

Behavior:

n/a

Related Commands: Ild_PpbEntryCmd, Ild_PpbExitCmd, Ild_PpbLockBitReadOp, Ild_Poll

Example Code:

```
op_status = lld_PpbProgramOp(addr, offset);
printf("%X\n", op_status);
```

2.8.2.7 IId_PpbStatusReadOp

Description:

This function reads the status of the PPB Protection Bit for the addressed sector/sector group.

Returns: FLASHDATA (0 = protected, 1 = unprotected)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index to the sector/sector group.

Behavior:

n/a

Related Commands: Ild_PpbEntryCmd, Ild_PpbExitCmd, Ild_PpbAllEraseCmd, Ild_PpbProgramCmd

Example Code:

```
data = 11d_PpbStatusReadOp(addr, offset);
  printf("%8.8X\n", data);
```

2.8.3 Lock Register Commands

2.8.3.1 IId_LockRegEntryCmd

Description:

This mode of operation is used to read and program the Lock Register Bits. Non-Lock Register commands should not be used while in this mode.



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_LockRegBitsProgramCmd, Ild_LockRegBitsReadCmd, Ild_LockRegExitCmd

Example Code:

11d_LockRegEntryCmd(addr);

2.8.3.2 IId_SSRLockRegEntryCmd (Device with Address Space Overlay Mode)

Description:

This mode of operation is used to read and program the Lock Register Bits.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
Offset	ADDRESS	sector offset for ASO (Address Space Overlay).

Behavior:

n/a

 $\textbf{Related Commands:} \quad \textbf{IId_SSRLockRegBitsProgramCmd}, \ \textbf{IId_SSRLockRegBitsReadCmd}, \ \textbf{IId_SSRLockRegExitCmd}, \ \textbf{IId_SSRLockRegExitCm$

11d_SSRLockRegEntryCmd(base_addr, offset);

2.8.3.3 IId_LockRegBitsProgramCmd

Description:

Example Code:

Programs the Lock Register with a value. Refer to the data sheet for bit definitions.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
Value	FLASHDATA	The Lock Register value to be programmed.

Behavior:

n/a

 $\textbf{Related Commands:} \hspace{0.2cm} \textbf{Ild_LockRegEntryCmd, Ild_LockRegBitsReadCmd, Ild_LockRegExitCmd} \\$

Example Code:

1ld_LockRegBitsProgramCmd(addr, value);

2.8.3.4 IId_SSRLockRegBitsProgramCmd (Device with Address Space Overlay Mode)

Description:

Programs the Lock Register with a value. Refer to the data sheet for bit definitions.



Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	sector offset for ASO (Address Space Overlay).
value	FLASHDATA	The Lock Register value to be programmed.

Behavior:

n/a

Related Commands: Ild_SSRLockRegEntryCmd, Ild_SSRLockRegBitsReadCmd, Ild_SSRLockRegExitCmd **Example Code:**

11d SSRLockRegBitsProgramCmd(base addr, offset, value);

2.8.3.5 IId_LockRegBitsReadCmd

Description:

This command returns the value of the Lock Register.

Returns: FLASHDATA (Lock Register Word)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Related Commands: Ild_LockRegBitsProgramCmd, Ild_LockRegEntryCmd, Ild_LockRegExitCmd

Example Code:

```
data = lld_LockRegBitsReadCmd(addr);
printf("%8.8X\n", data);
```

2.8.3.6 IId_SSRLockRegBitsReadCmd (Device with Address Space Overlay Mode)

Description:

This command returns the value of the Lock Register.

Returns: FLASHDATA (Lock Register Word)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	sector offset for ASO (Address Space Overlay).

Behavior:

n/a

Related Commands: Ild_SSRLockRegBitsProgramCmd, Ild_SSRLockRegEntryCmd, Ild_SSRLockRegExitCmd **Example Code:**

```
data = lld_SSRLockRegBitsReadCmd(base_addr, offset);
  printf("%8.8X\n", data);
```



2.8.3.7 IId_LockRegExitCmd

Description:

This command exits the Lock Register mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_LockRegBitsProgramCmd, Ild_LockRegBitsReadCmd, Ild_LockRegEntryCmd

Example Code:

11d_LockRegExitCmd(addr);

2.8.3.8 IId_SSRLockRegExitCmd (Device with Address Space Overlay Mode)

Description:

This command exits the SSR Lock Register mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior: n/a

Related Commands: Ild_SSRLockRegBitsProgramCmd, Ild_SSRLockRegBitsReadCmd, Ild_SSRLockRegEntryCmd,

Example Code:

11d SSRLockRegExitCmd(addr);

2.8.4 Password Protection Mode Commands

2.8.4.1 IId_PasswordProtectionEntryCmd

Description:

This command puts the state machine in Password Protection Modification mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

Only Password Protection Mode commands should be issued while in this mode.

Related Commands: Ild_PasswordProtectionProgramCmd, Ild_PasswordProtectionReadCmd, Ild_PasswordProtectionUnlockCmd, Ild_PasswordProtectionExitCmd

Example Code:

11d PasswordProtectionEntryCmd(addr);



2.8.4.2 IId_PasswordProtectionProgramCmd

Description:

This command is used to program the password once the device is in the Password Protection Modification mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	The offset of the password to write. There are four separate passwords (offsets 0 - 3).
pwd	FLASHDATA	Password word.

Behavior:

You should read the data sheet about this feature, because this is OTP memory - you only get one chance.

Related Commands: Ild_PasswordProtectionEntryCmd, Ild_PasswordProtectionReadCmd, Ild_PasswordProtectionUnlockCmd, Ild_PasswordProtectionExitCmd

Example Code:

```
lld_PasswordProtectionProgramCmd(addr, 0, pwd1);
lld_PasswordProtectionProgramCmd(addr, 1, pwd2);
lld_PasswordProtectionProgramCmd(addr, 2, pwd3);
lld_PasswordProtectionProgramCmd(addr, 3, pwd4);
```

2.8.4.3 IId_PasswordProtectionReadCmd

Description:

This function issues the read password command.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
pwd0	FLASHDATA *	A pointer to a location to store the first password word.
pwd1	FLASHDATA *	A pointer to a location to store the second password word.
pwd2	FLASHDATA *	A pointer to a location to store the third password word.
pwd3	FLASHDATA *	A pointer to a location to store the forth password word.

Behavior:

This command will not return the password after Password Protection mode is committed.

Related Commands: Ild_PasswordProtectionProgramCmd, Ild_PasswordProtectionEntryCmd, Ild_PasswordProtectionUnlockCmd, Ild_PasswordProtectionExitCmd

Example Code:

```
lld_PasswordProtectionReadCmd(addr, &pwd0, &pwd1, &pwd2, &pwd3);
printf("%8.8X %8.8X %8.8X %8.8X\n", pwd0, pwd1, pwd2, pwd3);
```

2.8.4.4 IId PasswordProtectionUnlockCmd

Description:

This command presents the password to the flash. There is no indication of success.

Returns: n/a



Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
pwd0	FLASHDATA	The first word of the password.
pwd1	FLASHDATA	The second word of the password.
pwd2	FLASHDATA	The third word of the password.
pwd3	FLASHDATA	The forth word of the password.

Behavior:

n/a

Related Commands: Ild_PasswordProtectionProgramCmd, Ild_PasswordProtectionReadCmd, Ild_PasswordProtectionEntryCmd, Ild_PasswordProtectionExitCmd

Example Code:

lld_PasswordProtectionUnlockCmd(addr, pwd0, pwd1, pwd2, pwd3);

2.8.4.5 IId_PasswordProtectionExitCmd

Description:

This command exits the Password Protection Manipulation Mode.

Returns: n/a

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

Resets the device to read array mode.

Related Commands: Ild_PasswordProtectionProgramCmd, Ild_PasswordProtectionReadCmd, Ild_PasswordProtectionUnlockCmd, Ild_PasswordProtectionEntryCmd

Example Code:

11d_PasswordProtectionExitCmd(addr);

2.8.5 PPB Commands

2.8.5.1 IId_PpbEntryCmd

Description:

This command put the flash into PPB Command Set Mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Related Commands: Ild_PpbStatusReadCmd, Ild_PpbExitCmd, Ild_PpbAllEraseCmd, Ild_PpbProgramCmd



Example Code:

11d_PpbEntryCmd(addr);

2.8.5.2 IId_PpbProgramCmd

Description:

This command sets the PPB protection for a sector/sector group. When set, the PPB Status Read will return 0 (protected), otherwise it will return 1 (unprotected).

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index to the flash sector to be protected.

Behavior:

n/a

Related Commands: Ild_PpbEntryCmd, Ild_PpbExitCmd, Ild_PpbAllEraseCmd, Ild_PpbStatusReadCmd

Example Code:

11d PpbProgramCmd(addr, offset);

2.8.5.3 IId_PpbAllEraseCmd

Description:

This command un-protects all the PPB bits for sectors/sector groups.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

All the PPB bits are erased at once.

Related Commands: Ild_PpbEntryCmd, Ild_PpbExitCmd, Ild_PpbStatusReadCmd, Ild_PpbProgramCmd

11d PpbAllEraseCmd(addr);

2.8.5.4 IId PpbStatusReadCmd

Description:

Example Code:

Reads the status of the PPB Protection Bit for the addressed sector/sector group.

Returns: FLASHDATA (0 = protected, 1 = unprotected)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index to the sector/sector group.

Behavior:

n/a



Related Commands: Ild_PpbEntryCmd, Ild_PpbExitCmd, Ild_PpbAllEraseCmd, Ild_PpbProgramCmd

Example Code:

data = lld_PpbStatusReadCmd(addr, offset);
 printf("%8.8X\n", data);

2.8.5.5 IId_PpbExitCmd

Description:

This command exits the PPB Command Set Mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Related Commands: Ild_PpbEntryCmd, Ild_PpbStatusReadCmd, Ild_PpbAllEraseCmd, Ild_PpbProgramCmd

Example Code:

11d PpbExitCmd(addr);

2.8.5.6 IId PpbSAProtectStatusCmd

Description:

This command is used to Read PPB SA Protect Status.

Returns: FLASHDATA (Word array data)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	Sector offset for ASO (Address Space Overlay).

Behavior: n/a

Related Commands: Ild_PpbEntryCmd, Ild_PpbProgramCmd, Ild_PpbAllEraseCmd,

Ild_PpbStatusReadCmd, Ild_PpbExitCmd

Example Code:

sa protect status = 11d PpbSAProtectStatusCmd (base addr, offset);

2.8.6 DYB Commands

2.8.6.1 IId_DybEntryCmd

Description:

This command enters the DYB Protection Command Set Mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.



n/a

Related Commands: Ild_DybSetCmd, Ild_DybClrCmd, Ild_DybReadCmd, Ild_DybExitCmd

Example Code:

11d_DybEntryCmd(addr);

2.8.6.2 IId_DybSetCmd

Description:

This command sets the DYB to 0 (protected).

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index to the sector to be protected.

Behavior:

n/a

Related Commands: Ild_DybEntryCmd, Ild_DybClrCmd, Ild_DybReadCmd, Ild_DybExitCmd

Example Code:

11d_DybSetCmd(addr, offset);

2.8.6.3 Ild_DybClrCmd

Description:

This command un-protects the appropriate DYB.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index to the sector to be un-protected.

Behavior:

n/a

Related Commands: Ild_DybEntryCmd, Ild_DybSetCmd, Ild_DybReadCmd, Ild_DybExitCmd

Example Code:

lld_DybClrCmd(addr, offset);

2.8.6.4 IId_DybReadCmd

Description:

This command reads the value of the sector's DYB bit.

Returns: FLASHDATA (0=protected, 1=un-protected)



Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	An index to the appropriate sector.

Behavior:

n/a

Related Commands: Ild_DybEntryCmd, Ild_DybSetCmd, Ild_DybClrCmd, Ild_DybExitCmd

Example Code:

```
data = lld_DybReadCmd(addr, offset);
  printf("%8.8X\n", data);
```

2.8.6.5 IId_DybExitCmd

Description:

This commands exits the DYB Protection Command Set Mode.

Returns: n/a

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Related Commands: Ild_DybEntryCmd, Ild_DybSetCmd, Ild_DybClrCmd, Ild_DybReadCmd

Example Code:

11d_DybExitCmd(addr);

2.8.6.6 2.8.6.6 Ild_DybSAProtectStatusCmd

Description:

This command is used to Read DYB SA Protect Status.

Returns: FLASHDATA (Word array data)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	ADDRESS	Sector offset for ASO (Address Space Overlay).

Behavior: n/a

Related Commands: Ild_DybEntryCmd, Ild_DybSetCmd, Ild_DybClrCmd, Ild_DybReadCmd,

Ild_DybExitCmd
Example Code:

sa_protect_status = lld_DybSAProtectStatusCmd (base_addr, offset);



2.8.7 PPB Lock Bit Operation

2.8.7.1 IId_PpbLockBitReadOp

Description:

This function reads the value of the PPB Lock Bit.

Returns: FLASHDATA (0=PPB Protection selected, 1=not selected)

Parameters:

	Name	Туре	Description
ĺ	base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Behavior:

n/a

Related Commands: Ild_PpbLockBitEntryCmd, Ild_PpbLockBitExitCmd

Example Code:

data = lld_PpbLockBitReadOp(addr);
 printf("%8.8X\n", data);

2.8.7.2 IId_PpbLockBitSetOp

Description:

This function sets the Flash Protection Mode to PPB Mode (as opposed to Password Protection Mode).

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Related Commands: Ild_PpbLockBitEntryCmd, Ild_PpbLockBitExitCmd, Ild_Poll

Example Code:

11d_PpbLockBitSetOp(addr);

2.8.8 PPB Lock Bit Commands

2.8.8.1 IId_PpbLockBitEntryCmd

Description:

This command enters the PPB Lock Bit Manipulation Mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.



n/a

Related Commands: Ild_PpbLockBitSetCmd, Ild_PpbLockBitReadCmd, Ild_PpbLockBitExitCmd

Example Code:

11d_PpbLockBitEntryCmd(addr);

2.8.8.2 IId_PpbLockBitSetCmd

Description:

This command sets the Flash Protection Mode to PPB Mode (as opposed to Password Protection Mode).

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

Related Commands: Ild_PpbLockBitEntryCmd, Ild_PpbLockBitReadCmd, Ild_PpbLockBitExitCmd

Example Code:

11d PpbLockBitSetCmd(addr);

2.8.8.3 IId_PpbLockBitReadCmd

Description:

This command read the value of the PPB Lock Bit.

Returns: FLASHDATA (0=PPB Protection selected, 1=not selected)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

n/a

 $\textbf{Related Commands:} \hspace{0.1in} \textbf{Ild_PpbLockBitEntryCmd}, \hspace{0.1in} \textbf{Ild_PpbLockBitExitCmd}, \hspace{0.1in} \textbf{Ild_PpbLockBitEx$

Example Code:

```
data = lld_PpbLockBitReadCmd(addr);
  printf("%8.8X\n", data);
```

2.8.8.4 IId_PpbLockBitExitCmd

Description:

This command exits the PPB Lock Bit Manipulation Mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.



n/a

Related Commands: Ild_PpbLockBitEntryCmd, Ild_PpbLockBitSetCmd, Ild_PpbLockBitReadCmd

Example Code:

11d_PpbLockBitExitCmd(addr);

2.8.9 Sector Protection Commands

2.8.9.1 IId SectorLockCmd

Description:

This command locks and protects all sectors.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.

Behavior:

All sectors will be locked for writing.

Related Commands: Ild_SectorUnlockCmd, Ild_SectorLockRangeCmd

Example Code:

11d_SectorLockCmd(base_addr;

2.8.9.2 IId_SectorUnlockCmd

Description:

This command unlocks and un-protects a sector.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
offset	FLASHDATA	An index into the location where the sector to unlock.

Behavior:

The specified sector will be unlocked for writing.

Related Commands: Ild_SectorUnlockCmd, Ild_SectorLockRangeCmd

Example Code:

1ld_SectorUnlockCmd(base_addr, offset);

2.8.9.3 IId_SectorLockRangeCmd

Description:

This command locks and protects a range of sectors.

Returns: -1 for error, 0 for success



Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device being manipulated.
StartSec	ADDRESS	An index into the location where the start sector to lock.
StopSec	ADDRESS	An index into the location where the stop sector to lock.

Behavior:

The specified range of sectors will be lock for writing.

Related Commands: Ild_SectorUnlockCmd, Ild_SectorLockRangeCmd

Example Code:

11d SectorLockRangeCmd(base addr, StartSec, StopSec);

2.9 Miscellaneous APIs

2.9.1 Miscellaneous Commands

2.9.1.1 IId_SetConfigRegCmd

Description:

This command is used to set the Configuration Register. Refer to the data sheet for specific bit information.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash to be manipulated.
value	FLASHDATA	The configuration data to be written.

Behavior:

n/a

Related Commands: Ild_ReadConfigRegCmd

Example Code:

11d SetConfigRegCmd(addr, value);

2.9.1.2 IId_SetConfigRegCmd (Device with Address Space Overlay Mode)

Description:

This command is used to set the Configuration Register. Refer to the data sheet for specific bit information.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash to be manipulated.
offset	ADDRESS	sector offset for ASO (Address Space Overlay).
value	FLASHDATA	The configuration data to be written.

Behavior:

n/a

Related Commands: Ild_ReadConfigRegCmd



Example Code:

1ld_SetConfigRegCmd(base_addr, offset, value);

2.9.1.3 IId_SetConfigRegCmd (WS-P Device)

Description:

The command is used to set the Configuration Registers for WS-P devices. Refer to the data sheets for specific bit information.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
value	FLASHDATA	The data to be written to Configuration Register 0.
Value1	FLASHDATA	The data to be written to Configuration Register 1.

Behavior:

n/a

Related Commands: Ild_ReadConfigRegCmd

Example Code:

1ld SetConfigRegCmd(base addr, value, value1);

2.9.1.4 IId_ReadConfigRegCmd

Description:

This command reads the Configuration Register word.

Returns: Configuration Register Word

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_SetConfigRegCmd

Example Code:

data = lld_ReadConfigRegCmd(addr);
printf("%8.8X\n", data);

2.9.1.5 IId_ReadConfigRegCmd (Device with Address Space Overlay Mode)

Description:

This command reads the Configuration Register word.

Returns: Configuration Register Word

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	Sector offset to read.



n/a

Related Commands: Ild_SetConfigRegCmd

Example Code:

data = lld_ReadConfigRegCmd(base_addr, offset);
 printf("%8.8X\n", data);

2.10 Deep Power-Down APIs

2.10.1 Deep Power-Down Commands

2.10.1.1 IId EnterDeepPowerDownCmd

Description:

This command is used to enter Deep Power Down (DPD) mode.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_ReleaseDeepPowerDownCmd

Example Code:

11d_EnterDeepPowerDownCmd(base_addr);

2.10.1.2 IId_ReleaseDeepPowerDown

Description:

This command is used to exit Deep Power Down (DPD) mode. Exiting the DPD mode is accomplished with the assertion of CS# during any read or write transaction (CS# LOW for at least four clock cycles). During the t_{DPD} (300 μ s) period the device will ignore command sequences (read and write transactions will not be processed) and RDS will not toggle during an attempted read transaction. A "dummy" write transaction is the preferred method for exiting DPD. Driving the RESET# input LOW (for the minimum t_{RP} time) will also cause the device to exit the DPD mode. The device will take t_{DPD} to return to the idle state.

This API provides 2 methods to exit deep power down: a dummy write and a read array. User may also issue a hardware reset operation to exit DPD.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
mode	FLASHDATA	2 methods to exit deep power down: mode = 0: issue "dummy" write mode = 1: issue read array

Behavior:

n/a



Related Commands: Ild_EnterDeepPowerDownCmd()

Example Code:

lld_ReleaseDeepPowerDownCmd(base_addr, mode);

2.11 Temperature Sensor APIs

2.11.1 Temperature Sensor Commands

2.11.1.1 IId_MeasureTemperatureCmd

Description:

This command is used to measure temperature of device.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_ReadTemperatureRegCmd

Example Code:

11d_MeasureTemperatureCmd(base_addr);

2.11.1.2 IId ReadTemperatureRegCmd

Description:

This command is used to read temperature register.

Returns: FLASHDATA (Word Temperature Register Result)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_MeasureTemperatureCmd

Example Code:

```
temp_reg = lld_ReadTemperatureRegCmd(base_addr);
printf("Temperature Register = 0x%04X\n", temp_reg);
```

2.11.1.3 IId_MeasureTemperatureRegOp

Description:

This operation is used to measure temperature and read temperature register.

Returns: DEVSTATUS (DEV_BUSY = Measure temperature failed; DEV_NO_BUSY = Measure temperature completed)



Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
temperature_reg	FLASHDATA *	The pointer of temperature register value.

Behavior:

When operation return status is "DEV_NO_BUSY", the operation read temperature register value from device and store into output parameter "temperature_reg"; when operation return status is "DEV_BUSY", the operation doesn't read temperature register.

Related Commands: Ild_MeasureTemperatureCmd, Ild_ReadTemperatureRegCmd

Example Code:

```
status = lld_MeasureTemperatureRegOp(base_addr, temperature_reg);
if (status != DEV_NO_BUSY)
  printf("Measure Temperature Failed!\n");
else
  printf("Measure Temperature Registers = %X\n", &temperature_reg);
```

2.12 Power-On Reset Timer APIs

2.12.1 Power-On Reset Timer Commands

2.12.1.1 IId_ProgramPORTimerRegCmd

Description:

This command is used to program Power On Reset Timer Register.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
portime	FLASHDATA	The data to be used for programming.

Behavior:

n/a

Related Commands: Ild_ReadPORTimerRegCmd

Example Code:

11d_ProgramPORTimerRegCmd(base_addr, wr_por_reg);

2.12.1.2 IId_ReadPORTimerRegCmd

Description:

This command is used to read Power On Reset Timer Register.

Returns: FLASHDATA (Word Power On Reset Timer Result)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.



n/a

Related Commands: Ild_ProgramPORTimerRegCmd

Example Code:

```
rd_por_reg = lld_ReadPORTimerRegCmd(base_addr);
printf("POR Register = 0x%04X\n", rd por reg);
```

2.13 Interrupt APIs

2.13.1 Interrupt Commands

2.13.1.1 IId_LoadInterruptConfigRegCmd

Description:

This command is used to load Interrupt Configuration Register.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
icr	FLASHDATA	The data to be used for programming.

Behavior:

n/a

Related Commands: Ild_ReadInterruptConfigRegCmd

Example Code:

lld LoadInterruptConfigRegCmd(base addr, load icr);

2.13.1.2 IId_ReadInterruptConfigRegCmd

Description:

This command is used to read Interrupt Configuration Register.

Returns: FLASHDATA (Word Interrupt Configuration Register)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_LoadInterruptConfigRegCmd

Example Code:

```
read_icr = lld_ReadInterruptConfigRegCmd(base_addr);
printf("Interrupt Configuration Register = 0x%04X\n", read icr);
```

2.13.1.3 IId_LoadInterruptStatusRegCmd

Description:



This command is used to load Interrupt Status Register.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
isr	FLASHDATA	The data to be used for programming.

Behavior:

n/a

Related Commands: Ild_ReadInterruptStatusRegCmd

Example Code:

11d_LoadInterruptStatusRegCmd(base_addr, load_isr);

2.13.1.4 IId_ReadInterruptStatusRegCmd

Description:

This command is used to read Interrupt Status Register.

Returns: FLASHDATA (Word Interrupt Status Register)

Parameters:

Behavior:

n/a

Related Commands: Ild_LoadInterruptStatusRegCmd

Example Code:

```
read_isr = lld_ReadInterruptStatusRegCmd(base_addr);
printf("Interrupt Configuration Register = 0x%04X\n", read isr);
```

2.14 Volatile and Non-Volatile Configuration Register APIs

2.14.1 Configuration Register Operation

2.14.1.1 IId_ProgramNonVolatileConfigRegOp

Description:

This function is used to program non-volatile configuration register and poll the status for completion

Returns: DEVSTATUS (DEV_NOT_BUSY = Program Completed; DEV_PROGRAM_ERROR = Program Error; DEV_ERASE_ERROR = Erase Error)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
nvcr	FLASHDATA	The data to be used for programming.

Behavior:

n/a

Related Commands: Ild_ProgramNonVolatileConfigRegCmd, Ild_EraseNonVolatileConfigRegCmd, Ild_ReadNonVolatileConfigRegCmd



Example Code:

```
dev_status = lld_ProgramNonVolatileConfigRegOp (base_addr, pgm_nvcr);
printf("status = %s\n", get_status_str(dev_status));
```

2.14.2 Configuration Register Commands

2.14.2.1 Ild_LoadVolatileConfigRegCmd

Description:

This command is used to load Volatile Configuration Register.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
vcr	FLASHDATA	The data to be used for write.

Behavior:

n/a

Related Commands: Ild_ReadVolatileConfigRegCmd

Example Code:

lld_LoadVolatileConfigRegCmd(base_addr, load_vcr);

2.14.2.2 IId_ReadVolatileConfigRegCmd

Description:

This command is used to read Volatile Configuration Register.

Returns: FLASHDATA (Word Volatile Configuration Register)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_LoadInterruptConfigRegCmd

Example Code:

```
read_vcr = lld_ReadVolatileConfigRegCmd(base_addr);
printf("Interrupt Configuration Register = 0x%04X\n", read vcr);
```

2.14.2.3 Ild_ProgramNonVolatileConfigRegCmd

Description:

This command is used to Program Non-Volatile Configuration Register.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
nvcr	FLASHDATA	The data to be used for programming.



When issued, this command will begin the programming process. The flash will no longer be in read array mode during programming. Typically, this command is followed by a status polling routine to determine the state of the flash.

Related Commands: Ild_EraseNonVolatileConfigRegCmd, Ild_ReadNonVolatileConfigRegCmd

Example Code:

11d ProgramNonVolatileConfigRegCmd(base addr, pgm nvcr);

2.14.2.4 IId ReadNonVolatileConfigRegCmd

Description:

This command is used to read Non-Volatile Configuration Register.

Returns: FLASHDATA (Word Non-Volatile Configuration Register)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_ EraseNonVolatileConfigRegCmd, Ild_ProgramNonVolatileConfigRegCmd

Example Code:

```
read_nvcr = lld_ReadVolatileConfigRegCmd(base_addr);
printf("Interrupt Configuration Register = 0x%04X\n", read nvcr);
```

2.14.2.5 IId_EraseNonVolatileConfigRegCmd

Description:

This command is used to Erase Non-Volatile Configuration Register.

Returns: n/a Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_ProgramNonVolatileConfigRegCmd, Ild_ReadNonVolatileConfigReg

Example Code:

11d EraseNonVolatileConfigRegCmd (base addr);

2.15 Evaluate Erase Status APIs

2.15.1 Evaluate Erase Status Commands

2.15.1.1 IId_EvaluateEraseStatusCmd

Description:



The Evaluate Erase Status (EES) command verifies that the last erase operation on the addressed sector was completed successfully. The EES command can be used to detect erase operations that failed due to loss of power, reset, or failure during an erase operation. Please read device data sheet for more detail.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
offset	ADDRESS	Sector offset for SO (Address Space Overlay).

Behavior:

n/a

Related Commands: n/a

Example Code:

11d EvaluateEraseStatusCmd (base addr, offset);

2.16 CRC APIs

2.16.1 CRC Commands

2.16.1.1 IId_CRCEnterCmd

Description:

This command is used to enter CRC ASO.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash to be manipulated.

Behavior:

n/a

Related Commands: n/a

Example Code:

11d_CRCEnterCmd (base_addr);

2.16.1.2 IId_LoadCRCStartAddrCmd

Description:

This command is used to load CRC start address.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
bl	ADDRESS	Beginning location of checkvalue calculation.

Behavior:

n/a



Related Commands: Ild_CRCEnterCmd, Ild_CRCExitCmd

Example Code:

11d_LoadCRCStartAddrCmd (base_addr, bl);

2.16.1.3 IId_LoadCRCEndAddrCmd

Description:

This command is used to load CRC end address.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.
el	ADDRESS	Ending location of checkvalue calculation.

Behavior:

n/a

Related Commands: Ild_CRCEnterCmd, Ild_CRCExitCmd

Example Code:

11d_LoadCRCEndAddrCmd (base_addr, el);

2.16.1.4 IId_CRCSuspendCmd

Description:

This command is used to suspend CRC calculation.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_CRCEnterCmd, Ild_CRCExitCmd

Example Code:

11d_CRCSuspendCmd (base_addr);

2.16.1.5 IId_CRCResumeCmd

Description:

This command is used to resume CRC calculation.

Returns: n/a
Parameters:

Ν	Name	Туре	Description
b	oase_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a



Related Commands: Ild_CRCEnterCmd, Ild_CRCExitCmd, Ild_CRCSuspendCmd

Example Code:

11d CRCResumeCmd (base addr);

2.16.1.6 IId_ReadCheckvalueLowResultRegCmd

Description:

This command is used to read CheckValue Low Result.

Returns: FLASHDATA (Word CheckValue Low Result)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_CRCEnterCmd, Ild_CRCExitCmd, Ild_LoadCRCStartAddrCmd, Ild_LoadCRCEndAddrCmd Example Code:

low = lld ReadCheckvalueLowResultRegCmd (base addr);

2.16.1.7 IId_ReadCheckvalueHighResultRegCmd

Description:

This command is used to read CheckValue High Result.

Returns: FLASHDATA (Word CheckValue High Result)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_CRCEnterCmd, Ild_CRCExitCmd, Ild_LoadCRCStartAddrCmd, Ild_LoadCRCEndAddrCmd Example Code:

high = lld ReadCheckvalueHighResultRegCmd (base addr);

2.16.1.8 IId CRCExitCmd

Description:

This command is used to exit CRC ASO.

Returns: n/a
Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior:

n/a

Related Commands: Ild_CRCEnterCmd



Example Code:

11d_CRCExitCmd (base_addr);

2.17 Continuity Check APIs

2.17.1 Continuity Check Operation

2.17.1.1 IId_ContinuityCheckOp

Description:

The Continuity Check provides a basic test of connectivity from package connectors to each die pad and to each individual die in a DDP.

Returns: DEVSTATUS (Continuity Check pattern detected, Continuity Check Error)

Parameters:

Name	Туре	Description
base_addr	FLASHDATA *	The base address of the flash device to be manipulated.

Behavior: n/a **Example Code**:

```
continuity_check_status = lld_ContinuityCheckOp (base_addr);
printf("continuity check status = %s\n", get_status_str(continuity_check_status));
```

Revision History



Cypress® Low Level Driver User Guide Revision History

Documen	Document Title: Cypress® Low Level Driver User Guide				
Documen	Document Number: 002-00329				
Revision	Issue Date	Origin of Change	Description of Change		
**	01/07/2010	_	Initial revision		
			Files: Added sentence about trace.c/trace.h		
*A	02/24/2011	_	Making the LLD Work in Your Environment: Changed S29GL512R and S29GLxxxR to S29GL512S and S29GLxxxS		
			Global: Rearranged the order of the sections to improve usability of document		
			Common API: Added paragraph under section heading		
			Basic Operations: Modified note		
		3/2011 –	LLD Cleanup: Moved Ild_GetVersion to of "Basic Operations" section		
			Changed the name of Ild_EraseSuspendnOp to Ild_EraseSuspendnOp(CMD1)		
	09/28/2011		Changed the name of Ild_ProgramSuspendOp to Ild_ProgramSuspendOp(CMD1) and edited the table description		
			Edited the table description of Ild_BlandkCheckOP		
*B			Changed the name of Ild_StatusRegReadCmd to Ild_StatusRegReadCmd(CMD2)		
			Edited the example code of Ild_StatusRegReadCmd		
			Changed the name of Ild_StatusRegClearCmd to Ild_StatusRegClearCmd(CMD2)		
			Removed: Ild_BitfieldProgrammingOp, Ild_BitFieldCmd APIs, Ild_SecSiSectorExitCmd		
			Added: Ild_StatusGetReg, Ild_StatusClear(CMD1) Ild_StatusClear(CMD2), Ild_EraseSuspendOp(CMD2), Ild_ProgramSuspendOp(CMD2), Ild_GetVersion API, Ild_StatusRegReadCmd(CMD1), Ild_StatusRegClearCmd(CMD1), Ild_AutoselectEntryCmd(Device with Address Space Overlay Mode), Ild_LockReg2EntryCmd, Ild_SetConfigRegCmd(WS-P Device)		



Cypress® Low Level Driver User Guide Revision History (Continued)

Document Title: Cypress® Low Level Driver User Guide Document Number: 002-00329 Origin of Revision **Issue Date Description of Change** Change General: Updated from Release 11.3.2 to Release 14.4.1 Deep Power-Down APIs: Added section Temperature Sensor APIs: Added section Power-On Reset Timer APIs: Added section Interrupt APIs: Added section *C 12/16/2014 Volatile and Non-Volatile Configuration Register APIs: Added section Evaluate Erase Status APIs: Added section ECC APIs: Added section CRC APIs: Added section SA Protect Status APIs: Added two sections: PPB SA Protect Status Commands and DYB SA Protect Status Commands General: Updated from Release 14.4.1 to Release 15.2.1. Changed flash bank to flash device throughout Introduction: Updated section API Specification: Nomenclature, Arguments, and Typedefs: updated Interleaved *D 06/30/2015 Typdefs: updated section Common APIs Example Code: updated throughout Sector Protection APIs: Ild PpbLockBitReadOp, Ild PpbLockBitSetOp: moved sections Ild_LockReg2EntryCmd: deleted section ECC APIs: Removed section *E 10/06/2015 BACD Updated to the Cypress template