ETHFEHigh Frequency Electronics



${\bf Indholds for tegnelse}$

1	Amplitude modulation	5
	1.1 Lektion 30-01-2018	5
	1.1.1 Basic Modulation Types and Concepts	5
	1.1.2 Amplitude Modulations	6
	1.1.3 Amplitude Demodulation	9
2	Frequency modulation	11
3	Phase modulation	13

Amplitude modulation


1.1 Lektion 30-01-2018

- 1. Intro
- 2. AM Modulation/demodulation

• **Pensum:** JV, Ch 1 p 1-6

• Opgaver: P.I-1

1.1.1 Basic Modulation Types and Concepts



Original baseband signal

Transmitted bandpass signal

Reconstructed baseband signal

- Modulation: Hvordan signaler moduleres ind på bærebølger, der efterfølgende typisk sendes ud som elektromagtetiske signaler via et transmissionsmedie.
 - Bandpass signalet er det transmitterede signal til receiveren.
 - Flere baseband signals kan blive transmitteret samtidigt gennem den samme kanal ved forskellige carrier frequencies.

• **Demodulation:** Hvordan det sendte signal demoduleres så det originale signal gendannes.

- Receiveren gendanner det low-frequency baseband signal.
- Scopet af demodulationen afhænger af hvilken type data der bliver sendt.
 - * In a radio telephony channel it may suffice at the receiver site to get an output with a power spectrum that contains the dominant part of the input power spectrum.
 - * In a television video channel it is important to reconstruct in time-domain the shape of the signal being send.
 - * In digital transmissions, the goal is to rebuild a logical bitstream representation equivalent to the input stream.

1.1.2 Amplitude Modulations

Typer af moduleringer der er egnet for RF communication kaldes continuous wave modulations, CW.

- Baseband information er overlagt en sinusoidal carrier wave med amplitude A_{c0} og vinkelfrekvens ω_c .
 - Carrier 1.1
 - Modulated carrier 1.2

$$y(t) = A_{c0}\cos(\omega_c t) \tag{1.1}$$

$$y(t) = A(t)\cos(\omega_c t + \phi(t) + \phi_0) \tag{1.2}$$


- The time dependencies of A(t) and $\phi(t)$ in 1.2 contain the baseband message and the angle ϕ_0 represents an offset phase for the carrier compared to the timing of the baseband message.
- If there is no synchronism between the two, the offset may be set to zero without loss of generality. Eq. 1.2 is called the envelope-phase representation of a modulated signal.

Den største forskel mellem forskellige modulation typer er hvordan et baseband signal x(t) indeholder det overlagte signal y(t) som er moduleret. Amplitude modulations indebærer **AM** and **DSB-SC**.

AM

• Skalering af signalniveauerne beregnes ved modulation index m.

- Med et normaliseret baseband signal $|x(t)| \le 1$, indebærer betingelsen $m \le 1$ (eller 100%) et undistorted reproduction af baseband signalet.
- Det er let at gendanne baseband signalet fra en AM modulated wave i en receiver med det simple envelope detector circuit.



Figur 1.1: Examples of modulation waveshapes (AM and DSB(-SC)) from a sinusoidal baseband signal x(t).

- Amplitude modulation, $\phi(t) = 0$
 - amplitude modulation, AM 1.3
 - double-sideband (supressed carrier), DSB/DSB-SC 1.4


$$y(t) = A_{c0}(1 + mx(t))\cos(\omega_c t)$$
 (1.3)

$$y(t) = A_{c0}x(t)\cos(\omega_c t) \tag{1.4}$$

- Envelope detectorens low-pass filter bandwidth skal være højere end envelope frekvensen.
- En AM modulated wave har spektrale komponenter fra baseband signalet over og under carrier signalet.

$$y(t)_{|AM} = A_{c0}(1 + mA_x \cos \omega_x t) \cos \omega_c t \tag{1.5}$$

$$y(t)_{|AM} = A_{c0}\cos\omega_c t + \frac{A_{c0}}{2}mA_x\cos(\omega_c - \omega_x)t + \frac{A_{c0}}{2}mA_x\cos(\omega_c + \omega_x)t$$
(1.6)




Figur 1.2: Spectral components in a double-sided amplitude spectrum of the sinusoidal baseband signal and the AM modulated waveform from Eq. 1.6. u and l are the upper and lower sideband components.

With maximum undistorted modulation, i.e. m=1 and $A_x=1$, the power of the AM modulated wave, say it is a voltage across a 1Ω resistor, becomes;

$$P_{|AM} = 2\frac{A_{c0}^2}{4} + 4\frac{A_{c0}^2 m^2 A_x^2}{16}$$
 (1.7)

$$P_{|AM} = \frac{1}{2}A_{c0}^2 + \frac{1}{4}A_{c0}^2 \tag{1.8}$$

so at most 33% of the transmitted power contains the message from the baseband signal.



Figur 1.3: Block schemes for simple AM modulation (left) and demodulation (right).


DSB-SC

DSB moduleringen fra Eq. 1.4 har ingen carrier component deraf kommer betegnelsen *suppressed carrier* eller SC.

$$y(t)_{|DSB-SC} = A_{c0}A_x \cos \omega_x t \cos \omega_c t \tag{1.9}$$

$$y(t)_{|DSB-SC} = \frac{A_{c0}A_x}{2}\cos(\omega_c - \omega_x)t + \frac{A_{c0}A_x}{2}\cos(\omega_c + \omega_x)t \qquad (1.10)$$

- Carrier componenterne indeholder ingen information, derfor er det mere kompliceret at gendanne baseband signalet i receiveren.
- For at kunne detektere baseband signalet fra et DSB moduleret signal, skal dette signal igen multipliceres med en carrier.
 - Hvis fasen $\phi(t)$ er forskellig fra nul vil cosine enten reducerer eller forvrænge signalet.
 - For at få et predictable result skal oscillatoren i demodulatoren være synkroniseret med carrier af det modtagede signal.
 - A simple method is to let a fragment of the full carrier a pilot carrier follow the signal.
 - * Gøres ved at indsætte en konstant < 1 istedet for 1.



Figur 1.4: Block schemes for simple DSB-SC modulation (left) and demodulation (right).

Frequency modulation

Phase modulation