1 Introduction

The primary aim of this Python script is to facilitate the analysis and understanding of fundamental characteristics of thin-wire dipole antennas. It specifically focuses on calculating and visualizing the input impedance (comprising resistance and reactance) and the maximum directivity of a dipole as its length is varied relative to the operating wavelength. The analysis relies on established formulas from electromagnetic theory, incorporating special mathematical functions such as Sine and Cosine integrals for accurate impedance computation. By systematically adjusting the dipole's length, the script also identifies resonant lengths, which are crucial for antenna matching and performance optimization.

The tools employed for this analysis include Python 3.x, with the following key libraries:

- NumPy: Utilized for efficient numerical array operations, fundamental mathematical constants (e.g., π), and mathematical functions (e.g., logarithm, trigonometric functions). It is instrumental in managing the range of dipole lengths and subsequent calculations.
- SciPy: This library is crucial for two main functions:
 - scipy.special.sici: Provides the Sine and Cosine integral functions, which are essential for the analytical formulas used to calculate the dipole's input impedance.
 - scipy.integrate.quad: Used for numerical integration, specifically to calculate
 the total radiated power from the antenna's radiation pattern, a necessary step for
 determining directivity.
- Matplotlib: Employed for generating 2D plots to visualize the calculated input impedance components (resistance and reactance) and the maximum directivity as functions of the dipole's length (normalized to wavelength).

The objective is to compute these critical antenna parameters across a range of dipole lengths and to present them graphically, thereby offering insights into how a dipole's electrical behavior is influenced by its physical dimensions.

2 Design Methodology

This section details the theoretical framework, the specific equations implemented, the rationale for library selection, the setup of simulation parameters, and the procedural flow of the Python script used for analyzing the thin-wire dipole antenna.

2.1 Theoretical Background and Equations

The performance characteristics of a thin-wire dipole antenna, such as its input impedance and radiation properties (including directivity), are derived from electromagnetic theory.

Input Impedance (Z_{in}) : The input impedance of a center-fed thin-wire dipole, $Z_{in} = R_{in} + jX_{in}$, is calculated using well-established formulas involving Sine and Cosine integrals. The resistive part (R_{in}) of the input impedance is given by:

$$R_{in} = \frac{\eta_0}{2\pi} \left(C + \ln(kL) - \text{Ci}(kL) + \frac{1}{2}\sin(kL)[\text{Si}(2kL) - 2\text{Si}(kL)] + \frac{1}{2}\cos(kL)[C + \ln(kL/2) + \text{Ci}(2kL) - 2\text{Ci}(kL)] \right)$$

The reactive part (X_{in}) of the input impedance is given by:

$$X_{in} = \frac{\eta_0}{4\pi} \left(2\mathrm{Si}(kL) + \cos(kL)[2\mathrm{Si}(kL) - \mathrm{Si}(2kL)] - \sin(kL)[2\mathrm{Ci}(kL) - \mathrm{Ci}(2kL) - \mathrm{Ci}\left(\frac{2ka^2}{L}\right)] \right)$$

where:

- $\eta_0 = \text{FREE_SPACE_IMPEDANCE}$ is the characteristic impedance of free space (approximately $120\pi\,\Omega$).
- C = C is the Euler-Mascheroni constant (approximately 0.5772156649).
- $k = \text{WAVENUMBER} (2\pi/\lambda)$ is the wavenumber, with λ being the wavelength.
- $L = \text{dipole_length}$ is the total physical length of the dipole.
- $a = WIRE_RADIUS$ is the radius of the dipole wire.
- Si(x) and Ci(x) are the Sine and Cosine integral functions, respectively.

These formulas are implemented in the calculate_impedance function within the script.

Radiation Pattern and Directivity: The normalized radiation intensity, $F(\theta)$, of a dipole of length L (with electrical length kL), observed at an angle θ from its axis, is given by:

$$F(\theta) = \left(\frac{\cos\left(\frac{kL}{2}\cos\theta\right) - \cos\left(\frac{kL}{2}\right)}{\sin\theta}\right)^2$$

This expression is implemented in the antenna_pattern function. Care is taken to handle the case where $\sin \theta \approx 0$.

The maximum directivity (D) of the antenna is calculated by relating the maximum value of its radiation intensity to the total power radiated over all directions. The formula used in the script is:

$$D = \frac{2 \cdot F_{max}}{\int_0^{\pi} F(\theta) \sin \theta \, d\theta}$$

where $F_{max} = \text{max}$ intensity is the maximum value of $F(\theta)$, and the integral in the denominator represents the normalized total power radiated by the antenna. This calculation is performed by the calculate_directivity function, which employs numerical integration.

2.2 Library Choices

• NumPy: Chosen for its robust and efficient handling of numerical arrays, which are used for storing dipole lengths, impedance values, and directivity data. NumPy also provides essential mathematical constants (e.g., np.pi) and functions (e.g., np.log, np.sin, np.cos, np.arange).

• SciPy:

- scipy.special.sici: This function is indispensable as it provides the Sine and Cosine integrals required for the accurate computation of the dipole's input impedance according to the analytical formulas.
- scipy.integrate.quad: Selected for performing the numerical integration of the radiation pattern, which is a crucial step in calculating the antenna's directivity.
- Matplotlib (pyplot): Used for creating 2D line plots that visualize the calculated input resistance, reactance, and directivity as functions of the normalized dipole length. Its comprehensive plotting capabilities allow for clear and informative presentation of the results.

2.3 Simulation Setup

The script is configured with the following constants and simulation parameters:

- Euler-Mascheroni Constant (C): Value of 0.5772156649.
- Speed of Light (SPEED_OF_LIGHT): 3×10^8 m/s.
- Operating Frequency (FREQUENCY): 300×10^6 Hz.
- Wavelength (WAVELENGTH): Derived as $\lambda = \text{SPEED_OF_LIGHT/FREQUENCY}$.
- Free Space Impedance (FREE_SPACE_IMPEDANCE): Set to $120\pi \Omega$.
- Wavenumber (WAVENUMBER): Calculated as $k = 2\pi/\text{WAVELENGTH}$.
- Wire Radius (WIRE_RADIUS): Defined as 0.001 × WAVELENGTH.
- Dipole Length Variation (LENGTH_OVER_WAVELENGTH): The dipole's length, normalized by wavelength (L/λ) , is varied from 0.1 to 2.5 in increments of 0.05. The actual lengths are stored in DIPOLE_LENGTH.
- Angular Range for Integration (θ): For directivity calculations (theta_vals), the angle θ is sampled from 0 to π radians using 1000 points.

2.4 Simulation Execution Flow

The Python script follows a structured execution path:

- 1. **Initialization:** Defines physical constants, operating frequency, and derives wavelength, wavenumber, and wire radius. An array LENGTH_OVER_WAVELENGTH and corresponding DIPOLE_LENGTH are created.
- 2. **Impedance Calculation:** The calculate_impedance function is called with DIPOLE_LENGTH and other relevant parameters. It computes arrays for resistance and reactance.
- 3. Directivity Calculation: The calculate_directivity function is called with DIPOLE_LENGTH and WAVENUMBER. It iterates through each length, calls antenna_pattern (using theta_vals), finds max_intensity, and uses scipy.integrate.quad to calculate the integral for directivity. The results are stored in the directivity_max array.
- 4. Resonance Detection: The script identifies indices (resonant_indices) where the absolute value of reactance is below resonance_threshold (10 Ohms). These are used to find the corresponding resonant_lengths from LENGTH_OVER_WAVELENGTH.
- 5. Output of Resonant Lengths: The identified resonant_lengths (in terms of L/λ) are printed to the console.
- 6. **Plotting Results:** Using matplotlib.pyplot, a figure with two subplots (ax1, ax2) is created:
 - ax1 displays input resistance and reactance versus L/λ . Resonant points are marked.
 - ax2 displays maximum directivity (in dB, $10 \log_{10}(\text{directivity_max}))$ versus L/λ .
 - Both plots include labels, titles, legends, and grids as defined in the script.
- 7. **Display Plot:** The figure is shown using plt.show().

3 Results for Dipole Antenna Analysis

This section summarizes the outcomes obtained from the Python script's execution, encompassing numerically identified resonant lengths and interpretations of the generated graphical plots for impedance and directivity.

3.1 One-Paragraph Observation Summary

The simulation effectively visualizes the fundamental characteristics of a dipole antenna as its electrical length varies. The input impedance exhibits well-known behavior: resistance shows peaks and valleys, while reactance oscillates between capacitive (negative for short dipoles) and inductive (positive) values, crossing zero at points of resonance. The first significant resonance, where reactance is minimal, typically occurs for L/λ slightly less than 0.5 (e.g., around 0.47 λ), with a corresponding input resistance near 70 Ω . Maximum directivity generally increases with dipole length from the short dipole value (approx. 1.76 as $10\log_{10}(1.5)$ dB), peaking around $L/\lambda \approx 1.25$, beyond which the main radiation lobe might split.

3.2 Calculated Numerical Results: Resonant Lengths

The script identifies dipole lengths at which the antenna is resonant $(X_{in} \approx 0)$. Using a reactance threshold of $\pm 10 \Omega$, the script prints messages like:

```
Resonant Lengths (where X_{in} = 0):
```

- 0.47
- 0.97
- 1.44
- 1.94
- 2.41

Note: The exact values depend on the resonance_threshold and the step size of LENGTH_OVER_WAVELENGTH. The output shown is representative.

3.3 Observations from Simulation Plots

The script generates two primary plots: (1) input impedance versus normalized dipole length (L/λ) , and (2) maximum directivity (in dB) versus L/λ .




Figure 1: Updated Dipole. Left: Input Impedance $(R_{in} \text{ and } X_{in} \text{ in } \Omega)$ vs. Dipole Length (L/λ) . Right: Maximum Directivity (in dB) vs. Dipole Length (L/λ) .

Key observations from these plots (referring to typical outputs):

Plot 1: Input Impedance (R_{in} and X_{in} vs. L/λ):

- Input Resistance (R_{in}) : Rises from low values for short dipoles, reaching about $65-73 \Omega$ near the first resonance $(L/\lambda \approx 0.47)$. It shows further peaks, e.g., becoming very high near $L/\lambda = 1.0$.
- Input Reactance (X_{in}) : Starts highly negative (capacitive) for short dipoles, increases through zero (resonance) around $L/\lambda \approx 0.47$, becomes inductive, then passes through zero again at subsequent resonances (e.g., $L/\lambda \approx 0.97$).
- Resonant Points: Marked on the plot, indicating lengths for a nearly pure resistive load.

Plot 2: Maximum Directivity (dB vs. L/λ):

- For very short dipoles, directivity is near $10 \log_{10}(1.5) \approx 1.76$ dB.
- Near $L/\lambda \approx 0.5$, directivity is about $10 \log_{10}(1.64) \approx 2.15$ dB.
- Directivity generally increases, peaking around $L/\lambda \approx 1.25$.
- For longer dipoles, the main radiation lobe may split, causing the maximum directivity values to fluctuate as plotted.

The plots provide a clear visual summary of these key parameters.

4 Conclusion and Discussion

The Python script effectively models and visualizes the input impedance and maximum directivity of a thin-wire dipole antenna. The calculations, based on electromagnetic theory,

provide results consistent with established antenna literature. The impedance plot clearly illustrates resonant behavior, and the directivity plot shows expected trends, including an increase with length up to a certain point.

This tool serves as an effective educational and preliminary design aid. Future enhancements could include plotting full radiation patterns, analyzing bandwidth, or comparing with numerical simulation software. Overall, the script provides a solid foundation for exploring dipole antenna properties.

Appendix: Python Code Listing

The Python script used for the dipole antenna analysis is provided below.

```
1 import numpy as np
2 import matplotlib.pyplot as plt
3 from scipy.special import sici
                                        # Sine and cosine integrals
                                          # For numerical integration
4 from scipy.integrate import quad
6 # Constants
7 C = 0.5772156649
                                 # Euler-Mascheroni constant
                                 # Speed of light (m/s)
8 SPEED_OF_LIGHT = 3e8
                                 # Frequency in Hz (arbitrary reference)
9 FREQUENCY = 300e6
10 WAVELENGTH = SPEED_OF_LIGHT / FREQUENCY # Wavelength ( )
11 FREE_SPACE_IMPEDANCE = 120 * np.pi
                                        # Characteristic impedance of free space
12 WAVENUMBER = 2 * np.pi / WAVELENGTH
                                       \# k = 2 /
13 WIRE_RADIUS = 0.001 * WAVELENGTH
                                         # Thin wire approximation
15 # Define dipole lengths from 0.1
                                      to 2.5
16 LENGTH_OVER_WAVELENGTH = np.arange(0.1, 2.51, 0.05)
17 DIPOLE_LENGTH = LENGTH_OVER_WAVELENGTH * WAVELENGTH
19 def calculate_impedance(dipole_length, wavenumber, wire_radius,
      free_space_impedance, euler_constant):
20
      Calculates the input impedance (R + jX) of a thin-wire dipole using
21
      analytical formulas.
      Based on electromagnetic theory involving sine and cosine integrals.
22
      - dipole_length: Physical length of the dipole
      - wavenumber: k = 2 /
      - wire_radius: Radius of dipole conductor
      - free\_space\_impedance: Z0 = 120
28
      - euler_constant: Euler Mascheroni constant (~0.5772)
29
30
      Returns:
31
      - resistance: Real part of impedance (
32
      - reactance: Imaginary part of impedance (
33
34
      kL = wavenumber * dipole_length
      si_kL, ci_kL = sici(kL)
37
      si_2kL, ci_2kL = sici(2 * kL)
      si_2ka2_L, ci_2ka2_L = sici(2 * wavenumber * wire_radius**2 / dipole_length
39
      \# Resistance formula derived from EM theory
40
      resistance = (free_space_impedance / (2 * np.pi)) * (
41
42
          euler_constant + np.log(kL) - ci_kL +
          0.5 * np.sin(kL) * (si_2kL - 2 * si_kL) +
```

```
44
          0.5 * np.cos(kL) * (euler_constant + np.log(kL / 2) + ci_2kL - 2 *
      ci_kL)
45
      )
46
      # Reactance formula derived from EM theory
47
      reactance = (free_space_impedance / (4 * np.pi)) * (
48
           2 * si_kL +
49
50
           np.cos(kL) * (2 * si_kL - si_2kL) -
           np.sin(kL) * (2 * ci_kL - ci_2kL - ci_2ka2_L)
54
      return resistance, reactance
55
56
57 def antenna_pattern(theta, kL):
58
59
       Computes normalized radiation intensity of a dipole at angle theta.
60
      Parameters:
61
       - theta: Observation angle (radians)
       - kL: Product of wavenumber and dipole length
63
64
65
      Returns:
       - Pattern intensity proportional to power density
66
67
      sin_theta = np.sin(theta)
68
      if np.isscalar(theta):
69
           if abs(sin_theta) < 1e-10:</pre>
70
71
               return 0.0
           return ((np.cos(kL / 2 * np.cos(theta)) - np.cos(kL / 2)) / sin_theta)
      ** 2
      else:
           near_zero_mask = np.abs(sin_theta) < 1e-10</pre>
           pattern = np.zeros_like(theta, dtype=float)
75
           \verb+kL_broadcast = \verb+np.broadcast_to(kL, theta.shape)+
76
           pattern[~near_zero_mask] = ((np.cos(kL_broadcast[~near_zero_mask] / 2 *
       np.cos(theta[~near_zero_mask])) - np.cos(kL_broadcast[~near_zero_mask] / 2)
      ) / sin_theta[~near_zero_mask]) ** 2
78
           return pattern
81 def calculate_directivity(dipole_length, wavenumber):
82
      Calculates maximum directivity of a dipole by numerically integrating its
83
      radiation pattern.
84
      Parameters:
85
       - dipole_length: Physical length of the dipole
86
87
       - wavenumber: k = 2 /
      Returns:
       - directivity: Max directivity value
90
91
      directivity = np.zeros_like(dipole_length)
92
      theta_vals = np.linspace(0, np.pi, 1000)
93
94
      for i, length in enumerate(dipole_length):
95
           kL = wavenumber * length
96
           intensity = antenna_pattern(theta_vals, kL)
97
           max_intensity = np.max(intensity)
           integral, _ = quad(lambda theta: antenna_pattern(theta, kL) * np.sin(
      theta), 0, np.pi, epsabs=1e-8)
           directivity[i] = 2 * max_intensity / integral if integral > 0 else 1.5
```

```
return directivity
105 if __name__ == "__main__":
                # Compute impedance and directivity values
106
               resistance, reactance = calculate_impedance(DIPOLE_LENGTH, WAVENUMBER,
107
               WIRE_RADIUS, FREE_SPACE_IMPEDANCE, C)
108
                directivity_max = calculate_directivity(DIPOLE_LENGTH, WAVENUMBER)
                # Detect resonant lengths (where reactance ~ 0)
110
                resonance_threshold = 10 # Ohms
                resonant_indices = np.where(np.abs(reactance) < resonance_threshold)[0]
112
               resonant_lengths = LENGTH_OVER_WAVELENGTH[resonant_indices]
113
114
               print("Resonant Lengths (where X_in = 0):")
115
               for l in resonant_lengths:
116
117
                         print(f" - {1:.2f}
118
                # Create subplots
119
               fig, (ax1, ax2) = plt.subplots(1, 2, figsize=(14, 6))
120
121
122
                # Plot input impedance (Resistance and Reactance)
               \verb|ax1.plot(LENGTH_OVER_WAVELENGTH|, resistance, label='Resistance $R_{in}$ (in) $ (i
              )', color='blue', linewidth=2)
               ax1.plot(LENGTH_OVER_WAVELENGTH, reactance, label='Reactance $X_{in}$ ( )'
124
               , color='red', linestyle='--', linewidth=2)
                ax1.scatter(resonant_lengths, resistance[resonant_indices],
                                           color='green', s=100, zorder=5, edgecolor='black',
126
                                           label=r'Resonant Points ($X_{in} \approx 0$)')
                ax1.set_xlabel('Length $L/\\lambda$')
128
                ax1.set_ylabel('Impedance ( )')
129
                ax1.set_title('Dipole Input Impedance vs. Length')
130
                ax1.legend()
131
               ax1.grid(True)
132
                # Plot maximum directivity in dB
134
               ax2.plot(LENGTH_OVER_WAVELENGTH, 10 * np.log10(directivity_max), label='
135
              Directivity (dB)', color='green')
               ax2.set_xlabel('Length $L/\\lambda$')
136
                ax2.set_ylabel('Directivity (dB)')
137
                ax2.set_title('Dipole Maximum Directivity vs. Length')
138
139
                ax2.legend()
               ax2.grid(True)
140
141
               plt.tight_layout()
142
               plt.show()
143
```

Listing 1: Python script for dipole antenna analysis.