



Tools and Debugging

ocpihdl, ocpixml, and ocpi_debug

Outline

- 1. Collect HDL device/worker information: ocpihdl and ocpixml
- 2. Review worker lifecycle
- Control worker state with ocpihal
- 4. Change and view worker properties
- 5. Introduce ocpi_debug





Using ocpihdl

- We can use ocpihdl to:
 - Probe the xml of the currently loaded bitstream
 - Display currently loaded workers
 - View/change worker status
 - Set/change worker properties
 - Reset workers
 - Step through an application
 - ...
- Without options, ocpihal prints out all of its uses





Finding the available HDL devices on Matchstiq-Z1



\$ ocpihdl search


- Provides information for available HDL devices
 - Name
 - Date of bitstream creation
 - Platform
 - Part
 - UUID (Unique identifier of the bitstream)

% ocpihdl search
OpenCPI HDL device found: 'PL:0': bitstream date Mon May 1 08:59:51 2017, platform "matchstiq_z1",
part "xc7z020", UUID 10226754-2e6e-11e7-88f7-573bc8e8124c

\$ ocpihdl probe

Similar to "search", but you can specify a device

Loading/Probing the Bitstream



Load a bitstream (e.g. on the Matchstiq-Z1):
 \$ ocpihdl load <path to bitstream>

Examine the XML packaged into a *currently loaded* bitstream:
 \$ ocpihdl getxml <output-file>





Loading/Probing the Bitstream


- \$ ocpihdl **getxml** <output-file>
- \$ grep controlOperation < output-file>
 - What controlOperations are implemented by each worker?

If you ever want to remove the bitstream from the FPGA:
 \$ ocpihdl unload





Worker LifeCycle







- Find worker index and other information
 \$ ocpihdl get
 - Can specify <index/worker-name> (and even property>) here as well
- Reset or Unreset the control reset signal into workers
 \$ ocpihdl wreset/wunreset <index>
- Perform other control operations on workers
 \$ ocpihdl wop <index> start/initialize/stop
- Set worker properties
 \$ ocpihdl set <index/worker-name> <property> <value>
- Observe worker state
 - \$ ocpihdl status <index/worker-name>
 - Add -v to see worker properties





View Worker Information from Bitstream





\$ ocpihdl get

```
% ocpihdl aet
HDL Device: 'PL:0' is platform 'matchstiq z1' part 'xc7z020' and UUID '10226754-2e6e-1
1e7-88f7-573bc8e8124c'
Platform configuration workers are:
  Instance p/matchstiq z1 of io worker matchstiq z1 (spec ocpi.platform) with index 0
  Instance p/time server of io worker time server (spec ocpi.devices.time server) with
 index 1
Container workers are:
  Instance c/ocscp of normal worker ocscp (spec ocpi.ocscp)
  Instance c/unoc term0 0 of io worker sdp term (spec ocpi.devices.sdp term)
  Instance c/unoc term1 0 of io worker sdp term (spec ocpi.devices.sdp term)
  Instance c/unoc term2 0 of io worker sdp term (spec ocpi.devices.sdp term)
  Instance c/unoc term3 0 of io worker sdp term (spec ocpi.devices.sdp term)
  Instance c/tb bias wti0 time client of normal worker time client (spec ocpi.time cli
ent)
  Instance c/metadata of normal worker metadata (spec ocpi.metadata)
Application workers are:
  Instance a/pattern of normal worker pattern (spec ocpi.pattern) with index 2
  Instance a/bias of normal worker bias (spec ocpi.bias) with index 3
  Instance a/capture of normal worker capture (spec ocpi.capture) with index 4
```

We can identify them by their indices

If the worker is 'RESET'

\$ ocpihdl wunreset <index>

```
% ocpihdl status 2
Status of instance 'a/pattern' of worker 'pattern' is 'RESET'
Worker 2 on device pl:0
 Status: 0x00008000
Control: 0x00000000 not enabled (reset asserted); timeout value is 1
 ConfigAddr: 0x00000000
 PageWindow: 0x00000000
  Instance a/pattern of normal worker pattern (spec ocpi.pattern) with index 2
% ocpihdl wunreset 2
Worker 2 on device pl:0: reset deasserted, was asserted
% ocpihdl status 2
Status of instance 'a/pattern' of worker 'pattern' is ['EXISTS'
Worker 2 on device pl:0
 Status: 0x00008000
 Control: 0x80000000 enabled (reset not asserted); timeout value is 1
 ConfigAddr: 0x00000000
 PageWindow: 0x000000000
  Instance a/pattern of normal worker pattern (spec ocpi.pattern) with index 2
```





• If the worker implements the 'initialize' controlOperation:

\$ ocpihdl wop <index> initialize

```
% ocpihdl wop 2 initialize
Worker 2 on device pl:0: the 'initialize' control operation was performed with result 'success'
01)
% ocpihdl status 2
Status of instance 'a/pattern' of worker 'pattern' is 'INITIALIZED'
Worker 2 on device pl:0
Status: 0x00048000 opValid:0x0:init
Control: 0x80000000 enabled (reset not asserted); timeout value is 1
ConfigAddr: 0x00000000
PageWindow: 0x00000000
Instance a/pattern of normal worker pattern (spec ocpi.pattern) with index 2
```

Ultimately, to bring the worker to 'OPERATING':

\$ ocpihdl wop <index> start





- Writable worker properties can be changed:
 - \$ ocpihdl set <index/worker-name> <value>
- Readable (the explicit flag, not the concept) / Volatile properties can be read:

\$ ocpihdl status -v <index/worker-name>

```
% ocpihdl set 2 step true
Setting the step property to 'true' on instance 'a/counter'
% ocpihdl status 2 ; ocpihdl get -v 2
Status of instance 'a/counter' of worker 'counter-1' is 'OPERATING'
Worker 2 on device pl:0
            0x091f0000 addrValid beValid:0x1 opValid:0x1:start wrtValid:1
Status:
Control: 0x80000004 enabled (reset not asserted); timeout value is 16
ConfigAddr: 0x00000008
 PageWindow: 0x00000000
  Instance a/counter of normal worker counter-1 (spec local.counter) with index 2
                 counter: 2
                     max: 9
  2
3
              ocpi debug: true
             ocpi endian: little
                    step: true
```





Debugging

- ocpi_debug
 - Worker parameter that can enable debugging
 - Set to true in OWD before building workers for debugging
 - Add debugging functionality to worker that depends on ocpi_debug
- In VHDL: "ocpi_debug"
 debug gen : if its(ocpi debug) generate
- In C++: "<WORKER_NAME>_OCPI_DEBUG"
 if (COUNTER OCPI DEBUG) {





Execution and Debug Utilities

- Log level
 - export OCPI LOG LEVEL=8
 - OCPI LOG LEVEL=10 make tests
 - ocpirun -l 8 (lowercase L)
- "ocpirun -C" finds containers, including simulators
- "ocpiview" is used to view simulation waveform results
- printf/cout
- ocpi_debug OWD parameter
- gdb



