



# Lab 3: Peak Detector

Simple RCC Worker

## Objectives

- Design, Build and Test an RCC Application worker that
  - Implements the peak detector function reports signed min/max peaks
  - Routes data/messages through the worker (pass-thru)
- Unit Test the RCC Application worker
  - Unit tests performed on multiple platforms
    - CentOS7
    - Xilinx13 3
- Introduce:
  - C++ conventions
    - Accessing port data and Properties
  - Framework interactions
    - RCC\_ADVANCE vs. RCC\_OK vs. RCC\_ADVANCE\_DONE





#### What's Provided?

- Component's Datasheet
  - /home/training/provided/doc/Peak\_Detector.pdf
- Scripts for generating and validating data
  - /home/training/provided/lab3/peak\_detector.test/
- Script for plotting I/Q data
  - /home/training/provided/scripts/plotAndFft.py





### **Application Worker Development Flow**

- 1. Protocol (OPS): Create new or select pre-existing
- 2. Component (OCS): Create new or select pre-existing
- 3. Create new App Worker (Modify OWD, Makefile, and source RCC/HDL code)
- 4. Build the App Worker for target device(s)
- 5. Create Unit Test (<component>-test.xml, generate, verify and view scripts)
- 6. Build Unit Test
- 7. Run Unit Test






#### Overview

- What are the requirements of this component?
  - Given an input of complex numbers, the "peak\_detector" component is meant to find the biggest I or Q sample and the smallest I or Q sample. The basic idea is:

```
current_biggest = max(current_biggest,max(I,Q))
current_smallest = min(current_smallest,min(I,Q))
```

Pass input of complex numbers to the output ports







#### Step 1 - Create new or select pre-existing OPS

- Identify the OPS(s) declared by this component
  - HINT: Examine the "Ports" table in the Component Datasheet
- Is the OPS(s) available in this project's component library?
  - HINT: Examine available protocols /home/training/training\_project/components/specs/
- Is the OPS(s) available from the framework or another Project?
  - HINT: check the top-level "specs" of the Core Project
- If NO to all questions => custom OPS XML file must be created
- ANSWER: OPS is available from framework. REUSE!






#### Step 1 – Create new or select pre-existing OPS (cont.)

- Open **₩OPI**

- In the Ports section, identify which Protocol is being used
- The Protocols are located in the Core Project
- For convenience, the Protocol specified in the datasheet is also here: File name: iqstream protocol.xml

#### Step 1 – Create new or select pre-existing OPS (cont.)





```
How to decode the Protocol for data types and accessing data
```

```
<ProtocolName> = "Iqstream"
<OpName> = "Iq" when used in a type, "iq" when used to access data
<ArgName> = "Data" when used in a type, "data" when used to access data
<ProtocolNameOpNameArgName> = "IqstreamIqData"
```

File name: iqstream\_protocol.xml


Recall: to access members in a struct, need the <memberName>


myStructPtr->I;
myStructPtr->Q;
Or
(\*myStructPtr).I;
(\*myStructPtr).Q;

#### Step 1 – Create new or select pre-existing OPS (cont.)

# How to decode the Protocol for data types and accessing data

<PortInName> = the Name of the Consumer Port defined in the OCS, example "in"
<PortOutName> = the Name of the Producer Port defined in the OCS, example "out"









#### Step 2 - Create new or select pre-existing OCS

- Examine the Properties and Ports listed in the Component Datasheet
  - Use Properties/Ports information to answer the following questions
- Is the OCS XML file available in this project's component library?
  - HINT: Browse /home/training/training\_project/components/specs/
- Is the OCS XML file available from the framework?
  - HINT: Browse IDE options
- If NO to all questions => custom OCS XML file must be created
- ANSWER: Custom OCS XML file must be created.





#### Step 2 – Create new or select pre-existing OCS (cont.)

- Create new Asset Type: Component
  - Component Name: peak detector
  - Library: components
- In the OCS Editor
  - Reference the component datasheet to add the properties and ports described in the Properties and Ports tables, respectively





### Step 3 – Create new App Worker

- Create new Asset Type: Worker
  - Worker Name: peak detector
  - Library: components
  - Component: peak\_detector-spec.xml
  - Model: RCC
  - Prog. Lang: C++
- In the OWD RCC Editor
  - Add ControlOperations: start





- The auto-generated skeleton source code contains the default function calls, in this case 'run'. By modifying the OWD top-level attribute ControlOperations to support the 'start' function, the skeleton should be updated by performing a rebuild of the worker so that the framework's auto code generation feature is leveraged to create the 'start' function call.
- Rebuild the Worker:
  - Use the IDE's Perspective





#### Before adding the 'start' Control Operation

```
class Peak_detectorWorker : public Peak_detectorWorkerBase {
   RCCResult run(bool /*timedout*/) {
      return RCC_DONE; // change this as needed for this worker to do something useful
      // return RCC_ADVANCE; when all inputs/outputs should be advanced each time "run" is called.
      // return RCC_ADVANCE_DONE; when all inputs/outputs should be advanced, and there is nothing more to do.
      // return RCC_DONE; when there is nothing more to do, and inputs/outputs do not need to be advanced.
   }
};
```

#### After adding the 'start' Control Operation

```
class Peak_detectorWorker : public Peak_detectorWorkerBase {
   RCCResult start() {
     return RCC_OK;
   }
   RCCResult run(bool /*timedout*/) {
     return RCC_DONE; // change this as needed for this worker to do something useful
     // return RCC_ADVANCE; when all inputs/outputs should be advanced each time "run" is called.
     // return RCC_ADVANCE_DONE; when all inputs/outputs should be advanced, and there is nothing more to do.
     // return RCC_DONE; when there is nothing more to do, and inputs/outputs do not need to be advanced.
   }
};
```







Open **;©CPI** 

In the body of the *Peak\_detectorWorker* class, put any persistent local variables needed:

```
int16_t max_buff, min_buff; // internal buffers match type "short" in the OCS
```

Then, in the Start RCC Worker Method, initialize them:

```
class Peak_detectorWorker : public Peak_detectorWorkerBase {
  int16_t max_buff, min_buff;

  RCCResult start() {
    max_buff = -32768; // initialize max to most neg
    min_buff = 32767; // initialize min to most pos
    return RCC_OK;
  }
```

#### In the Run RCC Worker Method

- 1. Make sure there is room on the output port
- 2. Do work
- 3. Advance ports









#### In the Run RCC Worker Method

1. Make sure there is room on the output port

```
const size_t num_of_elements = <PortInName>.<OpName>() <ArgName>().size();
<PortOutName>.<OpName>().<ArgName>().resize(num_of_elements)
<PortOutName>.setOpCode(<PortInName>.opCode());

// 1. Make sure there is room on the output port
    const size_t num_of_elements = in.iq().data().size();
    out.iq().data().resize(num_of_elements);
    out.setOpCode(in.opCode());
```

#### In the Run RCC Worker Method

- 2. Do work
- Create pointer objects for reading input data and writing output data





#### In the Run RCC Worker Method

- 2. Do work (continued)
- Is the input a Sequence or Array? If so, we need to iterate through the elements.
- Recall max\_peak is the greatest value of either I or Q and the min\_peak is the smallest value of either I or Q.

```
for ( ) { // decrement through num_of_elements
    // 1. determine max peak and min peak
    *odata++=*idata++ // 2. copy this message to output buffer
}
// 3. set properties().max_peak & set properties().min_peak
// to the calculated max_buff and min_buff
```





#### In the Run RCC Worker Method

2. Do work (continued)

```
8 #include <algorithm>
9 #include "peak_detector-worker.hh"
```

include the standard template library "algorithm" to use the max and min functions over sequences

```
// 2. Do work
const IqstreamIqData *idata = in.iq().data().data();
IqstreamIqData *odata = out.iq().data().data();
for (unsigned n = num_of_elements; n; n--) {
    max_buff = std::max(std::max(idata->I,idata->Q),max_buff);
    min_buff = std::min(std::min(idata->I,idata->Q),min_buff);
    *odata++ = *idata++; // copy this message to output buffer
}
properties().max_peak = max_buff;
properties().min_peak = min_buff;
```





In the Run RCC Worker Method

3. Advance port

We are *done* when the length of the input buffer is zero.

```
// 3. Advance ports
return num_of_elements ? RCC_ADVANCE : RCC_ADVANCE_DONE;
```





### Step 4(a) – Build the App Worker for x86

- Execute build for CentOS7-x86
  - 1. Use the IDE to "Add" the App Worker to the Project Operations Panel
  - 2. Highlight "centos7" in RCC Platforms panel
  - 3. Click "Build Assets"
  - 4. Review the Console window messages





#### Step 4(a) – Build the App Worker for x86 (cont.)

• If the build was free from errors, the end of the build log messages should resemble the following:

```
Compiling peak_detector.cc for target linux-c7-x86_64, configuration 0

Generating dispatch file: target-linux-c7-x86_64/peak_detector_dispatch.c

Compiling target-linux-c7-x86_64/peak_detector_dispatch.c for target linux-c7-x86_64, configuration 0

Generating artifact/runtime xml file target-linux-c7-x86_64/peak_detector_assy-art.xml for all workers in one binary
```

Linking final artifact file "target-linux-c7-x86 64/peak detector.so" and adding metadata to it...





#### Step 4(a) – Build the App Worker for x86 (cont.)

- To confirm that the RCC Worker artifact was built, check to see that the "target-linux-c7-x86\_64" directory was created *and* the .so was generated.
  - Navigate to components/{worker}.rcc and observe new artifacts in "target-linux-c7-x86 64/"

```
$ ls -l target-linux-c7-x86_64
peak_detector_assy-art.xml
peak_detector_assy.xml
peak_detector_dispatch.c
peak_detector_dispatch.o
peak_detector_dispatch.o.deps
peak_detector.o
peak_detector.o
peak_detector.so
peak_detector.so
peak_detector.so
```

The x86 version was built





#### Step 4(b) – Build the App Worker for ARM

- Execute build for ARM
  - Browse to the top-level of the project's directory and execute
  - Same operations in IDE except different platform
  - Command-line alternative:

\$ ocpidev build worker peak\_detector.rcc --rcc-platform xilinx13\_3





#### Step 4(a) – Build the App Worker for ARM (cont.)

• If the build was free from errors, the end of the build log messages should resemble the following:

Compiling target-linux-x13\_3-arm/peak\_detector\_dispatch.c for target linux-x13\_3-arm, configuration 0 Generating artifact/runtime xml file target-linux-x13\_3-arm/peak\_detector\_assy-art.xml for all workers in one binary

Linking final artifact file "target-linux-x13\_3-arm/peak\_detector.so" and adding metadata to it...





#### Step 4(b) – Build the App Worker for ARM

- To confirm that the RCC Worker ARM artifact was built, check to see that the "target-linux-x13\_3-arm" directory was created *and* the .so was generated.
  - Navigate to components/{worker}.hdl and observe new artifacts in "target-linux-x13\_3-arm/"

```
$ ls -l target-linux-x13_3-arm
peak_detector_assy.xml
peak_detector_dispatch.c
peak_detector_dispatch.o
peak_detector_dispatch.o
peak_detector_dispatch.o
peak_detector.o
peak_detector.o
peak_detector.o
peak_detector.so
peak_detector.so
```

The ARM version was built





## Step 5(a) - 7(a) CentOS7 - x86

- These slides cover employing the framework's Unit Test Suite to generate:
  - OAS (OpenCPI Application Specification) XML file(s)
    - Used by the framework for running the Worker on a given platform
  - Input test data file(s)
- CRITICAL NOTE: The IDE does not currently support creation of a unit test directory.





## Step 5(a) - Create Unit Test

- Create a unit test for the "peak\_detector" component, which results in generation of the "peak\_detector.test/" directory
- \$ ocpidev create test peak\_detector
  - Note the Makefile and stub files peak\_detector-test.xml, generate.py, verify.py, view.sh
- Copy generate.py, verify.py, and view.sh

```
$ cp -a ~/provided/lab3/peak_detector.test/*
~/training_project/components/peak_detector.test/
```





#### Step 5(a) - Create Unit Test

- Edit the Unit Test Description XML file declaring a default test case:
  - Name: peak detector-test.xml
  - Located in the "peak\_detector.test/" directory
    - Edit the "input" element
      - Add the sample size as a parameter to the generate script
        - script="generate.py 32768"
      - Add an attribute "messagesize" with a size of 8192
    - Edit the "output" element
      - Add the sample size as a parameter to the verify script
        - script="verify.py 32768"





### Step 5(a) - Create Unit Test (cont)

• peak\_detector-test.xml result

### Step 6(a) – Build Unit Test (x86)

- Build the Unit Test Suite for the target software platform
  - 1. Use the IDE to "Add" the Unit Test to the Project Operations panel
  - 2. Highlight "centos7" in the RCC Platforms panel
  - 3. Click "Build Tests"
  - 4. Review the Console window messages and address any errors
- Observe new artifacts in peak\_detector.test/gen/
  - cases.txt "Human-readable" file which lists various test configurations.
  - cases.xml Used by framework to execute tests.
  - cases.xml.deps List of dependent files
  - applications/ OAS files and scripts used by framework to execute applications.





### Step 7(a) – Run Unit Test (x86)

- otep (a) Ran ont rest (xoo)
- Similar in IDE, but "Run Tests" button
- OR in a terminal, browse to {component}.test/ and execute
- \$ make run View=1
  - This uses the default centos?
- The test should run quickly. Upon completion, you should see "PASSED" along with final values for the min/max peaks. Plots of input and output (time and frequency domain) will pop up.
- Also try:
  - \$ make run OnlyPlatforms=centos7 View=1 {limits platforms to test}
  - \$ make run {run on all available platforms, no plotting}
  - \$ make verify {verify previous results}
  - \$ make view {plot previous results}





## Step 7(a) – Run Unit Test (x86) (cont.)

Input data is generated

#### Target platform is chosen

Generating run script for platform: centos7

- The Component Unit Test is run on CentOS7
- Python script verifies output data from the Unit Test

```
*** Python: Peak Detector ***

*** Validate output against expected data ***
File to validate: case00.00.peak_detector.rcc.out.out
uut_min_peak = -31129
uut_max_peak = 31129
file_min_peak = -31129
file_max_peak = 31129
Data matched expected results.
PASSED

*** End validation ***
```





## Step 5(b) – 7(b) Xilinx13\_3 - ARM

- These slides cover employing the framework's Unit Test Suite to generate:
  - OAS (OpenCPI Application Specification) XML file(s)
    - Ùsed by the framework for running the Worker on a given platform
  - Input test data file(s)
  - Various scripts to manage the execution of the applications onto the target platform(s)
- CRITICAL NOTE: The IDE does not currently support creation of a unit test directory.

#### Step 5(b) - Create Unit Test

- Located in "peak\_detector.test/" directory
  - Same as used for CentOS7
    - REUSE!

```
<tests useHDLFileIo='true'>
    <input port='in' script='generate.py 32768' messagesize='8192'/>
    <output port='out' script='verify.py 32768' view='view.sh'/>
</tests>
```





### Step 6(b) – Build Unit Test (ARM)

- Build the Unit Test Suite for the target software platform
  - 1. Use the IDE to "Add" the Unit Test to the Project Operations panel
  - 2. Highlight "xilinx13\_3" the RCC Platforms panel
  - 3. Click "Build Tests"
  - 4. Review the Console window messages and address any errors
- Observe possibly-updated artifacts in peak\_detector.test/gen/
  - cases.txt "Human-readable" file which lists various test configurations.
  - cases.xml Used by framework to execute tests.
  - cases.xml.deps List of dependent files
  - applications/ OAS files and scripts used by framework to execute applications.





### Step 7(b) – Run Unit Test (ARM)

- Setup deployment platform
  - 1. Connect to serial port via USB on rear of Matchstiq-Z1 using host
    - screen /dev/ttyUSB0 115200
  - 2. Boot and login into Petalinux
    - User/Password = root:root
  - 3. Verify host and Matchstiq-Z1 have valid IP addresses
    - For training, they should both be on the same subnet
  - 4. Run setup script on Matchstiq-Z1
    - source /mnt/card/opencpi/mynetsetup.sh <host ip address>

More detail on this process can be found in the Matchstiq-Z1 Getting Started Guide document

## Step 7(b) – Run Unit Test (ARM) (cont.)

- On the Development Host, set OCPI\_REMOTE\_TEST\_SYSTEMS, as shown: \$ export OCPI\_REMOTE\_TEST\_SYSTEMS={IP of Matchstiq-Z1}=root=root=/mnt/training project
- If using the IDE, the above must be set before launching!
- On the Development Host, browse to the peak\_detector.test/
- \$ make run OnlyPlatforms=xilinx13 3 View=1
  - This will run the unit test remotely (over ssh) on the Matchstiq-Z1's ARM
- Also try:
  - \$ make run {run on all available platforms, no plotting}
  - \$ make verify {verify previous results}
  - \$ make view {plot previous results}





## Step 7(b) – Run Unit Test (ARM) (cont.)

Python script verifies output data from the Unit Test

```
*** Python: Peak Detector ***

*** Validate output against expected data ***
File to validate: case00.00.peak_detector.rcc.out.out
uut_min_peak = -31129
uut_max_peak = 31129
file_min_peak = -31129
file_max_peak = 31129
Data matched expected results.
PASSED

*** End validation ***
```



