
TODO:


Different analog connector Too many vias in high current traces? Different ground plane, need something special for signal ground?



Sheet:	F.Cu F.Silk	
File: UPD-board.kicad_pcb	B.Cu B.Silk	
Title:		
Size: A4 Date:		Rev:
KiCad E.D.A. kicad 6.0.7-f9a2dced07~116~ubuntu20.04.1		ld: 1/1

TODO:

Different analog connector Too many vias in high current traces? Different ground plane, need something special for signal ground?



Sheet:		F.Cu		-
File: UPD-bo	ard.kicad_pcb			D
Title:				
Size: A4	Date:		Rev:	
KiCad E.D.A. kicad 6.0.7-f9a2dced07~116~ubuntu20.04.1		ld: 1/1		
/,		Б.		

