100 nm Al on Fe 20kV base case 4096 ch

John Minter

Started 2018-08-07, Last modified: 2018-08-13

Abstract

The objective was to analyze the base case for 100 nm of Al on Fe at 15 kV using the base case from Llovet and Salvat 2018 table 3 case 1 using the Al K-L3 (K_{α} 1) transition. In this second (baseline) simulation I collected 4096 channels of data.

Contents

1	Set up for the analysis	1			
2	Get the current simulation time				
3	Retrieve the number of showers	2			
4	Compute the total maximum intensity for each element 4.1 Retrieve the data	2 2 3			
5	•	4 4 4 6			
1	Set up for the analysis				
	ote: This simulation used the same MSIMPA parameters for all layers and a REFLIN parameter (5E-1) hish.	to			
	[Material file, up to 20 chars] SIMPA 1.0E+3 1.0E+3 1E+3 0 0 0 -1E+2 [EABS(1:3),C1,C2,WCC,WCR]				

First load the libraries we need...

MSIMPA 1.0E+3 1.0E+3 1E+3 0.2 0.2 1 1

MFNAME Fe.mat

```
library(rpenepma)
library(dplyr)
library(pander)
panderOptions('table.split.table', Inf)
library(ggplot2)
```

[Material file, up to 20 chars]

[EABS(1:3),C1,C2,WCC,WCR]

Next, set the paths and constants that we need...

```
sim_dir <- "C:/Users/jrminter/Documents/work/penepma16/Al-100nm-on-Fe/Al_100_Fe_15kV_4096_ch"
sim_nam <- "Al-100nm-on-Fe-base-4096-channels"
res_fi <- "./penepma-res.dat"
int_fi <- "./pe-intens-01.dat"
spc_fi <- "./pe-spect-01.dat"
out_ti <- sprintf("%s-%gkV", sim_nam, e0)
msa_fi <- sprintf("./%s-%gkV.msa", sim_nam, e0)</pre>
```

2 Get the current simulation time

```
if (moved_data==FALSE){
  # When we have not moved the simulation measure the simulation time.
  # Note copying the files to another directory seems to change the time
  # Test a reload.
  delta_t <- penepma_measure_simulation_time(sim_dir)</pre>
  # print(delta t)
  save(delta_t, file="./delta_t.rda")
  rm(delta t)
 load("./delta t.rda")
  msg <- "Analyzed from simulation directory."
} else {
  # When we have moved the simulation, reload the delta_t.rda
  msg <- "Analyzed from data stored in delta_t.rda."</pre>
 load("./delta_t.rda")
cat(c(msg, "\nCurrent simulation time:",
      round(as.numeric(delta_t, units="hours"), 3), "hrs"))
```

Analyzed from data stored in delta_t.rda. Current simulation time: 1.261 hrs

3 Retrieve the number of showers

We want retrieve the number of showers (trajectories) that our penepma16 simulation calculated.

```
options(scipen = -6) # force printing in exponential format
num_showers <- penepma_get_number_of_showers(res_fi)
options(scipen = 3) # reset to default
cat("Number of trajectories: ", num_showers)</pre>
```

Number of trajectories: 3144

4 Compute the total maximum intensity for each element

4.1 Retrieve the data

First retrieve the intensity data as a tibble and print a preview.

```
tib <- penepma_get_intensities(int_fi)</pre>
print(tib)
# A tibble: 7 \times 14
     IZ SO
              S1
                       keV
                              P.mu
                                       P.se
                                               C.mu
                                                        C.se
                                                                B.mu
                                                                         B.se
  <int> <chr> <chr> <dbl>
                             <dbl>
                                      <dbl>
                                               <dbl>
                                                       <dbl>
                                                                <dbl>
                                                                        <dbl>
     13 K
              L2
                      1.49 1.06e-5 7.05e-6 0.
                                                     0.
                                                             0.
                                                                      0.
1
2
                      1.49 1.83e-5 8.85e-6 1.14e-8 3.42e-8 1.15e-7 1.99e-7
     13 K
              L3
3
     13 K
              МЗ
                      1.56 4.82e-7 1.44e-6 0.
                                                     0.
                                                             0.
4
     26 K
              L2
                      6.39 4.46e-5 2.34e-6 2.28e-7 1.52e-7 1.69e-6 8.32e-7
5
     26 K
              L3
                      6.40 8.66e-5 3.52e-6 5.70e-7 2.45e-7 3.32e-6 1.14e-6
6
     26 K
              M2
                      7.06 5.24e-6 7.47e-7 1.14e-8 3.42e-8 1.53e-7 2.29e-7
7
     26 K
                      7.06 1.11e-5 1.10e-6 2.28e-8 4.84e-8 3.09e-7 3.15e-7
              МЗ
# ... with 4 more variables: TF.mu <dbl>, TF.se <dbl>, Int.mu <dbl>,
    Int.se <dbl>
What features did we measure?
print(names(tib))
 [1] "IZ"
               "S0"
                        "S1"
                                  "keV"
                                           "P.mu"
                                                     "P.se"
              "B.mu"
 [8] "C.se"
                        "B.se"
                                  "TF.mu"
                                           "TF.se"
                                                     "Int.mu" "Int.se"
How many transitions did we measure?
print(nrow(tib))
[1] 7
Measure our test transition ("Al K-L3")
val <- penepma_get_total_intensity_z_transition(tib, 13, "K", "L3")
print(val)
# A tibble: 1 x 7
            IZ SO
  Symbol
                      S1
                               Int.mu
                                           Int.se Int.snr
  <chr> <int> <chr> <chr>
                                 <dbl>
                                            <dbl>
                                                     <dbl>
                            0.0000184 0.00000887
1 Al
            13 K
                      L3
                                                      2.08
```

4.2 Compute the maximum total intensity for each element

- 1. Compute the maximum total intensity for each element.
- 2. Stack each row of data together into a tibble.
- 3. Prepend the sample ID to the data.
- 4. Print a well-formatted a table using pander.
- 5. Save the final tibble so it can be r-loaded later

```
# 1
Al_t <- penepma_get_max_total_intensity_z(tib, 13)
Fe_t <- penepma_get_max_total_intensity_z(tib, 26)
# 2
tot_int <- dplyr::bind_rows(Al_t, Fe_t)
#3
Al_100_Fe_15kV_4096_ch <- prepend_sample_id_max_int_tib(tot_int, out_ti)
# 4
pander(Al_100_Fe_15kV_4096_ch)</pre>
```

Sample.ID	Symbol	IZ	S0	S1	Int.mu	Int.se	Int.snr
Al-100nm-on-Fe-base-4096- channels-15kV	Al	13	K	L3	0.00001842	0.00000887	2.077
Al-100nm-on-Fe-base-4096- channels-15kV	Fe	26	K	L3	0.00009045	0.0000038	23.8

5 Process the spectra data

5.1 Load the raw data

```
tib <- penepma_read_raw_data(spc_fi,min_intensity_clip=5.0e-10)
rownames(tib) <- c()</pre>
```

5.2 Summarize the spectrum data

How many rows of data are there?

```
cat(c("Number of measurements: ", nrow(tib)))
```

Number of measurements: 4096

Generate a summary:


pander(summary(tib))

keV	mu	se		
Min.: 0.01244	Min.: 0.50	Min. : 0.5		
1st Qu.: 5.00872	1st Qu.: 0.50	1st Qu.: 0.5		
Median $:10.00500$	Median: 0.50	Median: 0.5		
Mean $:10.00500$	Mean: 16.97	Mean: 22.4		
3rd Qu.:15.00128	3rd Qu.: 0.50	3rd Qu.: 0.5		
Max. :19.99756	Max. :18524.16	Max. :2394.2		


5.3 Plot the spectrum.

Start with a log-intensity plot.

Al-100nm-on-Fe-base-4096-channels-15kV



And then on a linear intensity scale...



5.4 Write a spectrum file in MSA format

penepma_to_msa(spc_fi, msa_fi,e0, out_ti)