

Intel® Architecture Memory Encryption Technologies

Specification

April 2021

Revision 1.3

Document Number: 336907-003US



Notice: This document contains information on products in the design phase of development. The information here is subject to change without notice. Do not finalize a design with this information.

Intel technologies' features and benefits depend on system configuration and may require enabled hardware, software, or service activation. Learn more at intel.com, or from the OEM or retailer.

No computer system can be absolutely secure. Intel does not assume any liability for lost or stolen data or systems or any damages resulting from such losses.

You may not use or facilitate the use of this document in connection with any infringement or other legal analysis concerning Intel products described herein. You agree to grant Intel a non-exclusive, royalty-free license to any patent claim thereafter drafted which includes subject matter disclosed herein.

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document. The products described may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

This document contains information on products, services and/or processes in development. All information provided here is subject to change without notice. Contact your Intel representative to obtain the latest Intel product specifications and roadmaps.

Intel disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade.

Copies of documents which have an order number and are referenced in this document may be obtained by calling 1-800-548-4725 or by visiting www.intel.com/design/literature.htm.

Intel, the Intel logo, and Xeon are trademarks of Intel Corporation in the U.S. and/or other countries.

*Other names and brands may be claimed as the property of others

Copyright $\ @$ 2021, Intel Corporation. All Rights Reserved.



Contents

1	Intro	oduction	7
2	Intro	oduction to Total Memory Encryption (TME)	8
3	Intro	oduction to Multi-Key Total Memory Encryption (MKTME)	9
	3.1	High-level Architecture	9
4	TME	& MKTME: Enumeration and Control Registers	11
	4.1	Enumeration	
		4.1.1 TME	
		4.1.2 Multi-key TME	
		4.1.3 Memory Encryption Capability MSR (IA32_TME_CAPABILITY 4.1.4 CPUID Reporting of MAX_PA_WIDTH	
	4.2	Memory Encryption Configuration and Status Registers	
		4.2.1 Activation MSR (IA32_TME_ACTIVATE)	
		4.2.2 IA32_TME_ACTIVATE WRMSR Response and Error Handling	
		4.2.3 Core Address Masking MSR (MK_TME_CORE_ACTIVATE)	
		4.2.4 Exclusion Range MSRs	
5	Runt	ime Behavior of MKTME	
	5.1	Changes to Specification of Physical Address	
		5.1.1 IA Paging	
		5.1.2 EPT Paging	
_		·	
6		ME Key Programming	
	6.1	Overview	
	6.2	PCONFIG Instruction	
		6.2.1 PCONFIG Description	
		6.2.3 PCONFIG Enumeration	
		6.2.4 PCONFIG Concurrency	24
		6.2.5 PCONFIG Operation	
		6.2.6 Flags Affected	
		6.2.8 Protected Mode Exceptions	
		6.2.9 Real-Address Mode Exceptions	
		6.2.10 Virtual-8086 Mode Exceptions	
		6.2.11 Compatibility Mode Exceptions	
		6.2.12 64-Bit Mode Exceptions	
7	Softv	ware Life Cycle: Managing Pages with KeyID	
	7.1	Overview	
	7.2	Restrictions and Cache Management	
	7.3	General Software Guidance for Dealing with Aliased Address Mappi	
	7.4	AddPage: Associating a KeyID to a Page	
	7.5	EvictPage: Disassociating a KeyID from a Page	
	7.6	Paging by OS/VMM Example	
	7.7	OS/VMM Access to Guest Memory	33

intel

	•		
	7.8	I/O Interactions	33
Figures			
	Figure Figure	e 2-1. Two-Socket Configuration of TME e 3-1. High-level Architecture of MKTME e 5-1. KeyID Usage e 6-1. MKTME Engine Overview	9 18
Tables			
	Table Table Table	4-1. IA32_TME_CAPABILITY MSR - Address 981H	13 15
	Table Table Table	4-6. IA32_TME_EXCLUDE_BASE MSR - Address 984H	17 20 21
	Table Table	6-3. PCONFIG Targets	22 22
		6-6. Programming Status for MKTME_KEY_PROGRAM	2.5



Revision History

Revision Number	Description	Date
1.0	Initial release of the document.	December 2017
1.2	Additional details added.	April 2019
1.3	Added support for 256b keys and KeyID0/TME encryption bypass.	April 2021

intel. *Terminology*

TME (Total Memory Encryption): This is a baseline capability for memory encryption with a single ephemeral key.

MKTME (Multi-Key Total Memory Encryption): Add support to use multiple keys for page granular memory encryption with additional support for software provisioned keys.



1 Introduction

This document describes the memory encryption support available beginning with the 3rd generation Intel® Xeon® Processor Scalable Family. Note that Intel platforms support many different types of memory and not all SoCs will support this capability for all types of memory. Initial implementation is focused on traditional DRAM.

Total Memory Encryption (TME) – the capability to encrypt the entirety of physical memory of a system. This capability is typically enabled in the very early stages of the boot process with a small change to BIOS and once configured and locked, will encrypt all the data on external memory buses of an SoC using the NIST standard AES-XTS algorithm with 128-bit keys or 256-bit keys depending on the algorithm availability and selection. The encryption key used for TME uses a hardware random number generator implemented in the Intel SoC, and the keys are not accessible by software or using external interfaces to the Intel SoC. TME capability is intended to provide protections of AES-XTS to external memory buses and DIMMs. The architecture is flexible and will support additional memory protection schemes in the future. This capability, when enabled, is intended to support (unmodified) existing system and application software. Overall performance impact of this capability is likely to be relatively small and is highly dependent on workload.

Multi-Key Total Memory Encryption (MKTME) builds on TME and adds support for multiple encryption keys. The SoC implementation supports a fixed number of encryption keys, and software can configure the SoC to use a subset of available keys. Software manages the use of keys and can use each of the available keys for encrypting any page of the memory. Thus, MKTME allows page granular encryption of memory. By default, MKTME uses the TME encryption key unless explicitly specified by software. In addition to supporting a CPU generated ephemeral key (not accessible by software or using external interfaces to the SoC), MKTME also supports software provided keys. Software provided keys are particularly useful when used with non-volatile memory or when combined with attestation mechanisms and/or used with key provisioning services. In a virtualization scenario, we anticipate the VMM or hypervisor managing the use of keys to transparently support legacy operating systems without any changes (thus, MKTME can also be viewed as TME virtualization in such a deployment scenario). An OS may be enabled to take additional advantage of the MKTME capability both in native and in a virtualized environment. When properly enabled, MKTME is available to each guest OS in a virtualized environment, and the quest OS can take advantage of MKTME in the same way as a native OS.

intel

2 Introduction to Total Memory Encryption (TME)

The diagram below gives an overview of total memory encryption in a two-socket configuration. Actual implementation may vary.

Cache Cache AES XTS AES XTS AES XTS **AES XTS** DRAM NVRAM DRAM **NVRAM** Controller Controller Controller Controller Encrypted Encrypted using using AES XTS AES XTS

Figure 2-1. Two-Socket Configuration of TME

The AES XTS encryption engine is in the direct data path to external memory buses and therefore, all the memory data entering and/or leaving the SoC on memory buses is encrypted using AES XTS. The data inside the SoC (in caches, etc.) remains plain text and supports all the existing software and I/O models.

In a typical deployment, the encryption key is generated by the CPU and therefore is not visible to the software. When the system is configured with NVRAM, if the NVRAM is to be treated as DRAM, then it can also use CPU generated keys. However, if NVRAM is to be treated as non-volatile memory, there is an option to have the same key generated/reused across platform power cycles/reboots.



3 Introduction to Multi-Key Total Memory Encryption (MKTME)

3.1 High-level Architecture

The high-level architecture of MKTME is shown in the figure below.

Figure 3-1. High-level Architecture of MKTME






Figure 3-1 shows the basic architecture of MKTME which shares basic hardware architecture with TME, with the exception that AES XTS now supports multiple keys. The right side of the figure shows the use of MKTME in a virtualized environment, though architecture supports use of MKTME in a native OS deployment scenario as well. In this example we show one hypervisor/VMM and two VMs. By default, a hypervisor uses KeyID 0 (same as TME), though it can use a different KeyID for its own memory as well. VM1 uses KeyID1 for its own private pages, and VM2 is using KeyID 2 for its own private pages. Additionally, VM1 can always use KeyID 0 (TME KeyID) for any page and is also opting to use KeyID 3 for shared memory between itself and VM2. The KeyID is included in the Page Table Entry as upper bits of the physical address field. As in this example, KeyID 2 is shown. The remainder of the bits in the physical address field are used to actually address bits in the memory. The figure shows one possible page assignment along with the KeyID for illustration purposes, though in this case the hypervisor has full freedom to use any KeyID with any pages for itself or any of its quest VMs. Note that the idea of oversubscribing physical address bits in the page table extends to other page tables as well, including IA page tables and IOMMU page tables. The KeyID remains part of the physical address bits everywhere in the SoC, with the exception of a tweak for AES XTS and on external memory buses. The KeyID is not used outside of the SoC or in the tweak for AES XTS.



4 TME & MKTME: Enumeration and Control Registers

This information is applicable only to CPUs that enumerate TME and/or MKTME capabilities.

4.1 Enumeration

TME and MKTME capability is exposed to the BIOS/Software via the MSR described in this section. The maximum number of keys available/supported in the processor for MKTME are enumerated. BIOS will need to activate this capability via an MSR (described later) and it must select the number of keys to be supported/used for MKTME during the early boot process. Upon activation, all memory (except memory in the TME Exclusion range) attached to the CPU/SoC is encrypted using AES-XTS with a 128-bit or 256-bit ephemeral key (platform key) that is generated by the CPU on every boot. Note that this behavior is applicable only when TME encryption is not bypassed (using bit 31 in the IA32_TME_ACTIVATE MSR). If TME encryption is bypassed, all accesses with KeyIDO will bypass encryption/decryption.

Intel processors support external memory controllers. These memory controllers may be attached to the processor via coherent buses such as the Intel® Ultra Path Interconnect (Intel® UPI) or Compute Express Link (CXL). MKTME enumeration can be used to discover the capabilities of the Intel processor and some of the memory attached to the integrated memory controller, but does not necessarily represent external memory controller features, or some types of memory attached to the integrated controller. The memory regions that are capable of being protected by CPU cryptographic capabilities are communicated to the system software via a new UEFI memory attribute, EFI_MEMORY_CPU_CRYPTO, introduced in UEFI 2.8. If this flag is set, the memory region is capable of being protected with the CPU's memory cryptographic capabilities. If this flag is cleared, the memory region is not capable of being protected with the CPU's memory cryptographic capabilities or the CPU does not support CPU memory cryptographic capabilities. System software must consult the attribute to determine the ranges that can be encrypted using MKTME.

4.1.1 TME

CPUID.TME (CPUID.(EAX=07H, ECX=0H): ECX[13]) enumerates the existence of these four architectural MSRs and their MSR addresses:

- IA32 TME CAPABILITY Address 981H
- IA32 TME ACTIVATE Address 982H
- IA32_TME_EXCLUDE_MASK Address 983H
- IA32_TME_EXCLUDE_BASE Address 984H



4.1.2 Multi-key TME

The CPUID.TME bit indicates the presence of the TME_CAPABILITY MSR, and that MSR will further enumerate the TME characteristics as well as the MKTME availability and characteristics. MKTME is enabled/configured by BIOS using the IA32_TME_ACTIVATE MSR. MKTME requires TME and therefore cannot be enabled without enabling TME.

4.1.3 Memory Encryption Capability MSR (IA32_TME_CAPABILITY)

Table 4-1. IA32_TME_CAPABILITY MSR - Address 981H

Register Address	Architectural MSR Name and Bit Fields	MSR/Bit Description	Comment
981H	IA32_TME_CAPABILITY MSR	Memory Encryption Capability MSR	One MSR for TME and MKTME.
	0	Support for AES-XTS 128-bit encryption algorithm.	NIST standard.
	1	Reserved	
	2	Support for AES-XTS 256-bit encryption algorithm.	NIST standard.
	30:3	Reserved	
	31	TME encryption bypass supported.	
	35:32	MK_TME_MAX_KEYID_BITS Number of bits which can be allocated for usage as key identifiers for multi-key memory encryption. Zero if MKTME is not supported.	4 bits allow for a max value of 15, which can address 32K keys.
	50:36	MK_TME_MAX_KEYS Indicates the maximum number of keys which are available for usage. This value may not be a power of 2. Zero if MKTME is not supported.	KeyID 0 is specially reserved and is not accounted for in this field. Max value is 32K-1 keys.
	63:51	Reserved	

4.1.4 CPUID Reporting of MAX_PA_WIDTH

CPUID enumeration of MAX_PA_WIDTH (leaf 80000008.EAX) is unaffected by MKTME activation and will continue to report the maximum number of physical address bits available for software to use, irrespective of the number of KeyID bits.



4.2 Memory Encryption Configuration and Status Registers

4.2.1 Activation MSR (IA32_TME_ACTIVATE)

This MSR is used to lock the following MSRs. Any write to the following MSRs will be ignored after they are locked. The lock is reset when CPU is reset.

- IA32_TME_ACTIVATE
- IA32 TME EXCLUDE MASK
- IA32_TME_EXCLUDE_BASE

Note: IA32_TME_EXCLUDE_MASK and IA32_TME_EXCLUDE_BASE MSRs are expected to be configured before the IA32_TME_ACTIVATE MSR.

To enable MKTME, the Hardware Encryption Enable bit in the IA32_TME_ACTIVATE MSR must be set, and bits 35:32 must have a non-zero value (which will specify the number of KeyID bits configured for MKTME).

Table 4-2. IA32_TME_ACTIVATE MSR - Address 982H

Register Address	Architectural MSR Name and Bit Fields	MSR/Bit Description	Comment
982H	IA32_TME_ACTIVATE MSR	Memory Encryption Activation MSR	
	0	Lock RO – Will be set upon successful WRMSR (or first SMI); written value ignored.	
	1	Hardware Encryption Enable (TME Enabled depending on TME Encryption Bypass Enable (bit 31))	This bit also enables MKTME; MKTME cannot be enabled without enabling encryption hardware.
	2	Key Select: 0 - Create a new TME key (expected cold/warm boot). 1 - Restore the TME key from storage (expected when resume from standby).	
	3	Save TME key for Standby: Save key into storage to be used when resume from standby.	May not be supported in all CPUs.



Register Address	Architectural MSR Name and Bit Fields	MSR/Bit Description	Comment
	7:4	TME Policy/Encryption Algorithm:	TME Encryption algorithm to be used.
		Only algorithms enumerated in the IA32_TME_CAPABILITY MSR are allowed.	
		For example:	
		0000 - AES-XTS-128	
		0010 - AES-XTS-256	
		Other values are invalid.	
	30:8	Reserved	
	31	TME Encryption Bypass Enable	
		When encryption hardware is enabled:	
		Total Memory Encryption is enabled using CPU generated ephemeral key based on hardware random number generator when this bit is set to 0.	
		Total Memory Encryption is bypassed (no encryption/decryption for KeyID0) when this bit is set to 1. On some processors, bypassing TME encryption can provide performance benefits to accesses made with KeyID 0 by avoiding the latency of decryption or encryption and decryption.	
		Software must inspect the Hardware Encryption Enable (bit 1) and TME Encryption Bypass Enable (bit 31) to determine if TME encryption is enabled.	
	35:32	Reserved if MKTME is not enumerated.	
		MK TME KEYID BITS	
		The number of key identifier bits to allocate to MKTME usage. Similar to enumeration, this is an encoded value.	
		Writing a value greater than MK_TME_MAX_KEYID_BITS will result in #GP.	
		Writing a non-zero value to this field will #GP if bit 1 of EAX (Hardware Encryption Enable) is not also set to '1, as encryption hardware must be enabled to use MKTME.	



15

Register Address	Architectural MSR Name and Bit Fields	MSR/Bit Description	Comment
		Example: To support 255 keys, this field would be set to a value of 8.	
	47:36	Reserved	
	63:48	MK_TME_CRYPTO_ALGS Bit 48: AES-XTS 128 Bit 49: Reserved Bit 50: AES-XTS-256 Bit 63:51: Reserved (#GP) Bitmask for BIOS to set which encryption algorithms are allowed for MKTME, will be later enforced by the key loading ISA ('1 = allowed).	

4.2.2 IA32_TME_ACTIVATE WRMSR Response and Error Handling

Table 4-3. IA32_TME_ACTIVATE WRMSR Response and Error Handling

Conditions	Response
WRMSR when not enumerated.	#GP
WRMSR while lock status = 1.	#GP
WRMSR with 63:8 (reserved) \neq 0.	#GP
WRMSR with Unsupported policy value (IA32_TME_CAPABILITY[IA32_TME_ACTIVATE[7:4]]= 0).	#GP
WRMSR with enabled=0.	TME disabled, MSR locked subsequent RDMSR returns xx01b.
WRMSR with enabled=1 and key select=0 (new key); RNG success.	TME enabled and MSR locked subsequent RDMSR returns xx011b.
WRMSR with enabled=1 and key select=0; RNG fail	Not enabled subsequent RDMSR returns xx000b.
WRMSR with enabled=1 and key select=1; Non-zero key restored from CPU.	TME enabled and MSR locked subsequent RDMSR returns xx111b.
WRMSR with enabled=1 and key select=1; Fail - Zero key restored from CPU.	Not enabled subsequent RDMSR returns xx100b.
WRMSR with any other legal values.	Subsequent RDMSR returns written values + lock status=1.
If MK_TME_KEYID_BITS > MK_TME_MAX_KEYID_BITS	#GP
If MK_TME_KEYID_BITS $> 0 \&\& (TME)$ Enable $== 0$ (TME must be enabled at the same point as MK-TME).	#GP
If MK_TME_KEYID_BITS > 0 and TME is not successfully activated (lock is not set).	Write not committed.
If MK_TME_CRYPTO_ALGS reserved bits are set.	#GP



4.2.3 Core Address Masking MSR (MK_TME_CORE_ACTIVATE)

This is a BIOS only MSR.

After successful activation using the IA32_TME_ACTIVATE MSR, this register should be written on each physical core with a value of 0 in EDX:EAX; failure to do so may result in unpredictable behavior. Accesses to this MSR will #GP if MKTME is not supported.

BIOS is expected to write to this MSR on each core after doing MKTME activation. The first SMI on each core will also cause this value to be synchronized with the package MSR value.

Table 4-4. MK_TME_CORE_ACTIVATE MSR - Address 9FFH

Register Address	MSR Name and Bit Fields	MSR/Bit Description	Comment
9FFH	MK_TME_CORE_ACTIVATE MSR	This MSR will #GP if MKTME is not supported.	
	31:0	Reserved	
	35:32	MK_TME_KEYID_BITS (read only) The number of key identifier bits to allocate to MKTME usage. Similar to enumeration, this is an encoded value. This is a read-only field. #GP on a non-zero write.	Will be shadowed from the package MSR value on write.
	63:36	Reserved	

4.2.4 Exclusion Range MSRs

TME and MKTME (for KeyID=0 only) support one exclusion range to be used for special cases. (Note: For all KeyIDs other than 0, the TME Exclusion Range does not apply to MKTME.) The range of physical addresses specified in this MSR does not apply memory encryption described in this document. This range is primarily intended to be used for memory not available to the OS and typically configured by BIOS. However, TME/MKTME (for KeyID=0) architecture does not place any restrictions on the use of the exclusion range. The software is able to determine this range by reading the MSR. The definition of this range follows the definition of many range registers implemented in Intel processors.



Table 4-5. IA32_TME_EXCLUDE_MASK MSR - Address 983H

Register Address	MSR Name and Bit Fields	MSR/Bit Description	Comment
983H	IA32_TME_EXCLUDE_ MASK MSR		
	10:0	Reserved	
	11	Enable - When set to '1', then IA32_TME_EXCLUDE_BASE and IA32_TME_EXCLUDE_MASK MSRs are used to define an exclusion region for TME/MKTME (for KeyID=0).	
	MAXPHYSADDR-1:12	TMEEMASK - This field indicates the bits that must match TMEEBASE in order to qualify as a TME/MKTME (for KeyID=0) exclusion memory range access.	
	63:MAXPHYSADDR	Reserved; must be zero.	

Table 4-6. IA32_TME_EXCLUDE_BASE MSR - Address 984H

Register Address	MSR Name and Bit Fields	MSR/Bit Description	Comment
984H	IA32_TME_EXCLUDE_ BASE MSR		
	11:0	Reserved	
	MAXPHYSADDR-1:12	TMEEBASE - Base physical address to be excluded for TME/MKTME (for KeyID=0) encryption.	
	63:MAXPHYSADDR	Reserved; must be zero.	

Note: Writing '1' into bits above the max supported physical size will result in #GP.

The IA32_TME_EXCLUDE_MASK MSR must define a contiguous region. WRMSR will #GP if the TMEEMASK field does not specify a contiguous region.

These MSRs are locked by the IA32_TME_ACTIVATE MSR. If lock=1, then WRMSR to IA32_TME_EXCLUDE_MASK/IA32_TME_EXCLUDE_BASE MSRs will result in #GP.

intel

5 Runtime Behavior of MKTME


After MKTME is activated by the BIOS, there are a number of changes to the runtime behavior of the processor which are described in this section.

5.1 Changes to Specification of Physical Address

The most significant change for MKTME is the repurposing of physical address bits to communicate the KeyID to the encryption engine(s) in the memory controller(s). This change necessitates a number of other hardware and software changes in order to maintain proper behavior.

When MKTME is activated, the upper bits of the platform physical address (starting with the highest order bit available as enumerated by the CPUID MAX_PA info) are repurposed for usage as a KeyID as shown below.

Figure 5-1. KeyID Usage



5.1.1 IA Paging

When IA paging is being used without EPT, the upper bits starting with MAX_PA for each level of the IA page table are repurposed for usage as KeyID bits. Similarly, the upper bits of the physical address in CR3 will be treated in the same manner.

Note that when EPT is active, IA paging does not generate/use platform physical addresses, instead it produces/uses guest physical addresses. Guest physical addresses are not modified by MKTME and will continue to index into EPT page table walks as they did prior to enabling MKTME.

5.1.2 EPT Paging

When EPT is enabled during VMX non-root operation, the upper bits for each level of EPT page walk are repurposed for usage as KeyID bits. Similarly, the upper bits of the physical address in EPTP will be treated in the same manner. Note that a guest OS may also use a KeyID in an IA page address, and full guest PA (including KeyID) is used by EPT.

5.1.3 Other Physical Addresses

Other physically addressed structures such as VMCS pointers, physically addressed bitmaps, etc., will receive similar treatment with the upper bits of the address starting



with MAX PA being repurposed as KeyID bits. Note that any reserved bit checking remains unchanged, which means that the checking of these addresses will only be based upon the CPUID MAX_PA value.

intel

6 MKTME Key Programming

6.1 Overview

Figure 6-1 shows a high-level overview of the MKTME engine meant to introduce the terminology that is used for the rest of the document and does not imply implementation.

Figure 6-1. MKTME Engine Overview

The MKTME engine maintains an internal key table not accessible by software to store the information (key and encryption mode) associated with each KeyID. Each KeyID may be associated with three encryption modes: Encryption using key specified, do not encrypt at all (memory will be plain text), or encrypt using TME Key. Future implementation may support additional encryption modes. PCONFIG is a new instruction that is used to program KeyID attributes for MKTME. While initial implementation may only use PCONFIG for MKTME, it may be extended in the future to support additional usages. Therefore, PCONFIG is enumerated separately from MKTME.

6.2 PCONFIG Instruction

Table 6-1. PCONFIG Instruction Details

Opcode	Instruction	Description
0F 01 C5	PCONFIG	This instruction is used to execute functions for configuring platform features.
		EAX: Leaf function to be invoked.
		RBX/RCX/RDX: Leaf-specific purpose.



6.2.1 PCONFIG Description

The PCONFIG instruction is invoked by software for configuring platform features. PCONFIG supports multiple leaves and a leaf function is invoked by setting the appropriate leaf value in EAX. RBX, RCX, and RDX have a leaf-specific purpose. An attempt to execute an undefined leaf results in a #GP(0). PCONFIG is a package scoped instruction and likewise, needs to be executed once per physical package to configure the desired platform feature.

Addresses and operands are 32 bits outside 64-bit mode (IA32_EFER.LMA = $0 \mid \mid CS.L = 0$) and are 64 bits in 64-bit mode (IA32_EFER.LMA = 1 && CS.L = 1). The CS.D value has no impact on address calculation. The DS segment is used to create linear addresses.

Table 6-2 shows the leaf encodings for PCONFIG.

Table 6-2. PCONFIG Leaf Encodings

Leaf	Encoding	Description	
MKTME_KEY_PROGRAM	0x00000000	This leaf is used to program the key and encryption mode associated with a KeyID.	
RESERVED	0x00000001-0xFFFFFFF	Reserved for future use (#GP(0) if used).	

A PCONFIG target is defined as any hardware block on the platform which can be configured using PCONFIG. PCONFIG currently only supports one target, MKTME.

Table 6-3 shows the supported targets for PCONFIG.

Table 6-3. PCONFIG Targets

Target Identifier	Value	Description	
INVALID_TARGET	0x00000000	Invalid target identifier.	
MKTME	0x00000001	Multi-Key Total Memory Encryption Engine.	
RESERVED	0x00000002-0xFFFFFFF	Reserved for future use.	

6.2.1.1 MKTME_KEY_PROGRAM Leaf

The MKTME_KEY_PROGRAM leaf of PCONFIG is used by software to manage the key associated with a KeyID. The leaf function is invoked by setting the leaf value of '0' in EAX and the address of MKTME_KEY_PROGRAM_STRUCT in RBX. Successful execution of the leaf clears RAX (set to zero) and ZF, CF, PF, AF, OF, and SF are cleared. In case of failure, the failure reason is indicated in RAX with ZF set to 1 and CF, PF, AF, OF, and SF are cleared. The MKTME_KEY_PROGRAM leaf works using the MKTME_KEY_PROGRAM_STRUCT in memory, as shown in Table 6-4.



Table 6-4. MKTME_KEY_PROGRAM_STRUCT Format

Field	Offset (bytes)	Size (bytes)	Comments
KEYID	0	2	Key Identifier
KEYID_CTRL	2	4	KeyID control:Bits [7:0]: COMMANDBits [23:8]: CRYPTO_ALGBits [31:24]: Reserved; must be zero
RSVD	6	58	Reserved; must be zero.
KEY_FIELD_1	64	64	Software supplied KeyID data key or entropy for KeyID data key.
KEY_FIELD_2	128	64	Software supplied KeyID tweak key or entropy for KeyID tweak key.

The following sub-sections provide a description of each of the fields in MKTME_KEY_PROGRAM_STRUCT.

6.2.1.1.1 KEYID

Key Identifier being programmed into the MKTME engine.

6.2.1.1.2 KEYID_CTRL

The KEYID_CTRL field carries two sub-fields used by software to control the behavior of a KeyID: Command and KeyID encryption algorithm.

The command used controls the encryption mode for a KeyID. Table 6-5 provides a summary of the commands supported.

Table 6-5. Supported Key Programming Commands

Command	Encoding	Description
KEYID_SET_KEY_DIRECT	0	Software uses this mode to directly program a key for use with KeyID.
KEYID_SET_KEY_RANDOM	1	The CPU generates and assigns an ephemeral key for use with a KeyID. Each time the instruction is executed, the CPU generates a new key using a hardware random number generator and the keys are discarded on reset.
KEYID_CLEAR_KEY	2	Clear the (software programmed) key associated with the KeyID. On execution of this command, the KeyID gets TME behavior (encrypt with platform TME key or bypass TME encryption).
KEYID_NO_ENCRYPT	3	Do not encrypt memory when this KeyID is in use.

The cryptographic algorithm field (CRYPTO_ALG) allows software to select one of the activated cryptographic algorithms for the KeyID. As discussed previously, the BIOS can activate a set of algorithms to allow for use when programming keys using the IA32_TME_ACTIVATE MSR (does not apply to KeyID 0 which uses the TME policy when TME encryption is not bypassed). The ISA checks to ensure that the algorithm selected by software is one of the algorithms that has been activated by the BIOS. Note that



software is required to provide one of the activated algorithms in this field, including for the KEYID_CLEAR_KEY and KEYID_NO_ENCRYPT commands.

6.2.1.1.3 **KEY_FIELD_1**

This field carries a software supplied data key to be used for the KeyID if the direct key programming option is used (KEYID_SET_KEY_DIRECT). When the random key programming option is used (KEYID_SET_KEY_RANDOM), this field carries a software supplied entropy to be mixed in the CPU generated random data key. It is software's responsibility to ensure that the key supplied for the direct programming option or the entropy supplied for the random programming option does not result in weak keys. There are no explicit checks in the instruction to detect or prevent weak keys. When AES XTS-128 is used, the upper 48B are treated as reserved and must be zeroed out by software before executing the instruction. When AES XTS-256 is used, the upper 32B are treated as reserved and must be zeroed out by software before executing the instruction.

6.2.1.1.4 **KEY_FIELD_2**

This field carries a software supplied tweak key to be used for the KeyID if the direct key programming option is used (KEYID_SET_KEY_DIRECT). When the random key programming option is used (KEYID_SET_KEY_RANDOM), this field carries a software supplied entropy to be mixed in the CPU generated random tweak key. It is software's responsibility to ensure that the key supplied for the direct programming option or the entropy supplied for the random programming option does not result in weak keys. There are no explicit checks in the instruction to detect or prevent weak keys. When AES XTS-128 is used, the upper 48B are treated as reserved and must be zeroed out by software before executing the instruction. When AES XTS-256 is used, the upper 32B are treated as reserved and must be zeroed out by software before executing the instruction.

All KeyIDs default to TME behavior (encrypt with TME key or bypass encryption) on MKTME activation. Software can at any point decide to change the key for a KeyID using the PCONFIG instruction. Change of keys for a KeyID does NOT change the state of TLB, caches, or memory pipeline. It is software's responsibility to take appropriate actions to ensure correct behavior. Examples of software flows are provided in section 7.

Table 6-6 shows the return values associated with the MKTME_KEY_PROGRAM leaf of PCONFIG. On instruction execution, RAX is populated with the return value.

Table 6-6. Programming Status for MKTME_KEY_PROGRAM

Return Value	Encoding	Description
PROG_SUCCESS	0	KeyID was successfully programmed.
INVALID_PROG_CMD	1	Invalid KeyID programming command.
ENTROPY_ERROR	2	Insufficient entropy.
INVALID_KEYID	3	KeyID not valid.
INVALID_CRYPTO_ALG	4	Invalid cryptographic algorithm chosen (not supported).
DEVICE_BUSY	5	Failure to access key table (see Section 6.2.4).



6.2.2 PCONFIG Virtualization

Software in VMX root mode can control the execution of PCONFIG in VMX non-root mode using the following execution controls introduced for PCONFIG:

- PCONFIG_ENABLE: This control is a single bit control and enables the PCONFIG instruction in VMX non-root mode. If 0, the execution of PCONFIG in VMX non-root mode causes #UD. Else, execution of PCONFIG works according to PCONFIG_EXITING. VM-exit control 27 of secondary execution control is assigned to PCONFIG_ENABLE.
- PCONFIG_EXITING: This is a 64b control and allows VMX root mode to cause a VM-exit for various leaf functions of PCONFIG. This control does not have any effect if the PCONFIG_ENABLE control is clear. VMCS index 0x203E/0x203F (64b control field) is assigned to PCONFIG_EXITING

6.2.3 PCONFIG Enumeration

PCONFIG is enumerated in extended features (CPUID.(EAX=07H, ECX=0H):EDX[18]). When 0, PCONFIG will #UD. A new CPUID leaf, PCONFIG_LEAF (leaf encoding 1BH), returns PCONFIG information. More specifically, sub-leaf n (n \geq 0) returns information about targets supported on the platform. The Intel® 64 and IA-32 Architectures Software Developer's Manual will define the sub-leaf types and information returned. Software is expected to scan all sub-leaves to get the information about all targets supported on the platform. It should also be noted that the sub-leaves of the same target need not be consecutive.

6.2.3.1 CPUID.PCONFIG_LEAF.n $(n \ge 0)$

Returns information about supported targets on the platform. The information returned is shown below:

- EAX: Sub-leaf type
 - Bits 11:0: 0: Invalid sub-leaf, 1: Target Identifier
- If EAX[11:0] == 0
 - EAX:EBX:ECX:EDX = 0
 - Sub-leaves m>n return all 0s
- If EAX[11:0] == 1
 - EAX[31:12] = 0
 - EBX: Target_ID_1
 - ECX: Target_ID_2
 - EDX: Target ID 3

Software is expected to scan all sub-leaves until an invalid sub-leaf is returned. All sub-leaves after the first invalid sub-leaf are invalid as well.

6.2.4 PCONFIG Concurrency

In a scenario where the MKTME_KEY_PROGRAM leaf of PCONFIG is executed concurrently on multiple logical processors, only one logical processor will succeed in



updating the key table. PCONFIG execution will return with an error code (DEVICE_BUSY) on other logical processors and software must retry. In cases where the instruction execution fails with a DEVICE_BUSY error code, the key table is not updated, thereby ensuring that either the key table is updated in its entirety with the information for a KeyID, or it is not updated at all. In order to accomplish this, the MKTME_KEY_PROGRAM leaf of PCONFIG maintains a writer lock for updating the key table. This lock is referred to as the key table lock and denoted in the instruction flows as KEY_TABLE_LOCK. The lock can either be unlocked, when no logical processor is holding the lock (also the initial state of the lock), or in an exclusive state where a logical processor is trying to update the key table. There can be only one logical processor holding the lock in an exclusive state. The lock, being exclusive, can only be acquired when the lock is in unlocked state.

PCONFIG uses the following syntax to acquire the KEY_TABLE_LOCK in an exclusive mode and release the lock:

KEY_TABLE_LOCK.ACQUIRE(WRITE)

KEY_TABLE_LOCK.RELEASE()

6.2.5 PCONFIG Operation

Table 6-7. Variable Definitions

Variable Name	Туре	Size (Bytes)	Description
TMP_KEY_PROGRAM_STRUCT	MKTME_KEY_PROGRAM _STRUCT	192	Structure holding the key programming structure.
TMP_RND_DATA_KEY	UINT128	32	Random data key generated for random key programming option.
TMP_RND_TWEAK_KEY	UINT128	32	Random tweak key generated for random key programming option.



```
(* #GP(0) for an unsupported leaf *)
if(EAX != 0) #GP(0)
(* KEY PROGRAM leaf flow *)
if (EAX == 0)
    (* #GP(0) if TME ACTIVATE MSR is not locked or does not enable hardware
    encryption or multiple keys are not enabled *)
    if (IA32 TME ACTIVATE.LOCK != 1 OR IA32 TME ACTIVATE.ENABLE != 1 OR
    IA32 TME ACTIVATE.MK TME KEYID BITS == 0) #GP(0)
    (* Check MKTME KEY PROGRAM STRUCT is 256B aligned *)
    if (DS:RBX is not 256B aligned) \#GP(0);
    (* Check that MKTME KEY PROGRAM STRUCT is read accessible *)
    <<DS: RBX should be read accessible>>
    (* Copy MKTME KEY PROGRAM STRUCT to a temporary variable *)
    TMP KEY PROGRAM STRUCT = DS:RBX.*;
    (* RSVD field check *)
    if(TMP KEY PROGRAM STRUCT.RSVD != 0) #GP(0);
    if(TMP KEY PROGRAM STRUCT.KEYID CTRL.RSVD !=0) #GP(0);
    if (TMP KEY PROGRAM STRUCT.KEYID CTRL.ENC ALG[0] == 1)
         if(TMP KEY PROGRAM STRUCT.KEY FIELD 1.BYTES[63:16] != 0) #GP(0);
         if(TMP KEY PROGRAM STRUCT.KEY FIELD 2.BYTES[63:16] != 0) #GP(0);
    if (TMP KEY PROGRAM STRUCT.KEYID CTRL.ENC ALG[2] == 1)
         if (TMP KEY PROGRAM STRUCT.KEY FIELD 1.BYTES[63:32] != 0) #GP(0);
         if(TMP KEY PROGRAM STRUCT.KEY FIELD 2.BYTES[63:32] != 0) #GP(0);
    (* Check for a valid command *)
    if (TMP KEY PROGRAM STRUCT. KEYID CTRL.COMMAND is not a valid command)
         RFLAGS.ZF = 1;
         RAX = INVALID PROG CMD;
         goto EXIT;
    (* Check that the KEYID being operated upon is a valid KEYID *)
    if (TMP KEY PROGRAM STRUCT.KEYID >
                           2^IA32 TME ACTIVATE.MK TME KEYID BITS - 1
         OR TMP KEY PROGRAM STRUCT.KEYID >
                           IA32 TME CAPABILITY.MK TME MAX KEYS
         OR TMP KEY PROGRAM STRUCT.KEYID == 0)
    {
         RFLAGS.ZF = 1;
        RAX = INVALID KEYID;
        goto EXIT;
```



```
(* Check that only one algorithm is requested for the KeyID and it is
    One of the activated algorithms *)
 if(NUM BITS(TMP KEY PROGRAM STRUCT.KEYID CTRL.CRYPTO ALG) != 1 ||
    (TMP KEY PROGRAM STRUCT.KEYID CTRL.CRYPTO ALG &
      IA32 TME ACTIVATE. MK TME CRYPTO ALGS == 0))
{
    RFLAGS.ZF = 1;
    RAX = INVALID CRYPTO ALG;
    goto EXIT;
(* Try to acquire exclusive lock *)
if (NOT KEY TABLE LOCK.ACQUIRE(WRITE))
    //PCONFIG failure
    RFLAGS.ZF = 1;
    RAX = DEVICE BUSY;
    goto EXIT;
}
(* Lock is acquired and key table will be updated as per the command
   Before this point no changes to the key table are made *)
switch (TMP KEY PROGRAM STRUCT.KEYID CTRL.COMMAND)
case KEYID SET KEY DIRECT:
         DATA KEY=TMP KEY PROGRAM STRUCT.KEY FIELD 1,
         TWEAK KEY=TMP KEY PROGRAM STRUCT.KEY FIELD 2,
         ENCRYPTION MODE=ENCRYPT WITH KEYID KEY,
         to MKTME Key table at index TMP KEY PROGRAM STRUCT.KEYID
    >>
    break;
case KEYID SET KEY RANDOM:
    TMP RND DATA KEY = <<Generate a random key using hardware RNG>>
    if (NOT ENOUGH ENTROPY)
        RFLAGS.ZF = 1;
        RAX = ENTROPY ERROR;
         goto EXIT;
    TMP RND TWEAK KEY = <<Generate a random key using hardware RNG>>
    if (NOT ENOUGH ENTROPY)
    {
         RFLAGS.ZF = 1;
        RAX = ENTROPY ERROR;
         goto EXIT;
    }
     (* Mix user supplied entropy to the data key and tweak key *)
    TMP RND DATA KEY = TMP RND KEY XOR
         TMP KEY PROGRAM STRUCT.KEY FIELD 1.BYTES[15:0];
    TMP RND TWEAK KEY = TMP RND TWEAK KEY XOR
         TMP KEY PROGRAM STRUCT.KEY FIELD 2.BYTES[15:0];
    <<Write
         DATA KEY=TMP RND DATA KEY,
```



```
TWEAK KEY=TMP RND TWEAK KEY,
            ENCRYPTION MODE=ENCRYPT WITH KEYID KEY,
            to MKTME KEY TABLE at index TMP KEY PROGRAM STRUCT.KEYID
         >>
         break;
    case KEYID CLEAR KEY:
        <<Write
         DATA KEY='0,
         TWEAK KEY='0,
         ENCRYPTION MODE = ENCRYPT WITH TME KEY OR BYPASS,
         to MKTME KEY TABLE at index TMP KEY PROGRAM STRUCT.KEYID
    break;
    case KEYID NO ENCRYPT:
         <<Write
         DATA KEY='0,
         TWEAK KEY='0,
         ENCRYPTION MODE=NO ENCRYPTION,
         to MKTME KEY TABLE at index TMP KEY PROGRAM STRUCT.KEYID
         >>
         break;
     }
RAX = 0;
RFLAGS.ZF = 0;
//Release Lock
KEY TABLE LOCK (RELEASE);
EXIT:
RFLAGS.CF=0;
RFLAGS.PF=0;
RFLAGS.AF=0;
RFLAGS.OF=0;
RFLAGS.SF=0;
end of flow
  6.2.6
            Flags Affected
   ZF
                       Cleared if instruction completes successfully.
                       Set if error occurred. RAX is set to the error code.
   CF, PF, AF, OF, SF
                       Cleared.
```



6.2.7 Use of Prefixes

LOCK Causes #UD

REP* Cause #UD (includes REPNE/REPNZ and REP/REPE/REPZ)

Operand size Causes #UD VEX Causes #UD

Segment overrides Ignored
Address size Ignored
REX Ignored

6.2.8 Protected Mode Exceptions

#UD If any of the LOCK/REP/OSIZE/VEX prefixes are used.

If current privilege level is not 0.

If CPUID.7.0:EDX[18] = 0.

If in VMX non-root mode and VMCS.PCONFIG_ENABLE = 0.

#GP(0) If input value in EAX encodes an unsupported leaf.

If the IA32_TME_ACTIVATE MSR is not locked.

If hardware encryption and MKTME capability are not enabled in

the IA32_TME_ACTIVATE MSR.

If memory operand is not 256B aligned.

If any of the reserved bits in MKTME KEY PROGRAM STRUCT

are set.

If a memory operand effective address is outside the DS

segment limit.

#PF(fault code) If a page fault occurs in accessing memory operands.

6.2.9 Real-Address Mode Exceptions

#UD If any of the LOCK/REP/OSIZE/VEX prefix is used.

If current privilege level is not 0.

If $CPUID.7.0:EDX[PCONFIG_BIT] = 0$.

If in VMX non-root mode and VMCS.PCONFIG_ENABLE = 0.

#GP(0) If input value in EAX encodes an unsupported leaf.

If IA32_TME_ACTIVATE MSR is not locked.

If hardware encryption and MKTME capability are not enabled in

IA32 TME ACTIVATE MSR.

If memory operand is not 256B aligned.

If any of the reserved bits in MKTME_KEY_PROGRAM_STRUCT

are set



6.2.10 Virtual-8086 Mode Exceptions

#UD PCONFIG instruction is not recognized in virtual-8086 mode

6.2.11 Compatibility Mode Exceptions

Same exceptions as in protected mode.

6.2.12 64-Bit Mode Exceptions

#UD If any of the LOCK/REP/OSIZE/VEX prefix is used.

If current privilege level is not 0.

If CPUID.7.0:EDX[18] = 0

If in VMX non-root mode and VMCS.PCONFIG ENABLE = 0.

#GP(0) If input value in EAX encodes an unsupported leaf.

If the IA32_TME_ACTIVATE MSR is not locked.

If hardware encryption and MKTME capability are not enabled in

the IA32_TME_ACTIVATE MSR.

If memory operand is not 256B aligned.

If any of the reserved bits in MKTME_KEY_PROGRAM_STRUCT

are set.

If a memory operand is non-canonical form.

#PF(fault code) If a page fault occurs in accessing memory operands.



7 Software Life Cycle: Managing Pages with KeyID

7.1 Overview

As mentioned earlier in the document, the KeyID is an integral part of the physical address, meaning it is not only present in page tables but is also present in the TLB, caches, etc. Therefore, software needs be aware of this and must take appropriate steps to maintain correctness of operations and security.

Note that while this section focuses on virtualization scenarios, the TME and MKTME architecture is applicable to both native OS and virtualized environments, and for DRAM and NVRAM types of memory.

7.2 Restrictions and Cache Management

The hardware/CPU does not enforce coherency between mappings of the same physical page with different KeyIDs or encryption keys. System software is responsible for carefully managing the caches in regard to usage of key identifiers (KeyIDs) and maintaining cache coherency when the KeyID or a key associated with a physical page is changed by the software. Specifically, the CPU will treat two physical addresses that are identical except for the KeyID bits as two different physical addresses though these two addresses reference the same location in memory. Software must take necessary steps to ensure that this does not result in unpredictable or incorrect behavior, or violate security properties desired. MKTME retains the existing behavior of the caches and TLB for the entire physical address including the KeyID portion of the physical address and expects software to properly flush the caches and/or perform TLB shootdowns.

The sections below are intended to give examples of algorithms that shouldn't be used by software to ensure correctness and security. Please check the final version of this specification for any updated algorithms or requirements in this area.

7.3 General Software Guidance for Dealing with Aliased Address Mappings

The following list details some general guidelines for OS/VMM software vendors to consider when using MKTME with more than the default single KeyID.

- 1. Software should avoid mapping the same physical address with multiple KeyIDs.
- 2. If software must map the same physical address with multiple KeyIDs, it should mark those pages as read-only, except for one KeyID.
- 3. If software must map the same physical address with multiple KeyIDs as read-write, then software must ensure that all writes are done with a single KeyID (this includes locked and non-locked writes that do not modify the data).



7.4 AddPage: Associating a KeyID to a Page

The following algorithm should be used by the OS/VMM when assigning a new KeyID to a physical page.

- 1. Program a new key for the KeyID, if not already programmed (using the PCONFIG instruction).
- 2. Map the physical page to the VMM's address space (with the new KeyID) by updating its paging structure entries (IA-PT), if not already mapped.
- 3. Ensure that the step 1 has successfully completed.
- 4. Zero-page contents via the new mapping (with new KeyID) to avoid data leakage between KeyID domains.
- 5. Make the page available to a new VM with the new KeyID set in the EPT page-table entry.

This will ensure against data leakage between KeyID domains, such as VMs with KeyIDs, when the KeyID is changed for a physical page (but the data is in clear in the CPU caches). The assumption is that before using this algorithm to assign a new KeyID, the software/VMM makes sure that the page was evicted correctly from the previous KeyID (using the algorithm defined in the next section).

Note: Guidance for usage of the PCONFIG instruction: PCONFIG is package scope and hence software is expected to execute PCONFIG on one LP on each package/socket. Software can use CPUID Leaf 0BH to determine the topology of the system which will indicate the physical packages present on the system.

7.5 EvictPage: Disassociating a KeyID from a Page

The following algorithm should be used by the OS/VMM when changing the KeyID of a physical page so that the current KeyID is no longer used with the page.

- 1. Steps to be completed before changing the KeyID:
 - a) Make the physical page not accessible to the VM (by updating the EPT page-table entry).
 - b) Invalidate all page mappings/aliases (the INVEPT instruction and IOMMU (VT-d) invalidation if page was mapped as device accessible) from the TLB (across the logical processors, with the old KeyID).
 - c) Map the page to VMM address space (with the old KeyID) by updating its paging structure entries (IA-PT) if not already mapped.
 - d) OS/VMM flushes dirty cache lines (for page using old KeyID) to prevent aliasing overwrite/data corruption.
 - Options: CLFLUSH, CLWB+fence, CLFLUSHOPT+fence or WBINVD.
 - Software can optionally avoid doing these flushes if it tracks page modification using EPT page-modification logging or accessed and dirty flags for EPT (optimization).
- 2. The page is now ready to be used with a new KeyID (example, using steps in the previous section).



This will ensure that no cache lines aliased by physical address exist in the CPU caches when the KeyID of the physical page is changed.

Note: Guidance for usage of the WBINVD instruction: The WBINVD instruction should be run on each socket if those invalidate all coherent caches on the sockets.

7.6 Paging by OS/VMM Example

Below is an example of a software sequence where the OS/VMM is reallocating a page from VM2 to VM3. VM2 memory uses KeyID2, and VM3 memory uses KeyID3.

- 1. Evict a page with KeyID2 from VM2 using the EvictPage algorithm described in section 7.5.
- 2. The OS/VMM reads the evicted page with KeyID2, encrypts the page contents with the Full Disk Encryption key (optional), and writes the page to disk/stores on a swap file (or in OS/VMM memory, using the VMM KeyID=0).
- 3. Add the evicted page to VM3 KeyID3 using the AddPage algorithm in section 7.4.

7.7 OS/VMM Access to Guest Memory

The OS/VMM can access guest memory (in clear) for emulation purposes (MMIO) by setting the guest KeyID bits in its paging structure entries (IA-PT).

7.8 I/O Interactions

The OS/VMM can use the TME key (KeyID=0) to set up shared memory between the Guest VM and the VMM as needed for I/O purposes. For directed I/O (e.g., SR-IOV), the OS/VMM should program the KeyID as part of the physical addresses in IOMMU (VT-d) page tables corresponding to the KeyID as part of the physical addresses in EPT (for the Guest VM). This will allow DMAs to be able to access memory in clear without requiring changes to I/O devices and/or I/O drivers in the guest VM or OS/VMM.