MACRO-80 3.35 Page

0000'

Title FDC MK I CONTROL ROUTINES
subttl Version DS 2.2 13/11/80

00001

.Z80 ASEG ORG 0100H .Comment \*

Author: R. Cowderoy

Copyright (C) 1980 R. Cowderoy, P. D. Curtis and Dondene Ltd.

For use with the Henelec Disk Controller card with Nascom 1 or 2 or RICZ80 computer.

## Ammendment notes:

- 1) Format changed to 11 bytes in L6 for use with Pertek drives. Bytes sent to disk changed to OCO8H. PC & RC typed DRH 2/11/80. Changed to OCOOH DRH 26/11/80
- 2) Conditional assembly for D-DOS added. DRH 5/11/80.
- Jumps to LDDRS and LDCMD added to jump table.
   DRH 5/11/80.
- 4) Side select, drive select and track select separated in LDDRS, DRSEL and SEEKTR, PC & RC typed DRH 12/11/80.
- 5) Conditional assembly for RAM at 8800H added.
  DRH 16/11/80.
- 6) Format bytes changed to COOH.
  DRH 2/12/80

This document is disclosed as a 'Trade secret' supplied for the purposes of debugging faults within the Henelec Disk System. Disclosure of part or all of this document to a third party without the express permission of the copyright holders is an infringement of the terms of the supply agreement.

	CONTROL ROUTINES DS 2.2 13/11/80	MACRO-80 3.35 Page 1-1
0100		
		Conditional assembly. Allows assembly for RICZ80 or NASCOM with either CP/M or D-DOS V1.0.
FFFF		TRUE EQU OFFFFH
0000		FALSE EQUINOT TRUE
FFFF		NASCOM EQUITRUE
0000		RICZ80 EQU FALSE
FFFF		CPM EQU TRUE
0000		DDOS EQUIFALSE
0000 FFFF		RAM EQU FALSE EPROM EQU TRUE
FFFF		EPROM EQUITRUE
		; PIO port addresses  IF NASCOM
		;FDC data port
0004		DPORT EQU 4
9009		DCNTRL EQU 6
AAA=		; FDC control port
0005		CPORT EQU 5
0007		CCNTRL EQU 7
	•	ENDIF
	• .	IF RICZ80
		; FDC data port
		DPORT EQU 20H
		DCNTRL EQU 21H
		; FDC control port
		CPORT EQU 22H
	.•	CCNTRL EQU 23H ENDIF
		f Ohio mode and to hit of A 7 1 1
0000		; Chip mask set to bits 6 & 7 input CPMASK EQU OCOH
		; Origins of CPM and D-DOS
F400		CPMORG EQU 0F400H
B400		EDOSORG EQU 08400H
8C00		RDOSORG EQU OBCOOH
		; Data table set up in first 10H bytes defines
		; the configuration of the system.
	•	IF CPM
E400	00 0000	+PHASE CPMORG
r400	C3 0000	ORIGIN: JP 0
TANO	0.6.40	CPM workspace
F403	0048	WSPACE: DEFW 0048H ENDIF
		IF DDOS AND RAM

IF DDOS AND RAM
•PHASE RDOSORG-400H

```
Version DS 2.2 13/11/80
                                ORIGIN: JP ROOSORG
                                : D-DOS workspace
                                WSPACE: DEFW OCOBH
                                        ENDTE
                                        IF DDOS AND EPROM
                                        *PHASE EDOSORG-400H
                                ORIGIN: JP EDOSORG
                                ; D-DOS workspace
                                WSPACE: DEFW OCOBH
                                        ENDIF
 F405
         1000
                                ISTACK: DEFW 1000H
 F407
         1000
                                EOOTST: DEFW 1000H
                                ; Format buffer
 F409
         1000
                                FMTBUF: DEFW 1000H
                                : Maximum number of drives
 F40B
         03
                                DRIVES: DEFB 3
                                ; Maximum number of tracks per side
 F40C
         23
                                TRACKS: DEFB 35
                                : Number of retries
 F40D
         05
                                NTRY: DEFB 5
                                        IF NASCOM
                                ; Timer delay count
 F40E
         FO
                                TDEL: DEFB OF OH
                                        ENDIF
                                ; Timer delay count
                                        IF RICZ80
                                TDEL:
                                        DEFB 90H
                                        ENDIF
                                ; Sides flag. O for single, 1 for double
 F40F
         01
                                DELS: DEFB 1
                                ; Jump table gives the DNLY legal access points
                                ; to the FDC software
 F410
         C3 F670
                                        JP READ
 F413
         C3 F6A5
                                        JP WRITE
 F416
         C3 F431
                                        JP INIT
 F419
         C3 F6DA
                                        JP FORMAT
 F41C
         C3 F7A1
                                        JP WRBOOT
 F41F
                                        JP SEEKTR
         C3 F573
 F422
         C3 F604
                                        JP RDENTR
 F425
         C3 F639
                                        JP WRENTR
 F428
         C3 F524
                                        JP DRSEL
 F428
         C3 F507
                                        JP LDDRS
 F42E
         C3 F46A
                                        JP LDCMD
                                ; Set data port to input
 F431
         CD F457
                                INIT: CALL IMODE
 F434
         3E FF
                                        LD A.OFFH
                                ; Set control port lines to 1
 F436
         D3 05
                                        OUT (CPORT),A
                                ; Set control port to bit mode
```

MACRO-80 3.35

Page 1-2

FDC MK I CONTROL ROUTINES

```
FDC MK I CONTROL ROUTINES
                                MACRO-80 3.35
                                                    Page
                                                           1-3
Version DS 2.2 13/11/80
 F438
          D3 07
                                         OUT (CCNTRL),A
                                ; Set up control port
 F43A
          3E CO
                                        LD A.CPMASK
 F43C
          D3 07
                                        OUT (CCNTRL).A
                                ; Set drive select to 0
 F43E
          AF
                                        XOR A
 F43F
         CD F507
                                        CALL LDDRS
                                : Start motors
 F442
         CD F4E3
                                        CALL MSTART
                                ; Master reset line to 0
 F445
         3E 2F
                                        LD A, 2FH
 F447
         D3 05
                                        OUT (CPORT),A
                                ; Delay
 F449
         06 20
                                        LD B,20H
 F44B
         05
                                RSLOOP: DEC B
 F44C
         C2 F44B
                                        JP NZ.RSLOOP
                                ; Master reset line to 1
 F44F
         3E 3F
                                        LD A.3FH
 F451
         D3 05
                                        OUT (CPORT).A
                                ; Wait until command done
 F453
         CD F4C4
                                        CALL WAITBY
 F456
         C9
                                        RET
                                ; Subroutine to set data port to bit input mode
 F457
         F5
                                IMODE: PUSH AF
                                ; Set to bit mode
 F458
         3E FF
                                        LD A, OFFH
 F45A
         D3 06
                                        OUT (DCNTRL),A
                                ; Set all bits to input
 F45C
         D3 06
                                        OUT (DCNTRL),A
 F45E
         F1
                                        POP AF
F45F
         C9
                                        RET
                               ; Subroutine to set data port to bit output mode
F460
         F5
                               OMODE: PUSH AF
                               ; Set to bit mode
F461
         3E FF
                                       LD A, OFFH
F463
         D3 04
                                       OUT (DCNTRL),A
                               ; Set all bits to output
F465
         AF
                                       XOR A
F466
        D3 06
                                       OUT (DCNTRL), A
F468
        F1
                                       POP AF
F469
        C9
                                       RET
                               ; Subroutine to load contents of A reg to
                               ; FDC command req
003C
                               CMDREG EQU 3CH
F46A
        F5
                               LDCMD: PUSH AF
                               ; Select command reg
F46B
        3E 3C
                                       LD A, CMDREG
F46D
        D3 05
                                       OUT (CPORT),A
F46F
        CD F460
                                       CALL OMODE
F472
        F1
                                       POP AF
```

```
FDC MK I CONTROL ROUTINES
                                MACRO-80 3.35
                                                    Page 1-4
Version DS 2.2 13/11/80
                                : Send command to data port
 F473
         2F
                                         CPL
 F474
         D3 04
                                        OUT (DPORT),A
                                : Pulse write enable
 F476
          3E 34
                                         LD A, CMDREG-8
 F478
         D3 05
                                         OUT (CPORT),A
 F47A
         F6 08
                                         OR 8
 F47C
         D3 05
                                         OUT (CPORT).A
                                ; Set data port back to input
 F47E
         CD F457
                                         CALL IMODE
 F481
         C9
                                        RET
                                ; Subroutine to load E reg into FDC sector reg
 003E
                                SECREG EQUI 3EH
                                ; Select sector reg
 F482
         3E 3E
                                LDSEC: LD A.SECREG
 F484
         D3 05
                                        OUT (CPORT).A
 F486
         CD F460
                                        CALL OMODE
 F489
         7B
                                        LD A,E
 F48A
         2F
                                        CPL
 F48B
         D3 04
                                        OUT (DPORT),A
                                ; Pulse write enable
 F48D
         3E 36
                                        LD A, SECREG-8
 F48F
         D3 05
                                        OUT (CPORT),A
 F491
         F6 08
                                        OR 8
 F493
         D3 05
                                        OUT (CPORT),A
 F495
         CD F457
                                        CALL
                                                IMODE
 F498
         C9
                                        RET
                                ; Subroutine to read FDC status reg to A reg
 003C
                                STAREG EQU 3CH
                                ; Select status reg
 F499
         3E 3C
                                ROSTAT: LD A.STAREG
 F49B
         D3 05
                                        OUT (CPORT).A
 F49D
         CD F457
                                        CALL IMODE
                                ; Read enable to 0
 FAAO
         3E 38
                                        LD A.STAREG-4
 F4A2
         D3 05
                                        OUT (CPORT),A
                                ; Read status reg
 F4A4
         DB 04
                                        IN A, (DPORT)
 F4A6
         2F
                                        CPL
                                ; Set flags
 F4A7
         87
                                        OR A
 F4A8
         F5
                                        PUSH AF
                                ; Read enable to 1
 F4A9
         3E 3C
                                        LD A, STAREG
 F4AB
         D3 05
                                        OUT(CPORT),A
 F4AD
         F1
                                        POP AF
 F4AE
         C9
                                        RET
                                ; Subroutine to read FDC track reg to A reg
 003D
                                TRKREG EQU 3DH
```

```
FDC MK I CONTROL ROUTINES
                                MACRO-80 3.35
                                                    Page
                                                           1-5
Version DS 2.2 13/11/80
                                 ; Select track req
 F4AF
          3E 3D
                                 RDTRK: LD A.TRKREG
 F481
          D3 05
                                         OUT (CPORT),A
 F483
          CD F457
                                        CALL IMODE
                                 : Read enable to 0
 F486
          3E 39
                                        LD A, TRKREG-4
 F4B8
          D3 05
                                         OUT (CPORT),A
                                 ; Read track reg
 F4BA
          DB 04
                                        IN A, (DPORT)
 F4BC
          2F
                                        CPL
 F4ED
          F5
                                        PUSH AF
                                 ; Read enable to 1
 F4BE
          3E 3D
                                        LD A.TRKREG
 F4C0
          D3 05
                                         OUT (CPORT).A
 F4C2
          F1
                                        POP
                                                 AF
 F4C3
          C9
                                        RET
                                 : Subroutine to check that drive motor is on
                                 ; and that busy flag = 0
 F4C4
          CD F499
                                 WAITBY: CALL ROSTAT
 F4C7
          F2 F4CD
                                         JP P, MOTON
                                 ; Start motors
 F4CA
          CD F4E3
                                 MSTRT: CALL MSTART
 F4CD
          CD F499
                                MOTON: CALL ROSTAT
                                 ; Restart motors
 F4D0
          FA F4CA
                                        JP M, MSTRT
                                 ; Busy bit to Carry flag
 F403
          1F
                                        rra
 F4D4
          DA F4CD
                                         JP C, MOTON
 F4D7
          C9
                                 ; Subroutine to check if command has timed out
                                 ; If so reset FDC using force interrupt
                                 ; FDC FORCE INTERRUPT
 0000
                                FRCINT EQU ODOH
                                 Return if top bit = 0
 F4D8
          B7
                                 TIMOUT: OR A
 F4D9
          FO
                                        RET P
 F4DA
          3E D0
                                        LD A.FRCINT
                                 ; Reset FDC busy bit
 F4DC
          CD F46A
                                        CALL LDCMD
                                 ; Load timeout error code
 F4DF
          3E 80
                                        LD A,80H
 F4E1
          B7
                                         OR A
 F4E2
          C9
                                        RET
                                 ; Subroutine to turn on drive motors
                                 ; Dummy WRITE to turn on motors
 F4E3
          CD F482
                                MSTART: CALL LDSEC
 F4E6
         E5
                                        PUSH HL
                                ; Delay for 1 second
 F4E7
          21 03E8
                                        LD HL,1000
 F4EA
          CD F560
                                        CALL MSEC
```

gradien aus

```
Version DS 2.2 13/11/80
```

Part of the second of the seco

```
F4ED
        E1
                                       POP HL
F4EE
        C9
                                       RET
                               ; Subroutine to load A to FDC track reg
F4EF
        F5
                               LDTRK: PUSH AF
                               ; Select track reg
        3E 3D
F4F0
                                       LD A, TRKREG
F4F2
        03 05
                                       OUT (CPORT),A
F4F4
        CD F460
                                       CALL OMODE
F4F7
        F1
                                       POP AF
F4F8
        2F
                                       CPL
F4F9
        D3 04
                                       OUT (DPORT),A
                               ; Pulse write enable
F4FB
        3E 35
                                       LD A, TRKREG-8
F4FD
        D3 05
                                       OUT (CPORT),A
F4FF
        3E 3D
                                       LD A.TRKREG
F501
        D3 05
                                       OUT (CPORT).A
F503
        CD F457
                                       CALL IMODE
F506
        C9
                               ; Subroutine to load A to FDC Drive select req
F507
        E5
                               LDDRS: PUSH HL
F508
        2A F403
                                       LD HL, (WSPACE)
                               ; A reg to workspace
F50B
        77
                                       LD (HL).A
F50C
        E1
                                       POP HL
F50D
        F5
                                       PUSH AF
F50E
        3E 3F
                                       LD A,3FH
F510
        D3 05
                                       OUT (CPORT),A
F512
        CD F460
                                       CALL OMODE
F515
        F1
                                       POP AF
F516
        D3 04
                                       OUT (DPORT).A
                               ; Pulse drive select load
        3E 1F
F518
                                       LD A,1FH
F51A
        D3 05
                                       OUT (CPORT).A
F51C
        3E 3F
                                       LD A,3FH
F51E
        03 05
                                       OUT (CPORT),A
F520
        CD F457
                                       CALL IMODE
F523
        C9
                                       RET
                               ; Subroutine to select drive specified in C req
                               ; Current drive number stored in WSPACE
                               ; Drive numbers are 0, 2 or 4.
                               ; Subroutine will read new track number from
                               ; the drive
F524
        E5
                               DRSEL: PUSH HL
                               ; Get current drive number
F525
        2A F403
                                      LD HL, (MSPACE)
F528
        7E
                                      LD A, (HL)
                               ; Remove side select bit
F529
        E6 FE
                                       AND OFEH
F528
        B9
                                       CP C
F52C
        CA F550
                                       JP Z, SAMEDR
```

```
FDC MK I CONTROL ROUTINES
                                 MACRO-80 3.35
                                                    Page
                                                          1-7
Version DS 2.2 13/11/80
                                 ; Get number of drives
  F52F
          3A FAOR
                                         LD A, (DRIVES)
                                 ; Correct max drive number
  F532
          07
                                         RLCA
  F533
          30
                                         DEC A
                                 ; Compare against new drive number
 F534
          89
                                         CP C
 F535
          D2 F53D
                                         JP NC, DNUMOK
                                ; Load drive select fail code
 F538
          3E 1F
                                SLFAIL: LD A, 1FH
 F53A
         B7
                                         OR A
 F53B
         E1
                                        POP HL
 F53C
         C9
                                        RET
                                ; Store new drive number
         79
 F53D
                                DNUMOK: LD A.C
                                ; Load drive select reg
 F53E
         CD F507
                                        CALL LDDRS
                                : 100 mS delay
 F541
         21 0064
                                        LD HL,100
 F544
         CD F560
                                        CALL MSEC
                                ; Get address of buffer for read addess
 F547
         2A F403
                                        LD HL, (WSPACE)
 F54A
         23
                                        INC HL
 F54B
         23
                                        INC HL
                                ; Load read address command
 F54C
         3E C0
                                        LD A, OCOH
 F54E
         CD F604
                                        CALL RDENTR
 F551
         C2 F538
                                        JP NZ, SLFAIL
                                ; Get current track number
 F554
         2A F403
                                        LD HL, (MSPACE)
 F557
         23
                                        INC HL
 F558
         23
                                        INC HL
F559
         7F
                                        LD A, (HL)
                               ; Load this to FDC track req
F55A
         CD F4EF
                                        CALL LDTRK
F550
         E1
                               SAMEDR: POP HL
F55E
         AF
                                       XOR A
F55F
        C9
                                       RET
                               ; Timing subroutine
                               Delay number of millisecs specified in HL
F560
        C5
                               MSEC:
                                      PUSH BC
                               ; Adjust TDEL for 1 mS
F561
        3A F40E
                               MS1:
                                       LD A. (TDEL)
F564
        47
                                       LD B.A
F565
        05
                               MS2:
                                       DEC B
F566
        0E 00
                                       LD C.O
F568
        C2 F565
                                       JP NZ, MS2
F56B
        28
                                       DEC HL
F56C
        7C
                                       LD A,H
F56D
        85
                                       OR L
F56E
        C2 F561
                                       JP NZ, MS1
F571
        C1
                                       POP BC
```

```
FDC MK I CONTROL ROUTINES
                                MACRO-80 3.35
                                                   Page 1-8
Version DS 2.2 13/11/80
  F572
         C9
                                        RET
                                ; Subroutine to perform seek command to
                                ; track specified in D reg
  003F
                                DATREG EQU 3FH
  001F
                                SEEKCM EQU 1FH
  000F
                                RESTOR EQU OFH
 F573
         C5
                                SEEKTR: PUSH BC
                                C reg holds side number
 F574
          0E 00
                                        LD
                                               C,0
                                ; Get number of tracks on disk
 F576
         3A F40C
                                        LD A. (TRACKS)
                                ; Correct max track number
 F579
          3D
                                        DEC A
                                : Compare against requested track
 F57A
         BA
                                        CP D
         D2 F591
 F578
                                        JP NC, SIDE
 F57E
          47
                                        LD B.A
                                ; Test for double sided drive
 F57F
          3A F40F
                                        LD A, (DBLS)
 F582
                                        OR A
         B7
                                ; Jump if single sided
 F583
         CA F5CF
                                        JP Z, TOOBIG
                                ; Calculate new track number for second side
 F586
         7A
                                        LD A,D
 F587
          90
                                        SUB B
 F588
         30
                                        DEC A
                                ; Check that new number < tracks per side
 F589
          0E 01
                                        LD C;1
  F58B
         57
                                        LD D,A
 F58C
         78
                                        LD A.B
 F58D
         ĐΑ
                                        CP D
                                ; Jump if too big
 F58E
         DA F5CF
                                        JP C, TOOBIG
 F591
                                SIDE: PUSH HL
 F592
         2A F403
                                        LD HL, (MSPACE)
                                ; Get drive number
 F595
         46
                                        LD B. (HL)
 F596
         E1
                                        POP HL
 F597
         78
                                        LD A,B
 F598
         E6 01
                                        AND 1
 F59A
                                        CP C
         B9
 F59B
         CA F5AD
                                        JP Z,CPTRK
 F59E
         78
                                        LD A.B
                                ; Get drive number
 F59F
         E6 FE
                                        AND OFEH
                                ; Add side select bit
 F5A1
         81
                                        OR C
 F5A2
         CD F507
                                        CALL LDDRS
 F5A5
         E5
                                        PUSH HL
                                ; Delay for side select to settle
 F5A6
         21 0001
                                        LD HL,1
 F5A9
         CD F560
                                        CALL MSEC
```

```
Page
Version DS 2.2 13/11/80
  F5AC
          F1
                                         POP HL
  F5AD
          C1
                                 CPTRK: POP BC
  F5AE
          CD F4AF
                                         CALL ROTRK
                                         SUB D
  F5E1
          92
                                 ; Already on correct track
  F5B2
          C8
                                         RET Z
                                 ; Look for new track
  F5B3
          CD F5D4
                                         CALL SEEKS
                                 : Return if seek ok
  F586
          C8
                                         RET Z
                                 ; Return if drive not ready
  F587
          F8
                                         RET M
                                 ; Seek failed, do a reseek
                                 ; Restore to track 0
  F5E8
          3E OF
                                 RESEEK: LD A.RESTOR
          CD F46A
  F5BA
                                         CALL LDCMD
                                 ; Wait for head to home
  F5ED
          DB 05
                                 RWAIT: IN A. (CPORT)
  F5EF
          E6 40
                                         AND 40H
                                 ; Wait for IRQ
  F5C1
          CA F5BD
                                         JP Z, RWAIT
  F5C4
          CD F499
                                         CALL ROSTAT
  F5C7
          CD F4D8
                                         CALL TIMOUT
  F5CA
          F8
                                         RET M
                                 : Try again
  F5CB
          CD F504
                                         CALL SEEKS
          C9
  F5CE
                                         RET
  F5CF
                                 TOOBIG: POP BC
          C1
                                 ; Load error code for invalid track
  F500
          3E 10
                                         LD A, 10H
  F5D2
          B7
                                         OR A
  F503
          C9
                                         RET
                                 : Seek new track
  F5D4
          CD F4C4
                                 SEEKS: CALL WAITBY
                                 ; Select data reg
  F5D7
          3E 3F
                                         LD A, DATREG
  F5D9
          D3 05
                                         OUT (CPORT),A
          CD F460
 F5DB
                                         CALL OMODE
  F5DE
          7A
                                         LD A,D
  F50F
          2F
                                         CPL
  F5E0
          D3 84
                                         OUT (DPORT),A
                                 ; Pulse write enable
 F5E2
          3E 37
                                         LD A, DATREG-8
  F5E4
          D3 05
                                         OUT (CPORT),A
  F5E6
          F6 08
                                         OR 8
  F5E8
          D3 05
                                         OUT (CFORT),A
  F5EA
          CD F457
                                         CALL IMODE
                                 ; Send a seek command
  F5ED
          3E 1F
                                         LD A, SEEKCM
          CD F46A
  F5EF
                                         CALL LDCMD
 F5F2
          DB 05
                                 SWAIT: IN A, (CPORT)
                                 ; Mask out IRQ input
```

MACRO-80 3.35

1-9

FDC MK I CONTROL ROUTINES

```
FDC MK I CONTROL ROUTINES
                                MACRO-80 3.35
                                                    Page
                                                         1-10
Version DS 2.2 13/11/80
 F5F4
         E6 40
                                         AND 40H
                                : Wait until IRQ = 1
 F5F6
          CA F5F2
                                         JP Z, SWAIT
                                 ; Read status
 F5F9
          CD F499
                                         CALL RDSTAT
                                ; Mask error bits
 F5FC
          E6 98
                                         AND 98H
                                ; Check for timeout
 F5FE
          CD F4D8
                                         CALL TIMOUT
 F601
          C9
                                        RET
                                 ; Subroutine to read a sector from the current
                                 ; track into memory
                                  On entry:
                                     Sector number = E
                                     Buffer start = HL
                                 : On exit:
                                     End of buffer = HL
                                     FDC status
                                                    = A
  0088
                                RDCMD EQU 88H
                                 ; Read sector comand to A reg
          3E 88
  F602
                                ROSECT: LD A, ROCMD
                                ; Entry point for other read commands
 F604
          C5
                                ROENTR: PUSH BC
 F605
          F5
                                         PUSH AF
 F606
          CD F4C4
                                         CALL WAITBY
 F609
          06 3F
                                        LD B, DATREG
 F60B
          0E 3B
                                         LD C, DATREG-4
                                 ; Load FDC sector reg
          CD F482
 F60D
                                         CALL LDSEC
                                 : Retrieve command
 F610
          F1
                                         POP AF
                                 ; Load command to FDC
 F611
          CD F46A
                                         CALL LDCMD
 F614
          78
                                         LD A,B
  F615
          D3 05
                                         OUT (CPORT),A
 F617
          DB 05
                                 RDWAIT: IN A, (CPORT)
                                 ; Mask DRQ and INTRQ
  F619
          E6 C0
                                         AND OCOH
                                 ; Loop if no requests
  F61B
          CA F617
                                         JP Z, ROWAIT
                                 ; Jump if INTRQ
  F61E
          F2 F62F
                                         JP P, RDIRQ
  F621
          79
                                         LD A,C
                                 ; FDC read enable to 0
  F622
          D3 05
                                         OUT (CPORT),A
                                 ; Read data byte
          DB 04
  F624
                                         IN A, (DPORT)
  F626
          2F
                                         CPL
                                 ; Store in buffer
  F627
          77
                                         LD (HL),A
  F628
          78
                                         LD A,B
                                 ; FDC read enable to 1
```

```
FDC MK I CONTROL ROUTINES
                                MACRO-80 3.35
                                                    Page
                                                         1-11
Version DS 2.2 13/11/80
 F629
          D3 05
                                        OUT (CPORT).A
 F62B
          23
                                        INC HL
 F62C
          C3 F617
                                        JP ROWAIT
 F62F
          CD F499
                                RDIRQ: CALL RDSTAT
                                ; Check for timeout
 F632
          CD F4D8
                                        CALL TIMOUT
 F635
         C1
                                        POP
                                                BC
 F636
         C9
                                        RET
                                ; Subroutine to write from memory to sector
                                ; on current track
                                 On entry:
                                     Sector number = E
                                     Buffer start = H
                                 : On exit:
                                     Buffer finish = HL
                                     FDC status
 00A8
                                WRCMD EQUIDABH
                                ; Write sector command to A reg
 F637
          3E A8
                                WRSECT: LD A, WRCMD
                                ; Entry point for other write commands
 F639
         C5
                                WRENTR: PUSH BC
 F63A
         F5
                                        PUSH AF
 F63B
         CD F4C4
                                        CALL WAITBY
 F63E
         06 3F
                                        LD B.DATREG
 F640
         0E 37
                                        LD C, DATREG-8
                                ; Load FDC sector reg
 F642
         CD F482
                                        CALL LDSEC
                                ; Retrieve command
 F645
         F1
                                        POP AF
                                ; Load write command to FDC command reg
 F646
         CD F46A
                                        CALL LDCMD
                                ; Set DPORT to output mode
 F649
         CD F460
                                        CALL OMODE
 F64C
         78
                                        LD A.B
                                ; Set CPORT to address FDC data reg
 F64D
         03 05
                                        OUT (CPORT),A
                                ; Get a data byte
                                WBYTEL: LD A, (HL)
 F64F
         7E
 F650
         23
                                        INC HL
 F651
         2F
                                        CPL
                                ; Output the data to DPORT
 F652
         D3 N4
                                        OUT (DPORT),A
 F654
         DB 05
                                WRWAIT: IN A, (CPORT)
                                ; Mask DRQ and INTRQ
 F656
         E6 C0
                                        AND OCOH
                                ; Loop if no requests
 F658
         CA F654
                                        JP Z,WRWAIT
                                ; Jump if INTRQ
 F65B
         F2 F667
                                        JP P.WRIRQ
                                ; Set FDC write enable to 0
 F65E
         79
                                        LD A,C
 F65F
         D3 05
                                        OUT (CPORT),A
```

```
FDC MK I CONTROL ROUTINES
                                 MACRO-80 3.35
                                                    Page
                                                          1-12
Version DS 2.2 13/11/80
                                 ; Set FDC write enable to 1
 F661
          78
                                         LD A.B
 F662
          D3 05
                                         OUT (CPORT).A
 F664
          C3 F64F
                                                 WBYTEL
                                         JP
                                 : Read FDC status
 F667
          CD F499
                                 WRIRG: CALL ROSTAT
                                 ; Check for timeout
 F66A
          CD F4D8
                                         CALL TIMOUT
 F66D
         C1
                                         POP BC
                                 ; Correct buffer pointer
 F66E
          28
                                         DEC HL
 F66F
         C9
                                         RET
 F670
         CD F524
                                 READ:
                                         CALL DRSEL
 F673
         CO
                                         RET NZ
 F674
         CD F573
                                         CALL SEEKTR
 F677
         CO
                                         RET NZ
 F678
         C5
                                         PUSH BC
                                 ; Save buffer start
 F679
         E5
                                         PUSH HL
 F67A
         3A F40D
                                         LD A. (NTRY)
 F67D
          47
                                        LD B,A
 F67E
          0E 02
                                         LD C,2
                                 ; Start of buffer
 F680
         E1
                                RFLOOP: POP HL
 F681
         E5
                                        PUSH HL
 F682
         CD F602
                                         CALL RDSECT
                                ; Jump if read ok
 F685
         CA F6A0
                                         JP Z, RDEXIT
                                 ; Jump if motor off
 F688
         FA F6A1
                                         JP M.RFEXIT
 F68B
         05
                                        DEC B
                                 ; Try again
 F68C
         C2 F680
                                         JP NZ, RFLOOP
 F68F
         OD
                                        DEC C
 F690
         CA F6A1
                                         JP Z, RFEXIT
                                 : Reset heads to track 0
 F693
         CD F5B8
                                        CALL RESEEK
 F696
         C2 F6A1
                                         JP NZ, RFEXIT
 F699
         3A F40D
                                        LD A, (NTRY)
 F69C
         47
                                        LD B,A
                                 ; Try reading again
 F69D
         C3 F680
                                         JP RFLOOP
 F6A0
         E3
                                ROEXIT: EX (SP),HL
 F6A1
         E1
                                RFEXIT: POP HL
 F6A2
         C1
                                        POP BC
                                 ; Set flags
 F6A3
         B7
                                        OR A
 F6A4
         C9
                                        RET
 F6A5
         CD F524
                                WRITE: CALL DRSEL
 F6A8
         CO
                                        RET NZ
 F6A9
         CD F573
                                        CALL SEEKTR
```

```
FDC MK I CONTROL ROUTINES
                                MACRO-80 3.35
                                                    Page
                                                          1-13
Version DS 2.2 13/11/80
 F6AC
          CO
                                         RET NZ
 F6AD
          C5
                                         PUSH BC
 F6AE
         E5
                                         PUSH HL
 F6AF
          3A F40D
                                         LD A, (NTRY)
 F682
          47
                                         LD B.A
 F683
          0E 02
                                         LD C.2
 F685
         E1
                                 WFLOOP: POP HL
 F686
         E5
                                         PUSH HL
                                         CALL WRSECT
 F687
         CD F637
                                 ; Exit if write ok
 F6BA
         CA F6D5
                                        , JP Z, WREXIT
                                 ; Exit if motor off
 F6BD
         FA F6D6
                                         JP M, WFEXIT
 F6C0
          05
                                         DEC B
 F6C1
         C2 F6B5
                                         JP NZ,WFLOOP
 F6C4
          00
                                         DEC C
 F6C5
         CA F6D6
                                         JP Z.WFEXIT
                                 : Restore to track 0
 F608
          CD F5B8
                                         CALL RESEEK
                                 : Exit if seek fails
 F6CB
         C2 F6D6
                                         JP NZ, WFEXIT
 F6CE
         3A F40D
                                         LD A, (NTRY)
 F6D1
          47
                                         LD B,A
                                         JP WFLOOP
 F6D2
         C3 F685
 F6D5
         E3
                                WREXIT: EX (SP), HL
 F606
         E1
                                WFEXIT: POP HL
 F6D7
         C1
                                         POP BC
                                 ; Set flags
 F608
         87
                                         OR A
 F6D9
         C9
                                         RET
                                 ; Subroutine to format disk
                                 ; Track addresses from 0 to TRACKS
                                 ; Sector addresses from 1 to 18
 005B
                                STEPIN EQU 58H
 F6DA
         CD F431
                                FORMAT: CALL INIT
                                 ; Load initial track address
 F6DD
         16 00
                                        LD D.0
                                 ; Load initial sector address
 F6DF
         1E 01
                                TRACKL: LD E,1
                                ; Set up memory image of track data
 F6E1
         2A F409
                                         LD HL, (FMTBUF)
                                ; 14 bytes to FF
 F6E4
         3E 0E
                                         LD A,14
 F6E6
         36 FF.
                                         LD (HL), OFFH
                                L1:
 F6E8
         23
                                         INC HL
 F6E9
         3D
                                         DEC A
 F6EA
         C2 F6E6
                                         JP NZ,L1
                                ; 6 bytes to 0 for sync
 F6ED
         3E 06
                                SECTL: LD A,6
 F6EF
         36 00
                                L2:
                                        LD (HL),0
```

```
FDC MK I CONTROL ROUTINES
                                MACRO-80 3.35
                                                    Page 1-14
Version DS 2.2 13/11/80
 F6F1
         23
                                        INC HL
 F6F2
         3D
                                        DEC A
         C2 F6EF
 F6F3
                                        JP NZ,L2
                                ; ID address mark
 F6F6
         36 FE
                                        LD (HL), OFEH
 F6F8
         23
                                        INC HL
                                ; Track address
 F6F9
         72
                                        LD (HL),D
 F6FA
         23
                                        INC HL
 F6FB
         36 00
                                        LD (HL),0
 F6FD
         23
                                        INC HL
                                : Sector address
 F6FE
         73
                                        LD (HL).E
 F6FF
         23
                                        INC HL
 F700
         36 00
                                        LD (HL),0
         23
 F702
                                        INC HL
                                ; ID field CRC
 F703
         36 F7 ·
                                        LD (HL), OF7H
 F705
         23
                                        INC HL
                                ; 11 bytes to FF
 F706
         3E 0B
                                        LD A,11
         36 FF
 F708
                                L4:
                                        LD (HL), OFFH
 F70A
         23
                                        INC HL
 F70B
         30
                                        DEC A
         C2 F708
 F70C
                                        JP NZ,L4
                                ; 6 bytes to 0 for sync
 F70F
         3E 06
                                        LD A.6
         36 00
 F711
                                L3:
                                        LD (HL),0
 F713
         23
                                        INC HL
 F714
         3D
                                        DEC A
 F715
         C2 F711
                                        JP NZ.L3
                                ; Data address mark
 F718
         36 FB
                                        LD (HL), OFBH
 F71A
         23
                                        INC HL
                                ; 128 bytes data field
 F71B
         3E 80
                                        LD A,128
         36 E5
 F710
                                L5:
                                        LD (HL), 0E5H
 F71F
         23
                                        INC HL
 F720
         30
                                        DEC A
         C2 F71D
 F721
                                        JP NZ,L5
                                ; Data field CRC
 F724
         36 F7
                                        LD (HL), OF7H
 F726
         23
                                        INC HL
                                ; 11 bytes to FF
 F727
         3E 0B
                                        LD A,11
 F729
         36 FF
                                L6;
                                        LD (HL), OFFH
 F72B
         23
                                        INC HL
 F72C
         3D
                                        DEC A
 F72D
         C2 F729
                                        JP NZ,L6
                                ; Increment sector counter
 F730
         10
                                        INC E
                                ; Test for 18th sector
 F731
         7B
                                        LD A,E
```

```
FDC HK I CONTROL ROUTINES
                                 MACRO-80 3.35
                                                    Page
Version DS 2.2 13/11/80
 F732
         FE 13
                                         CP 19
                                 ; More to do, so round again
 F734
          C2 F6ED
                                         JP NZ, SECTL
                                 ; 255 bytes to FF. End of track gap
 F737
          3E FF
                                         LD A.255
 F739
          36 FF
                                L7:
                                         LD (HL), OFFH
 F73B
          23
                                         INC HL
 F73C
          3D
                                         DEC A
 F73D
          C2 F739
                                         JP NZ.L7
                                 ; Write the data using the write track command
 F740
          3A F40F
                                         LD A, (DBLS)
                                 SDLP:
 F743
         F5
                                         PUSH AF
                                 ; Side select
 F744
          CD F507
                                         CALL LDDRS
 F747
          2A F409
                                         LD HL, (FMTBUF)
                                 ; Write entire track command
 F74A
          3E F4
                                         LD A.OF4H
                                 ; Write it
 F74C
         CD F639
                                         CALL WRENTR
 F74F
          87
                                         OR A
                                 ; Return if error in write
 F750
         CO
                                         RET NZ
 F751
         E5
                                         PUSH HL
          2A F409
 F752
                                         LD HL, (FMTBUF)
                                 ; Check that OCOO bytes have been written
 F755
          01 OC00
                                         LD BC, OCOOH
 F758
          09
                                         ADD HL,BC
 F759
          4D
                                         LD C,L
 F75A
          44
                                         LD B,H
 F75B
         E1
                                         POP HL
 F75C
         7D
                                         LD A,L
 F75D
          91
                                         SUB C
 F75E
         7C
                                         LD A.H
 F75F
          98
                                         SBC A,B
          DA F781
 F760
                                         JP C, FERR
 F763
         F1
                                         POP AF
 F764
         B7
                                         OR A
                                 ; Jump if side select = 0
 F765
         CA F76C
                                         JP Z,SDNXT
 F768
          3D
                                         DEC A
 F769
          C3 F743
                                         JP SDLP
 F76C
         14
                                 SDNXT: INC D
 F76D
          3A F40C
                                         LD A, (TRACKS)
          92
 F770
                                         SUB D
 F771
         C8
                                         RET Z
 F772
          3E 5B
                                NEXTTR: LD A.STEPIN
          CD F46A
 F774
                                         CALL LDCMD
 F777
         DB 05
                                STWAIT: IN A, (CPORT)
 F779
         E6 40
                                         AND 40H
 F778
         CA F777
                                         JP Z,STWAIT
 F77E
         C3 F6DF
                                         JP TRACKL
 F781
         F1
                                FERR:
                                       POP AF
```

```
FDC MK I CONTROL ROUTINES
                                MACRO-80 3.35
                                                    Page
                                                           1-16
Version DS 2.2 13/11/80
                                ; Format error code
 F782
          3E FF
                                         LD A, OFFH
 F784
          C9
                                         RET
                                ; Bootstrap program
                                ; Reads sector 1 of track 0 into memory then
                                ; jumps to it
 F785
          2A F405
                                START: LD HL, (ISTACK)
 F788
         F9
                                        LD SP,HL
                                ; NAS-SYS set up call
 F789
         CD 000D
                                        CALL 000DH
                                ; Set up drives
 F78C
         CD F431
                                        CALL INIT
                                ; Set drive 0
 F78F
          0E 00
                                        LD C,0
                                ; Sector 1 track 0
 F791
         11 0001
                                        LD DE,1
 F794
          2A F407
                                        LD HL, (BOOTST)
 F797
          CD F670
                                        CALL READ
                                ; Try again if read fails
 F79A
         C2 F785
                                        JP NZ, START
 F79D
         2A F407
                                        LD HL, (BOOTST)
                                ; Jump to bootstrap
 F7A0
         E9
                                        JP (HL)
                                ; Subroutine to write bootstrap to disk
 F7A1
         CD F431
                                WREOOT: CALL INIT
 F7A4
         0E 00
                                        LD C,0
 F7A6
         11 0001
                                        LD DE,1
 F7A9
         2A F407
                                        LD HL, (BOOTST)
 F7AC
         CD F6A5
                                        CALL WRITE
 F7AF
         C9
                                        RET
 F7B0
         20 43 4F 50
                                        DEFM " COPYRIGHT (C) DONDENE LTD. 1980 "
 F784
         59 52 49 47
 F7B8
         48 54 20 28
 F7BC
         43 29 20 44
 F7C0
         4F 4E 44 45
 F7C4
         4E 45 20 4C
 F7C8
         54 44 2E 20
 F7CC
         31 39 38 30
 F7D0
         20
```

\*DEPHASE

END

Version DS 2.2 13/11/80									
Macros:									
Symbols	:								
BOOTST	F407	CCNTRL	0007	CMDREG	003C	CPM	FFFF		
CPYASK	00C0	CPMORG	F400	CPORT	0005	CPTRK	F5AD		
DATREG	003F	DBLS	F40F	DCNTRL	0006	odos	0000		
DWUHOK	F53D	DPORT	0004	DRIVES	F40B	DRSEL	F524		
EDOSOR	B400	EPROM	FFFF	FALSE	0000	FERR	F781		
FMTBUF	F409	FORMAT	F6DA	FRCINT	00D0	INODE	F457		
TINI	F431	ISTACK	F405	L1	F6E6	L2	F6EF		
L3	F711	L4	F708	L5	F71D	L6	F729		
L.7	F739	LDCMD	F46A	LDDRS	F507	LDSEC	F482		
LDTRK	F4EF	мотом	F4CD	MS1	F561	MS2	F565		
MSEC	F560	MSTART	F4E3	MSTRT	F4CA	NASCOM	FFFF		
NEXTTR	F772	NTRY	F40D	OMODE	F460	ORIGIN	F400		
ram	0000	rdcmd	0088	RDENTR	F604	RDEXIT	F6A0		
RDIRQ •	F62F	rdosor	8000	RDSECT	F602	RDSTAT	F499		
RDTRK	F4AF	RDWAIT	F617	read	F670	reseek	F5B8		
RESTOR	000F	RFEXIT	F6A1	RFLOOP	F680	RICZ80	0000		
rsloop	F44B	RNAIT	F580	Samedr	F55D	SDLP	F743		
SDNXT	F76C	SECREG	003E	SECTL	F&ED	SEEKCM	001F		
SEEKS	F5D4	SEEKTR	F573	SIDE	F591	SLFAIL	F538		
STAREG	003C	START	F785	STEPIN	005B	STWAIT	F777		
SWAIT	F5F2	TDEL	F40E	TUONIT	F4D8	TOOBIG	F5CF		
TRACKL	F6DF	Tracks	F40C	TRKREG	003D	TRUE	FFFF		
WAITBY	F4C4	WBYTEL	F64F	WFEXIT	F6D6	WFL00P	F6B5		

MACRO-80 3.35

Page

No Fatal error(s)

WRBOOT F7A1

WRIRQ F667

WSPACE F403

WRCMD

WRITE

8A00

F6A5

WRENTR F639

WRSECT F637

WREXIT F6D5

WRWAIT F654

FDC MK I CONTROL ROUTINES