AIRCRAFT AND SIMULATOR SETUP

1.	Time	As Chosen
2.	Weather	As Chosen
3.	A/C Position	As Chosen
	IF FLYING ON IVAO	
	a. A/C Position	Free of other traffic
	b. IVAO Pilot Client	Connect
4.	EFB > Fenix > MY FLIGHTS	Import Flight Plan
5.	A/C Refueling / Boarding / Loading	Initiate / Completed
C	OCKPIT INSPECTION	
1.	ADIRS	OFF
2.	Gear Lever	DOWN
3.	Thrust Levers	IDLE
4.	ENG Master Switches	OFF
5.	ENG Mode Selector	NORM
6.	Spoilers	RETRACTED
7.	Flaps	UP
8.	PARKING BRK	ON
9.	Weather Radar & PWS	Both OFF
10	. XPDR	STBY
11	. TCAS	ABV & STBY
12	EXT PWR	Check green AVAIL
	IF EXT PWR NOT AVAILABLE	

a. EFB > Fenix > GROUND SERVICES Enable GPU

COCKPIT PREPARATION

1. BAT 1 & 2	
2. EXT PWR	
3. PFD / ND / UPPER and LOWER ECAM	
4. Internal Lights	
OVERHEAD PANEL 5. ADIRS 1/2/3	
6. OXYGEN CREW SUPPLY	
7. FUEL PUMPS L / CTR / R	
8. STROBE Light	
9. EMER EXIT LT	
10. NO SMOKING Light	
11. SEAT BELTS Light	
PEDESTRAL	
12. Frequencies	Set
13. PA	
14. Weather Radar & PWS	
15. ATIS	•
a. QNH	•
MCDU	
16. ENG Model & NAV DATA BASE	Check
17. INIT Page 1	
IF FLYING ON IVAO	
a. IFR Clearance	Obtained
b. FCU ALT SELECT	Set Initial Climb
c. XPDR	Set Squawk
18. F-PLN Page	Enter
a. Check and Remove Discontinuities	
b. SID and STAR	Verify Constraints
19. RAD NAV Page	Verify Frequencies
Once A/C Loading Completed	
20. INIT Page 2	Set
a. Fuel Quantity	Verify Sufficient
21. PROG Page	Set
a. Altitudes	Vanife.
	verity
b. Emergency Runway	•
	Enter
b. Emergency Runway	Enter Set
b. Emergency Runway	Enter Set Calculate in EFB > Departure Perf

BEFORE START

1.	PARKING BRK	Verify ON
2.	BEACON Light	ON
3.	NAV & LOGO Lights	ON
4.	APU Fire TEST	Verify
5.	ENG 1 Fire TEST	Verify
6.	ENG 2 Fire TEST	Verify
7.	APU Start	
	a. APU MASTER SW	ON
	ONCE ECAM 2 SHOWS APU Parameters	
	b. APU START	ON
	ONCE APU START GREEN AVAIL ILLUMINATED	
	c. APU BLEED	ON
8.	EXT PWR	OFF
P	PUSHBACK & ENGINE START	
1.	A/C Refueling / Boarding / Loading	
1.		Verify ON
1.	A/C Refueling / Boarding / LoadingAPU BLEED	Verify ON
1. 2.	A/C Refueling / Boarding / LoadingAPU BLEED	Verify ON As Required / Obtained
1. 2. 3. 4.	A/C Refueling / Boarding / Loading	Verify ON As Required / Obtained Noted
1. 2. 3. 4.	A/C Refueling / Boarding / Loading	Verify ON As Required / Obtained Noted Perform / Follow Instructions
1. 2. 3. 4. 5.	A/C Refueling / Boarding / Loading	Verify ON As Required / Obtained Noted Perform / Follow Instructions
1. 2. 3. 4. 5.	A/C Refueling / Boarding / Loading	
1. 2. 3. 4. 5.	A/C Refueling / Boarding / Loading	As Required / Obtained Noted Perform / Follow Instructions Verify IDLE
1. 2. 3. 4. 5.	A/C Refueling / Boarding / Loading	As Required / Obtained Noted Perform / Follow Instructions Verify IDLE IGN / START ON
1. 2. 3. 4. 5.	A/C Refueling / Boarding / Loading	As Required / Obtained Noted Perform / Follow Instructions Verify IDLE IGN / START ON MONITOR
1. 2. 3. 4. 5.	A/C Refueling / Boarding / Loading	As Required / Obtained Noted Perform / Follow Instructions Verify IDLE IGN / START ON MONITOR Wait for AVAIL

BEFORE TAXI

Completed	Pushback	1. P
01	PARKING BRK	2. P
LOCH	COCKPIT DOOR	3. C
As Required	FLAPS	4. F
ARMEI	Spoilers	5. S
1 or :	Weather Radar	6. V
AUTO	PWS	7. P
F/CTL Page	ECAM	8. E
As Required	a. PITCH TRIM	а
Free and Correc	b. Flight Controls	b
Deactivate	c. ECAM F/CTL Page	С
MA	AUTO BRK	9. A
Activate	Flight Director (FD)	10. F
TAX	NOSE Light	11. N
OI	RWY TURN OFF Light	12. R
OFI	APU BLEED	13. A
OFI	APU MASTER SW	14. A
As Required / Obtained	Taxi Clearance	15. T

TAXI

1.	PARKING BRK	OFF
2.	Brakes	Check
3.	TO Config	Push
4.	UPPER ECAM T.O Memo	Check No Warnings / No Blue besides CABIN
	a CARIN item will become READY during taxi roll	_

BEFORE TAKEOFF

1.	PARKING BRK	ON
2.	Initial Climb Altitude	Verify
3.	QNH	Verify
4.	ND	Set Desired Range
5.	Radio Frequencies	Set / Verify
6.	Crew Briefing	Completed
7.	Squawk	Verify
8.	XPDR	ON
9.	TCAS	ABV & TA or TA/RA
	IF FLYING ON IVAO	
	a. IVAO Pilot Client TCAS	ON
	b. IVAO Pilot Client XPDR	Verify ALT and Correct Squawk
10.	NOSE Light	то
11.	LAND Lights	ON
12.	RWY TURN OFF Lights	OFF
13.	PACK 1 & 2	OFF
14.	Takeoff Clearance	As Required / Obtained
	CLEARED FOR 1	TAKEOFF
15.	Start Time	Noted
16.	Clock	Start
17.	PARKING BRK	OFF
T	AKEOFF	
1.	Thrust Levers	FLEX or TOGA
2	Floyator Control	Potate at Vr (less than 9.5 Degrees Pitch)

Normal Procedures

AFTER TAKEOFF / CLIMB

4	Landing Cook (at positive rate of climb, may 200 I/T)	UD
	Landing Gear (at positive rate of climb, max 220 KT)	
	A/THR	•
4.		
т. 5.		
	PACK 1 & 2	• .
	QNH (at Transition Altitude / when prompted)	
	Spoilers	. ,
	LAND LT and NOSE LT (after passing FL 100)	
	SEAT BELTS (calm air, after pitch < 7.5 degrees)	
	ND	
	RUISE	
1.	TOD	Monitor
2.	Destination Data (when prompted)	Enter
	BEFORE TOD	
3.	FCU ALT SELECT Se	t Procedure / Assigned Altitude
	AT TOD	
4.	ALT SELECT KNOB	Initiate Descent
	a. Push (for managed descent, following planned profile)	
	b. Pull (for open descent, when vectored by ATC)	
D	ESCENT	
1.	TCAS Mode	BLW
2.	Destination Data	Verify / Set
3.	Arrival Performance	Calculate in EFB > Arrival Perf
	a. Landing Weight = GW - (Current FOB - EFOB at Destination (MCDL	J FUEL PRED Page))
4.	AUTO BRK	As Required
5.	SEAT BEALTS	As Required
	WHEN PASSING FL 100	
6.	NOSE LT and LAND LT	ON
7.	SEAT BELTS	ON
	AT TRANSITION ALTITUDE	
8.	QNH	Set Local
	For Simulator Use Only	Page 6

APPROACH

	MCDU > PERF > APPR MODELS		
	CLEARED FOR ILS APP		
3.	LOC Mode	Enable	
4.	APPR Mode	Enable	
5.	Landing Gear (max 250 KT)	DOWN	
6.	Flaps	Set According to Speed	
7.	Spoilers	ARMED	
	UPPER ECAM LDG Memo		
	QNH	-	
10	. AUTO BRK	Verify Set	
L	LANDING		
1.	Landing Clearance	As Required / Obtained	
2.	AP 1 & 2	According to Desired Landing Mode	
3.	Approach Speed	Monitor	
	AT RETARD CALLO	DUT	
4.	Thrust Lever	IDLE	
5.			
	Initiate Flare		
	Initiate Flare		
G	O AROUND		
_		TOGA	
1.	O AROUND		
1. 2.	O AROUND Thrust Lever	UP	

AFTER LANDING

1.	REVERSE THRUST	As Required			
	CLEAR OF RWY				
2.	PARKING BRK	ON			
3.	Flaps	UP			
4.	Spoilers	RET			
5.	Weather Radar & PWS	OFF			
6.	XPDR	OFF			
7.	TCAS	ABV & STBY			
8.	LS Mode	Disable			
9.	Clock	Stop			
10.	. LDG LT	OFF			
11.	. NOSE LT	TAXI			
12.	. RWY TURNOFF LT	ON			
13.	. APU	As Required / Start			
	a. Do not turn on APU BLEED				
14.	. Taxi Clearance	As Required / Obtained			
15.	. PARKING BRK	OFF			
P	ARKING				
	PARKING BRK				
	Thrust Lever				
	NOSE LT & RWY TURNOFF LT				
4.	ENG 1 & 2 Master	OFF			
5.	Deboarding	Start (EFB Message)			
6.	STROBE LT	OFF			
7.	BEACON LT	OFF			
8.	NAV & LOGO LT	OFF			
9.	SEAT BELTS	OFF			
10.	EXT PWR	As Required			
11.	. Wait until Deboarding Complete				

SHUTDOWN

1.	ADIRS 1/2/3	OFF
2.	OXYGEN CREW SUPPLY	OFF
3.	FUEL PUMPS L / CTR / R	OFF
4.	NO SMOKING	OFF
5.	EMER EXIT LT	OFF
6.	APU & EXT PWR	OFF
7.	BAT 1 & 2	OFF